| How to read this list: | |
|---|---|
| **Mark** | **Description** |
| X | Function is supported. |
| * | Function is added or developed newly |

# Function List

| Automaker: | DAIHATSU |
|---|---|
| **Software Version:** | **V1.21** |

| Automaker | Region | Year | Model | Vehicle Type | ECU Type | System | ECU Supplier | Sys. Info. | Read Code | Clear Code | Data Stream | Actuations | Special Functions |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| DAIHATSU | JAPAN | | | | | Engine1 | | | X | X | X | X | |
| DAIHATSU | JAPAN | | | | | Engine2 | | | * | * | * | * | |
| DAIHATSU | JAPAN | | | | | Engine3 | | | * | * | * | * | |
| DAIHATSU | JAPAN | | | | | AT | | | X | X | X | | |
| DAIHATSU | JAPAN | | | | | ABS | | | X | X | X | | |
| DAIHATSU | JAPAN | | | | | SRS | | | X | X | | | |
| DAIHATSU | JAPAN | | | | | EPS | | | X | X | X | | |
| DAIHATSU | JAPAN | | | | | IMM | | | X | X | | | |