TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD CHECK MODE PILOT QUANTITY LEARNING PILOT QUANTITY LEARNING(DETAIL) PRESSURE DISCHARGE CLACE CHECK LEARNING VALUES CONFIRMATION
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MANUAL TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	GENERAL	POWER TRAIN	ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	GENERAL	POWER TRAIN	ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	GENERAL	POWER TRAIN	ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	PARTS EXCHANGE
TOYOTA	GENERAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION RESET MEMORY INSPECTION MODE
TOYOTA	GENERAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			HV-BATTERY INITIALIZATION ONBOARD EQUALIZING CHARGE
TOYOTA	GENERAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	GENERAL	POWER TRAIN	HYBRID GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	GENERAL	POWER TRAIN	SEQUENTIAL M/T			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	POWER TRAIN	CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	GENERAL	POWER TRAIN	E-ACM			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	GENERAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	GENERAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	GENERAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	GENERAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	GENERAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	GENERAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	GENERAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	GENERAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	GENERAL	CHASSIS	TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	CHASSIS	TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	CHASSIS	TRACTION CONTROL SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	GENERAL	CHASSIS	FOUR WHEEL DRIVE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY
TOYOTA	GENERAL	CHASSIS	AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	CHASSIS	AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
TOYOTA	GENERAL	CHASSIS	AHC&AIR SUSPENSION			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	GENERAL	CHASSIS	EMS			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	CHASSIS	STABILIZER			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	CHASSIS	EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	GENERAL	CHASSIS	EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	GENERAL	CHASSIS	TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	GENERAL	CHASSIS	TPMS(WIRELESS CHECK)	PACIFIC SENSOR		TPMS(WIRELESS CHECK)							TMPS SENSOR STATUS READ TMPS ID REGISTRATION
TOYOTA	GENERAL	CHASSIS	VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
TOYOTA	GENERAL	CHASSIS	ARS			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	CHASSIS	ELECTRIC PARKING BRAKE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY
TOYOTA	GENERAL	CHASSIS	PARKING ASSIST MOTOR			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	CHASSIS	KDSS			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	IPA			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	GENERAL	BODY	AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	GENERAL	BODY	ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	GENERAL	BODY	ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	GENERAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	GENERAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	GENERAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	GENERAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	GENERAL	BODY	SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	GENERAL	BODY	SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	GENERAL	BODY	THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
TOYOTA	GENERAL	BODY	GATEWAY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	GENERAL	BODY	GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
TOYOTA	GENERAL	BODY	GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	GENERAL	BODY	ECM GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
TOYOTA	GENERAL	BODY	ECB GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
TOYOTA	GENERAL	BODY	PM1 GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
TOYOTA	GENERAL	BODY	PM2 GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
TOYOTA	GENERAL	BODY	NAVIGATION SYSTEM			OBD-II 16PIN CONNECTOR	O	O					MAP INFORMATION SOFTWARE ERROR HISTORY OPTICAL DISC ERROR HISTORY
TOYOTA	GENERAL	BODY	ACCESSORY GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	GENERAL	BODY	MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	GENERAL	BODY	BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	GENERAL	BODY	BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	BODY	CENTER CONSOLE SWITCH			OBD-II 16PIN CONNECTOR			O	O			
TOYOTA	GENERAL	BODY	REAR CONSOLE SWITCH			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	BODY	TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	BODY	COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	BODY	COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	BODY	COMBINATION SW			OBD-II 16PIN CONNECTOR			O				
TOYOTA	GENERAL	BODY	STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	BODY	STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR			O				
TOYOTA	GENERAL	BODY	MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	MIRROR			OBD-II 16PIN CONNECTOR			O	O			
TOYOTA	GENERAL	BODY	MIRROR L			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	BODY	RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	BODY	RAIN SENSOR			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	GENERAL	BODY	WIPER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	AFS			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	BODY	POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	BODY	ELECTRIC POWER CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	BODY	PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	BODY	PRE-CRASH			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	BODY	OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	GENERAL	BODY	NIGHT VIEW			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	GENERAL	BODY	FREE-TRONIC			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	BODY	STARTING CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	DOOR & SEAT	PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	DOOR & SEAT	BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	DOOR & SEAT	PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	DOOR & SEAT	DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR LEFT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR LEFT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR RIGHT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR RIGHT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	DRIVER SEAT SW			OBD-II 16PIN CONNECTOR			O				
TOYOTA	GENERAL	DOOR & SEAT	DRIVER SEAT SW			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR SEAT SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	GENERAL	DOOR & SEAT	FRONT LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	FRONT RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	REAR RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	GENERAL	DOOR & SEAT	SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	GENERAL	DOOR & SEAT	RETRACTABLE HARDTOP			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MANUAL TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	POWER TRAIN	ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	JAPAN LOCAL	POWER TRAIN	ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	JAPAN LOCAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION RESET MEMORY INSPECTION MODE
TOYOTA	JAPAN LOCAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			HV-BATTERY INITIALIZATION ONBOARD EQUALIZING CHARGE
TOYOTA	JAPAN LOCAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	POWER TRAIN	HYBRID GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	JAPAN LOCAL	POWER TRAIN	SEQUENTIAL M/T			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	JAPAN LOCAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	JAPAN LOCAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	JAPAN LOCAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	JAPAN LOCAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	JAPAN LOCAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	JAPAN LOCAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	JAPAN LOCAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	JAPAN LOCAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	JAPAN LOCAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	JAPAN LOCAL	CHASSIS	TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	CHASSIS	TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	CHASSIS	TRACTION CONTROL SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	JAPAN LOCAL	CHASSIS	FOUR WHEEL DRIVE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY
TOYOTA	JAPAN LOCAL	CHASSIS	AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	CHASSIS	AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	JAPAN LOCAL	CHASSIS	AHC&AIR SUSPENSION			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	JAPAN LOCAL	CHASSIS	EMS			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	CHASSIS	STABILIZER			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	CHASSIS	EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	JAPAN LOCAL	CHASSIS	EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	JAPAN LOCAL	CHASSIS	TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	JAPAN LOCAL	CHASSIS	VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
TOYOTA	JAPAN LOCAL	CHASSIS	ARS			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	CHASSIS	ELECTRIC PARKING BRAKE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY
TOYOTA	JAPAN LOCAL	BODY	IPA			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	JAPAN LOCAL	BODY	AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	JAPAN LOCAL	BODY	ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
TOYOTA	JAPAN LOCAL	BODY	ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	JAPAN LOCAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	JAPAN LOCAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	JAPAN LOCAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	JAPAN LOCAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	JAPAN LOCAL	BODY	SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	JAPAN LOCAL	BODY	SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	JAPAN LOCAL	BODY	THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
TOYOTA	JAPAN LOCAL	BODY	GATEWAY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	JAPAN LOCAL	BODY	GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
TOYOTA	JAPAN LOCAL	BODY	GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	JAPAN LOCAL	BODY	ECM GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
TOYOTA	JAPAN LOCAL	BODY	ECB GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
TOYOTA	JAPAN LOCAL	BODY	PM1 GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
TOYOTA	JAPAN LOCAL	BODY	PM2 GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
TOYOTA	JAPAN LOCAL	BODY	NAVIGATION SYSTEM			OBD-II 16PIN CONNECTOR	O	O					MAP INFORMATION SOFTWARE ERROR HISTORY OPTICAL DISC ERROR HISTORY
TOYOTA	JAPAN LOCAL	BODY	ACCESSORY GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	JAPAN LOCAL	BODY	MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	JAPAN LOCAL	BODY	BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	JAPAN LOCAL	BODY	BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	BODY	CENTER CONSOLE SWITCH			OBD-II 16PIN CONNECTOR			O	O			
TOYOTA	JAPAN LOCAL	BODY	REAR CONSOLE SWITCH			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	BODY	TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	BODY	COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	JAPAN LOCAL	BODY	COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	BODY	COMBINATION SW			OBD-II 16PIN CONNECTOR			O				
TOYOTA	JAPAN LOCAL	BODY	STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	BODY	STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR			O				
TOYOTA	JAPAN LOCAL	BODY	MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	MIRROR			OBD-II 16PIN CONNECTOR			O	O			
TOYOTA	JAPAN LOCAL	BODY	MIRROR L			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	BODY	RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	BODY	RAIN SENSOR			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	JAPAN LOCAL	BODY	WIPER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	AFS			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	BODY	POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	BODY	PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	PRE-CRASH			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	BODY	OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	JAPAN LOCAL	BODY	NIGHT VIEW			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	BODY	FREE-TRONIC			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	DOOR & SEAT	DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR LEFT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR LEFT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR RIGHT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR RIGHT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	DRIVER SEAT SW			OBD-II 16PIN CONNECTOR			O				
TOYOTA	JAPAN LOCAL	DOOR & SEAT	DRIVER SEAT SW			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR SEAT SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	JAPAN LOCAL	DOOR & SEAT	FRONT LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	FRONT RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	REAR RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	JAPAN LOCAL	DOOR & SEAT	RETRACTABLE HARDTOP			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	VZN130	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 3-VZE	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 22R-E(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 22R-E(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	4RUNNER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 22R-E(1992)	17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	4RUNNER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	4RUNNER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	4RUNNER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	4RUNNER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	4RUNNER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	4RUNNER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	4RUNNER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	4RUNNER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	4RUNNER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	4RUNNER		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	4RUNNER		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	4RUNNER		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	4RUNNER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	4RUNNER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	4RUNNER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	4RUNNER		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	4RUNNER		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	4RUNNER		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
TOYOTA	4RUNNER		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	4RUNNER		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	4RUNNER		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	4RUNNER		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALPHARD		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	ALPHARD		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	ALPHARD		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	ALPHARD		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	ALPHARD		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	ALPHARD		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	ALPHARD		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALPHARD		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	ALPHARD		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	ALPHARD		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	ALPHARD		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	ALPHARD		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	ALPHARD		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALPHARD		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALPHARD		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	ALPHARD		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION RESET MEMORY INSPECTION MODE
TOYOTA	ALPHARD		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALPHARD		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	ALPHARD		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			HV-BATTERY INITIALIZATION ONBOARD EQUALIZING CHARGE
TOYOTA	ALPHARD		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALPHARD		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	ALPHARD		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	ALPHARD		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	ALPHARD		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	ALPHARD		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	ALPHARD		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	ALPHARD		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	ALPHARD		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	ALPHARD		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	ALPHARD		EMS			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALPHARD		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	ALPHARD		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	ALPHARD		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	ALPHARD		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	ALTIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALTIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	ALTIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	ALTIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	ALTIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	ALTIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	ALTIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALTIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	ALTIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	ALTIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	ALTIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	ALTIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	ALTIS		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALTIS		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALTIS		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	ALTIS		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION RESET MEMORY INSPECTION MODE
TOYOTA	ALTIS		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALTIS		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	ALTIS		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			HV-BATTERY INITIALIZATION ONBOARD EQUALIZING CHARGE
TOYOTA	ALTIS		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	ALTIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	ALTIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	ALTIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	ALTIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	ALTIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	ALTIS		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	ALTIS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	ALTIS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	ALTIS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	AVALON		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVALON		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVALON		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVALON		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVALON		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVALON		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	AVALON		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVALON		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVALON		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVALON		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVALON		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVALON		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	AVALON		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MCX10	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	AVALON		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	AVALON		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	AVALON		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	AVALON		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	AVALON		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	AVALON		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	AVALON		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	AVALON		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	AVALON		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	AVALON		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	AVALON		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	AVALON		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	AVALON		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	AVALON		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	AVALON		TRACTION CONTROL SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	AVALON		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVALON		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
TOYOTA	AVALON		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	AVALON		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	AVALON		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	AVALON		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	AVALON		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	AVALON		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	AVALON		GATEWAY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	AVALON		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
TOYOTA	AVALON		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVALON		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	AVALON		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVALON		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVALON		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVALON		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	AVALON		MIRROR L			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVALON		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	AVALON		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVALON		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	AVALON		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE(K3-VE)	OBD-II 16PIN CONNECTOR	O		O	O		O	RESET MEMORY
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVANZA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	AVANZA		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	AVANZA		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	AVANZA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	AVANZA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	AVANZA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	AVANZA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O			O	INITIALIZATION OF IMMOBILIZER REGISTRATION OF NEW KEYS
TOYOTA	AVANZA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	AVANZA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	AVANZA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	AVANZA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	AVANZA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	AVANZA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	AVENSIS		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT220 LHDDENSO EFI	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	AVENSIS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	AVENSIS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	AVENSIS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	AVENSIS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	AVENSIS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	AVENSIS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	AVENSIS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	AVENSIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	AVENSIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	AVENSIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	AVENSIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	AVENSIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	AVENSIS		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	AVENSIS		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	AVENSIS		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	AVENSIS		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	AVENSIS		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	AVENSIS		ELECTRIC PARKING BRAKE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY
TOYOTA	AVENSIS		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	AVENSIS		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVENSIS		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	AVENSIS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	AVENSIS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	AVENSIS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	AVENSIS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	AVENSIS		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	AVENSIS		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	AVENSIS		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
TOYOTA	AVENSIS		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	AVENSIS		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVENSIS		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	AVENSIS		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVENSIS		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	AVENSIS		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVENSIS		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	AVENSIS		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	AVENSIS		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	AVENSIS		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	AVENSIS		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	AVENSIS VERSO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	AVENSIS VERSO		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	AVENSIS VERSO		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	AVENSIS VERSO		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	AVENSIS VERSO		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	AVENSIS VERSO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	AVENSIS VERSO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	AVENSIS VERSO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	AVENSIS VERSO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	AVENSIS VERSO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	AVENSIS VERSO		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	AVENSIS VERSO		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	AVENSIS VERSO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	AVENSIS VERSO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	AVENSIS VERSO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	AVENSIS VERSO		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	AVENSIS VERSO		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	AVENSIS VERSO		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AVENSIS VERSO		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	AYGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AYGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	AYGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AYGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AYGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AYGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	AYGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AYGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AYGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	AYGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AYGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	AYGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	AYGO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	AYGO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	AYGO		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	AYGO		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	AYGO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	CAMRY		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CAMRY		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CAMRY		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CAMRY		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CAMRY		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CAMRY		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	CAMRY		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CAMRY		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CAMRY		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CAMRY		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CAMRY		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CAMRY		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	CAMRY		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 5S-FE(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CAMRY		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 5S-FE(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CAMRY		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 3VZ-FE(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CAMRY		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 3VZ-FE(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CAMRY		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 5S-FE(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CAMRY		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 5S-FE(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CAMRY		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 3VZ-FE(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CAMRY		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 3VZ-FE(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CAMRY		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	CAMRY		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	CAMRY		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CAMRY		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CAMRY		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CAMRY		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION RESET MEMORY INSPECTION MODE
TOYOTA	CAMRY		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CAMRY		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CAMRY		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			HV-BATTERY INITIALIZATION ONBOARD EQUALIZING CHARGE
TOYOTA	CAMRY		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CAMRY		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	CAMRY		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CAMRY		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CAMRY		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CAMRY		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CAMRY		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CAMRY		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	CAMRY		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CAMRY		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CAMRY		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	CAMRY		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	CAMRY		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	CAMRY		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CAMRY		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CAMRY		TRACTION CONTROL SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CAMRY		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	CAMRY		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	CAMRY		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	CAMRY		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	CAMRY		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	CAMRY		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	CAMRY		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CAMRY		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CAMRY		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CAMRY		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	CAMRY		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	CAMRY		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CAMRY		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CAMRY		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CAMRY		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CAMRY		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CAMRY		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CAMRY		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CAMRY		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CAMRY		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CAMRY		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CAMRY		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CAMRY		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CAMRY		PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CAMRY		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	CAMRY HYBRID		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CAMRY HYBRID		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O	O			TORQUE SENSOR ADJUSTMENT
TOYOTA	CARINA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT190 LEAN BURN	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CARINA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT190 WITH O2(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CARINA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT190 WITH O2(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CARINA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT190 W/O O2(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CARINA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT190 W/O O2(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CARINA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT191(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CARINA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT191(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CARINA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST191 3S-FE(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CARINA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST191 3S-FE(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CARINA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST191 3S-GE	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CARINA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CARINA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CELICA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELICA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	CELICA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CELICA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CELICA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CELICA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	CELICA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELICA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CELICA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CELICA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CELICA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CELICA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT180	17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT200	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST182(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST182(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST182 W/ O2(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST182 W/ O2(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST182 W/O O2(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST182 W/O O2(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST184(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST184(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST185	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST202 3S-FE -9508	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST202 3S-FE 9508-	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST202 3S-GE	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST204 5S-FE -9712(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST204 5S-FE -9712(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST204 5S-FE 9712-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST204 5S-FE 9712-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST205	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 3S-GTE	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 4A-FE	17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 5S-FE(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 5S-FE(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 7A-FE(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 7A-FE(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELICA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CELICA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	CELICA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CELICA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CELICA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	CELICA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	CELICA		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CELICA		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CELICA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	CELICA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	CELICA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	CELICA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CELICA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MANUAL TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELSIOR		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CELSIOR		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CELSIOR		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CELSIOR		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CELSIOR		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CELSIOR		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CELSIOR		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	CELSIOR		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CELSIOR		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CELSIOR		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	CELSIOR		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	CELSIOR		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CELSIOR		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CELSIOR		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	CELSIOR		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	CELSIOR		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	CELSIOR		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CELSIOR		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CELSIOR		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CELSIOR		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
TOYOTA	CELSIOR		GATEWAY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	CELSIOR		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
TOYOTA	CELSIOR		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		REAR LEFT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		REAR RIGHT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		REAR SEAT SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CELSIOR		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CELSIOR		STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CELSIOR		STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR			O				
TOYOTA	CELSIOR		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CELSIOR		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	COASTER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	COASTER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COASTER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COASTER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COASTER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COASTER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	COASTER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	COASTER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	COASTER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COASTER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COASTER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COASTER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	COASTER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	COASTER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	COASTER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	COASTER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	COASTER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	COASTER		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	COASTER		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CONDOR		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZF61	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CONDOR		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZF80	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CONDOR		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZF81,85	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CONDOR		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CONDOR		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	COROLLA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	COROLLA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COROLLA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COROLLA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COROLLA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COROLLA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	COROLLA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	COROLLA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COROLLA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COROLLA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COROLLA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	COROLLA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE101 4A-FE WITH O2 AU(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE101 4A-FE WITH O2 AU(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE101 4A-FE WITH O2 OT(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE101 4A-FE WITH O2 OT(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE101 4A-FE W/O O2(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE101 4A-FE W/O O2(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE101 4A-GE	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE102 WITH O2(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE102 WITH O2(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE102 W/O O2	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE103	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE110 -9704(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE110 -9704(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE110 9704-9910(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE110 9704-9910(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE110 9910-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE110 9910-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111 WITH O2 -9704(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111 WITH O2 -9704(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111 W/O O2 -9704(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111 W/O O2 -9704(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111 S/AFRI 9704-9910(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111 S/AFRI 9704-9910(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111 OTHER 9704-9910(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111 OTHER 9704-9910(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111 WITH O2 9910-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111 WITH O2 9910-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111 W/O O2 9910-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111 W/O O2 9910-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE112 WITH O2 -9704(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE112 WITH O2 -9704(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE112 W O2 9704-9910(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE112 W O2 9704-9910(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE112 WITH O2 9910-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE112 WITH O2 9910-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE112 W/O O2(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE112 W/O O2(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE115 -9704	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE115 9704-9910	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE92 SOUTH AFR(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE92 SOUTH AFR(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE101 -9505(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE101 -9505(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE101 9505-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE101 9505-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE101(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE101(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE104	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE111 -9704(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE111 -9704(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE111 9704-9910(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE111 9704-9910(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE111 9910-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EE111 9910-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 4A-FE(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 4A-FE(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 7A-FE(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	COROLLA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 7A-FE(MT)	17PIN RECTANGULAR CONNECTOR	O		O				

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	COROLLA		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	COROLLA		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	COROLLA		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	PARTS EXCHANGE
TOYOTA	COROLLA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	COROLLA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	COROLLA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	COROLLA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	COROLLA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	COROLLA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	COROLLA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	COROLLA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	COROLLA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	COROLLA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	COROLLA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	COROLLA		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	COROLLA		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	COROLLA		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	COROLLA		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	COROLLA		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	COROLLA		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	COROLLA		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	COROLLA		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	COROLLA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	COROLLA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	COROLLA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	COROLLA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	COROLLA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	COROLLA		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	COROLLA		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	COROLLA		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	COROLLA		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	COROLLA		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	COROLLA		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	COROLLA VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	COROLLA VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COROLLA VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COROLLA VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COROLLA VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COROLLA VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	COROLLA VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	COROLLA VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COROLLA VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COROLLA VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COROLLA VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COROLLA VERSO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	COROLLA VERSO		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	COROLLA VERSO		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	COROLLA VERSO		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	COROLLA VERSO		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	COROLLA VERSO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	COROLLA VERSO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	COROLLA VERSO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	COROLLA VERSO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	COROLLA VERSO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	COROLLA VERSO		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	COROLLA VERSO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	COROLLA VERSO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	COROLLA VERSO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	COROLLA VERSO		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	COROLLA VERSO		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	COROLLA VERSO		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	COROLLA/AURIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	COROLLA/AURIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	COROLLA/AURIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COROLLA/AURIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COROLLA/AURIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COROLLA/AURIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	COROLLA/AURIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	COROLLA/AURIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COROLLA/AURIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	COROLLA/AURIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COROLLA/AURIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	COROLLA/AURIS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	COROLLA/AURIS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	COROLLA/AURIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	COROLLA/AURIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	COROLLA/AURIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	COROLLA/AURIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	COROLLA/AURIS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	COROLLA/AURIS		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	COROLLA/AURIS		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	COROLLA/AURIS		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	COROLLA/AURIS		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	COROLLA/AURIS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	COROLLA/AURIS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	COROLLA/AURIS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	COROLLA/AURIS		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	COROLLA/AURIS		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	COROLLA/AURIS		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	COROLLA/AURIS		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	COROLLA/AURIS		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	COROLLA/AURIS		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	COROLLA/AURIS		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	COROLLA/AURIS		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	COROLLA/AURIS		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	COROLLA/AURIS		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CORONA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CORONA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CORONA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CORONA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CORONA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CORONA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	CORONA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CORONA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CORONA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CORONA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CORONA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CORONA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	CORONA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AT190(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AT190(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AT210(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AT210(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AT220(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AT220(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	ST191 WITH O2(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	ST191 WITH O2(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	ST191 W/O O2(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	ST191 W/O O2(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	ST210	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT190(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT190(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT210(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT210(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT220(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AT220(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST191 WITH O2(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST191 WITH O2(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST191 W/O O2(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST191 W/O O2(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CORONA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	ST210	17PIN RECTANGULAR CONNECTOR	O		O				

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	CORONA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CORONA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CORONA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CORONA		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CORONA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CORONA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	CORONA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CORONA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CORONA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	CORONA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	CORONA		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CORONA		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CORONA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	CORONA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	CORONA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	CORONA		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CORONA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CORONA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CRESSIDA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MX83	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CRESSIDA		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CRESSIDA		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CRESSIDA		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CRESSIDA		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CRESSIDA		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CRESSIDA		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CRESSIDA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CROWN		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CROWN		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CROWN		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CROWN		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CROWN		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	CROWN		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CROWN		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CROWN		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CROWN		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	CROWN		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	CROWN		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS133 WITH O2(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS133 WITH O2(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS133 W/O O2(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS133 W/O O2(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS155 LHD -9708(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS155 LHD 9708-9910(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS155 LHD 9910-(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CROWN		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS155 RHD -9708(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS155 RHD W/O O2 9708-(AT	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS155 -9708(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS155 9708-(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS133 WITH O2(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS133 WITH O2(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS133 W/O O2(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS133 W/O O2(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 LHD -9708(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 LHD -9708(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 LHD 9708-9910(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 LHD 9708-9910(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 LHD 9910-(AT)	17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 LHD 9910-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 RHD -9708(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 LHD 9910-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 RHD -9708(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 RHD W/O O2 9708-(AT	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 RHD W/O O2 9708-(MT	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 -9708(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 -9708(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 9708-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS155 9708-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	CROWN		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	CROWN		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	CROWN		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	CROWN		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CROWN		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CROWN		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CROWN		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CROWN		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CROWN		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	CROWN		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CROWN		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	CROWN		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	CROWN		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	CROWN		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CROWN		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CROWN		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	CROWN		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
TOYOTA	CROWN		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	CROWN		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	CROWN		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	CROWN		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	CROWN		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CROWN		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	CROWN		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
TOYOTA	CROWN		GATEWAY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	CROWN		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
TOYOTA	CROWN		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	CROWN		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	CROWN		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	CROWN COMFORT		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN COMFORT		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CROWN COMFORT		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CROWN COMFORT		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CROWN COMFORT		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CROWN COMFORT		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	CROWN COMFORT		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	CROWN COMFORT		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CROWN COMFORT		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	CROWN COMFORT		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	CROWN COMFORT		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	CROWN COMFORT		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	CROWN COMFORT		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	CROWN COMFORT		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	CROWN COMFORT		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	DYNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	DYNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	DYNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	DYNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	DYNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	DYNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	DYNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	DYNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	DYNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	DYNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	DYNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	DYNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	DYNA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZU100	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	DYNA		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	DYNA		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	DYNA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	DYNA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	DYNA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	DYNA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	DYNA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	DYNA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	DYNA		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	DYNA		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	DYNA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	DYNA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	DYNA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	DYNA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	DYNA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	FJ CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	FJ CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	FJ CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	FJ CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	FJ CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	FJ CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	FJ CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	FJ CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	FJ CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	FJ CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	FJ CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	FJ CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	FJ CRUISER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	FJ CRUISER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	FJ CRUISER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	FJ CRUISER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	FJ CRUISER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	FJ CRUISER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	FJ CRUISER		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	FJ CRUISER		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	FJ CRUISER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	FJ CRUISER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	FJ CRUISER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	FJ CRUISER		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	FJ CRUISER		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	FJ CRUISER		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	FJ CRUISER		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	FJ CRUISER		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	FJ CRUISER		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	FORTUNER/HILUX SW4		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	FORTUNER/HILUX SW4		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	FORTUNER/HILUX SW4		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	FORTUNER/HILUX SW4		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	FORTUNER/HILUX SW4		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	FORTUNER/HILUX SW4		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	FORTUNER/HILUX SW4		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	FORTUNER/HILUX SW4		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD CHECK MODE PILOT QUANTITY LEARNING PILOT QUANTITY LEARNING(DETAIL) PRESSURE DISCHARGE CLACE CHECK LEARNING VALUES CONFIRMATION
TOYOTA	FORTUNER/HILUX SW4		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	FORTUNER/HILUX SW4		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	FORTUNER/HILUX SW4		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	FORTUNER/HILUX SW4		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	FORTUNER/HILUX SW4		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	FORTUNER/HILUX SW4		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	FORTUNER/HILUX SW4		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	FORTUNER/HILUX SW4		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	FORTUNER/HILUX SW4		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	FORTUNER/HILUX SW4		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	FORTUNER/HILUX SW4		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	FORTUNER/HILUX SW4		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	FORTUNER/HILUX SW4		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	FORTUNER/HILUX SW4		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	FORTUNER/HILUX SW4		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	FORTUNER/HILUX SW4		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	FORTUNER/HILUX SW4		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	FORTUNER/HILUX SW4		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	FORTUNER/HILUX SW4		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	FORTUNER/HILUX SW4		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HARRIER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HARRIER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HARRIER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HARRIER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HARRIER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	HARRIER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HARRIER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HARRIER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HARRIER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HARRIER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	HARRIER		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	HARRIER		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	HARRIER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	HARRIER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	HARRIER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HARRIER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HARRIER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HARRIER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HARRIER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HARRIER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	HARRIER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HARRIER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HARRIER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	HARRIER		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	HARRIER		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	HARRIER		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HARRIER		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
TOYOTA	HARRIER		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	HARRIER		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	HARRIER		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	HARRIER		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
TOYOTA	HARRIER		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	HARRIER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	HARRIER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	HARRIER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	HARRIER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HARRIER		GATEWAY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HARRIER		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
TOYOTA	HARRIER		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	HARRIER		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	HARRIER		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HARRIER		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HARRIER		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	HARRIER		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HARRIER		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HARRIER		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HARRIER		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HARRIER		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HARRIER		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HARRIER		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HARRIER		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HARRIER		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HARRIER		MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		MIRROR			OBD-II 16PIN CONNECTOR			O	O			
TOYOTA	HARRIER		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HARRIER		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HARRIER		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HIACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HIACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HIACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HIACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HIACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	HIACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HIACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HIACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HIACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HIACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RCH12	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RCH18	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RCH22	17PIN RECTANGULAR CONNECTOR	O		O				

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RCH28	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZH102	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZH103	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZH105	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZH112	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZH113	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZH115	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZH125	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZH135	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZH153	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZH155	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HIACE		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	HIACE		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	HIACE		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	HIACE		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HIACE		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HIACE		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HIACE		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HIACE		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	HIACE		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HIACE		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HIACE		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	HIACE		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	HIACE		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	HIACE		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HIACE		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	HIACE		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	HIACE		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HIACE		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	HIACE		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	HIGHLANDER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HIGHLANDER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HIGHLANDER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HIGHLANDER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HIGHLANDER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	HIGHLANDER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	HIGHLANDER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HIGHLANDER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HIGHLANDER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HIGHLANDER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HIGHLANDER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	HIGHLANDER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	HIGHLANDER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HIGHLANDER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HIGHLANDER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HIGHLANDER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HIGHLANDER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	HIGHLANDER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HIGHLANDER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HIGHLANDER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	HIGHLANDER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	HIGHLANDER		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	HIGHLANDER		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	HIGHLANDER		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	HIGHLANDER		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	HIGHLANDER		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	HIGHLANDER		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	HIGHLANDER		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
TOYOTA	HIGHLANDER		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	HIGHLANDER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	HIGHLANDER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	HIGHLANDER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HIGHLANDER		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
TOYOTA	HIGHLANDER		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	HIGHLANDER		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HIGHLANDER		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HIGHLANDER		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HIGHLANDER		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HIGHLANDER		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HIGHLANDER		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HIGHLANDER		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HIGHLANDER		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HIGHLANDER		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	HIGHLANDER HV		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER HV		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HIGHLANDER HV		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HIGHLANDER HV		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HIGHLANDER HV		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HIGHLANDER HV		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	HIGHLANDER HV		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER HV		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HIGHLANDER HV		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HIGHLANDER HV		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HIGHLANDER HV		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HIGHLANDER HV		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	HIGHLANDER HV		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER HV		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER HV		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HIGHLANDER HV		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION RESET MEMORY INSPECTION MODE
TOYOTA	HIGHLANDER HV		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER HV		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HIGHLANDER HV		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			HV-BATTERY INITIALIZATION ONBOARD EQUALIZING CHARGE
TOYOTA	HIGHLANDER HV		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER HV		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	HIGHLANDER HV		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HIGHLANDER HV		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HIGHLANDER HV		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	HIGHLANDER HV		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	HIGHLANDER HV		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	HIGHLANDER HV		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER HV		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	HIGHLANDER HV		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	HIGHLANDER HV		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HIGHLANDER HV		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
TOYOTA	HIGHLANDER HV		GATEWAY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HIGHLANDER HV		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
TOYOTA	HIGHLANDER HV		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER HV		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HIGHLANDER HV		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER HV		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER HV		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HIGHLANDER HV		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HIGHLANDER HV		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER HV		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HIGHLANDER HV		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HILUX		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	HILUX		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RN106 22R-E(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HILUX		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RN106 22R-E(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HILUX		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RN110 22R-E	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HILUX		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RN85	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HILUX		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RN142	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HILUX		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZN147 -9908	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HILUX		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZN147 9908-	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	HILUX		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	HILUX		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	HILUX		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HILUX		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HILUX		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HILUX		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HILUX		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HILUX		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	HILUX		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HILUX		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HILUX		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	HILUX		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	HILUX		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HILUX		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	HILUX		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	HILUX		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HILUX		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	HILUX		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	HONGQI		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HONGQI		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HONGQI		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HONGQI		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HONGQI		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	HONGQI		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	HONGQI		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	HONGQI		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HONGQI		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	HONGQI		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	HONGQI		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	HONGQI		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HONGQI		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	HONGQI		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HONGQI		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	HONGQI		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	HONGQI		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	HONGQI		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	HONGQI		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	HONGQI		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	HONGQI		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	HONGQI		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	HONGQI		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	HONGQI		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
TOYOTA	HONGQI		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	HONGQI		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	HONGQI		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	HONGQI		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HONGQI		GATEWAY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HONGQI		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
TOYOTA	HONGQI		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	HONGQI		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	HONGQI		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	HONGQI		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	HONGQI		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HONGQI		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HONGQI		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HONGQI		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HONGQI		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HONGQI		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HONGQI		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	HONGQI		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HONGQI		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	HONGQI		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	HONGQI		NIGHT VIEW			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	IQ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	IQ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	IQ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	IQ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	IQ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	IQ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	IQ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	IQ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	IQ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	IQ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	IQ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	IQ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	IQ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	IQ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	IQ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	IQ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	IQ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	IQ		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	IQ		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	IQ		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	IQ		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	IQ		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	IQ		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	IQ		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
TOYOTA	IQ		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	IQ		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	IQ		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	IQ		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	IQ		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	IQ		PM1 GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
TOYOTA	IQ		PM2 GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
TOYOTA	IQ		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	IQ		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	IQ		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	IQ		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	IQ		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	IQ		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	IQ		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	IQ		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	IQ		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	KF72(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	KF72(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	KF82(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	KF82(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZF71(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZF71(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZF81(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	KIJANG INNOVA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZF81(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	KIJANG INNOVA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	KIJANG INNOVA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	KIJANG INNOVA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	KIJANG INNOVA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	KIJANG INNOVA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	KIJANG INNOVA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	KIJANG INNOVA		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	KIJANG INNOVA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	KIJANG INNOVA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	KIJANG INNOVA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	KLUGER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	KLUGER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	KLUGER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	KLUGER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	KLUGER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	KLUGER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	KLUGER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	KLUGER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	KLUGER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	KLUGER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	KLUGER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	KLUGER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	KLUGER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	KLUGER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	KLUGER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	KLUGER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	KLUGER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	KLUGER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	KLUGER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	KLUGER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	KLUGER		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	KLUGER		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	KLUGER		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
TOYOTA	KLUGER		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	KLUGER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	KLUGER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	KLUGER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	KLUGER		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	KLUGER		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	KLUGER		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	KLUGER		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	KLUGER		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	KLUGER		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	FZJ70	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	FZJ73	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	FZJ75 COLOMBIA	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	FZJ75 OTHERS	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	FZJ80 WITH O2 -9501(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	FZJ80 WITH O2 -9501(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	FZJ80 W/O O2 -9501	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	FZJ80 WITH O2 9501-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	FZJ80 WITH O2 9501-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	FZJ80 W/O O2 9501-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	FZJ80 W/O O2 9501-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZJ90 -9906	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZJ90 DENSO EFI 9906-	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZJ90 OTHER 9906-	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZJ95 -9906(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZJ95 -9906(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZJ95 DENSO EFI 9906-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZJ95 DENSO EFI 9906-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZJ95 OTHER 9906-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZJ95 OTHER 9906-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	VZJ90,95 -9906(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	VZJ90,95 -9906(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA(1994-1993)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LAND CRUISER		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	LAND CRUISER		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	LAND CRUISER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	LAND CRUISER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	LAND CRUISER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	LAND CRUISER		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	LAND CRUISER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	LAND CRUISER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	LAND CRUISER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	LAND CRUISER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	LAND CRUISER		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	LAND CRUISER		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	LAND CRUISER		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	LAND CRUISER		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	LAND CRUISER		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	LAND CRUISER		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
TOYOTA	LAND CRUISER		VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
TOYOTA	LAND CRUISER		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	LAND CRUISER		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
TOYOTA	LAND CRUISER		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	LAND CRUISER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	LAND CRUISER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	LAND CRUISER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	LAND CRUISER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	LAND CRUISER		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	LAND CRUISER		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	LAND CRUISER		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
TOYOTA	LAND CRUISER		GATEWAY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	LAND CRUISER		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
TOYOTA	LAND CRUISER		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	LAND CRUISER		ACCESSORY GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	LAND CRUISER		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	LAND CRUISER		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	LAND CRUISER		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	LAND CRUISER		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	LAND CRUISER		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	LAND CRUISER		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	LAND CRUISER		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	LAND CRUISER		FRONT LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		FRONT RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	LAND CRUISER		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	LAND CRUISER		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	LAND CRUISER		MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	LAND CRUISER		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	LAND CRUISER		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	LAND CRUISER		WIPER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LAND CRUISER		PRE-CRASH			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	LITEACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LITEACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	LITEACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	LITEACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	LITEACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	LITEACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	LITEACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	LITEACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	LITEACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	LITEACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	LITEACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	LITEACE		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	LITEACE		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	SR40(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	LITEACE		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	SR40(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	LITEACE		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	YR22,29	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	LITEACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SR40(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LITEACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SR40(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LITEACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	YR22,29	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	LITEACE		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	LITEACE		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	LITEACE		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	LITEACE		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	LITEACE		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	LITEACE		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	LITEACE		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	LITEACE		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	LITEACE		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	LITEACE		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	LITEACE		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	LITEACE		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	LITEACE		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	LITEACE		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	LITEACE		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	MATRIX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	MATRIX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	MATRIX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	MATRIX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	MATRIX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	MATRIX		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	MATRIX		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	MATRIX		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	MATRIX		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	MATRIX		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	MATRIX		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	MATRIX		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	MATRIX		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	MATRIX		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	MATRIX		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	MATRIX		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	MATRIX		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	MATRIX		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	MATRIX		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	MATRIX		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	MATRIX		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	MATRIX		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	MATRIX		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	MATRIX		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	MATRIX		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	MATRIX		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	MATRIX		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	MATRIX		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	MATRIX		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	MATRIX		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	MATRIX		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	MATRIX		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	MATRIX		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	MATRIX		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	MATRIX		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	MATRIX		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	MATRIX		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	MATRIX		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	MATRIX		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	MR2		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	MR2		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	MR2		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	MR2		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	MR2		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	MR2		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	MR2		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	MR2		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	MR2		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	MR2		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	MR2		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	MR2		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	MR2		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SW20 3S-GE	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	MR2		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 3S-GTE	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	MR2		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 5S-EF(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	MR2		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 5S-EF(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	MR2		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	MR2		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	MR2		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	MR2		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	MR2		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	MR2		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	MR2		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	MR2		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	MR2		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	MR2		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	MR2		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	MR2		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	MR2		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	PASEO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PASEO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PASEO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PASEO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PASEO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PASEO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	PASEO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PASEO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PASEO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PASEO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PASEO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	PASEO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL54 EURO -9608(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL54 EURO -9608(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL54 EURO 9608-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL54 EURO 9608-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL54 OTHERS -9608(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL54 OTHERS -9608(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL54 OTHERS 9608-9712(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL54 OTHERS 9608-9712(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL54 OTHERS 9712-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL54 OTHERS 9712-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA CALIFORNIA(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA CALIFORNIA(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PASEO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA FEDERAL	17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	PASEO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PASEO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	PASEO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PASEO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PASEO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	PASEO		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	PASEO		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	PASSO		ENGINE & TRANSMISSION			OBD-II 16PIN CONNECTOR	O		O	O		O	
TOYOTA	PASSO		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O		O	AIR BLEEDING MODE CHECK MODE
TOYOTA	PASSO		EPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	PASSO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	PICNIC		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PICNIC		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PICNIC		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PICNIC		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PICNIC		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PICNIC		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	PICNIC		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PICNIC		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PICNIC		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PICNIC		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PICNIC		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	PICNIC		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	PICNIC		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SXM10 -0005(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PICNIC		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SXM10 -0005(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PICNIC		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SXM10 SINGAPORE 0005-	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PICNIC		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PICNIC		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PICNIC		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PICNIC		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PICNIC		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	PICNIC		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PICNIC		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PICNIC		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	PICNIC		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	PICNIC		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	PICNIC		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	PICNIC		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	PICNIC		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	PICNIC		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	PICNIC		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	PICNIC		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PICNIC		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	PREMIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PREMIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PREMIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PREMIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PREMIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PREMIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	PREMIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PREMIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PREMIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PREMIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PREMIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	PREMIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	PREMIO		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PREMIO		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PREMIO		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PREMIO		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION RESET MEMORY INSPECTION MODE
TOYOTA	PREMIO		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PREMIO		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PREMIO		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			HV-BATTERY INITIALIZATION ONBOARD EQUALIZING CHARGE
TOYOTA	PREMIO		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PREMIO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PREMIO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	PREMIO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PREMIO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PREMIO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	PREMIO		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	PREMIO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	PREMIO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	PREMIO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	Y		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	TCR10,11 -9608	17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	TCR10,11 9608-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	TCR10,11 9608-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	TCR20,21 -9608	17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	TCR20,21 9608-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PREVIA/TARAGO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	TCR20,21 9608-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	PREVIA/TARAGO		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	PREVIA/TARAGO		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	PREVIA/TARAGO		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	PREVIA/TARAGO		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PREVIA/TARAGO		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PREVIA/TARAGO		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PREVIA/TARAGO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PREVIA/TARAGO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	PREVIA/TARAGO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PREVIA/TARAGO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PREVIA/TARAGO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	PREVIA/TARAGO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PREVIA/TARAGO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	PREVIA/TARAGO		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	PREVIA/TARAGO		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	PREVIA/TARAGO		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	PREVIA/TARAGO		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PREVIA/TARAGO		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	PREVIA/TARAGO		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	PREVIA/TARAGO		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	PREVIA/TARAGO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	PREVIA/TARAGO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	PREVIA/TARAGO		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	PREVIA/TARAGO		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	PREVIA/TARAGO		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	PREVIA/TARAGO		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	PREVIA/TARAGO		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	PREVIA/TARAGO		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	PREVIA/TARAGO		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PREVIA/TARAGO		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PREVIA/TARAGO		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PREVIA/TARAGO		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PREVIA/TARAGO		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PREVIA/TARAGO		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PREVIA/TARAGO		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PREVIA/TARAGO		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PREVIA/TARAGO		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PREVIA/TARAGO		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PREVIA/TARAGO		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PREVIA/TARAGO		PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PRIUS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PRIUS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PRIUS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PRIUS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PRIUS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PRIUS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	PRIUS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PRIUS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PRIUS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	PRIUS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PRIUS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	PRIUS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	PRIUS		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	PRIUS		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	PRIUS		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PRIUS		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PRIUS		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PRIUS		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION RESET MEMORY INSPECTION MODE
TOYOTA	PRIUS		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION RESET MEMORY INSPECTION MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	PRIUS		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PRIUS		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O				ECU INITIALIZATION SOC(STATUS OF CHARGING) SET V80 CONTROL SET ON BOARD EQUALIZING CHARGE
TOYOTA	PRIUS		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			HV-BATTERY INITIALIZATION ONBOARD EQUALIZING CHARGE
TOYOTA	PRIUS		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PRIUS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	PRIUS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	PRIUS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PRIUS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PRIUS		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PRIUS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PRIUS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	PRIUS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PRIUS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	PRIUS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	PRIUS		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	PRIUS		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	PRIUS		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PRIUS		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PRIUS		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	PRIUS		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	PRIUS		IPA			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	PRIUS		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PRIUS		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	PRIUS		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
TOYOTA	PRIUS		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	PRIUS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	PRIUS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	PRIUS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	PRIUS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	PRIUS		GATEWAY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	PRIUS		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
TOYOTA	PRIUS		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	PRIUS		PM1 GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
TOYOTA	PRIUS		PM2 GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
TOYOTA	PRIUS		NAVIGATION SYSTEM			OBD-II 16PIN CONNECTOR	O	O					MAP INFORMATION SOFTWARE ERROR HISTORY OPTICAL DISC ERROR HISTORY

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	PRIUS		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	PRIUS		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	PRIUS		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PRIUS		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	PRIUS		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PRIUS		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PRIUS		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PRIUS		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PRIUS		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	PRIUS		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PRIUS		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	PRIUS		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	PRIUS		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	RAV4		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	RAV4		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	RAV4		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	RAV4		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	RAV4		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	RAV4		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	RAV4		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	RAV4		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	RAV4		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	RAV4		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	RAV4		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	RAV4		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	RAV4		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SXA10,11 WITH O2 -9608(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	RAV4		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SXA10,11 WITH O2 -9608(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	RAV4		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SXA10,11 W/O O2 -9608(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	RAV4		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SXA10,11 W/O O2 -9608(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	RAV4		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SXA10,11 9608-9709(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	RAV4		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SXA10,11 9608-9709(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	RAV4		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SXA10,11 9709-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	RAV4		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	SXA10,11 9709-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	RAV4		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	RAV4		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	RAV4		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	RAV4		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	RAV4		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	RAV4		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	RAV4		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	RAV4		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	RAV4		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	RAV4		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	RAV4		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	RAV4		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	RAV4		FOUR WHEEL DRIVE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY
TOYOTA	RAV4		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	RAV4		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	RAV4		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	RAV4		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	RAV4		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	RAV4		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	RAV4		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	RAV4		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	RAV4		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	RAV4		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	RAV4		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	RAV4		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	RAV4		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	RAV4		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	RAV4		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	RAV4		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	RAV4		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	RAV4-EV		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	RAV4-EV		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	REIZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	REIZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	REIZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	REIZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	REIZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	REIZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	REIZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	REIZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	REIZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	REIZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	REIZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	REIZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	REIZ		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	REIZ		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	REIZ		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	REIZ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	REIZ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	REIZ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	REIZ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	REIZ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	REIZ		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	REIZ		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	REIZ		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	REIZ		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	REIZ		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	REIZ		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	REIZ		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	REIZ		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	REIZ		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	REIZ		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	REIZ		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	REIZ		GATEWAY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	REIZ		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
TOYOTA	REIZ		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	REIZ		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	REIZ		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	REIZ		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	REIZ		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	REIZ		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	REIZ		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	REIZ		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	REIZ		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	REIZ		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	REIZ		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	REIZ		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	REIZ		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	SIENNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SIENNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SIENNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SIENNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SIENNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	SIENNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SIENNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SIENNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SIENNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SIENNA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	SIENNA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SIENNA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	SIENNA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	SIENNA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	SIENNA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	SIENNA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	SIENNA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	SIENNA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	SIENNA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	SIENNA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	SIENNA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	SIENNA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	SIENNA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	SIENNA		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	SIENNA		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
TOYOTA	SIENNA		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	SIENNA		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	SIENNA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	SIENNA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	SIENNA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	SIENNA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	SIENNA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	SIENNA		GATEWAY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	SIENNA		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
TOYOTA	SIENNA		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
TOYOTA	SIENNA		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	SIENNA		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	SIENNA		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	SIENNA		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	SIENNA		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	SIENNA		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	SIENNA		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	SIENNA		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	SIENNA		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	SIENNA		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	SIENNA		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	SIENNA		MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		MIRROR			OBD-II 16PIN CONNECTOR			O	O			
TOYOTA	SIENNA		MIRROR L			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SIENNA		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	SOLARA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SOLARA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SOLARA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SOLARA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SOLARA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SOLARA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	SOLARA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SOLARA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SOLARA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SOLARA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SOLARA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SOLARA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	SOLARA		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	SOLARA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	SOLARA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	SOLARA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	SOLARA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	SOLARA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	SOLARA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	SOLARA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	SOLARA		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	SOLARA		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	SOLARA		TRACTION CONTROL SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	SOLARA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	SOLARA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	SOLARA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	SOLARA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	SOLARA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	SOLARA		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SOLARA		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	SOLARA		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	SOLUNA(AFC)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AL50 -9810(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SOLUNA(AFC)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AL50 -9810(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SOLUNA(AFC)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AL50 9810-9906(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SOLUNA(AFC)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AL50 9810-9906(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SOLUNA(AFC)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AL50 INDONESIA 9906-	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SOLUNA(AFC)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AL50 OTHER 9906-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SOLUNA(AFC)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AL50 OTHER 9906-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SPACIO		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	SPACIO		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AE111	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SPACIO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	SPACIO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	SPACIO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	SPACIO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	SPACIO		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	SPACIO		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	SPACIO		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	SPACIO		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	STARLET		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EP81 -9405	17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	STARLET		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EP81 9405-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	STARLET		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EP81 9405-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	STARLET		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EP82	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	STARLET		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EP91(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	STARLET		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EP91(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	STARLET		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	STARLET		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	SUPRA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SUPRA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SUPRA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SUPRA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SUPRA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SUPRA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	SUPRA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	SUPRA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SUPRA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	SUPRA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SUPRA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	SUPRA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	SUPRA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZA80 2JZ-GE LHD(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZA80 2JZ-GE LHD(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZA80 2JZ-GE RHD	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZA80 2JZ-GTE(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZA80 2JZ-GTE(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 2JZ-GE(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 2JZ-GE(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 2JZ-GTE(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 2JZ-GTE(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZA80 2JZ-GE LHD(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZA80 2JZ-GE LHD(MT)	17PIN RECTANGULAR CONNECTOR	O		O				

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	SUPRA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZA80 2JZ-GE RHD	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZA80 2JZ-GTE(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZA80 2JZ-GTE(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 2JZ-GE(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 2JZ-GE(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 2JZ-GTE(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SUPRA		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 2JZ-GTE(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	SUPRA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	SUPRA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	SUPRA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	SUPRA		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	SUPRA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	SUPRA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	SUPRA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	SUPRA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	SUPRA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	SUPRA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	SUPRA		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	SUPRA		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	SUPRA		TRACTION CONTROL SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	SUPRA		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
TOYOTA	SUPRA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	SUPRA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	SUPRA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	T100		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	T100		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	T100		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	T100		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	T100		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	T100		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	T100		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	T100		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	T100		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	T100		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	T100		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	T100		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	T100		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	T100		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	T100		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	T100		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	TACOMA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TACOMA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TACOMA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TACOMA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TACOMA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TACOMA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	TACOMA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TACOMA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TACOMA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TACOMA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TACOMA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TACOMA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	TACOMA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	TACOMA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	TACOMA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	TACOMA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	TACOMA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	TACOMA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	TACOMA		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	TACOMA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	TACOMA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	TACOMA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	TACOMA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	TACOMA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	TAMARAW		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	KF80,82(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TAMARAW		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	KF80,82(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TAMARAW		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZF81(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TAMARAW		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZF81(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TAMARAW		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	TAMARAW		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	TERCEL		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TERCEL		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TERCEL		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TERCEL		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TERCEL		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TERCEL		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	TERCEL		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TERCEL		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TERCEL		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TERCEL		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TERCEL		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TERCEL		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL51 TAIWAN(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL51 TAIWAN(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL51 OTHERS(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL51 OTHERS(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL53 TAIWAN(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL53 TAIWAN(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL53 OTHERS -9508	17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL53 OTHERS 9508-9608(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL53 OTHERS 9508-9608(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL53 OTHERS 9608-9712(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL53 OTHERS 9608-9712(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL53 OTHERS 9712-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TERCEL		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	EL53 OTHERS 9712-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TERCEL		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	TERCEL		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	TRUCK		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	TRUCK		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TRUCK		ENGINE & TRANSMISSION	A	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TRUCK		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TRUCK		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TRUCK		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	TRUCK		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TRUCK		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TRUCK		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TRUCK		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TRUCK		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TRUCK		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	TRUCK		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TRUCK		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	TUNDRA/SEQUOIA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TUNDRA/SEQUOIA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TUNDRA/SEQUOIA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TUNDRA/SEQUOIA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TUNDRA/SEQUOIA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TUNDRA/SEQUOIA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	TUNDRA/SEQUOIA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TUNDRA/SEQUOIA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	TUNDRA/SEQUOIA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	TUNDRA/SEQUOIA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TUNDRA/SEQUOIA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	TUNDRA/SEQUOIA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	TUNDRA/SEQUOIA		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	TUNDRA/SEQUOIA		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	TUNDRA/SEQUOIA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	TUNDRA/SEQUOIA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	TUNDRA/SEQUOIA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	TUNDRA/SEQUOIA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	TUNDRA/SEQUOIA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	TUNDRA/SEQUOIA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	TUNDRA/SEQUOIA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	TUNDRA/SEQUOIA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	TUNDRA/SEQUOIA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	TUNDRA/SEQUOIA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	TUNDRA/SEQUOIA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	TUNDRA/SEQUOIA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	TUNDRA/SEQUOIA		ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	TUNDRA/SEQUOIA		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	TUNDRA/SEQUOIA		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	TUNDRA/SEQUOIA		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TUNDRA/SEQUOIA		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	TUNDRA/SEQUOIA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	TUNDRA/SEQUOIA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	TUNDRA/SEQUOIA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	TUNDRA/SEQUOIA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	TUNDRA/SEQUOIA		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	TUNDRA/SEQUOIA		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	TUNDRA/SEQUOIA		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TUNDRA/SEQUOIA		BODY			OBD-II 16PIN CONNECTOR	O						
TOYOTA	TUNDRA/SEQUOIA		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TUNDRA/SEQUOIA		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	TUNDRA/SEQUOIA		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TUNDRA/SEQUOIA		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	TUNDRA/SEQUOIA		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TUNDRA/SEQUOIA		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TUNDRA/SEQUOIA		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TUNDRA/SEQUOIA		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TUNDRA/SEQUOIA		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	TUNDRA/SEQUOIA		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	TUNDRA/SEQUOIA		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	TUNDRA/SEQUOIA		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	UNSER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	KF80(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	UNSER		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	KF80(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	UNSER		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	UNSER		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	VENZA		ENGINE	GASOLINE		OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	VENZA		ENGINE	GASOLINE		OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	VENZA		ENGINE	GASOLINE		OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	VENZA		ENGINE	GASOLINE		OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	VENZA		ENGINE	GASOLINE		OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	VENZA		ENGINE	DIESEL		OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	VENZA		ENGINE	DIESEL		OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	VENZA		ENGINE	DIESEL		OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	VENZA		ENGINE	DIESEL		OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	VENZA		ENGINE	DIESEL		OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	VENZA		ENGINE	DIESEL		OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	VENZA		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	VENZA		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	VENZA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	VENZA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	VENZA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	VENZA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	VENZA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	VENZA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	VENZA		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	VENZA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	VENZA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	VENZA		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	VENZA		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	VENZA		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	VENZA		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	VENZA		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	VENZA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	VENZA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	VENZA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	VENZA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	VENZA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE
TOYOTA	VENZA		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	VENZA		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	VENZA		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	VENZA		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	VENZA		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	VENZA		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	VENZA		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	VENZA		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	VENZA		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	VENZA		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	VENZA		NAVIGATION SYSTEM			OBD-II 16PIN CONNECTOR	O	O					MAP INFORMATION SOFTWARE ERROR HISTORY OPTICAL DISC ERROR HISTORY
TOYOTA	VIOS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	VIOS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	VIOS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	VIOS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	VIOS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	VIOS		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	VIOS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	VIOS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	VIOS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	VIOS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	VIOS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	VIOS		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	VIOS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	VIOS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	VIOS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	VIOS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	VIOS		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	VIOS		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	VIOS		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	VIOS		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	VIOS		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	VIOS		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	VIOS		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	VIOS		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	VIOS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	VIOS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	VIOS		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	VIOS		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION WIRELESS CODE ERASURE WIRELESS CODE REGISTRATION WIRELESS CODE LOCK DIAGNOSIS MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	VIOS		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	VIOS		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	WILL		ENGINE & TRANSMISSION			OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	WILL		ENGINE & TRANSMISSION			OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	WILL		ENGINE & TRANSMISSION			OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	WILL		ENGINE & TRANSMISSION			OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	WILL		ENGINE & TRANSMISSION			OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	WILL		ENGINE & TRANSMISSION			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	WILL		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	WILL		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	WILL		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	WISH		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	WISH		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	WISH		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	WISH		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	WISH		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	WISH		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	WISH		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	WISH		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	WISH		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	WISH		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	WISH		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	WISH		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	WISH		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	WISH		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	WISH		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	WISH		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	WISH		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	WISH		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	WISH		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	WISH		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT ALL SIGNAL CHECK ONE SIGNAL CHECK ABNORMAL OPERATION HISTORY
TOYOTA	WISH		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	WISH		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	WISH		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	XA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	XA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	XA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	XA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	XA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	XA		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	XA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	XA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	XA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	XA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	XA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	XA		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	XA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	XA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	XA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	XA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	XA		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	XA		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	XA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	XA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	XA		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	YARIS/ECHO/VITZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	YARIS/ECHO/VITZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	YARIS/ECHO/VITZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	YARIS/ECHO/VITZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	YARIS/ECHO/VITZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	YARIS/ECHO/VITZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE VIN READ VIN WRITE FUEL DENSITY LEARNING VALUE RESET LEARNING VALUE RESET A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET RESET MEMORY
TOYOTA	YARIS/ECHO/VITZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
TOYOTA	YARIS/ECHO/VITZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	YARIS/ECHO/VITZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
TOYOTA	YARIS/ECHO/VITZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
TOYOTA	YARIS/ECHO/VITZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
TOYOTA	YARIS/ECHO/VITZ		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
TOYOTA	YARIS/ECHO/VITZ		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	YARIS/ECHO/VITZ		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
TOYOTA	YARIS/ECHO/VITZ		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	YARIS/ECHO/VITZ		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	YARIS/ECHO/VITZ		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
TOYOTA	YARIS/ECHO/VITZ		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
TOYOTA	YARIS/ECHO/VITZ		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	YARIS/ECHO/VITZ		ECT	16PIN CONNECTOR		OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
TOYOTA	YARIS/ECHO/VITZ		ECT	16PIN CONNECTOR		OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY A/T CODE - SET COMPENSATION CODE A/T CODE - READ COMPENSATION CODE A/T CODE RESET
TOYOTA	YARIS/ECHO/VITZ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	YARIS/ECHO/VITZ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	YARIS/ECHO/VITZ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	YARIS/ECHO/VITZ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
TOYOTA	YARIS/ECHO/VITZ		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
TOYOTA	YARIS/ECHO/VITZ		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
TOYOTA	YARIS/ECHO/VITZ		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
TOYOTA	YARIS/ECHO/VITZ		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
TOYOTA	YARIS/ECHO/VITZ		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
TOYOTA	YARIS/ECHO/VITZ		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION ALL SIGNAL CHECK ONE SIGNAL CHECK
TOYOTA	YARIS/ECHO/VITZ		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
TOYOTA	YARIS/ECHO/VITZ		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
TOYOTA	YARIS/ECHO/VITZ		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					CHECK MODE
TOYOTA	YARIS/ECHO/VITZ		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				ALL SIGNAL CHECK
TOYOTA	YARIS/ECHO/VITZ		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
TOYOTA	YARIS/ECHO/VITZ		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION
TOYOTA	YARIS/ECHO/VITZ		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	YARIS/ECHO/VITZ		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
TOYOTA	YARIS/ECHO/VITZ		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
TOYOTA	YARIS/ECHO/VITZ		FREE-TRONIC			OBD-II 16PIN CONNECTOR	O		O				
TOYOTA	ZACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	KF60	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	ZACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	KF80(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	ZACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	KF80(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	ZACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	KF82	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	ZACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZF84	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	ZACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZF85(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	ZACE		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	RZF85(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
TOYOTA	ZACE		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
TOYOTA	ZACE		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MANUAL TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	GENERAL	POWER TRAIN	ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	GENERAL	POWER TRAIN	ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
LEXUS	GENERAL	POWER TRAIN	ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY
LEXUS	GENERAL	POWER TRAIN	ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	PARTS EXCHANGE
LEXUS	GENERAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION
LEXUS	GENERAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			HV-BATTERY INITIALIZATION ONBOARD EQUALIZING CHARGE
LEXUS	GENERAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	POWER TRAIN	HYBRID GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GENERAL	POWER TRAIN	SEQUENTIAL M/T			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
LEXUS	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
LEXUS	GENERAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	POWER TRAIN	CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GENERAL	POWER TRAIN	E-ACM			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GENERAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GENERAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GENERAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GENERAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GENERAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	GENERAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	GENERAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GENERAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	GENERAL	CHASSIS	TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	CHASSIS	TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	CHASSIS	TRACTION CONTROL SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GENERAL	CHASSIS	FOUR WHEEL DRIVE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY
LEXUS	GENERAL	CHASSIS	AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	CHASSIS	AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	GENERAL	CHASSIS	AHC&AIR SUSPENSION			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GENERAL	CHASSIS	EMS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	CHASSIS	STABILIZER			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	CHASSIS	EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
LEXUS	GENERAL	CHASSIS	EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
LEXUS	GENERAL	CHASSIS	TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	GENERAL	CHASSIS	TPMS(WIRELESS CHECK)	PACIFIC SENSOR		TPMS(WIRELESS CHECK)							TMPS SENSOR STATUS READ TMPS ID REGISTRATION
LEXUS	GENERAL	CHASSIS	VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
LEXUS	GENERAL	CHASSIS	ARS			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	CHASSIS	ELECTRIC PARKING BRAKE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY
LEXUS	GENERAL	BODY	IPA			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GENERAL	BODY	AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
LEXUS	GENERAL	BODY	ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
LEXUS	GENERAL	BODY	ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
LEXUS	GENERAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GENERAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	GENERAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GENERAL	BODY	SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GENERAL	BODY	SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	GENERAL	BODY	THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
LEXUS	GENERAL	BODY	GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GENERAL	BODY	GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GENERAL	BODY	GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GENERAL	BODY	ECM GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
LEXUS	GENERAL	BODY	ECB GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
LEXUS	GENERAL	BODY	PM1 GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GENERAL	BODY	PM2 GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GENERAL	BODY	NAVIGATION SYSTEM			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GENERAL	BODY	ACCESSORY GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GENERAL	BODY	MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION
LEXUS	GENERAL	BODY	BODY			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GENERAL	BODY	BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GENERAL	BODY	BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	BODY	CENTER CONSOLE SWITCH			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	GENERAL	BODY	REAR CONSOLE SWITCH			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	BODY	TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	BODY	COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	BODY	COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	BODY	COMBINATION SW			OBD-II 16PIN CONNECTOR			O				
LEXUS	GENERAL	BODY	STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	BODY	STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR			O				
LEXUS	GENERAL	BODY	MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	MIRROR			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	GENERAL	BODY	MIRROR L			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	BODY	RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	BODY	RAIN SENSOR			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GENERAL	BODY	WIPER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	BODY	AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	BODY	ELECTRIC POWER CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	BODY	PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	PRE-CRASH			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	BODY	OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
LEXUS	GENERAL	BODY	NIGHT VIEW			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	BODY	FREE-TRONIC			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	DOOR & SEAT	DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	DOOR & SEAT	PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	DOOR & SEAT	REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	DOOR & SEAT	REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	DOOR & SEAT	BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	DOOR & SEAT	PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	DOOR & SEAT	REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	DOOR & SEAT	REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	DOOR & SEAT	DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	REAR LEFT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	REAR LEFT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	REAR RIGHT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	REAR RIGHT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	DRIVER SEAT SW			OBD-II 16PIN CONNECTOR			O				
LEXUS	GENERAL	DOOR & SEAT	DRIVER SEAT SW			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	DOOR & SEAT	REAR SEAT SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GENERAL	DOOR & SEAT	FRONT LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	FRONT RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	REAR LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GENERAL	DOOR & SEAT	REAR RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GENERAL	DOOR & SEAT	SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GENERAL	DOOR & SEAT	RETRACTABLE HARDTOP			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MANUAL TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	POWER TRAIN	ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	POWER TRAIN	ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
LEXUS	JAPAN LOCAL	POWER TRAIN	ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY
LEXUS	JAPAN LOCAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	POWER TRAIN	HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION
LEXUS	JAPAN LOCAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			HV-BATTERY INITIALIZATION ONBOARD EQUALIZING CHARGE
LEXUS	JAPAN LOCAL	POWER TRAIN	HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	POWER TRAIN	HYBRID GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	JAPAN LOCAL	POWER TRAIN	SEQUENTIAL M/T			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
LEXUS	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O						
LEXUS	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	JAPAN LOCAL	POWER TRAIN	CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	JAPAN LOCAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	JAPAN LOCAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	JAPAN LOCAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	JAPAN LOCAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	JAPAN LOCAL	POWER TRAIN	IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	JAPAN LOCAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	JAPAN LOCAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	JAPAN LOCAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	JAPAN LOCAL	CHASSIS	ANTI-LOCK BRAKE SYSTEM			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	JAPAN LOCAL	CHASSIS	TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	CHASSIS	TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	CHASSIS	TRACTION CONTROL SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	JAPAN LOCAL	CHASSIS	FOUR WHEEL DRIVE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY
LEXUS	JAPAN LOCAL	CHASSIS	AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	CHASSIS	AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	JAPAN LOCAL	CHASSIS	AHC&AIR SUSPENSION			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	JAPAN LOCAL	CHASSIS	EMS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	CHASSIS	STABILIZER			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	CHASSIS	EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
LEXUS	JAPAN LOCAL	CHASSIS	EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
LEXUS	JAPAN LOCAL	CHASSIS	TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	JAPAN LOCAL	CHASSIS	VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
LEXUS	JAPAN LOCAL	CHASSIS	ARS			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	CHASSIS	ELECTRIC PARKING BRAKE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY
LEXUS	JAPAN LOCAL	BODY	IPA			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	JAPAN LOCAL	BODY	AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
LEXUS	JAPAN LOCAL	BODY	ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
LEXUS	JAPAN LOCAL	BODY	ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
LEXUS	JAPAN LOCAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	JAPAN LOCAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	JAPAN LOCAL	BODY	SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	JAPAN LOCAL	BODY	SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	JAPAN LOCAL	BODY	SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	JAPAN LOCAL	BODY	THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
LEXUS	JAPAN LOCAL	BODY	GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	JAPAN LOCAL	BODY	GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	JAPAN LOCAL	BODY	GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	JAPAN LOCAL	BODY	ECM GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
LEXUS	JAPAN LOCAL	BODY	ECB GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
LEXUS	JAPAN LOCAL	BODY	ACCESSORY GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	JAPAN LOCAL	BODY	MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION
LEXUS	JAPAN LOCAL	BODY	BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	JAPAN LOCAL	BODY	BODY2			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	JAPAN LOCAL	BODY	BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	BODY	CENTER CONSOLE SWITCH			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	JAPAN LOCAL	BODY	REAR CONSOLE SWITCH			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	BODY	TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	BODY	COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	BODY	COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	BODY	COMBINATION SW			OBD-II 16PIN CONNECTOR			O				
LEXUS	JAPAN LOCAL	BODY	STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	BODY	STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR			O				
LEXUS	JAPAN LOCAL	BODY	MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	MIRROR			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	JAPAN LOCAL	BODY	MIRROR L			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	BODY	RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	BODY	RAIN SENSOR			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	JAPAN LOCAL	BODY	WIPER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	BODY	POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	BODY	POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	BODY	PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	PRE-CRASH			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	BODY	OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
LEXUS	JAPAN LOCAL	BODY	NIGHT VIEW			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	BODY	FREE-TRONIC			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	DOOR & SEAT	DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR LEFT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR LEFT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR RIGHT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR RIGHT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	DRIVER SEAT SW			OBD-II 16PIN CONNECTOR			O				
LEXUS	JAPAN LOCAL	DOOR & SEAT	DRIVER SEAT SW			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR SEAT SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	JAPAN LOCAL	DOOR & SEAT	FRONT LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	FRONT RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	REAR RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	JAPAN LOCAL	DOOR & SEAT	SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	JAPAN LOCAL	DOOR & SEAT	RETRACTABLE HARDTOP			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	ES250		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 1990-1991(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	ES250		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 1990-1991(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	ES250		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 1990-1991(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	ES250		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 1990-1991(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	ES250		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES250		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES250		TRANSMISSION CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES250		AIR CONDITION SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES250		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES250		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	ES300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	ES300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	ES300(1998~)		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	ES300(1998~)		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	ES300(1998~)		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	ES300(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	ES300(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	ES300(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	ES300(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	ES300(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	ES300(1998~)		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	ES300(1998~)		EMS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES300(1998~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	ES300(1998~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	ES300(1998~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	ES300(1998~)		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
LEXUS	ES300(1998~)		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES300(1998~)		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	ES300(1998~)		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES300(1998~)		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 1993-(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 1993-(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	VCV10	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 1993-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 1993-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	ES300(1994~1997)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	VCV10	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	ES300(1994~1997)		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES300(1994~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	ES300(1994~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	ES300(1994~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	ES300(1994~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	ES300(1994~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	ES300(1994~1997)		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	ES300(1994~1997)		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES300(1994~1997)		AIR CONDITION SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES300(1994~1997)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	ES300(1994~1997)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	ES300(1994~1997)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	ES300(1994~1997)		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	ES300(1994~1997)		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	ES300(~1993)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 1993-(AT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	ES300(~1993)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 1993-(MT)	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	ES300(~1993)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	VCV10	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	ES300(~1993)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 1993-(AT)	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	ES300(~1993)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 1993-(MT)	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	ES300(~1993)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	VCV10	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	ES300(~1993)		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES300(~1993)		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES300(~1993)		TRANSMISSION CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES300(~1993)		AIR CONDITION SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES300(~1993)		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	ES300(~1993)		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	ES330		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES330		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES330		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES330		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES330		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES330		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	ES330		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES330		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES330		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES330		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES330		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES330		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	ES330		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	ES330		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	ES330		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	ES330		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	ES330		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	ES330		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	ES330		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	ES330		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	ES330		EMS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES330		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	ES330		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	ES330		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	ES330		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
LEXUS	ES330		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES330		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	ES330		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES330		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	ES350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	ES350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	ES350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	ES350		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
LEXUS	ES350		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY
LEXUS	ES350		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	ES350		E-ACM			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	ES350		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	ES350		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	ES350		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	ES350		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
LEXUS	ES350		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
LEXUS	ES350		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	ES350		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	ES350		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	ES350		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	ES350		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION
LEXUS	ES350		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	ES350		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	ES350		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	ES350		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	ES350		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES350		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES350		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	ES350		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	ES350		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	ES350		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	ES350		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	ES350		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	ES350		PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	ES350		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS300(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS300(1998~)		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
LEXUS	GS300(1998~)		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY
LEXUS	GS300(1998~)		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	GS300(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS300(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GS300(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS300(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS300(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GS300(1998~)		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	GS300(1998~)		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	GS300(1998~)		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS300(1998~)		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	GS300(1998~)		EMS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		STABILIZER			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS300(1998~)		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
LEXUS	GS300(1998~)		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
LEXUS	GS300(1998~)		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	GS300(1998~)		VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
LEXUS	GS300(1998~)		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
LEXUS	GS300(1998~)		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
LEXUS	GS300(1998~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GS300(1998~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS300(1998~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS300(1998~)		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS300(1998~)		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GS300(1998~)		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GS300(1998~)		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS300(1998~)		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS300(1998~)		DRIVER SEAT SW			OBD-II 16PIN CONNECTOR			O				
LEXUS	GS300(1998~)		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS300(1998~)		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS300(1998~)		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1998~)		PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS147 WITH O2	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS147 WITH O2	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS147 W/O O2	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 1995~	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS147 WITH O2	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS147 W/O O2	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	GS300(1996~1997)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 1995~	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	GS300(1996~1997)		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GS300(1996~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS300(1996~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GS300(1996~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS300(1996~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS300(1996~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GS300(1996~1997)		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	GS300(1996~1997)		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GS300(1996~1997)		TRACTION CONTROL SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GS300(1996~1997)		AIR CONDITION SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GS300(1996~1997)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GS300(1996~1997)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS300(1996~1997)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS300(1996~1997)		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GS300(1996~1997)		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	GS300(~1995)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS147 WITH O2	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	GS300(~1995)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	JZS147 W/O O2	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	GS300(~1995)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 1995~	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	GS300(~1995)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS147 WITH O2	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	GS300(~1995)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	JZS147 W/O O2	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	GS300(~1995)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 1995~	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	GS300(~1995)		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GS300(~1995)		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GS300(~1995)		TRANSMISSION CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GS300(~1995)		TRACTION CONTROL SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GS300(~1995)		AIR CONDITION SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GS300(~1995)		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	GS300(~1995)		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	GS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS350		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
LEXUS	GS350		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY
LEXUS	GS350		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	GS350		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS350		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GS350		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS350		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS350		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GS350		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	GS350		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	GS350		FOUR WHEEL DRIVE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GS350		EMS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		STABILIZER			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS350		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
LEXUS	GS350		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
LEXUS	GS350		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	GS350		VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
LEXUS	GS350		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
LEXUS	GS350		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GS350		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS350		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS350		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS350		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GS350		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS350		DRIVER SEAT SW			OBD-II 16PIN CONNECTOR			O				
LEXUS	GS350		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS350		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS350		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS350		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS350		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS350		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
LEXUS	GS400		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS400		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS400		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS400		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS400		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS400		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GS400		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS400		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS400		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS400		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS400		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS400		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS400		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GS400		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS400		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS400		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GS400		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	GS400		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	GS400		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GS400		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS400		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS400		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS400		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS400		MIRROR			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	GS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS430		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
LEXUS	GS430		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY
LEXUS	GS430		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	GS430		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS430		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS430		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GS430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GS430		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	GS430		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	GS430		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS430		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	GS430		EMS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		STABILIZER			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS430		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
LEXUS	GS430		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
LEXUS	GS430		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	GS430		VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
LEXUS	GS430		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GS430		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
LEXUS	GS430		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GS430		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS430		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS430		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS430		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GS430		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GS430		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS430		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS430		DRIVER SEAT SW			OBD-II 16PIN CONNECTOR			O				
LEXUS	GS430		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS430		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS430		MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		MIRROR			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	GS430		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS430		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS430		PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS430		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
LEXUS	GS450H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS450H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS450H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS450H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS450H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS450H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS450H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS450H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS450H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GS450H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS450H		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS450H		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION
LEXUS	GS450H		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS450H		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			HV-BATTERY INITIALIZATION ONBOARD EQUALIZING CHARGE
LEXUS	GS450H		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		HYBRID GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GS450H		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	GS450H		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	GS450H		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS450H		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GS450H		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS450H		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GS450H		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GS450H		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	GS450H		EMS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		STABILIZER			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS450H		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
LEXUS	GS450H		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
LEXUS	GS450H		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	GS450H		VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
LEXUS	GS450H		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
LEXUS	GS450H		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
LEXUS	GS450H		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
LEXUS	GS450H		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GS450H		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS450H		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS450H		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS450H		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GS450H		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GS450H		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION
LEXUS	GS450H		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS450H		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS450H		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS450H		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GS450H		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS450H		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS450H		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS450H		DRIVER SEAT SW			OBD-II 16PIN CONNECTOR			O				
LEXUS	GS450H		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS450H		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS450H		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS450H		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS450H		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS450H		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS450H		PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS450H		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
LEXUS	GS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GS460		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
LEXUS	GS460		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY
LEXUS	GS460		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GS460		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	GS460		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS460		EMS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		STABILIZER			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS460		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
LEXUS	GS460		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
LEXUS	GS460		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	GS460		VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
LEXUS	GS460		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
LEXUS	GS460		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
LEXUS	GS460		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
LEXUS	GS460		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GS460		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS460		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS460		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS460		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS460		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GS460		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	GS460		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION
LEXUS	GS460		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GS460		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS460		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS460		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS460		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS460		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS460		DRIVER SEAT SW			OBD-II 16PIN CONNECTOR			O				
LEXUS	GS460		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS460		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS460		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS460		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GS460		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	GS460		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GS460		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
LEXUS	GX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	GX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	GX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	GX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	GX470		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GX470		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GX470		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GX470		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GX470		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GX470		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GX470		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	GX470		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	GX470		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	GX470		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	GX470		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	GX470		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GX470		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	GX470		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
LEXUS	GX470		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	GX470		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	GX470		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	GX470		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	GX470		MIRROR			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	IS200		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS200		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS200		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS200		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS200		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS200		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	IS200		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS200		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS200		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS200		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS200		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS200		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	IS200		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	IS200		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MANUAL TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	IS200		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	IS200		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	IS200		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS200		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS200		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS200		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	IS200		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	IS200		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	IS200		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	IS200		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	IS200		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	IS200		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS200		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	IS200		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS200		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS200		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
LEXUS	IS200		BODY			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	IS200		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS200		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS220D		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS220D		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS220D		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS220D		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	IS220D		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS220D		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS220D		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS220D		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS220D		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	IS220D		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	IS220D		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	IS220D		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
LEXUS	IS220D		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
LEXUS	IS220D		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
LEXUS	IS220D		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
LEXUS	IS220D		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	IS220D		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS220D		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS220D		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS220D		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	IS220D		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	IS220D		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION
LEXUS	IS220D		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS220D		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	IS220D		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS220D		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	IS220D		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS220D		MIRROR L			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	IS220D		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS220D		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	IS220D		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS220D		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	IS250		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS250		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS250		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS250		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS250		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	IS250		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS250		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS250		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS250		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS250		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	IS250		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
LEXUS	IS250		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY
LEXUS	IS250		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	IS250		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	IS250		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	IS250		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
LEXUS	IS250		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	IS250		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
LEXUS	IS250		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	IS250		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS250		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS250		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS250		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	IS250		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS250		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS250		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	IS250		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS250		MIRROR L			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS250		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	IS250		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS250		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	IS250		PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS300		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS300		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS300		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS300		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS300		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS300		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	IS300		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS300		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS300		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS300		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS300		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	IS300		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	IS300		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	IS300		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MANUAL TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	IS300		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	IS300		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	IS300		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS300		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS300		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS300		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	IS300		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	IS300		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	IS300		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	IS300		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	IS300		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	IS300		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS300		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	IS300		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS300		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS300		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
LEXUS	IS300		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS300		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS300		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	IS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	IS350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	IS350		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS350		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	IS350		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS350		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS350		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS350		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	IS350		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS350		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS350		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS350		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	IS-F		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	IS-F		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	IS-F		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	IS-F		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS-F		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
LEXUS	IS-F		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
LEXUS	IS-F		ENTRY&START			OBD-II 16PIN CONNECTOR	O		O	O			KEY CODE ERASURE KEY CODE REGISTRATION
LEXUS	IS-F		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
LEXUS	IS-F		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	IS-F		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS-F		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS-F		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS-F		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	IS-F		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	IS-F		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION
LEXUS	IS-F		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	IS-F		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS-F		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	IS-F		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS-F		MIRROR L			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	IS-F		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	IS-F		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	IS-F		POWER SOURCE CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	IS-F		PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS400(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS400(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS400(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS400(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LS400(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	LS400(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS400(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS400(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS400(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS400(1998~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LS400(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LS400(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	LS400(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LS400(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LS400(1998~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	LS400(1998~)		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	LS400(1998~)		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1998~)		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	LS400(1998~)		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1998~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	LS400(1998~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS400(1998~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	LS400(1998~)		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1998~)		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	LS400(1998~)		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1998~)		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1998~)		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1998~)		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1998~)		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1998~)		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1998~)		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1998~)		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	USA 1994~	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	LS400(1995~1997)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	USA 1994~	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	LS400(1995~1997)		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS400(1995~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LS400(1995~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	LS400(1995~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LS400(1995~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LS400(1995~1997)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	LS400(1995~1997)		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	LS400(1995~1997)		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS400(1995~1997)		TRACTION CONTROL SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS400(1995~1997)		AIR CONDITION SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS400(1995~1997)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	LS400(1995~1997)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS400(1995~1997)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	LS400(1995~1997)		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS400(1995~1997)		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	LS400(1991~1994)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	UCF10 WITH O2 -9208	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	LS400(1991~1994)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	UCF10 WITH O2 9208-	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	LS400(1991~1994)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	UCF10 W/O O2 -9208	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	LS400(1991~1994)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	UCF10 W/O O2 9208-	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	LS400(1991~1994)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	UCF20 WITH O2 -9608	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	LS400(1991~1994)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	UCF20 W/O O2 -9608	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	LS400(1991~1994)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	UCF10 WITH O2 -9208	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	LS400(1991~1994)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	UCF10 WITH O2 9208-	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	LS400(1991~1994)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	UCF10 W/O O2 -9208	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	LS400(1991~1994)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	UCF10 W/O O2 9208-	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	LS400(1991~1994)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	UCF20 WITH O2 -9608	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	LS400(1991~1994)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	UCF20 W/O O2 -9608	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	LS400(1991~1994)		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS400(1991~1994)		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS400(1991~1994)		TRANSMISSION CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS400(1991~1994)		TRACTION CONTROL SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS400(1991~1994)		AIR CONDITION SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS400(1991~1994)		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS400(1991~1994)		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	LS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	LS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LS430		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
LEXUS	LS430		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY
LEXUS	LS430		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	LS430		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS430		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS430		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LS430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	LS430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LS430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LS430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	LS430		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	LS430		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS430		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	LS430		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	LS430		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS430		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	LS430		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
LEXUS	LS430		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	LS430		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	LS430		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	LS430		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		REAR LEFT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		REAR RIGHT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		REAR SEAT SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS430		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS430		STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS430		STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR			O				
LEXUS	LS430		MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		MIRROR			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	LS430		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS430		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS430		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS430		PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS450		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	LS450		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MANUAL TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	LS450		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	LS450		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	LS450		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS450		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS450		TRANSMISSION CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS450		AIR CONDITION SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS450		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	LS450		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	LS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS460		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	LS460		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
LEXUS	LS460		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY
LEXUS	LS460		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	LS460		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	LS460		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS460		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
LEXUS	LS460		VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
LEXUS	LS460		ELECTRIC PARKING BRAKE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY
LEXUS	LS460		IPA			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	LS460		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
LEXUS	LS460		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
LEXUS	LS460		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	LS460		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS460		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	LS460		ECM GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
LEXUS	LS460		ECB GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
LEXUS	LS460		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION
LEXUS	LS460		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		REAR LEFT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		REAR RIGHT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS460		DRIVER SEAT SW			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		CENTER CONSOLE SWITCH			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	LS460		REAR CONSOLE SWITCH			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		FRONT LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		FRONT RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		REAR LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		REAR RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS460		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		COMBINATION SW			OBD-II 16PIN CONNECTOR			O				
LEXUS	LS460		STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR			O				
LEXUS	LS460		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	LS460		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		ELECTRIC POWER CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		PRE-CRASH			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS460		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
LEXUS	LS600H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	LS600H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS600H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS600H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS600H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS600H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LS600H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS600H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LS600H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS600H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LS600H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LS600H		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS600H		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION
LEXUS	LS600H		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS600H		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			HV-BATTERY INITIALIZATION ONBOARD EQUALIZING CHARGE
LEXUS	LS600H		HYBRID BATTERY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		HYBRID GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	LS600H		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	LS600H		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	LS600H		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS600H		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	LS600H		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O	O	O				TORQUE SENSOR ADJUSTMENT
LEXUS	LS600H		VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
LEXUS	LS600H		ELECTRIC PARKING BRAKE			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY
LEXUS	LS600H		IPA			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	LS600H		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
LEXUS	LS600H		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	LS600H		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	LS600H		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS600H		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	LS600H		ECM GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
LEXUS	LS600H		ECB GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				INITIALIZATION
LEXUS	LS600H		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION
LEXUS	LS600H		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		REAR LEFT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		REAR RIGHT SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LS600H		DRIVER SEAT SW			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		CENTER CONSOLE SWITCH			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	LS600H		REAR CONSOLE SWITCH			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		FRONT LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		FRONT RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		REAR LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		REAR RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		REAR LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		REAR RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LS600H		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		COMBINATION SW			OBD-II 16PIN CONNECTOR			O				
LEXUS	LS600H		STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR			O				
LEXUS	LS600H		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	LS600H		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		PRE-CRASH			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LS600H		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
LEXUS	LX430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LX430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	LX430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LX430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LX430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	LX430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LX430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LX430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	LX430		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	LX430		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	LX430		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	LX430		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LX430		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	LX430		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	LX430		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX430		MIRROR			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	LX450		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX450		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX450		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX450		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX450		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX450		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LX450		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	LX450		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX450		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX450		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX450		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX450		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LX450		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LX450		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	LX450		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LX450		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LX450		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	LX450		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	LX450		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX450		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	LX450		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX450		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	LX450		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LX450		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	LX450		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX450		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	LX450		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX450		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	LX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX470		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LX470		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	LX470		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LX470		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	LX470		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LX470		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	LX470		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	LX470		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	LX470		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX470		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	LX470		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	LX470		VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
LEXUS	LX470		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX470		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	LX470		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LX470		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	LX470		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
LEXUS	LX470		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX470		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	LX470		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX470		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX470		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX470		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX470		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX470		MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX470		MIRROR			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	LX470		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LX470		WIPER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX570		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX570		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX570		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX570		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX570		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX570		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LX570		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	LX570		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX570		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	LX570		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX570		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	LX570		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	LX570		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	LX570		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	LX570		VGRS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE COUNT CLEAR STEERING ANGLE ADJUST
LEXUS	LX570		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
LEXUS	LX570		ENTRY&START			OBD-II 16PIN CONNECTOR	O	O	O	O			COMMUNICATION CHECK KEY CODE ERASURE KEY CODE REGISTRATION ID CODE BOX AND STEERING LOCK
LEXUS	LX570		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	LX570		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LX570		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	LX570		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	LX570		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	LX570		GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	LX570		ACCESSORY GATEWAY			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	LX570		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION
LEXUS	LX570		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX570		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX570		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX570		DRIVER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LX570		PASSENGER DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LX570		REAR RIGHT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LX570		REAR LEFT DOOR MOTOR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LX570		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX570		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	LX570		FRONT LEFT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX570		FRONT RIGHT SEAT A/C			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	LX570		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LX570		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LX570		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LX570		CLEARANCE SONAR			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LX570		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O	O	O				
LEXUS	LX570		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	LX570		PRE-CRASH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	RX300		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX300		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX300		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX300		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	RX300		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX300		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX300		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX300		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX300		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	RX300		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	RX300		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	RX300		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	RX300		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	RX300		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	RX300		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	RX300		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	RX300		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	RX300		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	RX300		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX300		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	RX300		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	RX300		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX300		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	RX330		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX330		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX330		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX330		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	RX330		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX330		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX330		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX330		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX330		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	RX330		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX330		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX330		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX330		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	RX330		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	RX330		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	RX330		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	RX330		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	RX330		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	RX330		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	RX330		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	RX330		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX330		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	RX330		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	RX330		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX330		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	RX330		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX330		MIRROR			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	RX330		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX330		WIPER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX350		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	RX350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX350		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	RX350		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	RX350		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	RX350		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	RX350		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	RX350		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	RX350		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	RX350		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	RX350		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	RX350		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	RX350		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O	O	O	O			SERVOMOTOR INITIALIZATION
LEXUS	RX350		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	RX350		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX350		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	RX350		MAIN BODY			OBD-II 16PIN CONNECTOR	O	O	O	O			INITIALIZATION
LEXUS	RX350		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	RX350		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX350		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		COMBINATION METER			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	RX350		MIRROR L			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX350		WIPER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX350		AFS			OBD-II 16PIN CONNECTOR	O	O	O	O			
LEXUS	RX350		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
LEXUS	RX400H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX400H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX400H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX400H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX400H		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	RX400H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX400H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	RX400H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX400H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	RX400H		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	RX400H		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX400H		HYBRID CONTROL			OBD-II 16PIN CONNECTOR	O	O	O	O		O	INITIALIZATION
LEXUS	RX400H		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	RX400H		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	RX400H		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	RX400H		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	RX400H		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	RX400H		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	RX400H		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR) TEST MODE(STEERING ADJUST) RESET MEMORY
LEXUS	RX400H		EMPS/EHPS			OBD-II 16PIN CONNECTOR	O		O				RECORDS CLEARANCE TORQUE SENSOR ADJUSTMENT
LEXUS	RX400H		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	RX400H		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	RX400H		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX400H		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	RX400H		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	RX400H		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	RX400H		BODY			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		BODY			OBD-II 16PIN CONNECTOR	O						
LEXUS	RX400H		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		BACK DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		MASTER SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX400H		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		MIRROR L			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		RAIN SENSOR			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	RX400H		WIPER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		AFS			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	RX400H		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MANUAL TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	SC300(1996~)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	SC300(1996~)		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC300(1996~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	SC300(1996~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	SC300(1996~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	SC300(1996~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	SC300(1996~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	SC300(1996~)		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	SC300(1996~)		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC300(1996~)		AIR CONDITION SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC300(1996~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	SC300(1996~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	SC300(1996~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	SC300(1996~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	SC300(1996~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	SC300(1996~)		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC300(1996~)		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	SC300(1992~1995)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	SC300(1992~1995)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	SC300(1992~1995)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	SC300(1992~1995)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	SC300(1992~1995)		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC300(1992~1995)		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC300(1992~1995)		TRANSMISSION CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC300(1992~1995)		AIR CONDITION SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC300(1992~1995)		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC300(1992~1995)		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	SC400(1996~)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	SC400(1996~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	SC400(1996~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	SC400(1996~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	SC400(1996~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	SC400(1996~)		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	SC400(1996~)		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	SC400(1996~)		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC400(1996~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	SC400(1996~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	SC400(1996~)		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	SC400(1996~)		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC400(1996~)		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	SC400(1992~1995)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	SC400(1992~1995)		ENGINE & TRANSMISSION	SEMI-CIRCULAR CONNECTOR	MANUAL TRANSMISSION	17PIN RECTANGULAR CONNECTOR	O		O				
LEXUS	SC400(1992~1995)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	AUTOMATIC TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	SC400(1992~1995)		ENGINE & TRANSMISSION	RECTANGULAR CONNECTOR	MANUAL TRANSMISSION	17PIN SEMI-CIRCULAR CONNECTOR	O		O				
LEXUS	SC400(1992~1995)		CRUISE CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC400(1992~1995)		ANTI-LOCK BRAKE SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC400(1992~1995)		TRANSMISSION CONTROL			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC400(1992~1995)		AIR CONDITION SYSTEM			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC400(1992~1995)		SRS-AIRBAG			17PIN SEMI-CIRCULAR CONNECTOR	O						
LEXUS	SC400(1992~1995)		SRS-AIRBAG			17PIN RECTANGULAR CONNECTOR	O						
LEXUS	SC430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	SC430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	SC430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	SC430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	SC430		ENGINE & TRANSMISSION	16PIN CONNECTOR	GASOLINE	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	SC430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	SC430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	SC430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY CATALYST RECORD
LEXUS	SC430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O		O	O			RESETTING ADAPTIVE VALUES
LEXUS	SC430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O			RESETTING ADAPTIVE VALUES
LEXUS	SC430		ENGINE & TRANSMISSION	16PIN CONNECTOR	DIESEL	OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE SUPPLY PUMP INITIALIZATION INJECTOR COMPENSATION RESET MEMORY ELECTRIC THROTTLE LEARNING DECEL. SENSOR 0 POINT CALI. CVT OIL PRESSURE CALI.
LEXUS	SC430		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O			CHECK MODE RESET MEMORY
LEXUS	SC430		ECT			OBD-II 16PIN CONNECTOR	O	O	O	O		O	CHECK MODE RESET MEMORY
LEXUS	SC430		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O	O	O			O	
LEXUS	SC430		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	SC430		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	SC430		CRUISE CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	SC430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	SC430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	SC430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	SC430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	SC430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O		O				PROGRAM MODE
LEXUS	SC430		IMMOBILISER			OBD-II 16PIN CONNECTOR	O	O	O	O			PROGRAM MODE
LEXUS	SC430		ANTI-LOCK BRAKE SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			RESET MEMORY TEST MODE(STEERING ADJUST) AIR BLEEDING MODE BACKUP MEMORY DELETION ECB UTILITY - ZERO DOWN INITIAL LINEAR VALVE LEARNING INITIAL (YAW RATE & G SENSOR)
LEXUS	SC430		TRANSMISSION CONTROL			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	SC430		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		AHC&AIR SUSPENSION			OBD-II 16PIN CONNECTOR	O	O	O	O			HEIGHT OFFSET
LEXUS	SC430		TIRE PRESSURE MONITOR			OBD-II 16PIN CONNECTOR	O		O				TIRE ID REGISTRATION
LEXUS	SC430		AIR CONDITION SYSTEM			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	SC430		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	SC430		SRS-AIRBAG			OBD-II 16PIN CONNECTOR	O						
LEXUS	SC430		THEFT DETERRENT			OBD-II 16PIN CONNECTOR	O		O	O			PROGRAM MODE
LEXUS	SC430		GATEWAY			OBD-II 16PIN CONNECTOR	O						
LEXUS	SC430		GATEWAY			OBD-II 16PIN CONNECTOR	O	O					
LEXUS	SC430		BODY2			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		BODY3			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		BODY4			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		BODY5			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		DRIVER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		PASSENGER DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		REAR LEFT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		REAR RIGHT DOOR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		DRIVER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		PASSENGER SEAT			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		SLIDE ROOF			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		TILT & TELESCOPIC			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		COMBINATION METER			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		COMBINATION SW			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	SC430		STEERING PAD SWITCH			OBD-II 16PIN CONNECTOR	O		O				
LEXUS	SC430		MIRROR			OBD-II 16PIN CONNECTOR	O		O	O			
LEXUS	SC430		MIRROR			OBD-II 16PIN CONNECTOR			O	O			
LEXUS	SC430		AFS			OBD-II 16PIN CONNECTOR	O		O	O			

TOYOTA/LEXUS VEHICLE COVERAGE

MAKER	CAR1	CAR2	SYSTEM1	SYSTEM2	SYSTEM3	DLC ADPATER	DTC	HISTORY DTC	CURRENT	ACTUATOR	FREEZE FRAME	ECU INFO FUNC	SPECIAL FUNCTION
LEXUS	SC430		OCCUPANT DETECTION			OBD-II 16PIN CONNECTOR	O		O				SENSITIVITY CHECK ZERO POINT CALIBRATION