FCAR Diagnostic List fuso_v7.83

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Models	Type	System	Version info.	Read DTC	Clear DTC	Data stream	Action test	Special Function	Remark
Test by System	Power transmission	Engine Systems	√	√	√	√	√	√	
		Integrated control	√	√	√	√	√	–	
		Transmission	√	√	√	√	–	–	
		Integrated security system	√	√	√	√	–	–	
		Motor control	√	√	√	√	–	–	
		Battery control	√	√	√	√	–	–	
		Airbag	√	√	√	√	–	–	
		SCR	√	√	√	√	–	–	
	Chassis	ABS	√	√	√	√	√	–	
		Retarder	√	√	√	–	–	–	
	Car body	Anti-theft system	√	√	√	√	√	–	
		EZGO	√	√	√	–	–	–	
Test by Vehicle	Canter	EEC-Combustion engine Control unit	√	√	√	√	√	√	
		TCM-DUONIC Control unit	√	√	√	√	√	√	
		ABS-Antilock brake system Control unit	√	√	√	√	√	√	
		SRS-Supplemental restraint system Control unit	√	√	√	–	–	–	
		ICUC-Instrument panel	√	√	√	√	√	√	
		IMMO-Immobilizer Control unit	√	√	√	√	√	–	
		EZGO-Hill Start Assist Control unit	√	√	√	√	√	√	
		HLAL-Control unit 'Automatic headlamp adjustment'	√	√	√	√	–	√	
		HVAC-Control and operating unit 'Automotive air conditioning'	√	√	√	√	√	–	
		ISS-Automatic engine start/stop Control unit	√	√	√	√	√	√	
		SSAM-Signal Actuator Module	√	√	√	√	√	√	
	Fighter	ACM-AdBlue exhaust aftertreatment unit	√	√	√	√	√	–	