


How to use Actia PassThru device with Honda HDS software

1. Install HDS software v2.21 or newer.
2. Double click on *Honda HDS PassThru.reg*, agree to add data to registry.
3. Install PassThru drivers with default parameters (latest version available from <http://www.passthruxs.com/download.htm>, named *API Passthru+ XS for Workshop*)
4. Run HDS, go to configuration page, for *Comms Interface* select *SPX-MVCI*:



5. Done!