

MaxiDiag_Infiniti_V2.30 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.

Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data	Freeze Frame Data
ENGINE	●	●	●	※	●
AT/CVT	●	●	●	※	●
ABS	●	●	●	※	●
AIRBAG	○	●	●	○	○
Traction Control System	●	●	●	●	●
BCM	※	●	●	○	●
Electric Power Steering	●	●	●	○	●
4WD/E-4WD/AWD	●	●	●	※	●
Smart Entrance	○	●	●	※	●
ACT	●	●	●	●	●
Active Sus	●	●	●	●	●
Auto Speed Control Device	○	●	○	○	●
Air Pressure Monitor	※	●	○	○	●
Adaptive Light	●	●	●	○	●
Auto Slide Door	●	●	●	○	●
Diff Lock	○	●	●	○	●
Driver Position	●	●	●	○	●
Head Lamp Levelizer	●	●	●	○	●
HICAS	●	●	●	○	●
ICC	●	●	●	※	●
Intelligent Key	●	●	●	○	●
IPDM E/R	○	●	●	○	●
METER	○	●	●	○	●
Meter AC AMP	●	●	●	○	●
Motor Assist	○	●	●	○	●
Multi AV	※	●	●	○	●
Precrash Seatbelt	●	●	●	○	●
Rearview Camera	●	○	○	○	●
Sblind Camera	●	○	○	○	●
Heating and Air	●	●	●	○	●
Hybrid	●	●	●	○	●
Lane Camera	●	●	●	○	●
Air Levelizer	●	●	●	○	●
Sonar	●	●	●	○	●

Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data	Freeze Frame Data
Auto Back Door	○	●	●	○	●
Total Illum C/U	●	○	○	○	●
Cinvertible Roof	●	●	●	○	●