

TPMS_Bugatti_V1.11 Function List (Note:For reference only)

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Control Unit	ECU Information	Read Codes	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function (●)	Special Function (※)
ABS Brakes	●	●	●	●	※	●	1. 0001 2. 0002 3. 0003 4. 0004 5. 0005	1. 0006 2. 0007 3. 0008 4. 0009
Tire Pressure II	●	●	●	●	※	●	1. 0001 2. 0002 3. 0003 4. 0004 5. 0005	1. 0006 2. 0007 3. 0008 4. 0009
Tire Pressure	●	●	●	●	※	●	1. 0001 2. 0002 3. 0003 4. 0004 5. 0005	1. 0006 2. 0007 3. 0008 4. 0009



Specil_Function

Index	Specil Function Name	Index	Specil Function Name
0001	Coding	0002	Basic Settings
0003	Adaptation	0004	Security Access
0005	AdvancedDataStream	0006	Single Reading
0007	Login CodingII	0008	Readiness
0009	Advanced ID		