

MaxiDiagElite_Eobd_V1.43 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Function	Mode	ISO 15765-4 (CAN)	SAE J1850 (PWM)	SAE J1850 (VPW)	ISO 14230-4 (KWP2000)	ISO 9141-2
DTC&FFD	\$02, \$03, \$04, \$07	●	●	●	●	●
DTC&FFD	\$0a	●	○	○	○	○
Live Data	\$01	●	●	●	●	●
Vehicle Status	\$01	●	●	●	●	●
I/M Readiness	\$01	●	●	●	●	●
02 Sensor Monitor	\$05	○	●	●	●	●
On-Board Monitor	\$06	●	●	●	●	●
Component Test	\$08	●	●	●	●	●
Vehicle Info.	\$09	●	●	●	●	●