

TPMS_Seat_V1.11 Function List (Note:For reference only)

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

| Control Unit | ECU Information | Read Codes | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function (●) | Special Function (※) |
|------------------|-----------------|------------|-------------|-----------|--------------|-------------|--|--------------------------------------|
| ABS Brakes | ● | ● | ● | ● | ※ | ● | 1.0001 2.0002 3.0003 4.0004 5.0005 | 1.0006 2.0007 3.0008 4.0009 |
| Tire Pressure II | ● | ● | ● | ● | ※ | ● | 1.0001 2.0002 3.0003 4.0004 5.0005 | 1.0006 2.0007 3.0008 4.0009 |
| Tire Pressure | ● | ● | ● | ● | ※ | ● | 1.0001 2.0002 3.0003 4.0004 5.0005 | 1.0006 2.0007 3.0008 4.0009 |



Specil_Function

| Index | Specil Function Name | Index | Specil Function Name |
|-------|----------------------|-------|----------------------|
| 0001 | Coding | 0002 | Basic Settings |
| 0003 | Adaptation | 0004 | Security Access |
| 0005 | AdvancedDataStream | 0006 | Single Reading |
| 0007 | Login CodingII | 0008 | Readiness |
| 0009 | Advanced ID | | |