

MaxiSys_Dodge_V6.30 Function List (Note:For reference only)

NOTES:

- This function is supported.
 - This function is not supported.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
 - ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
1996~2003	All Model	PCM	●	●	●	●	●	●	○	C000 C001 C002 C003 C004 C005 C006 C007 C008 C009 C00A C00B C00C C00D C00E C00F C010 C011 C012 C013 C014 C015 C016 C017 C018 C019
1996~2003	All Model	TCM	○	●	●	●	●	●	○	C02D C02E C02F C030 C031 C032 C033 061F 0391 0625 0626
1996~2003	All Model	ABS	○	●	●	●	○	●	○	002F 0577 0578
1996~2003	All Model	ORC	○	●	●	●	○	○	○	0622 0623
1996~2003	All Model	SKM	○	●	●	●	○	●	○	C01A C01B C01C C01D C01E C01F C020 C021 C022 C023 C024 C025 C026 C027 C028 C029 C02A C02B C02C
1996~2003	All Model	APM	○	●	●	●	○	●	○	0579
1996~2003	All Model	ATC	○	●	●	●	○	●	○	057A 057B 057C
1996~2003	All Model	AUD	○	●	●	●	○	○	○	057D 057E 057F
1996~2003	All Model	BCM	○	●	●	●	○	●	○	0581 008F 003D 0582 0583 0584 0585 057A 0586 0587 0588 0589 058A 008E 058B 058C 058D 058E 058F 0590 0591 0592 049F 0593 0594 0595 0596 0597 0598 0599 059A 059C 059D 059E 059F 0600 0601
1996~2003	All Model	CMT	○	●	●	○	○	○	○	
1996~2003	All Model	DAA	○	●	●	○	○	○	○	0602 0603 0604 0605 0606 0607 01C8 0608 0609
1996~2003	All Model	DDM	○	●	●	●	○	●	○	060A 057A 060B 0592 060C
1996~2003	All Model	DSD	○	●	●	●	○	●	○	060D 057A
1996~2003	All Model	FCM	○	●	●	●	○	●	○	060E 060F 003F 003D 0610 0611 0612
1996~2003	All Model	FDC	○	●	●	●	○	○	○	0613
1996~2003	All Model	HFM	○	●	●	●	○	●	○	057A
1996~2003	All Model	HVA	○	●	●	●	○	●	○	0614 0615 0616 0617 0618
1996~2003	All Model	LSA	○	●	●	○	○	○	○	
1996~2003	All Model	MIC	○	●	●	●	○	●	○	
1996~2003	All Model	MSM	○	●	●	●	○	●	○	
1996~2003	All Model	NAV	○	●	●	○	○	○	○	0619
1996~2003	All Model	OCM	○	○	○	●	○	○	○	057A 0620 0621 0608
1996~2003	All Model	PAM	○	●	●	●	○	○	○	
1996~2003	All Model	PDM	○	●	●	●	○	●	○	0610 060B 057A 0592 060C
1996~2003	All Model	PLM	○	●	●	●	○	●	○	0624 061A 060D 061B 00B4 00B5 057A 061C 061D
1996~2003	All Model	PSD	○	●	●	●	○	●	○	0624 061A 060D 061B 00B4 00B5 057A
1996~2003	All Model	RSA	○	●	●	○	○	○	○	
1996~2003	All Model	RSM	○	●	●	○	○	○	○	
1996~2003	All Model	SAR	○	●	●	○	○	●	○	057F
1996~2003	All Model	SLA	○	○	○	●	○	●	○	
1996~2003	All Model	SRM	○	○	○	●	○	●	○	
1996~2003	All Model	VIC	○	●	●	○	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
1996~2003	All Model	VTS	○	○	○	●	○	●	○	0627 0628 008F 0582 0583 0587 0629 062A 062B 062C
1996~2003	All Model	XCM	○	○	○	●	○	●	○	062D
2004	Durango (Pre-2011)	OCM	○	●	●	●	●	○	○	011E
2004	Durango (Pre-2011)	RADIO	○	●	●	●	●	○	○	
2004	Durango (Pre-2011)	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A
2004	Durango (Pre-2011)	HFM	○	●	●	●	●	●	○	00E3
2004	Durango (Pre-2011)	TCM	○	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 0175
2004	Durango (Pre-2011)	ABS	○	●	●	●	●	●	●	0031 002E 002F 0030
2004	Durango (Pre-2011)	HSM	○	●	●	●	●	●	○	
2004	Durango (Pre-2011)	SDAR	○	●	●	●	●	○	○	
2004	Durango (Pre-2011)	VES	○	●	●	●	●	●	○	
2004	Durango (Pre-2011)	WCM	○	●	●	●	●	○	●	01D2 0228 0226 0225 0227
2004	Durango (Pre-2011)	DDM	○	●	●	●	●	●	●	00AC
2004	Durango (Pre-2011)	HVAC	○	●	●	●	●	●	○	00EA 00E8 0378 00E9 0324
2004	Durango (Pre-2011)	EOM	○	●	●	●	●	●	●	00BA 00BC
2004	Durango (Pre-2011)	ORC	○	●	●	●	●	○	●	
2004	Durango (Pre-2011)	PCM	○	●	●	●	●	●	●	0127 0126 0044 0129 026C 026D 0128 012E 012F 012C 012D 0381 0173 012A 012B 013B
2004	Durango (Pre-2011)	PDM	○	●	●	●	●	●	●	
2004	Durango (Pre-2011)	FCMCGW	○	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 0033 0040
2004	Durango (Pre-2011)	CCN	○	●	●	●	●	●	●	008C 008F 008E 0091 008D 0090
2004	Durango (Pre-2011)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2005	Durango (Pre-2011)	WCM	○	●	●	●	●	○	●	01D2 0228 0226 0225 0227
2005	Durango (Pre-2011)	HVAC	○	●	●	●	●	●	○	00EA 00E8 0378 00E9 0324
2005	Durango (Pre-2011)	ORC	○	●	●	●	●	○	●	
2005	Durango (Pre-2011)	TCM	○	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 0175
2005	Durango (Pre-2011)	RADIO	○	●	●	●	●	○	○	
2005	Durango (Pre-2011)	OCM	○	●	●	●	●	○	○	011E
2005	Durango (Pre-2011)	SDAR	○	●	●	●	●	○	○	
2005	Durango (Pre-2011)	PDM	○	●	●	●	●	●	●	
2005	Durango (Pre-2011)	HSM	○	●	●	●	●	●	○	
2005	Durango (Pre-2011)	VES	○	●	●	●	●	●	○	
2005	Durango (Pre-2011)	FCMCGW	○	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 0033 0040
2005	Durango (Pre-2011)	HFM	○	●	●	●	●	●	○	00E3
2005	Durango (Pre-2011)	DDM	○	●	●	●	●	●	●	00AC
2005	Durango (Pre-2011)	CCN	○	●	●	●	●	●	●	008C 008F 008E 0091 008D 0090
2005	Durango (Pre-2011)	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A
2005	Durango (Pre-2011)	EOM	○	●	●	●	●	○	●	00BC
2005	Durango (Pre-2011)	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0381 0173 012A 0482 012B 013B
2005	Durango (Pre-2011)	ABS	○	●	●	●	●	●	●	002F 002E 0031 0030
2005	Durango (Pre-2011)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2005	300 / Magnum / Charger (Pre-2011)	WCM	○	●	●	●	●	○	●	01D2 0228 0226 0225 0227
2005	300 / Magnum / Charger (Pre-2011)	HIDT	○	●	●	●	●	●	○	00E5
2005	300 / Magnum / Charger (Pre-2011)	FCMCGW	○	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 002E 0033
2005	300 / Magnum / Charger (Pre-2011)	ABS	○	●	●	●	●	●	●	005A 0058 0059 005E 005C 005D 005F 005B
2005	300 / Magnum / Charger (Pre-2011)	DDM	○	●	●	●	●	●	●	00AC
2005	300 / Magnum / Charger (Pre-2011)	LRSM	○	●	●	●	●	○	●	010D
2005	300 / Magnum / Charger (Pre-2011)	PDM	○	●	●	●	●	●	●	00AC
2005	300 / Magnum / Charger (Pre-2011)	ORC	○	●	●	●	●	○	●	
2005	300 / Magnum / Charger (Pre-2011)	EOM	○	●	●	●	●	●	●	00BA 00BC
2005	300 / Magnum / Charger (Pre-2011)	HFM	○	●	●	●	●	●	○	00E3
2005	300 / Magnum / Charger (Pre-2011)	SCM	○	●	●	●	○	●	●	
2005	300 / Magnum / Charger (Pre-2011)	SUNR	○	●	●	●	●	●	○	
2005	300 / Magnum / Charger (Pre-2011)	OCM	○	●	●	●	●	○	○	011E
2005	300 / Magnum / Charger (Pre-2011)	HVAC	○	●	●	●	●	●	○	00EA 00E9
2005	300 / Magnum / Charger (Pre-2011)	SDAR	○	●	●	●	●	○	○	
2005	300 / Magnum / Charger (Pre-2011)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2005	300 / Magnum / Charger (Pre-2011)	PTS	○	●	●	●	●	●	○	01B4 01B3 01B5
2005	300 / Magnum / Charger (Pre-2011)	TCM	○	●	●	●	●	●	●	01F4 01F3 01F2 0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 01F1 0177 01EF 0175
2005	300 / Magnum / Charger (Pre-2011)	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0381 0173 012A 0482 012B 013B
2005	300 / Magnum / Charger (Pre-2011)	RADIO	○	●	●	●	●	○	○	
2005	300 / Magnum / Charger (Pre-2011)	CCN	○	●	●	●	●	●	○	008F 008E 0382 0090 0383
2005	300 / Magnum / Charger (Pre-2011)	ESM	○	●	●	●	●	●	○	
2005	300 / Magnum / Charger (Pre-2011)	HSM	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2005	300 / Magnum / Charger (Pre-2011)	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A
2005	Dakota	EOM	○	●	●	●	●	○	●	00BC
2005	Dakota	RADIO	○	●	●	●	●	○	○	
2005	Dakota	OCM	○	●	●	●	●	○	○	011E
2005	Dakota	CCN	○	●	●	●	●	●	●	008C 008F 008E 0091 008D 0090
2005	Dakota	WCM	○	●	●	●	●	○	●	01D2 0228 0226 0225 0227
2005	Dakota	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9
2005	Dakota	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A
2005	Dakota	TCM	○	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 0175
2005	Dakota	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0381 0173 012A 0482 012B 013B
2005	Dakota	ABS	○	●	●	●	●	●	●	005A 0002 005E
2005	Dakota	SDAR	○	●	●	●	●	○	○	
2005	Dakota	ORC	○	●	●	●	●	○	●	
2005	Dakota	HFM	○	●	●	●	●	●	○	00E3
2005	Dakota	FCMCGW	○	●	●	●	●	●	●	003C 003D 0032 00C4 003F 003E 0036 0037 0034 0038 003A 002E 0033
2005	Grand Cherokee	HVAC	○	●	●	●	●	●	○	00EA 00E9
2005	Grand Cherokee	ESM	○	●	●	●	●	●	○	
2005	Grand Cherokee	CCN	○	●	●	●	●	●	●	0097 008C 008F 008E 0091 0090
2005	Grand Cherokee	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2005	Grand Cherokee	ITM	○	●	●	●	●	●	●	0106
2005	Grand Cherokee	HSM	○	●	●	●	●	●	○	
2005	Grand Cherokee	AHBM	○	●	●	●	●	●	○	0066
2005	Grand Cherokee	ABS	○	●	●	●	●	●	●	005A 0058 0059 005E 005C 005D 005F 005B
2005	Grand Cherokee	ORC	○	●	●	●	●	○	●	
2005	Grand Cherokee	OCM	○	●	●	●	●	○	○	011E
2005	Grand Cherokee	PDM	○	●	●	●	●	●	●	
2005	Grand Cherokee	SCM	○	●	●	●	●	○	●	
2005	Grand Cherokee	SUNR	○	●	●	●	●	●	○	
2005	Grand Cherokee	DDM	○	●	●	●	●	●	●	00AC
2005	Grand Cherokee	WCM	○	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 022D 0227 0274
2005	Grand Cherokee	FCMCGW	○	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 0373 0374 0033 0040
2005	Grand Cherokee	PTS	○	●	●	●	●	●	○	01B4 01B3 01B5
2005	Grand Cherokee	VES	○	●	●	●	●	●	○	
2005	Grand Cherokee	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A
2005	Grand Cherokee	HFM	○	●	●	●	●	●	○	00E3
2005	Grand Cherokee	TCM	○	●	●	●	●	●	●	01F4 01F3 01F2 0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 0175
2005	Grand Cherokee	LRSM	○	●	●	●	●	○	○	010D
2005	Grand Cherokee	RADIO	○	●	●	●	●	○	○	
2005	Grand Cherokee	SDAR	○	●	●	●	●	○	○	
2005	Grand Cherokee	EOM	○	●	●	●	●	○	●	00BC

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2005	Grand Cherokee	FDCM	○	●	●	●	●	●	●	
2005	Grand Cherokee	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0381 0173 012A 0482 012B 013B 0042 0149 0142 0145 014B 014A 0148 0049 0146 0147
2006	Dodge Ram	HFM	○	●	●	●	●	●	○	00E3
2006	Dodge Ram	RADIO	○	●	●	●	●	○	●	
2006	Dodge Ram	EOM	○	●	●	●	●	○	●	00BC
2006	Dodge Ram	OCM	○	●	●	●	●	○	○	011E
2006	Dodge Ram	SDAR	○	●	●	●	●	○	○	
2006	Dodge Ram	AMP	○	●	●	●	●	○	●	028A 028D 006D 006C 027F 0068 006A
2006	Dodge Ram	VES	○	●	●	●	●	●	○	
2006	Dodge Ram	TCM	○	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 0175
2006	Dodge Ram	SUNR	○	●	●	●	●	●	○	
2006	Dodge Ram	HVAC	○	●	●	●	●	●	●	00EB 00E8 00E9 00EA
2006	Dodge Ram	ORC	○	●	●	●	●	○	●	
2006	Dodge Ram	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0386 0173 012A 0482 012B 013B 0486 0156 0157 0154 0155 0576 0141 0150 0151 0153 015A 0159 037D 0488 0158 0487 014F 0152
2006	Dodge Ram	FDCM	○	●	●	●	●	○	○	02B5 02B3 02B2 02B1 02AF 02B0
2006	Dodge Ram	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2006	Dodge Ram	WCM	○	●	●	●	●	○	●	01D2 0228 023F 0226 0225 0232 0230 0231 022F 01DE 0233 022D 023D 023E 0271 0270
2006	Dodge Ram	TIPMCGW	○	●	●	●	●	●	●	02DC 030C 0483 003D 0214 0032 003F 0484 0036 0037 0389 0034 0038 002E 020E 0215 028F 0211 0387 0388
2006	Dodge Ram	CCN	○	●	●	●	●	●	○	008C 008F 008E 0090
2006	Dodge Ram	JTEC Engine	○	●	●	●	○	●	○	
2006	Dodge Ram	PCI to CAN Gateway	○	●	●	●	●	○	○	
2006	Durango (Pre-2011)	HVAC	○	●	●	●	●	●	○	00EA 00E8 0378 00E9 0324
2006	Durango (Pre-2011)	OCM	○	●	●	●	●	○	○	011E
2006	Durango (Pre-2011)	WCM	○	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0233 022D 023D 023E 0271 0270 0227
2006	Durango (Pre-2011)	SAS	○	●	●	●	●	○	○	
2006	Durango (Pre-2011)	RADIO	○	●	●	●	●	○	●	
2006	Durango (Pre-2011)	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2006	Durango (Pre-2011)	PDM	○	●	●	●	●	●	●	
2006	Durango (Pre-2011)	HFM	○	●	●	●	●	●	○	00E3
2006	Durango (Pre-2011)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2006	Durango (Pre-2011)	VES	○	●	●	●	●	●	○	
2006	Durango (Pre-2011)	EOM	○	●	●	●	●	○	●	00BC
2006	Durango (Pre-2011)	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0381 0173 012A 0482 012B 013B
2006	Durango (Pre-2011)	TCM	○	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 0175
2006	Durango (Pre-2011)	SDAR	○	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	Durango (Pre-2011)	CCN	○	●	●	●	●	●	●	008C 008F 008E 0091 008D 0090
2006	Durango (Pre-2011)	FCMCGW	○	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 002E 0033 00C6 0040
2006	Durango (Pre-2011)	PLGM	○	●	●	●	●	●	●	038A 038B
2006	Durango (Pre-2011)	DDM	○	●	●	●	●	●	●	00AC
2006	Durango (Pre-2011)	HSM	○	●	●	●	●	●	○	
2006	Durango (Pre-2011)	AMP	○	●	●	●	●	○	●	0069 006D 0079 0068 0289 028A 006B 006C 006A
2006	Durango (Pre-2011)	ORC	○	●	●	●	●	○	●	
2006	Liberty	TCM	○	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 0175
2006	Liberty	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0381 0173 012A 0482 012B 013B
2006	Liberty	SAS	○	●	●	●	●	○	○	
2006	Liberty	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2006	Liberty	EOM	○	●	●	○	○	○	○	
2006	Liberty	HFM	○	●	●	●	○	●	○	
2006	Liberty	TCM	○	●	●	●	●	●	○	
2006	Liberty	RADIO	○	●	●	●	●	●	●	
2006	Liberty	MIC/CCN	○	●	●	●	○	●	○	008C 804F 8050 8051 8052
2006	Liberty	PCM	○	●	●	●	●	●	●	
2006	Liberty	SKREEM	○	●	●	●	●	○	○	8003 8004 8005 8006 8007 01D2 04A2 8008 8009 800A 800B 800C 01DE 800E 01DA
2006	Liberty	SDAR	○	●	●	●	●	●	○	
2006	Liberty	ORC	○	●	●	●	●	●	●	
2006	Liberty	BCM	○	●	●	●	○	●	○	0081 8018 8017 8015 8057 8012 003F 002E 8058
2006	Liberty	OCM	○	●	●	●	○	○	○	011E 801A 8023 8024
2006	Liberty	ITM	○	○	○	●	○	●	○	
2006	300 / Magnum / Charger (Pre-2011)	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0381 0173 012A 0482 012B 013B 0042 0149 0142 0145 0045 0046 014B 014A 0148 0049 014D 048A 0489 0146 0147 048B
2006	300 / Magnum / Charger (Pre-2011)	SCM	○	●	●	●	○	●	●	
2006	300 / Magnum / Charger (Pre-2011)	ESM	○	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	PDM	○	●	●	●	●	●	●	00AC
2006	300 / Magnum / Charger (Pre-2011)	FCMCGW	○	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0038 00C8 003A 002E 0033
2006	300 / Magnum / Charger (Pre-2011)	HSM	○	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	PTIM	○	●	●	●	●	●	●	
2006	300 / Magnum / Charger (Pre-2011)	HVAC	○	●	●	●	●	●	○	00EA 00E9
2006	300 / Magnum / Charger (Pre-2011)	VES	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	300 / Magnum / Charger (Pre-2011)	HFM	○	●	●	●	●	●	○	00E3
2006	300 / Magnum / Charger (Pre-2011)	AMP	○	●	●	●	●	○	●	0289 028B 028A 006D 006B 0073 006C 0068 006A 0069
2006	300 / Magnum / Charger (Pre-2011)	WCM	○	●	●	●	●	○	●	022E 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0233 022D 023D 023E 0271 0270 0227
2006	300 / Magnum / Charger (Pre-2011)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2006	300 / Magnum / Charger (Pre-2011)	TCM	○	●	●	●	●	●	●	038C 01F3 01F2 0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 0175
2006	300 / Magnum / Charger (Pre-2011)	EOM	○	●	●	●	●	○	●	00BA 00BC
2006	300 / Magnum / Charger (Pre-2011)	HIDT	○	●	●	●	●	●	○	00E5
2006	300 / Magnum / Charger (Pre-2011)	LRSM	○	●	●	●	●	○	○	010D
2006	300 / Magnum / Charger (Pre-2011)	AHBM	○	●	●	●	●	●	○	0066
2006	300 / Magnum / Charger (Pre-2011)	PTS	○	●	●	●	○	●	○	01B4 01B3 01B5 01B8
2006	300 / Magnum / Charger (Pre-2011)	DDM	○	●	●	●	●	●	●	00AC
2006	300 / Magnum / Charger (Pre-2011)	CCN	○	●	●	●	●	●	○	008F 008E 0382 038D 0090 0383
2006	300 / Magnum / Charger (Pre-2011)	SUNR	○	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 005A 0058 0059 005E 005C 005D 005F 005B
2006	300 / Magnum / Charger (Pre-2011)	OCM	○	●	●	●	●	○	○	011E
2006	300 / Magnum / Charger (Pre-2011)	ITM	○	●	●	●	●	●	●	0106
2006	300 / Magnum / Charger (Pre-2011)	RADIO	○	●	●	●	●	○	●	
2006	300 / Magnum / Charger (Pre-2011)	ORC	○	●	●	●	●	●	●	
2006	300 / Magnum / Charger (Pre-2011)	SDAR	○	●	●	●	●	○	○	
2006	Dakota	FCMCGW	○	●	●	●	●	●	●	0039 003C 003D 0032 00C4 003F 003E 0036 0037 0034 0038 003A 00C9 0033 0040
2006	Dakota	EOM	○	●	●	●	●	○	●	00BC
2006	Dakota	HFM	○	●	●	●	●	●	○	00E3
2006	Dakota	AMP	○	●	●	●	●	○	●	0069 006D 0079 0068 0289 028A 006B 006C 006A
2006	Dakota	CCN	○	●	●	●	●	●	●	008C 008F 008E 0091 008D 0090
2006	Dakota	ORC	○	●	●	●	●	○	●	
2006	Dakota	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9
2006	Dakota	RADIO	○	●	●	●	●	○	●	

[illegible]

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	PT Cruiser	PCM	○	●	●	●	○	●	○	
2006	PT Cruiser	CAN GW	○	●	●	●	●	○	●	
2006	Grand Cherokee	OCM	○	●	●	●	●	○	○	011E
2006	Grand Cherokee	HVAC	○	●	●	●	●	●	○	00EA 00E9
2006	Grand Cherokee	ESM	○	●	●	●	●	●	○	
2006	Grand Cherokee	SDAR	○	●	●	●	●	○	○	
2006	Grand Cherokee	PDM	○	●	●	●	●	●	●	00AC 0306
2006	Grand Cherokee	EOM	○	●	●	●	●	○	●	00BA 00BC
2006	Grand Cherokee	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A
2006	Grand Cherokee	ORC	○	●	●	●	●	○	●	
2006	Grand Cherokee	DDM	○	●	●	●	●	●	●	00AC 0306
2006	Grand Cherokee	LRSM	○	●	●	●	●	○	○	010D
2006	Grand Cherokee	AHBM	○	●	●	●	●	●	○	0066
2006	Grand Cherokee	FCMCGW	○	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 002E 0033 0040
2006	Grand Cherokee	SCM	○	●	●	●	●	○	●	
2006	Grand Cherokee	VES	○	●	●	●	●	●	○	
2006	Grand Cherokee	CCN	○	●	●	●	●	●	●	0097 008C 008F 008E 0091 0094 0099 0098 0090
2006	Grand Cherokee	FDCM	○	●	●	●	●	●	●	
2006	Grand Cherokee	ITM	○	●	●	●	●	●	●	0106
2006	Grand Cherokee	PTS	○	●	●	●	●	●	○	01B4 01B3 01B5 01B8
2006	Grand Cherokee	RADIO	○	●	●	●	●	○	●	
2006	Grand Cherokee	WCM	○	●	●	●	●	○	●	022E 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0233 022D 023D 023E 0271 0270
2006	Grand Cherokee	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2006	Grand Cherokee	HSM	○	●	●	●	●	●	○	
2006	Grand Cherokee	TCM	○	●	●	●	●	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 0175 038C 01F3 01F2
2006	Grand Cherokee	HFM	○	●	●	●	●	●	○	00E3
2006	Grand Cherokee	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0381 0173 012A 0482 012B 013B 0042 0149 0142 0145 014B 014A 0148 0049 0146 0147
2006	Grand Cherokee	SUNR	○	●	●	●	●	●	○	
2006	Grand Cherokee	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2006	Grand Cherokee	TM	○	●	●	○	○	○	○	
2006	Commander	HVAC	○	●	●	●	●	●	○	00EA 00E9
2006	Commander	WCM	○	●	●	●	●	○	●	022E 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0233 022D 023D 023E 0271 0270
2006	Commander	FDCM	○	●	●	●	●	●	●	
2006	Commander	ORC	○	●	●	●	●	○	●	
2006	Commander	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A
2006	Commander	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2006	Commander	LRSM	○	●	●	●	●	○	●	010D
2006	Commander	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0381 0173 012A 0482 012B 013B 0042 0149 0142 0145 0045 0046 014B 014A 0148 0049 014D 048A 0489 0146 0147 048B

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	Commander	VES	○	●	●	●	●	●	○	
2006	Commander	CCN	○	●	●	●	●	●	●	0097 008C 008F 008E 0091 0094 0099 0098 0090
2006	Commander	SCM	○	●	●	●	●	○	●	
2006	Commander	TCM	○	●	●	●	●	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 0175 038C 01F3 01F2
2006	Commander	PTS	○	●	●	●	○	●	○	01B4 01B3 01B5 01B8
2006	Commander	HFM	○	●	●	●	●	●	○	00E3
2006	Commander	DDM	○	●	●	●	●	●	●	00AC 0306
2006	Commander	HSM	○	●	●	●	●	●	○	
2006	Commander	ITM	○	●	●	●	●	●	●	0106
2006	Commander	FCMCGW	○	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 002E 0033 0040
2006	Commander	ESM	○	●	●	●	●	●	○	
2006	Commander	RADIO	○	●	●	●	●	○	●	
2006	Commander	AHBM	○	●	●	●	●	●	○	0066
2006	Commander	OCM	○	●	●	●	●	○	○	011E
2006	Commander	TM	○	●	●	○	○	○	○	
2006	Commander	PDM	○	●	●	●	●	●	●	0306 00AC
2006	Commander	SDAR	○	●	●	●	●	○	○	
2006	Commander	SUNR	○	●	●	●	●	●	○	
2006	Commander	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2007	Pacifica	PLGM	○	●	●	●	●	●	●	038A 038B
2007	Pacifica	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2007	Pacifica	ORC	○	●	●	●	●	○	●	
2007	Pacifica	BCMCGW	○	●	●	●	●	●	●	007E 007D
2007	Pacifica	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Pacifica	AWD	○	●	●	●	●	○	●	
2007	Pacifica	SAS	○	●	●	●	○	○	○	
2007	Pacifica	AMP	○	●	●	○	○	○	○	
2007	Pacifica	MTC/CCN	○	●	●	●	○	●	○	
2007	Pacifica	RADIO	○	●	●	○	○	●	○	
2007	Pacifica	PDM	○	●	●	●	○	●	○	
2007	Pacifica	DDM	○	●	●	●	○	●	○	
2007	Pacifica	OCM	○	●	●	●	○	○	○	011E 802A 802B 8023 8024
2007	Pacifica	HFM	○	●	●	●	○	●	○	
2007	Pacifica	SKREEM	○	●	●	●	●	○	○	8003 8004 8005 8006 8007 01D2 04A2 8008 8009 800A 800B 800C 01DE 800E 01DA
2007	Pacifica	IPM	○	●	●	●	○	●	○	
2007	Pacifica	MTC	○	●	●	●	○	●	○	
2007	Pacifica	EOM	○	●	●	○	○	○	○	
2007	Pacifica	SDAR	○	●	●	●	●	●	○	
2007	Pacifica	NAV	○	●	●	○	○	○	○	
2007	Pacifica	PTS	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Pacifica	ATC	○	●	●	●	●	●	○	
2007	Pacifica	MHSM	○	●	●	●	○	●	○	
2007	Dodge Ram	PCM	○	●	●	●	●	●	●	03C7 0154 0155 0398 0141 0399 0044 0411 03F4 0150 0151 033D 037D 012D 0491 017B 0292 0173 0049 0276 0277 033B 033C 017A 0178 0179 0278 039A 013B 014F 033A 0152 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 026C 026D 040A 0128 027E 0490 0266 0265 0145 035B 02FB 013C 012C 0410 0177 0386 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 0486 0156 0157 0576 0153 015A 0159 0488 0158 0487
2007	Dodge Ram	FDCM	○	●	●	●	●	○	○	02B5 02B3 02B2 02B1 02AF 02B0
2007	Dodge Ram	HVAC	○	●	●	●	●	●	●	00EB 00E8 00E9 02EA 02EB 00EA
2007	Dodge Ram	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Dodge Ram	VES	○	●	●	●	●	●	○	
2007	Dodge Ram	TCM	○	●	●	●	●	●	○	01F6 0391 03AF 0499 049C 0392 027B 0167 0166 01EE 03B0 0498 049B 0393 027C 016A 0169 0394 03B1 0497 049A 0395 027D 0291 016C 016B 03B2 02F8 0496 0290 03B3 0495 049D 0396 027E 016E 016D 035B 01FC 0177 0176 024E 01FB 016F 0175
2007	Dodge Ram	SUNR	○	●	●	●	●	●	○	
2007	Dodge Ram	SDAR	○	●	●	●	●	○	○	
2007	Dodge Ram	ORC	○	●	●	●	●	○	●	
2007	Dodge Ram	RADIO	○	●	●	●	●	○	●	
2007	Dodge Ram	HFM	○	●	●	●	●	●	○	00E3
2007	Dodge Ram	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0090
2007	Dodge Ram	EOM	○	●	●	●	●	●	●	00BA 00BC
2007	Dodge Ram	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0483 003C 003D 0214 0032 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 0387 038F 0388 0390
2007	Dodge Ram	WCM	○	●	●	●	●	○	●	01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 01DE 0233 022D 023D 023E 0271 0270
2007	Dodge Ram	AMP	○	●	●	●	●	○	●	028A 028D 006D 006C 027F 0068 006A
2007	Dodge Ram	SAS	○	●	●	●	○	○	○	
2007	Durango (Pre-2011)	RADIO	○	●	●	●	●	○	●	
2007	Durango (Pre-2011)	EOM	○	●	●	●	●	●	●	00BA 00BC
2007	Durango (Pre-2011)	ORC	○	●	●	●	●	○	●	
2007	Durango (Pre-2011)	PTS	○	●	●	●	●	●	●	01B8
2007	Durango (Pre-2011)	PDM	○	●	●	●	●	●	●	00AC 0306
2007	Durango (Pre-2011)	DDM	○	●	●	●	●	●	●	0306 00AC
2007	Durango (Pre-2011)	PTIM	○	●	●	●	●	●	●	
2007	Durango (Pre-2011)	HSM	○	●	●	●	●	●	●	
2007	Durango (Pre-2011)	VES	○	●	●	●	●	●	○	
2007	Durango (Pre-2011)	FCMCGW	○	●	●	●	●	●	●	02DC 0039 003C 003D 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0388 0033 04A0 00C6 0040 00DA 0272 0273
2007	Durango (Pre-2011)	SAS	○	●	●	●	○	○	○	
2007	Durango (Pre-2011)	PLGM	○	●	●	●	●	●	●	038A 038B

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Durango (Pre-2011)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2007	Durango (Pre-2011)	WCM	○	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0233 022D 023D 023E 0271 0270
2007	Durango (Pre-2011)	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Durango (Pre-2011)	SDAR	○	●	●	●	●	○	○	
2007	Durango (Pre-2011)	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2007	Durango (Pre-2011)	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0381 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2007	Durango (Pre-2011)	HVAC	○	●	●	●	●	●	●	00EA 00E9 02EA 0323 02EB 00E8 0324
2007	Durango (Pre-2011)	HFM	○	●	●	●	●	●	○	00E3
2007	Durango (Pre-2011)	AMP	○	●	●	●	●	○	●	0069 006D 0079 0068 0303
2007	Aspen	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2007	Aspen	PDM	○	●	●	●	●	●	●	00AC 0306
2007	Aspen	PTS	○	●	●	●	●	●	●	01B8
2007	Aspen	ORC	○	●	●	●	●	○	●	
2007	Aspen	SAS	○	●	●	●	○	○	○	
2007	Aspen	PLGM	○	●	●	●	●	●	●	038A 038B
2007	Aspen	SDAR	○	●	●	●	●	○	○	
2007	Aspen	EOM	○	●	●	●	●	●	●	00BA
2007	Aspen	VES	○	●	●	●	●	●	○	
2007	Aspen	FCMCGW	○	●	●	●	●	●	●	02DC 0039 003C 003D 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0388 0033 04A0 00C6 0040 00DA 0272 0273
2007	Aspen	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Aspen	DDM	○	●	●	●	●	●	●	00AC 0306
2007	Aspen	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0381 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2007	Aspen	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2007	Aspen	RADIO	○	●	●	●	●	○	●	
2007	Aspen	HSM	○	●	●	●	●	●	●	
2007	Aspen	AMP	○	●	●	●	●	○	●	0069 006D 0079 0068 0303
2007	Aspen	HVAC	○	●	●	●	●	●	●	00EA 00E9 02EA 0323 02EB 00E8 0324
2007	Aspen	WCM	○	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0233 022D 023D 023E 0271 0270
2007	Aspen	HFM	○	●	●	●	●	○	○	00E3
2007	Wrangler	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Wrangler	AMP	○	●	●	●	●	○	●	006D 0068
2007	Wrangler	OCM	○	●	●	●	●	○	○	011E
2007	Wrangler	ASBS	○	●	●	●	●	○	○	0317 0318 031A 031B 0319

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Wrangler	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0386 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0049 0144 02C0 02BB 031D 02C1 02C2
2007	Wrangler	ORC	○	●	●	●	●	○	●	
2007	Wrangler	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2007	Wrangler	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2007	Wrangler	SAS	○	●	●	●	○	○	○	
2007	Wrangler	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2007	Wrangler	ITM	○	●	●	●	○	●	●	0385 0106
2007	Wrangler	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 01DE 0227 0274
2007	Wrangler	TCM	○	●	●	●	●	●	○	03AF 0499 049C 0392 03B0 0498 049B 0393 0394 03B1 0497 049A 0395 03B2 0496 03B3 0495 049D 0396 01FC 0177 0176 024E 01FB 016F 0175
2007	Sebring / 200 / Avenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0483 003C 003D 0214 0032 003F 0484 0036 02C3 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2007	Sebring / 200 / Avenger	DDM	○	●	●	●	●	●	○	0306
2007	Sebring / 200 / Avenger	TCM	○	●	●	●	●	●	●	03AF 0499 049C 0392 027B 0167 0166 01EE 03B0 0498 049B 0393 027C 016A 0169 0394 03B1 0497 049A 0395 027D 0291 016C 016B 03B2 02F8 0496 0290 03B3 0495 049D 0396 027E 016E 016D 01FC 0177 0176 024E 01FB 016F 0175 01F0 0172 04B0 0170 0391
2007	Sebring / 200 / Avenger	AWD	○	●	●	●	●	○	●	
2007	Sebring / 200 / Avenger	WCM	○	●	●	●	●	○	●	022E 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 01DE 0233 022D 023D 023E 0271 0270
2007	Sebring / 200 / Avenger	PTCM	○	●	●	●	●	○	●	0259 04A4
2007	Sebring / 200 / Avenger	HFM	○	●	●	●	●	●	○	00E3
2007	Sebring / 200 / Avenger	SAS	○	●	●	●	○	○	○	
2007	Sebring / 200 / Avenger	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0386 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0142 0310 0313 03A3 0144 03A4 02E7 013E 0141 012E 0314
2007	Sebring / 200 / Avenger	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0382 0094 0092 038D 0096 0383
2007	Sebring / 200 / Avenger	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB
2007	Sebring / 200 / Avenger	VES3	○	●	●	●	●	●	●	
2007	Sebring / 200 / Avenger	ITM	○	●	●	●	●	●	●	0385 0106
2007	Sebring / 200 / Avenger	PDM	○	●	●	●	●	●	○	0306
2007	Sebring / 200 / Avenger	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2007	Sebring / 200 / Avenger	ORC	○	●	●	●	●	○	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Sebring / 200 / Avenger	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Sebring / 200 / Avenger	AMP	○	●	●	●	●	○	●	0069 006D 0079 0068
2007	Nitro	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 01DE 0227 0274
2007	Nitro	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB
2007	Nitro	PCM	○	●	●	●	●	●	●	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0044 0049 0144 02C0 02BB 031D 02C1 013B 02C2 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 035B 02FB 013C 012C 0410 0177 0386 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC
2007	Nitro	SAS	○	●	●	●	○	○	○	
2007	Nitro	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2007	Nitro	HFM	○	●	●	●	●	●	○	00E3
2007	Nitro	DMFR	○	●	●	●	●	●	●	
2007	Nitro	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2007	Nitro	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Nitro	ITM	○	●	●	●	●	●	●	0106
2007	Nitro	AMP	○	●	●	●	●	○	●	006D 0068
2007	Nitro	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2007	Nitro	OCM	○	●	●	●	●	○	○	011E
2007	Nitro	VES3	○	●	●	●	●	●	●	
2007	Nitro	DMFL	○	●	●	●	●	●	●	
2007	Nitro	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2007	Nitro	PTS	○	●	●	●	●	●	●	01B8
2007	Nitro	ESM	○	●	●	●	●	●	○	
2007	Nitro	ORC	○	●	●	●	●	○	●	
2007	Liberty	SAS	○	●	●	●	●	○	○	
2007	Liberty	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0381 0173 012A 0482 012B 013B 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0140 027E 0490 0266 0265 0145 035B 02FB 0410 0177 0281 0280 0176 024E 048C 0170 016F 0175 0269 01FC
2007	Liberty	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Liberty	SKREEM	○	●	●	●	●	○	○	8003 8004 8005 8006 8007 01D2 04A2 8008 8009 800A 800B 800C 01DE 800E 01DA
2007	Liberty	ORC	○	●	●	●	●	●	●	
2007	Liberty	MIC/CCN	○	●	●	●	○	●	○	008C 804F 8050 8051 8052
2007	Liberty	TCM	○	●	●	●	●	●	○	
2007	Liberty	HFM	○	●	●	●	○	●	○	
2007	Liberty	EOM	○	●	●	○	○	○	○	
2007	Liberty	RADIO	○	●	●	●	●	●	●	
2007	Liberty	SDAR	○	●	●	●	●	●	○	
2007	Liberty	PCM	○	●	●	●	●	●	●	
2007	Liberty	OCM	○	●	●	●	○	○	○	011E 801A 8023 8024

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Liberty	ITM	○	○	○	●	○	●	○	
2007	Liberty	BCM	○	●	●	●	○	●	○	0081 8018 8017 8015 8057 8012 003F 002E 8058
2007	300 / Magnum / Charger (Pre-2011)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2007	300 / Magnum / Charger (Pre-2011)	SDAR	○	●	●	●	●	○	○	
2007	300 / Magnum / Charger (Pre-2011)	CCN	○	●	●	●	●	●	○	008F 008E 0382 038D 0090 0383
2007	300 / Magnum / Charger (Pre-2011)	HVAC	○	●	●	●	●	●	○	00EA 00E9 02EA 02EB
2007	300 / Magnum / Charger (Pre-2011)	AMP	○	●	●	●	●	○	●	0289 028B 028A 006D 006B 0073 006C 0068 006A 0069
2007	300 / Magnum / Charger (Pre-2011)	PTS	○	●	●	●	○	●	○	01B4 01B3 01B5 01B8
2007	300 / Magnum / Charger (Pre-2011)	WCM	○	●	●	●	●	○	●	022E 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0233 022D 023D 023E 0271 0270 0227
2007	300 / Magnum / Charger (Pre-2011)	AHBM	○	●	●	●	●	●	○	0067 0066
2007	300 / Magnum / Charger (Pre-2011)	LRSM	○	●	●	●	●	○	○	010D
2007	300 / Magnum / Charger (Pre-2011)	EOM	○	●	●	●	●	○	●	00BA 00BC
2007	300 / Magnum / Charger (Pre-2011)	SCM	○	●	●	●	○	●	●	
2007	300 / Magnum / Charger (Pre-2011)	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0381 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0149 0142 0045 0046 014B 014A 0148 0049 014D 048A 0489 0146 0147 048B
2007	300 / Magnum / Charger (Pre-2011)	RADIO	○	●	●	●	●	○	●	
2007	300 / Magnum / Charger (Pre-2011)	ORC	○	●	●	●	○	●	○	
2007	300 / Magnum / Charger (Pre-2011)	ITM	○	●	●	●	●	●	●	0106
2007	300 / Magnum / Charger (Pre-2011)	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2007	300 / Magnum / Charger (Pre-2011)	VES	○	●	●	●	●	●	○	
2007	300 / Magnum / Charger (Pre-2011)	DDM	○	●	●	●	●	●	●	
2007	300 / Magnum / Charger (Pre-2011)	ESM	○	●	●	●	●	●	○	
2007	300 / Magnum / Charger (Pre-2011)	HFM	○	●	●	●	●	●	○	00E3

[illegible]

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Dakota	FCMCGW	○	●	●	●	●	●	●	02DC 0039 003C 003D 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0388 0033 04A0 00C6 0040 00DA 0272 0273
2007	Dakota	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0381 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2007	Dakota	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2007	Dakota	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Raider	AMP	○	●	●	●	●	○	●	0069 006D 0079 0068 0303
2007	Raider	SDAR	○	●	●	●	●	○	○	
2007	Raider	FCMCGW	○	●	●	●	●	●	●	02DC 0039 003C 003D 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0388 0033 04A0 00C6 0040 00DA 0272 0273
2007	Raider	EOM	○	●	●	●	●	●	●	00BA 00BC
2007	Raider	WCM	○	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0233 022D 023D 023E 0271 0270
2007	Raider	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Raider	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2007	Raider	RADIO	○	●	●	●	●	○	●	
2007	Raider	OCM	○	●	●	●	●	○	○	011E
2007	Raider	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB
2007	Raider	ORC	○	●	●	●	●	○	●	
2007	Raider	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0381 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2007	Caliber	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A
2007	Caliber	RADIO	○	●	●	●	●	○	●	
2007	Caliber	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0382 0094 0092 038D 0096 0383
2007	Caliber	PCM	○	●	●	●	●	●	●	02E7 0140 013E 0126 0141 0044 0411 0128 03F4 012E 0314 012C 012D 0386 0173 012A 012B 013B 0042 0142 0310 0313 03A3 0144 03A4
2007	Caliber	WCM	○	●	●	●	●	○	●	01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 01DE 0233 022D 023D 023E 0271 0270
2007	Caliber	HFM	○	●	●	●	●	●	○	00E3
2007	Caliber	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Caliber	SAS	○	●	●	●	○	○	○	
2007	Caliber	TCM	○	●	●	●	●	●	●	0380
2007	Caliber	OCM	○	●	●	●	●	○	○	011E
2007	Caliber	SDAR	○	●	●	●	●	○	○	
2007	Caliber	ORC	○	●	●	●	●	○	●	
2007	Caliber	ITM	○	●	●	●	●	●	●	0106

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Caliber	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0483 003C 003D 0032 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390
2007	Caliber	AWD	○	●	●	●	●	●	●	
2007	PT Cruiser	RADIO	○	●	●	●	●	○	●	
2007	PT Cruiser	ITM	○	●	●	●	●	●	●	0385 0106 010A
2007	PT Cruiser	ABS	○	●	●	●	●	●	●	03AB 0002 005E 0060 005B
2007	PT Cruiser	OCM	○	●	●	●	●	○	○	011E
2007	PT Cruiser	CCN	○	●	●	●	●	●	●	008C 008F 008E 0094 0092 0096
2007	PT Cruiser	PCM	○	●	●	●	●	●	●	0042 0149 0142 0044 0145 012D 0173 0148 0049 013B 048B 0127 0126 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 0386 012A 0482 012B
2007	PT Cruiser	TIPMCGW	○	●	●	●	●	●	●	02DC 030E 030C 0483 003D 0032 003F 0484 0036 0037 0389 0034 0038 002E 020E 0215 028F 028E 0211 0388
2007	PT Cruiser	DDM	○	●	●	●	●	●	○	
2007	PT Cruiser	PDM	○	●	●	●	○	●	○	
2007	PT Cruiser	TCM	○	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 04B0 0177 0170 0391 0175
2007	PT Cruiser	ORC	○	●	●	●	●	○	●	
2007	PT Cruiser	WCM	○	●	●	●	●	○	●	01D2 0228 0240 0226 0225 0232 0230 0231 022F 01DE 0233 022D 023D 023E 0271 0270
2007	PT Cruiser	HFM	○	●	●	●	●	●	○	00E3
2007	PT Cruiser	SDAR	○	●	●	●	●	○	○	
2007	PT Cruiser	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A
2007	PT Cruiser	PCM	○	●	●	●	○	●	○	
2007	PT Cruiser	CAN GW	○	●	●	●	●	○	●	
2007	Sprinter	RCM	○	●	●	●	●	●	○	
2007	Sprinter	CCN	○	●	●	●	●	○	○	0007 0005 0334 0006 032F 0330 0331 0332 0333 0009 000A 032E 0008
2007	Sprinter	AEHM	○	●	●	●	●	○	○	0004
2007	Sprinter	BCM	○	●	●	●	●	●	○	02E1
2007	Sprinter	HVAC	○	●	●	●	●	●	●	0012
2007	Sprinter	DDM	○	●	●	●	●	●	○	
2007	Sprinter	ECM	○	●	●	●	●	●	●	0042 0142 0127 0044 0337 001E 0045 0046 0023 0043 0049 014D 026E 002E 026F 0336 0025 0024 0022 0020 0021
2007	Sprinter	PSM	○	●	●	●	●	●	○	
2007	Sprinter	EISCGW	○	●	●	●	●	○	●	002C 002B 002A
2007	Sprinter	PTS	○	●	●	●	●	●	●	02D2 02D3
2007	Sprinter	ORC	○	●	●	○	●	○	○	0014 0013 02CF
2007	Sprinter	TCM	○	●	●	●	●	○	○	02D6 02D7 02D4 02D5 0018
2007	Sprinter	ACH	○	●	●	●	●	●	○	
2007	Sprinter	RADIO	○	●	●	●	●	○	○	
2007	Sprinter	AHLM	○	●	●	●	●	●	○	029F
2007	Sprinter	ABS	○	●	●	●	●	○	●	032D 0002 0001 0003
2007	Sprinter	SCM	○	●	●	●	●	●	○	
2007	Sprinter	ESM	○	●	●	●	●	●	○	
2007	Sprinter	TPM	○	●	●	●	●	○	○	02D0 02D1 001A 001B 001C 001D 0247 004E

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Sprinter	BCH	○	●	●	●	●	●	○	
2007	Sprinter	SBM	○	●	●	●	●	●	○	
2007	Sprinter	TM	○	●	●	●	○	○	○	
2007	Sprinter	HFM	○	●	●	●	●	○	○	
2007	Sprinter	CDC	○	●	●	●	●	○	○	
2007	Grand Cherokee	ITM	○	●	●	●	●	●	●	0106
2007	Grand Cherokee	HVAC	○	●	●	●	●	●	○	00EA 00E9 02EA 02EB
2007	Grand Cherokee	TM	○	●	●	○	○	○	○	
2007	Grand Cherokee	FCMCGW	○	●	●	●	●	●	●	02DC 0039 003C 003D 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0388 0033 04A0 00C6 0040 00DA 0272 0273
2007	Grand Cherokee	LRSM	○	●	●	●	●	○	○	010D
2007	Grand Cherokee	SUNR	○	●	●	●	●	●	○	
2007	Grand Cherokee	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2007	Grand Cherokee	FDCM	○	●	●	●	●	●	●	
2007	Grand Cherokee	HSM	○	●	●	●	●	●	●	
2007	Grand Cherokee	AMP	○	●	●	●	●	○	●	0069 006D 0073 0068 006A 0289 028A 006B 006C
2007	Grand Cherokee	DDM	○	●	●	●	●	●	●	00AC 0306
2007	Grand Cherokee	EOM	○	●	●	●	●	○	●	00BA 00BC
2007	Grand Cherokee	SDAR	○	●	●	●	●	○	○	
2007	Grand Cherokee	WCM	○	●	●	●	●	○	●	022E 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0233 022D 023D 023E 0271 0270
2007	Grand Cherokee	ESM	○	●	●	●	●	●	○	
2007	Grand Cherokee	PDM	○	●	●	●	●	●	●	00AC 0306
2007	Grand Cherokee	SCM	○	●	●	●	●	○	●	
2007	Grand Cherokee	CCN	○	●	●	●	●	●	●	0097 008C 00BC 008F 008E 0382 0091 0094 0099 0098 0090 0383
2007	Grand Cherokee	PTS	○	●	●	●	○	●	○	01B4 01B3 01B5 01B8
2007	Grand Cherokee	HFM	○	●	●	●	●	●	○	00E3
2007	Grand Cherokee	VES	○	●	●	●	●	●	○	
2007	Grand Cherokee	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2007	Grand Cherokee	AHBM	○	●	●	●	●	●	○	0067 0066
2007	Grand Cherokee	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Grand Cherokee	RADIO	○	●	●	●	●	○	●	
2007	Grand Cherokee	PCM	○	●	●	●	●	●	●	0042 0149 0142 0044 0145 012D 0045 0046 014B 0173 014A 0148 0049 014D 048A 0489 0146 0147 013B 048B 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 035B 02FB 013C 012C 0410 0177 0381 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC
2007	Grand Cherokee	ORC	○	●	●	●	●	○	●	
2007	Commander	LRSM	○	●	●	●	●	○	○	010D
2007	Commander	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2007	Commander	SCM	○	●	●	●	●	○	●	
2007	Commander	HVAC	○	●	●	●	●	●	○	00EA 00E9 02EA 02EB
2007	Commander	PTS	○	●	●	●	○	●	○	01B4 01B3 01B5 01B8
2007	Commander	SUNR	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Commander	FDCM	○	●	●	●	●	●	●	
2007	Commander	VES	○	●	●	●	●	●	○	
2007	Commander	CCN	○	●	●	●	●	●	●	0097 008C 00BC 008F 008E 0382 0091 0094 0099 0098 0090 0383
2007	Commander	SDAR	○	●	●	●	●	○	○	
2007	Commander	ORC	○	●	●	●	●	○	●	
2007	Commander	AMP	○	●	●	●	●	○	●	0069 006D 0073 0068 006A 0289 028A 006B 006C
2007	Commander	ITM	○	●	●	●	●	●	●	0106
2007	Commander	DDM	○	●	●	●	●	●	●	0306 00AC
2007	Commander	AHBM	○	●	●	●	●	●	○	0067 0066
2007	Commander	WCM	○	●	●	●	●	○	●	022E 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0233 022D 023D 023E 0271 0270
2007	Commander	TM	○	●	●	○	○	○	○	
2007	Commander	PLGM	○	●	●	●	●	●	●	038A 038B
2007	Commander	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2007	Commander	PDM	○	●	●	●	●	●	●	00AC 0306
2007	Commander	HFM	○	●	●	●	●	●	○	00E3
2007	Commander	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2007	Commander	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0381 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0149 0142 0045 0046 014B 014A 0148 0049 014D 048A 0489 0146 0147 048B
2007	Commander	HSM	○	●	●	●	●	●	●	
2007	Commander	RADIO	○	●	●	●	●	○	●	
2007	Commander	ESM	○	●	●	●	●	●	○	
2007	Commander	FCMCGW	○	●	●	●	●	●	●	02DC 0039 003C 003D 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0388 0033 04A0 00C6 0040 00DA 0272 0273
2007	Crossfire	OCM	○	●	●	●	○	○	○	
2007	Crossfire	ORC	○	●	●	●	○	○	○	
2007	Crossfire	BCM	○	●	●	●	○	●	○	
2007	Crossfire	SLA	○	●	●	●	○	●	○	
2007	Crossfire	SKREEM	○	●	●	●	○	●	○	
2007	Crossfire	TPM	○	●	●	●	●	○	●	8001 8002
2007	Crossfire	HVAC	○	●	●	●	○	●	○	
2007	Crossfire	CLP	○	●	●	●	○	●	○	
2007	Crossfire	TCM	○	●	●	●	●	●	●	
2007	Crossfire	ESP	○	●	●	●	○	●	○	
2007	Crossfire	IC	○	●	●	●	○	●	○	8070 807D
2007	Crossfire	PCM	○	●	●	●	○	●	○	
2007	Crossfire	PTCM	○	●	●	●	○	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Pacifica	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2008	Pacifica	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062
2008	Pacifica	SAS	○	●	●	●	○	○	○	
2008	Pacifica	PLGM	○	●	●	●	●	●	●	038A 038B
2008	Pacifica	BCMCGW	○	●	●	●	●	●	●	007E 007D
2008	Pacifica	AWD	○	●	●	●	●	○	●	
2008	Pacifica	ORC	○	●	●	●	●	●	●	
2008	Pacifica	AMP	○	●	●	○	○	○	○	
2008	Pacifica	SKREEM	○	●	●	●	●	○	○	8003 8004 8005 8006 8007 01D2 04A2 8008 8009 800A 800B 800C 01DE 800E 01DA
2008	Pacifica	MTC	○	●	●	●	○	●	○	
2008	Pacifica	NAV	○	●	●	○	○	○	○	
2008	Pacifica	PDM	○	●	●	●	○	●	○	
2008	Pacifica	HFM	○	●	●	●	○	●	○	
2008	Pacifica	MIC/CCN	○	●	●	●	○	●	○	
2008	Pacifica	SDAR	○	●	●	●	●	●	○	
2008	Pacifica	DDM	○	●	●	●	○	●	○	
2008	Pacifica	IPM	○	●	●	●	○	●	○	
2008	Pacifica	PTS	○	●	●	●	●	●	○	
2008	Pacifica	MHSM	○	●	●	●	○	●	○	
2008	Pacifica	RADIO	○	●	●	○	○	●	○	
2008	Pacifica	ATC	○	●	●	●	●	●	○	
2008	Pacifica	OCM	○	●	●	●	○	○	○	011E 802A 802B 8023 8024
2008	Pacifica	EOM	○	●	●	○	○	○	○	
2008	Dodge Ram	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030C 0483 003C 003D 0214 0032 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 0387 038F 0388 0390
2008	Dodge Ram	RADIO	○	●	●	●	●	○	●	
2008	Dodge Ram	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2008	Dodge Ram	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0090
2008	Dodge Ram	FDCM	○	●	●	●	●	○	○	02B5 02B3 02B2 02B1 02AF 02B0
2008	Dodge Ram	AMP	○	●	●	●	●	○	●	028A 028D 006D 006C 027F 0068 006A
2008	Dodge Ram	HFM	○	●	●	●	●	●	○	00E3
2008	Dodge Ram	EOM	○	●	●	●	●	●	●	00BA 00BC
2008	Dodge Ram	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 033F 0227 023D 023E 0271 0270
2008	Dodge Ram	ORC	○	●	●	●	●	○	●	
2008	Dodge Ram	SAS	○	●	●	●	○	○	○	
2008	Dodge Ram	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 00EB

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Dodge Ram	TCM	○	●	●	●	●	●	○	03AF 0499 049C 0392 027B 0167 0166 01EE 03B0 0498 049B 0393 027C 016A 0169 0394 03B1 0497 049A 0395 027D 0291 016C 016B 03B2 02F8 0496 0290 03B3 0495 049D 0396 027E 016E 016D 035B 01FC 0177 0176 024E 01FB 016F 0175 01F6 0391
2008	Dodge Ram	SUNR	○	●	●	●	●	●	○	
2008	Dodge Ram	VES	○	●	●	●	●	●	○	
2008	Dodge Ram	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0386 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0486 0156 0157 0154 0155 0576 0141 0150 0151 0153 015A 0159 037D 0488 0158 0487 014F 0152 03C7 0398 0399 033D 0491 017B 0292 0049 0276 0277 033B 033C 017A 0178 0179 0278 033A 039A
2008	Dodge Ram	SDAR	○	●	●	●	●	○	○	
2008	Durango (Pre-2011)	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0293 0033 0388 04A6 04A0 00C6 0040 00DA 0272 0273
2008	Durango (Pre-2011)	PDM	○	●	●	●	●	●	●	0306 00AC
2008	Durango (Pre-2011)	PLGM	○	●	●	●	●	●	●	038A 038B
2008	Durango (Pre-2011)	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2008	Durango (Pre-2011)	ORC	○	●	●	●	●	○	●	
2008	Durango (Pre-2011)	HFM	○	●	●	●	●	●	○	00E3
2008	Durango (Pre-2011)	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0381 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2008	Durango (Pre-2011)	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2008	Durango (Pre-2011)	PTS	○	●	●	●	●	●	●	01B8
2008	Durango (Pre-2011)	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2008	Durango (Pre-2011)	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9 0324 02EA 02EB 0323
2008	Durango (Pre-2011)	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 01DE 0227 023E 0271
2008	Durango (Pre-2011)	HSM	○	●	●	●	●	●	●	
2008	Durango (Pre-2011)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2008	Durango (Pre-2011)	AMP	○	●	●	●	●	○	●	006D 0068
2008	Durango (Pre-2011)	PTIM	○	●	●	●	●	●	●	
2008	Durango (Pre-2011)	EOM	○	●	●	●	●	●	●	00BA 00BC
2008	Durango (Pre-2011)	SAS	○	●	●	●	○	○	○	
2008	Durango (Pre-2011)	DDM	○	●	●	●	●	●	●	00AC 0306
2008	Durango (Pre-2011)	VES3	○	●	●	●	●	●	●	
2008	Aspen	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2008	Aspen	HSM	○	●	●	●	●	●	●	
2008	Aspen	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Aspen	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2008	Aspen	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9 0324 02EA 02EB 0323
2008	Aspen	PTS	○	●	●	●	●	●	●	01B8
2008	Aspen	HFM	○	●	●	●	●	●	○	00E3
2008	Aspen	PLGM	○	●	●	●	●	●	●	038A 038B
2008	Aspen	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0293 0033 0388 04A6 04A0 00C6 0040 00DA 0272 0273
2008	Aspen	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0381 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2008	Aspen	PTIM	○	●	●	●	●	●	●	
2008	Aspen	ORC	○	●	●	●	●	○	●	
2008	Aspen	PDM	○	●	●	●	●	●	●	00AC 0306
2008	Aspen	DDM	○	●	●	●	●	●	●	00AC 0306
2008	Aspen	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 01DE 0227 023E 0271
2008	Aspen	EOM	○	●	●	●	●	●	●	00BA
2008	Aspen	AMP	○	●	●	●	●	○	●	006D 0068
2008	Aspen	SAS	○	●	●	●	○	○	○	
2008	Aspen	VES3	○	●	●	●	●	●	●	
2008	Aspen	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2008	Wrangler (Export)	PCM	○	●	●	●	●	●	○	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0044 0049 0144 02C0 02BB 031D 02C1 013B 02C2
2008	Wrangler (Export)	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2008	Wrangler (Export)	WCM	○	●	●	●	●	○	●	0233 01D2 03E4 0228 0232 0230 0231 022F 01DE 0227
2008	Wrangler (Export)	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2008	Wrangler (Export)	TCM	○	●	●	●	●	●	○	03AF 0499 049C 0392 03B0 0498 049B 0393 0394 03B1 0497 049A 0395 03B2 0496 03B3 0495 049D 0396 01FC 0177 0176 024E 01FB 016F 0175
2008	Wrangler (Export)	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2008	Wrangler (Export)	ORC	○	●	●	●	●	○	●	
2008	Wrangler (Export)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2008	Wrangler (Export)	SAS	○	●	●	●	○	○	○	
2008	Wrangler (Export)	CCN	○	●	●	●	○	●	●	00BC 0382 038D 0383
2008	Journey	DISP	○	●	●	●	●	○	○	
2008	Journey	AMP	○	●	●	●	●	○	●	006D 0068
2008	Journey	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2008	Journey	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 02E3 021F 038F 0388 0390 03A1 03A2
2008	Journey	VES3	○	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Journey	AWD	○	●	●	●	●	○	●	
2008	Journey	SAS	○	●	●	●	○	○	○	
2008	Journey	ORC	○	●	●	●	●	○	●	02A1 0122
2008	Journey	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 00EC 02EA
2008	Journey	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2008	Journey	DMFR	○	●	●	●	●	●	●	
2008	Journey	PCM	○	●	●	●	●	●	●	02E7 0140 013E 0126 0141 0044 0411 0128 03F4 012E 0314 012C 012D 0386 0173 012A 012B 013B 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 026C 026D 040A 027E 0490 0266 0265 0145 035B 02FB 013C 0410 0177 0281 0280 0176 024E 048C 0170 016F 0175 0269 01FC 0042 0142 0310 0313 0312 03A3 0311 0144 03A4
2008	Journey	DMFL	○	●	●	●	●	●	●	
2008	Journey	TCM	○	●	●	●	●	●	●	0391 0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 04B0 0177 0170 0175
2008	Journey	CCN	○	●	●	●	○	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2008	Journey	WCM	○	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0300 0245 0225 01DA
2008	Journey	HFM	○	●	●	●	●	●	○	00E3
2008	Journey	ITM	○	●	●	●	●	●	●	0106
2008	Wrangler	PCM	○	●	●	●	●	●	●	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0044 0049 0144 02C0 02BB 031D 02C1 013B 02C2 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 035B 02FB 013C 012C 0410 0177 0386 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC
2008	Wrangler	ASBS	○	●	●	●	●	○	○	0317 0318 031A 031B 0319
2008	Wrangler	ITM	○	●	●	●	○	●	●	0385 0106
2008	Wrangler	TCM	○	●	●	●	●	●	○	03AF 0499 049C 0392 03B0 0498 049B 0393 0394 03B1 0497 049A 0395 03B2 0496 03B3 0495 049D 0396 01FC 0177 0176 024E 01FB 016F 0175
2008	Wrangler	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F
2008	Wrangler	CCN	○	●	●	●	○	●	●	00BC 0382 038D 0383
2008	Wrangler	ORC	○	●	●	●	●	○	●	
2008	Wrangler	SAS	○	●	●	●	○	○	○	
2008	Wrangler	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2008	Wrangler	AMP	○	●	●	●	●	○	●	006D 0068
2008	Wrangler	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 01DE 0227 0274
2008	Wrangler	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062 0485
2008	Sebring / 200 / Avenger	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0382 0094 0092 038D 0096 0383
2008	Sebring / 200 / Avenger	PTCM	○	●	●	●	●	○	●	0259 04A4
2008	Sebring / 200 / Avenger	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2008	Sebring / 200 / Avenger	WCM	○	●	●	●	●	○	●	0233 022E 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 022D 0227 023D 023E 0271 0270

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Sebring / 200 / Avenger	AMP	○	●	●	●	●	○	●	006D 0068 0069 0079
2008	Sebring / 200 / Avenger	PDM	○	●	●	●	●	●	○	0306
2008	Sebring / 200 / Avenger	HFM	○	●	●	●	●	●	○	00E3
2008	Sebring / 200 / Avenger	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB
2008	Sebring / 200 / Avenger	ORC	○	●	●	●	●	○	●	
2008	Sebring / 200 / Avenger	AWD	○	●	●	●	●	○	●	
2008	Sebring / 200 / Avenger	VES3	○	●	●	●	●	●	●	
2008	Sebring / 200 / Avenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0214 0032 003F 0484 0036 02C3 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2008	Sebring / 200 / Avenger	DDM	○	●	●	●	●	●	○	0306
2008	Sebring / 200 / Avenger	SAS	○	●	●	●	○	○	○	
2008	Sebring / 200 / Avenger	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2008	Sebring / 200 / Avenger	ITM	○	●	●	●	●	●	●	0106 0385
2008	Sebring / 200 / Avenger	TCM	○	●	●	●	●	●	●	03AF 0499 049C 0392 027B 0167 0166 01EE 03B0 0498 049B 0393 027C 016A 0169 0394 03B1 0497 049A 0395 027D 0291 016C 016B 03B2 02F8 0496 0290 03B3 0495 049D 0396 027E 016E 016D 01FC 0177 0176 024E 01FB 016F 0175 01F0 0172 04B0 0170 0391
2008	Sebring / 200 / Avenger	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0386 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0142 0310 0313 03A3 0144 03A4 02E7 013E 0141 012E 0314
2008	Nitro	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2008	Nitro	OCM	○	●	●	●	●	○	○	011E
2008	Nitro	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062 0485
2008	Nitro	DMFR	○	●	●	●	●	●	●	
2008	Nitro	SAS	○	●	●	●	○	○	○	
2008	Nitro	AMP	○	●	●	●	●	○	●	006D 0068
2008	Nitro	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 01DE 0227 0274
2008	Nitro	HFM	○	●	●	●	●	●	○	00E3
2008	Nitro	ESM	○	●	●	●	●	●	○	
2008	Nitro	CCN	○	●	●	●	○	●	●	00BC 0382 038D 0383
2008	Nitro	PTS	○	●	●	●	●	●	●	01B8
2008	Nitro	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 02E2 038F 0388 0390 03A1 03A2
2008	Nitro	VES3	○	●	●	●	●	●	●	
2008	Nitro	PCM	○	●	●	●	●	●	●	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0044 0049 0144 02C0 02BB 031D 02C1 013B 02C2 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 035B 02FB 013C 012C 0410 0177 0386 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Nitro	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB
2008	Nitro	DMFL	○	●	●	●	●	●	●	
2008	Nitro	ITM	○	●	●	●	●	●	●	0106
2008	Nitro	ORC	○	●	●	●	●	○	●	
2008	Nitro	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2008	Liberty	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2008	Liberty	FDCM	○	●	●	●	●	●	○	0340
2008	Liberty	AMP	○	●	●	●	●	○	●	006D 0068
2008	Liberty	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2008	Liberty	HFM	○	●	●	●	●	●	○	00E3
2008	Liberty	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 02E2 038F 0388 0390 03A1 03A2
2008	Liberty	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2008	Liberty	ORC	○	●	●	●	●	○	●	
2008	Liberty	OCM	○	●	●	●	●	○	○	011E
2008	Liberty	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 01DE 0227 0274
2008	Liberty	SAS	○	●	●	●	○	○	○	
2008	Liberty	VES3	○	●	●	●	●	●	●	
2008	Liberty	DMFR	○	●	●	●	●	●	●	
2008	Liberty	PCM	○	●	●	●	●	●	●	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0044 0049 0144 02C0 02BB 031D 02C1 013B 02C2 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 035B 02FB 013C 012C 0410 0177 0386 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC
2008	Liberty	ESM	○	●	●	●	●	●	○	
2008	Liberty	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB
2008	Liberty	DMFL	○	●	●	●	●	●	●	
2008	Liberty	SUNR	○	●	●	●	●	○	○	04A7
2008	Liberty	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2008	Liberty	ITM	○	●	●	●	●	●	●	010A 0106
2008	Liberty	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2008	Liberty	PTS	○	●	●	●	●	●	●	01B8
2008	Challenger	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB
2008	Challenger	DDM	○	●	●	●	●	●	○	0306
2008	Challenger	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0386 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2008	Challenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0219 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A2
2008	Challenger	SCM	○	●	●	●	○	●	●	
2008	Challenger	HSM	○	●	●	●	●	●	●	
2008	Challenger	CCN	○	●	●	●	●	●	●	008F 008E 0382 038D 0090 0383

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Challenger	EOM	○	●	●	●	●	○	●	00BA 00BC
2008	Challenger	PEM	○	●	●	●	●	○	●	0463 0442 0307
2008	Challenger	AMP	○	●	●	●	●	○	●	006D 0068
2008	Challenger	ESM	○	●	●	●	●	●	○	
2008	Challenger	ORC	○	●	●	●	●	○	●	02A1
2008	Challenger	SUNR	○	●	●	●	●	●	○	
2008	Challenger	TPM	○	●	●	●	○	○	●	02F7 0232 0230 0231 022F
2008	Challenger	WCM	○	●	●	●	●	●	●	02A7 0228 02FF 03E6 0245 01D2 0225 0414 0233 022E 03E4 0232 0230 0231 022F 01DE 0300
2008	Challenger	PDM	○	●	●	●	●	●	○	0306
2008	Challenger	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2008	Challenger	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2008	Challenger	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2008	Challenger	HFM	○	●	●	●	●	●	○	00E3
2008	300 / Magnum / Charger (Pre-2011)	LRSM	○	●	●	●	●	○	○	010D
2008	300 / Magnum / Charger (Pre-2011)	HIDT	○	●	●	●	●	●	○	00E5
2008	300 / Magnum / Charger (Pre-2011)	WCM	○	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0300 0245 0225 01DA
2008	300 / Magnum / Charger (Pre-2011)	ACC	○	●	●	●	●	○	●	0064 0321 04A5 0065 02CE
2008	300 / Magnum / Charger (Pre-2011)	SUNR	○	●	●	●	●	●	○	
2008	300 / Magnum / Charger (Pre-2011)	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2008	300 / Magnum / Charger (Pre-2011)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2008	300 / Magnum / Charger (Pre-2011)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 030C 0219 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A2
2008	300 / Magnum / Charger (Pre-2011)	ORC	○	●	●	●	●	○	●	02A1
2008	300 / Magnum / Charger (Pre-2011)	EOM	○	●	●	●	●	○	●	00BA 00BC
2008	300 / Magnum / Charger (Pre-2011)	DDM	○	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	SDARV	○	●	●	●	●	○	○	
2008	300 / Magnum / Charger (Pre-2011)	AMP	○	●	●	●	●	○	●	006D 0068
2008	300 / Magnum / Charger (Pre-2011)	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2008	300 / Magnum / Charger (Pre-2011)	ITM	○	●	●	●	●	●	●	0106
2008	300 / Magnum / Charger (Pre-2011)	PTS	○	●	●	●	○	●	○	01B4 01B3 01B5 01B8

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	300 / Magnum / Charger (Pre-2011)	CCN	○	●	●	●	●	●	●	008F 008E 0382 038D 0090 0383
2008	300 / Magnum / Charger (Pre-2011)	SCM	○	●	●	●	○	●	●	
2008	300 / Magnum / Charger (Pre-2011)	PCM	○	●	●	●	●	●	●	0042 0149 0142 0044 0145 012D 0045 0046 014B 0173 014A 0148 0049 014D 048A 0489 0146 0147 013B 048B 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 035B 02FB 013C 012C 0410 0177 0386 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC
2008	300 / Magnum / Charger (Pre-2011)	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2008	300 / Magnum / Charger (Pre-2011)	HVAC	○	●	●	●	●	●	●	00EA 00E9 02EA 02EB
2008	300 / Magnum / Charger (Pre-2011)	HFM	○	●	●	●	●	●	○	00E3
2008	300 / Magnum / Charger (Pre-2011)	ESM	○	●	●	●	●	●	○	
2008	300 / Magnum / Charger (Pre-2011)	HSM	○	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	VES3	○	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	PDM	○	●	●	●	●	●	●	00AC
2008	300 / Magnum / Charger (Pre-2011)	AHBM	○	●	●	●	●	○	○	03C0 00BC
2008	300 / Magnum / Charger (Pre-2011)	PTIM	○	●	●	●	●	●	●	
2008	Compass	AWD	○	●	●	●	●	●	●	
2008	Compass	HFM	○	●	●	●	●	●	○	00E3
2008	Compass	ITM	○	●	●	●	●	●	●	0106
2008	Compass	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0382 0094 0092 038D 0096 0383
2008	Compass	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0032 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390
2008	Compass	SAS	○	●	●	●	○	○	○	
2008	Compass	RADIO	○	●	●	●	●	○	●	
2008	Compass	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2008	Compass	PCM	○	●	●	●	●	●	●	0042 0142 012D 0310 0313 0312 0173 03A3 0311 03A4 013B 0144 02E7 0140 013E 0126 0141 0044 0411 0128 03F4 012E 0314 012C 0386 012A 012B
2008	Compass	TCM	○	●	●	●	●	●	●	0380
2008	Compass	ORC	○	●	●	●	●	○	●	
2008	Compass	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 022D 0227 023D 023E 0271 0270
2008	Compass	SDAR	○	●	●	●	●	○	○	
2008	Compass	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0069 0073

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Dakota	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 01DE 0227 023E 0271
2008	Dakota	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB
2008	Dakota	AMP	○	●	●	●	●	○	●	006D 0068
2008	Dakota	EOM	○	●	●	●	●	○	●	00BA
2008	Dakota	HFM	○	●	●	●	●	●	○	00E3
2008	Dakota	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0293 0033 0388 04A6 04A0 00C6 0040 00DA 0272 0273
2008	Dakota	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2008	Dakota	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2008	Dakota	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2008	Dakota	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0381 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2008	Dakota	ORC	○	●	●	●	●	○	●	02A1
2008	Raider	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2008	Raider	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2008	Raider	ORC	○	●	●	●	●	○	●	02A1
2008	Raider	HFM	○	●	●	●	●	●	○	00E3
2008	Raider	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2008	Raider	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 01DE 0227 023E 0271
2008	Raider	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0381 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2008	Raider	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0036 00D5 00D8 049F 0037 0389 0035 0034 0038 00DB 00D6 00D9 003A 049E 0293 0033 0388 04A6 04A0 00C6 0040 00DA 0272 0273
2008	Raider	AMP	○	●	●	●	●	○	●	006D 0068
2008	Raider	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB
2008	Raider	EOM	○	●	●	●	●	○	●	00BA
2008	Caliber	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2008	Caliber	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0382 0094 0092 038D 0096 0383
2008	Caliber	EBG	○	●	●	●	●	○	○	
2008	Caliber	AMP	○	●	●	●	●	○	●	006D 0068 0289 028A 006B 006C 006A 0069 0073
2008	Caliber	TCM	○	●	●	●	●	●	●	0380
2008	Caliber	SAS	○	●	●	●	○	○	○	
2008	Caliber	SDAR	○	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Caliber	TIPMCGW	○	●	●	●	●	●	●	02F3 02DC 0483 003C 003D 0032 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 0388 0390 02F1 02F0 02EF 030E 030C 038F
2008	Caliber	PCM	○	●	●	●	●	●	●	02E7 0140 013E 0126 0141 0044 0411 0128 03F4 012E 0314 012C 012D 0386 0173 012A 012B 013B 0042 0142 0310 0313 0312 03A3 0311 03A4 0144
2008	Caliber	ITM	○	●	●	●	●	●	●	0106
2008	Caliber	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2008	Caliber	AWD	○	●	●	●	●	●	●	
2008	Caliber	HFM	○	●	●	●	●	●	○	00E3
2008	Caliber	ORC	○	●	●	●	●	○	●	
2008	Caliber	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 022D 0227 023D 023E 0271 0270
2008	PT Cruiser	HFM	○	●	●	●	●	●	○	00E3
2008	PT Cruiser	ITM	○	●	●	●	●	●	●	0385 0106 010A
2008	PT Cruiser	TIPMCGW	○	●	●	●	●	●	●	02DC 030E 030C 0483 003D 0032 003F 0484 0036 0037 0389 0034 0038 002E 020E 0215 028F 028E 0211 0388
2008	PT Cruiser	PDM	○	●	●	●	○	●	○	
2008	PT Cruiser	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 022D 0227 023D 023E 0271 0270
2008	PT Cruiser	ABS	○	●	●	●	●	●	●	03AB 0002 005E 0060 005B
2008	PT Cruiser	SDAR	○	●	●	●	●	○	○	
2008	PT Cruiser	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0386 0173 012A 0482 012B 013B 0042 0149 0142 0145 0148 0049 048B
2008	PT Cruiser	TCM	○	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 0175 04B0 0391
2008	PT Cruiser	DDM	○	●	●	●	●	●	○	
2008	PT Cruiser	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0069 0073
2008	PT Cruiser	ORC	○	●	●	●	●	○	●	
2008	PT Cruiser	RADIO	○	●	●	●	●	○	●	
2008	PT Cruiser	CCN	○	●	●	●	●	●	●	008C 008F 008E 0094 0092 0096
2008	PT Cruiser	OCM	○	●	●	●	●	○	○	011E
2008	Mini-Van	SKREEM	○	●	●	●	●	○	○	8003 8004 8005 8006 8007 01D2 04A2 8008 8009 800A 800B 800C 01DE 800E 01DA
2008	Mini-Van	BCM	○	●	●	●	○	●	○	
2008	Mini-Van	ABS	○	●	●	●	●	○	○	
2008	Mini-Van	IPM	○	●	●	●	○	●	○	
2008	Mini-Van	ATC	○	●	●	●	○	●	○	
2008	Mini-Van	PTS	○	●	●	●	●	●	○	
2008	Mini-Van	HFM	○	●	●	●	○	●	○	
2008	Mini-Van	PSD	○	●	●	●	○	●	○	
2008	Mini-Van	PLGM	○	●	●	●	●	●	●	
2008	Mini-Van	SDAR	○	●	●	●	●	●	○	
2008	Mini-Van	ORC	○	●	●	●	○	○	○	
2008	Mini-Van	PCM	○	●	●	●	○	●	○	
2008	Mini-Van	DSD	○	●	●	●	○	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Mini-Van	OCM	○	●	●	●	○	○	○	011E 802A 802B 8023 8024
2008	Mini-Van	EOM	○	●	●	○	○	○	○	
2008	Mini-Van	MIC/CCN	○	●	●	●	○	●	○	
2008	Mini-Van	MHSM	○	●	●	●	○	●	○	
2008	Mini-Van	MTC	○	●	●	●	○	●	○	
2008	Mini-Van	TCM	○	●	●	●	●	●	●	
2008	Town & Country / Caravan	DMFL	○	●	●	●	●	●	●	
2008	Town & Country / Caravan	DVD	○	●	●	●	●	○	○	
2008	Town & Country / Caravan	PSDML	○	●	●	●	●	○	●	0343 0461 04A9 0460 0342
2008	Town & Country / Caravan	PLGM	○	●	●	●	●	●	●	038A 038B 0342
2008	Town & Country / Caravan	DMRL	○	●	●	●	●	●	●	00B4 00B5 00B6
2008	Town & Country / Caravan	ORC	○	●	●	●	●	○	●	02A1 0122
2008	Town & Country / Caravan	PTS	○	●	●	●	●	●	●	01B8
2008	Town & Country / Caravan	TCM	○	●	●	●	●	●	○	03AF 0499 049C 0392 03B0 0498 049B 0393 0394 03B1 0497 049A 0395 03B2 0496 03B6 03B3 0495 049D 0396 04A8 01FC 0177 03B4 0175
2008	Town & Country / Caravan	AMP	○	●	●	●	●	○	●	006D 0068
2008	Town & Country / Caravan	FSM	○	●	●	●	●	●	○	03AC 03AD 0346 0347
2008	Town & Country / Caravan	PCM	○	●	●	●	●	●	●	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0044 0049 0144 02C0 02BB 031D 02C1 013B 02C2 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 035B 02FB 013C 012C 0410 0177 0386 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC
2008	Town & Country / Caravan	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2008	Town & Country / Caravan	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 003A 002E 038F 0388 0390 03A1 03A2
2008	Town & Country / Caravan	HVAC	○	●	●	●	●	●	●	00EA 00E9 00EC 02EA 02EB 03A9
2008	Town & Country / Caravan	HIDT	○	●	●	●	●	●	○	0480
2008	Town & Country / Caravan	VES2	○	●	●	●	●	●	●	
2008	Town & Country / Caravan	SAS	○	●	●	●	○	○	○	
2008	Town & Country / Caravan	PSDMR	○	●	●	●	●	○	●	0343 0461 04A9 0460 0342
2008	Town & Country / Caravan	VES3	○	●	●	●	●	●	●	
2008	Town & Country / Caravan	SDARV	○	●	●	●	●	○	○	
2008	Town & Country / Caravan	ITM	○	●	●	●	●	●	●	0106
2008	Town & Country / Caravan	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2008	Town & Country / Caravan	HFM	○	●	●	●	●	●	○	00E3
2008	Town & Country / Caravan	WCM	○	●	●	●	●	●	●	02A7 0414 0233 01D2 0228 03E6 0225 0232 0230 0231 022F 01DE 0300 01DA 0245 022E 03E4
2008	Town & Country / Caravan	DMRR	○	●	●	●	●	●	●	00B4 00B5 00B6
2008	Town & Country / Caravan	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2008	Town & Country / Caravan	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2008	Town & Country / Caravan	SUNR	○	●	●	●	●	●	○	
2008	Town & Country / Caravan	DMFR	○	●	●	●	●	●	●	
2008	Sprinter	AHLM	○	●	●	●	●	●	○	029F

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Sprinter	ACH	○	●	●	●	●	●	○	
2008	Sprinter	HVAC	○	●	●	●	●	●	●	0012
2008	Sprinter	ECM	○	●	●	●	●	●	●	0042 0142 0127 0044 0337 001E 0045 0046 0023 0043 0049 014D 026E 002E 026F 0336 0025 0024 0022 0020 0021
2008	Sprinter	BCH	○	●	●	●	●	●	○	
2008	Sprinter	SCM	○	●	●	●	●	●	○	
2008	Sprinter	RCM	○	●	●	●	●	●	○	
2008	Sprinter	PTS	○	●	●	●	●	●	●	02D2 02D3
2008	Sprinter	ESM	○	●	●	●	●	●	○	
2008	Sprinter	EISCGW	○	●	●	●	●	○	●	002C 002B 002A
2008	Sprinter	AEHM	○	●	●	●	●	○	○	0004
2008	Sprinter	BCM	○	●	●	●	●	●	○	02E1
2008	Sprinter	ABS	○	●	●	●	●	○	●	032D 0002 0001 0003
2008	Sprinter	RADIO	○	●	●	●	●	○	●	0041
2008	Sprinter	TCM	○	●	●	●	●	○	○	02D6 02D7 02D4 02D5 0018
2008	Sprinter	PSDMR	○	●	●	●	○	●	○	
2008	Sprinter	PSDML	○	●	●	●	○	●	○	
2008	Sprinter	ORC	○	●	●	○	●	○	○	0014 0013 02CF
2008	Sprinter	PSM	○	●	●	●	●	●	○	
2008	Sprinter	DDM	○	●	●	●	●	●	○	
2008	Sprinter	TM	○	●	●	●	○	○	○	
2008	Sprinter	CCN	○	●	●	●	●	○	○	0007 0008 0005 0334 0006 032F 0330 0331 0332 0333 0009 000A
2008	Sprinter	TPM	○	●	●	●	●	○	○	02D0 02D1 001A 001B 001C 001D 0247 004E
2008	Sprinter	SBM	○	●	●	●	●	●	○	
2008	Sprinter	CDC	○	●	●	●	●	○	○	
2008	Sprinter	HFM	○	●	●	●	●	○	○	
2008	Grand Cherokee	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2008	Grand Cherokee	TM	○	●	●	○	○	○	○	
2008	Grand Cherokee	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 002E 049E 0293 0033 0388 04A6 04A0 00C6 0040 022D 00DA 0272 0273
2008	Grand Cherokee	DDM	○	●	●	●	●	●	●	00AC 0306
2008	Grand Cherokee	FDCM	○	●	●	●	●	●	●	
2008	Grand Cherokee	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2008	Grand Cherokee	PTS	○	●	●	●	●	●	●	02ED 03B7 01B4 01B3 01B5 01B8
2008	Grand Cherokee	AHLM	○	●	●	●	●	●	○	029F
2008	Grand Cherokee	SDARV	○	●	●	●	●	○	○	
2008	Grand Cherokee	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2008	Grand Cherokee	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2008	Grand Cherokee	SUNR	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Grand Cherokee	PCM	○	●	●	●	●	●	●	0042 0149 0142 0044 0145 012D 0045 0046 014B 0173 014A 0148 0049 014D 048A 0489 0146 0147 013B 048B 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 035B 02FB 013C 012C 0410 0177 0381 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC
2008	Grand Cherokee	VES3	○	●	●	●	●	●	●	
2008	Grand Cherokee	AMP	○	●	●	●	●	○	●	006D 0068
2008	Grand Cherokee	CCN	○	●	●	●	●	●	●	0097 008C 00BC 008F 008E 0382 0091 0094 0099 0098 0090 0383
2008	Grand Cherokee	PDM	○	●	●	●	●	●	●	0306 00AC
2008	Grand Cherokee	HVAC	○	●	●	●	●	●	●	00EA 00E9 02EA 02EB
2008	Grand Cherokee	LRSM	○	●	●	●	●	○	○	010D
2008	Grand Cherokee	HFM	○	●	●	●	●	●	○	00E3
2008	Grand Cherokee	WCM	○	●	●	●	●	●	●	02A7 0414 0233 01D2 0228 03E6 0225 0232 0230 0231 022F 01DE 0300 01DA 0245 022E 03E4
2008	Grand Cherokee	HSM	○	●	●	●	●	●	●	
2008	Grand Cherokee	EOM	○	●	●	●	●	○	●	00BA 00BC
2008	Grand Cherokee	AHBM	○	●	●	●	●	○	○	03C0 00BC
2008	Grand Cherokee	ORC	○	●	●	●	●	○	●	02A1 0122
2008	Grand Cherokee	ESM	○	●	●	●	●	●	○	
2008	Grand Cherokee	SAS	○	●	●	●	○	○	○	
2008	Grand Cherokee	ITM	○	●	●	●	●	●	●	0106
2008	Commander	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2008	Commander	SAS	○	●	●	●	○	○	○	
2008	Commander	DDM	○	●	●	●	●	●	●	00AC 0306
2008	Commander	CCN	○	●	●	●	●	●	●	0097 008C 00BC 008F 008E 0382 0091 0094 0099 0098 0090 0383
2008	Commander	VES3	○	●	●	●	●	●	●	
2008	Commander	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2008	Commander	LRSM	○	●	●	●	●	○	○	010D
2008	Commander	PLGM	○	●	●	●	●	●	●	038A 038B
2008	Commander	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 002E 049E 0293 0033 0388 04A6 04A0 00C6 0040 022D 00DA 0272 0273
2008	Commander	AHBM	○	●	●	●	●	○	○	03C0 00BC
2008	Commander	SDARV	○	●	●	●	●	○	○	
2008	Commander	ESM	○	●	●	●	●	●	○	
2008	Commander	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2008	Commander	PDM	○	●	●	●	●	●	●	0306 00AC
2008	Commander	ORC	○	●	●	●	●	○	●	02A1 0122
2008	Commander	FDCM	○	●	●	●	●	●	●	
2008	Commander	WCM	○	●	●	●	●	●	●	02A7 0414 0233 01D2 0228 03E6 0225 0232 0230 0231 022F 01DE 0300 01DA 0245 022E 03E4
2008	Commander	ITM	○	●	●	●	●	●	●	0106
2008	Commander	PTS	○	●	●	●	○	●	○	01B4 01B3 01B5 01B8

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Commander	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0381 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0149 0142 0045 0046 014B 014A 0148 0049 014D 048A 0489 0146 0147 048B
2008	Commander	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2008	Commander	AMP	○	●	●	●	●	○	●	006D 0068
2008	Commander	TM	○	●	●	○	○	○	○	
2008	Commander	HVAC	○	●	●	●	●	●	●	00EA 00E9 02EA 02EB
2008	Commander	HFM	○	●	●	●	●	●	○	00E3
2008	Commander	SUNR	○	●	●	●	●	●	○	
2008	Commander	HSM	○	●	●	●	●	●	●	
2008	Viper (Pre-2011)	OCM	○	●	●	●	●	○	○	02AD 011E
2008	Viper (Pre-2011)	PCM	○	●	●	●	●	●	○	013E 0126 0141 0044 0411 0325 04AA 0193 04AC 0128 03F4 0145 04AB 0326 012C 012D 012A 0081 012B
2008	Viper (Pre-2011)	SDAR	○	●	●	●	●	●	○	
2008	Viper (Pre-2011)	HVAC	○	●	●	●	○	●	○	
2008	Viper (Pre-2011)	RADIO	○	●	●	○	○	●	○	
2008	Viper (Pre-2011)	ABS	○	●	●	●	○	●	○	
2008	Viper (Pre-2011)	ORC	○	●	●	●	●	●	●	
2008	Viper (Pre-2011)	BCM	○	●	●	●	○	●	○	
2008	Viper (Pre-2011)	MIC/CCN	○	●	●	●	●	○	○	801A
2008	Viper (Pre-2011)	PCI to CAN Gateway	○	●	●	●	○	○	○	
2008	Crossfire	OCM	○	●	●	●	○	○	○	
2008	Crossfire	ORC	○	●	●	●	○	○	○	
2008	Crossfire	BCM	○	●	●	●	○	●	○	
2008	Crossfire	TCM	○	●	●	●	●	●	●	
2008	Crossfire	PTCM	○	●	●	●	○	●	○	
2008	Crossfire	SLA	○	●	●	●	○	●	○	
2008	Crossfire	ESP	○	●	●	●	○	●	○	
2008	Crossfire	IC	○	●	●	●	○	●	○	8070 807D
2008	Crossfire	PCM	○	●	●	●	○	●	○	
2008	Crossfire	CLP	○	●	●	●	○	●	○	
2008	Crossfire	SKREEM	○	●	●	●	○	●	○	
2008	Crossfire	TPM	○	●	●	●	●	○	●	8001 8002
2008	Crossfire	HVAC	○	●	●	●	○	●	○	
2009	Dodge Ram	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 03C7 0154 0155 0398 0141 0399 0150 0151 033D 037D 0491 017B 0292 037A 0049 0276 0277 033B 033C 0379 017A 0178 0179 0278 039B 014F 033A 0152 039A 0486 0156 0157 0576 0153 015A 0159 0488 0158 0487

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Dodge Ram	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0090
2009	Dodge Ram	FDCM	○	●	●	●	●	○	○	02B5 02B3 02B2 02B1 02AF 02B0
2009	Dodge Ram	SDAR	○	●	●	●	●	○	○	
2009	Dodge Ram	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030C 0483 003C 003D 0214 0032 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 0387 038F 0388 0390
2009	Dodge Ram	RADIO	○	●	●	●	●	○	●	
2009	Dodge Ram	SAS	○	●	●	●	○	○	○	
2009	Dodge Ram	AMP	○	●	●	●	●	○	●	028A 028D 006D 006C 027F 0068 006A
2009	Dodge Ram	EOM	○	●	●	●	●	●	●	00BA 00BC
2009	Dodge Ram	TCM	○	●	●	●	●	●	○	03AF 0499 049C 0392 027B 0167 0166 01EE 03B0 0498 049B 0393 027C 016A 0169 0394 03B1 0497 049A 0395 027D 0291 016C 016B 03B2 02F8 0496 0290 03B3 0495 049D 0396 027E 016E 016D 035B 01FC 0177 0176 024E 01FB 016F 0175 01F6 0391
2009	Dodge Ram	ORC	○	●	●	●	●	○	●	
2009	Dodge Ram	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 033F 0227 023D 023E 0271 0270
2009	Dodge Ram	VES	○	●	●	●	●	●	○	
2009	Dodge Ram	HFM	○	●	●	●	●	●	○	00E3
2009	Dodge Ram	HVAC	○	●	●	●	●	●	●	00EB 00E8 00E9 02EA 02EB 00EA
2009	Dodge Ram	SUNR	○	●	●	●	●	●	○	
2009	Dodge Ram	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062 0485
2009	Ram 1500	DMFR	○	●	●	●	○	●	○	
2009	Ram 1500	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2009	Ram 1500	DMFL	○	●	●	●	●	●	○	
2009	Ram 1500	SDARV	○	●	●	●	●	○	○	
2009	Ram 1500	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2009	Ram 1500	ORC	○	●	●	●	●	○	●	02A1
2009	Ram 1500	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2009	Ram 1500	DTCM	○	●	●	●	●	●	○	
2009	Ram 1500	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2009	Ram 1500	PTS	○	●	●	●	●	●	●	02ED 03B7
2009	Ram 1500	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 008F 008E 003D 0214 0032 003F 0036 0037 0389 0038 002E 0387 038F 0388 0390 03A1 03A2
2009	Ram 1500	HFM	○	●	●	●	●	●	○	00E3
2009	Ram 1500	HSM	○	●	●	●	●	●	○	
2009	Ram 1500	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2009	Ram 1500	ABS	○	●	●	●	●	●	●	03AB 0002
2009	Ram 1500	AMP	○	●	●	●	●	○	●	006D 0068
2009	Ram 1500	WCM	○	●	●	●	●	●	●	02A7 0414 0233 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0300 0245 02FF

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Ram 1500	VES3	○	●	●	●	●	●	●	
2009	Ram 1500	SAS	○	●	●	●	○	○	○	
2009	Durango (Pre-2011)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2009	Durango (Pre-2011)	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0293 0033 0388 04A6 04A0 00C6 0040 00DA 0272 0273
2009	Durango (Pre-2011)	EOM	○	●	●	●	●	●	●	00BA 00BC
2009	Durango (Pre-2011)	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0381 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2009	Durango (Pre-2011)	EPS	○	●	●	●	●	○	○	
2009	Durango (Pre-2011)	TCM	○	●	●	●	●	○	○	018D 0360 035B 035C 035D 035E 035F
2009	Durango (Pre-2011)	SAS	○	●	●	●	○	○	○	
2009	Durango (Pre-2011)	MCPA	○	○	○	●	○	○	○	034C
2009	Durango (Pre-2011)	DDM	○	●	●	●	●	●	●	0306 00AC
2009	Durango (Pre-2011)	HSM	○	●	●	●	●	●	●	
2009	Durango (Pre-2011)	EAC	○	●	●	●	●	○	○	
2009	Durango (Pre-2011)	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2009	Durango (Pre-2011)	ABS	○	●	●	●	●	●	●	04AD 03BB 03AB 0002 0285 0062
2009	Durango (Pre-2011)	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 01DE 0227 023E 0271
2009	Durango (Pre-2011)	HCP	○	●	●	●	●	○	○	018D 0365 036C 0367 036B 0368 035B 0369 036D 0361 036F 036E
2009	Durango (Pre-2011)	AMP	○	●	●	●	●	○	●	006D 0068
2009	Durango (Pre-2011)	ORC	○	●	●	●	●	○	●	
2009	Durango (Pre-2011)	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2009	Durango (Pre-2011)	FDCM	○	●	●	●	●	●	○	0340
2009	Durango (Pre-2011)	APM	○	○	○	○	○	○	○	0422
2009	Durango (Pre-2011)	PDM	○	●	●	●	●	●	●	00AC 0306
2009	Durango (Pre-2011)	HVAC	○	●	●	●	●	●	●	00EA 00E9 02EA 02EB 034A 034B 00E8 0324
2009	Durango (Pre-2011)	HGM	○	●	●	●	●	●	●	
2009	Durango (Pre-2011)	MCPB	○	○	○	●	○	○	○	034C
2009	Durango (Pre-2011)	VES3	○	●	●	●	●	●	●	
2009	Durango (Pre-2011)	HFM	○	●	●	●	●	●	○	00E3
2009	Durango (Pre-2011)	SDARV	○	●	●	●	●	○	○	
2009	Durango (Pre-2011)	BPCM	○	○	○	●	○	○	○	02C5 0350 0351 034F 034E 0354 0352 0353 0356 0355 0358 0357
2009	Durango (Pre-2011)	PTS	○	●	●	●	●	●	●	01B8
2009	Durango (Pre-2011)	PLGM	○	●	●	●	●	●	●	038A 038B
2009	Aspen	ABS	○	●	●	●	●	●	●	04AD 03BB 03AB 0002 0285 0062
2009	Aspen	HGM	○	●	●	●	●	●	●	
2009	Aspen	HSM	○	●	●	●	●	●	●	
2009	Aspen	PLGM	○	●	●	●	●	●	●	038A 038B

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Wrangler (Export)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2009	Wrangler (Export)	SAS	○	●	●	●	○	○	○	
2009	Journey	ITM	○	●	●	●	●	●	●	0106
2009	Journey	WCM	○	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0300 0245 0225 01DA
2009	Journey	CCN	○	●	●	●	○	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2009	Journey	DISP	○	●	●	●	●	○	○	
2009	Journey	AMP	○	●	●	●	●	○	●	006D 0068
2009	Journey	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 02E3 021F 038F 0388 0390 03A1 03A2
2009	Journey	SAS	○	●	●	●	○	○	○	
2009	Journey	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0142 0310 0313 0312 03A3 0311 0144 03A4 02E7 013E 0141 012E 0314
2009	Journey	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2009	Journey	AWD	○	●	●	●	●	○	●	
2009	Journey	DMFL	○	●	●	●	●	●	●	
2009	Journey	DMFR	○	●	●	●	●	●	●	
2009	Journey	HFM	○	●	●	●	●	●	○	00E3
2009	Journey	TCM	○	●	●	●	●	●	●	0391 0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 04B0 0177 0170 0175
2009	Journey	SDARV	○	●	●	●	●	○	○	
2009	Journey	ORC	○	●	●	●	●	○	●	02A1 0122
2009	Journey	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9 00EC 02EA
2009	Journey	VES3	○	●	●	●	●	●	●	
2009	Journey	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2009	Wrangler	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2009	Wrangler	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2009	Wrangler	ASBS	○	●	●	●	●	○	○	0317 0318 031A 031B 0319
2009	Wrangler	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062 0485
2009	Wrangler	HFM	○	●	●	●	●	●	○	00E3
2009	Wrangler	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 013C 012C 012D 0410 0177 0386 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 02F9 03B8 0304 02FA 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0049 0144 02C0 02BB 031D 02C1 02C2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Wrangler	AMP	○	●	●	●	●	○	●	006D 0068
2009	Wrangler	ORC	○	●	●	●	●	○	●	
2009	Wrangler	TCM	○	●	●	●	●	●	○	03AF 0499 049C 0392 03B0 0498 049B 0393 0394 03B1 0497 049A 0395 03B2 0496 03B3 0495 049D 0396 01FC 0177 0176 024E 01FB 016F 0175
2009	Wrangler	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F
2009	Wrangler	SAS	○	●	●	●	○	○	○	
2009	Wrangler	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 01DE 0227 0274
2009	Wrangler	ITM	○	●	●	●	●	●	●	0385 0106
2009	Sebring / 200 / Avenger	ORC	○	●	●	●	●	○	●	
2009	Sebring / 200 / Avenger	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2009	Sebring / 200 / Avenger	SAS	○	●	●	●	○	○	○	
2009	Sebring / 200 / Avenger	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2009	Sebring / 200 / Avenger	AMP	○	●	●	●	●	○	●	006D 0068
2009	Sebring / 200 / Avenger	DDM	○	●	●	●	●	●	○	0306
2009	Sebring / 200 / Avenger	ITM	○	●	●	●	●	●	●	0106 0385
2009	Sebring / 200 / Avenger	PTCM	○	●	●	●	●	○	●	0259 04A4
2009	Sebring / 200 / Avenger	TCM	○	●	●	●	●	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 04B0 0177 0170 0391 0175 03AF 0499 049C 0392 027B 03B0 0498 049B 0393 027C 0394 03B1 0497 049A 0395 027D 0291 03B2 02F8 0496 0290 03B3 0495 049D 0396 027E 01FC 0176 024E 01FB 016F
2009	Sebring / 200 / Avenger	VES3	○	●	●	●	●	●	●	
2009	Sebring / 200 / Avenger	PCM	○	●	●	●	●	●	●	0042 0142 012D 0310 0313 0173 03A3 0144 03A4 013B 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 0410 0177 0386 0304 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 02E7 013E 0141 012E 0314
2009	Sebring / 200 / Avenger	PDM	○	●	●	●	●	●	○	0306
2009	Sebring / 200 / Avenger	WCM	○	●	●	●	●	○	●	0233 022E 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 022D 0227 023D 023E 0271 0270
2009	Sebring / 200 / Avenger	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0382 0094 0092 038D 0096 0383
2009	Sebring / 200 / Avenger	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2009	Sebring / 200 / Avenger	HFM	○	●	●	●	●	●	○	00E3
2009	Sebring / 200 / Avenger	AWD	○	●	●	●	●	○	●	
2009	Sebring / 200 / Avenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0214 0032 003F 0484 0036 02C3 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2009	Nitro	SAS	○	●	●	●	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Nitro	PCM	○	●	●	●	●	●	●	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0044 0049 0144 02C0 02BB 031D 02C1 013B 02C2 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 035B 02FB 03B8 013C 012C 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC
2009	Nitro	OCM	○	●	●	●	●	○	○	011E
2009	Nitro	PTS	○	●	●	●	●	●	●	01B8
2009	Nitro	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2009	Nitro	HFM	○	●	●	●	●	●	○	00E3
2009	Nitro	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 02E2 038F 0388 0390 03A1 03A2
2009	Nitro	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062 0485
2009	Nitro	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 01DE 0227 0274
2009	Nitro	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2009	Nitro	DMFR	○	●	●	●	●	●	●	
2009	Nitro	VES3	○	●	●	●	●	●	●	
2009	Nitro	AMP	○	●	●	●	●	○	●	006D 0068
2009	Nitro	DMFL	○	●	●	●	●	●	●	
2009	Nitro	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2009	Nitro	ORC	○	●	●	●	●	○	●	
2009	Nitro	ITM	○	●	●	●	●	●	●	0106
2009	Nitro	ESM	○	●	●	●	●	●	○	
2009	Nitro	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2009	Liberty	VES3	○	●	●	●	●	●	●	
2009	Liberty	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0049 0144 02C0 02BB 031D 02C1 02C2
2009	Liberty	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2009	Liberty	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2009	Liberty	SAS	○	●	●	●	○	○	○	
2009	Liberty	DMFL	○	●	●	●	●	●	●	
2009	Liberty	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2009	Liberty	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 02E2 038F 0388 0390 03A1 03A2
2009	Liberty	OCM	○	●	●	●	●	○	○	011E
2009	Liberty	AMP	○	●	●	●	●	○	●	006D 0068
2009	Liberty	ESM	○	●	●	●	●	●	○	
2009	Liberty	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2009	Liberty	ITM	○	●	●	●	●	●	●	010A 0106

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Liberty	FDCM	○	●	●	●	●	●	○	0340
2009	Liberty	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2009	Liberty	HFM	○	●	●	●	●	●	○	00E3
2009	Liberty	ORC	○	●	●	●	●	○	●	
2009	Liberty	PTS	○	●	●	●	●	●	●	01B8
2009	Liberty	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2009	Liberty	DMFR	○	●	●	●	●	●	●	
2009	Liberty	WCM	○	●	●	●	●	○	●	0233 01D2 03E4 0228 0232 0230 0231 022F 01DE 0227
2009	Liberty	SUNR	○	●	●	●	●	○	○	04A7
2009	Challenger	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2009	Challenger	ESM	○	●	●	●	●	●	○	
2009	Challenger	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2009	Challenger	ORC	○	●	●	●	●	○	●	02A1
2009	Challenger	CCN	○	●	●	●	●	●	●	008F 008E 0382 038D 0090 0383
2009	Challenger	HFM	○	●	●	●	●	●	○	00E3
2009	Challenger	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2009	Challenger	SUNR	○	●	●	●	●	●	○	
2009	Challenger	WCM	○	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0300 0245 02FF 01DA 0225
2009	Challenger	SCM	○	●	●	●	○	●	●	
2009	Challenger	TPM	○	●	●	●	○	○	●	02F7 0232 0230 0231 022F
2009	Challenger	PEM	○	●	●	●	●	○	●	0463 0442 0307
2009	Challenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0219 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A2
2009	Challenger	PDM	○	●	●	●	●	●	○	0306
2009	Challenger	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2009	Challenger	DDM	○	●	●	●	●	●	○	0306
2009	Challenger	EOM	○	●	●	●	●	○	●	00BA 00BC
2009	Challenger	AMP	○	●	●	●	●	○	●	006D 0068
2009	Challenger	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2009	Challenger	HSM	○	●	●	●	●	●	●	
2009	300 / Magnum / Charger (Pre-2011)	PEM	○	●	●	●	●	○	●	0463 0442 0307
2009	300 / Magnum / Charger (Pre-2011)	SUNR	○	●	●	●	●	●	○	
2009	300 / Magnum / Charger (Pre-2011)	EOM	○	●	●	●	●	○	●	00BA 00BC
2009	300 / Magnum / Charger (Pre-2011)	PDM	○	●	●	●	●	●	●	00AC
2009	300 / Magnum / Charger (Pre-2011)	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2009	300 / Magnum / Charger (Pre-2011)	PTIM	○	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	300 / Magnum / Charger (Pre-2011)	ITM	○	●	●	●	●	●	●	0106
2009	300 / Magnum / Charger (Pre-2011)	SCM	○	●	●	●	○	●	●	
2009	300 / Magnum / Charger (Pre-2011)	HIDT	○	●	●	●	●	●	○	00E5
2009	300 / Magnum / Charger (Pre-2011)	HFM	○	●	●	●	●	●	○	00E3
2009	Compass	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2009	Compass	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0032 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2009	Compass	ITM	○	●	●	●	●	●	●	0106
2009	Compass	PCM	○	●	●	●	●	●	●	0042 0142 012D 0310 0313 0173 03A3 0144 03A4 013B 0312 0311 02E7 0140 013E 0126 0141 0044 0411 0128 03F4 012E 0314 012C 0386 012A 012B
2009	Compass	SAS	○	●	●	●	○	○	○	
2009	Compass	TCM	○	●	●	●	●	●	●	0380
2009	Compass	HFM	○	●	●	●	●	●	○	00E3
2009	Compass	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0382 0094 0092 038D 0096 0383
2009	Compass	AWD	○	●	●	●	●	●	●	
2009	Compass	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2009	Compass	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 022D 0227 023D 023E 0271 0270
2009	Compass	AMP	○	●	●	●	●	○	●	006D 0068
2009	Compass	ORC	○	●	●	●	●	○	●	
2009	Dakota	HFM	○	●	●	●	●	●	○	00E3
2009	Dakota	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2009	Dakota	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2009	Dakota	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 01DE 0227 023E 0271
2009	Dakota	EOM	○	●	●	●	●	○	●	00BA
2009	Dakota	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0381 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2009	Dakota	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB
2009	Dakota	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2009	Dakota	AMP	○	●	●	●	●	○	●	006D 0068
2009	Dakota	ORC	○	●	●	●	●	○	●	02A1
2009	Dakota	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0293 0033 0388 04A6 04A0 00C6 0040 00DA 0272 0273
2009	Raider	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 01DE 0227 023E 0271

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Raider	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2009	Raider	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2009	Raider	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0381 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2009	Raider	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB
2009	Raider	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0293 0033 0388 04A6 04A0 00C6 0040 00DA 0272 0273
2009	Raider	HFM	○	●	●	●	●	●	○	00E3
2009	Raider	ORC	○	●	●	●	●	○	●	02A1
2009	Raider	EOM	○	●	●	●	●	○	●	00BA
2009	Raider	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2009	Raider	AMP	○	●	●	●	●	○	●	006D 0068
2009	Caliber	TCM	○	●	●	●	●	●	●	0380
2009	Caliber	ORC	○	●	●	●	●	○	●	
2009	Caliber	SAS	○	●	●	●	○	○	○	
2009	Caliber	ITM	○	●	●	●	●	●	●	0106
2009	Caliber	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062 0485
2009	Caliber	EBG	○	●	●	●	●	○	○	
2009	Caliber	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2009	Caliber	PCM	○	●	●	●	●	●	●	0042 0142 012D 0310 0313 0312 0173 03A3 0311 03A4 013B 0144 02E7 0140 013E 0126 0141 0044 0411 0128 03F4 012E 0314 012C 0386 012A 012B
2009	Caliber	AMP	○	●	●	●	●	○	●	006D 0068
2009	Caliber	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0032 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2009	Caliber	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0382 0094 0092 038D 0096 0383
2009	Caliber	AWD	○	●	●	●	●	●	●	
2009	Caliber	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 022D 0227 023D 023E 0271 0270
2009	Caliber	HFM	○	●	●	●	●	●	○	00E3
2009	PT Cruiser	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 022D 0227 023D 023E 0271 0270
2009	PT Cruiser	CCN	○	●	●	●	●	●	●	008C 008F 008E 0094 0092 0096
2009	PT Cruiser	RADIO	○	●	●	●	●	○	●	
2009	PT Cruiser	TIPMCGW	○	●	●	●	●	●	●	02DC 030E 030C 0483 003D 0032 003F 0484 0036 0037 0389 0034 0038 002E 020E 0215 028F 028E 0211 0388
2009	PT Cruiser	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0386 0173 012A 0482 012B 013B 0042 0149 0142 0145 0148 0049 048B
2009	PT Cruiser	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0069 0073
2009	PT Cruiser	HFM	○	●	●	●	●	●	○	00E3

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	PT Cruiser	OCM	○	●	●	●	●	○	○	011E
2009	PT Cruiser	ORC	○	●	●	●	●	○	●	
2009	PT Cruiser	SDAR	○	●	●	●	●	○	○	
2009	PT Cruiser	ITM	○	●	●	●	●	●	●	010A 0106 0385
2009	PT Cruiser	PDM	○	●	●	●	○	●	○	
2009	PT Cruiser	ABS	○	●	●	●	●	●	●	03AB 0002 005E 0060 005B
2009	PT Cruiser	TCM	○	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 04B0 0177 0170 0391 0175
2009	PT Cruiser	DDM	○	●	●	●	●	●	○	
2009	Mini-Van	MHSM	○	●	●	●	○	●	○	
2009	Mini-Van	PCM	○	●	●	●	○	●	○	
2009	Mini-Van	PLGM	○	●	●	●	●	●	●	
2009	Mini-Van	PSD	○	●	●	●	○	●	○	
2009	Mini-Van	BCM	○	●	●	●	○	●	○	
2009	Mini-Van	DSD	○	●	●	●	○	●	○	
2009	Mini-Van	MTC	○	●	●	●	○	●	○	
2009	Mini-Van	TCM	○	●	●	●	●	●	●	
2009	Mini-Van	ORC	○	●	●	●	○	○	○	
2009	Mini-Van	EOM	○	●	●	○	○	○	○	
2009	Mini-Van	HFM	○	●	●	●	○	●	○	
2009	Mini-Van	OCM	○	●	●	●	○	○	○	011E 802A 802B 8023 8024
2009	Mini-Van	PTS	○	●	●	●	●	●	○	
2009	Mini-Van	SKREEM	○	●	●	●	●	○	○	8003 8004 8005 8006 8007 01D2 04A2 8008 8009 800A 800B 800C 01DE 800E 01DA
2009	Mini-Van	IPM	○	●	●	●	○	●	○	
2009	Mini-Van	ABS	○	●	●	●	●	○	○	
2009	Mini-Van	SDAR	○	●	●	●	●	●	○	
2009	Mini-Van	MIC/CCN	○	●	●	●	○	●	○	
2009	Mini-Van	ATC	○	●	●	●	○	●	○	
2009	Routan	PSDML	○	●	●	●	●	○	●	0343 0461 04A9 0460 0342
2009	Routan	AMP	○	●	●	●	●	○	●	006D 0068
2009	Routan	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2009	Routan	PLGM	○	●	●	●	●	●	●	038A 038B 0342
2009	Routan	DVD	○	●	●	●	●	○	○	
2009	Routan	PTS	○	●	●	●	●	●	●	02ED 03B7
2009	Routan	WCM	○	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0300 0245 0225 01DA
2009	Routan	VES2	○	●	●	●	●	●	●	
2009	Routan	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062 0485
2009	Routan	DMRL	○	●	●	●	●	●	●	00B4 00B5 00B6
2009	Routan	SUNR	○	●	●	●	●	●	○	
2009	Routan	HFM	○	●	●	●	●	●	○	00E3
2009	Routan	DMFR	○	●	●	●	●	●	●	
2009	Routan	DMFL	○	●	●	●	●	●	●	
2009	Routan	DMRR	○	●	●	●	●	●	●	00B4 00B5 00B6

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Routan	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2009	Routan	PSDMR	○	●	●	●	●	○	●	0343 0461 04A9 0460 0342
2009	Routan	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2009	Routan	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2009	Routan	SAS	○	●	●	●	○	○	○	
2009	Routan	VES3	○	●	●	●	●	●	●	
2009	Routan	FSM	○	●	●	●	●	●	○	03AC 03AD 0346 0347
2009	Routan	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2009	Routan	ORC	○	●	●	●	●	○	●	02A1 0122
2009	Routan	HVAC	○	●	●	●	●	●	●	00EA 00E9 00EC 02EA 02EB 03B9 03A9
2009	Town & Country / Caravan	HIDT	○	●	●	●	●	●	○	0480
2009	Town & Country / Caravan	BSM	○	●	●	●	●	○	○	0372
2009	Town & Country / Caravan	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2009	Town & Country / Caravan	VES3	○	●	●	●	●	●	●	
2009	Town & Country / Caravan	DVD	○	●	●	●	●	○	○	
2009	Town & Country / Caravan	TCM	○	●	●	●	●	●	○	03AF 0499 049C 0392 03B0 0498 049B 0393 0394 03B1 0497 049A 0395 03B2 0496 03B6 03B3 0495 049D 0396 04A8 01FC 0177 03B4 0175
2009	Town & Country / Caravan	AHBM	○	●	●	●	●	○	○	03C0 00BC
2009	Town & Country / Caravan	SAS	○	●	●	●	○	○	○	
2009	Town & Country / Caravan	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2009	Town & Country / Caravan	WCM	○	●	●	●	●	●	●	02A7 0414 0233 01D2 0228 03E6 0225 0232 0230 0231 022F 01DE 0300 01DA 0245 022E 03E4
2009	Town & Country / Caravan	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0049 0144 02C0 02BB 031D 02C1 02C2
2009	Town & Country / Caravan	PSDMR	○	●	●	●	●	○	●	0343 0461 04A9 0460 0342
2009	Town & Country / Caravan	PTS	○	●	●	●	●	●	●	02ED 03B7
2009	Town & Country / Caravan	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 00EC 02EA 03B9
2009	Town & Country / Caravan	VES2	○	●	●	●	●	●	●	
2009	Town & Country / Caravan	HFM	○	●	●	●	●	●	○	00E3
2009	Town & Country / Caravan	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2009	Town & Country / Caravan	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 003A 002E 038F 0388 0390 03A1 03A2
2009	Town & Country / Caravan	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2009	Town & Country / Caravan	ITM	○	●	●	●	●	●	●	0106
2009	Town & Country / Caravan	FSM	○	●	●	●	●	●	○	03AC 03AD 0346 0347
2009	Town & Country / Caravan	SDARV	○	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Town & Country / Caravan	PSDML	○	●	●	●	●	○	●	0343 0461 04A9 0460 0342
2009	Town & Country / Caravan	SUNR	○	●	●	●	●	●	○	
2009	Town & Country / Caravan	PLGM	○	●	●	●	●	●	●	038A 038B 0342
2009	Town & Country / Caravan	ORC	○	●	●	●	●	○	●	02A1 0122
2009	Town & Country / Caravan	DMRL	○	●	●	●	●	●	●	00B4 00B5 00B6
2009	Town & Country / Caravan	DMRR	○	●	●	●	●	●	●	00B4 00B5 00B6
2009	Town & Country / Caravan	AMP	○	●	●	●	●	○	●	006D 0068
2009	Town & Country / Caravan	DMFL	○	●	●	●	●	●	●	
2009	Town & Country / Caravan	DMFR	○	●	●	●	●	●	●	
2009	Sprinter	RADIO	○	●	●	●	●	○	●	0041
2009	Sprinter	ECM	○	●	●	●	●	●	●	0042 0142 0127 0044 0337 001E 0045 0046 0023 0043 0049 014D 026E 002E 026F 0336 0025 0024 0022 0020 0021
2009	Sprinter	PSM	○	●	●	●	●	●	○	
2009	Sprinter	ESM	○	●	●	●	●	●	○	
2009	Sprinter	AHLM	○	●	●	●	●	●	○	029F
2009	Sprinter	PSDML	○	●	●	●	○	●	○	
2009	Sprinter	PSDMR	○	●	●	●	○	●	○	
2009	Sprinter	EISCGW	○	●	●	●	●	○	●	002C 002B 002A
2009	Sprinter	DDM	○	●	●	●	●	●	○	
2009	Sprinter	PTS	○	●	●	●	●	●	●	02D2 02D3
2009	Sprinter	AEHM	○	●	●	●	●	○	○	0004
2009	Sprinter	TCM	○	●	●	●	●	○	○	02D6 02D7 02D4 02D5 0018
2009	Sprinter	TM	○	●	●	●	○	○	○	
2009	Sprinter	BCM	○	●	●	●	●	●	○	02E1
2009	Sprinter	ABS	○	●	●	●	●	○	●	032D 0002 0001 0003
2009	Sprinter	SBM	○	●	●	●	●	●	○	
2009	Sprinter	RCM	○	●	●	●	●	●	○	
2009	Sprinter	HVAC	○	●	●	●	●	●	●	0012
2009	Sprinter	BCH	○	●	●	●	●	●	○	
2009	Sprinter	SCM	○	●	●	●	●	●	○	
2009	Sprinter	ACH	○	●	●	●	●	●	○	
2009	Sprinter	TPM	○	●	●	●	●	○	○	02D0 02D1 001A 001B 001C 001D 0247 004E
2009	Sprinter	CCN	○	●	●	●	●	○	○	0007 0008 0005 0334 0006 032F 0330 0331 0332 0333 0009 000A
2009	Sprinter	ORC	○	●	●	○	●	○	○	0014 0013 02CF
2009	Sprinter	HFM	○	●	●	●	●	○	○	
2009	Sprinter	CDC	○	●	●	●	●	○	○	
2009	Grand Cherokee	PDM	○	●	●	●	●	●	●	0306 00AC
2009	Grand Cherokee	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2009	Grand Cherokee	WCM	○	●	●	●	●	●	●	02A7 0414 0233 01D2 0228 03E6 0225 0232 0230 0231 022F 01DE 0300 01DA 0245 022E 03E4
2009	Grand Cherokee	TM	○	●	●	○	○	○	○	
2009	Grand Cherokee	VES3	○	●	●	●	●	●	●	
2009	Grand Cherokee	ESM	○	●	●	●	●	●	○	
2009	Grand Cherokee	DDM	○	●	●	●	●	●	●	0306 00AC

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Grand Cherokee	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 002E 049E 0293 0033 0388 04A6 04A0 00C6 0040 022D 00DA 0272 0273
2009	Grand Cherokee	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2009	Grand Cherokee	SAS	○	●	●	●	○	○	○	
2009	Grand Cherokee	SUNR	○	●	●	●	●	●	○	
2009	Grand Cherokee	FDCM	○	●	●	●	●	●	●	
2009	Grand Cherokee	EOM	○	●	●	●	●	○	●	00BA 00BC
2009	Grand Cherokee	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2009	Grand Cherokee	HVAC	○	●	●	●	●	●	●	00EA 00E9 02EA 02EB
2009	Grand Cherokee	AHLM	○	●	●	●	●	●	○	029F
2009	Grand Cherokee	ORC	○	●	●	●	●	○	●	02A1 0122
2009	Grand Cherokee	SDARV	○	●	●	●	●	○	○	
2009	Grand Cherokee	LRSM	○	●	●	●	●	○	○	010D
2009	Grand Cherokee	PTS	○	●	●	●	●	●	●	02ED 03B7
2009	Grand Cherokee	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2009	Grand Cherokee	HFM	○	●	●	●	●	●	○	00E3
2009	Grand Cherokee	HSM	○	●	●	●	●	●	●	
2009	Grand Cherokee	AHBM	○	●	●	●	●	○	○	03C0 00BC
2009	Grand Cherokee	PCM	○	●	●	●	●	●	●	0042 0149 0142 0044 0145 012D 0045 0046 014B 0173 014A 0148 0049 014D 048A 0489 0146 0147 013B 048B 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 035B 02FB 03B8 013C 012C 0410 0177 0381 0304 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC
2009	Grand Cherokee	ITM	○	●	●	●	●	●	●	0106
2009	Grand Cherokee	CCN	○	●	●	●	●	●	●	0097 008C 00BC 008F 008E 0382 0091 0094 0099 0098 0090 0383
2009	Grand Cherokee	AMP	○	●	●	●	●	○	●	006D 0068
2009	Commander	AHBM	○	●	●	●	●	○	○	03C0 00BC
2009	Commander	AHLM	○	●	●	●	●	●	○	029F
2009	Commander	PDM	○	●	●	●	●	●	●	00AC 0306
2009	Commander	SDARV	○	●	●	●	●	○	○	
2009	Commander	HFM	○	●	●	●	●	●	○	00E3
2009	Commander	WCM	○	●	●	●	●	●	●	02A7 0414 0233 01D2 0228 03E6 0225 0232 0230 0231 022F 01DE 0300 01DA 0245 022E 03E4
2009	Commander	SUNR	○	●	●	●	●	●	○	
2009	Commander	ESM	○	●	●	●	●	●	○	
2009	Commander	HVAC	○	●	●	●	●	●	●	00EA 00E9 02EA 02EB
2009	Commander	AMP	○	●	●	●	●	○	●	006D 0068
2009	Commander	HSM	○	●	●	●	●	●	●	
2009	Commander	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 002E 049E 0293 0033 0388 04A6 04A0 00C6 0040 022D 00DA 0272 0273

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Commander	CCN	○	●	●	●	●	●	●	0097 008C 00BC 008F 008E 0382 0091 0094 0099 0098 0090 0383
2009	Commander	PTS	○	●	●	●	●	●	●	02ED 03B7
2009	Commander	PLGM	○	●	●	●	●	●	●	038A 038B
2009	Commander	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2009	Commander	ITM	○	●	●	●	●	●	●	0106
2009	Commander	ORC	○	●	●	●	●	○	●	02A1 0122
2009	Commander	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2009	Commander	VES3	○	●	●	●	●	●	●	
2009	Commander	TM	○	●	●	○	○	○	○	
2009	Commander	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2009	Commander	DDM	○	●	●	●	●	●	●	00AC 0306
2009	Commander	FDCM	○	●	●	●	●	●	●	
2009	Commander	SAS	○	●	●	●	○	○	○	
2009	Commander	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2009	Commander	LRSM	○	●	●	●	●	○	○	010D
2009	Commander	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0381 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0149 0142 0045 0046 014B 014A 0148 0049 014D 048A 0489 0146 0147 048B
2009	Viper (Pre-2011)	OCM	○	●	●	●	●	○	○	02AD 011E
2009	Viper (Pre-2011)	PCM	○	●	●	●	●	●	○	013E 0126 0141 0044 0411 0325 04AA 0193 04AC 0128 03F4 0145 04AB 0326 012C 012D 012A 0081 012B
2009	Viper (Pre-2011)	ABS	○	●	●	●	○	●	○	
2009	Viper (Pre-2011)	ORC	○	●	●	●	●	●	●	
2009	Viper (Pre-2011)	BCM	○	●	●	●	○	●	○	
2009	Viper (Pre-2011)	MIC/CCN	○	●	●	●	●	○	○	801A
2009	Viper (Pre-2011)	RADIO	○	●	●	○	○	●	○	
2009	Viper (Pre-2011)	PCI to CAN Gateway	○	●	●	●	○	○	○	
2009	Viper (Pre-2011)	SDAR	○	●	●	●	●	●	○	
2009	Viper (Pre-2011)	HVAC	○	●	●	●	○	●	○	
2010	Ram 3500 Pickup	AMP	○	●	●	●	●	○	●	006D 0068
2010	Ram 3500 Pickup	HSM	○	●	●	●	●	●	○	
2010	Ram 3500 Pickup	ORC	○	●	●	●	●	○	●	02A1
2010	Ram 3500 Pickup	PTS	○	●	●	●	●	●	●	02ED 03B7
2010	Ram 3500 Pickup	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2010	Ram 3500 Pickup	DMFL	○	●	●	●	●	●	●	
2010	Ram 3500 Pickup	WCM	○	●	●	●	●	●	●	02A7 0228 02FF 03E6 0245 0414 0233 01D2 03E4 0232 0230 0231 022F 01DE 0300
2010	Ram 3500 Pickup	ABS	○	●	●	●	●	●	●	03AB 0002
2010	Ram 3500 Pickup	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2010	Ram 3500 Pickup	DMFR	○	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Ram 3500 Pickup	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 008F 003D 0214 0032 003F 0036 0037 0389 0038 002E 0387 038F 0388 0390 03A1 022D 03A2
2010	Ram 3500 Pickup	DTCM	○	●	●	●	●	●	○	
2010	Ram 3500 Pickup	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2010	Ram 3500 Pickup	VES3	○	●	●	●	●	●	●	
2010	Ram 3500 Pickup	ITBM	○	●	●	●	○	○	○	
2010	Ram 3500 Pickup	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 03FC 03FD 03FE 0154 0155 0403 0401 0150 0407 0491 017B 04AF 03C7 03CB 0049 03C8 0379 04AE 0179 03C1 039A 03C6 03C3 03C4 03C9 03FF 03C2
2010	Ram 3500 Pickup	SAS	○	●	●	●	○	○	○	
2010	Ram 3500 Pickup	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2010	Ram 3500 Pickup	HFM	○	●	●	●	●	●	○	00E3
2010	Ram 3500 Pickup	SDARV	○	●	●	●	●	○	○	
2010	Ram 2500	DMFL	○	●	●	●	●	●	●	
2010	Ram 2500	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2010	Ram 2500	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 008F 008E 003D 0214 0032 003F 0036 0037 0389 0038 002E 0387 038F 0388 0390 03A1 022D 03A2
2010	Ram 2500	PTS	○	●	●	●	●	●	●	02ED 03B7
2010	Ram 2500	HFM	○	●	●	●	●	●	○	00E3
2010	Ram 2500	ABS	○	●	●	●	●	●	●	03AB 0002
2010	Ram 2500	DMFR	○	●	●	●	●	●	●	
2010	Ram 2500	ORC	○	●	●	●	●	○	●	02A1
2010	Ram 2500	SDARV	○	●	●	●	●	○	○	
2010	Ram 2500	VES3	○	●	●	●	●	●	●	
2010	Ram 2500	FDCM	○	●	●	●	●	○	○	02B5 02B3 02B2 02B1 02AF 02B0
2010	Ram 2500	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2010	Ram 2500	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2010	Ram 2500	SAS	○	●	●	●	○	○	○	
2010	Ram 2500	HSM	○	●	●	●	●	●	○	
2010	Ram 2500	ITBM	○	●	●	●	○	○	○	
2010	Ram 2500	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2010	Ram 2500	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2010	Ram 2500	AMP	○	●	●	●	●	○	●	006D 0068
2010	Ram 2500	DTCM	○	●	●	●	●	●	○	
2010	Ram 2500	WCM	○	●	●	●	●	●	●	02A7 0414 0233 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0300 0245 02FF

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Ram 2500	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 03C7 0154 0155 0044 0411 0403 0401 03FF 03F4 0150 0407 012D 0491 017B 04AF 03CB 0049 03C8 0379 04AE 0179 03C1 035B 039A 03C2 03C3 03C4 03C9 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 026C 026D 040A 0128 027E 0490 0266 0265 0145 02FB 03B8 013C 012C 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 03C6
2010	Dodge Ram	RADIO	○	●	●	●	●	○	●	
2010	Dodge Ram	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 033F 0227 023D 023E 0271 0270
2010	Dodge Ram	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 03C7 0154 0155 0398 0141 0399 0150 0151 033D 037D 0491 017B 0292 037A 0049 0276 0277 033B 033C 0379 017A 0178 0179 0278 014F 033A 0152 039A 039B 0486 0156 0157 0576 0153 015A 0159 0488 0158 0487
2010	Dodge Ram	SAS	○	●	●	●	○	○	○	
2010	Dodge Ram	FDCM	○	●	●	●	●	○	○	02B5 02B3 02B2 02B1 02AF 02B0
2010	Dodge Ram	ORC	○	●	●	●	●	○	●	
2010	Dodge Ram	HVAC	○	●	●	●	●	●	●	00EB 00E8 00E9 02EA 02EB 00EA
2010	Dodge Ram	HFM	○	●	●	●	●	●	○	00E3
2010	Dodge Ram	SUNR	○	●	●	●	●	●	○	
2010	Dodge Ram	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0090
2010	Dodge Ram	TCM	○	●	●	●	●	●	○	01F6 0391 03AF 0499 049C 0392 027B 0167 0166 01EE 03B0 0498 049B 0393 027C 016A 0169 0394 03B1 0497 049A 0395 027D 0291 016C 016B 03B2 02F8 0496 0290 03B3 0495 049D 0396 027E 016E 016D 035B 01FC 0177 0176 024E 01FB 016F 0175
2010	Dodge Ram	SDAR	○	●	●	●	●	○	○	
2010	Dodge Ram	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2010	Dodge Ram	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030C 0483 003C 003D 0214 0032 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 0387 038F 0388 0390
2010	Dodge Ram	AMP	○	●	●	●	●	○	●	028A 028D 006D 006C 027F 0068 006A
2010	Dodge Ram	VES	○	●	●	●	●	●	○	
2010	Dodge Ram	EOM	○	●	●	●	●	●	●	00BA 00BC
2010	Ram 1500	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2010	Ram 1500	WCM	○	●	●	●	●	●	●	02A7 0414 0233 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0300 0245 02FF 01DA
2010	Ram 1500	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2010	Ram 1500	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 008F 008E 003D 0214 0032 003F 0036 0037 0389 0038 002E 0387 038F 0388 0390 03A1 03A2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Ram 1500	ABS	○	●	●	●	●	●	●	03AB 0002
2010	Ram 1500	AMP	○	●	●	●	●	○	●	006D 0068
2010	Ram 1500	HFM	○	●	●	●	●	●	○	00E3
2010	Ram 1500	SDARV	○	●	●	●	●	○	○	
2010	Ram 1500	HSM	○	●	●	●	●	●	○	
2010	Ram 1500	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2010	Ram 1500	ORC	○	●	●	●	●	○	●	02A1
2010	Ram 1500	ITBM	○	●	●	●	○	○	○	
2010	Ram 1500	DMFR	○	●	●	●	●	●	●	
2010	Ram 1500	DMFL	○	●	●	●	●	●	●	
2010	Ram 1500	VES3	○	●	●	●	●	●	●	
2010	Ram 1500	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2010	Ram 1500	SAS	○	●	●	●	○	○	○	
2010	Ram 1500	DTCM	○	●	●	●	●	●	○	
2010	Ram 1500	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2010	Ram 1500	PTS	○	●	●	●	●	●	●	02ED 03B7
2010	Ram 1500	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2010	Ram (Mexico)	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2010	Ram (Mexico)	SAS	○	●	●	●	○	○	○	
2010	Ram (Mexico)	ITBM	○	●	●	●	○	○	○	
2010	Ram (Mexico)	DMFR	○	●	●	●	●	●	●	
2010	Ram (Mexico)	HFM	○	●	●	●	●	●	○	00E3
2010	Ram (Mexico)	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2010	Ram (Mexico)	DTCM	○	●	●	●	●	●	○	
2010	Ram (Mexico)	DMFL	○	●	●	●	●	●	●	
2010	Ram (Mexico)	ORC	○	●	●	●	●	○	●	02A1
2010	Ram (Mexico)	HSM	○	●	●	●	●	●	○	
2010	Ram (Mexico)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 008F 008E 003D 0214 0032 003F 0036 0037 0389 0038 002E 0387 038F 0388 0390 03A1 03A2
2010	Ram (Mexico)	AMP	○	●	●	●	●	○	●	006D 0068
2010	Ram (Mexico)	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2010	Ram (Mexico)	VES3	○	●	●	●	●	●	●	
2010	Ram (Mexico)	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2010	Ram (Mexico)	SDARV	○	●	●	●	●	○	○	
2010	Ram (Mexico)	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 0154 0155 0044 0411 0403 0401 03F4 0150 035B 0407 012D 0491 017B 04AF 03C7 03CB 0049 03C8 0379 04AE 0179 03C1 039A 03C6 03C3 03C4 03C9 03FF 03C2 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 026C 026D 040A 0128 027E 0490 0266 0265 0145 02FB 03B8 013C 012C 0410 0177 0386 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0304

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Ram (Mexico)	PTS	○	●	●	●	●	●	●	02ED 03B7
2010	Ram (Mexico)	WCM	○	●	●	●	●	●	●	02A7 0414 0233 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0300 0245 02FF 01DA
2010	Ram (Mexico)	ABS	○	●	●	●	●	●	●	03AB 0002
2010	Ram (Mexico)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2010	Wrangler (Export)	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2010	Wrangler (Export)	TCM	○	●	●	●	●	●	○	03AF 0499 049C 0392 03B0 0498 049B 0393 0394 03B1 0497 049A 0395 03B2 0496 03B3 0495 049D 0396 01FC 0177 0176 024E 01FB 016F 0175
2010	Wrangler (Export)	ORC	○	●	●	●	●	○	●	03CC 02A1 0122 03CD
2010	Wrangler (Export)	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2010	Wrangler (Export)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2010	Wrangler (Export)	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2010	Wrangler (Export)	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2010	Wrangler (Export)	PCM	○	●	●	●	●	●	○	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0044 0049 0144 02C0 02BB 031D 02C1 013B 02C2
2010	Wrangler (Export)	SAS	○	●	●	●	○	○	○	
2010	Wrangler (Export)	WCM	○	●	●	●	●	○	●	0233 01D2 03E4 0228 0232 0230 0231 022F 01DE 0227
2010	Journey	VES3	○	●	●	●	●	●	●	
2010	Journey	HVAC	○	●	●	●	●	●	●	00EA 00E9 00EC 02EA 02EB 03A9 03B9
2010	Journey	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0142 0310 0313 0312 03A3 0311 0144 03A4 02E7 013E 0141 012E 0314
2010	Journey	DMFR	○	●	●	●	●	●	○	
2010	Journey	TCM	○	●	●	●	●	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 04B0 0177 0170 0391 0175
2010	Journey	WCM	○	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0300 0245 0225 01DA 02FF
2010	Journey	DISP	○	●	●	●	●	○	○	
2010	Journey	ITM	○	●	●	●	●	●	●	03CF 0107 03CE
2010	Journey	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2010	Journey	SAS	○	●	●	●	○	○	○	
2010	Journey	ORC	○	●	●	●	●	○	●	03CC 02A1 0122
2010	Journey	CCN	○	●	●	●	○	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2010	Journey	DMFL	○	●	●	●	●	●	●	
2010	Journey	HFM	○	●	●	●	●	●	○	00E3
2010	Journey	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 02E3 021F 038F 0388 0390 03A1 03A2
2010	Journey	SDARV	○	●	●	●	●	○	○	
2010	Journey	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Journey	AWD	○	●	●	●	●	○	●	
2010	Journey	AMP	○	●	●	●	●	○	●	006D 0068
2010	Wrangler	TCM	○	●	●	●	●	●	○	03AF 0499 049C 0392 03B0 0498 049B 0393 0394 03B1 0497 049A 0395 03B2 0496 03B3 0495 049D 0396 01FC 0177 0176 024E 01FB 016F 0175
2010	Wrangler	ORC	○	●	●	●	●	○	●	03CC 02A1 0122 03CD
2010	Wrangler	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2010	Wrangler	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2010	Wrangler	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062 0485
2010	Wrangler	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 0227
2010	Wrangler	ITM	○	●	●	●	●	●	●	0385 0106
2010	Wrangler	ASBS	○	●	●	●	●	○	○	0317 0318 031A 031B 0319
2010	Wrangler	HFM	○	●	●	●	●	●	○	00E3
2010	Wrangler	AMP	○	●	●	●	●	○	●	006D 0068
2010	Wrangler	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 04B1 039F
2010	Wrangler	SAS	○	●	●	●	○	○	○	
2010	Wrangler	PCM	○	●	●	●	●	●	●	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0044 0049 0144 02C0 02BB 031D 02C1 013B 02C2 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 035B 02FB 013C 012C 0410 0177 0386 0173 012A 0281 0280 0176 024E 048C 0170 016F 012B 0175 0269 01FC 02F9 03B8 0304 02FA
2010	Sebring / 200 / Avenger	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0382 0094 0092 038D 0096 0383
2010	Sebring / 200 / Avenger	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2010	Sebring / 200 / Avenger	HFM	○	●	●	●	●	●	○	00E3
2010	Sebring / 200 / Avenger	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0142 0310 0313 03A3 0144 03A4 02E7 013E 0141 012E 0314
2010	Sebring / 200 / Avenger	ORC	○	●	●	●	●	○	●	03CC
2010	Sebring / 200 / Avenger	DDM	○	●	●	●	●	●	○	0306
2010	Sebring / 200 / Avenger	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2010	Sebring / 200 / Avenger	VES3	○	●	●	●	●	●	●	
2010	Sebring / 200 / Avenger	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2010	Sebring / 200 / Avenger	WCM	○	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 0227 023D 023E 0271 0270
2010	Sebring / 200 / Avenger	PTCM	○	●	●	●	●	○	●	0259 04A4
2010	Sebring / 200 / Avenger	AWD	○	●	●	●	●	○	●	
2010	Sebring / 200 / Avenger	AMP	○	●	●	●	●	○	●	006D 0068
2010	Sebring / 200 / Avenger	ITM	○	●	●	●	●	●	●	0385 0106 03CF 0107 03CE
2010	Sebring / 200 / Avenger	SAS	○	●	●	●	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Sebring / 200 / Avenger	TCM	○	●	●	●	●	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 04B0 0177 0170 0391 0175 03AF 0499 049C 0392 027B 03B0 0498 049B 0393 027C 0394 03B1 0497 049A 0395 027D 0291 03B2 02F8 0496 0290 03B3 0495 049D 0396 027E 01FC 0176 024E 01FB 016F
2010	Sebring / 200 / Avenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0214 0032 003F 0484 0036 02C3 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2010	Sebring / 200 / Avenger	PDM	○	●	●	●	●	●	○	0306
2010	Nitro	PTS	○	●	●	●	●	●	●	02ED 03B7
2010	Nitro	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2010	Nitro	SAS	○	●	●	●	○	○	○	
2010	Nitro	ITM	○	●	●	●	●	●	●	03CF 0107 03CE
2010	Nitro	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 02E2 038F 0388 0390 03A1 03A2
2010	Nitro	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 0227
2010	Nitro	AMP	○	●	●	●	●	○	●	006D 0068
2010	Nitro	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2010	Nitro	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2010	Nitro	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062 0485
2010	Nitro	ORC	○	●	●	●	●	○	●	03CC 03CD
2010	Nitro	DMFL	○	●	●	●	●	●	●	
2010	Nitro	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0049 0144 02C0 02BB 031D 02C1 02C2
2010	Nitro	HFM	○	●	●	●	●	●	○	00E3
2010	Nitro	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2010	Nitro	ESM	○	●	●	●	●	●	○	
2010	Nitro	DMFR	○	●	●	●	●	●	○	
2010	Nitro	OCM	○	●	●	●	●	○	○	011E
2010	Liberty	PTS	○	●	●	●	●	●	●	02ED 03B7
2010	Liberty	HFM	○	●	●	●	●	●	○	00E3
2010	Liberty	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2010	Liberty	OCM	○	●	●	●	●	○	○	011E
2010	Liberty	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2010	Liberty	ESM	○	●	●	●	●	●	○	
2010	Liberty	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2010	Liberty	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2010	Liberty	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2010	Liberty	DMFL	○	●	●	●	●	●	●	
2010	Liberty	FDCM	○	●	●	●	●	●	○	0340
2010	Liberty	ORC	○	●	●	●	●	○	●	03CC 03CD

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Liberty	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0049 0144 02C0 02BB 031D 02C1 02C2
2010	Liberty	SUNR	○	●	●	●	●	○	○	04A7
2010	Liberty	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 02E2 038F 0388 0390 03A1 03A2
2010	Liberty	AMP	○	●	●	●	●	○	●	006D 0068
2010	Liberty	WCM	○	●	●	●	●	○	●	0233 01D2 03E4 0228 0232 0230 0231 022F 01DE 0227
2010	Liberty	ITM	○	●	●	●	●	●	●	03CF 010A 0107 03CE
2010	Liberty	SAS	○	●	●	●	○	○	○	
2010	Liberty	DMFR	○	●	●	●	●	●	○	
2010	Liberty	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2010	Challenger	DDM	○	●	●	●	●	●	○	0306
2010	Challenger	CCN	○	●	●	●	●	●	●	008F 008E 0382 038D 0090 0383
2010	Challenger	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2010	Challenger	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2010	Challenger	HFM	○	●	●	●	●	●	○	00E3
2010	Challenger	ORC	○	●	●	●	○	●	○	02A1
2010	Challenger	PEM	○	●	●	●	●	○	●	0463 0307
2010	Challenger	ESM	○	●	●	●	●	●	○	
2010	Challenger	SUNR	○	●	●	●	●	●	○	
2010	Challenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0219 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A2
2010	Challenger	WCM	○	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0300 0245 02FF 01DA
2010	Challenger	HSM	○	●	●	●	●	●	●	
2010	Challenger	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0386 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2010	Challenger	SCM	○	●	●	●	○	●	●	
2010	Challenger	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2010	Challenger	AMP	○	●	●	●	●	○	●	006D 0068
2010	Challenger	PDM	○	●	●	●	●	●	○	0306
2010	Challenger	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2010	Challenger	EOM	○	●	●	●	●	○	●	00BC
2010	Challenger	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2010	300 / Magnum / Charger (Pre-2011)	HIDT	○	●	●	●	●	●	○	00E5

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	300 / Magnum / Charger (Pre-2011)	PCM	○	●	●	●	●	●	●	0042 0149 0142 0044 0145 012D 0045 0046 014B 0173 014A 0148 0049 014D 048A 0489 0146 0147 013B 048B 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 035B 02FB 03B8 013C 012C 0410 0177 0386 0304 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC
2010	300 / Magnum / Charger (Pre-2011)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0219 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A2
2010	300 / Magnum / Charger (Pre-2011)	PTIM	○	●	●	●	●	●	●	
2010	300 / Magnum / Charger (Pre-2011)	PDM	○	●	●	●	●	●	●	00AC
2010	300 / Magnum / Charger (Pre-2011)	ESM	○	●	●	●	●	●	○	
2010	300 / Magnum / Charger (Pre-2011)	SDARV	○	●	●	●	●	○	○	
2010	300 / Magnum / Charger (Pre-2011)	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2010	300 / Magnum / Charger (Pre-2011)	MSMD	○	●	●	●	●	○	○	02EE
2010	300 / Magnum / Charger (Pre-2011)	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2010	300 / Magnum / Charger (Pre-2011)	SCM	○	●	●	●	○	●	●	
2010	300 / Magnum / Charger (Pre-2011)	ORC	○	●	●	●	○	●	○	02A1
2010	300 / Magnum / Charger (Pre-2011)	ACC	○	●	●	●	●	○	●	0064 0321 04A5 0065 02CE
2010	300 / Magnum / Charger (Pre-2011)	LRSM	○	●	●	●	●	○	○	010D
2010	300 / Magnum / Charger (Pre-2011)	AHBM	○	●	●	●	●	○	○	03C0 00BC
2010	300 / Magnum / Charger (Pre-2011)	PTS	○	●	●	●	●	●	●	02ED 03B7
2010	300 / Magnum / Charger (Pre-2011)	HVAC	○	●	●	●	●	●	●	00EA 00E9 02EA 02EB
2010	300 / Magnum / Charger (Pre-2011)	AMP	○	●	●	●	●	○	●	006D 0068
2010	300 / Magnum / Charger (Pre-2011)	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2010	300 / Magnum / Charger (Pre-2011)	DTCM	○	●	●	●	●	●	○	
2010	300 / Magnum / Charger (Pre-2011)	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2010	300 / Magnum / Charger (Pre-2011)	TCM	○	●	●	●	●	○	○	038C 01F3 01F2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	300 / Magnum / Charger (Pre-2011)	HFM	○	●	●	●	●	●	○	00E3
2010	300 / Magnum / Charger (Pre-2011)	WCM	○	●	●	●	●	●	●	02A7 0414 0233 01D2 0228 03E6 0225 0232 0230 0231 022F 0300 01DA 0245 022E 03E4 01DE 02FF
2010	300 / Magnum / Charger (Pre-2011)	CCN	○	●	●	●	●	●	●	008F 008E 0382 038D 0090 0383
2010	300 / Magnum / Charger (Pre-2011)	SUNR	○	●	●	●	●	●	○	
2010	300 / Magnum / Charger (Pre-2011)	EOM	○	●	●	●	●	○	●	00BC
2010	300 / Magnum / Charger (Pre-2011)	HSM	○	●	●	●	●	●	●	
2010	300 / Magnum / Charger (Pre-2011)	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2010	300 / Magnum / Charger (Pre-2011)	DDM	○	●	●	●	●	●	●	
2010	300 / Magnum / Charger (Pre-2011)	VES3	○	●	●	●	●	●	●	
2010	Compass	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2010	Compass	SAS	○	●	●	●	○	○	○	
2010	Compass	HFM	○	●	●	●	●	●	○	00E3
2010	Compass	WCM	○	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 0232 0230 0231 022F 0227 02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0032 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2010	Compass	TIPMCGW	○	●	●	●	●	●	●	
2010	Compass	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2010	Compass	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2010	Compass	AMP	○	●	●	●	●	○	●	0069 006D 0079 0068 0303
2010	Compass	PCM	○	●	●	●	●	●	●	03E0 0149 03D0 04B2 03DD 03E3 03E2 03DE 03E1 012D 03D3 03DF 03D9 03DA 0049 03DB 03D4 03DC 03D2 03D6 03D8 057C 03D5 02E7 0140 013E 0126 0141 0044 0411 0128 03F4 012E 0314 012C 0386 0173 012A 012B 013B
2010	Compass	TCM	○	●	●	●	●	●	●	0380
2010	Compass	RADIO	○	●	●	●	●	●	○	039E 01BB 025D 039F
2010	Compass	ORC	○	●	●	●	●	○	●	03CC 03CD
2010	Compass	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0382 0094 0092 038D 0096 0383
2010	Compass	AWD	○	●	●	●	●	●	●	
2010	Dakota	HFM	○	●	●	●	●	●	○	00E3
2010	Dakota	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB
2010	Dakota	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0381 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B
2010	Dakota	ORC	○	●	●	●	○	●	○	02A1
2010	Dakota	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2010	Dakota	AMP	○	●	●	●	●	○	●	006D 0068

[illegible]

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Caliber	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2010	PT Cruiser	ITM	○	●	●	●	●	●	●	03CF 010A 0107 0106 03CE 0385
2010	PT Cruiser	HFM	○	●	●	●	●	●	○	00E3
2010	PT Cruiser	ABS	○	●	●	●	●	●	●	03AB 0002 005E 0060 005B
2010	PT Cruiser	DDM	○	●	●	●	●	●	○	
2010	PT Cruiser	CCN	○	●	●	●	●	●	●	008C 008F 008E 0094 0092 0096
2010	PT Cruiser	PDM	○	●	●	●	○	●	○	
2010	PT Cruiser	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 0227 023D 023E 0271 0270
2010	PT Cruiser	OCM	○	●	●	●	●	○	○	011E
2010	PT Cruiser	PCM	○	●	●	●	●	●	●	0127 0126 0044 0411 0129 026C 026D 040A 0128 03F4 012E 012F 013C 012C 012D 0386 0173 012A 0482 012B 013B 0042 0149 0142 0145 0148 0049 048B
2010	PT Cruiser	TCM	○	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 04B0 0177 0170 0391 0175
2010	PT Cruiser	RADIO	○	●	●	●	●	○	●	
2010	PT Cruiser	TIPMCGW	○	●	●	●	●	●	●	02DC 030E 030C 0483 003D 0032 003F 0484 0036 0037 0389 0034 0038 002E 020E 0215 028F 028E 0211 0388
2010	PT Cruiser	ORC	○	●	●	●	●	○	●	
2010	PT Cruiser	AMP	○	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0069 0073
2010	PT Cruiser	SDAR	○	●	●	●	●	○	○	
2010	Mini-Van	HFM	○	●	●	●	○	●	○	
2010	Mini-Van	DSD	○	●	●	●	○	●	○	
2010	Mini-Van	SKREEM	○	●	●	●	●	○	○	8003 8004 8005 8006 8007 01D2 04A2 8008 8009 800A 800B 800C 01DE 800E 01DA
2010	Mini-Van	PTS	○	●	●	●	●	●	○	
2010	Mini-Van	OCM	○	●	●	●	○	○	○	011E 802A 802B 8023 8024
2010	Mini-Van	SDAR	○	●	●	●	●	●	○	
2010	Mini-Van	MIC/CCN	○	●	●	●	○	●	○	
2010	Mini-Van	PCM	○	●	●	●	○	●	○	
2010	Mini-Van	BCM	○	●	●	●	○	●	○	
2010	Mini-Van	TCM	○	●	●	●	●	●	●	
2010	Mini-Van	IPM	○	●	●	●	○	●	○	
2010	Mini-Van	MHSM	○	●	●	●	○	●	○	
2010	Mini-Van	EOM	○	●	●	○	○	○	○	
2010	Mini-Van	MTC	○	●	●	●	○	●	○	
2010	Mini-Van	PSD	○	●	●	●	○	●	○	
2010	Mini-Van	ORC	○	●	●	●	○	○	○	
2010	Mini-Van	ABS	○	●	●	●	●	○	○	
2010	Mini-Van	PLGM	○	●	●	●	●	●	●	
2010	Mini-Van	ATC	○	●	●	●	○	●	○	
2010	Routan	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2010	Routan	PSDMR	○	●	●	●	●	○	●	0343 0461 04A9 0460 0342
2010	Routan	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2010	Routan	DVD	○	●	●	●	●	○	○	

[illegible]

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Grand Cherokee	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0381 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0149 0142 0045 0046 014B 014A 0148 0049 014D 048A 0489 0146 0147 048B
2010	Grand Cherokee	HFM	○	●	●	●	●	●	○	00E3
2010	Grand Cherokee	TM	○	●	●	○	○	○	○	
2010	Grand Cherokee	HSM	○	●	●	●	●	●	●	
2010	Grand Cherokee	WCM	○	●	●	●	●	●	●	02A7 0414 0233 01D2 0228 03E6 0225 0232 0230 0231 022F 01DE 0300 01DA 0245 022E 03E4 02FF
2010	Grand Cherokee	FDCM	○	●	●	●	●	●	●	
2010	Grand Cherokee	VES3	○	●	●	●	●	●	●	
2010	Grand Cherokee	AMP	○	●	●	●	●	○	●	006D 0068
2010	Commander	LRSM	○	●	●	●	●	○	○	010D
2010	Commander	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2010	Commander	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2010	Commander	AHBM	○	●	●	●	●	○	○	03C0 00BC
2010	Commander	ESM	○	●	●	●	●	●	○	
2010	Commander	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2010	Commander	TM	○	●	●	○	○	○	○	
2010	Commander	CCN	○	●	●	●	●	●	●	0097 008C 00BC 008F 008E 0382 0091 0094 0099 0098 0090 0383
2010	Commander	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 002E 049E 0293 0033 0388 04A6 04A0 00C6 0040 022D 00DA 0272 0273
2010	Commander	SUNR	○	●	●	●	●	●	○	
2010	Commander	PDM	○	●	●	●	●	●	●	00AC 0306
2010	Commander	PCM	○	●	●	●	●	●	●	027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0127 0140 0126 02F9 0044 0411 026C 026D 040A 0128 027E 0490 0266 0265 03F4 0145 035B 02FB 03B8 013C 012C 012D 0410 0177 0381 0304 0173 012A 0281 0280 02FA 0176 024E 048C 0170 016F 012B 0175 0269 01FC 013B 0042 0149 0142 0045 0046 014B 014A 0148 0049 014D 048A 0489 0146 0147 048B
2010	Commander	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2010	Commander	FDCM	○	●	●	●	●	●	●	
2010	Commander	SDARV	○	●	●	●	●	○	○	
2010	Commander	PLGM	○	●	●	●	●	●	●	038A 038B
2010	Commander	HVAC	○	●	●	●	●	●	●	00EA 00E9 02EA 02EB
2010	Commander	AMP	○	●	●	●	●	○	●	006D 0068
2010	Commander	WCM	○	●	●	●	●	●	●	02A7 0414 0233 0228 02FF 03E6 0232 0230 0231 022F 01DE 0245 01D2 0225 0300 01DA 022E 03E4
2010	Commander	ORC	○	●	●	●	○	●	○	02A1 0122
2010	Commander	VES3	○	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Commander	DDM	○	●	●	●	●	●	●	0306 00AC
2010	Commander	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 0116 0117 0115 0119
2010	Commander	PTS	○	●	●	●	●	●	●	02ED 03B7
2010	Commander	SAS	○	●	●	●	○	○	○	
2010	Commander	HSM	○	●	●	●	●	●	●	
2010	Commander	AHLM	○	●	●	●	●	●	○	029F
2010	Commander	HFM	○	●	●	●	●	●	○	00E3
2010	Viper (Pre-2011)	PCM	○	●	●	●	●	●	○	013E 0126 0141 0044 0411 0325 04AA 0193 04AC 0128 03F4 0145 04AB 0326 012C 012D 012A 0081 012B
2010	Viper (Pre-2011)	OCM	○	●	●	●	●	○	○	02AD 011E
2010	Viper (Pre-2011)	HVAC	○	●	●	●	○	●	○	
2010	Viper (Pre-2011)	MIC/CCN	○	●	●	●	●	○	○	801A
2010	Viper (Pre-2011)	RADIO	○	●	●	○	○	●	○	
2010	Viper (Pre-2011)	PCI to CAN Gateway	○	●	●	●	○	○	○	
2010	Viper (Pre-2011)	BCM	○	●	●	●	○	●	○	
2010	Viper (Pre-2011)	SDAR	○	●	●	●	●	●	○	
2010	Viper (Pre-2011)	ABS	○	●	●	●	○	●	○	
2010	Viper (Pre-2011)	ORC	○	●	●	●	●	●	●	
2011	Ram 3500 Pickup	DMFR	○	●	●	●	●	●	●	
2011	Ram 3500 Pickup	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 03C7 0154 0155 0044 0411 0403 0401 03FF 03F4 0150 012D 0491 04AF 03CB 0049 03C8 0379 04AE 0179 03C1 035B 039A 03C2 03C4 03C9
2011	Ram 3500 Pickup	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F
2011	Ram 3500 Pickup	DTCM	○	●	●	●	●	●	○	
2011	Ram 3500 Pickup	VES3	○	●	●	●	●	●	●	
2011	Ram 3500 Pickup	ABS	○	●	●	●	●	●	●	03AB 0002
2011	Ram 3500 Pickup	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Ram 3500 Pickup	DMFL	○	●	●	●	●	●	●	
2011	Ram 3500 Pickup	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2011	Ram 3500 Pickup	AMP	○	●	●	●	●	○	●	006D 0068
2011	Ram 3500 Pickup	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2011	Ram 3500 Pickup	ORC	○	●	●	●	●	○	●	02A1
2011	Ram 3500 Pickup	HSM	○	●	●	●	●	●	●	0412
2011	Ram 3500 Pickup	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	Ram 3500 Pickup	SDARV	○	●	●	●	●	○	○	
2011	Ram 3500 Pickup	SAS	○	●	●	●	○	○	○	
2011	Ram 3500 Pickup	HFM	○	●	●	●	●	●	○	00E3
2011	Ram 3500 Pickup	ITBM	○	●	●	●	○	○	○	
2011	Ram 3500 Pickup	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0214 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 022D 03A2
2011	Ram 3500 Pickup	WCM	○	●	●	●	●	●	●	02A7 01D2 0228 03E6 0300 0245 0414 03E4 0232 0230 0231 022F
2011	Ram 3500 Cab Chassis	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2011	Ram 3500 Cab Chassis	DTCM	○	●	●	●	●	●	○	
2011	Ram 3500 Cab Chassis	DMFL	○	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Ram 3500 Cab Chassis	SAS	○	●	●	●	○	○	○	
2011	Ram 3500 Cab Chassis	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 03ED 03E8 03E9 03EA 03EB 03EC 03C7 0154 0155 0044 0150 0491 017B 04AF 03CB 0049 03C8 0179 03C1 03EF 039A 03EE 03C4
2011	Ram 3500 Cab Chassis	ORC	○	●	●	●	●	○	●	02A1
2011	Ram 3500 Cab Chassis	ABS	○	●	●	●	●	●	●	03AB 0002
2011	Ram 3500 Cab Chassis	DMFR	○	●	●	●	●	●	●	
2011	Ram 3500 Cab Chassis	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2011	Ram 3500 Cab Chassis	ITBM	○	●	●	●	○	○	○	
2011	Ram 3500 Cab Chassis	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Ram 3500 Cab Chassis	HFM	○	●	●	●	●	●	○	00E3
2011	Ram 3500 Cab Chassis	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 008F 008E 003D 0214 0032 003F 0036 0037 0389 0038 002E 0387 038F 0388 0390 03A1 03A2
2011	Ram 3500 Cab Chassis	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2011	Ram 3500 Cab Chassis	HSM	○	●	●	●	●	●	●	0412
2011	Ram 3500 Cab Chassis	TCM	○	●	●	●	○	●	○	01F6 0391
2011	Ram 3500 Cab Chassis	AMP	○	●	●	●	●	○	●	006D 0068
2011	Ram 3500 Cab Chassis	DCU	○	○	○	○	○	○	○	
2011	Ram 3500 Cab Chassis	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2011	Ram 2500	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Ram 2500	SAS	○	●	●	●	○	○	○	
2011	Ram 2500	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2011	Ram 2500	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2011	Ram 2500	DTCM	○	●	●	●	●	●	○	
2011	Ram 2500	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2011	Ram 2500	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2011	Ram 2500	HSM	○	●	●	●	●	●	●	0412
2011	Ram 2500	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2011	Ram 2500	FDCM	○	●	●	●	●	○	○	02B5 02B3 02B2 02B1 02AF 02B0
2011	Ram 2500	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 022D 03A2
2011	Ram 2500	ABS	○	●	●	●	●	●	●	03AB 0002
2011	Ram 2500	ORC	○	●	●	●	●	○	●	02A1

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Ram 2500	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 03C7 0154 0155 0044 0150 0491 04AF 03CB 0049 03C8 0379 04AE 0179 03C1 035B 039A 03C2 03C4 03C9
2011	Ram 2500	AMP	○	●	●	●	●	○	●	006D 0068
2011	Ram 2500	DMFR	○	●	●	●	●	●	●	
2011	Ram 2500	HFM	○	●	●	●	●	●	○	00E3
2011	Ram 2500	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	Ram 2500	ITBM	○	●	●	●	○	○	○	
2011	Ram 2500	SDARV	○	●	●	●	●	○	○	
2011	Ram 2500	DMFL	○	●	●	●	●	●	●	
2011	Ram 2500	VES3	○	●	●	●	●	●	●	
2011	Ram 4500/5500	ORC	○	●	●	●	●	○	●	02A1
2011	Ram 4500/5500	HFM	○	●	●	●	●	●	○	00E3
2011	Ram 4500/5500	HSM	○	●	●	●	●	●	●	0412
2011	Ram 4500/5500	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2011	Ram 4500/5500	DMFR	○	●	●	●	●	●	●	
2011	Ram 4500/5500	AMP	○	●	●	●	●	○	●	006D 0068
2011	Ram 4500/5500	DTCM	○	●	●	●	●	●	○	
2011	Ram 4500/5500	ABS	○	●	●	●	●	●	●	03AB 0002
2011	Ram 4500/5500	DCU	○	○	○	○	○	○	○	
2011	Ram 4500/5500	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2011	Ram 4500/5500	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2011	Ram 4500/5500	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Ram 4500/5500	DMFL	○	●	●	●	●	●	●	
2011	Ram 4500/5500	PCM	○	●	●	●	●	●	●	03ED 03E8 03E9 03EA 03EB 03EC 03C7 0154 0155 0044 0411 03F4 0150 012D 0491 017B 04AF 03CB 0049 03C8 0179 03C1 03EF 039A 03EE 03C4
2011	Ram 4500/5500	TCM	○	●	●	●	○	●	○	01F6 0391
2011	Ram 4500/5500	SAS	○	●	●	●	○	○	○	
2011	Ram 4500/5500	ITBM	○	●	●	●	○	○	○	
2011	Ram 4500/5500	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 008F 008E 003D 0214 0032 003F 0036 0037 0389 0038 002E 0387 038F 0388 0390 03A1 03A2
2011	Ram 4500/5500	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F
2011	Ram 1500	DTCM	○	●	●	●	●	●	●	
2011	Ram 1500	EAC	○	●	●	●	●	○	○	
2011	Ram 1500	DMFL	○	●	●	●	●	●	●	
2011	Ram 1500	HVAC	○	●	●	●	●	●	●	00EC 02EA 02EB 00EA 00E9 03A9 03B9
2011	Ram 1500	EPS	○	●	●	●	●	○	○	
2011	Ram 1500	HFM	○	●	●	●	●	●	○	00E3
2011	Ram 1500	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	Ram 1500	VES3	○	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Ram 1500	HCP	○	●	●	●	●	○	○	041E 0420 035B 041F 036A 0368
2011	Ram 1500	HGM	○	●	●	●	●	●	●	
2011	Ram 1500	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2011	Ram 1500	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2011	Ram 1500	TCM	○	●	●	●	●	○	○	035B 0416 0415 0417
2011	Ram 1500	AMP	○	●	●	●	●	○	●	006D 0068
2011	Ram 1500	APM	○	○	○	○	○	○	○	0422
2011	Ram 1500	DMFR	○	●	●	●	●	●	●	
2011	Ram 1500	MCPB	○	○	○	●	○	○	○	034C
2011	Ram 1500	BPCM	○	●	●	●	●	●	○	041C 034E
2011	Ram 1500	PHGM	○	●	●	●	○	●	○	
2011	Ram 1500	ORC	○	●	●	●	●	○	●	02A1
2011	Ram 1500	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A1 03A2 03E7 0476 0387
2011	Ram 1500	SAS	○	●	●	●	○	○	○	
2011	Ram 1500	OBCM	○	●	●	●	●	●	○	
2011	Ram 1500	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Ram 1500	ABS	○	●	●	●	●	●	●	04AD 0002 03BB 03AB
2011	Ram 1500	DRM	○	●	●	●	●	○	○	
2011	Ram 1500	ITBM	○	●	●	●	○	○	○	
2011	Ram 1500	HSM	○	●	●	●	●	●	●	0412
2011	Ram 1500	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2011	Ram 1500	SDARV	○	●	●	●	●	○	○	
2011	Ram 1500	MCPA	○	○	○	●	○	○	○	034C
2011	Ram 1500	BTM	○	●	●	●	●	●	○	
2011	Ram 1500	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 027B 048D 025F 025E 0260 027C 048E 0262 0261 027D 048F 0264 0263 02F8 0044 026C 026D 027E 0490 0266 0265 0421 0145 035B 02FB 0177 0304 0173 0281 0280 0176 024E 048C 0170 016F 0175 0269 01FC 013B
2011	Ram 1500	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 0228 03E6 0232 0230 0231 022F 0300 0245 03E4
2011	Ram (Mexico)	ITBM	○	●	●	●	○	○	○	
2011	Ram (Mexico)	HSM	○	●	●	●	●	●	●	0412
2011	Ram (Mexico)	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F
2011	Ram (Mexico)	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2011	Ram (Mexico)	DMFR	○	●	●	●	●	●	●	
2011	Ram (Mexico)	VES3	○	●	●	●	●	●	●	
2011	Ram (Mexico)	SAS	○	●	●	●	○	○	○	
2011	Ram (Mexico)	ABS	○	●	●	●	●	●	●	03AB 0002
2011	Ram (Mexico)	ORC	○	●	●	●	●	○	●	02A1
2011	Ram (Mexico)	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	Ram (Mexico)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Ram (Mexico)	DTCM	○	●	●	●	●	●	○	
2011	Ram (Mexico)	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2011	Ram (Mexico)	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2011	Ram (Mexico)	SDARV	○	●	●	●	●	○	○	
2011	Ram (Mexico)	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Ram (Mexico)	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 03ED 03E8 03E9 03EA 03EB 03EC 03C7 0154 0155 0044 0411 0403 0401 03FF 03F4 0150 012D 0491 017B 04AF 03CB 0049 03C8 04AE 0179 03C1 03EF 035B 039A 03EE 03C2 03C3 03C4 03C9 042A 03F8 03F6 03F9 03F7 03FA 042B 0127 03F3 0140 0126 0404 0402 040A 0400 0128 042C 03FB 0406 0407 040C 040E 040F 03B8 013C 012C 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2011	Ram (Mexico)	AMP	○	●	●	●	●	○	●	006D 0068
2011	Ram (Mexico)	HFM	○	●	●	●	●	●	○	00E3
2011	Ram (Mexico)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 03A2
2011	Ram (Mexico)	DMFL	○	●	●	●	●	●	●	
2011	Wrangler (Export)	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2011	Wrangler (Export)	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2011	Wrangler (Export)	RADIO	○	●	●	●	●	●	○	039E 039F 01BB 025D
2011	Wrangler (Export)	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2011	Wrangler (Export)	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2011	Wrangler (Export)	ORC	○	●	●	●	●	○	●	03CC 02A1 0122 03CD
2011	Wrangler (Export)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2011	Wrangler (Export)	PCM	○	●	●	●	●	●	●	0042 012D 02BA 02BD 0428 0424 0049 0423 0427 03D2 0425 031D 0447 013B
2011	Wrangler (Export)	WCM	○	●	●	●	●	○	●	0233 01D2 03E4 0228 0232 0230 0231 022F 01DE 0227
2011	Wrangler (Export)	SAS	○	●	●	●	○	○	○	
2011	Journey	RFH	○	●	●	●	●	●	●	0443 0440 0442 0441 0444 043F 0445
2011	Journey	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2011	Journey	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2011	Journey	HFM	○	●	●	●	●	○	○	00E3
2011	Journey	ICS	○	●	●	●	●	●	○	
2011	Journey	ORC	○	●	●	●	●	○	●	02A1 0122
2011	Journey	DDM	○	●	●	●	●	●	●	
2011	Journey	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	Journey	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2011	Journey	IPC	○	●	●	●	●	●	○	04B3
2011	Journey	DTCM	○	●	●	●	●	●	●	
2011	Journey	TGW	○	●	●	●	●	○	●	0305 025D 0446
2011	Journey	PDM	○	●	●	●	●	●	●	
2011	Journey	SCCM	○	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Journey	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0429 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 0431 0042 0430 0049 042F 03D2 042E 0432 042D 031D 03D8
2011	Journey	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2011	Journey	HSM	○	●	●	●	●	●	●	
2011	Journey	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2011	Journey	VES3	○	●	●	●	●	●	○	
2011	Journey	AMP	○	●	●	●	●	○	○	006D 0068
2011	Freemont	VES3	○	●	●	●	●	●	○	
2011	Freemont	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0429 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 0431 0042 0430 0049 042F 03D2 042E 0432 042D 031D 03D8
2011	Freemont	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2011	Freemont	DDM	○	●	●	●	●	●	●	
2011	Freemont	TGW	○	●	●	●	●	○	●	0305 025D 0446
2011	Freemont	AMP	○	●	●	●	●	○	○	006D 0068
2011	Freemont	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2011	Freemont	HFM	○	●	●	●	●	○	○	00E3
2011	Freemont	SCCM	○	●	●	●	●	○	○	
2011	Freemont	IPC	○	●	●	●	●	●	○	04B3
2011	Freemont	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2011	Freemont	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2011	Freemont	ICS	○	●	●	●	●	●	○	
2011	Freemont	ORC	○	●	●	●	●	○	●	02A1 0122
2011	Freemont	DTCM	○	●	●	●	●	●	●	
2011	Freemont	PDM	○	●	●	●	●	●	●	
2011	Freemont	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	Freemont	RFH	○	●	●	●	●	●	●	0443 0440 0442 0441 0444 043F 0445
2011	Freemont	HSM	○	●	●	●	●	●	●	
2011	Freemont	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2011	Wrangler	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2011	Wrangler	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2011	Wrangler	ASBS	○	●	●	●	●	○	○	0317 0318 031A 031B 0319
2011	Wrangler	AMP	○	●	●	●	●	○	●	006D 0068
2011	Wrangler	HFM	○	●	●	●	●	●	○	00E3
2011	Wrangler	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2011	Wrangler	SAS	○	●	●	●	○	○	○	
2011	Wrangler	ORC	○	●	●	●	●	○	●	03CC 02A1 0122 03CD

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Wrangler	ESM	○	●	●	●	●	●	○	
2011	Wrangler	PCM	○	●	●	●	●	●	●	0042 012D 02BA 02BD 0428 0424 0049 0423 0427 03D2 0425 031D 0447 013B 042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2011	Wrangler	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D 04B1
2011	Wrangler	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2011	Wrangler	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2011	Wrangler	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 0227
2011	Wrangler	ITM	○	●	●	●	●	●	●	0437 03CF 0449 0436 0385
2011	Sebring / 200 / Avenger	HFM	○	●	●	●	●	●	○	00E3
2011	Sebring / 200 / Avenger	TCM	○	●	●	●	○	●	●	044D 044E 044A 044C 01EF 044B 0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 04B0 0177 0170 0391 0175
2011	Sebring / 200 / Avenger	VES3	○	●	●	●	●	●	●	
2011	Sebring / 200 / Avenger	AMP	○	●	●	●	●	○	●	006D 0068
2011	Sebring / 200 / Avenger	ORC	○	●	●	●	●	○	●	03CC
2011	Sebring / 200 / Avenger	SAS	○	●	●	●	○	○	○	
2011	Sebring / 200 / Avenger	DDM	○	●	●	●	●	●	○	0306
2011	Sebring / 200 / Avenger	CCN	○	●	●	●	●	●	●	00BC 008F 008E 0382 038D 0090 0383
2011	Sebring / 200 / Avenger	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2011	Sebring / 200 / Avenger	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2011	Sebring / 200 / Avenger	ESM	○	●	●	●	○	●	●	
2011	Sebring / 200 / Avenger	ITM	○	●	●	●	●	●	●	0385 0106 03CF 0107 03CE
2011	Sebring / 200 / Avenger	WCM	○	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 0232 0230 0231 022F 0227
2011	Sebring / 200 / Avenger	ABS	○	●	●	●	●	●	●	03AB 0002
2011	Sebring / 200 / Avenger	PTCM	○	●	●	●	●	○	●	0259 04A4
2011	Sebring / 200 / Avenger	AWD	○	●	●	●	●	○	●	
2011	Sebring / 200 / Avenger	PDM	○	●	●	●	●	●	○	0306
2011	Sebring / 200 / Avenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0214 03E7 0484 0036 02C3 0037 0389 0034 0038 003A 002E 038F 0388 0390 03A2
2011	Sebring / 200 / Avenger	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2011	Nitro	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2011	Nitro	DMFR	○	●	●	●	●	●	○	
2011	Nitro	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2011	Nitro	HFM	○	●	●	●	●	●	○	00E3
2011	Nitro	ESM	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Nitro	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2011	Nitro	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 0227
2011	Nitro	OCM	○	●	●	●	●	○	○	011E
2011	Nitro	SAS	○	●	●	●	○	○	○	
2011	Nitro	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2011	Nitro	DMFL	○	●	●	●	●	●	●	
2011	Nitro	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	Nitro	AMP	○	●	●	●	●	○	●	006D 0068
2011	Nitro	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2011	Nitro	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 02E2 038F 0388 0390 03A1 03A2
2011	Nitro	ITM	○	●	●	●	●	●	●	03CF 0107 03CE
2011	Nitro	ORC	○	●	●	●	●	○	●	03CC 03CD
2011	Nitro	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F
2011	Liberty	AMP	○	●	●	●	●	○	●	006D 0068
2011	Liberty	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F
2011	Liberty	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2011	Liberty	CCN	○	●	●	●	●	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2011	Liberty	FDCM	○	●	●	●	●	●	○	0340
2011	Liberty	MSMD	○	●	●	●	●	●	●	02EE 00BC 0114 044F 0116 0117 0115 0119 0455 0451 0450 0454 0452 0453
2011	Liberty	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 0042 02BA 02BD 0428 0424 0049 0423 0427 03D2 0425 031D 013B
2011	Liberty	ORC	○	●	●	●	●	○	●	03CC 03CD
2011	Liberty	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2011	Liberty	ESM	○	●	●	●	●	●	○	
2011	Liberty	DMFR	○	●	●	●	●	●	○	
2011	Liberty	DMFL	○	●	●	●	●	●	●	
2011	Liberty	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	Liberty	OCM	○	●	●	●	●	○	○	011E
2011	Liberty	WCM	○	●	●	●	●	○	●	0233 01D2 03E4 0228 0232 0230 0231 022F 01DE 0227
2011	Liberty	HFM	○	●	●	●	●	●	○	00E3
2011	Liberty	ITM	○	●	●	●	●	●	●	03CF 010A 0107 03CE
2011	Liberty	SAS	○	●	●	●	○	○	○	
2011	Liberty	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 02E2 038F 0388 0390 03A1 03A2
2011	Liberty	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2011	Liberty	SUNR	○	●	●	●	●	○	○	04A7
2011	Challenger	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2011	Challenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0219 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Challenger	EPS	○	●	●	●	●	○	○	
2011	Challenger	AMP	○	●	●	●	●	○	●	006D 0068
2011	Challenger	HSM	○	●	●	●	●	●	●	
2011	Challenger	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2011	Challenger	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2011	Challenger	SAS	○	●	●	●	●	●	○	
2011	Challenger	ORC	○	●	●	●	●	○	●	02A1
2011	Challenger	HFM	○	●	●	●	●	●	○	00E3
2011	Challenger	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2011	Challenger	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2011	Challenger	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2011	Challenger	ABS	○	●	●	●	●	●	●	0433 03AB
2011	Challenger	DDM	○	●	●	●	●	●	○	0306
2011	Challenger	EOM	○	●	●	●	●	○	●	00BA 00BC
2011	Challenger	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 0228 03E6 0232 0230 0231 022F 0300 0245 03E4
2011	Challenger	PDM	○	●	●	●	●	●	○	0306
2011	Challenger	CCN	○	●	●	●	●	●	●	008F 008E 0382 038D 0090 0383
2011	Challenger	SUNR	○	●	●	●	●	●	○	
2011	Challenger	ESM	○	●	●	●	●	●	○	
2011	Charger (Post-2011)	TPM	○	●	●	●	●	○	●	0435 0458 0232 0230 0231 022F 0459
2011	Charger (Post-2011)	RFH	○	●	●	●	●	●	●	0443 0440 0442 04B4 0441 0444 043F 0445
2011	Charger (Post-2011)	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	Charger (Post-2011)	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2011	Charger (Post-2011)	SCCM	○	●	●	●	●	○	○	
2011	Charger (Post-2011)	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2011	Charger (Post-2011)	DTCM	○	●	●	●	●	●	○	
2011	Charger (Post-2011)	AMP	○	●	●	●	●	○	○	006D 0068
2011	Charger (Post-2011)	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2011	Charger (Post-2011)	BSM	○	●	●	●	●	○	○	0372
2011	Charger (Post-2011)	TCM	○	●	●	●	●	○	●	038C 01F3 01F2
2011	Charger (Post-2011)	IPC	○	●	●	●	●	●	○	04B3 0456
2011	Charger (Post-2011)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2011	Charger (Post-2011)	ACC	○	●	●	●	●	○	●	
2011	Charger (Post-2011)	VSIM	○	●	●	●	●	●	●	
2011	Charger (Post-2011)	ESM	○	●	●	●	●	●	○	
2011	Charger (Post-2011)	ORC	○	●	●	●	●	○	●	02A1
2011	Charger (Post-2011)	DDM	○	●	●	●	●	●	●	
2011	Charger (Post-2011)	HSM	○	●	●	●	●	●	●	
2011	Charger (Post-2011)	PDM	○	●	●	●	●	●	●	
2011	Charger (Post-2011)	EPS	○	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Charger (Post-2011)	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0429 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2011	Charger (Post-2011)	ICS	○	●	●	●	●	●	○	
2011	Charger (Post-2011)	TGW	○	●	●	●	●	○	●	0305 025D 0446
2011	Charger (Post-2011)	HFM	○	●	●	●	●	○	○	00E3
2011	300 / Magnum / Charger (Pre-2011)	EPS	○	●	●	●	●	○	○	
2011	300 / Magnum / Charger (Pre-2011)	HSM	○	●	●	●	●	●	●	
2011	300 / Magnum / Charger (Pre-2011)	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	300 / Magnum / Charger (Pre-2011)	TPM	○	●	●	●	●	○	●	0435 0458 0232 0230 0231 022F 0459
2011	300 / Magnum / Charger (Pre-2011)	AFLS	○	●	●	●	●	●	○	045B
2011	300 / Magnum / Charger (Pre-2011)	TCM	○	●	●	●	●	○	●	038C 01F3 01F2
2011	300 / Magnum / Charger (Pre-2011)	ICS	○	●	●	●	●	●	○	
2011	300 / Magnum / Charger (Pre-2011)	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0429 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 0431 0042 0430 02BD 0049 042F 03D2 042E 0432 042D 031D 03D8
2011	300 / Magnum / Charger (Pre-2011)	SCCM	○	●	●	●	●	○	○	
2011	300 / Magnum / Charger (Pre-2011)	ACC	○	●	●	●	●	○	●	
2011	300 / Magnum / Charger (Pre-2011)	AMP	○	●	●	●	●	○	○	006D 0068
2011	300 / Magnum / Charger (Pre-2011)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2011	300 / Magnum / Charger (Pre-2011)	HFM	○	●	●	●	●	○	○	00E3
2011	300 / Magnum / Charger (Pre-2011)	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2011	300 / Magnum / Charger (Pre-2011)	ESM	○	●	●	●	●	●	○	
2011	300 / Magnum / Charger (Pre-2011)	TGW	○	●	●	●	●	○	●	0305 025D 0446
2011	300 / Magnum / Charger (Pre-2011)	BSM	○	●	●	●	●	○	○	0372

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	300 / Magnum / Charger (Pre-2011)	ORC	○	●	●	●	●	○	●	02A1
2011	300 / Magnum / Charger (Pre-2011)	DTCM	○	●	●	●	●	●	○	
2011	300 / Magnum / Charger (Pre-2011)	DDM	○	●	●	●	●	●	●	
2011	300 / Magnum / Charger (Pre-2011)	PDM	○	●	●	●	●	●	●	
2011	300 / Magnum / Charger (Pre-2011)	RFH	○	●	●	●	●	●	●	0443 0440 0442 04B4 0441 0444 043F 0445
2011	300 / Magnum / Charger (Pre-2011)	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2011	300 / Magnum / Charger (Pre-2011)	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2011	300 / Magnum / Charger (Pre-2011)	IPC	○	●	●	●	●	●	○	04B3 0456
2011	Compass	AWD	○	●	●	●	●	●	●	
2011	Compass	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2011	Compass	WCM	○	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 0232 0230 0231 022F 0227
2011	Compass	ORC	○	●	●	●	●	○	●	03CC 03CD
2011	Compass	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2011	Compass	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2011	Compass	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2011	Compass	CCN	○	●	●	●	●	●	●	00BC 008F 008E 0382 038D 0090 0383
2011	Compass	HFM	○	●	●	●	●	●	○	00E3
2011	Compass	AMP	○	●	●	●	●	○	●	006D 0068 0069 0079 0303
2011	Compass	SAS	○	●	●	●	○	○	○	
2011	Compass	TCM	○	●	●	●	●	●	●	0380
2011	Compass	PCM	○	●	●	●	●	●	●	03E0 0149 03D0 04B2 03DD 03E3 03E2 03DE 03E1 012D 03D3 03DF 03D9 03DA 0049 03DB 03D4 03DC 03D2 03D6 03D8 057C 03D5 042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2011	Compass	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2011	Dakota	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 01DE 0227 023E 0271
2011	Dakota	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0293 0033 0388 04A6 04A0 00C6 0040 00DA 0272 0273
2011	Dakota	ORC	○	●	●	●	○	●	○	02A1
2011	Dakota	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2011	Dakota	HFM	○	●	●	●	●	●	○	00E3

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Dakota	AMP	○	●	●	●	●	○	●	006D 0068
2011	Dakota	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2011	Dakota	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB
2011	Dakota	EOM	○	●	●	●	●	○	●	00BA
2011	Dakota	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F
2011	Dakota	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0381 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2011	Ypsilon	EPS	○	●	●	●	○	○	●	
2011	Ypsilon	AHM	○	●	●	●	●	●	○	
2011	Ypsilon	HVAC	○	●	●	●	●	●	●	
2011	Ypsilon	ECM	○	●	●	●	●	●	●	04BE 04C0 04BF
2011	Ypsilon	ORC	○	●	●	●	●	●	●	
2011	Ypsilon	BCM	○	●	●	●	●	●	○	04E5 04E6
2011	Ypsilon	IPC	○	●	●	●	●	●	○	04DB
2011	Ypsilon	TCM	○	●	●	●	○	●	●	
2011	Ypsilon	ABS	○	●	●	●	○	●	●	
2011	Caliber	TCM	○	●	●	●	●	●	●	0380
2011	Caliber	SAS	○	●	●	●	○	○	○	
2011	Caliber	HFM	○	●	●	●	●	●	○	00E3
2011	Caliber	ABS	○	●	●	●	●	●	●	03AB 0002 0485 0285 0062
2011	Caliber	AMP	○	●	●	●	●	○	●	006D 0068 0069 0079 0303
2011	Caliber	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2011	Caliber	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2011	Caliber	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0382 0094 0092 038D 0096 0383
2011	Caliber	ORC	○	●	●	●	●	○	●	03CC
2011	Caliber	WCM	○	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 0232 0230 0231 022F 0227
2011	Caliber	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 03E0 0149 03D0 04B2 03DD 03E3 03E2 03DE 03E1 03D3 03DF 03D9 03DA 0049 03DB 03D4 03DC 03D2 03D6 03D8 057C 03D5
2011	Caliber	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0032 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2011	Caliber	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2011	Mini-Van	IPM	○	●	●	●	○	●	○	
2011	Mini-Van	ATC	○	●	●	●	○	●	○	
2011	Mini-Van	PLGM	○	●	●	●	●	●	●	
2011	Mini-Van	MHSM	○	●	●	●	○	●	○	
2011	Mini-Van	ORC	○	●	●	●	○	○	○	
2011	Mini-Van	SDAR	○	●	●	●	●	●	○	
2011	Mini-Van	ABS	○	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Mini-Van	BCM	○	●	●	●	○	●	○	
2011	Mini-Van	HFM	○	●	●	●	○	●	○	
2011	Mini-Van	SKREEM	○	●	●	●	●	○	○	8003 8004 8005 8006 8007 01D2 04A2 8008 8009 800A 800B 800C 01DE 800E 01DA
2011	Mini-Van	MTC	○	●	●	●	○	●	○	
2011	Mini-Van	PTS	○	●	●	●	●	●	○	
2011	Mini-Van	DSD	○	●	●	●	○	●	○	
2011	Mini-Van	PCM	○	●	●	●	○	●	○	
2011	Mini-Van	PSD	○	●	●	●	○	●	○	
2011	Mini-Van	TCM	○	●	●	●	●	●	●	
2011	Mini-Van	EOM	○	●	●	○	○	○	○	
2011	Mini-Van	OCM	○	●	●	●	○	○	○	011E 802A 802B 8023 8024
2011	Mini-Van	MIC/CCN	○	●	●	●	○	●	○	
2011	Routan	PLGM	○	●	●	●	●	●	●	038A 038B 0342
2011	Routan	HSM	○	●	●	●	●	●	●	0412
2011	Routan	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2011	Routan	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	Routan	SUNR	○	●	●	●	●	●	○	
2011	Routan	VES2	○	●	●	●	●	●	●	
2011	Routan	PSDMR	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2011	Routan	DMRL	○	●	●	●	●	●	●	00B4 00B5 00B6
2011	Routan	AMP	○	●	●	●	●	○	●	006D 0068
2011	Routan	PSDML	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2011	Routan	ORC	○	●	●	●	●	○	●	03CC 02A1 0122
2011	Routan	DMFR	○	●	●	●	●	●	○	
2011	Routan	ABS	○	●	●	●	●	●	●	03AB 0002
2011	Routan	RADIO	○	●	●	●	●	●	●	039E 039F 01BB 025D
2011	Routan	CCN	○	●	●	●	●	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2011	Routan	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2011	Routan	WCM	○	●	●	●	●	●	●	02A7 0414 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2011	Routan	SAS	○	●	●	●	○	○	○	
2011	Routan	DMRR	○	●	●	●	●	●	●	00B4 00B5 00B6
2011	Routan	DMFL	○	●	●	●	●	●	●	
2011	Routan	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB 03A9 00E9
2011	Routan	HFM	○	●	●	●	●	●	○	00E3
2011	Routan	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2011	Routan	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2011	Routan	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F 0459
2011	Routan	FSM	○	●	●	●	●	●	○	03AC 03AD 0346 0347
2011	Routan	VES3	○	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Routan	DVD	○	●	●	●	●	○	○	
2011	Town & Country / Caravan	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F
2011	Town & Country / Caravan	FSM	○	●	●	●	●	●	○	03AC 03AD 0346 0347
2011	Town & Country / Caravan	HSM	○	●	●	●	●	●	●	0412
2011	Town & Country / Caravan	BSM	○	●	●	●	●	○	○	0372
2011	Town & Country / Caravan	AHBM	○	●	●	●	●	○	○	03C0 00BC
2011	Town & Country / Caravan	PSDML	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2011	Town & Country / Caravan	PLGM	○	●	●	●	●	●	●	038A 038B 0342
2011	Town & Country / Caravan	PCM	○	●	●	●	●	●	●	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 014A 0148 0044 0049 0144 02C0 02BB 031D 02C1 013B 02C2 042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 0428 0424 0423 0427 03D2 0425
2011	Town & Country / Caravan	ABS	○	●	●	●	●	●	●	0002 04EB 03AB
2011	Town & Country / Caravan	HIDT	○	●	●	●	●	●	○	0480
2011	Town & Country / Caravan	SAS	○	●	●	●	○	○	○	
2011	Town & Country / Caravan	VES2	○	●	●	●	●	●	●	
2011	Town & Country / Caravan	VES3	○	●	●	●	●	●	●	
2011	Town & Country / Caravan	AMP	○	●	●	●	●	○	●	006D 0068
2011	Town & Country / Caravan	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	Town & Country / Caravan	PSDMR	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2011	Town & Country / Caravan	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB 045C 00E9 045D 045E 045F 03A9
2011	Town & Country / Caravan	ORC	○	●	●	●	●	○	●	03CC 02A1 0122
2011	Town & Country / Caravan	DVD	○	●	●	●	●	○	○	
2011	Town & Country / Caravan	DMRL	○	●	●	●	●	●	●	00B4 00B5 00B6
2011	Town & Country / Caravan	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F 0459
2011	Town & Country / Caravan	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2011	Town & Country / Caravan	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2011	Town & Country / Caravan	CCN	○	●	●	●	●	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2011	Town & Country / Caravan	HFM	○	●	●	●	●	●	○	00E3
2011	Town & Country / Caravan	TCM	○	●	●	●	●	●	○	03AF 0499 049C 0392 03B0 0498 049B 0393 0394 03B1 0497 049A 0395 03B2 0496 03B6 03B3 0495 049D 0396 04A8 01FC 0177 03B4 0175
2011	Town & Country / Caravan	DMRR	○	●	●	●	●	●	●	00B4 00B5 00B6
2011	Town & Country / Caravan	WCM	○	●	●	●	●	●	●	02A7 0414 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2011	Town & Country / Caravan	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2011	Town & Country / Caravan	DMFR	○	●	●	●	●	●	○	
2011	Town & Country / Caravan	DMFL	○	●	●	●	●	●	●	
2011	Town & Country / Caravan	SDARV	○	●	●	●	●	○	○	
2011	Town & Country / Caravan	SUNR	○	●	●	●	●	●	○	
2011	Town & Country / Caravan	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 003A 002E 038F 0388 0390 03A1 03A2
2011	Durango (Post-2011)	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Grand Cherokee	SDARV	○	●	●	●	●	○	○	
2011	Grand Cherokee	ACC	○	●	●	●	●	○	○	
2011	Grand Cherokee	SAS	○	●	●	●	●	●	○	
2011	Grand Cherokee	HFM	○	●	●	●	●	●	○	00E3
2011	Grand Cherokee	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 0465 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2011	Grand Cherokee	ITM	○	●	●	●	●	●	●	0107 0437 03CF 03CE 0436
2011	Grand Cherokee	ESM	○	●	●	●	●	●	○	
2011	Grand Cherokee	AMP	○	●	●	●	●	○	●	006D 0068
2011	Grand Cherokee	VES3	○	●	●	●	●	●	●	
2011	Grand Cherokee	PTS	○	●	●	●	●	●	●	02ED 03B7
2011	Grand Cherokee	PCM	○	●	●	●	●	●	●	0431 012D 0042 0430 0049 042F 03D2 042E 0432 042D 031D 03D8 042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2011	Grand Cherokee	DTCM	○	●	●	●	●	●	●	
2011	Grand Cherokee	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2011	Grand Cherokee	PLGM	○	●	●	●	○	●	●	038A 038B
2011	Grand Cherokee	BSM	○	●	●	●	●	○	○	0372
2011	Grand Cherokee	HVAC	○	●	●	●	●	●	●	045C 00E9 045D 045F 02EB
2011	Grand Cherokee	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2011	Grand Cherokee	AHBM	○	●	●	●	○	●	○	0066
2011	Grand Cherokee	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 03A2
2011	Grand Cherokee	ORC	○	●	●	●	●	○	●	03CC 02A1 0122
2011	Grand Cherokee	AHLM	○	●	●	●	●	●	○	0464
2011	Grand Cherokee	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2012	Ram 3500 Pickup	HSM	○	●	●	●	●	●	●	0412
2012	Ram 3500 Pickup	SAS	○	●	●	●	○	○	○	
2012	Ram 3500 Pickup	DMFR	○	●	●	●	●	●	●	
2012	Ram 3500 Pickup	AMP	○	●	●	●	●	○	●	006D 0068
2012	Ram 3500 Pickup	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 03C7 0154 0155 0044 0411 0403 0401 03FF 03F4 0150 012D 0491 04AF 03CB 0049 03C8 0379 04AE 0179 03C1 035B 039A 03C2 03C4 03C9 0407
2012	Ram 3500 Pickup	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2012	Ram 3500 Pickup	ITBM	○	●	●	●	○	○	○	
2012	Ram 3500 Pickup	ABS	○	●	●	●	●	●	●	03AB 0002
2012	Ram 3500 Pickup	ORC	○	●	●	●	●	○	●	02A1
2012	Ram 3500 Pickup	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 022D 03A2
2012	Ram 3500 Pickup	DMFL	○	●	●	●	●	●	●	
2012	Ram 3500 Pickup	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2012	Ram 3500 Pickup	PTS	○	●	●	●	●	●	●	02ED 03B7

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Ram 3500 Pickup	HFM	○	●	●	●	●	●	○	00E3
2012	Ram 3500 Pickup	VES3	○	●	●	●	●	●	●	
2012	Ram 3500 Pickup	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2012	Ram 3500 Pickup	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2012	Ram 3500 Pickup	DTCM	○	●	●	●	●	●	○	
2012	Ram 3500 Pickup	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Ram 3500 Cab Chassis	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2012	Ram 3500 Cab Chassis	ORC	○	●	●	●	●	○	●	02A1
2012	Ram 3500 Cab Chassis	DMFL	○	●	●	●	●	●	●	
2012	Ram 3500 Cab Chassis	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0214 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 03A2
2012	Ram 3500 Cab Chassis	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2012	Ram 3500 Cab Chassis	ITBM	○	●	●	●	○	○	○	
2012	Ram 3500 Cab Chassis	SAS	○	●	●	●	○	○	○	
2012	Ram 3500 Cab Chassis	TCM	○	●	●	●	○	●	○	01F6 0391
2012	Ram 3500 Cab Chassis	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2012	Ram 3500 Cab Chassis	HSM	○	●	●	●	●	●	●	0412
2012	Ram 3500 Cab Chassis	HFM	○	●	●	●	●	●	○	00E3
2012	Ram 3500 Cab Chassis	PCM	○	●	●	●	●	●	●	03ED 03E8 03E9 03EA 03EB 03EC 03C7 0154 0155 0044 0411 03F4 0150 012D 0491 017B 04AF 03CB 0049 03C8 0179 03C1 0478 0477 03EF 039A 03EE 03C4 042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 0406 0407 040C 040E 040F 03B8 013C 012C 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2012	Ram 3500 Cab Chassis	DTCM	○	●	●	●	●	●	○	
2012	Ram 3500 Cab Chassis	DCU	○	○	○	○	○	○	○	
2012	Ram 3500 Cab Chassis	DMFR	○	●	●	●	●	●	●	
2012	Ram 3500 Cab Chassis	ABS	○	●	●	●	●	●	●	03AB 0002
2012	Ram 3500 Cab Chassis	AMP	○	●	●	●	●	○	●	006D 0068
2012	Ram 3500 Cab Chassis	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Ram 3500 Cab Chassis	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2012	Ram 2500	DMFR	○	●	●	●	●	●	●	
2012	Ram 2500	HFM	○	●	●	●	●	●	○	00E3
2012	Ram 2500	ITBM	○	●	●	●	○	○	○	
2012	Ram 2500	DMFL	○	●	●	●	●	●	●	
2012	Ram 2500	ORC	○	●	●	●	●	○	●	02A1
2012	Ram 2500	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2012	Ram 2500	PTS	○	●	●	●	●	●	●	02ED 03B7

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Ram 2500	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 03C7 0154 0155 0044 0411 0403 0401 03FF 03F4 0150 012D 0491 04AF 03CB 0049 03C8 0379 04AE 0179 03C1 035B 039A 03C2 03C4 03C9 042A 03F8 03F6 03F9 03F7 03FA 042B 0127 03F3 0140 0126 0404 0402 040A 0400 0128 042C 03FB 0406 0407 040C 040E 040F 03B8 013C 012C 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 04EE 04F0 04EF 04ED 04F1 04EC 04F2
2012	Ram 2500	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 022D 03A2
2012	Ram 2500	ABS	○	●	●	●	●	●	●	03AB 0002
2012	Ram 2500	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2012	Ram 2500	DTCM	○	●	●	●	●	●	○	
2012	Ram 2500	VES3	○	●	●	●	●	●	●	
2012	Ram 2500	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 0228 03E6 0232 0230 0231 022F 0300 0245 03E4
2012	Ram 2500	AMP	○	●	●	●	●	○	●	006D 0068
2012	Ram 2500	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2012	Ram 2500	HSM	○	●	●	●	●	●	●	0412
2012	Ram 2500	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Ram 2500	SAS	○	●	●	●	○	○	○	
2012	Ram 2500	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2012	Ram 2500	FDCM	○	●	●	●	●	○	○	02B5 02B3 02B2 02B1 02AF 02B0
2012	Ram 4500/5500	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2012	Ram 4500/5500	ITBM	○	●	●	●	○	○	○	
2012	Ram 4500/5500	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2012	Ram 4500/5500	DTCM	○	●	●	●	●	●	○	
2012	Ram 4500/5500	SAS	○	●	●	●	○	○	○	
2012	Ram 4500/5500	HFM	○	●	●	●	●	●	○	00E3
2012	Ram 4500/5500	DCU	○	○	○	○	○	○	○	
2012	Ram 4500/5500	ABS	○	●	●	●	●	●	●	03AB 0002
2012	Ram 4500/5500	TCM	○	●	●	●	○	●	○	01F6 0391
2012	Ram 4500/5500	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Ram 4500/5500	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0214 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 03A2
2012	Ram 4500/5500	PCM	○	●	●	●	●	●	●	03ED 03E8 03E9 03EA 03EB 03EC 03C7 0154 0155 0044 0411 03F4 0150 012D 0491 017B 04AF 03CB 0049 03C8 0179 03C1 03EF 039A 03EE 03C4 0478 0477
2012	Ram 4500/5500	ORC	○	●	●	●	●	○	●	02A1
2012	Ram 4500/5500	DMFR	○	●	●	●	●	●	●	
2012	Ram 4500/5500	HSM	○	●	●	●	●	●	●	0412
2012	Ram 4500/5500	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2012	Ram 4500/5500	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2012	Ram 4500/5500	DMFL	○	●	●	●	●	●	●	
2012	Ram 4500/5500	AMP	○	●	●	●	●	○	●	006D 0068

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Ram 1500	ABS	○	●	●	●	●	●	●	03AB 0002
2012	Ram 1500	AMP	○	●	●	●	●	○	●	006D 0068
2012	Ram 1500	PTS	○	●	●	●	●	●	●	02ED 03B7
2012	Ram 1500	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2012	Ram 1500	VES3	○	●	●	●	●	●	●	
2012	Ram 1500	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2012	Ram 1500	DMFL	○	●	●	●	●	●	●	
2012	Ram 1500	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2012	Ram 1500	SAS	○	●	●	●	○	○	○	
2012	Ram 1500	HFM	○	●	●	●	●	●	○	00E3
2012	Ram 1500	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2012	Ram 1500	HSM	○	●	●	●	●	●	●	0412
2012	Ram 1500	ORC	○	●	●	●	●	○	●	02A1
2012	Ram 1500	DMFR	○	●	●	●	●	●	●	
2012	Ram 1500	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 03A2
2012	Ram 1500	ITBM	○	●	●	●	○	○	○	
2012	Ram 1500	DTCM	○	●	●	●	●	●	●	
2012	Ram 1500	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2012	Ram 1500	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Ram 1500	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 00EC 02EA 03B9
2012	Ram (Mexico)	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 03ED 03E8 03E9 03EA 03EB 03EC 03C7 0154 0155 0044 0150 0491 017B 04AF 03CB 0049 03C8 04AE 0179 03C1 0478 0477 03EF 035B 039A 03EE 03C2 03C3 03C4 03C9
2012	Ram (Mexico)	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 0228 03E6 0232 0230 0231 022F 0300 0245 03E4
2012	Ram (Mexico)	SAS	○	●	●	●	○	○	○	
2012	Ram (Mexico)	HFM	○	●	●	●	●	●	○	00E3
2012	Ram (Mexico)	HSM	○	●	●	●	●	●	●	0412
2012	Ram (Mexico)	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2012	Ram (Mexico)	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2012	Ram (Mexico)	MSMD	○	●	●	●	●	○	○	02EE 00BC 0114 044F 0116 0117 0115 0119
2012	Ram (Mexico)	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2012	Ram (Mexico)	DMFL	○	●	●	●	●	●	●	
2012	Ram (Mexico)	VES3	○	●	●	●	●	●	●	
2012	Ram (Mexico)	ABS	○	●	●	●	●	●	●	03AB 0002

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Ram (Mexico)	ITBM	○	●	●	●	○	○	○	
2012	Ram (Mexico)	ORC	○	●	●	●	●	○	●	02A1
2012	Ram (Mexico)	AMP	○	●	●	●	●	○	●	006D 0068
2012	Ram (Mexico)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 03A2
2012	Ram (Mexico)	DMFR	○	●	●	●	●	●	●	
2012	Ram (Mexico)	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Ram (Mexico)	PTS	○	●	●	●	●	●	●	02ED 03B7
2012	Ram (Mexico)	DTCM	○	●	●	●	●	●	○	
2012	500	HVAC	○	●	●	●	●	●	○	04FE
2012	500	TCM	○	●	●	●	●	●	○	044D 02BD 044E 044A 04FA 044C 01EF 044B
2012	500	CTM	○	●	●	●	○	●	○	
2012	500	RADIO	○	●	●	●	●	○	○	
2012	500	EPS	○	●	●	●	●	○	○	050B 050C
2012	500	VTM	○	●	●	●	●	○	○	
2012	500	ORC	○	●	●	●	●	○	●	
2012	500	ABS	○	●	●	●	●	●	○	04F4
2012	500	IPC	○	●	●	●	●	●	○	04FB 04DB
2012	500	TPM	○	●	●	●	●	●	●	
2012	500	BCM	○	●	●	●	●	●	●	
2012	500	PCM	○	●	●	●	●	●	●	0507 04C2
2012	500	PTS	○	●	●	●	●	○	○	
2012	Wrangler (Export)	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2012	Wrangler (Export)	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2012	Wrangler (Export)	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2012	Wrangler (Export)	ORC	○	●	●	●	●	○	●	03CC 02A1 0122 03CD
2012	Wrangler (Export)	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 0227
2012	Wrangler (Export)	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2012	Wrangler (Export)	SAS	○	●	●	●	○	○	○	
2012	Wrangler (Export)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2012	Wrangler (Export)	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2012	Wrangler (Export)	PCM	○	●	●	●	●	●	●	0042 012D 02BA 0428 0424 0049 0423 0427 03D2 0425 031D 0447 013B
2012	Journey	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2012	Journey	ICS	○	●	●	●	●	●	○	
2012	Journey	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2012	Journey	RFH	○	●	●	●	●	●	●	0443 0440 0442 050E 0441 0444 043F 0445 050F
2012	Journey	PTS	○	●	●	●	●	●	●	02ED 03B7
2012	Journey	DTCM	○	●	●	●	●	●	●	
2012	Journey	SCCM	○	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Journey	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0429 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 0431 0042 0430 0049 042F 03D2 042E 0432 042D 031D 03D8
2012	Journey	VES3	○	●	●	●	●	●	○	
2012	Journey	DDM	○	●	●	●	●	●	●	
2012	Journey	PDM	○	●	●	●	●	●	●	
2012	Journey	ORC	○	●	●	●	●	○	●	02A1 0122
2012	Journey	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2012	Journey	TGW	○	●	●	●	●	○	●	0305 025D 050D 0446
2012	Journey	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2012	Journey	AMP	○	●	●	●	●	○	○	006D 0068
2012	Journey	HSM	○	●	●	●	●	●	●	
2012	Journey	HFM	○	●	●	●	●	○	○	00E3
2012	Journey	IPC	○	●	●	●	●	●	○	04B3
2012	Journey	TCM	○	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 047D 0175
2012	Journey	EPPM	○	●	●	●	●	○	●	047E
2012	Journey	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2012	Freemont	IPC	○	●	●	●	●	●	○	04B3
2012	Freemont	AMP	○	●	●	●	●	○	○	006D 0068
2012	Freemont	SCCM	○	●	●	●	●	○	○	
2012	Freemont	PTS	○	●	●	●	●	●	●	02ED 03B7
2012	Freemont	ORC	○	●	●	●	●	○	●	02A1 0122
2012	Freemont	PDM	○	●	●	●	●	●	●	
2012	Freemont	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2012	Freemont	ICS	○	●	●	●	●	●	○	
2012	Freemont	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2012	Freemont	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0429 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 0431 0042 0430 0049 042F 03D2 042E 0432 042D 031D 03D8
2012	Freemont	TCM	○	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 047D 0175
2012	Freemont	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2012	Freemont	HSM	○	●	●	●	●	●	●	
2012	Freemont	RFH	○	●	●	●	●	●	●	0443 0440 0442 0441 0444 043F 0445 050E 050F
2012	Freemont	DTCM	○	●	●	●	●	●	●	
2012	Freemont	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2012	Freemont	VES3	○	●	●	●	●	●	○	
2012	Freemont	HFM	○	●	●	●	●	○	○	00E3
2012	Freemont	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2012	Freemont	DDM	○	●	●	●	●	●	●	

[illegible]

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Nitro	DMFR	○	●	●	●	●	●	○	
2012	Nitro	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062 0485
2012	Nitro	AMP	○	●	●	●	●	○	●	006D 0068
2012	Nitro	HFM	○	●	●	●	●	●	○	00E3
2012	Nitro	SAS	○	●	●	●	○	○	○	
2012	Nitro	ORC	○	●	●	●	●	○	●	03CC 03CD
2012	Nitro	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 0227
2012	Nitro	ESM	○	●	●	●	●	●	○	
2012	Nitro	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2012	Nitro	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2012	Nitro	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2012	Nitro	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2012	Nitro	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2012	Nitro	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2012	Nitro	OCM	○	●	●	●	●	○	○	011E
2012	Liberty	ESM	○	●	●	●	●	●	○	
2012	Liberty	ORC	○	●	●	●	●	○	●	03CC 03CD
2012	Liberty	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2012	Liberty	SUNR	○	●	●	●	●	○	○	04A7
2012	Liberty	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 0042 02BA 0428 0424 0049 0423 0427 03D2 0425 031D 013B
2012	Liberty	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2012	Liberty	HFM	○	●	●	●	●	●	○	00E3
2012	Liberty	SAS	○	●	●	●	○	○	○	
2012	Liberty	FDCM	○	●	●	●	●	●	○	0340
2012	Liberty	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2012	Liberty	PTS	○	●	●	●	●	●	●	02ED 03B7
2012	Liberty	DMFR	○	●	●	●	●	●	○	
2012	Liberty	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2012	Liberty	DMFL	○	●	●	●	●	●	●	
2012	Liberty	ITM	○	●	●	●	●	●	●	03CF 010A 0107 0106 03CE
2012	Liberty	AMP	○	●	●	●	●	○	●	006D 0068
2012	Liberty	CCN	○	●	●	●	●	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2012	Liberty	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453 02EE 00BC 0114 0116 0117 0115 0119

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Liberty	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2012	Liberty	WCM	○	●	●	●	●	○	●	0233 01D2 03E4 0228 0232 0230 0231 022F 01DE 0227
2012	Liberty	OCM	○	●	●	●	●	○	○	011E
2012	Challenger	AMP	○	●	●	●	●	○	●	006D 0068
2012	Challenger	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2012	Challenger	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2012	Challenger	DDM	○	●	●	●	●	●	○	0306
2012	Challenger	EPS	○	●	●	●	●	○	○	
2012	Challenger	CCN	○	●	●	●	●	●	●	008F 008E 0382 038D 0090 0383
2012	Challenger	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2012	Challenger	PDM	○	●	●	●	●	●	○	0306
2012	Challenger	ADCM	○	●	●	●	●	○	○	
2012	Challenger	SAS	○	●	●	●	●	●	○	
2012	Challenger	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2012	Challenger	HFM	○	●	●	●	●	●	○	00E3
2012	Challenger	ESM	○	●	●	●	●	●	○	
2012	Challenger	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2012	Challenger	ABS	○	●	●	●	●	●	●	0433 03AB
2012	Challenger	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2012	Challenger	EOM	○	●	●	●	●	○	●	00BA 00BC
2012	Challenger	HSM	○	●	●	●	●	●	●	
2012	Challenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0219 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A2
2012	Challenger	ORC	○	●	●	●	●	○	●	02A1
2012	Challenger	SUNR	○	●	●	●	●	●	○	
2012	Challenger	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2012	Charger (Post-2011)	TPM	○	●	●	●	●	○	●	0435 0458 0232 0230 0231 022F 0459
2012	Charger (Post-2011)	AMP	○	●	●	●	●	○	○	006D 0068
2012	Charger (Post-2011)	TCM	○	●	●	●	●	○	●	047F 038C 01F3 01F2
2012	Charger (Post-2011)	RFH	○	●	●	●	●	●	●	0443 0440 0442 050E 04B4 0444 043F 0445 050F
2012	Charger (Post-2011)	PDM	○	●	●	●	●	●	●	
2012	Charger (Post-2011)	TGW	○	●	●	●	●	○	●	0305 025D 050D 0446
2012	Charger (Post-2011)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2012	Charger (Post-2011)	DTCM	○	●	●	●	●	●	○	
2012	Charger (Post-2011)	ADCM	○	●	●	●	●	○	○	
2012	Charger (Post-2011)	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2012	Charger (Post-2011)	ICS	○	●	●	●	●	●	○	
2012	Charger (Post-2011)	HFM	○	●	●	●	●	○	○	00E3
2012	Charger (Post-2011)	ACC	○	●	●	●	●	○	●	
2012	Charger (Post-2011)	DDM	○	●	●	●	●	●	●	
2012	Charger (Post-2011)	ORC	○	●	●	●	●	○	●	02A1

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Charger (Post-2011)	SCCM	○	●	●	●	●	○	○	
2012	Charger (Post-2011)	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2012	Charger (Post-2011)	BSM	○	●	●	●	●	○	○	0372
2012	Charger (Post-2011)	IPC	○	●	●	●	●	●	○	04B3 0456
2012	Charger (Post-2011)	EPS	○	●	●	●	●	○	○	
2012	Charger (Post-2011)	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2012	Charger (Post-2011)	PTS	○	●	●	●	●	●	●	02ED 03B7
2012	Charger (Post-2011)	ESM	○	●	●	●	●	●	○	
2012	Charger (Post-2011)	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2012	Charger (Post-2011)	VSIM	○	●	●	●	●	●	●	
2012	Charger (Post-2011)	HSM	○	●	●	●	●	●	●	
2012	Charger (Post-2011)	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0429 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2012	300 / Magnum / Charger (Pre-2011)	ACC	○	●	●	●	●	○	●	
2012	300 / Magnum / Charger (Pre-2011)	PDM	○	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	RFH	○	●	●	●	●	●	●	0443 0440 0442 050E 0444 0465 043F 0445 050F
2012	300 / Magnum / Charger (Pre-2011)	ORC	○	●	●	●	●	○	●	02A1
2012	300 / Magnum / Charger (Pre-2011)	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2012	300 / Magnum / Charger (Pre-2011)	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2012	300 / Magnum / Charger (Pre-2011)	AFLS	○	●	●	●	●	●	○	045B
2012	300 / Magnum / Charger (Pre-2011)	SCCM	○	●	●	●	●	○	○	
2012	300 / Magnum / Charger (Pre-2011)	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2012	300 / Magnum / Charger (Pre-2011)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2012	300 / Magnum / Charger (Pre-2011)	BSM	○	●	●	●	●	○	○	0372
2012	300 / Magnum / Charger (Pre-2011)	ADCM	○	●	●	●	●	○	○	
2012	300 / Magnum / Charger (Pre-2011)	EPS	○	●	●	●	●	○	○	
2012	300 / Magnum / Charger (Pre-2011)	ESM	○	●	●	●	●	●	○	
2012	300 / Magnum / Charger (Pre-2011)	TGW	○	●	●	●	●	○	●	0305 025D 050D 0446

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	300 / Magnum / Charger (Pre-2011)	HSM	○	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0429 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 0431 0042 0430 02BD 0049 042F 03D2 042E 0432 042D 031D 03D8
2012	300 / Magnum / Charger (Pre-2011)	ICS	○	●	●	●	●	●	○	
2012	300 / Magnum / Charger (Pre-2011)	DTCM	○	●	●	●	●	●	○	
2012	300 / Magnum / Charger (Pre-2011)	TPM	○	●	●	●	●	○	●	0435 0458 0232 0230 0231 022F 0459
2012	300 / Magnum / Charger (Pre-2011)	TCM	○	●	●	●	●	○	●	047F 038C 01F3 01F2
2012	300 / Magnum / Charger (Pre-2011)	IPC	○	●	●	●	●	●	○	04B3 0456
2012	300 / Magnum / Charger (Pre-2011)	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2012	300 / Magnum / Charger (Pre-2011)	PTS	○	●	●	●	●	●	●	02ED 03B7
2012	300 / Magnum / Charger (Pre-2011)	AMP	○	●	●	●	●	○	○	006D 0068
2012	300 / Magnum / Charger (Pre-2011)	DDM	○	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	HFM	○	●	●	●	●	○	○	00E3
2012	Compass	WCM	○	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 0232 0230 0231 022F 0227
2012	Compass	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2012	Compass	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2012	Compass	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2012	Compass	CCN	○	●	●	●	●	●	●	00BC 008F 008E 0382 038D 0090 0383
2012	Compass	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2012	Compass	AMP	○	●	●	●	●	○	●	0069 006D 0079 0068 0303
2012	Compass	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 03E0 0149 03D0 04B2 03DD 03E3 03E2 03DE 03E1 03D3 03DF 03D9 03DA 0049 03DB 03D4 03DC 03D2 03D6 03D8 057C 03D5
2012	Compass	SAS	○	●	●	●	○	○	○	
2012	Compass	ABS	○	●	●	●	●	●	●	03AB 0002 0485 0285 0062
2012	Compass	HFM	○	●	●	●	●	●	○	00E3

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Compass	ORC	○	●	●	●	●	○	●	03CC 03CD
2012	Compass	TCM	○	●	●	●	●	●	●	0380
2012	Compass	AWD	○	●	●	●	●	●	●	
2012	Dakota	ORC	○	●	●	●	○	●	○	02A1
2012	Dakota	CCN	○	●	●	●	●	●	●	00BC 008F 008E 008D 038D 0090
2012	Dakota	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2012	Dakota	HVAC	○	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB
2012	Dakota	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0226 0225 0493 0232 0230 0231 022F 0494 01DE 0227 023E 0271
2012	Dakota	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0381 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2012	Dakota	EOM	○	●	●	●	●	○	●	00BA
2012	Dakota	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2012	Dakota	FCMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0039 003C 003D 02A6 02A5 02A4 0032 003E 0484 0036 00D5 00D8 049F 0037 0035 0389 0034 0038 00DB 00D6 00D9 003A 049E 0293 0033 0388 04A6 04A0 00C6 0040 00DA 0272 0273
2012	Dakota	HFM	○	●	●	●	●	●	○	00E3
2012	Dakota	AMP	○	●	●	●	●	○	●	006D 0068
2012	Dart	EDM	○	●	●	○	○	●	○	
2012	Dart	LBSS	○	●	●	●	●	●	●	
2012	Dart	PAM	○	●	●	●	●	○	○	
2012	Dart	OCM	○	●	●	●	●	○	●	011E
2012	Dart	RADIO	○	●	●	●	●	●	●	
2012	Dart	ABS	○	●	●	●	●	○	●	0434 0513 0514
2012	Dart	EPS	○	●	●	●	●	○	○	051A
2012	Dart	IPC	○	●	●	●	●	●	●	04B3
2012	Dart	SCCM	○	●	●	●	●	○	○	
2012	Dart	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2012	Dart	TCM	○	●	●	●	●	●	●	0510 044D 044E 044A 044C 01EF 044B
2012	Dart	ESM	○	●	●	●	○	○	●	
2012	Dart	CTM	○	●	●	●	●	○	○	
2012	Dart	PCM	○	●	●	●	●	●	●	04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 04F1 04EC 02F9 03F1 03F0 03F2 012A 02FA 012B 04F2 0511 0506 0509 050A 0504 0512
2012	Dart	AMP	○	●	●	●	●	○	○	
2012	Dart	RBSS	○	●	●	●	●	●	●	
2012	Dart	ORC	○	●	●	●	●	○	●	02A1
2012	Dart	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 02DC 008F 008E 0219 0518 0517 0519 03E7 043B 0036 049F 0389 02DD 0388 0516 04A6
2012	Dart	CSWM	○	●	●	●	●	●	●	
2012	Dart	ICS	○	●	●	●	●	●	○	
2012	Dart	RFH	○	●	●	●	●	●	●	0443 0440 0463 0442 051F 0414 051E 0444 051B 051C 051D 0445 04F7

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Caliber	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2012	Caliber	SAS	○	●	●	●	○	○	○	
2012	Caliber	WCM	○	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 0232 0230 0231 022F 0227
2012	Caliber	PCM	○	●	●	●	●	●	●	03E0 0149 03D0 04B2 03DD 03E3 03E2 03DE 03E1 012D 03D3 03DF 03D9 03DA 0049 03DB 03D4 03DC 03D2 03D6 03D8 057C 03D5 042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2012	Caliber	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0032 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2012	Caliber	HFM	○	●	●	●	●	●	○	00E3
2012	Caliber	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2012	Caliber	ABS	○	●	●	●	●	●	●	03AB 0002 0485 0285 0062
2012	Caliber	AWD	○	●	●	●	●	●	●	
2012	Caliber	CCN	○	●	●	●	●	●	●	008C 00BC 008F 008E 0382 0094 0092 038D 0096 0383
2012	Caliber	AMP	○	●	●	●	●	○	●	006D 0068 0069 0079 0303
2012	Caliber	TCM	○	●	●	●	●	●	●	0380
2012	Caliber	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2012	Caliber	ORC	○	●	●	●	●	○	●	03CC
2012	Mini-Van	MHSM	○	●	●	●	○	●	○	
2012	Mini-Van	PSD	○	●	●	●	○	●	○	
2012	Mini-Van	SDAR	○	●	●	●	●	●	○	
2012	Mini-Van	BCM	○	●	●	●	○	●	○	
2012	Mini-Van	HFM	○	●	●	●	○	●	○	
2012	Mini-Van	DSD	○	●	●	●	○	●	○	
2012	Mini-Van	ORC	○	●	●	●	○	○	○	
2012	Mini-Van	MIC/CCN	○	●	●	●	○	●	○	
2012	Mini-Van	MTC	○	●	●	●	○	●	○	
2012	Mini-Van	ABS	○	●	●	●	●	○	○	
2012	Mini-Van	EOM	○	●	●	○	○	○	○	
2012	Mini-Van	OCM	○	●	●	●	○	○	○	011E 802A 802B 8023 8024
2012	Mini-Van	PTS	○	●	●	●	●	●	○	
2012	Mini-Van	PCM	○	●	●	●	○	●	○	
2012	Mini-Van	ATC	○	●	●	●	○	●	○	
2012	Mini-Van	SKREEM	○	●	●	●	●	○	○	8003 8004 8005 8006 8007 01D2 04A2 8008 8009 800A 800B 800C 01DE 800E 01DA
2012	Mini-Van	PLGM	○	●	●	●	●	●	●	
2012	Mini-Van	IPM	○	●	●	●	○	●	○	
2012	Mini-Van	TCM	○	●	●	●	●	●	●	
2012	Routan	PSDMR	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2012	Routan	VES2	○	●	●	●	●	●	●	
2012	Routan	PSDML	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2012	Routan	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245 022E

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Routan	DMRL	○	●	●	●	●	●	●	00B4 00B5 00B6
2012	Routan	BSM	○	●	●	●	●	○	○	0372
2012	Routan	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2012	Routan	VES3	○	●	●	●	●	●	●	
2012	Routan	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F 0459
2012	Routan	PLGM	○	●	●	●	●	●	●	038A 038B 0342
2012	Routan	ORC	○	●	●	●	●	○	●	03CC 02A1 0122
2012	Routan	SAS	○	●	●	●	○	○	○	
2012	Routan	DMFL	○	●	●	●	●	●	●	
2012	Routan	HSM	○	●	●	●	●	●	●	0412
2012	Routan	ABS	○	●	●	●	●	●	●	03AB 0002 0433
2012	Routan	FSM	○	●	●	●	●	●	○	03AC 03AD 0346 0347
2012	Routan	DMFR	○	●	●	●	●	●	○	
2012	Routan	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB 03A9 00E9 045C 045D 045E 045F
2012	Routan	PCM	○	●	●	●	●	●	●	042A 03F6 03F7 042B 0127 03F3 0140 0126 0411 0404 040A 0128 042C 03F4 040C 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 012B 0408
2012	Routan	HFM	○	●	●	●	●	●	○	00E3
2012	Routan	CCN	○	●	●	●	●	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2012	Routan	AMP	○	●	●	●	●	○	●	006D 0068
2012	Routan	SUNR	○	●	●	●	●	●	○	
2012	Routan	DMRR	○	●	●	●	●	●	●	00B4 00B5 00B6
2012	Routan	DVD	○	●	●	●	●	○	○	
2012	Routan	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2012	Routan	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2012	Routan	PTS	○	●	●	●	●	●	●	02ED 03B7
2012	Routan	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2012	Town & Country / Caravan	AMP	○	●	●	●	●	○	●	006D 0068
2012	Town & Country / Caravan	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2012	Town & Country / Caravan	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2012	Town & Country / Caravan	VES2	○	●	●	●	●	●	●	
2012	Town & Country / Caravan	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2012	Town & Country / Caravan	BSM	○	●	●	●	●	○	○	0372
2012	Town & Country / Caravan	DMFL	○	●	●	●	●	●	●	
2012	Town & Country / Caravan	DMRL	○	●	●	●	●	●	●	00B4 00B5 00B6
2012	Town & Country / Caravan	DMRR	○	●	●	●	●	●	●	00B4 00B5 00B6
2012	Town & Country / Caravan	HSM	○	●	●	●	●	●	●	0412
2012	Town & Country / Caravan	HVAC	○	●	●	●	●	●	●	045C 00E9 045D 045E 045F 02EB 00EA 03B9 02EA 03A9
2012	Town & Country / Caravan	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F 0459
2012	Town & Country / Caravan	VES3	○	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Town & Country / Caravan	PCM	○	●	●	●	●	●	●	0042 012D 02BA 0428 0424 0049 0423 0427 03D2 0425 031D 013B 042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2012	Town & Country / Caravan	PSDMR	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2012	Town & Country / Caravan	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2012	Town & Country / Caravan	SAS	○	●	●	●	○	○	○	
2012	Town & Country / Caravan	AHBM	○	●	●	●	●	○	○	03C0 00BC
2012	Town & Country / Caravan	FSM	○	●	●	●	●	●	○	03AC 03AD 0346 0347
2012	Town & Country / Caravan	TCM	○	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 0481 0175
2012	Town & Country / Caravan	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB 0433
2012	Town & Country / Caravan	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2012	Town & Country / Caravan	WCM	○	●	●	●	●	●	●	02A7 0414 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2012	Town & Country / Caravan	HFM	○	●	●	●	●	●	○	00E3
2012	Town & Country / Caravan	DVD	○	●	●	●	●	○	○	
2012	Town & Country / Caravan	PTS	○	●	●	●	●	●	●	02ED 03B7
2012	Town & Country / Caravan	SUNR	○	●	●	●	●	●	○	
2012	Town & Country / Caravan	HIDT	○	●	●	●	●	●	○	0480
2012	Town & Country / Caravan	EPPM	○	●	●	●	●	○	●	047E
2012	Town & Country / Caravan	ORC	○	●	●	●	●	○	●	03CC 02A1 0122
2012	Town & Country / Caravan	CCN	○	●	●	●	●	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2012	Town & Country / Caravan	PSDML	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2012	Town & Country / Caravan	PLGM	○	●	●	●	●	●	●	038A 038B 0342
2012	Town & Country / Caravan	DMFR	○	●	●	●	●	●	○	
2012	Durango (Post-2011)	ITM	○	●	●	●	●	●	●	0107 0437 03CF 03CE 0436
2012	Durango (Post-2011)	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 0465 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2012	Durango (Post-2011)	DTCM	○	●	●	●	●	●	●	
2012	Durango (Post-2011)	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2012	Durango (Post-2011)	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409
2012	Durango (Post-2011)	PLGM	○	●	●	●	○	●	●	038A 038B
2012	Durango (Post-2011)	ACC	○	●	●	●	●	○	○	
2012	Durango (Post-2011)	BSM	○	●	●	●	●	○	○	0372
2012	Durango (Post-2011)	EPS	○	●	●	●	●	○	○	
2012	Durango (Post-2011)	PTS	○	●	●	●	●	●	●	02ED 03B7
2012	Durango (Post-2011)	HVAC	○	●	●	●	●	●	●	045C 00E9 045D 045E 045F 02EB
2012	Durango (Post-2011)	AHBM	○	●	●	●	○	●	○	0066
2012	Durango (Post-2011)	HFM	○	●	●	●	●	●	○	00E3
2012	Durango (Post-2011)	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2012	Durango (Post-2011)	DMFR	○	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Durango (Post-2011)	DMFL	○	●	●	●	●	●	●	
2012	Durango (Post-2011)	HSM	○	●	●	●	●	●	●	0412
2012	Durango (Post-2011)	VES3	○	●	●	●	●	●	●	
2012	Durango (Post-2011)	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Durango (Post-2011)	AMP	○	●	●	●	●	○	●	006D 0068
2012	Durango (Post-2011)	AHLM	○	●	●	●	●	●	○	0464
2012	Durango (Post-2011)	SAS	○	●	●	●	●	●	○	
2012	Durango (Post-2011)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 03A2
2012	Durango (Post-2011)	ORC	○	●	●	●	●	○	●	03CC 02A1 0122
2012	Durango (Post-2011)	ESM	○	●	●	●	●	●	○	
2012	Durango (Post-2011)	ABS	○	●	●	●	●	●	●	0433 03AB
2012	Durango (Post-2011)	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2012	Durango (Post-2011)	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2012	Durango (Post-2011)	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2012	Grand Cherokee	ELSD	○	●	●	●	●	●	○	0474 0473
2012	Grand Cherokee	ASCM	○	●	●	●	●	○	○	046E 0467 046F 0472 046A 0471 0466 0469 046B 0468 046D 046C 0470
2012	Grand Cherokee	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 0465 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2012	Grand Cherokee	DMFR	○	●	●	●	●	●	●	
2012	Grand Cherokee	DMFL	○	●	●	●	●	●	●	
2012	Grand Cherokee	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2012	Grand Cherokee	HSM	○	●	●	●	●	●	●	0412
2012	Grand Cherokee	BSM	○	●	●	●	●	○	○	0372
2012	Grand Cherokee	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2012	Grand Cherokee	DTCM	○	●	●	●	●	●	●	
2012	Grand Cherokee	ITM	○	●	●	●	●	●	●	0107 0437 03CF 03CE 0436
2012	Grand Cherokee	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Grand Cherokee	ORC	○	●	●	●	●	○	●	03CC 02A1 0122
2012	Grand Cherokee	AHLM	○	●	●	●	●	●	○	0464
2012	Grand Cherokee	ABS	○	●	●	●	●	●	●	0433 03AB
2012	Grand Cherokee	PCM	○	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 0431 0042 0430 0049 042F 03D2 042E 0432 042D 031D 03D8
2012	Grand Cherokee	PLGM	○	●	●	●	○	●	●	038A 038B
2012	Grand Cherokee	EPS	○	●	●	●	●	○	○	
2012	Grand Cherokee	AHBM	○	●	●	●	○	●	○	0066
2012	Grand Cherokee	HFM	○	●	●	●	●	●	○	00E3
2012	Grand Cherokee	ACC	○	●	●	●	●	○	○	
2012	Grand Cherokee	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 03A2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Grand Cherokee	SAS	○	●	●	●	●	●	○	
2012	Grand Cherokee	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2012	Grand Cherokee	VES3	○	●	●	●	●	●	●	
2012	Grand Cherokee	HVAC	○	●	●	●	●	●	●	045C 00E9 045D 045F 02EB
2012	Grand Cherokee	ADCM	○	●	●	●	●	○	○	
2012	Grand Cherokee	ESM	○	●	●	●	●	●	○	
2012	Grand Cherokee	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2012	Grand Cherokee	PTS	○	●	●	●	●	●	●	02ED 03B7
2012	Grand Cherokee	AMP	○	●	●	●	●	○	●	006D 0068
2012	Grand Cherokee	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2013	Forza	IPC	○	●	●	●	○	●	○	04E6 0586 0587
2013	Forza	ORC	○	●	●	●	○	●	○	
2013	Ram 3500 Pickup	DDM	○	●	●	●	●	●	●	
2013	Ram 3500 Pickup	ORC	○	●	●	●	●	●	●	02A1
2013	Ram 3500 Pickup	AMP	○	●	●	●	●	○	○	006D 0068
2013	Ram 3500 Pickup	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2013	Ram 3500 Pickup	ICS	○	●	●	●	●	●	●	
2013	Ram 3500 Pickup	DTCM	○	●	●	●	●	●	●	
2013	Ram 3500 Pickup	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Ram 3500 Pickup	IPC	○	●	●	●	●	●	●	04B3 0456 0530
2013	Ram 3500 Pickup	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 0525 0521 0526 03EC 0523 0524 03C7 0411 0403 03FF 03F4 0407 040F 012D 0313 0528 0491 04AF 03CB 0522 0478 0477 039A 0527 03C4 04EE 04EF 0127 03F3 0140 0126 040A 0401 0128 03B8 04ED 013C 012C 0410 04F1 04EC 0429 02F9 03F1 03F0 03F2 012A 02FA 040B 012B 04F2
2013	Ram 3500 Pickup	TCM	○	●	●	●	●	●	●	01EF
2013	Ram 3500 Pickup	SCCM	○	●	●	●	●	○	○	
2013	Ram 3500 Pickup	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2013	Ram 3500 Pickup	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 038F 03C0 022D
2013	Ram 3500 Pickup	RFH	○	●	●	●	●	●	●	0443 0463 0442 052A 051E 0444 043F 051B 0445 052B
2013	Ram 3500 Pickup	PDM	○	●	●	●	●	●	●	
2013	Ram 3500 Pickup	EDM	○	●	●	●	●	●	○	
2013	Ram 3500 Pickup	ASCM	○	●	●	●	●	○	●	052D 0466 0469 0468 046D 0470
2013	Ram 3500 Pickup	ITBM	○	●	●	●	●	○	○	
2013	Ram 3500 Pickup	HSM	○	●	●	●	●	●	●	
2013	Ram 3500 Pickup	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Ram 3500 Pickup	RADIO	○	●	●	●	●	●	●	
2013	Ram 3500 Pickup	DCU	○	●	●	○	○	○	○	
2013	Ram 3500 Pickup	VGT	○	●	●	○	○	○	○	
2013	Ram 3500 Pickup	VSIM	○	●	●	●	●	●	○	
2013	Ram 3500 Cab Chassis	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Ram 3500 Cab Chassis	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Ram 3500 Cab Chassis	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 038F 03C0 022D
2013	Ram 3500 Cab Chassis	ORC	○	●	●	●	●	●	●	02A1
2013	Ram 3500 Cab Chassis	EDM	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Ram 3500 Cab Chassis	VGT	○	●	●	○	○	○	○	
2013	Ram 3500 Cab Chassis	DDM	○	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	SCCM	○	●	●	●	●	○	○	
2013	Ram 3500 Cab Chassis	HSM	○	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	DTCM	○	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	TCM	○	●	●	●	●	●	●	01EF
2013	Ram 3500 Cab Chassis	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2013	Ram 3500 Cab Chassis	VSIM	○	●	●	●	●	●	○	
2013	Ram 3500 Cab Chassis	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 04EE 04EF 0127 03F3 0140 0126 0411 0403 040A 0401 0128 03FF 03F4 0407 040F 03B8 04ED 013C 012C 012D 0410 04F1 04EC 0429 02F9 03F1 03F0 03F2 012A 02FA 040B 012B 04F2 0525 0521 0526 03EC 0523 0524 03C7 052F 0491 03CB 03C8 052E 0478 0477 03EF 039A 0527 03C4 0313 0528 04AF
2013	Ram 3500 Cab Chassis	PDM	○	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	IPC	○	●	●	●	●	●	●	04B3 0456 0530
2013	Ram 3500 Cab Chassis	ITBM	○	●	●	●	●	○	○	
2013	Ram 3500 Cab Chassis	RFH	○	●	●	●	●	●	●	0443 0463 0442 052A 051E 0444 043F 051B 0445 052B
2013	Ram 3500 Cab Chassis	AMP	○	●	●	●	●	○	○	006D 0068
2013	Ram 3500 Cab Chassis	ICS	○	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2013	Ram 3500 Cab Chassis	RADIO	○	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	DCU	○	●	●	○	○	○	○	
2013	Ram 2500	EDM	○	●	●	●	●	●	○	
2013	Ram 2500	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Ram 2500	IPC	○	●	●	●	●	●	●	04B3 0456 0530
2013	Ram 2500	DCU	○	●	●	○	○	○	○	
2013	Ram 2500	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 038F 03C0 022D
2013	Ram 2500	RFH	○	●	●	●	●	●	●	0443 0463 0442 052A 051E 0444 043F 051B 0445 052B
2013	Ram 2500	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Ram 2500	ORC	○	●	●	●	●	●	●	02A1
2013	Ram 2500	DDM	○	●	●	●	●	●	●	
2013	Ram 2500	ICS	○	●	●	●	●	●	●	
2013	Ram 2500	HSM	○	●	●	●	●	●	●	
2013	Ram 2500	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 0525 0521 0526 03EC 0523 0524 03C7 0411 0403 03FF 03F4 0407 040F 012D 0313 0528 0491 04AF 03CB 0522 0478 0477 039A 0527 03C4 04EE 04F0 04EF 0127 03F3 0140 0126 040A 0401 0128 03B8 04ED 013C 012C 0410 04F1 04EC 0429 02F9 03F1 03F0 03F2 012A 02FA 040B 012B 04F2
2013	Ram 2500	RADIO	○	●	●	●	●	●	●	
2013	Ram 2500	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2013	Ram 2500	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2013	Ram 2500	PDM	○	●	●	●	●	●	●	
2013	Ram 2500	TCM	○	●	●	●	●	●	●	01EF
2013	Ram 2500	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2013	Ram 2500	VSIM	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Ram 2500	ASCM	○	●	●	●	●	○	●	052D 0466 0469 0468 046D 0470
2013	Ram 2500	FDCM	○	●	●	●	●	○	○	
2013	Ram 2500	VGT	○	●	●	○	○	○	○	
2013	Ram 2500	AMP	○	●	●	●	●	○	○	006D 0068
2013	Ram 2500	DTCM	○	●	●	●	●	●	●	
2013	Ram 2500	SCCM	○	●	●	●	●	○	○	
2013	Ram 2500	ITBM	○	●	●	●	●	○	○	
2013	Ram 4500/5500	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2013	Ram 4500/5500	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Ram 4500/5500	AMP	○	●	●	●	●	○	○	006D 0068
2013	Ram 4500/5500	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2013	Ram 4500/5500	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 04EE 04EF 0127 03F3 0140 0126 0411 0403 040A 0401 0128 03FF 03F4 0407 040F 03B8 04ED 013C 012C 012D 0410 04F1 04EC 0429 02F9 03F1 03F0 03F2 012A 02FA 040B 012B 04F2 0525 0521 0526 03EC 0523 0524 03C7 0313 0528 052F 0491 04AF 03CB 03C8 052E 0478 0477 03EF 039A 0527 03C4
2013	Ram 4500/5500	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Ram 4500/5500	VGT	○	●	●	○	○	○	○	
2013	Ram 4500/5500	TCM	○	●	●	●	●	●	●	01EF
2013	Ram 4500/5500	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2013	Ram 4500/5500	IPC	○	●	●	●	●	●	●	04B3 0456 0530
2013	Ram 4500/5500	ORC	○	●	●	●	●	●	●	02A1
2013	Ram 4500/5500	RADIO	○	●	●	●	●	●	●	
2013	Ram 4500/5500	HSM	○	●	●	●	●	●	●	
2013	Ram 4500/5500	VSIM	○	●	●	●	●	●	○	
2013	Ram 4500/5500	SCCM	○	●	●	●	●	○	○	
2013	Ram 4500/5500	DDM	○	●	●	●	●	●	●	
2013	Ram 4500/5500	ICS	○	●	●	●	●	●	●	
2013	Ram 4500/5500	RFH	○	●	●	●	●	●	●	0443 0463 0442 052A 051E 0444 043F 051B 0445 052B
2013	Ram 4500/5500	DTCM	○	●	●	●	●	●	●	
2013	Ram 4500/5500	DCU	○	●	●	○	○	○	○	
2013	Ram 4500/5500	PDM	○	●	●	●	●	●	●	
2013	Ram 4500/5500	EDM	○	●	●	●	●	●	○	
2013	Ram 4500/5500	ITBM	○	●	●	●	●	○	○	
2013	Ram 1500	EDM	○	●	●	●	●	●	○	
2013	Ram 1500	RFH	○	●	●	●	●	●	●	0443 0463 0442 052A 051E 0444 058C 043F 051B 0445 052B
2013	Ram 1500	DTCM	○	●	●	●	●	●	●	
2013	Ram 1500	ASCM	○	●	●	●	●	○	●	046E 052D 046A 0466 0469 0468 046D 046C 0470
2013	Ram 1500	DDM	○	●	●	●	●	●	●	
2013	Ram 1500	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 04EE 04EF 0127 03F3 0140 0126 0411 0403 040A 0401 0128 03FF 03F4 0407 040F 03B8 04ED 013C 012C 012D 0410 04F1 04EC 0429 02F9 03F1 03F0 03F2 012A 02FA 040B 012B 04F2
2013	Ram 1500	IPC	○	●	●	●	●	●	●	04B3 0456
2013	Ram 1500	AMP	○	●	●	●	●	○	○	006D 0068

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Ram 1500	RADIO	○	●	●	●	●	●	●	
2013	Ram 1500	ICS	○	●	●	●	●	●	●	
2013	Ram 1500	EPS	○	●	●	●	●	○	○	050B
2013	Ram 1500	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2013	Ram 1500	PDM	○	●	●	●	●	●	●	
2013	Ram 1500	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2013	Ram 1500	ITBM	○	●	●	●	●	○	○	
2013	Ram 1500	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Ram 1500	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 038F 022D 03C0
2013	Ram 1500	TCM	○	●	●	●	●	○	●	047F
2013	Ram 1500	ORC	○	●	●	●	●	●	●	02A1
2013	Ram 1500	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2013	Ram 1500	HSM	○	●	●	●	●	●	●	
2013	Ram 1500	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Ram 1500	ESM	○	●	●	●	●	○	○	
2013	Ram 1500	SCCM	○	●	●	●	●	○	○	
2013	Ram (Mexico)	VGT	○	●	●	○	○	○	○	
2013	Ram (Mexico)	ORC	○	●	●	●	●	●	●	02A1
2013	Ram (Mexico)	DCU	○	●	●	○	○	○	○	
2013	Ram (Mexico)	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 0525 0521 0526 03EC 0523 0524 03C7 0411 0403 03FF 03F4 0407 040F 012D 052F 0491 03CB 03C8 052E 0522 0478 0477 03EF 039A 0527 03C4 0313 0528 04AF 04EE 04EF 0127 03F3 0140 0126 040A 0401 0128 03B8 04ED 013C 012C 0410 04F1 04EC 0429 02F9 03F1 03F0 03F2 012A 02FA 040B 012B 04F2
2013	Ram (Mexico)	IPC	○	●	●	●	●	●	●	04B3 0456
2013	Ram (Mexico)	AMP	○	●	●	●	●	○	○	006D 0068
2013	Ram (Mexico)	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Ram (Mexico)	TCM	○	●	●	●	●	●	●	047F 01EF
2013	Ram (Mexico)	RFH	○	●	●	●	●	●	●	0443 0463 0442 052A 051E 0444 043F 051B 0445 052B
2013	Ram (Mexico)	SCCM	○	●	●	●	●	○	○	
2013	Ram (Mexico)	EDM	○	●	●	●	●	●	○	
2013	Ram (Mexico)	DDM	○	●	●	●	●	●	●	
2013	Ram (Mexico)	EPS	○	●	●	●	●	○	○	050B
2013	Ram (Mexico)	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2013	Ram (Mexico)	DTCM	○	●	●	●	●	●	●	
2013	Ram (Mexico)	PDM	○	●	●	●	●	●	●	
2013	Ram (Mexico)	ITBM	○	●	●	●	●	○	○	
2013	Ram (Mexico)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 038F 03C0 022D
2013	Ram (Mexico)	HSM	○	●	●	●	●	●	●	
2013	Ram (Mexico)	ICS	○	●	●	●	●	●	●	
2013	Ram (Mexico)	RADIO	○	●	●	●	●	●	●	
2013	Ram (Mexico)	ESM	○	●	●	●	●	○	○	
2013	Ram (Mexico)	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2013	Ram (Mexico)	VSIM	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Ram (Mexico)	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2013	Ram (Mexico)	ASCM	○	●	●	●	●	○	●	046E 052D 046A 0466 0469 0468 046D 046C 0470
2013	Ram (Mexico)	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	500	RBC	○	●	●	●	●	○	○	0533 0002 0534 0532 0531
2013	500	ORC	○	●	●	●	●	○	●	
2013	500	PCM	○	●	●	●	●	●	●	04C2 0507
2013	500	ESM	○	●	●	○	●	○	○	
2013	500	OBCM	○	●	●	●	●	○	○	
2013	500	EVCU	○	●	●	●	●	●	○	053C 053D 053A 0539 053E 053B
2013	500	BCM	○	●	●	●	●	●	●	
2013	500	PTS	○	●	●	●	●	○	○	
2013	500	BPCM	○	●	●	●	●	●	○	
2013	500	ABS	○	●	●	●	●	●	○	04F4
2013	500	TCM	○	●	●	●	●	●	○	044D 02BD 044E 044A 04FA 044C 01EF 044B
2013	500	HVAC	○	●	●	●	●	●	○	04FE
2013	500	IPC	○	●	●	●	●	●	○	04FB 04DB
2013	500	EAC	○	●	●	●	●	○	○	
2013	500	CTM	○	●	●	●	○	●	○	
2013	500	VTM	○	●	●	●	●	○	○	
2013	500	RADIO	○	●	●	●	●	○	○	
2013	500	TPM	○	●	●	●	●	●	●	
2013	500	EPS	○	●	●	●	●	○	○	050B 050C
2013	500	PIM	○	●	●	●	●	○	○	
2013	Wrangler (Export)	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 0227
2013	Wrangler (Export)	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2013	Wrangler (Export)	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2013	Wrangler (Export)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2013	Wrangler (Export)	SAS	○	●	●	●	○	○	○	
2013	Wrangler (Export)	PCM	○	●	●	●	●	●	●	0042 012D 02BA 0428 0424 0049 0423 0427 03D2 0425 031D 0447 013B
2013	Wrangler (Export)	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2013	Wrangler (Export)	ORC	○	●	●	●	●	○	●	03CC 02A1 0122 03CD
2013	Wrangler (Export)	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2013	Wrangler (Export)	ESM	○	●	●	●	●	●	○	
2013	Wrangler (Export)	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2013	Journey	EPPM	○	●	●	●	●	○	●	047E
2013	Journey	RFH	○	●	●	●	●	●	●	0443 0440 0442 050E 0441 0444 043F 0445 050F
2013	Journey	IPC	○	●	●	●	●	●	○	04B3
2013	Journey	VTM	○	●	●	●	●	○	○	
2013	Journey	DDM	○	●	●	●	●	●	●	
2013	Journey	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2013	Journey	SCCM	○	●	●	●	●	○	○	
2013	Journey	ICS	○	●	●	●	●	●	○	
2013	Journey	PDM	○	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Journey	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2013	Journey	HFM	○	●	●	●	●	○	○	00E3
2013	Journey	TCM	○	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 047D 0175
2013	Journey	DTCM	○	●	●	●	●	●	●	
2013	Journey	PCM	○	●	●	●	●	●	●	042A 03F8 03F6 03F9 03F7 03FA 042B 04EE 04EF 0127 03F3 0140 0126 0411 0404 0402 040A 0400 0128 042C 03FB 03F4 0406 040C 040E 03B8 04ED 013C 012C 012D 0410 04F1 04EC 0429 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 012B 04F2 0408 0409 053F 0431 0042 0430 0049 042F 03D2 042E 0432 042D 031D 03D8
2013	Journey	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2013	Journey	ORC	○	●	●	●	●	○	●	02A1 0122
2013	Journey	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Journey	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Journey	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2013	Journey	VES3	○	●	●	●	●	●	○	
2013	Journey	AMP	○	●	●	●	●	○	○	006D 0068
2013	Journey	TGW	○	●	●	●	●	○	●	0305 025D 050D 0446
2013	Journey	HSM	○	●	●	●	●	●	●	
2013	Freemont	HFM	○	●	●	●	●	○	○	00E3
2013	Freemont	PDM	○	●	●	●	●	●	●	
2013	Freemont	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2013	Freemont	IPC	○	●	●	●	●	●	○	04B3
2013	Freemont	RFH	○	●	●	●	●	●	●	0443 0440 0442 050E 0441 0444 043F 0445 050F
2013	Freemont	ORC	○	●	●	●	●	○	●	02A1 0122
2013	Freemont	SCCM	○	●	●	●	●	○	○	
2013	Freemont	DTCM	○	●	●	●	●	●	●	
2013	Freemont	TGW	○	●	●	●	●	○	●	0305 025D 050D 0446
2013	Freemont	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Freemont	TCM	○	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 047D 0175
2013	Freemont	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2013	Freemont	VTM	○	●	●	●	●	○	○	
2013	Freemont	EPPM	○	●	●	●	●	○	●	047E
2013	Freemont	PCM	○	●	●	●	●	●	●	042A 03F8 03F6 03F9 03F7 03FA 042B 0127 03F3 0140 0126 0411 0404 0402 040A 0400 0128 042C 03FB 03F4 0406 040C 040E 03B8 013C 012C 012D 0410 0429 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 012B 0408 0409 04EE 04EF 04ED 04F1 04EC 04F2 053F 0431 0042 0430 0049 042F 03D2 042E 0432 042D 031D 03D8
2013	Freemont	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2013	Freemont	HSM	○	●	●	●	●	●	●	
2013	Freemont	VES3	○	●	●	●	●	●	○	
2013	Freemont	ICS	○	●	●	●	●	●	○	
2013	Freemont	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Freemont	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2013	Freemont	AMP	○	●	●	●	●	○	○	006D 0068

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Freemont	DDM	○	●	●	●	●	●	●	
2013	Wrangler	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 0227
2013	Wrangler	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2013	Wrangler	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2013	Wrangler	ASBS	○	●	●	●	●	○	○	0317 0318 031A 031B 0319
2013	Wrangler	PCM	○	●	●	●	●	●	●	0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 012B 04EE 04EF 04ED 04F1 04EC 04F2 0042 02BA 0428 0424 0049 0423 0427 03D2 0425 031D 0447 013B
2013	Wrangler	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2013	Wrangler	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2013	Wrangler	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D 04B1
2013	Wrangler	ORC	○	●	●	●	●	○	●	03CC 02A1 0122 03CD
2013	Wrangler	AMP	○	●	●	●	●	○	●	006D 0068
2013	Wrangler	HFM	○	●	●	●	●	●	○	00E3
2013	Wrangler	ESM	○	●	●	●	●	●	○	
2013	Wrangler	SAS	○	●	●	●	○	○	○	
2013	Wrangler	ITM	○	●	●	●	●	●	●	0437 03CF 0449 0436 0385
2013	Wrangler	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2013	Wrangler	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2013	Sebring / 200 / Avenger	ABS	○	●	●	●	●	●	●	03AB 0002 0485 0285 0062
2013	Sebring / 200 / Avenger	DDM	○	●	●	●	●	●	○	0306
2013	Sebring / 200 / Avenger	AMP	○	●	●	●	●	○	●	006D 0068
2013	Sebring / 200 / Avenger	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2013	Sebring / 200 / Avenger	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2013	Sebring / 200 / Avenger	SAS	○	●	●	●	○	○	○	
2013	Sebring / 200 / Avenger	PTCM	○	●	●	●	●	○	●	0259 04A4
2013	Sebring / 200 / Avenger	PDM	○	●	●	●	●	●	○	0306
2013	Sebring / 200 / Avenger	PCM	○	●	●	●	●	●	●	042A 03F8 03F6 03F9 03F7 03FA 042B 04EE 04EF 0127 03F3 0140 0126 0411 0404 0402 040A 0400 0128 042C 03FB 03F4 0406 040C 040E 03B8 04ED 013C 012C 012D 0410 04F1 04EC 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 012B 04F2 0408 0409
2013	Sebring / 200 / Avenger	ORC	○	●	●	●	●	○	●	03CC
2013	Sebring / 200 / Avenger	CCN	○	●	●	●	●	●	●	00BC 008F 008E 0382 038D 0090 0383
2013	Sebring / 200 / Avenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0214 03E7 0484 0036 02C3 0037 0389 0034 0038 003A 002E 038F 0388 0390 03A2
2013	Sebring / 200 / Avenger	HFM	○	●	●	●	●	●	○	00E3
2013	Sebring / 200 / Avenger	WCM	○	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 0232 0230 0231 022F 0227
2013	Liberty	ITM	○	●	●	●	●	●	●	03CF 010A 0107 0106 03CE
2013	Liberty	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2013	Liberty	CCN	○	●	●	●	●	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2013	Liberty	DMFR	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Liberty	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2013	Liberty	WCM	○	●	●	●	●	○	●	0233 01D2 03E4 0228 0232 0230 0231 022F 01DE 0227
2013	Liberty	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062
2013	Liberty	HFM	○	●	●	●	●	●	○	00E3
2013	Liberty	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2013	Liberty	MSMD	○	●	●	●	●	●	●	02EE 00BC 0114 044F 0116 0117 0115 0119 0455 0451 0450 0454 0452 0453
2013	Liberty	ORC	○	●	●	●	●	○	●	03CC 03CD
2013	Liberty	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Liberty	SAS	○	●	●	●	○	○	○	
2013	Liberty	SUNR	○	●	●	●	●	○	○	04A7
2013	Liberty	DMFL	○	●	●	●	●	●	●	
2013	Liberty	AMP	○	●	●	●	●	○	●	006D 0068
2013	Liberty	ESM	○	●	●	●	●	●	○	
2013	Liberty	OCM	○	●	●	●	●	○	○	011E
2013	Liberty	FDCM	○	●	●	●	●	●	○	0340
2013	Liberty	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2013	Liberty	PCM	○	●	●	●	●	●	●	03F8 03F9 03FA 0127 03F3 0140 0126 0411 0402 040A 0400 0128 03FB 03F4 0406 040E 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 03F5 012B 0409 0042 02BA 0428 0424 0049 0423 0427 03D2 0425 031D 013B 042A 03FC 03F6 03FD 03F7 03FE 042B 0404 0403 0401 042C 03FF 0407 040C 040F 040D 040B 0408 04EE 04EF 04ED 04F1 04EC 04F2
2013	Challenger	HSM	○	●	●	●	●	●	●	
2013	Challenger	HFM	○	●	●	●	●	●	○	00E3
2013	Challenger	PCM	○	●	●	●	●	●	●	0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 012B 04EE 04EF 04ED 04F1 04EC 04F2
2013	Challenger	ORC	○	●	●	●	●	○	●	02A1
2013	Challenger	EOM	○	●	●	●	●	○	●	00BA 00BC
2013	Challenger	DDM	○	●	●	●	●	●	○	0306
2013	Challenger	PTS	○	●	●	●	●	○	●	02ED
2013	Challenger	SUNR	○	●	●	●	●	●	○	
2013	Challenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0219 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A2
2013	Challenger	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2013	Challenger	EPS	○	●	●	●	●	○	○	
2013	Challenger	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2013	Challenger	SAS	○	●	●	●	●	●	○	
2013	Challenger	CCN	○	●	●	●	●	●	●	008F 008E 0382 038D 0090 0383
2013	Challenger	PDM	○	●	●	●	●	●	○	0306
2013	Challenger	AMP	○	●	●	●	●	○	●	006D 0068
2013	Challenger	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2013	Challenger	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2013	Challenger	ESM	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Challenger	ADCM	○	●	●	●	●	○	○	
2013	Challenger	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2013	Challenger	ABS	○	●	●	●	●	●	●	0433 03AB
2013	Challenger	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2013	Charger (Post-2011)	DTCM	○	●	●	●	●	●	○	
2013	Charger (Post-2011)	ICS	○	●	●	●	●	●	○	
2013	Charger (Post-2011)	VSIM	○	●	●	●	●	●	●	
2013	Charger (Post-2011)	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Charger (Post-2011)	TGW	○	●	●	●	●	○	●	0305 025D 050D 0446
2013	Charger (Post-2011)	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2013	Charger (Post-2011)	ADCM	○	●	●	●	●	○	○	
2013	Charger (Post-2011)	HSM	○	●	●	●	●	●	●	
2013	Charger (Post-2011)	PDM	○	●	●	●	●	●	●	
2013	Charger (Post-2011)	DDM	○	●	●	●	●	●	●	
2013	Charger (Post-2011)	LBSS	○	●	●	●	●	○	○	
2013	Charger (Post-2011)	ESM	○	●	●	●	●	●	○	
2013	Charger (Post-2011)	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2013	Charger (Post-2011)	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Charger (Post-2011)	TPM	○	●	●	●	●	○	●	0435 0458 0232 0230 0231 022F 0459
2013	Charger (Post-2011)	SCCM	○	●	●	●	●	○	○	
2013	Charger (Post-2011)	RBSS	○	●	●	●	●	○	○	
2013	Charger (Post-2011)	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2013	Charger (Post-2011)	HFM	○	●	●	●	●	○	○	00E3
2013	Charger (Post-2011)	ORC	○	●	●	●	●	○	●	02A1
2013	Charger (Post-2011)	TCM	○	●	●	●	●	○	●	047F 038C 01F3 01F2
2013	Charger (Post-2011)	IPC	○	●	●	●	●	●	○	04B3 0456
2013	Charger (Post-2011)	ACC	○	●	●	●	●	○	●	
2013	Charger (Post-2011)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2013	Charger (Post-2011)	RFH	○	●	●	●	●	●	●	0443 0440 0442 050E 04B4 0444 043F 0445 050F
2013	Charger (Post-2011)	AMP	○	●	●	●	●	○	○	006D 0068
2013	Charger (Post-2011)	EPS	○	●	●	●	●	○	○	
2013	Charger (Post-2011)	PCM	○	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 0410 04F1 04EC 0429 02F9 03F1 03F0 03F2 012A 02FA 012B 04F2
2013	300 / Magnum / Charger (Pre-2011)	PDM	○	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	TPM	○	●	●	●	●	○	●	0435 0458 0232 0230 0231 022F 0459
2013	300 / Magnum / Charger (Pre-2011)	ORC	○	●	●	●	●	○	●	02A1
2013	300 / Magnum / Charger (Pre-2011)	DDM	○	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	IPC	○	●	●	●	●	●	○	04B3 0456

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	300 / Magnum / Charger (Pre-2011)	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	300 / Magnum / Charger (Pre-2011)	AFLS	○	●	●	●	●	●	○	045B
2013	300 / Magnum / Charger (Pre-2011)	LBSS	○	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2013	300 / Magnum / Charger (Pre-2011)	RBSS	○	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	ADCM	○	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	HFM	○	●	●	●	●	○	○	00E3
2013	300 / Magnum / Charger (Pre-2011)	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	300 / Magnum / Charger (Pre-2011)	TCM	○	●	●	●	●	○	●	047F 038C 01F3 01F2
2013	300 / Magnum / Charger (Pre-2011)	TGW	○	●	●	●	●	○	●	0305 025D 050D 0446
2013	300 / Magnum / Charger (Pre-2011)	SCCM	○	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	RFH	○	●	●	●	●	●	●	0443 0440 0442 050E 0444 0465 043F 0445 050F
2013	300 / Magnum / Charger (Pre-2011)	PCM	○	●	●	●	●	●	●	0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 013C 012C 012D 0410 0429 02F9 03F1 03F0 03F2 012A 02FA 012B 04EE 04EF 04ED 04F1 04EC 04F2 0431 0042 0430 02BD 0049 042F 03D2 042E 0432 042D 031D 03D8
2013	300 / Magnum / Charger (Pre-2011)	EPS	○	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	ICS	○	●	●	●	●	●	○	
2013	300 / Magnum / Charger (Pre-2011)	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2013	300 / Magnum / Charger (Pre-2011)	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2013	300 / Magnum / Charger (Pre-2011)	HSM	○	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	ESM	○	●	●	●	●	●	○	
2013	300 / Magnum / Charger (Pre-2011)	AMP	○	●	●	●	●	○	○	006D 0068
2013	300 / Magnum / Charger (Pre-2011)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2013	300 / Magnum / Charger (Pre-2011)	DTCM	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	300 / Magnum / Charger (Pre-2011)	ACC	○	●	●	●	●	○	●	
2013	Compass	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2013	Compass	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2013	Compass	ORC	○	●	●	●	●	○	●	03CC 03CD
2013	Compass	PCM	○	●	●	●	●	●	●	03E0 0149 03D0 04B2 03DD 03E3 03E2 03DE 03E1 012D 03D3 03DF 03D9 03DA 0049 03DB 03D4 03DC 03D2 03D6 03D8 057C 03D5 04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 0410 04F1 04EC 0386 02F9 03F1 03F0 03F2 012A 02FA 012B 04F2
2013	Compass	ABS	○	●	●	●	●	●	●	03AB 0002 0485 0285 0062
2013	Compass	CCN	○	●	●	●	●	●	●	00BC 008F 008E 0382 038D 0090 0383
2013	Compass	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2013	Compass	HFM	○	●	●	●	●	●	○	00E3
2013	Compass	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2013	Compass	AWD	○	●	●	●	●	●	●	
2013	Compass	WCM	○	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 0232 0230 0231 022F 0227
2013	Compass	TCM	○	●	●	●	●	●	●	0380
2013	Compass	SAS	○	●	●	●	○	○	○	
2013	Compass	AMP	○	●	●	●	●	○	●	006D 0068 0069 0079 0303
2013	Ypsilon	ECM	○	●	●	●	●	●	●	
2013	Ypsilon	AHM	○	●	●	●	●	●	○	
2013	Ypsilon	ORC	○	●	●	●	●	●	●	
2013	Ypsilon	TCM	○	●	●	●	○	●	●	
2013	Ypsilon	ABS	○	●	●	●	○	●	●	
2013	Ypsilon	HVAC	○	●	●	●	●	●	●	
2013	Ypsilon	IPC	○	●	●	●	●	●	○	04DB
2013	Ypsilon	EPS	○	●	●	●	○	○	●	
2013	Ypsilon	BCM	○	●	●	●	●	●	○	04E5 04E6
2013	Dart	PAM	○	●	●	●	●	○	○	
2013	Dart	ESM	○	●	●	●	○	○	●	
2013	Dart	OCM	○	●	●	●	●	○	●	011E
2013	Dart	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2013	Dart	RFH	○	●	●	●	●	●	●	0443 0440 0463 0442 051F 0414 051E 0444 051B 051C 051D 0445 04F7
2013	Dart	RADIO	○	●	●	●	●	●	●	
2013	Dart	EDM	○	●	●	○	○	●	○	
2013	Dart	IPC	○	●	●	●	●	●	●	04B3
2013	Dart	ICS	○	●	●	●	●	●	○	
2013	Dart	SCCM	○	●	●	●	●	○	○	
2013	Dart	LBSS	○	●	●	●	●	●	●	
2013	Dart	PCM	○	●	●	●	●	●	●	04EE 04ED 0511 0506 012C 012D 0509 050A 0140 0504 012B 0512 04F0 04EF 0127 03F3 0126 0411 040A 0128 03F4 03B8 013C 04F1 04EC 02F9 03F1 03F0 03F2 012A 02FA 04F2
2013	Dart	AMP	○	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Dart	RBSS	○	●	●	●	●	●	●	
2013	Dart	CTM	○	●	●	●	●	○	○	
2013	Dart	EPS	○	●	●	●	●	○	○	051A
2013	Dart	ABS	○	●	●	●	●	○	●	0434 0513 0514
2013	Dart	CSWM	○	●	●	●	●	●	●	
2013	Dart	ORC	○	●	●	●	●	○	●	02A1
2013	Dart	TCM	○	●	●	●	●	●	●	0510 044D 044E 044A 044C 01EF 044B
2013	Dart	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 02DC 008F 008E 0219 0518 0517 0519 03E7 043B 0036 049F 0389 02DD 0388 0516 04A6
2013	Routan	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F 0459
2013	Routan	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2013	Routan	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 02EA 00E9
2013	Routan	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Routan	PCM	○	●	●	●	●	●	●	042A 03F6 03F7 042B 04EE 04EF 0127 03F3 0140 0126 0411 0404 040A 0128 042C 03F4 040C 03B8 04ED 013C 012C 012D 0410 04F1 04EC 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 012B 04F2 0408
2013	Routan	ORC	○	●	●	●	●	○	●	03CC 02A1
2013	Routan	DMRL	○	●	●	●	●	●	●	00B4 00B5 00B6
2013	Routan	PLGM	○	●	●	●	●	●	●	038A 038B 0342
2013	Routan	HFM	○	●	●	●	●	●	○	00E3
2013	Routan	FSM	○	●	●	●	●	●	○	03AC 03AD 0346 0347
2013	Routan	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2013	Routan	SAS	○	●	●	●	○	○	○	
2013	Routan	PSDMR	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2013	Routan	VES3	○	●	●	●	●	●	●	
2013	Routan	DVD	○	●	●	●	●	○	○	
2013	Routan	DMFL	○	●	●	●	●	●	●	
2013	Routan	CCN	○	●	●	●	●	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2013	Routan	AMP	○	●	●	●	●	○	●	006D 0068
2013	Routan	LBSS	○	●	●	●	●	○	○	
2013	Routan	DMFR	○	●	●	●	●	●	○	
2013	Routan	VES2	○	●	●	●	●	●	●	
2013	Routan	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2013	Routan	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 003A 002E 038F 0388 0390 03A1 03A2
2013	Routan	RBSS	○	●	●	●	●	○	○	
2013	Routan	DMRR	○	●	●	●	●	●	●	00B4 00B5 00B6
2013	Routan	ABS	○	●	●	●	●	●	●	0433 03AB 0002
2013	Routan	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2013	Routan	HSM	○	●	●	●	●	●	●	0412
2013	Routan	SUNR	○	●	●	●	●	●	○	
2013	Routan	PSDML	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2013	Town & Country / Caravan	SAS	○	●	●	●	○	○	○	
2013	Town & Country / Caravan	PSDML	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Town & Country / Caravan	DMFL	○	●	●	●	●	●	●	
2013	Town & Country / Caravan	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2013	Town & Country / Caravan	EPPM	○	●	●	●	●	○	●	047E
2013	Town & Country / Caravan	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2013	Town & Country / Caravan	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2013	Town & Country / Caravan	PLGM	○	●	●	●	●	●	●	038A 038B 0342
2013	Town & Country / Caravan	VES3	○	●	●	●	●	●	●	
2013	Town & Country / Caravan	TCM	○	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 0481 0175
2013	Town & Country / Caravan	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Town & Country / Caravan	ABS	○	●	●	●	●	●	●	0002 0485 0285 0062 03AB 0433
2013	Town & Country / Caravan	VES2	○	●	●	●	●	●	●	
2013	Town & Country / Caravan	AMP	○	●	●	●	●	○	●	006D 0068
2013	Town & Country / Caravan	HSM	○	●	●	●	●	●	●	0412
2013	Town & Country / Caravan	HFM	○	●	●	●	●	●	○	00E3
2013	Town & Country / Caravan	AHBM	○	●	●	●	○	●	○	0066
2013	Town & Country / Caravan	LBSS	○	●	●	●	●	○	○	
2013	Town & Country / Caravan	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F 0459
2013	Town & Country / Caravan	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 003A 002E 038F 0388 0390 03A1 03A2
2013	Town & Country / Caravan	DMRL	○	●	●	●	●	●	●	00B4 00B5 00B6
2013	Town & Country / Caravan	HVAC	○	●	●	●	●	●	●	045C 00E9 045D 045E 045F 02EB 00EA 03B9 03A9 02EA
2013	Town & Country / Caravan	DMRR	○	●	●	●	●	●	●	00B4 00B5 00B6
2013	Town & Country / Caravan	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2013	Town & Country / Caravan	CCN	○	●	●	●	●	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2013	Town & Country / Caravan	WCM	○	●	●	●	●	●	●	02A7 0414 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2013	Town & Country / Caravan	DMFR	○	●	●	●	●	●	○	
2013	Town & Country / Caravan	PSDMR	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2013	Town & Country / Caravan	PCM	○	●	●	●	●	●	●	042A 03F6 03F7 042B 0127 03F3 0140 0126 0411 0404 040A 0128 042C 03F4 040C 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 012B 0408 0042 02BA 0428 0424 0049 0423 0427 03D2 0425 031D 013B 04EE 04EF 04ED 04F1 04EC 04F2
2013	Town & Country / Caravan	DVD	○	●	●	●	●	○	○	
2013	Town & Country / Caravan	ORC	○	●	●	●	●	○	●	03CC 02A1
2013	Town & Country / Caravan	HIDT	○	●	●	●	●	●	○	0480
2013	Town & Country / Caravan	FSM	○	●	●	●	●	●	○	03AC 03AD 0346 0347
2013	Town & Country / Caravan	RBSS	○	●	●	●	●	○	○	
2013	Town & Country / Caravan	SUNR	○	●	●	●	●	●	○	
2013	Durango (Post-2011)	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Durango (Post-2011)	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2013	Durango (Post-2011)	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2013	Durango (Post-2011)	ESM	○	●	●	●	●	●	○	
2013	Durango (Post-2011)	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2013	Durango (Post-2011)	DMFR	○	●	●	●	●	●	●	
2013	Durango (Post-2011)	EPS	○	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Durango (Post-2011)	SAS	○	●	●	●	●	●	○	
2013	Durango (Post-2011)	HSM	○	●	●	●	●	●	●	0412
2013	Durango (Post-2011)	HVAC	○	●	●	●	●	●	●	045C 00E9 045D 045E 045F 02EB
2013	Durango (Post-2011)	AHLM	○	●	●	●	●	●	○	0464
2013	Durango (Post-2011)	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2013	Durango (Post-2011)	HFM	○	●	●	●	●	●	○	00E3
2013	Durango (Post-2011)	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245 0465
2013	Durango (Post-2011)	DMFL	○	●	●	●	●	●	●	
2013	Durango (Post-2011)	AMP	○	●	●	●	●	○	●	006D 0068
2013	Durango (Post-2011)	ACC	○	●	●	●	●	○	○	
2013	Durango (Post-2011)	ITM	○	●	●	●	●	●	●	0107 0437 03CF 03CE 0436
2013	Durango (Post-2011)	DTCM	○	●	●	●	●	●	●	
2013	Durango (Post-2011)	BSM	○	●	●	●	●	○	○	0372
2013	Durango (Post-2011)	ORC	○	●	●	●	●	○	●	03CC 02A1 0122
2013	Durango (Post-2011)	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2013	Durango (Post-2011)	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 0127 03F3 0140 0126 0411 0403 040A 0128 03FF 03F4 0407 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040B 012B 042A 03F8 03F6 03F9 03F7 03FA 042B 0404 0402 0400 0401 042C 03FB 0406 040C 040E 040D 03F5 0408 0409
2013	Durango (Post-2011)	VES3	○	●	●	●	●	●	●	
2013	Durango (Post-2011)	PLGM	○	●	●	●	○	●	●	038A 038B
2013	Durango (Post-2011)	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2013	Durango (Post-2011)	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 03A2
2013	Durango (Post-2011)	AHBM	○	●	●	●	○	●	○	0066
2013	Durango (Post-2011)	ABS	○	●	●	●	●	●	●	0433 03AB
	Grand Cherokee	HSM	○	●	●	●	●	●	●	0412
	Grand Cherokee	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
	Grand Cherokee	ESM	○	●	●	●	●	●	○	
	Grand Cherokee	ABS	○	●	●	●	●	●	●	0433 03AB
	Grand Cherokee	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
	Grand Cherokee	PLGM	○	●	●	●	○	●	●	038A 038B
	Grand Cherokee	AHLM	○	●	●	●	●	●	○	0464
	Grand Cherokee	ACC	○	●	●	●	●	○	○	
	Grand Cherokee	ELSD	○	●	●	●	●	●	○	0474 0473
	Grand Cherokee	SAS	○	●	●	●	●	●	○	
	Grand Cherokee	AHBM	○	●	●	●	○	●	○	0066
	Grand Cherokee	VES3	○	●	●	●	●	●	●	
	Grand Cherokee	DMFL	○	●	●	●	●	●	●	
2013	Grand Cherokee	ASCM	○	●	●	●	●	○	○	046E 0467 046F 0472 046A 0471 0466 0469 046B 0468 046D 046C 0470
2013	Grand Cherokee	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Grand Cherokee	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 0127 03F3 0140 0126 0411 0403 040A 0128 03FF 03F4 0407 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040B 012B 042A 03F8 03F6 03F9 03F7 03FA 042B 0404 0402 0400 0401 042C 03FB 0406 040C 040E 040D 03F5 0408 0409 0431 0042 0430 0049 042F 03D2 042E 0432 042D 031D 03D8
2013	Grand Cherokee	EPS	○	●	●	●	●	○	○	
2013	Grand Cherokee	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2013	Grand Cherokee	ITM	○	●	●	●	●	●	●	0107 0437 03CF 03CE 0436
2013	Grand Cherokee	ADCM	○	●	●	●	●	○	○	
2013	Grand Cherokee	DTCM	○	●	●	●	●	●	●	
2013	Grand Cherokee	PTS	○	●	●	●	●	●	●	02ED 03B7
2013	Grand Cherokee	HVAC	○	●	●	●	●	●	●	045C 00E9 045D 045F 02EB
2013	Grand Cherokee	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2013	Grand Cherokee	HFM	○	●	●	●	●	●	○	00E3
2013	Grand Cherokee	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 0388 0390 03A1 03A2
2013	Grand Cherokee	AMP	○	●	●	●	●	○	●	006D 0068
2013	Grand Cherokee	ORC	○	●	●	●	●	○	●	03CC 02A1 0122
2013	Grand Cherokee	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 0465 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2013	Grand Cherokee	CCN	○	●	●	●	●	●	●	00BC 0382 038D 0383
2013	Grand Cherokee	DMFR	○	●	●	●	●	●	●	
2013	Grand Cherokee	BSM	○	●	●	●	●	○	○	0372
2013	Viper (Post-2013)	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Viper (Post-2013)	ICS	○	●	●	●	●	●	●	
2013	Viper (Post-2013)	ABS	○	●	●	●	●	●	●	
2013	Viper (Post-2013)	AMP	○	●	●	●	●	○	○	006D 0068
2013	Viper (Post-2013)	PCM	○	●	●	●	●	●	○	013E 0411 0193 04AC 04AB 012C 012D 0429 04AA 012A 0540 012B 03F4
2013	Viper (Post-2013)	ORC	○	●	●	●	●	●	●	02A1
2013	Viper (Post-2013)	SCCM	○	●	●	●	●	○	○	
2013	Viper (Post-2013)	RADIO	○	●	●	●	●	●	●	
2013	Viper (Post-2013)	RFH	○	●	●	●	●	●	●	0440 0442 0444 043F 0445
2013	Viper (Post-2013)	IPC	○	●	●	●	●	●	●	04B3
2013	Viper (Post-2013)	PDM	○	●	●	●	●	●	●	
2013	Viper (Post-2013)	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2013	Viper (Post-2013)	ADCM	○	●	●	●	●	○	○	
2013	Viper (Post-2013)	OCM	○	●	●	●	●	○	○	011E
2013	Viper (Post-2013)	DDM	○	●	●	●	●	●	●	
2013	Viper (Post-2013)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 038F 022D
2014	4C	BCM	○	●	●	●	●	●	●	04E5 04E6
2014	4C	PAM	○	●	●	●	●	○	○	
2014	4C	ABS	○	●	●	●	●	●	●	0514
2014	4C	IPC	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	4C	PCM	○	●	●	●	●	●	●	0140 012B
2014	4C	TPM	○	●	●	●	○	○	●	
2014	4C	ORC	○	●	●	●	●	○	●	
2014	4C	TCM	○	●	●	●	●	●	●	
2014	Fiat 500L	PCM	○	●	●	●	●	●	●	0507
2014	Fiat 500L	ESM	○	●	●	●	●	●	●	
2014	Fiat 500L	ETM	○	●	●	●	●	○	●	
2014	Fiat 500L	BCM	○	●	●	●	●	●	●	0543 0599 04E5
2014	Fiat 500L	PAM	○	●	●	●	●	○	○	
2014	Fiat 500L	TCM	○	●	●	●	●	●	●	044D 044E 044A 044C 01EF 044B
2014	Fiat 500L	HVAC	○	●	●	●	●	●	○	04FE
2014	Fiat 500L	ABS	○	●	●	●	●	○	●	
2014	Fiat 500L	IPC	○	●	●	●	○	●	○	
2014	Fiat 500L	ORC	○	●	●	●	●	○	●	
2014	Fiat 500L	TPM	○	●	●	●	●	●	●	
2014	Fiat 500L	EPS	○	●	●	●	●	○	○	
2014	Forza	ORC	○	●	●	●	○	●	○	
2014	Forza	IPC	○	●	●	●	○	●	○	04E6 0586 0587
2014	Renegade	HALF	○	●	●	●	●	○	●	
2014	Renegade	BCM	○	●	●	●	●	●	●	04E5 05A3 0541 05A2 05A0 059E 059D 059C
2014	Renegade	ESL	○	●	●	○	○	○	○	
2014	Renegade	TCM	○	●	●	●	●	○	○	
2014	Renegade	ETM	○	●	●	●	●	●	●	
2014	Renegade	RRM	○	●	●	●	●	●	●	
2014	Renegade	AMP	○	●	●	●	●	●	●	
2014	Renegade	ECM	○	●	●	●	●	●	●	04D2 05AE 05AF 05AC 04BF 05B9 05BA 05BB 05BC 02B9 05C2 05BE 05C0 05B4 05B5 05BF 05B8 04BE 05B1 04C0 05B0 05B6 05B7 05BD 05B2 05B3 05C1 05C3 04C6 04B9 05C4
2014	Renegade	CSWM	○	●	●	●	○	●	○	
2014	Renegade	HVAC	○	●	●	●	●	●	●	05C5
2014	Renegade	ABS	○	●	●	●	○	●	●	05C7 04EA 05C6
2014	Renegade	ESM	○	●	●	●	●	●	●	
2014	Renegade	IPC	○	●	●	●	●	●	●	05C9
2014	Renegade	DTCM	○	●	●	●	●	○	○	
2014	Renegade	ACC	○	●	●	●	●	●	●	
2014	Renegade	ORC	○	●	●	●	●	○	●	
2014	Renegade	RBSS	○	●	●	●	●	●	○	
2014	Renegade	LBSS	○	●	●	●	●	●	○	
2014	Renegade	PAM	○	●	●	●	●	○	○	
2014	Renegade	RFH	○	●	●	●	●	●	○	05D2 05D7 05D5 05D0 05D1 05D6 05D3 0443 05D8 05D9
2014	Renegade	EPS	○	●	●	●	○	○	●	
2014	Renegade	TTM	○	●	●	●	●	●	○	
2014	Ram 3500 Pickup	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 0553 038F 022D 03C0
2014	Ram 3500 Pickup	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Ram 3500 Pickup	SCCM	○	●	●	●	●	○	○	
2014	Ram 3500 Pickup	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Ram 3500 Pickup	RADIO	○	●	●	●	●	●	●	
2014	Ram 3500 Pickup	AMP	○	●	●	●	●	○	○	006D 0068
2014	Ram 3500 Pickup	HSM	○	●	●	●	●	●	●	
2014	Ram 3500 Pickup	DCU	○	●	●	○	○	○	○	
2014	Ram 3500 Pickup	PDM	○	●	●	●	●	●	●	
2014	Ram 3500 Pickup	ASCM	○	●	●	●	●	○	●	052D 0466 0469 0468 046D 0470
2014	Ram 3500 Pickup	ITBM	○	●	●	●	●	○	○	
2014	Ram 3500 Pickup	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Ram 3500 Pickup	EDM	○	●	●	●	●	●	○	
2014	Ram 3500 Pickup	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 04EE 054F 04EF 0127 03F3 0140 0126 0411 0403 040A 0401 0128 03FF 03F4 0407 040F 03B8 04ED 013C 012C 012D 0550 04EC 0551 0429 054B 054C 02F9 03F1 03F0 03F2 012A 02FA 040B 054E 012B 0525 0521 0526 03EC 0523 0524 03C7 0313 0528 0491 04AF 03CB 0522 0478 0477 039A 0527 04F0 0552 054A
2014	Ram 3500 Pickup	VSIM	○	●	●	●	●	●	○	
2014	Ram 3500 Pickup	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2014	Ram 3500 Pickup	RFH	○	●	●	●	●	●	●	0443 0463 0442 052A 0414 051E 0444 043F 051B 051D 0445 052B
2014	Ram 3500 Pickup	ORC	○	●	●	●	●	●	●	02A1
2014	Ram 3500 Pickup	TCM	○	●	●	●	●	●	●	01EF
2014	Ram 3500 Pickup	IPC	○	●	●	●	●	●	●	04B3 0456 0530
2014	Ram 3500 Pickup	ICS	○	●	●	●	●	●	●	
2014	Ram 3500 Pickup	VGT	○	●	●	○	○	○	○	
2014	Ram 3500 Pickup	DDM	○	●	●	●	●	●	●	
2014	Ram 3500 Pickup	DTCM	○	●	●	●	●	●	●	
2014	Ram 3500 Cab Chassis	AMP	○	●	●	●	●	○	○	006D 0068
2014	Ram 3500 Cab Chassis	DDM	○	●	●	●	●	●	●	
2014	Ram 3500 Cab Chassis	PCM	○	●	●	●	●	●	●	0525 0521 0526 03EC 0523 0524 03C7 0411 03F4 012D 0313 0528 0552 052F 0491 04AF 03CB 03C8 052E 0478 0477 03EF 039A 0527 03FC 03FD 03FE 04EE 054F 04F0 04EF 0127 03F3 0140 0126 0403 040A 0401 0128 03FF 0407 040F 03B8 04ED 013C 012C 0550 04EC 0551 0429 054B 054C 02F9 03F1 03F0 03F2 012A 02FA 040B 054E 012B 054A
2014	Ram 3500 Cab Chassis	TCM	○	●	●	●	●	●	●	01EF
2014	Ram 3500 Cab Chassis	RFH	○	●	●	●	●	●	●	0443 0463 0442 052A 0414 051E 0444 043F 051B 051D 0445 052B
2014	Ram 3500 Cab Chassis	SCCM	○	●	●	●	●	○	○	
2014	Ram 3500 Cab Chassis	ICS	○	●	●	●	●	●	●	
2014	Ram 3500 Cab Chassis	PDM	○	●	●	●	●	●	●	
2014	Ram 3500 Cab Chassis	DTCM	○	●	●	●	●	●	●	
2014	Ram 3500 Cab Chassis	HSM	○	●	●	●	●	●	●	
2014	Ram 3500 Cab Chassis	DCU	○	●	●	○	○	○	○	
2014	Ram 3500 Cab Chassis	ORC	○	●	●	●	●	●	●	02A1
2014	Ram 3500 Cab Chassis	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D 0553
2014	Ram 3500 Cab Chassis	PTS	○	●	●	●	●	●	●	02ED 03B7

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Ram 3500 Cab Chassis	EDM	○	●	●	●	●	●	○	
2014	Ram 3500 Cab Chassis	IPC	○	●	●	●	●	●	●	04B3 0456 0530
2014	Ram 3500 Cab Chassis	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2014	Ram 3500 Cab Chassis	RADIO	○	●	●	●	●	●	●	
2014	Ram 3500 Cab Chassis	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	Ram 3500 Cab Chassis	VSIM	○	●	●	●	●	●	○	
2014	Ram 3500 Cab Chassis	VGT	○	●	●	○	○	○	○	
2014	Ram 3500 Cab Chassis	ITBM	○	●	●	●	●	○	○	
2014	Ram 3500 Cab Chassis	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Ram 2500	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 0553 038F 022D 03C0
2014	Ram 2500	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Ram 2500	DDM	○	●	●	●	●	●	●	
2014	Ram 2500	AMP	○	●	●	●	●	○	○	006D 0068
2014	Ram 2500	RFH	○	●	●	●	●	●	●	0443 0463 0442 052A 0414 051E 0444 043F 051B 051D 0445 052B
2014	Ram 2500	ICS	○	●	●	●	●	●	●	
2014	Ram 2500	RADIO	○	●	●	●	●	●	●	
2014	Ram 2500	TCM	○	●	●	●	●	●	●	01EF
2014	Ram 2500	FDCM	○	●	●	●	●	○	○	
2014	Ram 2500	SCCM	○	●	●	●	●	○	○	
2014	Ram 2500	IPC	○	●	●	●	●	●	●	04B3 0456 0530
2014	Ram 2500	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Ram 2500	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2014	Ram 2500	PDM	○	●	●	●	●	●	●	
2014	Ram 2500	DTCM	○	●	●	●	●	●	●	
2014	Ram 2500	DCU	○	●	●	○	○	○	○	
2014	Ram 2500	EDM	○	●	●	●	●	●	○	
2014	Ram 2500	HSM	○	●	●	●	●	●	●	
2014	Ram 2500	ORC	○	●	●	●	●	●	●	02A1
2014	Ram 2500	VSIM	○	●	●	●	●	●	○	
2014	Ram 2500	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	Ram 2500	ITBM	○	●	●	●	●	○	○	
2014	Ram 2500	ASCM	○	●	●	●	●	○	●	052D 0466 0469 0468 046D 0470
2014	Ram 2500	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 04EE 054F 04F0 04EF 0127 03F3 0140 0126 0411 0403 040A 0401 0128 03FF 03F4 0407 040F 03B8 04ED 013C 012C 012D 0550 04EC 0551 0429 054B 054C 02F9 03F1 03F0 03F2 012A 02FA 040B 054E 012B 0525 0521 0526 03EC 0523 0524 03C7 0313 0528 0491 04AF 03CB 0522 0478 0477 039A 0527 054A 0552
2014	Ram 2500	VGT	○	●	●	○	○	○	○	
2014	Ram 4500/5500	SCCM	○	●	●	●	●	○	○	
2014	Ram 4500/5500	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D 0553
2014	Ram 4500/5500	ORC	○	●	●	●	●	●	●	02A1
2014	Ram 4500/5500	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2014	Ram 4500/5500	ICS	○	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Ram 4500/5500	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	Ram 4500/5500	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Ram 4500/5500	EDM	○	●	●	●	●	●	○	
2014	Ram 4500/5500	TCM	○	●	●	●	●	●	●	01EF
2014	Ram 4500/5500	RFH	○	●	●	●	●	●	●	0443 0463 0442 052A 0414 051E 0444 043F 051B 051D 0445 052B
2014	Ram 4500/5500	VSIM	○	●	●	●	●	●	○	
2014	Ram 4500/5500	DTCM	○	●	●	●	●	●	●	
2014	Ram 4500/5500	PDM	○	●	●	●	●	●	●	
2014	Ram 4500/5500	RADIO	○	●	●	●	●	●	●	
2014	Ram 4500/5500	IPC	○	●	●	●	●	●	●	04B3 0456 0530
2014	Ram 4500/5500	PCM	○	●	●	●	●	●	●	0525 0521 0526 03EC 0523 0524 03C7 0411 03F4 012D 0313 0528 0552 052F 0491 04AF 03CB 03C8 052E 0478 0477 03EF 039A 0527 03FC 03FD 03FE 04EE 054F 04EF 0127 03F3 0140 0126 0403 040A 0401 0128 03FF 0407 040F 03B8 04ED 013C 012C 0550 04EC 0551 0429 054B 054C 02F9 03F1 03F0 03F2 012A 054A 02FA 040B 054E 012B 04F0
2014	Ram 4500/5500	AMP	○	●	●	●	●	○	○	006D 0068
2014	Ram 4500/5500	VGT	○	●	●	○	○	○	○	
2014	Ram 4500/5500	DCU	○	●	●	○	○	○	○	
2014	Ram 4500/5500	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Ram 4500/5500	DDM	○	●	●	●	●	●	●	
2014	Ram 4500/5500	HSM	○	●	●	●	●	●	●	
2014	Ram 4500/5500	ITBM	○	●	●	●	●	○	○	
2014	Ram 1500	EDM	○	●	●	●	●	●	○	
2014	Ram 1500	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2014	Ram 1500	ESM	○	●	●	●	●	○	○	
2014	Ram 1500	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Ram 1500	ITBM	○	●	●	●	●	○	○	
2014	Ram 1500	AMP	○	●	●	●	●	○	○	006D 0068
2014	Ram 1500	RFH	○	●	●	●	●	●	●	0443 0463 0442 052A 0414 051E 0444 043F 051B 051D 0445 052B
2014	Ram 1500	RADIO	○	●	●	●	●	●	●	
2014	Ram 1500	IPC	○	●	●	●	●	●	●	04B3 0456
2014	Ram 1500	ORC	○	●	●	●	●	●	●	02A1
2014	Ram 1500	ICS	○	●	●	●	●	●	●	
2014	Ram 1500	DTCM	○	●	●	●	●	●	●	
2014	Ram 1500	SCCM	○	●	●	●	●	○	○	
2014	Ram 1500	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Ram 1500	DDM	○	●	●	●	●	●	●	
2014	Ram 1500	ASCM	○	●	●	●	●	○	●	046E 052D 046A 0466 0469 0468 046D 046C 0470
2014	Ram 1500	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Ram 1500	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 04EE 054F 04EF 0127 03F3 0140 0126 0411 0403 040A 0401 0128 03FF 03F4 0407 040F 03B8 04ED 013C 012C 012D 0550 04EC 0551 0429 054B 054C 02F9 03F1 03F0 03F2 012A 02FA 040B 054E 012B 04F0 055F 0149 055C 055B 0431 05E1 0430 0560 05E4 0049 03DC 055E 05E2 055D 05DF 0432 042D 055A 0555 05E0 0554 0558 0556 0557 031D 03D8 054A
2014	Ram 1500	PDM	○	●	●	●	●	●	●	
2014	Ram 1500	TCM	○	●	●	●	●	○	●	047F
2014	Ram 1500	HSM	○	●	●	●	●	●	●	
2014	Ram 1500	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 0553 038F 022D 03C0
2014	Ram 1500	EPS	○	●	●	●	●	○	○	050B
2014	Ram (Mexico)	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2014	Ram (Mexico)	ITBM	○	●	●	●	●	○	○	
2014	Ram (Mexico)	PCM	○	●	●	●	●	●	●	03FC 03FD 03FE 04EE 054F 04EF 0127 03F3 0140 0126 0411 0403 040A 0401 0128 03FF 03F4 0407 040F 03B8 04ED 013C 012C 012D 0550 04EC 0551 0429 054B 054C 02F9 03F1 03F0 03F2 012A 02FA 040B 054E 012B 04F0 0525 0521 0526 03EC 0523 0524 03C7 0313 0528 052F 0491 04AF 03CB 03C8 052E 0522 0478 0477 03EF 039A 0527 0552 054A
2014	Ram (Mexico)	IPC	○	●	●	●	●	●	●	04B3 0456
2014	Ram (Mexico)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 0553 038F 022D 03C0
2014	Ram (Mexico)	HSM	○	●	●	●	●	●	●	
2014	Ram (Mexico)	VGT	○	●	●	○	○	○	○	
2014	Ram (Mexico)	EDM	○	●	●	●	●	●	○	
2014	Ram (Mexico)	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Ram (Mexico)	PDM	○	●	●	●	●	●	●	
2014	Ram (Mexico)	DCU	○	●	●	○	○	○	○	
2014	Ram (Mexico)	ICS	○	●	●	●	●	●	●	
2014	Ram (Mexico)	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Ram (Mexico)	VSIM	○	●	●	●	●	●	○	
2014	Ram (Mexico)	DTCM	○	●	●	●	●	●	●	
2014	Ram (Mexico)	RFH	○	●	●	●	●	●	●	0443 0463 0442 052A 0414 051E 0444 043F 051B 051D 0445 052B
2014	Ram (Mexico)	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	Ram (Mexico)	ASCM	○	●	●	●	●	○	●	046E 052D 046A 0466 0469 0468 046D 046C 0470
2014	Ram (Mexico)	SCCM	○	●	●	●	●	○	○	
2014	Ram (Mexico)	DDM	○	●	●	●	●	●	●	
2014	Ram (Mexico)	ORC	○	●	●	●	●	●	●	02A1
2014	Ram (Mexico)	EPS	○	●	●	●	●	○	○	050B
2014	Ram (Mexico)	RADIO	○	●	●	●	●	●	●	
2014	Ram (Mexico)	AMP	○	●	●	●	●	○	○	006D 0068
2014	Ram (Mexico)	TCM	○	●	●	●	●	●	●	047F 01EF
2014	Ram (Mexico)	ESM	○	●	●	●	●	○	○	
2014	500	RBC	○	●	●	●	●	○	○	0533 0002 0534 0532 0531

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Journey	PDM	○	●	●	●	●	●	●	
2014	Journey	HFM	○	●	●	●	●	○	○	00E3
2014	Journey	RFH	○	●	●	●	●	●	●	0443 0440 0442 050E 0441 0444 043F 0445 050F
2014	Journey	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2014	Journey	VTM	○	●	●	●	●	○	○	
2014	Journey	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 038F 022D 03C0
2014	Journey	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2014	Journey	EPPM	○	●	●	●	●	○	●	047E
2014	Journey	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Journey	DDM	○	●	●	●	●	●	●	
2014	Journey	TCM	○	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 047D 0175
2014	Journey	DTCM	○	●	●	●	●	●	●	
2014	Journey	ORC	○	●	●	●	●	○	●	02A1 0122
2014	Journey	HSM	○	●	●	●	●	●	●	
2014	Freemont	HFM	○	●	●	●	●	○	○	00E3
2014	Freemont	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Freemont	VTM	○	●	●	●	●	○	○	
2014	Freemont	ICS	○	●	●	●	●	●	○	
2014	Freemont	DTCM	○	●	●	●	●	●	●	
2014	Freemont	PDM	○	●	●	●	●	●	●	
2014	Freemont	AMP	○	●	●	●	●	○	○	006D 0068
2014	Freemont	TGW	○	●	●	●	●	○	●	0305 025D 050D 0446
2014	Freemont	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2014	Freemont	RFH	○	●	●	●	●	●	●	0443 0440 0442 0441 0444 043F 0445 050E 050F
2014	Freemont	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2014	Freemont	IPC	○	●	●	●	●	●	○	04B3
2014	Freemont	VES3	○	●	●	●	●	●	○	
2014	Freemont	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Freemont	ORC	○	●	●	●	●	○	●	02A1 0122
2014	Freemont	HSM	○	●	●	●	●	●	●	
2014	Freemont	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2014	Freemont	DDM	○	●	●	●	●	●	●	
2014	Freemont	EPPM	○	●	●	●	●	○	●	047E
2014	Freemont	SCCM	○	●	●	●	●	○	○	
2014	Freemont	PCM	○	●	●	●	●	●	●	042A 03F8 03F6 03F9 03F7 03FA 042B 04EE 04EF 0127 03F3 0140 0126 0411 0404 0402 040A 0400 0128 042C 03FB 03F4 0406 040C 040E 03B8 04ED 013C 012C 012D 0410 04F1 04EC 0429 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 012B 04F2 0408 0409 053F 0551 054E 0431 0042 0430 0049 042F 03D2 042E 0432 042D 031D 03D8
2014	Freemont	TCM	○	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 047D 0175
2014	Freemont	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2014	Wrangler	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2014	Wrangler	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2014	Wrangler	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Wrangler	ABS	○	●	●	●	●	●	●	03AB 0002
2014	Wrangler	SAS	○	●	●	●	○	○	○	
2014	Wrangler	PCM	○	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 04EC 0551 0386 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 0042 02BA 0428 0424 0049 0423 0427 03D2 0425 031D 0447 013B
2014	Wrangler	ITM	○	●	●	●	●	●	●	0437 03CF 0449 0436 0385
2014	Wrangler	ORC	○	●	●	●	●	○	●	03CC 02A1 0122 03CD
2014	Wrangler	CCN	○	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2014	Wrangler	ESM	○	●	●	●	●	●	○	
2014	Wrangler	AMP	○	●	●	●	●	○	●	006D 0068
2014	Wrangler	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A1 03A2
2014	Wrangler	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 04B1 039F 04A1
2014	Wrangler	HFM	○	●	●	●	●	●	○	00E3
2014	Wrangler	ASBS	○	●	●	●	●	○	○	0317 0318 031A 031B 0319
2014	Wrangler	WCM	○	●	●	●	●	○	●	0233 01D2 0228 0232 0230 0231 022F 0227
2014	Sebring / 200 / Avenger	WCM	○	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 0232 0230 0231 022F 0227
2014	Sebring / 200 / Avenger	CCN	○	●	●	●	●	●	●	00BC 008F 008E 0382 038D 0090 0383
2014	Sebring / 200 / Avenger	ORC	○	●	●	●	●	○	●	03CC
2014	Sebring / 200 / Avenger	PDM	○	●	●	●	●	●	○	0306
2014	Sebring / 200 / Avenger	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2014	Sebring / 200 / Avenger	PTCM	○	●	●	●	●	○	●	0259 04A4
2014	Sebring / 200 / Avenger	PCM	○	●	●	●	●	●	●	042A 03F8 03F6 03F9 03F7 03FA 042B 04EE 04EF 0127 03F3 0140 0126 0411 0404 0402 040A 0400 0128 042C 03FB 03F4 0406 040C 040E 03B8 04ED 013C 012C 012D 0410 04EC 0551 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 054E 012B 0408 0409
2014	Sebring / 200 / Avenger	DDM	○	●	●	●	●	●	○	0306
2014	Sebring / 200 / Avenger	HFM	○	●	●	●	●	●	○	00E3
2014	Sebring / 200 / Avenger	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2014	Sebring / 200 / Avenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0214 03E7 0484 0036 02C3 0037 0389 0034 0038 003A 002E 038F 0388 0390 03A2
2014	Sebring / 200 / Avenger	SAS	○	●	●	●	○	○	○	
2014	Sebring / 200 / Avenger	ABS	○	●	●	●	●	●	●	03AB 0002
2014	Sebring / 200 / Avenger	AMP	○	●	●	●	●	○	●	006D 0068
2014	Liberty	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2014	Liberty	DMFR	○	●	●	●	●	●	○	
2014	Liberty	WCM	○	●	●	●	●	○	●	0233 01D2 03E4 0228 0232 0230 0231 022F 01DE 0227
2014	Liberty	FDCM	○	●	●	●	●	●	○	0340
2014	Liberty	SAS	○	●	●	●	○	○	○	
2014	Liberty	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2014	Liberty	SUNR	○	●	●	●	●	○	○	04A7

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Liberty	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Liberty	ABS	○	●	●	●	●	●	●	03AB 0002
2014	Liberty	CCN	○	●	●	●	●	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2014	Liberty	OCM	○	●	●	●	●	○	○	011E
2014	Liberty	ITM	○	●	●	●	●	●	●	03CF 010A 0107 0106 03CE
2014	Liberty	PCM	○	●	●	●	●	●	●	03F8 03F9 03FA 04EE 04EF 0127 03F3 0140 0126 0411 0402 040A 0400 0128 03FB 03F4 0406 040E 03B8 04ED 013C 012C 012D 04EC 0551 0386 02F9 03F1 03F0 03F2 012A 02FA 03F5 054E 012B 0409 0410 04F1 04F2 042A 03FC 03F6 03FD 03F7 03FE 042B 0404 0403 0401 042C 03FF 0407 040C 040F 040D 040B 0408
2014	Liberty	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2014	Liberty	HFM	○	●	●	●	●	●	○	00E3
2014	Liberty	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453 02EE 00BC 0114 0116 0117 0115 0119
2014	Liberty	ORC	○	●	●	●	●	○	●	03CC 03CD
2014	Liberty	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2014	Liberty	DMFL	○	●	●	●	●	●	●	
2014	Liberty	AMP	○	●	●	●	●	○	●	006D 0068
2014	Liberty	ESM	○	●	●	●	●	●	○	
2014	Cherokee	AMP	○	●	●	●	●	○	○	
2014	Cherokee	ESM	○	●	●	●	●	○	○	
2014	Cherokee	RFH	○	●	●	●	●	●	●	0443 0463 0442 051D 04F7
2014	Cherokee	DDM	○	●	●	●	●	●	●	
2014	Cherokee	AHLM	○	●	●	●	○	○	○	029F
2014	Cherokee	PLGM	○	●	●	●	●	●	○	0562
2014	Cherokee	ABS	○	●	●	●	●	○	●	0433 0513
2014	Cherokee	ACC	○	●	●	●	●	○	●	056B
2014	Cherokee	EPB	○	●	●	●	●	○	●	056C 056D
2014	Cherokee	ORC	○	●	●	●	●	●	●	02A1
2014	Cherokee	MSM	○	●	●	●	●	○	○	
2014	Cherokee	IPC	○	●	●	●	●	●	○	04B3
2014	Cherokee	PTU	○	●	●	○	○	○	○	0569
2014	Cherokee	RDM	○	●	●	○	○	○	○	056A
2014	Cherokee	ESL	○	●	●	●	●	○	●	
2014	Cherokee	TCM	○	●	●	●	●	○	●	047F 0564 0563
2014	Cherokee	PAM	○	●	●	●	●	●	●	
2014	Cherokee	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2014	Cherokee	EPS	○	●	●	●	●	○	○	051A
2014	Cherokee	EDM	○	●	●	○	○	●	○	
2014	Cherokee	LBSS	○	●	●	●	●	○	●	
2014	Cherokee	OCM	○	●	●	●	●	○	●	011E
2014	Cherokee	PDM	○	●	●	●	●	●	●	
2014	Cherokee	PCM	○	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 04ED 013C 012C 012D 0550 04EC 0551 02F9 03F1 03F0 03F2 012A 054E 012B 04F1 04F2 0430 0565 0567 0049 042F 0566 042E 042D 031D

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Cherokee	DTCM	○	●	●	●	●	●	●	0568
2014	Cherokee	SCCM	○	●	●	●	●	●	○	
2014	Cherokee	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 02DC 008F 008E 0219 0517 0519 05E6 03E7 043B 0036 049F 0389 02DD 0388 0516 04A6
2014	Cherokee	RADIO	○	●	●	●	●	●	●	
2014	Cherokee	CSWM	○	●	●	●	●	●	●	
2014	Cherokee	RBSS	○	●	●	●	●	○	●	
2014	Cherokee	ICS	○	●	●	●	●	●	●	
2014	Cherokee	FFCM	○	●	●	●	●	○	●	056F
2014	Challenger	ORC	○	●	●	●	●	○	●	02A1
2014	Challenger	CCN	○	●	●	●	●	●	●	008F 008E 0382 038D 0090 0383
2014	Challenger	PDM	○	●	●	●	●	●	○	0306
2014	Challenger	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F
2014	Challenger	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2014	Challenger	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2014	Challenger	SUNR	○	●	●	●	●	●	○	
2014	Challenger	PTS	○	●	●	●	●	○	●	02ED
2014	Challenger	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2014	Challenger	ABS	○	●	●	●	●	●	●	0433 03AB
2014	Challenger	DDM	○	●	●	●	●	●	○	0306
2014	Challenger	EOM	○	●	●	●	●	○	●	00BC
2014	Challenger	ESM	○	●	●	●	●	●	○	
2014	Challenger	PCM	○	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 04EC 0551 0386 02F9 03F1 03F0 03F2 012A 02FA 054E 012B
2014	Challenger	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0219 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A2
2014	Challenger	AMP	○	●	●	●	●	○	●	006D 0068
2014	Challenger	ADCM	○	●	●	●	●	○	○	
2014	Challenger	EPS	○	●	●	●	●	○	○	
2014	Challenger	TCM	○	●	●	●	●	○	○	038C 01F3 01F2
2014	Challenger	HFM	○	●	●	●	●	●	○	00E3
2014	Challenger	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2014	Challenger	HSM	○	●	●	●	●	●	●	
2014	Challenger	SAS	○	●	●	●	●	●	○	
2014	Charger (Post-2011)	PDM	○	●	●	●	●	●	●	
2014	Charger (Post-2011)	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	Charger (Post-2011)	ICS	○	●	●	●	●	●	○	
2014	Charger (Post-2011)	ESM	○	●	●	●	●	●	○	
2014	Charger (Post-2011)	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2014	Charger (Post-2011)	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2014	Charger (Post-2011)	TGW	○	●	●	●	●	○	●	0305 025D 050D 0446
2014	Charger (Post-2011)	IPC	○	●	●	●	●	●	○	04B3 0456
2014	Charger (Post-2011)	TCM	○	●	●	●	●	○	●	047F 038C 01F3 01F2
2014	Charger (Post-2011)	VSIM	○	●	●	●	●	●	●	
2014	Charger (Post-2011)	RFH	○	●	●	●	●	●	●	0443 0440 0442 050E 04B4 0444 043F 0445 050F

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Charger (Post-2011)	ACC	○	●	●	●	●	○	●	
2014	Charger (Post-2011)	SCCM	○	●	●	●	●	○	○	
2014	Charger (Post-2011)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2014	Charger (Post-2011)	HFM	○	●	●	●	●	○	○	00E3
2014	Charger (Post-2011)	DDM	○	●	●	●	●	●	●	
2014	Charger (Post-2011)	PCM	○	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 04EC 0551 0429 02F9 03F1 03F0 03F2 012A 02FA 054E 012B
2014	Charger (Post-2011)	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Charger (Post-2011)	HSM	○	●	●	●	●	●	●	
2014	Charger (Post-2011)	LBSS	○	●	●	●	●	○	○	
2014	Charger (Post-2011)	EPS	○	●	●	●	●	○	○	
2014	Charger (Post-2011)	DTCM	○	●	●	●	●	●	○	
2014	Charger (Post-2011)	AMP	○	●	●	●	●	○	○	006D 0068
2014	Charger (Post-2011)	ADCM	○	●	●	●	●	○	○	
2014	Charger (Post-2011)	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Charger (Post-2011)	RBSS	○	●	●	●	●	○	○	
2014	Charger (Post-2011)	ORC	○	●	●	●	●	○	●	02A1
2014	Charger (Post-2011)	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2014	300 / Magnum / Charger (Pre-2011)	TCM	○	●	●	●	●	○	●	047F 038C 01F3 01F2
2014	300 / Magnum / Charger (Pre-2011)	IPC	○	●	●	●	●	●	○	04B3 0456
2014	300 / Magnum / Charger (Pre-2011)	AFLS	○	●	●	●	●	●	○	045B
2014	300 / Magnum / Charger (Pre-2011)	RFH	○	●	●	●	●	●	●	0443 0440 0442 050E 0444 0465 043F 0445 050F
2014	300 / Magnum / Charger (Pre-2011)	ADCM	○	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	ORC	○	●	●	●	●	○	●	02A1
2014	300 / Magnum / Charger (Pre-2011)	RBSS	○	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	EPS	○	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	HFM	○	●	●	●	●	○	○	00E3
2014	300 / Magnum / Charger (Pre-2011)	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	300 / Magnum / Charger (Pre-2011)	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2014	300 / Magnum / Charger (Pre-2011)	PDM	○	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	LBSS	○	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	300 / Magnum / Charger (Pre-2011)	DDM	○	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	ACC	○	●	●	●	●	○	●	
2014	300 / Magnum / Charger (Pre-2011)	PCM	○	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 04EC 0551 0429 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 0431 0042 0430 02BD 0049 042F 03D2 042E 0432 042D 031D 03D8
2014	300 / Magnum / Charger (Pre-2011)	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	300 / Magnum / Charger (Pre-2011)	HSM	○	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	SCCM	○	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2014	300 / Magnum / Charger (Pre-2011)	AMP	○	●	●	●	●	○	○	006D 0068
2014	300 / Magnum / Charger (Pre-2011)	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	300 / Magnum / Charger (Pre-2011)	ICS	○	●	●	●	●	●	○	
2014	300 / Magnum / Charger (Pre-2011)	TGW	○	●	●	●	●	○	●	0305 025D 050D 0446
2014	300 / Magnum / Charger (Pre-2011)	ESM	○	●	●	●	●	●	○	
2014	300 / Magnum / Charger (Pre-2011)	DTCM	○	●	●	●	●	●	○	
2014	300 / Magnum / Charger (Pre-2011)	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2014	300 / Magnum / Charger (Pre-2011)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2014	Compass	ABS	○	●	●	●	●	●	●	03AB 0002 0285 0062 0485
2014	Compass	TIPMCGW	○	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2014	Compass	PCM	○	●	●	●	●	●	●	03E0 0149 03D0 04B2 03DD 03E3 03E2 03DE 03E1 012D 03D3 03DF 03D9 03DA 0049 03DB 03D4 03DC 03D2 03D6 03D8 057C 03D5 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 013C 012C 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 012B 04EE 04EF 04ED 04EC 0551 054E
2014	Compass	RADIO	○	●	●	●	●	●	●	04A1 039F 01BB 039E 025D
2014	Compass	SAS	○	●	●	●	○	○	○	
2014	Compass	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2014	Compass	WCM	○	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 0232 0230 0231 022F 0227
2014	Compass	ORC	○	●	●	●	●	○	●	03CC 03CD
2014	Compass	AMP	○	●	●	●	●	○	●	006D 0068

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Compass	CCN	○	●	●	●	●	●	●	00BC 008F 008E 0382 038D 0090 0383
2014	Compass	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2014	Compass	HFM	○	●	●	●	●	●	○	00E3
2014	Compass	TCM	○	●	●	●	●	●	●	0380 0510
2014	Compass	AWD	○	●	●	●	●	●	●	
2014	Ypsilon	HVAC	○	●	●	●	●	●	●	
2014	Ypsilon	AHM	○	●	●	●	●	●	○	
2014	Ypsilon	BCM	○	●	●	●	●	●	○	04E5 04E6
2014	Ypsilon	ORC	○	●	●	●	●	●	●	
2014	Ypsilon	IPC	○	●	●	●	●	●	○	04DB
2014	Ypsilon	TCM	○	●	●	●	○	●	●	
2014	Ypsilon	ABS	○	●	●	●	○	●	●	
2014	Ypsilon	EPS	○	●	●	●	○	○	●	
2014	Ypsilon	ECM	○	●	●	●	●	●	●	04BE 04C0 04BF
2014	Dart	IPC	○	●	●	●	●	●	●	04B3
2014	Dart	LBSS	○	●	●	●	●	●	●	
2014	Dart	ORC	○	●	●	●	●	○	●	02A1
2014	Dart	PCM	○	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 04ED 013C 012C 012D 0550 04EC 0551 02F9 03F1 03F0 03F2 012A 054E 012B 04F1 04F2 0511 0506 0509 050A 0504 0512
2014	Dart	ESM	○	●	●	●	○	○	●	
2014	Dart	RFH	○	●	●	●	●	●	●	0443 0440 0463 0442 051F 0414 051E 0444 051B 051C 051D 0445 04F7
2014	Dart	CTM	○	●	●	●	●	○	○	
2014	Dart	ICS	○	●	●	●	●	●	○	
2014	Dart	EPS	○	●	●	●	●	○	○	051A
2014	Dart	RADIO	○	●	●	●	●	●	●	
2014	Dart	EDM	○	●	●	○	○	●	○	
2014	Dart	ABS	○	●	●	●	●	○	●	0570 0434 0513 0514
2014	Dart	CSWM	○	●	●	●	●	●	●	
2014	Dart	TCM	○	●	●	●	●	●	●	0510 044D 044E 044A 044C 01EF 044B
2014	Dart	SCCM	○	●	●	●	●	○	○	
2014	Dart	OCM	○	●	●	●	●	○	●	011E
2014	Dart	PAM	○	●	●	●	●	○	○	
2014	Dart	RBSS	○	●	●	●	●	●	●	
2014	Dart	AMP	○	●	●	●	●	○	○	
2014	Dart	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 02DC 008F 008E 0219 0518 0517 0519 03E7 043B 0036 049F 0389 02DD 0388 0516 04A6
2014	Dart	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2014	Routan	DMRL	○	●	●	●	●	●	●	00B4 00B5 00B6
2014	Routan	DMFR	○	●	●	●	●	●	○	
2014	Routan	LBSS	○	●	●	●	●	○	○	
2014	Routan	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Routan	ABS	○	●	●	●	●	●	●	0433 03AB
2014	Routan	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2014	Routan	FSM	○	●	●	●	●	●	○	03AC 03AD 0346 0347
2014	Routan	PSDML	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Routan	DMRR	○	●	●	●	●	●	●	00B4 00B5 00B6
2014	Routan	PSDMR	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2014	Routan	VES2	○	●	●	●	●	●	●	
2014	Routan	RBSS	○	●	●	●	●	○	○	
2014	Routan	SAS	○	●	●	●	○	○	○	
2014	Routan	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2014	Routan	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F 0459
2014	Routan	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2014	Routan	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 003A 002E 038F 0388 0390 03A1 03A2
2014	Routan	DVD	○	●	●	●	●	○	○	
2014	Routan	ORC	○	●	●	●	●	○	●	03CC 02A1
2014	Routan	PCM	○	●	●	●	●	●	●	042A 03F6 03F7 042B 04EE 04EF 0127 03F3 0140 0126 0411 0404 040A 0128 042C 03F4 040C 03B8 04ED 013C 012C 012D 0410 04EC 0551 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 054E 012B 0408
2014	Routan	CCN	○	●	●	●	●	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2014	Routan	VES3	○	●	●	●	●	●	●	
2014	Routan	HVAC	○	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9 02EA
2014	Routan	HFM	○	●	●	●	●	●	○	00E3
2014	Routan	DMFL	○	●	●	●	●	●	●	
2014	Routan	PLGM	○	●	●	●	●	●	●	038A 038B 0342
2014	Routan	HSM	○	●	●	●	●	●	●	0412
2014	Routan	WCM	○	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245 022E
2014	Routan	AMP	○	●	●	●	●	○	●	006D 0068
2014	Routan	SUNR	○	●	●	●	●	●	○	
2014	Town & Country / Caravan	WCM	○	●	●	●	●	●	●	02A7 0414 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2014	Town & Country / Caravan	DMFL	○	●	●	●	●	●	●	
2014	Town & Country / Caravan	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB 02EA 045C 00E9 045D 045E 045F
2014	Town & Country / Caravan	ITM	○	●	●	●	●	●	●	03CF 0107 0106 03CE
2014	Town & Country / Caravan	RADIO	○	●	●	●	●	●	●	039E 01BB 025D 039F 04A1
2014	Town & Country / Caravan	ABS	○	●	●	●	●	●	●	0433 03AB
2014	Town & Country / Caravan	MSMD	○	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2014	Town & Country / Caravan	CCN	○	●	●	●	●	●	●	008C 00BC 0382 0091 0094 038D 0096 0383
2014	Town & Country / Caravan	PSDMR	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2014	Town & Country / Caravan	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Town & Country / Caravan	TIPMCGW	○	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 003A 002E 038F 0388 0390 03A1 03A2
2014	Town & Country / Caravan	PLGM	○	●	●	●	●	●	●	038A 038B 0342

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Town & Country / Caravan	PCM	○	●	●	●	●	●	●	042A 03F6 03F7 042B 04EE 04EF 0127 03F3 0140 0126 0411 0404 040A 0128 042C 03F4 040C 03B8 04ED 013C 012C 012D 0410 04EC 0551 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 054E 012B 0408 0042 02BA 0428 0424 0049 0423 0427 03D2 0425 031D 013B
2014	Town & Country / Caravan	RBSS	○	●	●	●	●	○	○	
2014	Town & Country / Caravan	AHBM	○	●	●	●	○	●	○	0066
2014	Town & Country / Caravan	PSDML	○	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2014	Town & Country / Caravan	VES3	○	●	●	●	●	●	●	
2014	Town & Country / Caravan	DMRL	○	●	●	●	●	●	●	00B4 00B5 00B6
2014	Town & Country / Caravan	ORC	○	●	●	●	●	○	●	03CC 02A1
2014	Town & Country / Caravan	HFM	○	●	●	●	●	●	○	00E3
2014	Town & Country / Caravan	SUNR	○	●	●	●	●	●	○	
2014	Town & Country / Caravan	SAS	○	●	●	●	○	○	○	
2014	Town & Country / Caravan	TPM	○	●	●	●	●	○	●	0414 0232 0230 0231 022F 0459
2014	Town & Country / Caravan	VES2	○	●	●	●	●	●	●	
2014	Town & Country / Caravan	DVD	○	●	●	●	●	○	○	
2014	Town & Country / Caravan	DMRR	○	●	●	●	●	●	●	00B4 00B5 00B6
2014	Town & Country / Caravan	AMP	○	●	●	●	●	○	●	006D 0068
2014	Town & Country / Caravan	LBSS	○	●	●	●	●	○	○	
2014	Town & Country / Caravan	HSM	○	●	●	●	●	●	●	0412
2014	Town & Country / Caravan	HIDT	○	●	●	●	●	●	○	0480
2014	Town & Country / Caravan	DMFR	○	●	●	●	●	●	○	
2014	Town & Country / Caravan	PEM	○	●	●	●	●	○	●	0443 0463 0442 0307
2014	Town & Country / Caravan	EPPM	○	●	●	●	●	○	●	047E
2014	Town & Country / Caravan	TCM	○	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 0481 0175
2014	Town & Country / Caravan	FSM	○	●	●	●	●	●	○	03AC 03AD 0346 0347
2014	ProMaster	PAM	○	●	●	●	●	○	○	
2014	ProMaster	HVAC	○	●	●	●	●	●	○	04FE
2014	ProMaster	BCM	○	●	●	●	●	●	●	003E 05E7 043B
2014	ProMaster	ABS	○	●	●	●	●	○	●	
2014	ProMaster	PCM	○	●	●	●	●	●	●	042A 03F6 03F7 042B 04EE 054F 04EF 0127 03F3 0140 0126 0575 0411 0404 040A 0128 042C 03F4 040C 04ED 013C 012C 012D 0550 0410 04EC 0551 054B 054C 02F9 03F1 03F0 03F2 012A 040D 054E 012B 0408 054A 0574 031D 05E9 0572 0565 0567 0049 03DC 055D 05E8 0554 0573 0556 0557 05EA
2014	ProMaster	ETM	○	●	●	●	●	○	●	
2014	ProMaster	ORC	○	●	●	●	●	○	●	
2014	ProMaster	TPM	○	●	●	●	●	●	●	
2014	ProMaster	TCM	○	●	●	●	○	●	●	044D 02BD 044E 044A 044C 01EF 044B
2014	ProMaster	IPC	○	●	●	●	●	●	○	
2014	Durango (Post-2011)	PLGM	○	●	●	●	●	●	○	0562
2014	Durango (Post-2011)	IPC	○	●	●	●	●	●	●	04B3 05EB
2014	Durango (Post-2011)	VES2	○	●	●	●	●	●	○	
2014	Durango (Post-2011)	EDM	○	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Durango (Post-2011)	PCM	○	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 04EC 0551 0429 02F9 03F1 03F0 03F2 012A 02FA 054E 012B
2014	Durango (Post-2011)	DTCM	○	●	●	●	●	●	●	
2014	Durango (Post-2011)	ESM	○	●	●	●	●	○	○	
2014	Durango (Post-2011)	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	Durango (Post-2011)	VES3	○	●	●	●	●	●	○	
2014	Durango (Post-2011)	AMP	○	●	●	●	●	○	○	006D 0068
2014	Durango (Post-2011)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2014	Durango (Post-2011)	ELSD	○	●	●	●	●	●	○	0474 0473
2014	Durango (Post-2011)	EPS	○	●	●	●	●	○	○	050B
2014	Durango (Post-2011)	AHLM	○	●	●	●	●	○	○	029F
2014	Durango (Post-2011)	LBSS	○	●	●	○	●	○	○	
2014	Durango (Post-2011)	RFH	○	●	●	●	●	●	●	0443 0440 0442 050E 0444 043F 0445 050F
2014	Durango (Post-2011)	DDM	○	●	●	●	●	●	●	
2014	Durango (Post-2011)	HVAC	○	●	●	●	●	●	○	00EA 03B9 02EB
2014	Durango (Post-2011)	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2014	Durango (Post-2011)	HVACR	○	●	●	●	●	●	●	00EA
2014	Durango (Post-2011)	SCCM	○	●	●	●	●	○	●	
2014	Durango (Post-2011)	TCM	○	●	●	●	●	○	●	047F
2014	Durango (Post-2011)	FFCM	○	●	●	●	●	○	○	056F
2014	Durango (Post-2011)	PDM	○	●	●	●	●	●	●	
2014	Durango (Post-2011)	ICS	○	●	●	●	●	○	○	
2014	Durango (Post-2011)	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2014	Durango (Post-2011)	ABS	○	●	●	●	●	●	●	0433 03AB 0434
2014	Durango (Post-2011)	RADIO	○	●	●	●	●	●	●	
2014	Durango (Post-2011)	HSM	○	●	●	●	●	●	●	
2014	Durango (Post-2011)	ACC	○	●	●	●	●	○	○	056B
2014	Durango (Post-2011)	RBSS	○	●	●	○	●	○	○	
2014	Durango (Post-2011)	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Durango (Post-2011)	ORC	○	●	●	●	●	○	●	03CC 02A1
2014	Grand Cherokee	ITM	○	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2014	Grand Cherokee	RBSS	○	●	●	○	●	○	○	
2014	Grand Cherokee	AFLS	○	●	●	●	●	○	●	045B
2014	Grand Cherokee	MSM	○	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	Grand Cherokee	LBSS	○	●	●	○	●	○	○	
2014	Grand Cherokee	DDM	○	●	●	●	●	●	●	
2014	Grand Cherokee	AMP	○	●	●	●	●	○	○	006D 0068
2014	Grand Cherokee	ASCM	○	●	●	●	●	○	●	046E 052D 046A 0466 0469 0468 046D 046C 0470
2014	Grand Cherokee	ELSD	○	●	●	●	●	●	○	0474 0473
2014	Grand Cherokee	ICS	○	●	●	●	●	○	○	
2014	Grand Cherokee	IPC	○	●	●	●	●	●	●	04B3 05EB
2014	Grand Cherokee	PTS	○	●	●	●	●	●	●	02ED 03B7
2014	Grand Cherokee	EPS	○	●	●	●	●	○	○	
2014	Grand Cherokee	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2014	Grand Cherokee	ABS	○	●	●	●	●	●	●	0433 03AB 0434

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Grand Cherokee	VES3	○	●	●	●	●	●	○	
2014	Grand Cherokee	SCCM	○	●	●	●	●	○	●	
2014	Grand Cherokee	FFCM	○	●	●	●	●	○	○	056F
2014	Grand Cherokee	PCM	○	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 04EC 0551 0429 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 0149 055C 055B 0431 05E1 0430 0560 0049 03DC 03D2 05E2 055D 05DF 0432 042D 055A 0555 05E0 0554 0558 0556 0557 031D 03D8
2014	Grand Cherokee	RFH	○	●	●	●	●	●	●	0443 0440 0442 050E 0444 0465 043F 0445 050F
2014	Grand Cherokee	ADCM	○	●	●	●	●	○	○	
2014	Grand Cherokee	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 038F 022D 03C0
2014	Grand Cherokee	ESM	○	●	●	●	●	○	○	
2014	Grand Cherokee	ORC	○	●	●	●	●	○	●	03CC 02A1
2014	Grand Cherokee	TCM	○	●	●	●	●	○	●	047F
2014	Grand Cherokee	DTCM	○	●	●	●	●	●	●	
2014	Grand Cherokee	RADIO	○	●	●	●	●	●	●	
2014	Grand Cherokee	HSM	○	●	●	●	●	●	●	
2014	Grand Cherokee	VES2	○	●	●	●	●	●	○	
2014	Grand Cherokee	EDM	○	●	●	●	●	●	○	
2014	Grand Cherokee	PDM	○	●	●	●	●	●	●	
2014	Grand Cherokee	PLGM	○	●	●	●	●	●	○	0562
2014	Grand Cherokee	HVAC	○	●	●	●	●	●	○	00EA 03B9 02EB
2014	Grand Cherokee	ACC	○	●	●	●	●	○	○	056B
2014	Viper (Post-2013)	ICS	○	●	●	●	●	●	●	
2014	Viper (Post-2013)	DDM	○	●	●	●	●	●	●	
2014	Viper (Post-2013)	PDM	○	●	●	●	●	●	●	
2014	Viper (Post-2013)	AMP	○	●	●	●	●	○	○	006D 0068
2014	Viper (Post-2013)	PCM	○	●	●	●	●	●	○	013E 0411 0193 04AC 04AB 012C 012D 0429 04AA 012A 0540 012B 03F4
2014	Viper (Post-2013)	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 038F 022D
2014	Viper (Post-2013)	OCM	○	●	●	●	●	○	○	011E
2014	Viper (Post-2013)	ORC	○	●	●	●	●	●	●	02A1
2014	Viper (Post-2013)	TPM	○	●	●	●	●	○	●	0435 0232 0230 0231 022F
2014	Viper (Post-2013)	ABS	○	●	●	●	●	●	●	
2014	Viper (Post-2013)	IPC	○	●	●	●	●	●	●	04B3
2014	Viper (Post-2013)	ADCM	○	●	●	●	●	○	○	
2014	Viper (Post-2013)	SCCM	○	●	●	●	●	○	○	
2014	Viper (Post-2013)	RADIO	○	●	●	●	●	●	●	
2014	Viper (Post-2013)	RFH	○	●	●	●	●	●	●	0440 0442 0444 043F 0445
2014	Viper (Post-2013)	HVAC	○	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2015	4C	ORC	○	▲	▲	▲	▲	○	▲	
2015	4C	PCM	○	▲	▲	▲	▲	▲	▲	0140 012B
2015	4C	BCM	○	▲	▲	▲	▲	▲	▲	04E5 04E6
2015	4C	TCM	○	▲	▲	▲	▲	▲	▲	
2015	4C	IPC	○	▲	▲	▲	▲	▲	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	4C	ABS	○	▲	▲	▲	▲	▲	▲	0514
2015	4C	PAM	○	▲	▲	▲	▲	○	○	
2015	4C	TPM	○	▲	▲	▲	○	○	▲	
2015	Fiat 500L	IPC	○	▲	▲	▲	○	▲	○	
2015	Fiat 500L	HVAC	○	▲	▲	▲	▲	▲	○	04FE
2015	Fiat 500L	PCM	○	▲	▲	▲	▲	▲	▲	0511 0506 012C 012D 0509 0140 0504 012B 0512
2015	Fiat 500L	ESM	○	▲	▲	▲	▲	▲	▲	
2015	Fiat 500L	TPM	○	▲	▲	▲	▲	▲	▲	
2015	Fiat 500L	ETM	○	▲	▲	▲	▲	○	▲	
2015	Fiat 500L	ORC	○	▲	▲	▲	▲	○	▲	
2015	Fiat 500L	BCM	○	▲	▲	▲	▲	▲	▲	0543 0599 04E5
2015	Fiat 500L	EPS	○	▲	▲	▲	▲	○	○	
2015	Fiat 500L	PAM	○	▲	▲	▲	▲	○	○	
2015	Fiat 500L	TCM	○	▲	▲	▲	▲	▲	▲	044E 044D 044A 044C 01EF 044B
2015	Fiat 500L	ABS	○	▲	▲	▲	▲	○	▲	
2015	Forza	IPC	○	▲	▲	▲	○	▲	○	04E6 0586 0587
2015	Forza	ORC	○	▲	▲	▲	○	▲	○	
2015	BU	PAM	○	▲	▲	▲	▲	○	○	
2015	BU	HALF	○	▲	▲	▲	▲	○	▲	
2015	BU	ABS	○	▲	▲	▲	○	▲	▲	05C7 04EA 05C6
2015	BU	LBSS	○	▲	▲	▲	▲	▲	○	
2015	BU	AMP	○	▲	▲	▲	▲	▲	▲	
2015	BU	IPC	○	▲	▲	▲	▲	▲	▲	05C9
2015	BU	BCM	○	▲	▲	▲	▲	▲	▲	04E5 05A3 0541 05A2 05A0 059E 059D 059C
2015	BU	ORC	○	▲	▲	▲	▲	○	▲	
2015	BU	RRM	○	▲	▲	▲	▲	▲	▲	
2015	BU	TCM	○	▲	▲	▲	▲	○	○	
2015	BU	HVAC	○	▲	▲	▲	▲	▲	▲	05C5
2015	BU	EPS	○	▲	▲	▲	○	○	▲	
2015	BU	ECM	○	▲	▲	▲	▲	▲	▲	04B9 05C3 04D2 05AF 05C4 05B0 04BF 05B9 05BA 05BB 05BC 02B9 05C2 05B4 05B5 05BF 05B8 04BE 04C6 05B1 04C0 05B6 05B7 05BD 05B2 05B3 05C1 05AE 05AC 05BE 05C0
2015	BU	ETM	○	▲	▲	▲	▲	▲	▲	
2015	BU	DTCM	○	▲	▲	▲	▲	○	○	
2015	BU	TTM	○	▲	▲	▲	▲	▲	○	
2015	BU	CSWM	○	▲	▲	▲	○	▲	○	
2015	BU	RFH	○	▲	▲	▲	▲	▲	○	05D2 05D7 05D5 05D0 05D1 05D6 05D3 0443 05D8 05D9
2015	BU	ESM	○	▲	▲	▲	▲	▲	▲	
2015	BU	ESL	○	▲	▲	○	○	○	○	
2015	BU	RBSS	○	▲	▲	▲	▲	▲	○	
2015	BU	ACC	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Pickup	IPC	○	▲	▲	▲	▲	▲	▲	04B3 0456 0530
2015	Ram 3500 Pickup	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Pickup	PDM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Pickup	ASCM	○	▲	▲	▲	▲	○	▲	052D 0466 0469 0468 046D 0470

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Ram 3500 Pickup	PCM	○	▲	▲	▲	▲	▲	▲	03FC 03FD 03FE 04EE 054F 04F0 04EF 0127 03F3 0140 0126 0411 0403 040A 0401 0128 03FF 03F4 0407 040F 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 0429 054B 054C 02F9 03F1 03F0 03F2 012A 02FA 040B 054E 012B 04F2 0525 0521 0526 03EC 0523 0524 03C7 0313 0528 0552 0491 04AF 03CB 0522 0478 0477 05EC 039A 0527
2015	Ram 3500 Pickup	MSM	○	▲	▲	▲	▲	▲	▲	0455 0451 0454 044F 0452 0450 0453
2015	Ram 3500 Pickup	ORC	○	▲	▲	▲	▲	▲	▲	02A1
2015	Ram 3500 Pickup	ITBM	○	▲	▲	▲	▲	○	○	
2015	Ram 3500 Pickup	HSM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Pickup	TCM	○	▲	▲	▲	▲	▲	▲	01EF
2015	Ram 3500 Pickup	DTCM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Pickup	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Pickup	VGT	○	▲	▲	○	○	○	○	
2015	Ram 3500 Pickup	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D 0553
2015	Ram 3500 Pickup	RFH	○	▲	▲	▲	▲	▲	▲	0443 0463 0442 052A 0414 051E 0444 043F 051B 051D 0445 052B
2015	Ram 3500 Pickup	EDM	○	▲	▲	▲	▲	▲	○	
2015	Ram 3500 Pickup	ICS	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Pickup	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2015	Ram 3500 Pickup	SCCM	○	▲	▲	▲	▲	○	○	
2015	Ram 3500 Pickup	VSIM	○	▲	▲	▲	▲	▲	○	
2015	Ram 3500 Pickup	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	Ram 3500 Pickup	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB
2015	Ram 3500 Pickup	DCU	○	▲	▲	○	○	○	○	
2015	Ram 3500 Pickup	PTS	○	▲	▲	▲	▲	▲	▲	02ED 03B7
2015	Ram 3500 Cab Chassis	PCM	○	▲	▲	▲	▲	▲	▲	0525 0521 0526 03EC 0523 0524 03C7 0411 03F4 012D 0313 0528 0552 052F 0491 04AF 03CB 03C8 052E 0478 0477 03EF 05EC 039A 0527 03FC 03FD 03FE 04EE 054F 04F0 04EF 0127 03F3 0140 0126 0403 040A 0401 0128 03FF 0407 040F 03B8 04ED 013C 012C 0550 0410 04F1 04EC 0551 0429 054B 054C 02F9 03F1 03F0 03F2 012A 02FA 040B 054E 012B 04F2
2015	Ram 3500 Cab Chassis	DCU	○	▲	▲	○	○	○	○	
2015	Ram 3500 Cab Chassis	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Cab Chassis	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Cab Chassis	EDM	○	▲	▲	▲	▲	▲	○	
2015	Ram 3500 Cab Chassis	PDM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Cab Chassis	MSM	○	▲	▲	▲	▲	▲	▲	0455 0451 0454 044F 0452 0450 0453
2015	Ram 3500 Cab Chassis	SCCM	○	▲	▲	▲	▲	○	○	
2015	Ram 3500 Cab Chassis	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2015	Ram 3500 Cab Chassis	TCM	○	▲	▲	▲	▲	▲	▲	01EF
2015	Ram 3500 Cab Chassis	ICS	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Cab Chassis	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	Ram 3500 Cab Chassis	ITBM	○	▲	▲	▲	▲	○	○	
2015	Ram 3500 Cab Chassis	VGT	○	▲	▲	○	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Ram 3500 Cab Chassis	RFH	○	▲	▲	▲	▲	▲	▲	0443 0463 0442 052A 0414 051E 0444 043F 051B 051D 0445 052B
2015	Ram 3500 Cab Chassis	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 0553 038F 022D 03C0
2015	Ram 3500 Cab Chassis	ORC	○	▲	▲	▲	▲	▲	▲	02A1
2015	Ram 3500 Cab Chassis	HSM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Cab Chassis	VSIM	○	▲	▲	▲	▲	▲	○	
2015	Ram 3500 Cab Chassis	PTS	○	▲	▲	▲	▲	▲	▲	02ED 03B7
2015	Ram 3500 Cab Chassis	DTCM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 3500 Cab Chassis	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB
2015	Ram 3500 Cab Chassis	IPC	○	▲	▲	▲	▲	▲	▲	04B3 0456 0530
2015	Ram 2500	VSIM	○	▲	▲	▲	▲	▲	○	
2015	Ram 2500	SCCM	○	▲	▲	▲	▲	○	○	
2015	Ram 2500	VGT	○	▲	▲	○	○	○	○	
2015	Ram 2500	HSM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 2500	EDM	○	▲	▲	▲	▲	▲	○	
2015	Ram 2500	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 0553 038F 022D 03C0
2015	Ram 2500	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 2500	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB
2015	Ram 2500	RFH	○	▲	▲	▲	▲	▲	▲	0443 0463 0442 052A 0414 051E 0444 043F 051B 051D 0445 052B
2015	Ram 2500	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2015	Ram 2500	ASCM	○	▲	▲	▲	▲	○	▲	052D 0466 0469 0468 046D 0470
2015	Ram 2500	PCM	○	▲	▲	▲	▲	▲	▲	03FC 03FD 03FE 04EE 054F 04F0 04EF 0127 03F3 0140 0126 0411 0403 040A 0401 0128 03FF 03F4 0407 040F 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 0429 054B 054C 02F9 03F1 03F0 03F2 012A 02FA 040B 054E 012B 04F2 0525 0521 0526 03EC 0523 0524 03C7 0313 0528 0552 0491 04AF 03CB 0522 0478 0477 05EC 039A 0527
2015	Ram 2500	FDCM	○	▲	▲	▲	▲	○	○	
2015	Ram 2500	TCM	○	▲	▲	▲	▲	▲	▲	01EF
2015	Ram 2500	DCU	○	▲	▲	○	○	○	○	
2015	Ram 2500	PTS	○	▲	▲	▲	▲	▲	▲	02ED 03B7
2015	Ram 2500	ICS	○	▲	▲	▲	▲	▲	▲	
2015	Ram 2500	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	Ram 2500	ITBM	○	▲	▲	▲	▲	○	○	
2015	Ram 2500	MSM	○	▲	▲	▲	▲	▲	▲	0455 0451 0454 044F 0452 0450 0453
2015	Ram 2500	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	Ram 2500	IPC	○	▲	▲	▲	▲	▲	▲	04B3 0456 0530
2015	Ram 2500	DTCM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 2500	ORC	○	▲	▲	▲	▲	▲	▲	02A1
2015	Ram 2500	PDM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 4500/5500	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	Ram 4500/5500	TCM	○	▲	▲	▲	▲	▲	▲	01EF
2015	Ram 4500/5500	ICS	○	▲	▲	▲	▲	▲	▲	
2015	Ram 4500/5500	DCU	○	▲	▲	○	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Ram 4500/5500	ITBM	○	▲	▲	▲	▲	○	○	
2015	Ram 4500/5500	DTCM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 4500/5500	RFH	○	▲	▲	▲	▲	▲	▲	0443 0463 0442 052A 0414 051E 0444 043F 051B 051D 0445 052B
2015	Ram 4500/5500	ORC	○	▲	▲	▲	▲	▲	▲	02A1
2015	Ram 4500/5500	VSIM	○	▲	▲	▲	▲	▲	○	
2015	Ram 4500/5500	VGT	○	▲	▲	○	○	○	○	
2015	Ram 4500/5500	PDM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 4500/5500	EDM	○	▲	▲	▲	▲	▲	○	
2015	Ram 4500/5500	SCCM	○	▲	▲	▲	▲	○	○	
2015	Ram 4500/5500	IPC	○	▲	▲	▲	▲	▲	▲	04B3 0456 0530
2015	Ram 4500/5500	PTS	○	▲	▲	▲	▲	▲	▲	02ED 03B7
2015	Ram 4500/5500	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 0553 038F 022D 03C0
2015	Ram 4500/5500	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB
2015	Ram 4500/5500	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 4500/5500	MSM	○	▲	▲	▲	▲	▲	▲	0455 0451 0454 044F 0452 0450 0453
2015	Ram 4500/5500	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	Ram 4500/5500	HSM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 4500/5500	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2015	Ram 4500/5500	PCM	○	▲	▲	▲	▲	▲	▲	03FC 03FD 03FE 04EE 054F 04F0 04EF 0127 03F3 0140 0126 0411 0403 040A 0401 0128 03FF 03F4 0407 040F 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 0429 054B 054C 02F9 03F1 03F0 03F2 012A 02FA 040B 054E 012B 04F2 0525 0521 0526 03EC 0523 0524 03C7 0313 0528 0552 052F 0491 04AF 03CB 03C8 052E 0478 0477 03EF 05EC 039A 0527
2015	Ram 1500	ASCM	○	▲	▲	▲	▲	○	▲	046E 052D 046A 0466 0469 0468 046D 046C 0470
2015	Ram 1500	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D 0553
2015	Ram 1500	ESM	○	▲	▲	▲	▲	○	○	
2015	Ram 1500	PDM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 1500	ITBM	○	▲	▲	▲	▲	○	○	
2015	Ram 1500	HSM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 1500	IPC	○	▲	▲	▲	▲	▲	▲	04B3 0456
2015	Ram 1500	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB
2015	Ram 1500	RFH	○	▲	▲	▲	▲	▲	▲	0443 0463 0442 052A 0414 051E 0444 043F 051B 051D 0445 052B
2015	Ram 1500	DTCM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 1500	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2015	Ram 1500	PTS	○	▲	▲	▲	▲	▲	▲	02ED 03B7
2015	Ram 1500	PCM	○	▲	▲	▲	▲	▲	▲	03FC 03FD 03FE 04EE 054F 04F0 04EF 0127 03F3 0140 0126 0411 0403 040A 0401 0128 03FF 03F4 0407 040F 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 0429 054B 054C 02F9 03F1 03F0 03F2 012A 02FA 040B 054E 012B 04F2 055F 0149 055C 055B 0431 05E1 0430 0560 05E4 0049 03DC 055E 05E2 055D 05DF 0432 042D 055A 0555 05E0 0554 0558 0556 0557 031D 03D8

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Ram 1500	ICS	○	▲	▲	▲	▲	▲	▲	
2015	Ram 1500	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Ram 1500	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	Ram 1500	TCM	○	▲	▲	▲	▲	○	▲	047F
2015	Ram 1500	SCCM	○	▲	▲	▲	▲	○	○	
2015	Ram 1500	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	Ram 1500	EDM	○	▲	▲	▲	▲	▲	○	
2015	Ram 1500	ORC	○	▲	▲	▲	▲	▲	▲	02A1
2015	Ram 1500	EPS	○	▲	▲	▲	▲	○	○	050B
2015	Ram 1500	MSM	○	▲	▲	▲	▲	▲	▲	0455 0451 0454 044F 0452 0450 0453
2015	Ram 1500	VSIM	○	▲	▲	▲	▲	▲	○	
2015	Vision	IPC	○	▲	▲	▲	▲	▲	○	0586 0587
2015	Vision	BCM	○	▲	▲	▲	▲	▲	○	
2015	Vision	ORC	○	▲	▲	▲	○	▲	○	
2015	Ram (Mexico)	ORC	○	▲	▲	▲	▲	▲	▲	02A1
2015	Ram (Mexico)	ESM	○	▲	▲	▲	▲	○	○	
2015	Ram (Mexico)	SCCM	○	▲	▲	▲	▲	○	○	
2015	Ram (Mexico)	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB
2015	Ram (Mexico)	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Ram (Mexico)	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	Ram (Mexico)	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 0553 038F 022D 03C0
2015	Ram (Mexico)	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2015	Ram (Mexico)	EDM	○	▲	▲	▲	▲	▲	○	
2015	Ram (Mexico)	PTS	○	▲	▲	▲	▲	▲	▲	02ED 03B7
2015	Ram (Mexico)	PCM	○	▲	▲	▲	▲	▲	▲	03FC 03FD 03FE 0525 0521 0526 03EC 0523 0524 03C7 0411 0403 03FF 03F4 0407 040F 012D 0313 0528 0552 052F 0491 04AF 03CB 03C8 052E 0522 0478 0477 03EF 05EC 039A 0527 04EE 054F 04F0 04EF 0127 03F3 0140 0126 040A 0401 0128 03B8 04ED 013C 012C 0550 0410 04F1 04EC 0551 0429 054B 054C 02F9 03F1 03F0 03F2 012A 02FA 040B 054E 012B 04F2
2015	Ram (Mexico)	ITBM	○	▲	▲	▲	▲	○	○	
2015	Ram (Mexico)	VGT	○	▲	▲	○	○	○	○	
2015	Ram (Mexico)	HSM	○	▲	▲	▲	▲	▲	▲	
2015	Ram (Mexico)	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	Ram (Mexico)	DTCM	○	▲	▲	▲	▲	▲	▲	
2015	Ram (Mexico)	ASCM	○	▲	▲	▲	▲	○	▲	046E 052D 046A 0466 0469 0468 046D 046C 0470
2015	Ram (Mexico)	VSIM	○	▲	▲	▲	▲	▲	○	
2015	Ram (Mexico)	ICS	○	▲	▲	▲	▲	▲	▲	
2015	Ram (Mexico)	DCU	○	▲	▲	○	○	○	○	
2015	Ram (Mexico)	TCM	○	▲	▲	▲	▲	▲	▲	01EF 047F
2015	Ram (Mexico)	MSM	○	▲	▲	▲	▲	▲	▲	0455 0451 0454 044F 0452 0450 0453
2015	Ram (Mexico)	PDM	○	▲	▲	▲	▲	▲	▲	
2015	Ram (Mexico)	RFH	○	▲	▲	▲	▲	▲	▲	0443 0463 0442 052A 0414 051E 0444 043F 051B 051D 0445 052B
2015	Ram (Mexico)	IPC	○	▲	▲	▲	▲	▲	▲	04B3 0456
2015	Ram (Mexico)	EPS	○	▲	▲	▲	▲	○	○	050B

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	500	PCM	○	▲	▲	▲	▲	▲	▲	04C2 0507
2015	500	TCM	○	▲	▲	▲	▲	▲	○	044D 02BD 044E 044A 04FA 044C 01EF 044B
2015	500	ABS	○	▲	▲	▲	▲	▲	○	04F4
2015	500	VTM	○	▲	▲	▲	▲	○	○	
2015	500	PIM	○	▲	▲	▲	▲	○	○	
2015	500	TPM	○	▲	▲	▲	▲	▲	▲	
2015	500	RADIO	○	▲	▲	▲	▲	○	○	
2015	500	ESM	○	▲	▲	○	▲	○	○	
2015	500	ORC	○	▲	▲	▲	▲	○	▲	
2015	500	RBC	○	▲	▲	▲	▲	○	○	0533 0002 0534 0532 0531
2015	500	BCM	○	▲	▲	▲	▲	▲	▲	
2015	500	PCM	○	▲	▲	▲	▲	▲	▲	0511 0506 012C 012D 0509 0140 0504 012B 0512
2015	500	EVCU	○	▲	▲	▲	▲	▲	○	053C 053D 053A 0539 053E 053B
2015	500	BPCM	○	▲	▲	▲	▲	▲	○	
2015	500	EPS	○	▲	▲	▲	▲	○	○	050B 050C
2015	500	EAC	○	▲	▲	▲	▲	○	○	
2015	500	CTM	○	▲	▲	▲	○	▲	○	
2015	500	PTS	○	▲	▲	▲	▲	○	○	
2015	500	OBCM	○	▲	▲	▲	▲	○	○	
2015	500	HVAC	○	▲	▲	▲	▲	▲	○	04FE
2015	500	IPC	○	▲	▲	▲	▲	▲	○	04FB 04DB
2015	Wrangler (Export)	CCN	○	▲	▲	▲	▲	▲	○	008C 00BC 0382 0091 0094 038D 0096 0383
2015	Wrangler (Export)	WCM	○	▲	▲	▲	▲	○	▲	0233 01D2 0228 0232 0230 0231 022F 0227
2015	Wrangler (Export)	ABS	○	▲	▲	▲	▲	▲	▲	03AB 0002
2015	Wrangler (Export)	TIPMCGW	○	▲	▲	▲	▲	▲	▲	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A1 03A2
2015	Wrangler (Export)	ESM	○	▲	▲	▲	▲	▲	○	
2015	Wrangler (Export)	SAS	○	▲	▲	▲	○	○	○	
2015	Wrangler (Export)	PCM	○	▲	▲	▲	▲	▲	▲	0042 012D 02BA 0428 0424 0049 0423 0427 03D2 0425 031D 0447 013B
2015	Wrangler (Export)	ORC	○	▲	▲	▲	▲	○	▲	03CC 02A1 0122 03CD
2015	Wrangler (Export)	TCM	○	▲	▲	▲	▲	○	○	038C 01F3 01F2
2015	Wrangler (Export)	RADIO	○	▲	▲	▲	▲	▲	▲	04A1 039F 01BB 039E 025D
2015	Wrangler (Export)	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 03A9 02EB
2015	Journey	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB
2015	Journey	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2015	Journey	TGW	○	▲	▲	▲	▲	○	▲	0305 025D 050D 0446
2015	Journey	PTS	○	▲	▲	▲	▲	▲	▲	02ED 03B7
2015	Journey	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	Journey	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2015	Journey	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Journey	RFH	○	▲	▲	▲	▲	▲	▲	0443 0440 0442 050E 0441 0444 043F 0445 050F
2015	Journey	SCCM	○	▲	▲	▲	▲	○	○	
2015	Journey	TCM	○	▲	▲	▲	▲	▲	▲	047C 0479 047A 047B 042C 0410 047D 0175
2015	Journey	PDM	○	▲	▲	▲	▲	▲	▲	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Journey	VES3	○	▲	▲	▲	▲	▲	○	
2015	Journey	DTCM	○	▲	▲	▲	▲	▲	▲	
2015	Journey	ITM	○	▲	▲	▲	▲	▲	▲	0107 0437 0104 03CE 0436
2015	Journey	ICS	○	▲	▲	▲	▲	▲	○	
2015	Journey	TPM	○	▲	▲	▲	▲	○	▲	0435 0232 0230 0231 022F
2015	Journey	VTM	○	▲	▲	▲	▲	○	○	
2015	Journey	HSM	○	▲	▲	▲	▲	▲	▲	
2015	Journey	HFM	○	▲	▲	▲	▲	○	○	00E3
2015	Journey	PCM	○	▲	▲	▲	▲	▲	▲	042A 03F8 03F6 03F9 03F7 03FA 042B 04EE 04F0 04EF 0127 03F3 0140 0126 0411 0404 0402 040A 0400 0128 042C 03FB 03F4 0406 040C 040E 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 0381 0429 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 054E 012B 04F2 0408 0409 0431 0042 0430 0049 042F 03D2 042E 0432 042D 031D 03D8 053F
2015	Journey	EPPM	○	▲	▲	▲	▲	○	▲	047E
2015	Journey	IPC	○	▲	▲	▲	▲	▲	○	04B3
2015	Journey	ORC	○	▲	▲	▲	▲	○	▲	02A1 0122
2015	Freemont	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2015	Freemont	HFM	○	▲	▲	▲	▲	○	○	00E3
2015	Freemont	RFH	○	▲	▲	▲	▲	▲	▲	0443 0440 0442 0441 0444 043F 0445 050E 050F
2015	Freemont	ORC	○	▲	▲	▲	▲	○	▲	02A1 0122
2015	Freemont	PDM	○	▲	▲	▲	▲	▲	▲	
2015	Freemont	TPM	○	▲	▲	▲	▲	○	▲	0435 0232 0230 0231 022F
2015	Freemont	IPC	○	▲	▲	▲	▲	▲	○	04B3
2015	Freemont	PCM	○	▲	▲	▲	▲	▲	▲	0431 012D 0042 0430 0049 042F 03D2 042E 0432 042D 031D 03D8 042A 03F8 03F6 03F9 03F7 03FA 042B 04EE 04F0 04EF 0127 03F3 0140 0126 0411 0404 0402 040A 0400 0128 042C 03FB 03F4 0406 040C 040E 03B8 04ED 013C 012C 0550 0410 04F1 04EC 0551 0381 0429 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 054E 012B 04F2 0408 0409 053F
2015	Freemont	DTCM	○	▲	▲	▲	▲	▲	▲	
2015	Freemont	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2015	Freemont	HSM	○	▲	▲	▲	▲	▲	▲	
2015	Freemont	SCCM	○	▲	▲	▲	▲	○	○	
2015	Freemont	TGW	○	▲	▲	▲	▲	○	▲	0305 025D 050D 0446
2015	Freemont	VTM	○	▲	▲	▲	▲	○	○	
2015	Freemont	ITM	○	▲	▲	▲	▲	▲	▲	0107 0437 0104 03CE 0436
2015	Freemont	VES3	○	▲	▲	▲	▲	▲	○	
2015	Freemont	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB
2015	Freemont	TCM	○	▲	▲	▲	▲	▲	▲	047C 0479 047A 047B 042C 0410 047D 0175
2015	Freemont	ICS	○	▲	▲	▲	▲	▲	○	
2015	Freemont	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	Freemont	EPPM	○	▲	▲	▲	▲	○	▲	047E
2015	Freemont	PTS	○	▲	▲	▲	▲	▲	▲	02ED 03B7
2015	Freemont	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Wrangler	AMP	○	▲	▲	▲	▲	○	▲	006D 0068

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Wrangler	TCM	○	▲	▲	▲	▲	○	○	038C 01F3 01F2
2015	Wrangler	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 03A9 02EB
2015	Wrangler	TIPMCGW	○	▲	▲	▲	▲	▲	▲	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 002E 038F 0388 0390 03A1 03A2
2015	Wrangler	ESM	○	▲	▲	▲	▲	▲	○	
2015	Wrangler	SAS	○	▲	▲	▲	○	○	○	
2015	Wrangler	ORC	○	▲	▲	▲	▲	○	▲	03CC 02A1 0122 03CD
2015	Wrangler	HFM	○	▲	▲	▲	▲	▲	○	00E3
2015	Wrangler	TPM	○	▲	▲	▲	▲	○	▲	0414 0232 0230 0231 022F
2015	Wrangler	CCN	○	▲	▲	▲	▲	▲	○	008C 00BC 0382 0091 0094 038D 0096 0383
2015	Wrangler	ABS	○	▲	▲	▲	▲	▲	▲	03AB 0002
2015	Wrangler	ITM	○	▲	▲	▲	▲	▲	▲	0437 03CF 0449 0436 0385
2015	Wrangler	RADIO	○	▲	▲	▲	▲	▲	▲	04A1 039F 01BB 039E 025D 04B1
2015	Wrangler	WCM	○	▲	▲	▲	▲	○	▲	0233 01D2 0228 0232 0230 0231 022F 0227
2015	Wrangler	ASBS	○	▲	▲	▲	▲	○	○	0317 0318 031A 031B 0319
2015	Wrangler	PCM	○	▲	▲	▲	▲	▲	▲	04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 0381 0386 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 04F2 0042 02BA 0428 0424 0049 0423 0427 03D2 0425 031D 0447 013B
2015	Liberty	HFM	○	▲	▲	▲	▲	▲	○	00E3
2015	Liberty	ITM	○	▲	▲	▲	▲	▲	▲	03CF 010A 0107 0106 03CE
2015	Liberty	PCM	○	▲	▲	▲	▲	▲	▲	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 03F5 040B 012B 0408 0409 04EE 04EF 04ED 04EC 0551 054E 04F1 04F2
2015	Liberty	DMFL	○	▲	▲	▲	▲	▲	▲	
2015	Liberty	SUNR	○	▲	▲	▲	▲	○	○	04A7
2015	Liberty	FDCM	○	▲	▲	▲	▲	▲	○	0340
2015	Liberty	ABS	○	▲	▲	▲	▲	▲	▲	03AB 0002
2015	Liberty	WCM	○	▲	▲	▲	▲	○	▲	0233 01D2 03E4 0228 0232 0230 0231 022F 01DE 0227
2015	Liberty	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 00E9 03A9 02EB 03B9
2015	Liberty	RADIO	○	▲	▲	▲	▲	▲	▲	039E 01BB 025D 039F 04A1
2015	Liberty	AMP	○	▲	▲	▲	▲	○	▲	006D 0068
2015	Liberty	SAS	○	▲	▲	▲	○	○	○	
2015	Liberty	TIPMCGW	○	▲	▲	▲	▲	▲	▲	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 003F 0036 0037 0389 0038 003A 002E 021F 038F 0388 0390 03A1 03A2
2015	Liberty	MSMD	○	▲	▲	▲	▲	▲	▲	02EE 00BC 0114 044F 0116 0117 0115 0119 0455 0451 0450 0454 0452 0453
2015	Liberty	OCM	○	▲	▲	▲	▲	○	○	011E
2015	Liberty	ORC	○	▲	▲	▲	▲	○	▲	03CC 03CD
2015	Liberty	DMFR	○	▲	▲	▲	▲	▲	○	
2015	Liberty	ESM	○	▲	▲	▲	▲	▲	○	
2015	Liberty	CCN	○	▲	▲	▲	▲	▲	▲	008C 00BC 0382 0091 0094 038D 0096 0383

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Liberty	TCM	○	▲	▲	▲	▲	○	○	038C 01F3 01F2
2015	Liberty	PTS	○	▲	▲	▲	▲	▲	▲	02ED 03B7
2015	Cherokee	CSWM	○	●	●	●	●	●	●	
2015	Cherokee	LBSS	○	●	●	●	●	○	●	
2015	Cherokee	AMP	○	●	●	●	●	○	○	
2015	Cherokee	RDM	○	●	●	○	○	○	○	056A
2015	Cherokee	ESM	○	●	●	●	●	○	○	
2015	Cherokee	TCM	○	●	●	●	●	○	●	047F 0564 0563
2015	Cherokee	FFCM	○	●	●	●	●	○	●	056F
2015	Cherokee	EPS	○	●	●	●	●	○	○	051A
2015	Cherokee	RFH	○	●	●	●	●	●	●	0443 0463 0442 051D 04F7
2015	Cherokee	HVAC	○	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2015	Cherokee	ESL	○	●	●	●	●	○	●	
2015	Cherokee	DTV	○	●	●	●	○	●	●	
2015	Cherokee	EDM	○	●	●	○	○	●	○	
2015	Cherokee	PCM	○	●	●	●	●	●	●	04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 0550 04F1 04EC 0551 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 04F2 0430 0565 0567 0049 042F 0566 042E 042D 031D
2015	Cherokee	ACC	○	●	●	●	●	○	●	056B
2015	Cherokee	AHLM	○	●	●	●	○	○	○	029F
2015	Cherokee	DTCM	○	●	●	●	●	●	●	0568
2015	Cherokee	PLGM	○	●	●	●	●	●	○	0562
2015	Cherokee	PAM	○	●	●	●	●	●	●	
2015	Cherokee	IPC	○	●	●	●	●	●	○	04B3
2015	Cherokee	ABS	○	●	●	●	●	○	●	0433 0513
2015	Cherokee	DDM	○	●	●	●	●	●	●	
2015	Cherokee	SCCM	○	●	●	●	●	●	○	
2015	Cherokee	RBSS	○	●	●	●	●	○	●	
2015	Cherokee	ICS	○	●	●	●	●	●	●	
2015	Cherokee	MSM	○	●	●	●	●	○	○	
2015	Cherokee	BCM	○	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 02DC 008F 008E 0219 05ED 0517 0519 05E6 03E7 043B 0036 049F 0389 02DD 0388 0516 04A6
2015	Cherokee	ORC	○	●	●	●	●	●	●	02A1
2015	Cherokee	PDM	○	●	●	●	●	●	●	
2015	Cherokee	EPB	○	●	●	●	●	○	●	056C 056D
2015	Cherokee	PTU	○	●	●	○	○	○	○	0569
2015	Cherokee	RADIO	○	●	●	●	●	●	●	
2015	Cherokee	OCM	○	●	●	●	●	○	●	011E
2015	Challenger	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	Challenger	LBSS	○	▲	▲	▲	▲	○	○	
2015	Challenger	ICS	○	▲	▲	▲	▲	▲	○	
2015	Challenger	SCCM	○	▲	▲	▲	▲	○	▲	
2015	Challenger	PCM	○	▲	▲	▲	▲	▲	▲	04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 0429 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 04F2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Challenger	TCM	○	▲	▲	▲	▲	○	▲	047F
2015	Challenger	TPM	○	▲	▲	▲	▲	○	▲	0435 0232 0230 0231 022F
2015	Challenger	EPS	○	▲	▲	▲	▲	○	○	
2015	Challenger	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB
2015	Challenger	ADCM	○	▲	▲	▲	▲	○	○	
2015	Challenger	RFH	○	▲	▲	▲	▲	▲	▲	0443 0440 0442 0444 043F 0445
2015	Challenger	PDM	○	▲	▲	▲	▲	▲	▲	
2015	Challenger	PTS	○	▲	▲	▲	▲	○	▲	02ED
2015	Challenger	ESM	○	▲	▲	▲	▲	▲	○	
2015	Challenger	ORC	○	▲	▲	▲	▲	○	▲	02A1
2015	Challenger	HSM	○	▲	▲	▲	▲	▲	▲	
2015	Challenger	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2015	Challenger	RBSS	○	▲	▲	▲	▲	○	○	
2015	Challenger	ACC	○	▲	▲	▲	▲	○	○	
2015	Challenger	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	Challenger	IPC	○	▲	▲	▲	▲	▲	▲	04B3 05EB
2015	Challenger	MSM	○	▲	▲	▲	▲	▲	▲	0455 0451 0454 044F 0452 0450 0453
2015	Challenger	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2015	Challenger	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Charger (Post-2011)	MSM	○	▲	▲	▲	▲	▲	▲	0455 0451 0454 044F 0452 0450 0453
2015	Charger (Post-2011)	ESM	○	▲	▲	▲	▲	▲	○	
2015	Charger (Post-2011)	HSM	○	▲	▲	▲	▲	▲	▲	
2015	Charger (Post-2011)	IPC	○	▲	▲	▲	▲	▲	▲	04B3 05EB
2015	Charger (Post-2011)	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	Charger (Post-2011)	RBSS	○	▲	▲	▲	▲	○	○	
2015	Charger (Post-2011)	SCCM	○	▲	▲	▲	▲	○	▲	
2015	Charger (Post-2011)	FFCM	○	▲	▲	▲	▲	○	○	056F
2015	Charger (Post-2011)	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	Charger (Post-2011)	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2015	Charger (Post-2011)	PTS	○	▲	▲	▲	▲	○	▲	02ED
2015	Charger (Post-2011)	ITM	○	▲	▲	▲	▲	▲	▲	0107 0437 0104 03CE 0436
2015	Charger (Post-2011)	ACC	○	▲	▲	▲	▲	○	○	
2015	Charger (Post-2011)	RFH	○	▲	▲	▲	▲	▲	▲	0443 0440 0442 050E 04B4 0444 043F 0445 050F
2015	Charger (Post-2011)	ICS	○	▲	▲	▲	▲	▲	○	
2015	Charger (Post-2011)	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB
2015	Charger (Post-2011)	EPS	○	▲	▲	▲	▲	○	○	
2015	Charger (Post-2011)	TPM	○	▲	▲	▲	▲	○	▲	0435 0232 0230 0231 022F
2015	Charger (Post-2011)	ORC	○	▲	▲	▲	▲	○	▲	02A1
2015	Charger (Post-2011)	PCM	○	▲	▲	▲	▲	▲	▲	04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 0429 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 04F2
2015	Charger (Post-2011)	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Charger (Post-2011)	TCM	○	▲	▲	▲	▲	○	▲	047F 038C 01F3 01F2
2015	Charger (Post-2011)	DTCM	○	▲	▲	▲	▲	▲	○	
2015	Charger (Post-2011)	ADCM	○	▲	▲	▲	▲	○	○	
2015	Charger (Post-2011)	VSIM	○	▲	▲	▲	▲	▲	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Charger (Post-2011)	LBSS	○	▲	▲	▲	▲	○	○	
2015	Charger (Post-2011)	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 038F 022D 03C0
2015	Charger (Post-2011)	PDM	○	▲	▲	▲	▲	▲	▲	
2015	300 / Magnum / Charger (Pre-2011)	ITM	○	▲	▲	▲	▲	▲	▲	0107 0437 0104 03CE 0436
2015	300 / Magnum / Charger (Pre-2011)	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	300 / Magnum / Charger (Pre-2011)	EPS	○	▲	▲	▲	▲	○	○	
2015	300 / Magnum / Charger (Pre-2011)	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2015	300 / Magnum / Charger (Pre-2011)	ACC	○	▲	▲	▲	▲	○	○	
2015	300 / Magnum / Charger (Pre-2011)	HSM	○	▲	▲	▲	▲	▲	▲	
2015	300 / Magnum / Charger (Pre-2011)	ICS	○	▲	▲	▲	▲	▲	○	
2015	300 / Magnum / Charger (Pre-2011)	ADCM	○	▲	▲	▲	▲	○	○	
2015	300 / Magnum / Charger (Pre-2011)	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB
2015	300 / Magnum / Charger (Pre-2011)	AFLS	○	▲	▲	▲	▲	▲	○	045B
2015	300 / Magnum / Charger (Pre-2011)	LBSS	○	▲	▲	▲	▲	○	○	
2015	300 / Magnum / Charger (Pre-2011)	DTCM	○	▲	▲	▲	▲	▲	○	
2015	300 / Magnum / Charger (Pre-2011)	RFH	○	▲	▲	▲	▲	▲	▲	0443 0440 0442 050E 0444 0465 043F 0445 050F
2015	300 / Magnum / Charger (Pre-2011)	TCM	○	▲	▲	▲	▲	○	▲	047F 038C 01F3 01F2
2015	300 / Magnum / Charger (Pre-2011)	DDM	○	▲	▲	▲	▲	▲	▲	
2015	300 / Magnum / Charger (Pre-2011)	ESM	○	▲	▲	▲	▲	▲	○	
2015	300 / Magnum / Charger (Pre-2011)	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	300 / Magnum / Charger (Pre-2011)	IPC	○	▲	▲	▲	▲	▲	▲	04B3 05EB
2015	300 / Magnum / Charger (Pre-2011)	RBSS	○	▲	▲	▲	▲	○	○	
2015	300 / Magnum / Charger (Pre-2011)	TPM	○	▲	▲	▲	▲	○	▲	0435 0232 0230 0231 022F
2015	300 / Magnum / Charger (Pre-2011)	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	300 / Magnum / Charger (Pre-2011)	PDM	○	▲	▲	▲	▲	▲	▲	
2015	300 / Magnum / Charger (Pre-2011)	PTS	○	▲	▲	▲	▲	○	▲	02ED
2015	300 / Magnum / Charger (Pre-2011)	MSM	○	▲	▲	▲	▲	▲	▲	0455 0451 0454 044F 0452 0450 0453
2015	300 / Magnum / Charger (Pre-2011)	ORC	○	▲	▲	▲	▲	○	▲	02A1
2015	300 / Magnum / Charger (Pre-2011)	PCM	○	▲	▲	▲	▲	▲	▲	04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 0429 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 04F2 0431 0042 0430 02BD 0049 042F 03D2 042E 0432 042D 031D 03D8
2015	300 / Magnum / Charger (Pre-2011)	FFCM	○	▲	▲	▲	▲	○	○	056F
2015	300 / Magnum / Charger (Pre-2011)	SCCM	○	▲	▲	▲	▲	○	▲	
2015	Compass	CCN	○	▲	▲	▲	▲	▲	▲	00BC 008F 008E 0382 038D 0090 0383
2015	Compass	WCM	○	▲	▲	▲	▲	○	▲	02A7 0233 022E 01D2 0228 0232 0230 0231 022F 0227
2015	Compass	TCM	○	▲	▲	▲	▲	▲	▲	01F5 0380 0510
2015	Compass	RADIO	○	▲	▲	▲	▲	▲	▲	04A1 039F 01BB 039E 025D
2015	Compass	SAS	○	▲	▲	▲	○	○	○	
2015	Compass	PCM	○	▲	▲	▲	▲	▲	▲	04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 0381 0386 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 04F2 057C
2015	Compass	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 03A9 02EB
2015	Compass	HFM	○	▲	▲	▲	▲	▲	○	00E3
2015	Compass	AMP	○	▲	▲	▲	▲	○	▲	006D 0068
2015	Compass	ORC	○	▲	▲	▲	▲	○	▲	03CC 03CD
2015	Compass	TIPMCGW	○	▲	▲	▲	▲	▲	▲	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 0388 0390 03A2
2015	Compass	ABS	○	▲	▲	▲	▲	▲	▲	03AB 0002 0285 0062 0485
2015	Compass	AWD	○	▲	▲	▲	▲	▲	▲	
2015	Compass	ITM	○	▲	▲	▲	▲	▲	▲	03CF 010A 0106 03CE
2015	Ypsilon	TCM	○	▲	▲	▲	○	▲	▲	
2015	Ypsilon	ORC	○	▲	▲	▲	▲	▲	▲	
2015	Ypsilon	BCM	○	▲	▲	▲	▲	▲	○	04E5 04E6
2015	Ypsilon	AHM	○	▲	▲	▲	▲	▲	○	
2015	Ypsilon	HVAC	○	▲	▲	▲	▲	▲	▲	
2015	Ypsilon	ECM	○	▲	▲	▲	▲	▲	▲	04BE 04C0 04BF
2015	Ypsilon	IPC	○	▲	▲	▲	▲	▲	○	04DB
2015	Ypsilon	EPS	○	▲	▲	▲	○	○	▲	
2015	Ypsilon	ABS	○	▲	▲	▲	○	▲	▲	
2015	Dart	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	Dart	ESM	○	▲	▲	▲	○	○	▲	
2015	Dart	ABS	○	▲	▲	▲	▲	○	▲	0570 0434 0513 0514
2015	Dart	AMP	○	▲	▲	▲	▲	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Dart	PCM	○	▲	▲	▲	▲	▲	▲	04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 0550 04F1 04EC 0551 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 04F2 0511 0506 0509 050A 0504 0512
2015	Dart	IPC	○	▲	▲	▲	▲	▲	▲	04B3
2015	Dart	CTM	○	▲	▲	▲	▲	○	○	
2015	Dart	EPS	○	▲	▲	▲	▲	○	○	051A
2015	Dart	RFH	○	▲	▲	▲	▲	▲	▲	0443 0440 0463 0442 051F 0414 051E 0444 051B 051C 051D 0445 04F7
2015	Dart	CSWM	○	▲	▲	▲	▲	▲	▲	
2015	Dart	SCCM	○	▲	▲	▲	▲	○	○	
2015	Dart	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 03A9 02EB
2015	Dart	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 02DC 008F 008E 0219 0518 0517 0519 03E7 043B 0036 049F 0389 02DD 0388 0516 04A6
2015	Dart	ORC	○	▲	▲	▲	▲	○	▲	02A1
2015	Dart	EDM	○	▲	▲	○	○	▲	○	
2015	Dart	OCM	○	▲	▲	▲	▲	○	▲	011E
2015	Dart	LBSS	○	▲	▲	▲	▲	▲	▲	
2015	Dart	TCM	○	▲	▲	▲	▲	▲	▲	044D 044E 044A 044C 01EF 044B 0510
2015	Dart	ICS	○	▲	▲	▲	▲	▲	○	
2015	Dart	RBSS	○	▲	▲	▲	▲	▲	▲	
2015	Dart	PAM	○	▲	▲	▲	▲	○	○	
2015	750	IPC	○	▲	▲	▲	▲	▲	○	0586 0587
2015	750	ORC	○	▲	▲	▲	○	▲	○	
2015	750	BCM	○	▲	▲	▲	▲	▲	○	
2015	Town & Country / Caravan	PTS	○	▲	▲	▲	▲	▲	▲	02ED 03B7
2015	Town & Country / Caravan	DMRR	○	▲	▲	▲	▲	▲	▲	00B4 00B5 00B6
2015	Town & Country / Caravan	DMFR	○	▲	▲	▲	▲	▲	○	
2015	Town & Country / Caravan	FSM	○	▲	▲	▲	▲	▲	○	03AC 03AD 0346 0347
2015	Town & Country / Caravan	LBSS	○	▲	▲	▲	▲	○	○	
2015	Town & Country / Caravan	PEM	○	▲	▲	▲	▲	○	▲	0443 0463 0442 0307
2015	Town & Country / Caravan	HIDT	○	▲	▲	▲	▲	▲	○	0480
2015	Town & Country / Caravan	TIPMCGW	○	▲	▲	▲	▲	▲	▲	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 003A 002E 038F 0388 0390 03A1 03A2
2015	Town & Country / Caravan	PLGM	○	▲	▲	▲	▲	▲	▲	038A 038B 0342
2015	Town & Country / Caravan	VES2	○	▲	▲	▲	▲	▲	▲	
2015	Town & Country / Caravan	PSDMR	○	▲	▲	▲	▲	○	○	0343 0461 04A9 0460 0342
2015	Town & Country / Caravan	RADIO	○	▲	▲	▲	▲	▲	▲	04A1 039F 01BB 039E 025D
2015	Town & Country / Caravan	RBSS	○	▲	▲	▲	▲	○	○	
2015	Town & Country / Caravan	HFM	○	▲	▲	▲	▲	▲	○	00E3
2015	Town & Country / Caravan	TCM	○	▲	▲	▲	▲	▲	▲	047C 0479 047A 047B 042C 0410 0481 0175
2015	Town & Country / Caravan	DMRL	○	▲	▲	▲	▲	▲	▲	00B4 00B5 00B6
2015	Town & Country / Caravan	ITM	○	▲	▲	▲	▲	▲	▲	03CF 0107 0106 03CE
2015	Town & Country / Caravan	AMP	○	▲	▲	▲	▲	○	▲	006D 0068
2015	Town & Country / Caravan	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB 045C 00E9 045D 045E 045F 03A9

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Town & Country / Caravan	PCM	○	▲	▲	▲	▲	▲	▲	042A 03F6 03F7 042B 04EE 04F0 04EF 0127 03F3 0140 0126 0411 0404 040A 0128 042C 03F4 040C 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 054E 012B 04F2 0408 0042 02BA 0428 0424 0049 0423 0427 03D2 0425 031D 013B
2015	Town & Country / Caravan	HSM	○	▲	▲	▲	▲	▲	▲	0412
2015	Town & Country / Caravan	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB
2015	Town & Country / Caravan	VES3	○	▲	▲	▲	▲	▲	▲	
2015	Town & Country / Caravan	TPM	○	▲	▲	▲	▲	○	▲	0414 0232 0230 0231 022F
2015	Town & Country / Caravan	MSMD	○	▲	▲	▲	▲	▲	▲	0455 0451 0450 0454 044F 0452 0453
2015	Town & Country / Caravan	SAS	○	▲	▲	▲	○	○	○	
2015	Town & Country / Caravan	CCN	○	▲	▲	▲	▲	▲	▲	008C 00BC 0382 0091 0094 038D 0096 0383
2015	Town & Country / Caravan	EPPM	○	▲	▲	▲	▲	○	▲	047E
2015	Town & Country / Caravan	ORC	○	▲	▲	▲	▲	○	▲	03CC 02A1
2015	Town & Country / Caravan	WCM	○	▲	▲	▲	▲	▲	▲	02A7 0414 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 0300 0245
2015	Town & Country / Caravan	DVD	○	▲	▲	▲	▲	○	○	
2015	Town & Country / Caravan	SUNR	○	▲	▲	▲	▲	▲	○	
2015	Town & Country / Caravan	DMFL	○	▲	▲	▲	▲	▲	▲	
2015	Town & Country / Caravan	PSDML	○	▲	▲	▲	▲	○	○	0343 0461 04A9 0460 0342
2015	Town & Country / Caravan	AHBM	○	▲	▲	▲	○	▲	○	0066
2015	200	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 03A9 02EB
2015	200	IPC	○	▲	▲	▲	▲	▲	▲	04B3 05EE
2015	200	PDM	○	▲	▲	▲	▲	▲	▲	
2015	200	ORC	○	▲	▲	▲	▲	▲	▲	02A1
2015	200	RRM	○	▲	▲	▲	▲	○	▲	
2015	200	RBSS	○	▲	▲	▲	▲	○	▲	
2015	200	ABS	○	▲	▲	▲	▲	○	▲	0433 0513
2015	200	SCCM	○	▲	▲	▲	▲	○	▲	
2015	200	FFCM	○	▲	▲	▲	▲	○	▲	056F
2015	200	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	200	EPS	○	▲	▲	▲	▲	○	○	051A
2015	200	OCM	○	▲	▲	▲	▲	○	▲	011E
2015	200	AMP	○	▲	▲	▲	▲	○	○	
2015	200	PAM	○	▲	▲	▲	▲	▲	▲	
2015	200	EPB	○	▲	▲	▲	▲	○	▲	056C 056D
2015	200	RFH	○	▲	▲	▲	▲	▲	▲	0443 0440 0463 0442 051F 0414 05EF 051D 04F7
2015	200	ESM	○	▲	▲	▲	▲	○	○	
2015	200	DTCM	○	▲	▲	▲	▲	▲	▲	0568
2015	200	ICS	○	▲	▲	▲	▲	▲	▲	
2015	200	PCM	○	▲	▲	▲	▲	▲	▲	04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 0550 04F1 04EC 0551 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 04F2
2015	200	PTU	○	▲	▲	○	○	○	○	0569
2015	200	CSWM	○	▲	▲	▲	▲	▲	▲	
2015	200	ACC	○	▲	▲	▲	▲	○	▲	056B
2015	200	DDM	○	▲	▲	▲	▲	▲	▲	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	200	MSM	○	▲	▲	▲	▲	○	○	
2015	200	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 02DC 008F 008E 0219 0517 0519 03E7 043B 0036 049F 0389 02DD 0388 0516 04A6
2015	200	LBSS	○	▲	▲	▲	▲	○	▲	
2015	200	TCM	○	▲	▲	▲	▲	○	▲	047F 0564 0563
2015	ProMaster	ETM	○	▲	▲	▲	▲	○	▲	
2015	ProMaster	TCM	○	▲	▲	▲	○	▲	▲	044D 02BD 044E 044A 044C 01EF 044B
2015	ProMaster	BCM	○	▲	▲	▲	▲	▲	▲	003E 05E7 043B
2015	ProMaster	ABS	○	▲	▲	▲	▲	○	▲	
2015	ProMaster	ORC	○	▲	▲	▲	▲	○	▲	
2015	ProMaster	TPM	○	▲	▲	▲	▲	▲	▲	
2015	ProMaster	PCM	○	▲	▲	▲	▲	▲	▲	042A 03F6 03F7 042B 04EE 04F0 04EF 0127 03F3 0140 0126 0575 0411 0404 040A 0128 042C 03F4 040C 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 02F9 03F1 03F0 03F2 012A 02FA 040D 054E 012B 04F2 0408 054A 0574 031D 05E9 0572 0565 0567 0049 03DC 055D 05E8 0554 0573 0556 0557 05EA
2015	ProMaster	PAM	○	▲	▲	▲	▲	○	○	
2015	ProMaster	IPC	○	▲	▲	▲	▲	▲	○	
2015	ProMaster	HVAC	○	▲	▲	▲	▲	▲	○	04FE
2015	ProMaster City	ETM	○	▲	▲	▲	○	○	▲	
2015	ProMaster City	RADIO	○	▲	▲	▲	○	○	▲	
2015	ProMaster City	PCM	○	▲	▲	▲	▲	▲	▲	04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 0550 04F1 04EC 0551 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 04F2
2015	ProMaster City	IPC	○	▲	▲	▲	▲	▲	○	
2015	ProMaster City	ABS	○	▲	▲	▲	▲	▲	○	04EA 0514
2015	ProMaster City	PAM	○	▲	▲	▲	▲	○	○	
2015	ProMaster City	TTM	○	▲	▲	▲	▲	○	▲	
2015	ProMaster City	TPM	○	▲	▲	▲	○	▲	▲	
2015	ProMaster City	ORC	○	▲	▲	▲	○	○	○	
2015	ProMaster City	HVAC	○	▲	▲	▲	▲	▲	○	04FE
2015	ProMaster City	BCM	○	▲	▲	▲	▲	▲	▲	043B 04E5
2015	ProMaster City	ESM	○	▲	▲	▲	▲	○	○	
2015	ProMaster City	TCM	○	▲	▲	▲	▲	○	▲	047F 0564 0563
2015	Durango (Post-2011)	RBSS	○	▲	▲	○	▲	○	○	
2015	Durango (Post-2011)	HVACR	○	▲	▲	▲	▲	▲	▲	00EA
2015	Durango (Post-2011)	ESM	○	▲	▲	▲	▲	○	○	
2015	Durango (Post-2011)	TPM	○	▲	▲	▲	▲	○	▲	0435 0232 0230 0231 022F
2015	Durango (Post-2011)	DTCM	○	▲	▲	▲	▲	▲	▲	
2015	Durango (Post-2011)	EDM	○	▲	▲	▲	▲	▲	○	
2015	Durango (Post-2011)	MSM	○	▲	▲	▲	▲	▲	▲	0455 0451 0454 044F 0452 0450 0453
2015	Durango (Post-2011)	PDM	○	▲	▲	▲	▲	▲	▲	
2015	Durango (Post-2011)	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Durango (Post-2011)	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	Durango (Post-2011)	ICS	○	▲	▲	▲	▲	○	○	
2015	Durango (Post-2011)	IPC	○	▲	▲	▲	▲	▲	▲	04B3 05EB

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Durango (Post-2011)	HVAC	○	▲	▲	▲	▲	▲	○	00EA 03B9 02EB
2015	Durango (Post-2011)	ITM	○	▲	▲	▲	▲	▲	▲	0107 0437 0104 03CE 0436
2015	Durango (Post-2011)	ELSD	○	▲	▲	▲	▲	▲	○	0474 0473
2015	Durango (Post-2011)	VES3	○	▲	▲	▲	▲	▲	○	
2015	Durango (Post-2011)	PCM	○	▲	▲	▲	▲	▲	▲	04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 0550 0410 04F1 04EC 0551 0381 0429 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 04F2
2015	Durango (Post-2011)	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	Durango (Post-2011)	SCCM	○	▲	▲	▲	▲	○	▲	
2015	Durango (Post-2011)	PTS	○	▲	▲	▲	▲	▲	▲	02ED 03B7
2015	Durango (Post-2011)	TCM	○	▲	▲	▲	▲	○	▲	047F
2015	Durango (Post-2011)	VES2	○	▲	▲	▲	▲	▲	○	
2015	Durango (Post-2011)	EPS	○	▲	▲	▲	▲	○	○	050B
2015	Durango (Post-2011)	LBSS	○	▲	▲	○	▲	○	○	
2015	Durango (Post-2011)	ORC	○	▲	▲	▲	▲	○	▲	03CC 02A1
2015	Durango (Post-2011)	HSM	○	▲	▲	▲	▲	▲	▲	
2015	Durango (Post-2011)	AHLM	○	▲	▲	▲	▲	○	○	029F
2015	Durango (Post-2011)	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 038F 022D 03C0
2015	Durango (Post-2011)	ACC	○	▲	▲	▲	▲	○	○	056B
2015	Durango (Post-2011)	FFCM	○	▲	▲	▲	▲	○	○	056F
2015	Durango (Post-2011)	PLGM	○	▲	▲	▲	▲	▲	○	0562
2015	Durango (Post-2011)	RFH	○	▲	▲	▲	▲	▲	▲	0443 0440 0442 050E 0444 043F 0445 050F
2015	Durango (Post-2011)	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2015	Grand Cherokee	TPM	○	▲	▲	▲	▲	○	▲	0435 0232 0230 0231 022F
2015	Grand Cherokee	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2015	Grand Cherokee	ABS	○	▲	▲	▲	▲	▲	▲	0433 03AB 0434
2015	Grand Cherokee	PCM	○	▲	▲	▲	▲	▲	▲	0149 055C 055B 0431 012D 05E1 0430 0560 0049 03DC 03D2 05E2 055D 05DF 0432 042D 055A 0555 05E0 0554 0558 0556 0557 031D 03D8 04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 0550 0410 04F1 04EC 0551 0381 0429 02F9 03F1 03F0 03F2 012A 02FA 054E 012B 04F2
2015	Grand Cherokee	ACC	○	▲	▲	▲	▲	○	○	056B
2015	Grand Cherokee	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	Grand Cherokee	SCCM	○	▲	▲	▲	▲	○	▲	
2015	Grand Cherokee	IPC	○	▲	▲	▲	▲	▲	▲	04B3 05EB
2015	Grand Cherokee	DTV	○	▲	▲	▲	○	▲	▲	
2015	Grand Cherokee	ORC	○	▲	▲	▲	▲	○	▲	03CC 02A1
2015	Grand Cherokee	VES3	○	▲	▲	▲	▲	▲	○	
2015	Grand Cherokee	AFLS	○	▲	▲	▲	▲	○	▲	045B
2015	Grand Cherokee	DTCM	○	▲	▲	▲	▲	▲	▲	
2015	Grand Cherokee	PLGM	○	▲	▲	▲	▲	▲	○	0562
2015	Grand Cherokee	PTS	○	▲	▲	▲	▲	▲	▲	02ED 03B7
2015	Grand Cherokee	PDM	○	▲	▲	▲	▲	▲	▲	
2015	Grand Cherokee	LBSS	○	▲	▲	○	▲	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Grand Cherokee	HVAC	○	▲	▲	▲	▲	▲	○	00EA 03B9 02EB
2015	Grand Cherokee	ADCM	○	▲	▲	▲	▲	○	○	
2015	Grand Cherokee	ASCM	○	▲	▲	▲	▲	○	▲	046E 052D 046A 0466 0469 0468 046D 046C 0470
2015	Grand Cherokee	VES2	○	▲	▲	▲	▲	▲	○	
2015	Grand Cherokee	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Grand Cherokee	TCM	○	▲	▲	▲	▲	○	▲	047F
2015	Grand Cherokee	EDM	○	▲	▲	▲	▲	▲	○	
2015	Grand Cherokee	RBSS	○	▲	▲	○	▲	○	○	
2015	Grand Cherokee	RFH	○	▲	▲	▲	▲	▲	▲	0443 0440 0442 050E 0444 0465 043F 0445 050F
2015	Grand Cherokee	ESM	○	▲	▲	▲	▲	○	○	
2015	Grand Cherokee	FFCM	○	▲	▲	▲	▲	○	○	056F
2015	Grand Cherokee	ANC	○	▲	▲	▲	○	○	▲	
2015	Grand Cherokee	HSM	○	▲	▲	▲	▲	▲	▲	
2015	Grand Cherokee	EPS	○	▲	▲	▲	▲	○	○	
2015	Grand Cherokee	MSM	○	▲	▲	▲	▲	▲	▲	0455 0451 0454 044F 0452 0450 0453
2015	Grand Cherokee	AMP	○	▲	▲	▲	▲	○	▲	006D 0068
2015	Grand Cherokee	ITM	○	▲	▲	▲	▲	▲	▲	0107 0437 0104 03CE 0436
2015	Grand Cherokee	ELSD	○	▲	▲	▲	▲	▲	○	0474 0473
2015	Grand Cherokee	ICS	○	▲	▲	▲	▲	○	○	
2015	Viper (Post-2013)	PCM	○	▲	▲	▲	▲	▲	○	013E 0411 0193 04AC 04AB 012C 012D 0429 04AA 012A 0540 012B 03F4
2015	Viper (Post-2013)	ICS	○	▲	▲	▲	▲	▲	▲	
2015	Viper (Post-2013)	ABS	○	▲	▲	▲	▲	▲	▲	
2015	Viper (Post-2013)	ADCM	○	▲	▲	▲	▲	○	○	
2015	Viper (Post-2013)	RADIO	○	▲	▲	▲	▲	▲	▲	
2015	Viper (Post-2013)	PDM	○	▲	▲	▲	▲	▲	▲	
2015	Viper (Post-2013)	OCM	○	▲	▲	▲	▲	○	○	011E
2015	Viper (Post-2013)	HVAC	○	▲	▲	▲	▲	▲	▲	00EA 03B9 02EA 02EB
2015	Viper (Post-2013)	IPC	○	▲	▲	▲	▲	▲	▲	04B3
2015	Viper (Post-2013)	ORC	○	▲	▲	▲	▲	▲	▲	02A1
2015	Viper (Post-2013)	SCCM	○	▲	▲	▲	▲	○	○	
2015	Viper (Post-2013)	BCM	○	▲	▲	▲	▲	▲	▲	02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 022D
2015	Viper (Post-2013)	TPM	○	▲	▲	▲	▲	○	▲	0435 0232 0230 0231 022F
2015	Viper (Post-2013)	DDM	○	▲	▲	▲	▲	▲	▲	
2015	Viper (Post-2013)	AMP	○	▲	▲	▲	▲	○	○	006D 0068
2016	Fiat 500X	TCM	▲	▲	▲	▲	○	○	▲	
2016	Fiat 500X	RRM	▲	▲	▲	▲	○	▲	▲	
2016	Fiat 500X	ETM	▲	▲	▲	▲	○	▲	▲	
2016	Fiat 500X	PCM	▲	▲	▲	▲	▲	▲	▲	013C 012C 012D
2016	Fiat 500X	AMP	▲	▲	▲	▲	○	▲	▲	
2016	Fiat 500X	LBSS	▲	▲	▲	▲	○	▲	○	
2016	Fiat 500X	BCM	▲	▲	▲	▲	○	▲	▲	04E5
2016	Fiat 500X	CSWM	▲	▲	▲	▲	○	▲	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2016	Fiat 500X	PAM	▲	▲	▲	▲	○	○	○	
2016	Fiat 500X	ORC	▲	▲	▲	▲	○	○	▲	
2016	Fiat 500X	IPC	▲	▲	▲	▲	○	▲	▲	
2016	Fiat 500X	RFH	▲	▲	▲	▲	○	▲	▲	05D2 05D7 0443 05D8 05D9 05D3
2016	Fiat 500X	HVAC	▲	▲	▲	▲	○	▲	▲	05C5
2016	Fiat 500X	HALF	▲	▲	▲	▲	○	○	○	
2016	Fiat 500X	DTCM	▲	▲	▲	▲	○	○	○	
2016	Fiat 500X	ESL	▲	▲	▲	▲	○	○	▲	
2016	Fiat 500X	EPS	▲	▲	▲	▲	○	○	▲	
2016	Fiat 500X	RBSS	▲	▲	▲	▲	○	▲	○	
2016	Fiat 500X	ACC	▲	▲	▲	▲	○	▲	▲	
2016	Fiat 500X	ABS	▲	▲	▲	▲	○	▲	○	05C7 05C6
2016	Fiat 500X	ESM	▲	▲	▲	▲	○	▲	▲	

Specil_Function

Index	Specil Function Name	Index	Specil Function Name
00E3	HFM Self Test	00E8	Actuator DTC Detection
00E9	Cool Down Test	00E5	Calibrate HDT Module
0001	Calibrate G-Sensor	0002	Bleed Brakes
0003	Drive Test	03E0	Compression Test (Engine NOT Running)
0004	AEHM Actuate Heater Booster	0005	Gauge Sweep Test
05E0	SCR System Catalyst Reset	0006	Speaker Test
0007	CCN Display Dimmer Test	0008	CCN LCD Display Test
0009	Oil Change Reset	0012	Learn Motor
0013	Reset ORC	0014	ORC Initialize ECU
0018	TCM Reset Learned Adaptives	02E1	Disable In Plant Mode
0020	Reset Adaptive Memory	0021	Throttle Valve Initialization
0022	Fuel Pump Activation	0023	Engine ECU Replaced (Drive Authorization)
0024	Camshaft Reference Adaptation	0025	O2 Sensor Monitor Test
0030	Bleed Brakes 2WD	03E1	Injector Circuit Test
0031	Bleed Brakes 4WD	0032	Disable Radio Clock Display
0033	Sound Horn On Lock	0034	Horn Chirp Duration
0035	Headlamps On With Wipers	0036	Flash Hazard Lamps On Lock
0037	Headlamps Delay Time	0038	Illuminated Entry Time
0039	Accessory Time Delay	0040	Trailer Tow Relay Outputs
0041	Radio Initialization	0042	Compression Test
0043	Exhaust Throttle Plate Adaptive Learn	0044	Injector Kill System Test
0045	Diesel Particulate Filter (New) Initialization	0046	Diesel Particulate Filter (Used) Learning
0049	Injector Quantity Adjustment	05E1	Clear DEF Pump Learned Offset Values
0058	Bleed Brakes:LX	0059	Bleed Brakes:WK
0060	Initialize ESP Module:PT	0062	Initialize ESP Sensor
0064	ACC Cutout Reasons Clear	0065	Align ACC Sensor
0066	Aim Test	0067	AHBM Self Test
0068	AMP Software Test	0069	AMP Channel Output Channel Test
0073	AMP Mute Channel:7 Channel	0079	AMP Multiple Mute Channel
0081	Reset ECU	0090	Unlock Driver Door On 1st Press
0091	Change Measurement Units	0092	Measurement Unit
0094	Language Preference	0096	Seatbelt Alert System
0097	CCN Gauge Test	0098	Service Interval - Gas
0099	Service Interval - Diesel	0104	ITM Siren Test
0106	ITM Initialize Siren	0107	ITM and Siren Communication Test
0114	Drive All Motors	0115	Standardization Routine
0116	Easy Entry/Exit Feature	0117	Key Fobs Linked to Memory Feature
0119	Tilt Mirrors in Reverse Feature	0122	Rollover Detection
0126	ETC Throttle Follower Test	0127	EGR System Test
0128	Purge Vapors System Test	0129	NVLD Forced Monitor Test
0140	ESIM Forced Monitor Test	0141	GENERATOR FULL FIELD TEST
0142	Cylinder Fuel Quantity Correction Test	0144	Program Variant Code
0145	Set RPM System Test	0146	NOx Catalyst(New) Initialization
0147	NOx Catalyst(Used) Learning	0148	IMA Rapid Calibration
0149	Cylinder Balance Test	0150	Set RPM System Test - Automatic Transmission
0151	Set RPM System Test - Manual Transmission	0152	VIEW/RESET TRIP INFORMATION ACCUMULATORS
0153	TORQUE CONVERTER CLUTCH TEST	0154	FUEL PRESSURE OVERRIDE - Automatic Transmission
0155	FUEL PRESSURE OVERRIDE - Manual Transmission	0156	CYLINDER PERFORMANCE TEST - Automatic Transmission
0157	CYLINDER PERFORMANCE TEST - Manual Transmission	0158	IDLE UP FEATURE ENABLE
0159	TVA SPAN TEST	0166	1st Gear Clutch Test:RWD
0167	1st Gear Clutch Test:FWD	0169	2nd Gear Clutch Test:RWD
0170	Quick Learn:NOT RFE	0172	Shift Lever Position Test:RFE
0173	FCM Enable Emissions Rolls Test Mode	0175	TCC Break-In

Index	Specil Function Name	Index	Specil Function Name
0176	Overdrive Switch Test	0177	Clear Variable Line Pressure (VLP) Counters
0178	Reset NOx Adsorber Counts	0179	Reset Pressure limiting Valve Accumulators
0193	Leak detection pump test	02E2	Program Tire Size:KK
0211	PT Restore Customer Preference	0214	Combined Rear Lighting
0215	Program Tire Size:PM or MK	0219	Auto Wipers
0225	Program Ignition Keys or Key FOBs:SKIM	0226	Program Ignition Keys or Key FOBs:RKEONLY
0227	WCM Replaced	0228	PCM Replaced
0230	Program Left Rear Tire Sensor ID	0231	Program Right Front Tire Sensor ID
0232	Program Left Front Tire Sensor ID	0233	TPM Trigger Module Test
0240	PCM Replaced 1.6L Only	0245	WIN Replaced
0247	Tire Pressure ECU Replacement with Manual Initialization	0259	Manual Top Movement
0260	2 Prime Gear Clutch Test:RFE	0261	2nd Gear Clutch Test:RFE
0262	2nd Gear Clutch Test:NonRFE	0263	3rd Gear Clutch Test:RFE
0264	3rd Gear Clutch Test:NonRFE	0265	Reverse Gear Clutch Test:RFE
0266	Reverse Gear Clutch Test:NonRFE	0269	TCC BreakIn
0270	WCM Replaced Var 5 non TPM	0271	WCM Replaced Not Var 5 non TPM
0272	WK:Enable DRL	0273	XK:Enable DRL
0274	WCM Replaced Non TPM	0276	Mobile DeSoot - Minimum Required Soot Load
0277	Mobile DeSoot - No Minimum Required Soot Load	0278	Reset Regenerative Filter Timers
0280	Neutral Gate Test:RFE	0281	Neutral Gate Test:NOT RFE
0285	Initialize ABS Non ESP	0289	AMP Channel Output Channel Test:6 Channel
0290	Direct Gear Clutch Test:68RFE	0291	3rd Gear Clutch Test:68RFE
0292	Enable / Disable Vehicle Features:pu	0293	Remote Start Override
0300	Reset WIN Configuration	03E2	HPV Electrical Circuit Test
0303	AMP Tone Test with volume control	0304	Engine On Odometer
0305	Anti-Theft Override Test	0306	Denormalize Window
0307	PEM Replace	0310	Cruise Control Data
0311	Manual DPF Regeneration	0312	ECM Replacement
0313	DPF Replacement	0314	Adaptive Numerator Learn
0317	Smart Bar Motor Self Test	0318	Sway Bar Telltale Fast Blink Actuator
0319	Sway Bar Telltale Slow Blink Actuator	0321	ACC Exit In-Plant Mode
0323	IR Sensor Data	0324	Rear AC and Rear Wiper Wash Data Display
0325	LDP Forced Monitor Test	0326	View Adaptive Numerator Status
0330	Customer Programmable- Daytime Running Lamps	0331	Customer Programmable- Language
0332	Customer Programmable- Speedometer/Odometer Units	0333	Customer Programmable- Temperature
0334	Pushbutton Test	0336	Set Maximum Vehicle Speed
0337	Set High Idle Allowed Speeds	0340	Non-Volatile Memory Reset
0342	Ramp Van Configuration	0343	Actuate Drive Clutch Engage
0346	Write Left Rear Seat Position	0347	Write Right Rear Seat Position
0350	Hybrid Battery Contactor Test	0351	HVIL Operating Status
0352	View Battery Monitoring Information	0353	View Battery Warranty Information
0354	Reset Weld Check Fault	0355	View Isolation Test Results
0356	View Hybrid Battery Reasons Contactor Not Closing When Commanded	0357	View Stored Reasons Contactor Not Closing When Commanded
0358	View Stored Hybrid Battery Reasons Contactors Opened	0360	Replace TCM
0361	View Battery Pack Information	0365	Enable Jump Assist Mode
0367	Regulation of Low Voltage Control	0368	Reset High Voltage Impact Event
0369	Trans Aux Pump Speed	0372	Sensor Connectivity and HMI Test
0373	Program Tire Size for EATX	0374	Program Tire Size for EGS 52
0378	ATC Data Display	0379	PTO RPM Adjustment
0380	TCM Initialization	0381	Enable Emissions Rolls Test Mode (FCM)
0382	Change Language Preference	0383	Update Measurement Unit
0385	ITM Initialize	0386	Enable Emissions Rolls Test Mode (TIPM)
0387	Relearn TIPM VIN	0388	Sound Horn on Lock

Index	Specil Function Name	Index	Specil Function Name
0389	Headlamps on with Wipers	0390	Tip Start Temporary Disable
0391	QuickLearn	0392	1st Gear Clutch Test RFE
0393	2nd Gear Clutch Test RFE	0394	2nd Prime Clutch Test RFE
0395	3rd Gear Clutch Test RFE	0396	Reverse Gear Clutch Test RFE
0398	Fuel System Run Up Test	0399	High Pressure Fuel System Test
0400	Overdrive Switch Test (Non-RFE)	0401	Overdrive Switch Test (RFE)
0402	Neutral Gate Test (Non-RFE)	0403	Neutral Gate Test (RFE)
0404	Neutral Gate Test (62TE)	0406	Shift Lever Position Test (Non-RFE)
0407	Shift Lever Position Test (RFE)	0408	TCC Break-In (62TE)
0409	TCC Break-In (Non-RFE)	0410	Clear Learned Variable Line Pressure (VLP) Counters
0411	Injector Kill Test	0412	Heated Steering Wheel Configuration
0414	TPM Sensor Rolls Test	0415	Trans Adapt Reset Trigger
0416	Check TCM VIN	0417	Trans Cleaning Procedure
0420	High Voltage Contactor Circuit	0421	Secondary Air Service Test
0422	Check APM VIN	0423	Lambda Sensor 1 Initialization
0424	IMA Quick Calibration	0425	Request Anti-Slugging For Air Condition Compressor
0427	Oxidation Catalyst Initialization	0428	Fuel Mean Value Adaption Initialization
0429	Enable Emissions Rolls Test Mode (PowerNet)	0430	DPF Reset Option
0431	Air Flow Meter Replace	0432	Reset Oil Change Indicator
0433	ABS Bleed Brakes	0434	Brake Pedal Calibration
0435	Sensor Rolls Test	0436	Initialize Siren
0437	ITM Self Test	0438	View Last VTA Trigger Cause Data
0440	Immobilizer Antenna Test	0441	ELV Replace
0442	Locate Learned Keys	0443	Door Handle Verification Test
0444	Erase Ignition FOBs	0445	RF-HUB Replace
0446	TGW Tone Test	0447	Stop Start Confirmation
0449	Ultrasonic Self Test	0450	Standardization
0451	MSMD Self Test	0452	Key Fobs Linked to Memory
0453	Tilt Mirrors in Reverse	0454	Clear All Learned Seat Parameters
0455	Actuate Seat Recall	0456	Disable/Enable Seatbelt Minder Chime
0458	Activate TPM High Gain Mode	0459	TPM Sensor Position Parameter Update
0460	Learn Side Identifier	0461	Sliding Door Close Test
0463	LF Antenna Verification Test	0464	Record Curb Sensor Values
0465	ESCL Replaced	0466	Fill Spring From Reservoir
0467	Atmosphere Valve Actuator Test	0468	Set Ride Height Level
0469	Height Sensor Check	0470	Write Suspension Height Values
0471	Enable/Disable Air Suspension for ITM	0472	Configure Suspension Type
0473	ELSD Quicklearn	0474	System Functionality Test
0476	Program Tire Size/Pinion Factor	0477	Set Max Vehicle Speed
0478	Set Max Cruise Speed	0479	2nd Gear Clutch Test 62TE
0480	HIDT Calibration	0481	Quicklearn (62TE - PCM Var16)
0482	Learn ETC (NGC4)	0483	Acutate Fuel Pump
0484	Enable/Disable Front Fog Lamp	0485	Initialize ABS
0486	Cylinder Performance Test	0487	Torque Converter Clutch Test
0488	Enable / Disable Vehicle Feature	0489	NOx Catalyst (Used) Learning
0490	Reverse Gear Clutch Test:Non RFE	0491	Enable / Disable Vehicle Features
0493	Program Ignition Keys SKIM only	0494	Program RKE Only Keys
0495	Reverse Gear Clutch Test 68RFE	0496	Direct Gear Clutch Test 68RFE
0497	3rd Gear Clutch Test 68RFE	0498	2nd Gear Clutch Test 68RFE
0499	1st Gear Clutch Test 68RFE	05E2	Reset Error Free Operation Time to 40 Hours
0504	Reset Accelerator Pedal Adaptives	0506	Brake Switch Learn
0507	Air-Conditioning Self Learning	0509	Clear Misfire TLC
0510	Clear Learned Values	0511	Air-Conditioning Self-Learning
0512	Throttle Body Self-Learning	0513	Longitudinal G-Sensor Calibration
0514	Steering Angle Sensor Calibration	0516	Sound Horn on Remote Start
0517	Enable Auto Highbeam	0518	Compass Calibration
0519	Enable the One Press All Unlock Feature	0521	Catalyst Efficiency Test
0522	Quicklearn RFE	0523	DEF Reductant Doser Prime Override Test
0524	DEF Reductant Doser Pump Override Test	0525	Alternator(s) Test

Index	Specil Function Name	Index	Specil Function Name
0526	DEF (Reductant) Pressure Line Heater Test	0527	Turbo Actuator Pre-Align / Self Calibrate
0528	Dual Alternator Enable / Disable	0530	Fleet PIN Reset
0531	Swap Line Test	0532	RBC Sensor Calibration
0533	Bleed Brakes Verification Test	0534	PTS Calibration
0539	High Voltage Battery Drain	0540	Learn Mis-Fire Adaptive Numerator
0541	LIN Line Request Check	0543	Configure Door Locks
0550	Clear Engine Auto Restart Crank Counter	0551	Cooled EGR H-Bridge Valve System Test
0552	Dual Fuel Tank Enable / Disable	0553	Rear View Camera Grid Lines
0554	SCR System Dosing Module Replacement	0555	SCR System After ECU Replacement Procedure
0556	SCR System Tank Pump Replacement	0557	SCR System Wiring Harness Replacement
0558	SCR System Pressure Line Replacement	0560	ECU Replaced With Value Transfer
0562	Calibrate Liftgate	0563	Valve Body Solenoid Learn
0564	TCM VIN Verification	0565	ECU Replaced Without Value Transfer
0566	Neutral gear position learning	0567	Initialize Air Flow Sensor Values
0568	Rear Differential Bleed	0569	Reset PTU Shift Counter
0570	ABS Valve Calibration	0572	DPF Pressure Sensor Reset
0573	SCR System Procedure After ECU Replacement	0574	SCR DEF Dosing Injection Quantity
0575	High Speed Fan Test	0576	Fuel Pressure Override Test
0577	Clear DTCs	0578	Hydraulic Valve Test
0579	Disable In-Plant Mode	0580	Tone Output Test
0581	Actuate Mode Doors	0582	Program RKE
0583	RKE Horn Chirp	0584	Enable VTSS
0585	Disable EU DRL	0586	Reset Oil Change Light Service Information
0586	Radio EQ Setting	0587	RKE Unlock Sequence
0587	Reset Wrench Light Service Information	0588	Rolling Door Locks
0589	Calibrate HVAC Door Motors	0590	Enable VTSS Tamper Alert
0591	Headlamps On W/Wipers	0592	Initialize VIN
0593	Primary Fuel Tank Data	0594	Secondary Fuel Tank Data
0595	Optical Horn Chirp	0596	Reset Customer Preferences
0597	Reset Learned Features	0598	Headlamp Delay
0599	Toggle Horn Chirp	0599	Enable Front Fog Lamp Dropout
0600	Enable Fleet DRL	0601	Init Learned Features
0602	Input Test	0603	Speaker Output Test
0604	Continuous Tone Test	0605	PCI Amplifier Test
0606	Mute Output Test	0607	Reset Amplifier
0608	Vin Verification	0609	Identify EQ
0610	Initialize Learned Features	0611	Configure for Radio Clock
0612	Wiper Actuation Test	0613	Input/Output Test
0614	Reset HVAC Module	0615	Actuator Circuit Test
0616	Disable Ambient Temp Sensor	0617	Enable Ambient Temp Sensor
0618	Reset Rear Blend Sw Span	0619	Navigation Voice Test
0620	Verify OCS	0621	Clear VIN Mismatch
0622	Configure for AOSIM	0623	Configure for Side Airbags
0624	Door Close Test	0625	TRD Link
0626	EATX DTC Event Data	0627	Enable Illuminated Entry
0628	Check VTSS Mode	0629	Instrusion Sensor Test
02E3	Program Tire Size:JC	03E3	High Pressure Fuel Rail Test (Engine Running)
8001	TPM Train Tires	8002	Stop Tire Training
8003	WCM Replaced - Gas	8004	PCM Replaced - Gas
8005	WCM Replaced - Diesel	8006	PCM Replaced - Diesel
8007	Erase Key FOBs Only	8008	Program Key FOBs
8009	View SKREEM VIN	8012	Enable VTSS
8015	Rolling Door Locks	8017	Optical Horn Chirp
8018	Horn Chirp	8023	Original VIN Read
8024	Current VIN Read	8050	Clear Learned Features
8051	Seatbelt Alert System 2007	8052	Seatbelt Alert System 2006
8057	RKE Unlock Sequence	8058	Update Model Year to 2007
8070	Oil Change	03E4	LRSM Re-Adaption
05E4	EGR Coolant Regeneration	04E5	Fire Protection System Activate

Index	Specil Function Name	Index	Specil Function Name
03E6	Program Ignition Keys or Key FOBs	04E6	Program Keys
05E6	Enable Trailer Tow Lamps	02E7	Downstream O2 Response Monitor
03E7	Enable/Disable DRL	05E7	Enable Heated Mirrors
03E8	DEF (Reductant) Doser Pump Override Test	05E8	SCR Reset Options
03E9	DEF (Reductant) Pressure Line Heater Tester	05E9	Closed Couple Replacement
000A	Personalize with Electronic Ignition Switch	001A	Left Front Tire Pressure Signal Transmission Test
001B	Left Rear Tire Pressure Signal Transmission Test	001C	Right Front Tire Pressure Signal Transmission Test
001D	Right Rear Tire Pressure Signal Transmission Test	001E	Check/Write VIN
002A	Replace Steering Column Lock	002B	Program New Ignition Key FOB
002C	Erase All Keys and Program New Ignition Key FOB	002E	Program Tire Size
002F	Bleed Brakes ABS only	003A	Program Network Configuration
003C	Add Navigation Radio	003D	Change Country Code
003E	Enable Front Fog Lamp Output	003F	Enable DRL
004E	View Electronic TPM ID	005A	Cycle Stop Lamp Relay
005B	Initialize Steering Angle Sensor	005C	Initialize ESP Module:LX
005D	Initialize ESP Module:WK	005E	Initialize ABS Module
005F	Initialize ESP Module:WK-Non ESP	006A	AMP Tone Test
006B	AMP Mute Channel:6 Channel	006C	AMP Mute Channel:8 Channel
006D	AMP Input Test	007D	Program Tire Size:CS
007E	Enable FCM/IPM Diagnostics	008C	CCN Self Test
008D	Disable Seatbelt Minder Chime	008E	Auto Door Unlock
008F	Auto Door Lock	00AC	Mirror Position Test
00B4	Latch Cinch Test	00B5	Latch Release Test
00B6	Learn Latch Sector Home	00BA	EOM Self Test
00BC	Self Test	00C4	Enable Cruise Control
00C6	Tip Start Override	00C8	Police VTA
00C9	Program Tire Size:ND	00D5	HB and HG:Enable DRL
00D6	ND:Enable DRL	00D8	HB and HG:Program Tire Size
00D9	ND:Program Tire Size	00DA	WK and XK:Program Tire Size
00DB	ND:Enable Cruise Control	00EA	Actuator Calibration Test
00EB	Actuator Calibration Test DR	00EC	HVAC Self Test
010A	Initialize ITM	010D	Initialize Optical Paths
011E	OCM System Verification Test	012A	Learn ETC
012B	Reset Memory	012C	Check PCM Odometer
012D	Check PCM VIN	012E	Set RPM Test - ETC Equipped
012F	Set RPM Test - non - ETC Equipped	013B	TIPM Enable Emissions Rolls Test Mode
013C	Cam Crank Relearn	013E	ETC System Test
014A	Fuel Mean Value Adaptation Initialization	014B	Exhaust Throttle Plate Adaptive Learn Position
014D	Manual Diesel Particulate Filter Regeneration	014F	VIEW/RESET DUTY CYCLE ACCUMULATORS
015A	TVA AUTO ZERO TEST	016A	2nd Gear Clutch Test:FWD
016B	3rd Gear Clutch Test:RWD	016C	3rd Gear Clutch Test:FWD
016D	Reverse Gear Clutch Test:RWD	016E	Reverse Gear Clutch Test:FWD
016F	Quick Learn:RFE	017A	Reset Aftertreatment Trip Information
017B	Enable / Disable Vehicle Features:cc	018D	Check Vin
01B3	Sensor Versions	01B4	Sensor Functional Test
01B5	Sensor Wiring Test	01B8	Configure PTS
01BB	Radio Tone Test	01D2	Erase All Ignition Keys
01DA	WCM TPM Sensor Test	01DE	Program Spare Tire Sensor ID
01EE	2 Prime Gear Clutch Test	01EF	Quick Learn
01F0	Shift Lever Position Test:NON RFE	01F1	Clear Variable Line Pressure (VLP)
01F2	Store Learned Adaptives	01F3	Reset Learned Adaptives
01F4	Initialize EGS-52	01F5	CVT Initialization
01F6	Enable or Disable Mobile PTO	01FB	Quick Learn:Non-RFE
01FC	Thermistor Test	020E	Program Tire Size:DR
021F	Program Tire Size:KA	022D	Update Pressure Thresholds
022E	ELV Replaced	022F	Program Right Rear Tire Sensor ID
023D	WCM Replaced 1	023E	WCM Replaced 2

Index	Specil Function Name	Index	Specil Function Name
023F	PCM Replaced SRT-10 Only	024E	Overdrive Switch Test:RFE
025D	Enable/Disable Front Seat Video	025E	1st Gear Clutch Test:RFE
025F	1st Gear Clutch Test:NonRFE	026C	02 Heater System Test:1bank
026D	02 Heater System Test:2bank	026E	Mass Air Flow Sensor Initialization
026F	Rail Pressure Initialization	027B	1st Gear Clutch Test:62TE
027C	2nd Gear Clutch Test:62TE	027D	3rd Gear Clutch Test:62TE
027E	Reverse Gear Clutch Test:62TE	027F	AMP Mute Channel:No Channel 7
028A	AMP Channel Output Channel Test:8 Channel	028B	AMP Channel Output Channel Test:7 Channel
028D	AMP Channel Output Channel Test:No Channel 7	028E	Program Tire Size:PT No TCM
028F	Program Tire Size:PM or MK No TCM	029F	Calibrate AHLM
02A1	Initialize ORC	02A4	Clear Remote Start Inhibit Reasons
02A5	Clear Remote Start Abort Reasons	02A6	Clear Last Successful Remote Start
02A7	Antenna Loop Test	02AD	OCM Rezero Procedure
02AF	Actuate TracRite Unlock LED	02B0	Actuate TracRite Unlock RR LED
02B1	Actuate TracRite Unlock FR/RR LED	02B2	Actuate SmartBar On-Road LED
02B3	Actuate SmartBar Off-Road LED	02B5	Actuate SmartBar Motor
02B9	Differential Pressure Sensor Replacement	02BA	Diesel Particulate Filter Replacement
02BB	Reset Mass Airflow Values	02BD	ECU Replacement With Value Transfer
02BE	ECU Replacement Without Value Transfer	02BF	Display Diesel Particulate Filter Values
02C0	Reset Inhibiting Timer	02C1	Set Oil Dilution Mass Value
02C2	View Oil Dilution Mass Value	02C3	Hard Top / Soft Top Configuration
02C5	Battery Pack Fan Test	02CE	Change Cruise Control Mode
02CF	Sensors:Bussed Inputs:and Bussed Outputs	02D0	Verify Front TPM Antenna
02D1	Verify Rear TPM Antenna	02D2	All LED and Sound
02D3	LED Zebra Display	02D4	TCC Solenoid Test
02D5	Transmission Shift Solenoids Test	02D6	Modulator Solenoid Test
02D7	Shift Pressure Solenoid Test	02DC	Accessory Delay Time
02DD	Illuminated Approach Time	02EA	First Pass Cool Down Test Results
02EB	Most Recent Cool Down Test Results	02ED	System Wiring Test
02EE	Actuate Memory Seat and Pedals	02EF	View Remote Start Inhibit Data
02F0	View Remote Start Abort Data	02F1	View Last Successful Remote Start Event Data
02F2	View Last VTA Trigger Cause	02F3	View Remote Start Enable Data
02F5	View VTA Enable Data	02F7	TPM Sensor Test
02F8	4th Gear Clutch Test:62TE	02F9	Exhaust Phaser 1 Cleaning
02FA	New Engine Installed	02FB	SRV Test
02FF	PCM Replaced Cummins	030C	Actuate Transmission Relay
030E	Actuate Engine Battery Feed	031A	Sway Bar Telltale Off Actuator
031B	Sway Bar Telltale On Actuator	031D	Service Diesel Particulate Filter Regeneration
032D	Activate/Deactivate Cruise Control	032E	Update Service Interval
032F	Customer Programmable- Clock	033A	VIEW/RESET DUTY CYCLE ACCUMULATORS:03
033B	Mobile DeSoot - No Minimum Required Soot Load Var03	033C	Mobile DeSoot - No Minimum Required Soot Load Var05
033D	Aisin Trans Data	033F	TPM Trigger Module Test DH
034A	Aux Heater Coolant Pump Temp Test	034B	EVAP Temp Target Speed
034C	Resolver Offset Learn Trigger Test	034E	Reset Active Discharge Fault
034F	Hybrid Battery Contactor Status	035B	Shift Lever Position Test
035C	Trans Adapts Reset Trigger	035D	Trans Fast Learn Trigger
035E	Trans Line Pressure	035F	Transmission Cleaning Procedure
036A	Hybrid Trans Start/Stop	036B	Replace HCP
036C	High Voltage Battery Charge	036D	Transmission Motor Control
036E	View Strong Hybrid Limp In Status	036F	View HV Charge Mode Status and Amp Hours of Algorithm Charge
037A	EVR Enable/Disable	037D	Auxiliary Fuel Filter Enable
038A	Calibrate Liftgate Full Close Position	038B	Calibrate Liftgate Full Open Position
038C	Initialize EGS	038D	Seatbelt Alert Minder
038F	Remote Start Temporary Disable	039A	Stationary Desoot
039B	VG Turbo Cleaning Procedure	039E	Radio Anti Theft Override Test
039F	Radio Hard-drive Back-up	03A1	Unlock All Doors First Press
03A2	Update Radio Market Select and DVD Region Code	03A3	Flexible Oil Change Indicator Reset

Index	Specil Function Name	Index	Specil Function Name
03A4	Set Oil Type	03A9	First Passed Cool Down Test Results
03AB	ABS Initialization	03AC	Calibrate Full Recline
03AD	Calibrate Stow	03AF	1st Gear Clutch Test - 62TE
03B0	2nd Gear Clutch Test - 62TE	03B1	3rd Gear Clutch Test - 62TE
03B2	4th Gear Clutch Test - 62TE	03B3	Reverse Gear Clutch Test - 62TE
03B4	Quicklearn - 62TE	03B6	Neutral Gate Test
03B7	Configure License Plate Size	03B8	VVT System Test
03B9	HVAC Cool Down Test	03BB	Vacuum Pump Rezero
03C0	Auto High Beam Aim Test	03C1	Reset Regen Filter Timers
03C2	View/Reset DOC After Treatment Over Temp Events	03C3	View/Reset DPF After Treatment Over Temp Events
03C4	View/Reset Duty Cycle Maps	03C6	VG Turbocharger Cleaning Procedure
03C7	Fuel Pressure Override	03C8	Oil Change Monitor Type
03C9	View/Reset NAC After Treatment Over Temp Events	03CB	Idle Shutdown Timer Adjustment
03CC	Activate Driver and Passenger Head Restraint	03CD	Rollover Detection TRW Only
03CE	Ultrasonic Motion Detection Test	03CF	Siren Test
03D0	EGR/ECU Self Test	03D2	Program Variant Coding
03D3	DPF Regeneration	03D4	New DPF Initialize
03D5	VGT Learn	03D6	Swirl Control Learn
03D8	Throttle Valve Learn	03D9	Engine ECU Replacement
03DA	Injector Accelerated Drift Learn	03DB	Mass Airflow Sensor Replace
03DC	O2 Sensor Replace	03DD	Fuel Rail Pressure Control Test
03DE	IMV Electrical Circuit Test	03DF	Engine Coolant System Air Purge
03EA	DEF (Reductant) Return Line Heater Test	03EB	DEF (Reductant) Suction Line Heater Test
03EC	DEF (Reductant) Tank Heater Test	03ED	DEF (Reductant) Doser Prime Override Test
03EE	View/Reset DEF (Reductant) Doser Purge Count Reset	03EF	Set PTO Max Vehicle Speed
03F0	Intake Phaser 1 Cleaning	03F1	Exhaust Phaser 2 Cleaning
03F2	Intake Phaser 2 Cleaning	03F3	Electric Vacuum Pump Test
03F4	Set Engine RPM	03F5	QuickLearn (Non-RFE)
03F6	2nd Gear Clutch Test (62TE)	03F7	3rd Gear Clutch Test (62TE)
03F8	1st Gear Clutch Test (Non-RFE)	03F9	2nd Gear Clutch Test (Non-RFE)
03FA	3rd Gear Clutch Test (Non-RFE)	03FB	Reverse Gear Clutch Test (Non-RFE)
03FC	1st Gear Clutch Test (RFE)	03FD	2nd Gear Clutch Test (RFE)
03FE	3rd Gear Clutch Test (RFE)	03FF	Reverse Gear Clutch Test (RFE)
040A	O2 System Heater Test	040B	Quicklearn (RFE)
040C	Thermistor Test (62TE)	040D	Quicklearn (62TE)
040E	Thermistor Test (Non-RFE)	040F	Thermistor Test (RFE)
041C	HV Battery Open Cable Detected Fault Reset	041E	Constrain Battery Power Limits
041F	Check HCP VIN	042A	1st Gear Clutch Test (62TE)
042B	4th Gear Clutch Test (62TE)	042C	Reverse Gear Clutch Test (62TE)
042D	Reset Zero Fuel Quantity Calibration	042E	Reset of Lambda values
042F	Lambda Sensor Replace	043A	Light Rain Sensor Re-Adaption
043B	Exit Shipping Mode	043F	Program Ignition FOBKs
044A	Learn Clutches Contact Point	044B	Reset of Data group
044C	New Actuators	044D	Bleed Hydraulic Circuit
044E	Hydraulic Circuit depressurization	044F	Easy Entry/Exit
045B	AFLS Calibration	045C	Actuator Calibration
045D	Front Blower State	045E	Rear Blower State
045F	First Passed Cooldown Test Results	046A	Disable Level Control
046B	Measure System Air Mass	046C	Spring Deflate to Reservoir
046D	Spring Deflate to Atmosphere	046E	Air Spring Circuit Test
046F	System Pressure Measurement	047A	3rd Gear Clutch Test 62TE
047B	4th Gear Clutch Test 62TE	047C	1st Gear Clutch Test 62TE
047D	Quicklearn (62TE - PCM Var17)	047E	Initialize EPPM
047F	Reset Adaptive Values	048A	NOx Catalyst (New) Initialization
048B	VIN Verify Write	048C	Quick Learn:Non RFE
048D	1st Gear Clutch Test:Non RFE	048E	2nd Gear Clutch Test:Non RFE
048F	3rd Gear Clutch Test:Non RFE	049A	3rd Gear Clutch Test FWD
049B	2nd Gear Clutch Test FWD	049C	1st Gear Clutch Test FWD

Index	Specil Function Name	Index	Specil Function Name
049D	Reverse Gear Clutch Test FWD	049E	Radio Clock Display
049F	Headlamp Delay Time	04A0	Temporary Tip Start Disable
04A1	Radio Anti-Theft Override Test	04A2	Program Ignition Keys
04A4	Rear Window Movement	04A5	ACC Post Service Flash Process
04A6	Temporary Remote Start Disable	04A7	Sunroof Initialization
04A8	Shift Lever Position Test - 62TE	04A9	Sliding Door Open Test
04AA	Leak Detection Pump (LDP) Forced Monitor	04AB	Throttle Follower Test
04AC	Purge Vapor System Test	04AD	ABS System Calibration
04AE	Quicklearn (PCM RFE Transmission)	04AF	Engine Warm Up
04B0	Clear Learned Variable Line Pressure Counters	04B1	JK Enable HFM
04B2	Fuel Rail Control Test	04B3	IPC Self Test
04B4	Disable Key-Alike	04B9	Self-learnt functions reset
04BE	Lambda sensor replacement	04BF	Phonic wheel replacement
04C0	Oil change	04C2	Reset learn flag wheel tooth
04C6	Neutral signal learning	04D2	Control unit replacement
04DB	IPC Replacement	04EA	Longitudinal and Lateral sensor calibration
04EB	Brake Sensor Zero Calibration	04EC	Coolant Three Way Valve Replaced
04ED	Active Grille Shutter Replaced	04EE	Active Grille Shutter Test
04EF	Coolant Three Way Valve Test	04F0	CNG/Gasoline Forced Fuel Type
04F1	Clear Stored Accumulated Fuel Mass	04F2	Reset VCM Adaptives
04F4	ABS Static Test	04F7	Update Front and Rear Axle Nominal Tire Pressure Values
04FA	Learn long acceleration Signal	04FB	IPC Enable Seatbelt Minder Chime
04FE	Self Learning Motor Test	050A	Emissions Rolls Test Mode
050B	Clear Steering Pull Compensation	050C	Initialize EPS
050D	ROW Map Configuration	050E	Clear Multi-Module VIN Handshake Immobilizer Failure
050F	View Recent Multi-Module VIN Handshake Immobilizer Failures	051A	EPS Learn
051B	Program Ignition FOBs Baseline System	051C	Program Ignition FOBs Keyless Go System
051D	Program Tire Sensor Identifications	051E	BCM Replaced
051F	Read Ignition Module (IGNM) Software Information	052A	Remote Start Antenna Test
052B	View Ignition (IGNM/KIN) Part Information	052D	Component Air Mass/Pressure/Ride Height Readings
052E	PTO Single Speed RPM	052F	Enable / Disable PTO Types
053A	High Voltage Battery Coolant Fill	053B	Power Electronics Coolant Fill
053C	Accelerator Pedal Learn	053D	Check EVCU VIN
053E	Motor Resolver Offset Learn	053F	Write Pinion Factor
054A	Max Vehicle Speed Adjustment	054B	Engine Idle Shutdown Feature Enable/Disable
054C	Engine Idle Shutdown Timer Adjustment	054E	Reset Enhanced Automatic Oil Change Indicator
054F	Alternator 2 Field Test	055A	SCR Extend Mileage W Active Fault
055B	SCR DEF Tank Fluid Level Reset	055C	DEF Dosing Injection Quantity
055D	Reset of O2 Values	055E	Program Variant Coding.
055F	Active Grill Shutter	056A	Reset RDM Shift Counter
056B	ACC Aim Mode - Auto Alignment	056C	Service Procedures
056D	Take Out of In Plant Mode	056F	FFCM Calibration
057A	Reset Module	057B	ATC AC Cooldown
057C	Uplift Pump Enable	057C	Reset ATC Head
057D	Automatic Loudness	057E	Radio Clock Display
057F	Reset Default Parameters	058A	Key FOB Test
058B	Double Door Unlock	058C	Lock Ignition FOBs
058C	Vehicle Configuration	058D	Fuel Gauge Update
058E	Enable Mopar VTSS	058F	Enable Mopar VTSS Tampr Alert
059A	Disable Disarm Switches	059B	Horn Chirp
059C	Ultrasonic sensors check	059C	DRL Enable
059D	Enable Immobilizer	059D	Modify volumetric sensors sensibility
059E	Modify longitudinal anti-tilt sensor	059E	Headlamp Delay Enable
059F	Horn Chirp Enable	05A0	Modify lateral anti-tilt sensor

Index	Specil Function Name	Index	Specil Function Name
05A2	LIN Siren Check	05A3	LIN Anti-tilt Sensor Check
05AC	Phase Front reset	05AE	Control unit reprogramming
05AF	Fuel supply system components replacement	05B0	Original VIN Lock
05B1	NOx replacement	05B2	Resetting distance travelled with Water in diesel warning lamp ON
05B3	Resetting distance travelled with water temperature warning lamp ON	05B4	Electrical VGT actuator test
05B5	Fan cooling activation	05B6	Particulate Filter Regeneration
05B7	Particulate filter with integrated pre-cat replacement	05B8	Injector replacement (per bank)
05B9	Cylinder 1 injector replacement	05BA	Cylinder 2 injector replacement
05BB	Cylinder 3 injector replacement	05BC	Cylinder 4 injector replacement
05BD	Replacement of EGR valve	05BE	EGR low pressure valve replacement
05BF	Glow plug preheating circuit test	05C0	EGR low pressure valve test
05C1	Throttle valve test	05C2	EGR high pressure valve test
05C3	Clutch group and/or clutch potentiometer replacement	05C4	Injector/s replacement
05C5	self learning motors test	05C6	Wheel Speed Sensor Recognition
05C7	Electric Park Brake management	05C9	Replacement instrument panel cluster
05D0	RFH_TPM program left rear tire sensorId	05D1	RFH_TPM program right front tire sensorId
05D2	Clear TPM Sensor Audit	05D3	RFH TPM sensor rolls tests
05D5	RFH TPM program left front tire sensorId	05D6	RFH TPM program right rear tire sensorId
05D7	Clear TPM Sensor Warnings	05D8	RFH immobilizer antenna test
05D9	RFH locate learned keys	05DF	Reset of SCR Long Term Adaptation Factor
05EA	Speed Limiter	05EB	Enable/Disable Seatbelt Minder
05EC	Snorkel Output Test	05ED	Disable Auto Relock
05EE	IPC Service Mode	05EF	Passenger Passive Entry Handle Delete
060A	Initialize Learned	060B	Mirror Actuation Test
060C	Initialize Module	060D	Inhibit Monitor
060E	Comb R Stop and Turn Lamps	060F	RG Headlamp Washer Disable
061A	Door Open Test	061B	Internal Relay Test
061C	Enable Chime	061D	Verify Module Calibration
061E	EATX TCM Has Been Changed	061F	Pinion Factor
062A	RKE FOB & Module Test	062B	Configure ITM
062C	Door Input Test	062D	Configure Module
800A	View SKREEM Country Code	800B	Reset SKREEM
800C	Enable Disable TPM	800E	WCM Trigger Module Test
801A	Reset Module	802A	Software Reset Module
802B	Hardware Reset Module	804F	Configure Cluster
807D	RESET OIL CHANGE		