

## MaxiSYS\_AlfaRomeo\_V1.50 Function List(Note:For reference only)

## NOTES:

- This function is supported.
- \* This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Mode1	Version	Group	System	ECU info.	Read Codes	Erase Codes		Active Test	Specil Function
145	1.4 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
145	1.6 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
145	1.8 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
145	2. 0 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
145	'98 1.4 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
145	'98 1.6 TS 16V	Safety	AlfaRemeo	•	•	•	•	•	0
145	'98 1.8 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
145	'98 2.0 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
145	'99 1.9 JTD	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
146	1.4 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
146	1.6 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
146	1.8 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
146	2.0 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
146	'98 1.4 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
146	'98 1.6 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
146	'98 1.8 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
146	'98 2.0 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
146	'99 1.9 JTD	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
155	1.6 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
155	1.8 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
155	2.0 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
155	2.5 TD	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
155	TD	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
GTV	'03 2.0 JTS	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
GTV	'03 2.0 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
GTV	'03 3.2 V6 24V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
GTV	2.0 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
GTV	2. 0 V6 TB	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
GTV	3.0 V6 24V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
GTV	'98 1.8 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
GTV	'98 2.0 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
GTV	'98 2.0 V6 TB	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes		Active Test	Specil Function
GTV	'98 3.0 V6 24V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
SPIDER	'03 2.0 JTS	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
SPIDER	'03 2.0 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
SPIDER	'03 3.2 V6 24V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
SPIDER	2. 0 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
SPIDER	3. 0 V6	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
SPIDER	'98 1.8 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
SPIDER	'98 2.0 TS 16V	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
SPIDER	'98 2.0 V6 TB	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
SPIDER	'98 3.0 V6	Safety	ICIT/TRW VAS95 alarm	•	•	•	•	•	0
145	1. 3	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
145	1.4 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
145	1.6	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
145	1.6 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
145	1.7 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
145	1.8 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
145	2.0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
145	'98 1.4 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
145	'98 1.6 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
145	'98 1.8 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
145	'98 2.0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
145	'99 1.9 JTD	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
145	TD	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	1.3	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	1.4 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	1.6	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	1.6 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	1.7 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	1.8 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	2.0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	'98 1.4 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	'98 1.6 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	'98 1.8 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	'98 2.0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	'99 1.9 JTD	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
146	TD	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
155	1.6 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
155	1.7 TS	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
155	1.8 TS	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
155	1.8 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
155	2. 0 TS	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
155	2.0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
155	2.5 TD	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
155	TD	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
155	V6	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
156	1.6 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
156	1.8 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
156	1.9 JTD	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
156	2. 0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
156	2. 4 JTD	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
156	2.5 V6 24V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
156	SELESPEED	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
164	2. 0 TS ECO	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
164	QV 24V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
164	SUPER 2.0 TS	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
164	SUPER TD	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
164	SUPER V6 24V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
164	SUPER V6 24V C.A.E.	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
164	SUPER V6 TB	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
164	V6 ECO	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
164	V6 ECO C.A.	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
166	2.0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
166	2.4 JTD	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
166	2.5 V6 24V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
166	3.0 V6 24V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
GTV	'03 2.0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
GTV	2. 0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
GTV	2. 0 V6 TB	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
GTV	3. 0 V6 24V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
GTV	'98 1.8 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
GTV	'98 2.0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
GTV	'98 2.0 V6 TB	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
GTV	'98 3.0 V6 24V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
SPIDER	'03 2.0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
SPIDER	2.0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
SPIDER	3. 0 V6	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
SPIDER	'98 1.8 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
SPIDER	'98 2.0 TS 16V	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
SPIDER	'98 2.0 V6 TB	Safety	Bosch 5.3 ABS	•	•	•	•	•	0
SPIDER	'98 3.0 V6	Safety	Bosch 5.3 ABS	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
145	1. 3	Engine -	Magneti Marelli IAW 18F Injection	•	0	0	•	•	0
146	1. 3	Engine -	Magneti Marelli IAW 18F Injection	•	0	0	•	•	0
145	1. 3	Engine -	Magneti Marelli IAW O8F Injection	•	0	0	•	•	0
146	1. 3	Engine -	Magneti Marelli IAW O8F Injection	•	0	0	•	•	0
33	1. 3 I. E. ECO	Engine -	Magneti Marelli IAW 08.68 Injection	•	0	0	•	•	0
33	1. 4 I. E. ECO	Engine -	Magneti Marelli IAW 08.68 Injection	•	0	0	•	•	0
145	2. 0 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.3 Injection (2.0 TS 16v eng.)	•	•	•	•	•	0
146	2.0 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.3 Injection (2.0 TS 16v eng.)	•	•	•	•	•	0
155	2.0 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.3 Injection (2.0 TS 16v eng.)	•	•	•	•	•	0
GTV	2.0 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.3 Injection (2.0 TS 16v eng.)	•	•	•	•	•	0
SPIDER	2.0 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.3 Injection (2.0 TS 16v eng.)	•	•	•	•	•	0
145	1. 3	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	1.4 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	1.6	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	1.6 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	1.7 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	1.8 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	2.0 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	'98 1.4 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	'98 1.6 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	'98 1.8 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	'98 2.0 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	'99 1.9 JTD	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	TD	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
146	1. 3	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
146	1.4 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
146	1. 6	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
146	1.6 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
146	1.7 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
146	1.8 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
146	2.0 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
146	'98 1.4 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
146	'98 1.6 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
146	'98 1.8 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
146	'98 2.0 TS 16V	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
146	'99 1.9 JTD	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
146	TD	Comfort	Borletti MCC55F climate control	•	•	•	•	•	0
145	1.4 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
145	1.6 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
145	1.8 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
145	2.0 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
146	1.4 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
146	1.6 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
146	1.8 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
146	2.0 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
155	1.6 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
155	1.8 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
155	2.0 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
156	1.6 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
GTV	2.0 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
SPIDER	2.0 TS 16V	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (TS 16v eng.)	•	•	•	•	•	0
145	1. 3	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
145	1.4 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
145	1.6	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
145	1.6 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
145	1.7 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
145	1.8 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
145	2.0 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
145	TD	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
146	1. 3	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
146	1.4 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
146	1.6	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
146	1.6 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
146	1.7 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
146	1.8 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
146	2.0 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
146	TD	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
155	1.6 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
155	1.7 TS	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
155	1.8 TS	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
155	1.8 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
155	2. 0 TS	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
155	2.0 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
155	2.5 TD	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
155	TD	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
155	V6	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
GTV	2.0 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
GTV	2.0 V6 TB	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
SPIDER	2.0 TS 16V	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
SPIDER	3. 0 V6	Safety	ICIT VAS 93 anti-theft device	•	•	•	•	•	0
		Engine -	Bosch Motronic M1.7 Injection (TS eng.						
155	1.7 TS	Gearbox	El. key)	•	•	•	•	•	0
155	1.8 TS	Engine - Gearbox	Bosch Motronic M1.7 Injection (TS eng. El. key)	•	•	•	•	•	0
155	2. 0 TS	Engine - Gearbox	Bosch Motronic M1.7 Injection (TS eng. El. key)	•	•	•	•	•	0
164	2. 0 TS ECO	Engine - Gearbox	Bosch Motronic M1.7 Injection (TS eng. El. key)	•	•	•	•	•	0
164	SUPER 2.0 TS	Engine -	Bosch Motronic M1.7 Injection (TS eng. El. key)	•	•	•	•	•	0
164	QV 24V	Gearbox Engine -	Bosch Motronic M1.7 Injection (V6 3.0	•	•	•	•	•	0
164	SUPER V6 24V	Gearbox Engine - Gearbox	eng. El. key) Bosch Motronic M1.7 Injection (V6 3.0 eng. El. key)	•	•	•	•	•	0
164	SUPER V6 24V C.A.E.	Engine - Gearbox	Bosch Motronic M1.7 Injection (V6 3.0 eng. El. key)	•	•	•	•	•	0
164	V6 ECO	Engine - Gearbox	Bosch Motronic M1.7 Injection (V6 3.0 eng. El. key)	•	•	•	•	•	0
164	V6 ECO C. A.	Engine - Gearbox	Bosch Motronic M1.7 Injection (V6 3.0 eng. El. key)	•	•	•	•	•	0
155	1.7 TS	Engine -	Bosch Motronic M1.7 Injection (TS eng.)	•	•	•	•	•	0
155	1.8 TS	Engine -	Bosch Motronic M1.7 Injection (TS eng.)	•	•	•	•	•	0
155	2.0 TS	Engine -	Bosch Motronic M1.7 Injection (TS eng.)	•	•	•	•	•	0
164	2. 0 TS ECO	Engine -	Bosch Motronic M1.7 Injection (TS eng.)	•	•	•	•	•	0
164	SUPER 2.0 TS	Engine -	Bosch Motronic M1.7 Injection (TS eng.)	•	•	•	•	•	0
145	1. 7 16V	Engine - Gearbox	Bosch Motronic M2.10.3 Injection (1.7 16v eng. El. key)	•	•	•	•	•	0
146	1.7 16V	Engine - Gearbox	Bosch Motronic M2.10.3 Injection (1.7 16v eng. El. key)	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GTV	3. 0 V6 24V	Engine - Gearbox	Bosch Motronic M3.7.1 Injection (3.0 12/24v eng. El. key)	•	•	•	•	•	0
GTV	'98 3.0 V6 24V	Engine - Gearbox	Bosch Motronic M3.7.1 Injection (3.0 12/24v eng. El. key)	•	•	•	•	•	0
SPIDER	3. 0 V6	Engine - Gearbox	Bosch Motronic M3.7.1 Injection (3.0 12/24v eng. El. key)	•	•	•	•	•	0
SPIDER	'98 3.0 V6	Engine - Gearbox	Bosch Motronic M3.7.1 Injection (3.0 12/24v eng. El. key)	•	•	•	•	•	0
164	Q4	Engine - Gearbox	Bosch Motronic M3.7.1 injection (3.0 24v 4X4 eng.)	•	•	•	•	•	0
164	SUPER V6 TB	Engine - Gearbox	Bosch Motronic ML4.1 injection (V6 T.Petr. El. Key eng.)	•	•	•	•	•	0
GTV	2. 0 V6 TB	Engine - Gearbox	Bosch Motronic ML4.1 injection (V6 T.Petr. El. Key eng.)	•	•	•	•	•	0
GTV	'98 2.0 V6 TB	Engine - Gearbox	Bosch Motronic ML4.1 injection (V6 T.Petr. El. Key eng.)	•	•	•	•	•	0
SPIDER	'98 2.0 V6 TB	Engine - Gearbox	Bosch Motronic ML4.1 injection (V6 T.Petr. El. Key eng.)	•	•	•	•	•	0
164	QV 24V	Engine -	Bosch Motronic M1.7 injection (V6 3.0	•	•	•	•	•	0
164	SUPER V6 24V	Engine -	Bosch Motronic M1.7 injection (V6 3.0	•	•	•	•	•	0
164	SUPER V6 24V C.A.E.	Engine -	Bosch Motronic M1.7 injection (V6 3.0	•	•	•	•	•	0
164	V6 ECO	Engine -	Bosch Motronic M1.7 injection (V6 3.0	•	•	•	•	•	0
164	V6 ECO C. A.	Engine -	Bosch Motronic M1.7 injection (V6 3.0	•	•	•	•	•	0
155	V6	Engine - Gearbox	Bosch Motronic M1.7 injection (V6 2.5 El. Key eng.)	•	•	•	•	•	0
155	V6	Engine -	Bosch Motronic M1.7 injection (V6 2.5	•	•	•	•	•	0
164	SUPER V6 TB	Engine - Gearbox	Bosch Motronic ML4.1 injection (V6 T/Petr. eng.)	•	•	•	•	•	0
164	V6 TURBO ECO	Engine - Gearbox	Bosch Motronic ML4.1 injection (V6 T/Petr. eng.)	•	•	•	•	•	0
145	1.7 16V	Engine - Gearbox	Bosch Motronic M2.10.3 injection (1.7 16v eng.)	•	•	•	•	•	0
146	1. 7 16V	Engine - Gearbox	Bosch Motronic M2.10.3 injection (1.7 16v eng.)	•	•	•	•	•	0
156	2.4 JTD	Engine - Gearbox	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	•	•	•	•	•	0
166	2.4 JTD	Engine - Gearbox	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	•	•	•	•	•	0
156	1.6 TS 16V	Safety	Allied MY97 Airbag (2F-2P-I-S)	•	•	•	•	0	0
156	1.8 TS 16V	Safety	Allied MY97 Airbag (2F-2P-I-S)	•	•	•	•	0	0
156	1.9 JTD	Safety	Allied MY97 Airbag (2F-2P-I-S)	•	•	•	•	0	0
156	2. 0 TS 16V	Safety	Allied MY97 Airbag (2F-2P-I-S)	•	•	•	•	0	0
156	2.4 JTD	Safety	Allied MY97 Airbag (2F-2P-I-S)	•	•	•	•	0	0
156	2. 5 V6 24V	Safety	Allied MY97 Airbag (2F-2P-I-S)	•	•	•	•	0	0
156	SELESPEED	Safety	Allied MY97 Airbag (2F-2P-I-S)	•	•	•	•	0	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
156	1.6 TS 16V	Comfort	Harrison climate control	•	•	•	•	0	0
156	1.8 TS 16V	Comfort	Harrison climate control	•	•	•	•	0	0
156	1.9 JTD	Comfort	Harrison climate control	•	•	•	•	0	0
156	2.0 TS 16V	Comfort	Harrison climate control	•	•	•	•	0	0
156	2. 4 JTD	Comfort	Harrison climate control	•	•	•	•	0	0
156	2.5 V6 24V	Comfort	Harrison climate control	•	•	•	•	0	0
156	SELESPEED	Comfort	Harrison climate control	•	•	•	•	0	0
GTV	'03 2.0 JTS	Comfort	Harrison climate control	•	•	•	•	0	0
GTV	'03 2.0 TS 16V	Comfort	Harrison climate control	•	•	•	•	0	0
GTV	'03 3.2 V6 24V	Comfort	Harrison climate control	•	•	•	•	0	0
GTV	'98 1.8 TS 16V	Comfort	Harrison climate control	•	•	•	•	0	0
GTV	'98 2.0 TS 16V	Comfort	Harrison climate control	•	•	•	•	0	0
GTV	'98 2.0 V6 TB	Comfort	Harrison climate control	•	•	•	•	0	0
GTV	'98 3.0 V6 24V	Comfort	Harrison climate control	•	•	•	•	0	0
SPIDER	'03 2.0 JTS	Comfort	Harrison climate control	•	•	•	•	0	0
SPIDER	'03 2.0 TS 16V	Comfort	Harrison climate control	•	•	•	•	0	0
SPIDER	'03 3.2 V6 24V	Comfort	Harrison climate control	•	•	•	•	0	0
SPIDER	'98 1.8 TS 16V	Comfort	Harrison climate control	•	•	•	•	0	0
SPIDER	'98 2.0 TS 16V	Comfort	Harrison climate control	•	•	•	•	0	0
SPIDER	'98 2.0 V6 TB	Comfort	Harrison climate control	•	•	•	•	0	0
SPIDER	'98 3.0 V6	Comfort	Harrison climate control	•	•	•	•	0	0
164	QV	Engine -	Bosch Motronic ML4.1 Injection (3.0 V6	•	•	•	•	•	0
164	V6	Engine -	Bosch Motronic ML4.1 Injection (3.0 V6	•	•	•	•	•	0
164	V6 ECO	Engine -	Bosch Motronic ML4.1 Injection (3.0 V6	•	•	•	•	•	0
164	V6 ECO C.A.	Engine -	Bosch Motronic ML4.1 Injection (3.0 V6	•	•	•	•	•	0
156	1.8 TS 16V	Engine -	Bosch Motronic M1.5.5 injection	•	•	•	•	•	0
156	2.0 TS 16V	Engine -	Bosch Motronic M1.5.5 injection	•	•	•	•	•	0
156	2.5 V6 24V	Engine -	Bosch Motronic ME2.1 injection (2.5 V6	•	•	•	•	•	0
145	'99 1.9 JTD	Engine - Gearbox	Bosch Diesel EDC15 injection (1.9 TD d.i. engine)	•	•	•	•	•	0
146	'99 1.9 JTD	Engine - Gearbox	Bosch Diesel EDC15 injection (1.9 TD d.i. engine)	•	•	•	•	•	0
156	1.9 JTD	Engine - Gearbox	Bosch Diesel EDC15 injection (1.9 TD d.i. engine)	•	•	•	•	•	0
145	1. 3	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
145	1.4 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
145	1. 6	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
145	1.6 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
145	1.7 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
145	1.8 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
145	2.0 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
145	'98 1.4 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
145	'98 1.6 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
145	'98 1.8 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
145	'98 2.0 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
145	'99 1.9 JTD	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
145	TD	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	1. 3	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	1.4 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	1. 6	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	1.6 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	1.7 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	1.8 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	2.0 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	'98 1.4 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	'98 1.6 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	'98 1.8 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	'98 2.0 TS 16V	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	'99 1.9 JTD	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
146	TD	Safety	TRW MY 97 Airbag (2F)	•	•	•	•	0	0
164	SUPER V6 24V C.A.E.	Engine -	ZF 4HP18 K Automatic Transmission	•	•	•	•	•	0
166	2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P-2L-I-S)	•	•	•	•	0	0
166	2. 0 V6 TB	Safety	TRW MY 97 Air Bag (2F-2P-2L-I-S)	•	•	•	•	0	0
166	2. 4 JTD	Safety	TRW MY 97 Air Bag (2F-2P-2L-I-S)	•	•	•	•	0	0
166	2.5 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P-2L-I-S)	•	•	•	•	0	0
166	3.0 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P-2L-I-S)	•	•	•	•	0	0
145	'98 1.4 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
145	'98 1.6 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
145	'98 1.8 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
145	'98 2.0 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
146	'98 1.4 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
146	'98 1.6 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
146	'98 1.8 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
146	'98 2.0 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
156	1.6 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
156	1.8 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
156	2.0 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
166	2.0 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
GTV	'98 1.8 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
GTV	'98 2.0 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
SPIDER	'98 1.8 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0

Mode1	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
SPIDER	'98 2.0 TS 16V	Engine -	Bosch Motronic M1.5.5 injection (eng. TS	•	•	•	•	•	0
GTV	'03 2.0 JTS	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
GTV	'03 2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
GTV	'03 3.2 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
GTV	2. 0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
GTV	2. 0 V6 TB	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
GTV	3.0 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
GTV	'98 1.8 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
GTV	'98 2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
GTV	'98 2.0 V6 TB	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
GTV	'98 3.0 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
SPIDER	'03 2.0 JTS	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
SPIDER	'03 2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
SPIDER	'03 3.2 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
SPIDER	2. 0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
SPIDER	3. 0 V6	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
SPIDER	'98 1.8 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
SPIDER	'98 2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
SPIDER	'98 2.0 V6 TB	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
SPIDER	'98 3.0 V6	Safety	TRW MY 97 Air Bag (2F-2P)	•	•	•	•	0	0
145	'98 1.4 TS 16V	Safety	TRW MY 97 Air Bag (2F-S)	•	•	•	•	0	0
145	'98 1.6 TS 16V	Safety	TRW MY 97 Air Bag (2F-S)	•	•	•	•	0	0
145	'98 1.8 TS 16V	Safety	TRW MY 97 Air Bag (2F-S)	•	•	•	•	0	0
145	'98 2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-S)	•	•	•	•	0	0
145	'99 1.9 JTD	Safety	TRW MY 97 Air Bag (2F-S)	•	•	•	•	0	0
146	'98 1.4 TS 16V	Safety	TRW MY 97 Air Bag (2F-S)	•	•	•	•	0	0
146	'98 1.6 TS 16V	Safety	TRW MY 97 Air Bag (2F-S)	•	•	•	•	0	0
146	'98 1.8 TS 16V	Safety	TRW MY 97 Air Bag (2F-S)	•	•	•	•	0	0
146	'98 2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-S)	•	•	•	•	0	0
146	'99 1.9 JTD	Safety	TRW MY 97 Air Bag (2F-S)	•	•	•	•	0	0
166	2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
166	2. 0 V6 TB	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
166	2.4 JTD	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
166	2.5 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
166	3.0 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
GTV	'03 2.0 JTS	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
GTV	'03 2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
GTV	'03 3.2 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	О
GTV	'98 1.8 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
GTV	'98 2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes		Active Test	Specil Function
GTV	'98 2.0 V6 TB	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
GTV	'98 3.0 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
SPIDER	'03 2.0 JTS	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
SPIDER	'03 2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
SPIDER	'03 3.2 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
SPIDER	'98 1.8 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
SPIDER	'98 2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
SPIDER	'98 2.0 V6 TB	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
SPIDER	'98 3.0 V6	Safety	TRW MY 97 Air Bag (2F-2P-I)	•	•	•	•	0	0
145	'98 1.4 TS 16V	Safety	TRW MY 97 Air Bag (2F-2L-S)	•	•	•	•	0	0
145	'98 1.6 TS 16V	Safety	TRW MY 97 Air Bag (2F-2L-S)	•	•	•	•	0	0
145	'98 1.8 TS 16V	Safety	TRW MY 97 Air Bag (2F-2L-S)	•	•	•	•	0	0
145	'98 2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2L-S)	•	•	•	•	0	0
145	'99 1.9 JTD	Safety	TRW MY 97 Air Bag (2F-2L-S)	•	•	•	•	0	0
146	'98 1.4 TS 16V	Safety	TRW MY 97 Air Bag (2F-2L-S)	•	•	•	•	0	0
146	'98 1.6 TS 16V	Safety	TRW MY 97 Air Bag (2F-2L-S)	•	•	•	•	0	0
146	'98 1.8 TS 16V	Safety	TRW MY 97 Air Bag (2F-2L-S)	•	•	•	•	0	0
146	'98 2.0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2L-S)	•	•	•	•	0	0
146	'99 1.9 JTD	Safety	TRW MY 97 Air Bag (2F-2L-S)	•	•	•	•	0	0
166	2. 0 TS 16V	Safety	TRW MY 97 Air Bag (2F-2P-I-S)	•	•	•	•	0	0
166	2. 0 V6 TB	Safety	TRW MY 97 Air Bag (2F-2P-I-S)	•	•	•	•	0	0
166	2. 4 JTD	Safety	TRW MY 97 Air Bag (2F-2P-I-S)	•	•	•	•	0	0
166	2.5 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P-I-S)	•	•	•	•	0	0
166	3.0 V6 24V	Safety	TRW MY 97 Air Bag (2F-2P-I-S)	•	•	•	•	0	0
156	1.6 TS 16V	Safety	Allied MY 97 Airbag (2F-2P)	•	•	•	•	0	0
156	1.8 TS 16V	Safety	Allied MY 97 Airbag (2F-2P)	•	•	•	•	0	0
156	1.9 JTD	Safety	Allied MY 97 Airbag (2F-2P)	•	•	•	•	0	0
156	2. 0 TS 16V	Safety	Allied MY 97 Airbag (2F-2P)	•	•	•	•	0	0
156	2. 4 JTD	Safety	Allied MY 97 Airbag (2F-2P)	•	•	•	•	0	0
156	2.5 V6 24V	Safety	Allied MY 97 Airbag (2F-2P)	•	•	•	•	0	0
156	SELESPEED	Safety	Allied MY 97 Airbag (2F-2P)	•	•	•	•	0	0
156	1.6 TS 16V	Safety	Allied MY 97 Air Bag (2F-2P-2L-I-S)	•	•	•	•	0	0
156	1.8 TS 16V	Safety	Allied MY 97 Air Bag (2F-2P-2L-I-S)	•	•	•	•	0	0
156	1.9 JTD	Safety	Allied MY 97 Air Bag (2F-2P-2L-I-S)	•	•	•	•	0	0
156	2. 0 TS 16V	Safety	Allied MY 97 Air Bag (2F-2P-2L-I-S)	•	•	•	•	0	0
156	2. 4 JTD	Safety	Allied MY 97 Air Bag (2F-2P-2L-I-S)	•	•	•	•	0	0
156	2.5 V6 24V	Safety	Allied MY 97 Air Bag (2F-2P-2L-I-S)	•	•	•	•	0	0
156	SELESPEED	Safety	Allied MY 97 Air Bag (2F-2P-2L-I-S)	•	•	•	•	0	0
166	2.5 V6 24V	Engine - Gearbox	Bosch Motronic ME2.1 injection (eng. V6 2.5 / 3.0)	•	•	•	•	•	0

Mode1	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
166	3. 0 V6 24V	Engine - Gearbox	Bosch Motronic ME2.1 injection (eng. V6 2.5 / 3.0)	•	•	•	•	•	0
GTV	'98 3.0 V6 24V	Engine - Gearbox	Bosch Motronic ME2.1 injection (eng. V6 2.5 / 3.0)	•	•	•	•	•	0
SPIDER	'98 3.0 V6	Engine - Gearbox	Bosch Motronic ME2.1 injection (eng. V6 2.5 / 3.0)	•	•	•	•	•	0
166	2.0 TS 16V	Safety	Bosch 5.3 TC ABS	•	•	•	•	•	0
166	2.0 V6 TB	Safety	Bosch 5.3 TC ABS	•	•	•	•	•	0
166	2.4 JTD	Safety	Bosch 5.3 TC ABS	•	•	•	•	•	0
156 MY	GTA 3.2 V6	Safety	Bosch 5.3 ASR ABS	•	•	•	•	•	0
166	2.5 V6 24V	Safety	Bosch 5.3 ASR ABS	•	•	•	•	•	0
166	3.0 V6 24V	Safety	Bosch 5.3 ASR ABS	•	•	•	•	•	0
GTV	'03 2.0 JTS	Safety	Bosch 5.3 ASR ABS	•	•	•	•	•	0
GTV	'03 3.2 V6 24V	Safety	Bosch 5.3 ASR ABS	•	•	•	•	•	0
SPIDER	'03 2.0 JTS	Safety	Bosch 5.3 ASR ABS	•	•	•	•	•	0
SPIDER	'03 3.2 V6 24V	Safety	Bosch 5.3 ASR ABS	•	•	•	•	•	0
166	2. 0 V6 TB	Engine - Gearbox	Bosch Motronic ME2.1 injection (eng. V6 2.0 TB)	•	•	•	•	•	0
166	'03 2.0 TS 16V	Instrumentation	Navigator/Siemens ICS instrument	•	•	•	•	0	0
166	'03 2.4 JTD 20V	Instrumentation	Navigator/Siemens ICS instrument	•	•	•	•	0	0
166	'03 2.5 V6 24V	Instrumentation	Navigator/Siemens ICS instrument	•	•	•	•	0	0
166	'03 3.0 V6 24V	Instrumentation	Navigator/Siemens ICS instrument	•	•	•	•	0	0
166	'03 3.2 V6 24V	Instrumentation	Navigator/Siemens ICS instrument	•	•	•	•	0	0
166	2.0 TS 16V	Instrumentation	Navigator/Siemens ICS instrument	•	•	•	•	0	0
166	2. 0 V6 TB	Instrumentation	Navigator/Siemens ICS instrument	•	•	•	•	0	0
166	2. 4 JTD	Instrumentation	Navigator/Siemens ICS instrument	•	•	•	•	0	0
166	2.5 V6 24V	Instrumentation	Navigator/Siemens ICS instrument	•	•	•	•	0	0
166	3.0 V6 24V	Instrumentation	Navigator/Siemens ICS instrument	•	•	•	•	0	0
166	'03 2.5 V6 24V	Engine -	ZF 4HP20 Automatic Transmission	•	•	•	•	•	0
166	'03 3.0 V6 24V	Engine -	ZF 4HP20 Automatic Transmission	•	•	•	•	•	0
166	2.5 V6 24V	Engine -	ZF 4HP20 Automatic Transmission	•	•	•	•	•	0
166	3. 0 V6 24V	Engine -	ZF 4HP20 Automatic Transmission	•	•	•	•	•	0
156	2.5 V6 24V	Engine -	AISIN Q-SYSTEM Automatic Gearbox	•	•	•	•	•	0
156 MY	2.5 V6 24V	Engine -	AISIN Q-SYSTEM Automatic Gearbox	•	•	•	•	•	0
156	SELESPEED	Engine -	Marelli SELESPEED Automatic Gearbox	•	•	•	•	•	0
156	SELESPEED	Engine -	Bosch Motronic ME3.1 injection	•	•	•	•	•	0
145	'98 1.4 TS 16V	Safety	Trw MY 97 airbag (2F-2L)	•	•	•	•	0	0
145	'98 1.6 TS 16V	Safety	Trw MY 97 airbag (2F-2L)	•	•	•	•	0	0
145	'98 1.8 TS 16V	Safety	Trw MY 97 airbag (2F-2L)	•	•	•	•	0	0
145	'98 2.0 TS 16V	Safety	Trw MY 97 airbag (2F-2L)	•	•	•	•	0	0
145	'99 1.9 JTD	Safety	Trw MY 97 airbag (2F-2L)	•	•	•	•	0	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
146	'98 1.4 TS 16V	Safety	Trw MY 97 airbag (2F-2L)	•	•	•	•	0	0
146	'98 1.6 TS 16V	Safety	Trw MY 97 airbag (2F-2L)	•	•	•	•	0	0
146	'98 1.8 TS 16V	Safety	Trw MY 97 airbag (2F-2L)	•	•	•	•	0	0
146	'98 2.0 TS 16V	Safety	Trw MY 97 airbag (2F-2L)	•	•	•	•	0	0
146	'99 1.9 JTD	Safety	Trw MY 97 airbag (2F-2L)	•	•	•	•	0	0
166	2. 0 TS 16V	Safety	TRW MY 97 airbag (2F-2P-2L-I)	•	•	•	•	0	0
166	2. 0 V6 TB	Safety	TRW MY 97 airbag (2F-2P-2L-I)	•	•	•	•	0	0
166	2. 4 JTD	Safety	TRW MY 97 airbag (2F-2P-2L-I)	•	•	•	•	0	0
166	2.5 V6 24V	Safety	TRW MY 97 airbag (2F-2P-2L-I)	•	•	•	•	0	0
166	3.0 V6 24V	Safety	TRW MY 97 airbag (2F-2P-2L-I)	•	•	•	•	0	0
166	3.0 V6 24V	Safety	Bosch 5.7 VDC ABS	•	•	•	•	•	0
156	1.6 TS 16V	Safety	Allied MY 97 Airbag (2F-2P-I)	•	•	•	•	0	0
156	1.8 TS 16V	Safety	Allied MY 97 Airbag (2F-2P-I)	•	•	•	•	0	0
156	1.9 JTD	Safety	Allied MY 97 Airbag (2F-2P-I)	•	•	•	•	0	0
156	2.0 TS 16V	Safety	Allied MY 97 Airbag (2F-2P-I)	•	•	•	•	0	0
156	2.4 JTD	Safety	Allied MY 97 Airbag (2F-2P-I)	•	•	•	•	0	0
156	2.5 V6 24V	Safety	Allied MY 97 Airbag (2F-2P-I)	•	•	•	•	0	0
156	SELESPEED	Safety	Allied MY 97 Airbag (2F-2P-I)	•	•	•	•	0	0
156	1.6 TS 16V	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	•	•	•	•	0	0
156	1.8 TS 16V	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	•	•	•	•	0	0
156	1.9 JTD	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	•	•	•	•	0	0
156	2.0 TS 16V	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	•	•	•	•	0	0
156	2.4 JTD	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	•	•	•	•	0	0
156	2.5 V6 24V	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	•	•	•	•	0	0
156	SELESPEED	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	•	•	•	•	0	0
147	1.6 TS 16V 105CV	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
147	1.6 TS 16V 120CV	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
147	1.9 JTD	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
147	1.9 JTD 16V	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
147	2.0 TS 16V	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
147	GTA 3.2 V6	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
147	GTA SELESPEED	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
147	SELESPEED	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
156	1.6 TS 16V	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
156	1.8 TS 16V	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
156	1.9 JTD	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
156	2.0 TS 16V	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
156	2.4 JTD	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
156	2.5 V6 24V	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0
156	SELESPEED	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	•	•	•	•	0	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
147	SELESPEED	Engine -	Marelli CFC208F SELESPEED Automatic	•	•	•	•	•	0
156 MY	JTS SELESPEED	Engine -	Marelli CFC208F SELESPEED Automatic	•	•	•	•	•	0
156 MY	SELESPEED	Engine -	Marelli CFC208F SELESPEED Automatic	•	•	•	•	•	0
156 MY	GTA SELESPEED	Engine -	Marelli SELESPEED CFC218F Automatic	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
147	1.9 JTD	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
147	1.9 JTD 16V	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
147	2.0 TS 16V	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
147	GTA 3.2 V6	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
147	GTA SELESPEED	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
147	SELESPEED	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	1.6 TS 16V	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	1.8 TS 16V	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	1.9 JTD	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	1.9 JTD 16V	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	2.0 TS 16V	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	2.4 JTD 10V	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	2.4 JTD 20V	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	2.5 V6 24V	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	GTA 3.2 V6	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	GTA SELESPEED	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	JTS 2.0	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	JTS SELESPEED	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
156 MY	SELESPEED	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
GT	1.8 TS 16V	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
GT	1.9 JTD 16V	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
GT	3. 2 V6 24V	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
GT	JTS 2.0	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
166	'03 2.0 TS 16V	Safety	TRW MY 99 Airbag (2F-2P-2L-I)	•	•	•	•	•	0
166	'03 2.4 JTD 20V	Safety	TRW MY 99 Airbag (2F-2P-2L-I)	•	•	•	•	•	0
166	'03 2.5 V6 24V	Safety	TRW MY 99 Airbag (2F-2P-2L-I)	•	•	•	•	•	0
166	'03 3.0 V6 24V	Safety	TRW MY 99 Airbag (2F-2P-2L-I)	•	•	•	•	•	0
166	'03 3.2 V6 24V	Safety	TRW MY 99 Airbag (2F-2P-2L-I)	•	•	•	•	•	0
166	2.0 TS 16V	Safety	TRW MY 99 Airbag (2F-2P-2L-I)	•	•	•	•	•	0
166	2. 0 V6 TB	Safety	TRW MY 99 Airbag (2F-2P-2L-I)	•	•	•	•	•	0
166	2.4 JTD	Safety	TRW MY 99 Airbag (2F-2P-2L-I)	•	•	•	•	•	0
166	2.5 V6 24V	Safety	TRW MY 99 Airbag (2F-2P-2L-I)	•	•	•	•	•	0
166	3. 0 V6 24V	Safety	TRW MY 99 Airbag (2F-2P-2L-I)	•	•	•	•	•	0
166	'03 2.0 TS 16V	Safety	TRW MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes		Active Test	Specil Function
166	'03 2.4 JTD 20V	Safety	TRW MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
166	'03 2.5 V6 24V	Safety	TRW MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
166	'03 3.0 V6 24V	Safety	TRW MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
166	'03 3.2 V6 24V	Safety	TRW MY 99 Airbag (2F-2P-2L-2T-I)	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Safety	Bosch ABS 5.7	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Safety	Bosch ABS 5.7	•	•	•	•	•	0
147	1.9 JTD	Safety	Bosch ABS 5.7	•	•	•	•	•	0
147	1.9 JTD 16V	Safety	Bosch ABS 5.7	•	•	•	•	•	0
147	2.0 TS 16V	Safety	Bosch ABS 5.7	•	•	•	•	•	0
147	GTA 3.2 V6	Safety	Bosch ABS 5.7	•	•	•	•	•	0
147	GTA SELESPEED	Safety	Bosch ABS 5.7	•	•	•	•	•	0
147	SELESPEED	Safety	Bosch ABS 5.7	•	•	•	•	•	0
156 MY	1.6 TS 16V	Safety	Bosch ABS 5.7	•	•	•	•	•	0
156 MY	1.8 TS 16V	Safety	Bosch ABS 5.7	•	•	•	•	•	0
156 MY	1.9 JTD	Safety	Bosch ABS 5.7	•	•	•	•	•	0
156 MY	1.9 JTD 16V	Safety	Bosch ABS 5.7	•	•	•	•	•	0
156 MY	2.0 TS 16V	Safety	Bosch ABS 5.7	•	•	•	•	•	0
156 MY	2.4 JTD 10V	Safety	Bosch ABS 5.7	•	•	•	•	•	0
156 MY	2.4 JTD 20V	Safety	Bosch ABS 5.7	•	•	•	•	•	0
156 MY	2.5 V6 24V	Safety	Bosch ABS 5.7	•	•	•	•	•	0
156 MY	GTA SELESPEED	Safety	Bosch ABS 5.7	•	•	•	•	•	0
156 MY	JTS 2.0	Safety	Bosch ABS 5.7	•	•	•	•	•	0
156 MY	JTS SELESPEED	Safety	Bosch ABS 5.7	•	•	•	•	•	0
156 MY	SELESPEED	Safety	Bosch ABS 5.7	•	•	•	•	•	0
GT	1.8 TS 16V	Safety	Bosch ABS 5.7	•	•	•	•	•	0
GT	1.9 JTD 16V	Safety	Bosch ABS 5.7	•	•	•	•	•	0
GT	3. 2 V6 24V	Safety	Bosch ABS 5.7	•	•	•	•	•	0
GT	JTS 2.0	Safety	Bosch ABS 5.7	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
147	1.9 JTD	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
147	1.9 JTD 16V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
147	2.0 TS 16V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
147	GTA 3.2 V6	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
147	GTA SELESPEED	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
147	SELESPEED	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
156 MY	1.6 TS 16V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
156 MY	1.8 TS 16V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
156 MY	1.9 JTD	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
156 MY	1.9 JTD 16V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
156 MY	2. 0 TS 16V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes		Active Test	Specil Function
156 MY	2.4 JTD 10V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
156 MY	2.4 JTD 20V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
156 MY	2.5 V6 24V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
156 MY	GTA SELESPEED	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
156 MY	JTS 2.0	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
156 MY	JTS SELESPEED	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
156 MY	SELESPEED	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
166	'03 2.0 TS 16V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
166	'03 2.4 JTD 20V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
166	'03 2.5 V6 24V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
166	'03 3.0 V6 24V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
166	'03 3.2 V6 24V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
166	2.0 TS 16V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
166	2.4 JTD	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
166	2.5 V6 24V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
166	3. 0 V6 24V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
GT	1.8 TS 16V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
GT	1.9 JTD 16V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
GT	3. 2 V6 24V	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
GT	JTS 2.0	Safety	Bosch ABS 5.7 VDC	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
147	1.9 JTD	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
147	1.9 JTD 16V	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
147	2. 0 TS 16V	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
147	GTA 3.2 V6	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
147	GTA SELESPEED	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
147	SELESPEED	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
156 MY	1.6 TS 16V	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
156 MY	1.8 TS 16V	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
156 MY	1.9 JTD	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
156 MY	1.9 JTD 16V	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
156 MY	2. 0 TS 16V	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
156 MY	2.4 JTD 10V	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
156 MY	2. 4 JTD 20V	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
156 MY	2. 5 V6 24V	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
156 MY	GTA SELESPEED	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
156 MY	JTS 2.0	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
156 MY	JTS SELESPEED	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
156 MY	SELESPEED	Safety	Bosch ABS 5.7 ASR/TC	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Instrumentation		•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
147	1.6 TS 16V 120CV	Instrumentation	Marelli Connect	•	•	•	•	•	0
147	1.9 JTD	Instrumentation	Marelli Connect	•	•	•	•	•	0
147	1.9 JTD 16V	Instrumentation	Marelli Connect	•	•	•	•	•	0
147	2. 0 TS 16V	Instrumentation	Marelli Connect	•	•	•	•	•	0
147	GTA 3.2 V6	Instrumentation	Marelli Connect	•	•	•	•	•	0
147	GTA SELESPEED	Instrumentation	Marelli Connect	•	•	•	•	•	0
147	SELESPEED	Instrumentation	Marelli Connect	•	•	•	•	•	0
GT	1.8 TS 16V	Instrumentation	Marelli Connect	•	•	•	•	•	0
GT	1.9 JTD 16V	Instrumentation	Marelli Connect	•	•	•	•	•	0
GT	3. 2 V6 24V	Instrumentation	Marelli Connect	•	•	•	•	•	0
GT	JTS 2.0	Instrumentation	Marelli Connect	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Other systems	TRW driver's door	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Other systems	TRW driver's door	•	•	•	•	•	0
147	1.9 JTD	Other systems	TRW driver's door	•	•	•	•	•	0
147	1.9 JTD 16V	Other systems	TRW driver's door	•	•	•	•	•	0
147	2.0 TS 16V	Other systems	TRW driver's door	•	•	•	•	•	0
147	GTA 3.2 V6	Other systems	TRW driver's door	•	•	•	•	•	0
147	GTA SELESPEED	Other systems	TRW driver's door	•	•	•	•	•	0
147	SELESPEED	Other systems	TRW driver's door	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Other systems	TRW Boot	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Other systems	TRW Boot	•	•	•	•	•	0
147	1.9 JTD	Other systems	TRW Boot	•	•	•	•	•	0
147	1.9 JTD 16V	Other systems	TRW Boot	•	•	•	•	•	0
147	2.0 TS 16V	Other systems	TRW Boot	•	•	•	•	•	0
147	GTA 3.2 V6	Other systems	TRW Boot	•	•	•	•	•	0
147	GTA SELESPEED	Other systems	TRW Boot	•	•	•	•	•	0
147	SELESPEED	Other systems	TRW Boot	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Safety	Marelli Body Computer	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Safety	Marelli Body Computer	•	•	•	•	•	0
147	1.9 JTD	Safety	Marelli Body Computer	•	•	•	•	•	0
147	1.9 JTD 16V	Safety	Marelli Body Computer	•	•	•	•	•	0
147	2.0 TS 16V	Safety	Marelli Body Computer	•	•	•	•	•	0
147	GTA 3.2 V6	Safety	Marelli Body Computer	•	•	•	•	•	0
147	GTA SELESPEED	Safety	Marelli Body Computer	•	•	•	•	•	0
147	SELESPEED	Safety	Marelli Body Computer	•	•	•	•	•	0
GT	1.8 TS 16V	Safety	Marelli Body Computer	•	•	•	•	•	0
GT	1.9 JTD 16V	Safety	Marelli Body Computer	•	•	•	•	•	0
GT	3. 2 V6 24V	Safety	Marelli Body Computer	•	•	•	•	•	0
GT	JTS 2.0	Safety	Marelli Body Computer	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Instrumentation	Mannesman VDO instrument panel	•	•	•	•	•	0064 0032 0042 0034

Mode1	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
147	1.6 TS 16V 120CV	Instrumentation	Mannesman VDO instrument panel	•	•	•	•	•	0064 0032 0042 0034
147	1.9 JTD	Instrumentation	Mannesman VDO instrument panel	•	•	•	•	•	0064 0032 0042 0034
147	1.9 JTD 16V	Instrumentation	Mannesman VDO instrument panel	•	•	•	•	•	0064 0032 0042 0034
147	2.0 TS 16V	Instrumentation	Mannesman VDO instrument panel	•	•	•	•	•	0064 0032 0042 0034
147	GTA 3.2 V6	Instrumentation	Mannesman VDO instrument panel	•	•	•	•	•	0064 0032 0042 0034
147	GTA SELESPEED	Instrumentation	Mannesman VDO instrument panel	•	•	•	•	•	0064 0032 0042 0034
147	SELESPEED	Instrumentation	Mannesman VDO instrument panel	•	•	•	•	•	0064 0032 0042 0034
GT	1.8 TS 16V	Instrumentation	Mannesman VDO instrument panel	•	•	•	•	•	0064 0032 0042 0034
GT	1.9 JTD 16V	Instrumentation	Mannesman VDO instrument panel	•	•	•	•	•	0064 0032 0042 0034
GT	3. 2 V6 24V	Instrumentation	Mannesman VDO instrument panel	•	•	•	•	•	0064 0032 0042 0034
GT	JTS 2.0	Instrumentation	Mannesman VDO instrument panel	•	•	•	•	•	0064 0032 0042 0034
147	1.6 TS 16V 105CV	Engine - Gearbox	Bosch Motronic Me7.3.1 EOBD injection (2 lambda sensors)	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
147	2.0 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
147	GTA 3.2 V6	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
147	GTA SELESPEED	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
147	SELESPEED	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
156	1.6 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
156	1.8 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
156	2.0 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
156	SELESPEED	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
156 MY	1.6 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
156 MY	1.8 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
156 MY	GTA 3.2 V6	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
156 MY	GTA SELESPEED	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
156 MY	SELESPEED	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
166	'03 2.0 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
166	'03 3.2 V6 24V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
166	2.0 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
GT	1.8 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
GT	3. 2 V6 24V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
GTV	'03 2.0 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
GTV	'03 3.2 V6 24V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
GTV	'98 2.0 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
SPIDER	'03 2.0 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
SPIDER	'03 3.2 V6 24V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
SPIDER	'98 2.0 TS 16V	Engine -	Bosch Motronic Me7.3.1 EOBD injection	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Comfort	Delphi Climate control (Dual zone)	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Comfort	Delphi Climate control (Dual zone)	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
147	1.9 JTD	Comfort	Delphi Climate control (Dual zone)	•	•	•	•	•	0
147	1.9 JTD 16V	Comfort	Delphi Climate control (Dual zone)	•	•	•	•	•	0
147	2.0 TS 16V	Comfort	Delphi Climate control (Dual zone)	•	•	•	•	•	0
147	GTA 3.2 V6	Comfort	Delphi Climate control (Dual zone)	•	•	•	•	•	0
147	GTA SELESPEED	Comfort	Delphi Climate control (Dual zone)	•	•	•	•	•	0
147	SELESPEED	Comfort	Delphi Climate control (Dual zone)	•	•	•	•	•	0
GT	1.8 TS 16V	Comfort	Delphi Climate control (Dual zone)	•	•	•	•	•	0
GT	1.9 JTD 16V	Comfort	Delphi Climate control (Dual zone)	•	•	•	•	•	0
GT	3. 2 V6 24V	Comfort	Delphi Climate control (Dual zone)	•	•	•	•	•	0
GT	JTS 2.0	Comfort	Delphi Climate control (Dual zone)	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Comfort	Delphi Climate control (Single zone)	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Comfort	Delphi Climate control (Single zone)	•	•	•	•	•	0
147	1.9 JTD	Comfort	Delphi Climate control (Single zone)	•	•	•	•	•	0
147	1.9 JTD 16V	Comfort	Delphi Climate control (Single zone)	•	•	•	•	•	0
147	2.0 TS 16V	Comfort	Delphi Climate control (Single zone)	•	•	•	•	•	0
147	GTA 3.2 V6	Comfort	Delphi Climate control (Single zone)	•	•	•	•	•	0
147	GTA SELESPEED	Comfort	Delphi Climate control (Single zone)	•	•	•	•	•	0
147	SELESPEED	Comfort	Delphi Climate control (Single zone)	•	•	•	•	•	0
GT	1.8 TS 16V	Comfort	Delphi Climate control (Single zone)	•	•	•	•	•	0
GT	1.9 JTD 16V	Comfort	Delphi Climate control (Single zone)	•	•	•	•	•	0
GT	3. 2 V6 24V	Comfort	Delphi Climate control (Single zone)	•	•	•	•	•	0
GT	JTS 2.0	Comfort	Delphi Climate control (Single zone)	•	•	•	•	•	0
156	2.5 V6 24V	Engine -	Bosch Motronic EOBD ME3.1 Injection (eng.	•	•	•	•	•	0
156 MY	2.5 V6 24V	Engine -	Bosch Motronic EOBD ME3.1 Injection (eng.	•	•	•	•	•	0
166	'03 2.5 V6 24V	Engine -	Bosch Motronic EOBD ME3.1 Injection (eng.	•	•	•	•	•	0
166	'03 3.0 V6 24V	Engine -	Bosch Motronic EOBD ME3.1 Injection (eng.	•	•	•	•	•	0
166	2.5 V6 24V	Engine -	Bosch Motronic EOBD ME3.1 Injection (eng.	•	•	•	•	•	0
166	3.0 V6 24V	Engine -	Bosch Motronic EOBD ME3.1 Injection (eng.	•	•	•	•	•	0
GTV	'98 3.0 V6 24V	Engine -	Bosch Motronic EOBD ME3.1 Injection (eng.	•	•	•	•	•	0
SPIDER	'98 3.0 V6	Engine -	Bosch Motronic EOBD ME3.1 Injection (eng.	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
147	1.9 JTD	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
147	1.9 JTD 16V	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
147	2.0 TS 16V	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
147	GTA 3.2 V6	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
147	GTA SELESPEED	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
147	SELESPEED	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
156 MY	1.6 TS 16V	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
156 MY	1.8 TS 16V	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
156 MY	1.9 JTD	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
156 MY	1.9 JTD 16V	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
156 MY	2.0 TS 16V	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
156 MY	2.4 JTD 10V	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
156 MY	2.4 JTD 20V	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
156 MY	2.5 V6 24V	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
156 MY	GTA 3.2 V6	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
156 MY	GTA SELESPEED	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
156 MY	JTS 2.0	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
156 MY	JTS SELESPEED	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
156 MY	SELESPEED	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
GT	1.8 TS 16V	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
GT	1.9 JTD 16V	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
GT	3. 2 V6 24V	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
GT	JTS 2.0	Other systems	Bosch discharge headlamp (left)	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
147	1.6 TS 16V 120CV	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
147	1.9 JTD	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
147	1.9 JTD 16V	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
147	2.0 TS 16V	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
147	GTA 3.2 V6	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
147	GTA SELESPEED	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
147	SELESPEED	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	1.6 TS 16V	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	1.8 TS 16V	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	1.9 JTD	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	1.9 JTD 16V	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	2.0 TS 16V	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	2.4 JTD 10V	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	2.4 JTD 20V	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	2.5 V6 24V	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	GTA 3.2 V6	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	GTA SELESPEED	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	JTS 2.0	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	JTS SELESPEED	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
156 MY	SELESPEED	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
GT	1.8 TS 16V	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
GT	1.9 JTD 16V	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
GT	3. 2 V6 24V	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0
GT	JTS 2.0	Other systems	Bosch discharge headlamp (right)	•	•	•	•	0	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
147	1.9 JTD	Engine - Gearbox	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	•	•	•	•	•	0
156	1.9 JTD	Engine - Gearbox	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	•	•	•	•	•	0
156	2. 4 JTD	Engine - Gearbox	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	•	•	•	•	•	0
156 MY	1.9 JTD	Engine - Gearbox	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	•	•	•	•	•	0
156 MY	2.4 JTD 10V	Engine - Gearbox	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	•	•	•	•	•	0
166	2.4 JTD	Engine - Gearbox	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	•	•	•	•	•	0
159	1.8 16V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
159	1.8 JTS TB 16V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
159	1.9 JTS 16V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
159	1.9 MJET 16V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
159	1.9 MJET 8V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
159	2.0 JTD 16V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
159	2. 2 JTS 16V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
159	2.4 MJET 20V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
159	3. 2 V6 24V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
BRERA	2. 0 JTD 16V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Safety	ESP TRW Lucas ABS	•	•	•	•	•	0
147	1. 6 TS 16V 120CV	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0
147	2.0 TS 16V	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0
147	SELESPEED	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0
156	1.6 TS 16V	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0
156	2.0 TS 16V	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0
156	SELESPEED	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0
156 MY	2.0 TS 16V	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0
156 MY	GTA 3.2 V6	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0
156 MY	SELESPEED	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GTV	'03 2.0 TS 16V	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0
GTV	'98 2.0 TS 16V	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0
SPIDER	'03 2.0 TS 16V	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0
SPIDER	'98 2.0 TS 16V	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside EEC (2 lambdas)	•	•	•	•	•	0
156	2.5 V6 24V	Engine - Gearbox	Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC	•	•	•	•	•	0
166	'03 2.5 V6 24V	Engine - Gearbox	Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC	•	•	•	•	•	0
166	'03 3.0 V6 24V	Engine - Gearbox	Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC	•	•	•	•	•	0
166	2.5 V6 24V	Engine - Gearbox	Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC	•	•	•	•	•	0
166	3.0 V6 24V	Engine - Gearbox	Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC	•	•	•	•	•	0
GTV	'98 3.0 V6 24V	Engine - Gearbox	Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC	•	•	•	•	•	0
SPIDER	'98 3.0 V6	Engine - Gearbox	Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC	•	•	•	•	•	0
159	1.8 16V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
159	1.8 JTS TB 16V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
159	1.9 JTS 16V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
159	1.9 MJET 16V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
159	1.9 MJET 8V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
159	2.0 JTD 16V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
159	2.2 JTS 16V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
159	2.4 MJET 20V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
159	3.2 V6 24V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
BRERA	1.8 JTS TB 16V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
BRERA	2.0 JTD 16V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
BRERA	2.2 JTS 16V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
BRERA	2.4 MJET 20V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
BRERA	3.2 V6 24V	Comfort	Valeo Parking control unit	•	•	•	•	0	0
156 MY	JTS 2.0	Engine -	Bosch Motronic MeD7.11 EOBD injection	•	•	•	•	•	0
156 MY	JTS SELESPEED	Engine -	Bosch Motronic MeD7.11 EOBD injection	•	•	•	•	•	0
GT	JTS 2.0	Engine -	Bosch Motronic MeD7.11 EOBD injection	•	•	•	•	•	0
GTV	'03 2.0 JTS	Engine -	Bosch Motronic MeD7.11 EOBD injection	•	•	•	•	•	0
SPIDER	'03 2.0 JTS	Engine -	Bosch Motronic MeD7.11 EOBD injection	•	•	•	•	•	0
156 MY	1.6 TS 16V	Comfort	Delphi Climate Control	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
156 MY	1.8 TS 16V	Comfort	Delphi Climate Control	•	•	•	•	•	0
156 MY	1.9 JTD	Comfort	Delphi Climate Control	•	•	•	•	•	0
156 MY	1.9 JTD 16V	Comfort	Delphi Climate Control	•	•	•	•	•	0
156 MY	2.0 TS 16V	Comfort	Delphi Climate Control	•	•	•	•	•	0
156 MY	2. 4 JTD 10V	Comfort	Delphi Climate Control	•	•	•	•	•	0
156 MY	2.4 JTD 20V	Comfort	Delphi Climate Control	•	•	•	•	•	0
156 MY	2.5 V6 24V	Comfort	Delphi Climate Control	•	•	•	•	•	0
156 MY	GTA 3.2 V6	Comfort	Delphi Climate Control	•	•	•	•	•	0
156 MY	GTA SELESPEED	Comfort	Delphi Climate Control	•	•	•	•	•	0
156 MY	JTS 2.0	Comfort	Delphi Climate Control	•	•	•	•	•	0
156 MY	JTS SELESPEED	Comfort	Delphi Climate Control	•	•	•	•	•	0
156 MY	SELESPEED	Comfort	Delphi Climate Control	•	•	•	•	•	0
1.47	1 0 ITD 10V	Engine -	Bosch EDC16 CF3/EOBD Diesel Injection						
147	1.9 JTD 16V	Gearbox	(1.9/2.4 eng.)	•	•	•	•	•	0
156 MY	1.9 JTD 16V	Engine -	Bosch EDC16 CF3/EOBD Diesel Injection		•	•	•	•	0
		Gearbox	(1.9/2.4 eng.)	+				_	
156 MY	2.4 JTD 20V	Engine - Gearbox	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	•	•	•	•	•	0
		Engine -	Bosch EDC16 CF3/EOBD Diesel Injection	<u> </u>		_	_	_	
166	'03 2.4 JTD 20V	Gearbox	(1. 9/2. 4 eng.)	•	•	•	•	•	0
GT	1.9 JTD 16V	Engine -	Bosch EDC16 CF3/EOBD Diesel Injection	•	•	•	•	•	0
		Gearbox	(1.9/2.4 eng.)			_	_		
156 MY	JTS 2.0	Engine -	Bosch Motronic MeD7.11 Extra EEC	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Safety	Bosch 8 ABS	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Safety	Bosch 8 ABS	•	•	•	•	•	0
147	1.9 JTD	Safety	Bosch 8 ABS	•	•	•	•	•	0
147	1.9 JTD 16V	Safety	Bosch 8 ABS	•	•	•	•	•	0
147	2.0 TS 16V	Safety	Bosch 8 ABS	•	•	•	•	•	0
147	GTA 3.2 V6	Safety	Bosch 8 ABS	•	•	•	•	•	0
147	GTA SELESPEED	Safety	Bosch 8 ABS	•	•	•	•	•	0
147	SELESPEED	Safety	Bosch 8 ABS	•	•	•	•	•	0
GT	1.8 TS 16V	Safety	Bosch 8 ABS	•	•	•	•	•	0
GT	1.9 JTD 16V	Safety	Bosch 8 ABS	•	•	•	•	•	0
GT	3. 2 V6 24V	Safety	Bosch 8 ABS	•	•	•	•	•	0
GT	JTS 2.0	Safety	Bosch 8 ABS	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
147	1.9 JTD	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
147	1.9 JTD 16V	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
147	2.0 TS 16V	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
147	GTA 3.2 V6	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes		Active Test	Specil Function
147	GTA SELESPEED	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
147	SELESPEED	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
166	'03 2.0 TS 16V	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
166	'03 2.4 JTD 20V	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
166	'03 2.5 V6 24V	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
166	'03 3.0 V6 24V	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
166	'03 3.2 V6 24V	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
MITO	1.3 MJET 16V	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
MITO	1.4 16V	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
MITO	1.4 TURBO 16V	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
MITO	1.6 MJET 16V	Other systems	Valeo discharge headlamp (left)	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Safety	Bosch 8 VDC ABS	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Safety	Bosch 8 VDC ABS	•	•	•	•	•	0
147	1.9 JTD	Safety	Bosch 8 VDC ABS	•	•	•	•	•	0
147	1.9 JTD 16V	Safety	Bosch 8 VDC ABS	•	•	•	•	•	0
147	2. 0 TS 16V	Safety	Bosch 8 VDC ABS	•	•	•	•	•	0
147	GTA 3.2 V6	Safety	Bosch 8 VDC ABS	•	•	•	•	•	0
147	GTA SELESPEED	Safety	Bosch 8 VDC ABS	•	•	•	•	•	0
147	SELESPEED	Safety	Bosch 8 VDC ABS	•	•	•	•	•	0
GT	1.8 TS 16V	Safety	Bosch 8 VDC ABS	•	•	•	•	•	0
GT	1.9 JTD 16V	Safety	Bosch 8 VDC ABS	•	•	•	•	•	0
GT	3. 2 V6 24V	Safety	Bosch 8 VDC ABS	•	•	•	•	•	0
GT	JTS 2.0	Safety	Bosch 8 VDC ABS	•	•	•	•	•	0
156 MY	1.6 TS 16V	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
156 MY	1.8 TS 16V	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
156 MY	1.9 JTD	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
156 MY	1.9 JTD 16V	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
156 MY	2.0 TS 16V	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
156 MY	2.4 JTD 10V	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
156 MY	2.4 JTD 20V	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
156 MY	2.5 V6 24V	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
156 MY	GTA 3.2 V6	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
156 MY	GTA SELESPEED	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
156 MY	JTS 2.0	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
156 MY	JTS SELESPEED	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
156 MY	SELESPEED	Comfort	Delphi Climate Control MY 03 (Single-	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
147	1.9 JTD	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
147	1.9 JTD 16V	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
147	2.0 TS 16V	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
147	GTA 3.2 V6	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
147	GTA SELESPEED	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
147	SELESPEED	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
166	'03 2.0 TS 16V	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
166	'03 2.4 JTD 20V	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
166	'03 2.5 V6 24V	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
166	'03 3.0 V6 24V	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
166	'03 3.2 V6 24V	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
MITO	1.3 MJET 16V	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
MITO	1.4 16V	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
MITO	1.4 TURBO 16V	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
MITO	1.6 MJET 16V	Other systems	Valeo discharge headlamp (right)	•	•	•	•	•	0
166	'03 2.4 JTD 20V	Engine -	AISIN YLII 5 Automatic Gearbox (1)	•	•	•	•	•	0
GT	1.8 TS 16V	Other systems	TRW Driver's Door (1)	•	•	•	•	•	0
GT	1.9 JTD 16V	Other systems	TRW Driver's Door (1)	•	•	•	•	•	0
GT	3. 2 V6 24V	Other systems	TRW Driver's Door (1)	•	•	•	•	•	0
GT	JTS 2.0	Other systems	TRW Driver's Door (1)	•	•	•	•	•	0
159	1.8 16V	Safety	TRW Lucas ABS	•	•	•	•	•	0
159	1.8 JTS TB 16V	Safety	TRW Lucas ABS	•	•	•	•	•	0
159	1.9 JTS 16V	Safety	TRW Lucas ABS	•	•	•	•	•	0
159	1.9 MJET 16V	Safety	TRW Lucas ABS	•	•	•	•	•	0
159	1.9 MJET 8V	Safety	TRW Lucas ABS	•	•	•	•	•	0
159	2.0 JTD 16V	Safety	TRW Lucas ABS	•	•	•	•	•	0
159	2. 2 JTS 16V	Safety	TRW Lucas ABS	•	•	•	•	•	0
159	2.4 MJET 20V	Safety	TRW Lucas ABS	•	•	•	•	•	0
159	3. 2 V6 24V	Safety	TRW Lucas ABS	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Safety	TRW Lucas ABS	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Safety	TRW Lucas ABS	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Safety	TRW Lucas ABS	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Safety	TRW Lucas ABS	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Safety	TRW Lucas ABS	•	•	•	•	•	0
147	GTA SELESPEED	Engine -	Marelli Automatic Gearbox SELESPEED	•	•	•	•	•	0118
111	OTH OLLEGIELD	Gearbox	CFC218F (1)						0110
147	SELESPEED	Engine - Gearbox	Marelli Automatic Gearbox SELESPEED CFC208F (1)	•	•	•	•	•	0118
GT	JTS 2.0	Engine - Gearbox	Marelli Automatic Gearbox SELESPEED CFC208F (1)	•	•	•	•	•	0118
166	'03 2.0 TS 16V	Comfort	Valeo Parking control unit (1)	•	•	•	•	0	0
166	'03 2.4 JTD 20V	Comfort	Valeo Parking control unit (1)	•	•	•	•	0	0
166	'03 2.5 V6 24V	Comfort	Valeo Parking control unit (1)	•	•	•	•	0	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
166	'03 3.0 V6 24V	Comfort	Valeo Parking control unit (1)	•	•	•	•	0	0
166	'03 3.2 V6 24V	Comfort	Valeo Parking control unit (1)	•	•	•	•	0	0
147	1.9 JTD	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	•	•	•	•	•	0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020
147	1.9 JTD 16V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	•	•	•	•	•	0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020
156 MY	1.9 JTD 16V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	•	•	•	•	•	0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020
159	1.9 MJET 16V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	•	•	•	•	•	0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020
159	1.9 MJET 8V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	•	•	•	•	•	0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020
159	2.4 MJET 20V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	•	•	•	•	•	0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020
166	'03 2.4 JTD 20V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	•	•	•	•	•	0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020
BRERA	2.4 MJET 20V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	•	•	•	•	•	0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020
GT	1.9 JTD 16V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	•	•	•	•	•	0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020
159	1.8 16V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
159	1.8 JTS TB 16V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
159	1.9 JTS 16V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
159	1.9 MJET 16V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
159	1.9 MJET 8V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
159	2.0 JTD 16V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
159	2. 2 JTS 16V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
159	2.4 MJET 20V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
159	3. 2 V6 24V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Comfort	Driver's seat Lear 2	•	•	•	•	•	0
159	1.8 16V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
159	1.8 JTS TB 16V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
159	1.9 JTS 16V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
159	1.9 MJET 16V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
159	1.9 MJET 8V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
159	2.0 JTD 16V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
159	2.2 JTS 16V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
159	2.4 MJET 20V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
159	3.2 V6 24V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
BRERA	2.2 JTS 16V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
BRERA	3.2 V6 24V	Comfort	Passenger seat Lear 2	•	•	•	•	•	0
159	1.8 16V	Other systems	Front Door G.E. PROCOND	•	•	•	•	•	0
159	1.8 JTS TB 16V	Other systems	Front Door G.E. PROCOND	•	•	•	•	•	0
159	1.9 JTS 16V	Other systems	Front Door G.E. PROCOND	•	•	•	•	•	0
159	1.9 MJET 16V	Other systems	Front Door G.E. PROCOND	•	•	•	•	•	0
159	1.9 MJET 8V	Other systems	Front Door G.E. PROCOND	•	•	•	•	•	0
159	2.0 JTD 16V	Other systems	Front Door G.E. PROCOND	•	•	•	•	•	0
159	2. 2 JTS 16V	Other systems	Front Door G.E. PROCOND	•	•	•	•	•	0
159	2.4 MJET 20V	Other systems	Front Door G.E. PROCOND	•	•	•	•	•	0
159	3. 2 V6 24V	Other systems	Front Door G.E. PROCOND	•	•	•	•	•	0
159	1.8 16V	Other systems	Driver's Door G.E. PROCOND 2	•	•	•	•	•	0
159	1.8 JTS TB 16V	Other systems	Driver's Door G.E. PROCOND 2	•	•	•	•	•	0
159	1.9 JTS 16V	Other systems	Driver's Door G.E. PROCOND 2	•	•	•	•	•	0
159	1.9 MJET 16V	Other systems	Driver's Door G.E. PROCOND 2	•	•	•	•	•	0
159	1.9 MJET 8V	Other systems	Driver's Door G.E. PROCOND 2	•	•	•	•	•	0
159	2.0 JTD 16V	Other systems	Driver's Door G.E. PROCOND 2	•	•	•	•	•	0
159	2.2 JTS 16V	Other systems	Driver's Door G.E. PROCOND 2	•	•	•	•	•	0
159	2.4 MJET 20V	Other systems	Driver's Door G.E. PROCOND 2	•	•	•	•	•	0
159	3.2 V6 24V	Other systems	Driver's Door G.E. PROCOND 2	•	•	•	•	•	0
159	1.8 16V	Other systems	Passenger Door G.E. PROCOND 2	•	•	•	•	•	0
159	1.8 JTS TB 16V	Other systems	Passenger Door G.E. PROCOND 2	•	•	•	•	•	0
159	1.9 JTS 16V	Other systems	Passenger Door G.E. PROCOND 2	•	•	•	•	•	0
159	1.9 MJET 16V	Other systems	Passenger Door G.E. PROCOND 2	•	•	•	•	•	0
159	1.9 MJET 8V	Other systems	Passenger Door G.E. PROCOND 2	•	•	•	•	•	0
159	2.0 JTD 16V	Other systems	Passenger Door G.E. PROCOND 2	•	•	•	•	•	0
159	2. 2 JTS 16V	Other systems	Passenger Door G.E. PROCOND 2	•	•	•	•	•	0
159	2.4 MJET 20V	Other systems	Passenger Door G.E. PROCOND 2	•	•	•	•	•	0
159	3. 2 V6 24V	Other systems	Passenger Door G.E. PROCOND 2	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
159	1.8 16V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
159	1.8 JTS TB 16V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
159	1.9 JTS 16V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
159	1.9 MJET 16V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
159	1.9 MJET 8V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
159	2.0 JTD 16V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
159	2. 2 JTS 16V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
159	2.4 MJET 20V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
159	3. 2 V6 24V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
BRERA	1.8 JTS TB 16V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
BRERA	2.0 JTD 16V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
BRERA	2. 2 JTS 16V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
BRERA	2.4 MJET 20V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
BRERA	3. 2 V6 24V	Instrumentation	Instrument panel Siemens 2	•	•	•	•	•	0070 0064 0065 0066 0034
159	1.8 16V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
159	1.8 JTS TB 16V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
159	1.9 JTS 16V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
159	1.9 MJET 16V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
159	1.9 MJET 8V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
159	2.0 JTD 16V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
159	2. 2 JTS 16V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
159	2.4 MJET 20V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
159	3. 2 V6 24V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
BRERA	3.2 V6 24V	Instrumentation	Marelli 3 Connect (multi-model)	•	•	•	•	•	0
159	1.8 16V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
159	1.8 JTS TB 16V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
159	1.9 JTS 16V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
159	1.9 MJET 16V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
159	1.9 MJET 8V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
159	2.0 JTD 16V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
159	2. 2 JTS 16V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
159	2.4 MJET 20V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
159	3. 2 V6 24V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
BRERA	2.2 JTS 16V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
BRERA	2.4 MJET 20V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Other systems	Litronic discharge headlamp (left)	•	•	•	•	•	0
159	1.8 16V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
159	1.8 JTS TB 16V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
159	1.9 JTS 16V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
159	1.9 MJET 16V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
159	1.9 MJET 8V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
159	2.0 JTD 16V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
159	2. 2 JTS 16V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
159	2.4 MJET 20V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
159	3. 2 V6 24V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
BRERA	1.8 JTS TB 16V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
BRERA	2.0 JTD 16V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
BRERA	2. 2 JTS 16V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
BRERA	2.4 MJET 20V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
BRERA	3. 2 V6 24V	Other systems	Litronic discharge headlamp (right)	•	•	•	•	0	0
159	1.8 16V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
159	1.8 JTS TB 16V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
159	1.9 JTS 16V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
159	1.9 MJET 16V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
159	1.9 MJET 8V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
159	2.0 JTD 16V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
159	2. 2 JTS 16V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
159	2.4 MJET 20V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
159	3. 2 V6 24V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Comfort	Climate control Delphi 2 (Single-zone)	•	•	•	•	•	0
159	1.8 16V	Other systems	Boot G.E. PROCOND 2	•	•	•	•	•	0
159	1.8 JTS TB 16V	Other systems	Boot G.E. PROCOND 2	•	•	•	•	•	0
159	1.9 JTS 16V	Other systems	Boot G.E. PROCOND 2	•	•	•	•	•	0
159	1.9 MJET 16V	Other systems	Boot G.E. PROCOND 2	•	•	•	•	•	0
159	1.9 MJET 8V	Other systems	Boot G. E. PROCOND 2	•	•	•	•	•	О
159	2.0 JTD 16V	Other systems	Boot G. E. PROCOND 2	•	•	•	•	•	Ο
159	2. 2 JTS 16V	Other systems	Boot G.E. PROCOND 2	•	•	•	•	•	Ο
159	2.4 MJET 20V	Other systems	Boot G.E. PROCOND 2	•	•	•	•	•	Ο
159	3. 2 V6 24V	Other systems	Boot G. E. PROCOND 2	•	•	•	•	•	0
159	1.8 16V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	О

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
159	1.8 JTS TB 16V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
159	1.9 JTS 16V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
159	1.9 MJET 16V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
159	1.9 MJET 8V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
159	2.0 JTD 16V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
159	2.2 JTS 16V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
159	2.4 MJET 20V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
159	3.2 V6 24V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
BRERA	2.2 JTS 16V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Comfort	Climate control Delphi (Two/Three-zone)	•	•	•	•	•	0
159	1.9 JTS 16V	Engine - Gearbox	Bosch Motronic Injection MeD7.6.1 CF4/EOBD (eng. 1.9/2.2)	•	•	•	•	•	0
159	2. 2 JTS 16V	Engine - Gearbox	Bosch Motronic Injection MeD7.6.1 CF4/EOBD (eng. 1.9/2.2)	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Engine - Gearbox	Bosch Motronic Injection MeD7.6.1 CF4/EOBD (eng. 1.9/2.2)	•	•	•	•	•	0
159	1.8 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
159	1.8 JTS TB 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
159	1.9 JTS 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
159	1.9 MJET 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
159	1.9 MJET 8V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
159	2.0 JTD 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
159	2.2 JTS 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
159	2.4 MJET 20V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
159	3. 2 V6 24V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
BRERA	2.2 JTS 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	•	•	•	•	•	0
159	1.8 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
159	1.8 JTS TB 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
159	1.9 JTS 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
159	1.9 MJET 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
159	1.9 MJET 8V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
159	2.0 JTD 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
159	2. 2 JTS 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
159	2.4 MJET 20V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
159	3.2 V6 24V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
BRERA	2.2 JTS 16V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Safety	Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I)	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Safety	Bosch 8 ASR ABS	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Safety	Bosch 8 ASR ABS	•	•	•	•	•	0
147	1.9 JTD	Safety	Bosch 8 ASR ABS	•	•	•	•	•	0
147	1.9 JTD 16V	Safety	Bosch 8 ASR ABS	•	•	•	•	•	0
147	2.0 TS 16V	Safety	Bosch 8 ASR ABS	•	•	•	•	•	0
147	GTA 3.2 V6	Safety	Bosch 8 ASR ABS	•	•	•	•	•	0
147	GTA SELESPEED	Safety	Bosch 8 ASR ABS	•	•	•	•	•	0
147	SELESPEED	Safety	Bosch 8 ASR ABS	•	•	•	•	•	0
GT	1.8 TS 16V	Safety	Bosch 8 ASR ABS	•	•	•	•	•	0
GT	1.9 JTD 16V	Safety	Bosch 8 ASR ABS	•	•	•	•	•	0
GT	3. 2 V6 24V	Safety	Bosch 8 ASR ABS	•	•	•	•	•	0
GT	JTS 2.0	Safety	Bosch 8 ASR ABS	•	•	•	•	•	0
159	1.8 16V	Safety	Body Computer Marelli 3	•	•	•	•	•	0
159	1.8 JTS TB 16V	Safety	Body Computer Marelli 3	•	•	•	•	•	0
159	1.9 JTS 16V	Safety	Body Computer Marelli 3	•	•	•	•	•	0
159	1.9 MJET 16V	Safety	Body Computer Marelli 3	•	•	•	•	•	0
159	1.9 MJET 8V	Safety	Body Computer Marelli 3	•	•	•	•	•	0
159	2.0 JTD 16V	Safety	Body Computer Marelli 3	•	•	•	•	•	0
159	2.2 JTS 16V	Safety	Body Computer Marelli 3	•	•	•	•	•	0
159	2.4 MJET 20V	Safety	Body Computer Marelli 3	•	•	•	•	•	0
159	3. 2 V6 24V	Safety	Body Computer Marelli 3	•	•	•	•	•	0
159	1.8 16V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
159	1.8 JTS TB 16V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
159	1.9 JTS 16V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
159	1.9 MJET 16V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
159	1.9 MJET 8V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
159	2.0 JTD 16V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
159	2.2 JTS 16V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
159	2. 4 MJET 20V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
159	3. 2 V6 24V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
BRERA	2. 0 JTD 16V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
BRERA	2. 4 MJET 20V	Safety	Steering Lock TRW 2	•	•	•	•	•	0

Mode1	Version	Group	System	ECU info.	Read Codes	Erase Codes		Active Test	Specil Function
BRERA	3.2 V6 24V	Safety	Steering Lock TRW 2	•	•	•	•	•	0
159	1.8 16V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
159	1.8 JTS TB 16V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
159	1.9 JTS 16V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
159	1.9 MJET 16V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
159	1.9 MJET 8V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
159	2.0 JTD 16V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
159	2.2 JTS 16V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
159	2.4 MJET 20V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
159	3.2 V6 24V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
BRERA	3.2 V6 24V	Safety	Electronic Key TRW (Teg Reader)	•	•	•	•	•	0
159	1.8 16V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
159	1.8 JTS TB 16V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
159	1.9 JTS 16V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
159	1.9 MJET 16V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
159	1.9 MJET 8V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
159	2.0 JTD 16V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
159	2. 2 JTS 16V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
159	2.4 MJET 20V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
159	3. 2 V6 24V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
BRERA	1.8 JTS TB 16V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
BRERA	2.0 JTD 16V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
BRERA	2. 2 JTS 16V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
BRERA	2.4 MJET 20V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
BRERA	3. 2 V6 24V	Safety	Tyre Pressure Control TRW 2	•	•	•	•	•	0007 0014 0005 0084 0012 0013 0006
159	1.9 MJET 16V	Engine -	Automatic Gearbox AISIN AF40-6	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
159	1.9 MJET 8V	Engine -	Automatic Gearbox AISIN AF40-6	•	•	•	•	•	0
159	2.4 MJET 20V	Engine -	Automatic Gearbox AISIN AF40-6	•	•	•	•	•	0
159	3. 2 V6 24V	Engine -	Automatic Gearbox AISIN AF40-6	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Engine -	Automatic Gearbox AISIN AF40-6	•	•	•	•	•	0
BRERA	3.2 V6 24V	Engine -	Automatic Gearbox AISIN AF40-6	•	•	•	•	•	0
GIULIETTA (191)	1.4 TURBO 16V	Instrumentation	Marelli/Microsoft Convergence (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.6 MJET 16V	Instrumentation	Marelli/Microsoft Convergence (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.8 JTS TB 16V	Instrumentation	Marelli/Microsoft Convergence (EP)	•	•	•	•	•	0
GIULIETTA (191)	2.0 MJET 16V	Instrumentation	Marelli/Microsoft Convergence (EP)	•	•	•	•	•	0
MITO	1.3 MJET 16V	Instrumentation	Marelli/Microsoft Convergence (EP)	•	•	•	•	•	0
MITO	1. 4 16V	Instrumentation	Marelli/Microsoft Convergence (EP)	•	•	•	•	•	0
MITO	1.4 TURBO 16V	Instrumentation	Marelli/Microsoft Convergence (EP)	•	•	•	•	•	0
MITO	1.6 MJET 16V	Instrumentation	Marelli/Microsoft Convergence (EP)	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
147	1.9 JTD	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
147	1.9 JTD 16V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
147	2. 0 TS 16V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
147	GTA 3.2 V6	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
147	GTA SELESPEED	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
147	SELESPEED	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
159	1.8 16V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
159	1.8 JTS TB 16V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
159	1.9 JTS 16V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
159	1.9 MJET 16V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
159	1.9 MJET 8V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
159	2.0 JTD 16V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
159	2. 2 JTS 16V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
159	2.4 MJET 20V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
159	3. 2 V6 24V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
GT	1.8 TS 16V		Marelli/Microsoft Convergence	•	•	•	•	•	0
GT	1.9 JTD 16V		Marelli/Microsoft Convergence	•	•	•	•	•	0
GT	3. 2 V6 24V		Marelli/Microsoft Convergence	•	•	•	•	•	0
GT	JTS 2.0	Instrumentation	Marelli/Microsoft Convergence	•	•	•	•	•	0
MITO	1.3 MJET 16V	Comfort	Denso Climate Control (EP)	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MITO	1.4 16V	Comfort	Denso Climate Control (EP)	•	•	•	•	•	0
MITO	1.4 TURBO 16V	Comfort	Denso Climate Control (EP)	•	•	•	•	•	0
MITO	1.6 MJET 16V	Comfort	Denso Climate Control (EP)	•	•	•	•	•	0
MITO	1.3 MJET 16V	Comfort	Denso Heater (EP)	•	•	•	•	•	0
MITO	1.6 MJET 16V	Comfort	Denso Heater (EP)	•	•	•	•	•	0
MITO	1.3 MJET 16V	Safety	TRW Tyre Pressure Control (EP)	•	•	•	•	•	0007 0005 0084 0012 0013 0006 0041 0014
MITO	1. 4 16V	Safety	TRW Tyre Pressure Control (EP)	•	•	•	•	•	0007 0005 0084 0012 0013 0006 0041 0014
MITO	1.4 TURBO 16V	Safety	TRW Tyre Pressure Control (EP)	•	•	•	•	•	0007 0005 0084 0012 0013 0006 0041 0014
MITO	1.6 MJET 16V	Safety	TRW Tyre Pressure Control (EP)	•	•	•	•	•	0007 0005 0084 0012 0013 0006 0041 0014
BRERA	1.8 JTS TB 16V	Safety	Body Computer Marelli 4	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Safety	Body Computer Marelli 4	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Safety	Body Computer Marelli 4	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Safety	Body Computer Marelli 4	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Safety	Body Computer Marelli 4	•	•	•	•	•	0
159	3. 2 V6 24V	Engine - Gearbox	Bosch Motronic MeD7.6.2 CF4/EOBD injection (eng. 3.2)	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Engine - Gearbox	Bosch Motronic MeD7.6.2 CF4/EOBD injection (eng. 3.2)	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Other systems	G.E. PROCOND 4 Driver's Door	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Other systems	G.E. PROCOND 4 Driver's Door	•	•	•	•	•	0
BRERA	2.2 JTS 16V	Other systems	G.E. PROCOND 4 Driver's Door	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Other systems	G.E. PROCOND 4 Driver's Door	•	•	•	•	•	0
BRERA	3.2 V6 24V	Other systems	G.E. PROCOND 4 Driver's Door	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Safety	WEBASTO hood/luggage compartment	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Safety	WEBASTO hood/luggage compartment	•	•	•	•	•	0
BRERA	2.2 JTS 16V	Safety	WEBASTO hood/luggage compartment	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Safety	WEBASTO hood/luggage compartment	•	•	•	•	•	0
BRERA	3.2 V6 24V	Safety	WEBASTO hood/luggage compartment	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Other systems	G.E. PROCOND 4 Passenger's Door	•	•	•	•	•	0
BRERA	2.0 JTD 16V		G.E. PROCOND 4 Passenger's Door	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Other systems	G.E. PROCOND 4 Passenger's Door	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Other systems	G.E. PROCOND 4 Passenger's Door	•	•	•	•	•	0
BRERA	3.2 V6 24V	Other systems	G.E. PROCOND 4 Passenger's Door	•	•	•	•	•	0
159	1.8 16V	Engine -	Siemens VDO CF4/EOBD injection (eng. 1.8)	•	•	•	•	•	0
147	1.6 TS 16V 105CV	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
147	1.6 TS 16V 120CV	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
147	1.9 JTD		Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
147	1.9 JTD 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
147	2.0 TS 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
147	GTA 3.2 V6	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
147	GTA SELESPEED	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
147	SELESPEED	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
159	1.8 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
159	1.8 JTS TB 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
159	1.9 JTS 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
159	1.9 MJET 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
159	1.9 MJET 8V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
159	2.0 JTD 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
159	2. 2 JTS 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
159	2.4 MJET 20V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
159	3. 2 V6 24V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
BRERA	2.2 JTS 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
GT	1.8 TS 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
GT	1.9 JTD 16V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
GT	3. 2 V6 24V	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
GT	JTS 2.0	Instrumentation	Marelli/Microsoft C3 Convergence	•	•	•	•	•	0
MITO	1.3 MJET 16V	Instrumentation	Marelli/Microsoft C3 (EP) Convergence	•	•	•	•	•	0
MITO	1.4 16V	Instrumentation	Marelli/Microsoft C3 (EP) Convergence	•	•	•	•	•	0
MITO	1.4 TURBO 16V	Instrumentation	Marelli/Microsoft C3 (EP) Convergence	•	•	•	•	•	0
MITO	1.6 MJET 16V	Instrumentation	Marelli/Microsoft C3 (EP) Convergence	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Safety	TRW Air Bag MY 03 (2F-2P-2L-1G-I)	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Safety	TRW Air Bag MY 03 (2F-2P-2L-1G-I)	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Safety	TRW Air Bag MY 03 (2F-2P-2L-1G-I)	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Safety	TRW Air Bag MY 03 (2F-2P-2L-1G-I)	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Safety	TRW Air Bag MY 03 (2F-2P-2L-2G-I)	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Safety	TRW Air Bag MY 03 (2F-2P-2L-2G-I)	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Safety	TRW Air Bag MY 03 (2F-2P-2L-2G-I)	•	•	•	•	•	0
BRERA	3.2 V6 24V	Safety	TRW Air Bag MY 03 (2F-2P-2L-2G-I)	•	•	•	•	•	0
159	2. 2 JTS 16V	Engine -	Marelli SELESPEED CFC300 Automatic	•	•	•	•	•	0014 0118 0164 0172
BRERA	2. 2 JTS 16V	Engine -	Marelli SELESPEED CFC300 Automatic	•	•	•	•	•	0014 0118 0164 0172
GIULIETTA (191)	1. 4 TURBO 16V	Engine - Gearbox	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	•	•	•	•	•	0
MITO	1. 4 16V	Engine - Gearbox	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	•	•	•	•	•	0

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes		Active Test	Specil Function
MITO	1.4 TURBO 16V	Engine - Gearbox	Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4)	•	•	•	•	•	0
GIULIETTA (191)	1.4 TURBO 16V	Comfort	VALEO Parking Control unit (EP) 2	•	•	•	•	0	0
GIULIETTA (191)	1.6 MJET 16V	Comfort	VALEO Parking Control unit (EP) 2	•	•	•	•	0	0
GIULIETTA (191)	1.8 JTS TB 16V	Comfort	VALEO Parking Control unit (EP) 2	•	•	•	•	0	0
GIULIETTA (191)	2.0 MJET 16V	Comfort	VALEO Parking Control unit (EP) 2	•	•	•	•	0	0
MITO	1.3 MJET 16V	Comfort	VALEO Parking Control unit (EP) 2	•	•	•	•	0	0
MITO	1.4 16V	Comfort	VALEO Parking Control unit (EP) 2	•	•	•	•	0	0
MITO	1.4 TURBO 16V	Comfort	VALEO Parking Control unit (EP) 2	•	•	•	•	0	0
MITO	1.6 MJET 16V	Comfort	VALEO Parking Control unit (EP) 2	•	•	•	•	0	0
MITO	1.3 MJET 16V	Engine - Gearbox	Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2	•	•	•	•	•	0043 0014 0047 0046
159	2.0 JTD 16V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	•	•	•	•	•	0029 0058 0059 0060 0061 0030 0043 0014 0022 0080 0054 0057 0003 0020 0052 0047 0062 0046 0198 0199
BRERA	2.0 JTD 16V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	•	•	•	•	•	0029 0058 0059 0060 0061 0030 0043 0014 0022 0080 0054 0057 0003 0020 0052 0047 0062 0046 0198 0199
GIULIETTA (191)	1.4 TURBO 16V	Instrumentation	Siemens 3 instrument panel	•	•	•	•	•	0027 0070 0064 0066 0065
GIULIETTA (191)	1.6 MJET 16V	Instrumentation	Siemens 3 instrument panel	•	•	•	•	•	0027 0070 0064 0066 0065
GIULIETTA (191)	1.8 JTS TB 16V	Instrumentation	Siemens 3 instrument panel	•	•	•	•	•	0027 0070 0064 0066 0065
GIULIETTA (191)	2.0 MJET 16V	Instrumentation	Siemens 3 instrument panel	•	•	•	•	•	0027 0070 0064 0066 0065
MITO	1.3 MJET 16V	Instrumentation	Siemens 3 instrument panel	•	•	•	•	•	0027 0070 0064 0066 0065
MITO	1.4 16V	Instrumentation	Siemens 3 instrument panel	•	•	•	•	•	0027 0070 0064 0066 0065
MITO	1.4 TURBO 16V	Instrumentation	Siemens 3 instrument panel	•	•	•	•	•	0027 0070 0064 0066 0065
MITO	1.6 MJET 16V	Instrumentation	Siemens 3 instrument panel	•	•	•	•	•	0027 0070 0064 0066 0065
MITO	1.3 MJET 16V	Safety	Delphi (EP) 3 Body computer	•	•	•	•	•	0
MITO	1.4 16V	Safety	Delphi (EP) 3 Body computer	•	•	•	•	•	0
MITO	1.4 TURBO 16V	Safety	Delphi (EP) 3 Body computer	•	•	•	•	•	0
MITO	1.6 MJET 16V	Safety	Delphi (EP) 3 Body computer	•	•	•	•	•	0
MITO	1.3 MJET 16V	Safety	DELPHI (EP) 3 Electric Steering	•	•	•	•	0	0051
MITO	1.4 16V	Safety	DELPHI (EP) 3 Electric Steering	•	•	•	•	0	0051
MITO	1.4 TURBO 16V	Safety	DELPHI (EP) 3 Electric Steering	•	•	•	•	0	0051
MITO	1.6 MJET 16V	Safety	DELPHI (EP) 3 Electric Steering	•	•	•	•	0	0051
GIULIETTA (191)	1.6 MJET 16V	Engine - Gearbox	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	•	•	•	•	•	0043 0198 0199 0014 0062 0046
GIULIETTA (191)	2.0 MJET 16V	Engine - Gearbox	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	•	•	•	•	•	0043 0198 0199 0014 0062 0046
MITO	1.6 MJET 16V	Engine - Gearbox	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.)	•	•	•	•	•	0043 0198 0199 0014 0062 0046
MITO	1.3 MJET 16V	Safety	Bosch ABS 8 ESP (EP) 2	•	•	•	•	•	0039

Mode1	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MITO	1.4 16V	Safety	Bosch ABS 8 ESP (EP) 2	•	•	•	•	•	0039
MITO	1.4 TURBO 16V	Safety	Bosch ABS 8 ESP (EP) 2	•	•	•	•	•	0039
MITO	1.6 MJET 16V	Safety	Bosch ABS 8 ESP (EP) 2	•	•	•	•	•	0039
MITO	1.3 MJET 16V	Safety	CONTINENTAL Airbag (EP-Proxy) 2	•	•	•	•	•	0
MITO	1. 4 16V	Safety	CONTINENTAL Airbag (EP-Proxy) 2	•	•	•	•	•	0
MITO	1.4 TURBO 16V	Safety	CONTINENTAL Airbag (EP-Proxy) 2	•	•	•	•	•	0
MITO	1.6 MJET 16V	Safety	CONTINENTAL Airbag (EP-Proxy) 2	•	•	•	•	•	0
159	1.8 JTS TB 16V	Engine - Gearbox	Bosch Injection Motronic MeD17.3.1 CF5/EOBD (eng. 1.8)	•	•	•	•	•	0102 0014
BRERA	1.8 JTS TB 16V	Engine - Gearbox	Bosch Injection Motronic MeD17.3.1 CF5/EOBD (eng. 1.8)	•	•	•	•	•	0102 0014
MITO	1.4 TURBO 16V	Comfort	Magneti Marelli suspension (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.4 TURBO 16V	Comfort	Marelli Radio Navigator (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.6 MJET 16V	Comfort	Marelli Radio Navigator (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.8 JTS TB 16V	Comfort	Marelli Radio Navigator (EP)	•	•	•	•	•	0
GIULIETTA (191)	2.0 MJET 16V	Comfort	Marelli Radio Navigator (EP)	•	•	•	•	•	0
MITO	1.3 MJET 16V	Comfort	Marelli Radio Navigator (EP)	•	•	•	•	•	0
MITO	1.4 16V	Comfort	Marelli Radio Navigator (EP)	•	•	•	•	•	0
MITO	1.4 TURBO 16V	Comfort	Marelli Radio Navigator (EP)	•	•	•	•	•	0
MITO	1.6 MJET 16V	Comfort	Marelli Radio Navigator (EP)	•	•	•	•	•	0
159	1.8 16V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
159	1.8 JTS TB 16V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
159	1.9 JTS 16V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
159	1.9 MJET 16V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
159	1.9 MJET 8V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
159	2.0 JTD 16V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
159	2. 2 JTS 16V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
159	2.4 MJET 20V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
159	3. 2 V6 24V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
BRERA	1.8 JTS TB 16V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
BRERA	2.0 JTD 16V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
BRERA	2. 2 JTS 16V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
BRERA	2.4 MJET 20V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
BRERA	3. 2 V6 24V	Comfort	Marelli Radio Navigator	•	•	•	•	•	0
MITO	1.4 TURBO 16V	Engine -	Injection Landi Renzo LCO2 Gas	•	•	•	•	•	0
GIULIETTA (191)	1.4 TURBO 16V	Engine - Gearbox	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	•	•	•	•	•	0102 0207
MITO	1.4 16V	Engine - Gearbox	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	•	•	•	•	•	0102 0207
MITO	1.4 TURBO 16V	Engine - Gearbox	Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4)	•	•	•	•	•	0102 0207

Mode1	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GIULIETTA (191)	1.4 TURBO 16V	Instrumentation	Lauberhorn Convergence (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.6 MJET 16V	Instrumentation	Lauberhorn Convergence (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.8 JTS TB 16V	Instrumentation	Lauberhorn Convergence (EP)	•	•	•	•	•	0
GIULIETTA (191)	2.0 MJET 16V	Instrumentation	Lauberhorn Convergence (EP)	•	•	•	•	•	0
MITO	1.3 MJET 16V	Instrumentation	Lauberhorn Convergence (EP)	•	•	•	•	•	0
MITO	1.4 16V	Instrumentation	Lauberhorn Convergence (EP)	•	•	•	•	•	0
MITO	1.4 TURBO 16V	Instrumentation	Lauberhorn Convergence (EP)	•	•	•	•	•	0
MITO	1.6 MJET 16V	Instrumentation	Lauberhorn Convergence (EP)	•	•	•	•	•	0
MITO	1.3 MJET 16V	Engine - Gearbox	Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD)	•	•	•	•	•	0102 0198 0199 0014 0212 0213
MITO	1.3 MJET 16V	Safety	CONTINENTAL Airbag (EP)	•	•	•	•	•	0
MITO	1.4 16V	Safety	CONTINENTAL Airbag (EP)	•	•	•	•	•	0
MITO	1.4 TURBO 16V	Safety	CONTINENTAL Airbag (EP)	•	•	•	•	•	0
MITO	1.6 MJET 16V	Safety	CONTINENTAL Airbag (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.4 TURBO 16V	Safety	Continental MK60EC ABS (EP)	•	•	•	•	•	0216 0075 0074
GIULIETTA (191)	1.6 MJET 16V	Safety	Continental MK60EC ABS (EP)	•	•	•	•	•	0216 0075 0074
GIULIETTA (191)	1.8 JTS TB 16V	Safety	Continental MK60EC ABS (EP)	•	•	•	•	•	0216 0075 0074
GIULIETTA (191)	2.0 MJET 16V	Safety	Continental MK60EC ABS (EP)	•	•	•	•	•	0216 0075 0074
GIULIETTA (191)	1.4 TURBO 16V	Safety	Bosch Air bag (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.6 MJET 16V	Safety	Bosch Air bag (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.8 JTS TB 16V	Safety	Bosch Air bag (EP)	•	•	•	•	•	0
GIULIETTA (191)	2.0 MJET 16V	Safety	Bosch Air bag (EP)	•	•	•	•	•	0
MITO	1.4 TURBO 16V	Engine -	Marelli DDCT CFC8TDF Automatic Gearbox	•	•	•	•	•	0164 0014 0220 0172
GIULIETTA (191)	1.8 JTS TB 16V	Engine - Gearbox	Bosch Motronic Injection MeD17.3.1 CF5/EOBD (EP eng. 1.8)	•	•	•	•	•	0102 0014
GIULIETTA (191)	1.4 TURBO 16V	Comfort	Marelli climate control Two-zone (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.6 MJET 16V	Comfort	Marelli climate control Two-zone (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.8 JTS TB 16V	Comfort	Marelli climate control Two-zone (EP)	•	•	•	•	•	0
GIULIETTA (191)	2.0 MJET 16V	Comfort	Marelli climate control Two-zone (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.4 TURBO 16V	Comfort	Marelli Manual Climate control (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.6 MJET 16V	Comfort	Marelli Manual Climate control (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.8 JTS TB 16V	Comfort	Marelli Manual Climate control (EP)	•	•	•	•	•	0
GIULIETTA (191)	2.0 MJET 16V	Comfort	Marelli Manual Climate control (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.4 TURBO 16V	Safety	Marelli 10 Body Computer	•	•	•	•	•	0
GIULIETTA (191)	1.6 MJET 16V	Safety	Marelli 10 Body Computer	•	•	•	•	•	0
GIULIETTA (191)	1.8 JTS TB 16V	Safety	Marelli 10 Body Computer	•	•	•	•	•	0
GIULIETTA (191)	2.0 MJET 16V	Safety	Marelli 10 Body Computer	•	•	•	•	•	0
GIULIETTA (191)	1.4 TURBO 16V	Comfort	Lear driver's seat (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.6 MJET 16V	Comfort	Lear driver's seat (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.8 JTS TB 16V	Comfort	Lear driver's seat (EP)	•	•	•	•	•	0

Mode1	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GIULIETTA (191)	2.0 MJET 16V	Comfort	Lear driver's seat (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.4 TURBO 16V	Comfort	Lear passenger seat (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.6 MJET 16V	Comfort	Lear passenger seat (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.8 JTS TB 16V	Comfort	Lear passenger seat (EP)	•	•	•	•	•	0
GIULIETTA (191)	2.0 MJET 16V	Comfort	Lear passenger seat (EP)	•	•	•	•	•	0
GIULIETTA (191)	1.4 TURBO 16V	Other systems	Automotive Lighting discharge headlights	•	•	•	•	•	0
GIULIETTA (191)	1.6 MJET 16V	Other systems	Automotive Lighting discharge headlights	•	•	•	•	•	0
GIULIETTA (191)	1.8 JTS TB 16V	Other systems	Automotive Lighting discharge headlights	•	•	•	•	•	0
GIULIETTA (191)	2.0 MJET 16V	Other systems	Automotive Lighting discharge headlights	•	•	•	•	•	0
159	1.8 16V	Safety	Convergence Lauberhorn C1	•	•	•	•	•	0
159	1.8 JTS TB 16V	Safety	Convergence Lauberhorn C1	•	•	•	•	•	0
159	1.9 JTS 16V	Safety	Convergence Lauberhorn C1	•	•	•	•	•	0
159	1.9 MJET 16V	Safety	Convergence Lauberhorn C1	•	•	•	•	•	0
159	1.9 MJET 8V	Safety	Convergence Lauberhorn C1	•	•	•	•	•	0
159	2.0 JTD 16V	Safety	Convergence Lauberhorn C1	•	•	•	•	•	0
159	2. 2 JTS 16V	Safety	Convergence Lauberhorn C1	•	•	•	•	•	0
159	2.4 MJET 20V	Safety	Convergence Lauberhorn C1	•	•	•	•	•	0
159	3. 2 V6 24V	Safety	Convergence Lauberhorn C1	•	•	•	•	•	0



## Special\_Function

Index	Specil Function Name	Index	Specil Function Name
0001	Air conditioner Learn	0002	Air flow meter replacement (only for version with Lambda sensor)
0003	Air flow meter sensor replacement	0004	Air flow sensor replacement
0005	Alarm deletion	0006	Alarm state check
0007	Antenna replacement	0008	Automatic Configuration Read
0009	Automatic Configuration Write	0010	Brake bleed
0011	Cam edges zeroing (VVT)	0012	Control unit activation
0013	Control unit deactivation	0014	Control unit replacement
0015	Cruise Control Learn	0016	Cyl. 1 injector classification
0017	Cyl. 2 injector classification	0018	Cyl. 3 injector classification
0019	Cyl. 4 injector classification	0020	Differential pressure sensor replacement (only for version with DPF)
0021	EGR valve learn	0022	EGR valve replacement
0023	Engine - Control Unit Group Replacement	0024	Engine type configuration
0025	FAP Replacement	0026	Fuel supply system
0027	Headlamp pos. correct.	0028	Injector classification (4 cyl. bank)
0029	Injector codes read	0030	Injector replacement (per bank)
0031	Inputs status	0032	Inspection service value
0033	Instrument panel lighting	0034	Instrument panel replacement
0035	Knock counter reset		Lambda sensor check
0037	Lambda sensor replacement (only for version with Lambda sensor)		LED colours configuration
0039	Longit. acc. sensor calibration	0040	Looks for faulty wheel transmitter
0041	Manual System Configuration		Odometer write
0041	Oil change (only for version with DPF)	0042	Oil change servicing information delete
0045	Overboost counter reset	0044	Particulate filter regeneration (only for version
0045	Particulate filter replacement (only for version with		
0047	Phonic wheel learn reset	0048	Phase sensor learn zeroing
			Phonic wheel replacement
0051	Position sensor calibration	0052 0054	Pre-catalyser replacement (only for version with DPF
0053	Rail pressure sensor and injector/s replacement		Rail pressure sensor replacement Replacement injectors (4 cyl. bank)
	Replacement injector cyl. 5 Replacement Lambda sensor		
			Replacement of injector cyl. 1
0059	Replacement of injector cyl. 2	0060	Replacement of injector cyl. 3 Replacement of particulate filter with built-in pre-
0061	Replacement of injector cyl. 4	0062	catalyzer (only for versions with DPF)
0063	Replacment of control unit and injector/s	0064	Reset odometer
0065	Seat belts alarm Enable	0066	Seat belts alarm exclusion
0067	Secondary wheel identification deletion	0068	Self-learnt functions reset
0069	Services Interval KM message	0070	Servicing information delete
0071	Servo Mechanism Group Replacement	0072	Speed limit setting
0073	Startup with Code Card	0074	Steering angle calibration
0075	Steering angle reset	0076	System configuration
0077	Throttle learn storage	0078	Tow hook presence disable
0079	Tow hook presence enable	0800	Variable geometry turbo replacement
0081	Vehicle configuration deletion	0082	Vehicle type learn reset
0083	Wheel identification check	0084	Wheel transmitters learning
0085	Zeroing of self-adaption parameters	0086	Engine control unit programming
0087	System calibration	0088	Total additive quantity
0089	Part. Filter regeneration	0090	Customer mode
0091	Mounting check	0092	Tyre Pressure check
0093	Control Unit Replacement	0094	Additive type configuration
0095	RH distribution flap learn	0096	LH distribution flap learn
0097	LH mixing flap learn	0098	RH mixing flap learn
0099	United Kingdom (Thatcham std)	0100	Date daylight time changed
		0102	0il change
0101	Fuel level regulat.	0102	off change

Index	Specil Function Name	Index	Specil Function Name
0105	Injector classification	0106	Recognition of speed sensor type
0107	Actuator tests	0108	Self-adaptation Parameter erasure
0109	Sensor vibration time too long	0110	Dist. To Next Service Zeroing (Coupon)
0111	Maintenance Services Config.	0112	Call buttons configuration
0113	Clutch replacement	0114	KIT/Gearbox replacement
0115	Electropump replacement	0116	Statistical data deletion
0117	Tunnel lever replacement	0118	Steering wheel levers replacement
0119	KIT/Pump replacement	0120	Pump relay replacement
0121	AUTO switch replacement	0122	Key storage
0123	System Configuration Read	0124	System Configuration Write
0125	Reset self-adapt. param. and idle act.	0126	Electronic Key control unit programming
0127	Engine Control + Electronic Key control units	0128	Clutch bleed
0129	Accumulator depressurisation	0130	Clutch self-calibration enable
0131	End of line / service self-calibration	0132	New actuators
0133	Flap actuators learning test	0134	Oil Counter Write
0135	Engagement lever pin securing screw diagnosis	0136	Selection lever return diagnosis
0137	Memory mode write	0138	Control Unit Unlock
0139	Calculation of clutch degradation index	0140	Test limit speed disable
0141	Test limit speed restore	0142	VIN Code Configuration
0143	Personal data deletion	0144	Cyl. 5 injector classification
0145	Injector classification (5 cyl. bank)	0146	Deletion of statistical data relating to errors
0147	CITY switch replacement	0148	SPORT switch replacement
0149	Activation/Deactivation 'Auxiliary video input'	0150	Cruise control learn zeroing
0151	Zeroing fan mode learn	0152	Borg Warner sol. valves compatibility
0153	Self-adapting parameters zeroing (air)	0154	Self-adapting parameters zeroing (knock)
0155	Gearbox Lever Position Learn	0156	Deletion stored buttons
0157	Audio System Test	0158	Convergence System Restart
0159	CAN Network Activation	0160	Deletion of air temperature sensor data
0161	High pressure pump replacement	0162	Additional diesel circuit filling
0163	Gearbox replacement	0164	Gearbox oil accumulator replacement
0165	Pilot injection learn	0166	ECO switch replacement
	End of line self-calibration		Forced trim correction
0169	Vehicle geometry height setting	0170	Pneumatic circuit filling
0171 0173	Pneumatic circuit unloading JukeBox data deletion	0172 0174	Longitudinal acceleration signal learn ECO/SPORT switch replacement
0175	'UP Function' switch replacement	0174	Services Interval KM write (only 1.6 MJET 16V 105 hp
0173	Automatic gearbox replacement	0178	Automatic gearbox and Control unit replacement
			Services Interval KM write (only for 1.4 TURBO 16v
0179	Automatic gearbox oil replacement	0180	120/150 bhp eng.)
0181	Static test	0182	C. P. H control unit programming
0183	C.P.H. control unit and engine control unit	0184	Remote control programming
0185	Key programming	0186	New vehicle preparation
0187	Reset distance till next servicing	0188	FAP Temperature Probe presence configuration
0189	Replacement of particulate filter and interventions	0190	Replacement of the additive, or the pump, or the
	on diesel additive circuit.		tubes.
0191	System configuration via Examiner Web	0192	Performance limiting deactivation
0193	Volumetric sensors automatic diagnosis	0194	Neutral signal learn
0195	Hydraulic Kit replacement	0196	Sensors module replacement
0197	Selection and/or engagement clutch electrovalve Resetting distance travelled with Water in diesel w.	0198	Resetting distance travelled with Water Temp. w. lamp
0199	lamp ON	0200	Accelerometer calibration
0201	Control unit Replacement / Reprogramming	0202	Motorised throttle replacement
0203	Upstream lambda sensor replacement	0204	MultiAir Rolling finger replacement
0205	Timing sensor and/or cam replacement	0206	Rpm sensor and/or distribution belt replacement
0207	Oil temperature sensor replacement	0208	UniAir module replacement
0209	Supercharging system components replacement	0210	Downstream lambda sensor and/or catalyzer and/or Injectors replacement
0211	Differential pressure sensor replacement	0212	Particulate filter with integrated pre-cat
0213	Particulate filter regeneration	0214	Mechanical waste-gate valve replacement
_			•

Index	Specil Function Name	Index	Specil Function Name
0215	Replacement of variable geometry turbo and/or turbo posit. sensor	0216	Lateral and longitud. acceleration sensor calibration
0217	Pressure sensor calibration	0218	Load valves calibration
0219	Pilot valves calibration	0220	Longitudinal acceleration sensor replacement
0221	Even no. gear clutch pressure sensor replacement	0222	Odd no. gear clutch position sensor replacement
0223	Odd and/or even gear clutch replacement	0224	Electropump drive unit replacement
0225	Gearbox button panel replacement	0226	Replacement injectors
0227	Additive quantity volume	0228	Air flow meter replacement
0229	Air metering unit replacement	0230	Supercharg. air cooling SV replacement
0231	Replacement of Lambda sensor	0232	Homologation number
0233	Speed limit	0234	Levers on steering wheel learn
0235	Gearbox and hydraulic KIT replacement	0236	Parking manoeuvre status
0237	Phonic wheel and/or phase sensor and/or rev sensor replacement	0238	Replacement of lambda sensor and/or spark plugs and/or injectors
0239	Replacement of pressure/temperature sensor in methane	0240	Pre-catalyzer replacement
0241	Particulate filter replacement	0242	Alcohol fuel setting
0243	Petrol fuel setting	0244	Air/Fuel learn setting