

How to read this list:	
Mark	Description
X	Function is supported.
*	Function is added or developed newly

Function List													
Automaker:				ISUZU									
Software Version:				V2.91									
Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions
ISUZU		(A) 2010	N TRUCK		4JJ1-TC(C/Rail)	Powertrain		X	X	X	X		
ISUZU		(A) 2010	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.5 4JK1-TC (TransTron)	Powertrain		X	X	X	X	X	
ISUZU		(A) 2010	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.0L 4JJ1-TC (TransTron)	Powertrain		X	X	X	X	X	
ISUZU		(A) 2010	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		V6 Engine	Powertrain		X	X	X	X	X	
ISUZU		(A) 2010	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X	
ISUZU		(9) 2009	N TRUCK		4JJ1-TC(C/Rail)	Powertrain		X	X	X	X		
ISUZU		(9) 2009	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.5 4JK1-TC (TransTron)	Powertrain		X	X	X	X	X	
ISUZU		(9) 2009	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.0L 4JJ1-TC (TransTron)	Powertrain		X	X	X	X	X	
ISUZU		(9) 2009	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		V6 Engine	Powertrain		X	X	X	X	X	
ISUZU		(9) 2009	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X	
ISUZU		(8) 2008	N TRUCK		4JJ1-TC(C/Rail)	Powertrain		X	X	X	X		
ISUZU		(8) 2008	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.5 4JK1-TC (TransTron)	Powertrain		X	X	X	X	X	
ISUZU		(8) 2008	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.0L 4JJ1-TC (TransTron)	Powertrain		X	X	X	X	X	
ISUZU		(8) 2008	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		V6 Engine	Powertrain		X	X	X	X	X	
ISUZU		(8) 2008	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X	
ISUZU		(7) 2007	N TRUCK		4JJ1-TC(C/Rail)	Powertrain		X	X	X	X		
ISUZU		(7) 2007	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		V6 Engine	Powertrain		X	X	X	X	X	
ISUZU		(7) 2007	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X	
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JA1-TC Bosch	Powertrain		X	X	X			
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.XL L4 HV240	Powertrain		X	X	X	X	X	
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.5L 4JK1-TC	Powertrain		X	X	X	X	X	X 1.Injector ID Code X 2.ID Code Registration
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.0L 4JJ1-TC	Powertrain		X	X	X	X	X	X 1.Injector ID Code X 2.ID Code Registration X 3.Lock ECU
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.5L V6 6VE1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AT JR405E	Powertrain		X	X	X	X	X	
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AW30-40LE	Powertrain		X	X	X			
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X	
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Immobiliser		X	X	X			
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Airbag		X	X	X	X		

ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		4JH1-TC Bosch	Engine		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		4HV1(CNG)	Engine		X	X	X	X	X	
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		4HK1-TC (C/Rail)	Engine		X	X	X			
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		4HL1-TC (C/Rail)	Engine		X	X	X			
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		4HL1-NA (C/Rail)	Engine		X	X	X			
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		MIMAMORI	Engine		X	X	X			
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		Hybrid System	Engine		X	X	X			
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		Transmission	Smoother-E		X	X	X			
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		Transmission	Smoother / Smoother-E Auto Shift		X	X	X			
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		Chassis	ABS / ASR		X	X	X			
ISUZU		(6) 2006	(Off-Road) Industrial Engine		4JJ1-TC (C/Rail_TIER3)	Engine		X	X	X			
ISUZU		(6) 2006	(Off-Road) Industrial Engine		4HK1-TC (C/Rail_TIER3)	Engine		X	X	X			
ISUZU		(6) 2006	(Off-Road) Industrial Engine		6HK1-TC (C/Rail_TIER3)	Engine		X	X	X			
ISUZU		(6) 2006	(Off-Road) Industrial Engine		6UZ1-TC (C/Rail_TIER3)	Engine		X	X	X			
ISUZU		(6) 2006	(Off-Road) Industrial Engine		6WG1-TC (C/Rail_TIER3)	Engine		X	X	X			
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JA1-TC Bosch	Powertrain		X	X	X			
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.XL L4 HV240	Powertrain		X	X	X	X	X	
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.5L 4JK1-TC	Powertrain		X	X	X	X	X	X 1.Injector ID Code X 2.ID Code Registration
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.0L 4JJ1-TC	Powertrain		X	X	X	X	X	X 1.Injector ID Code X 2.ID Code Registration X 3.Lock ECU
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.5L V6 6VE1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AT JR405E	Powertrain		X	X	X	X	X	
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AW30-40LE	Powertrain		X	X	X			
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X	
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Immobiliser		X	X	X			
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Airbag		X	X	X	X		
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4JH1-TC Bosch	Engine		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4JG2	Engine			X	X	X	X	
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4HG1(LPG)	Engine		X	X	X	X	X	
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4JG2(LPG)	Engine		X	X	X	X	X	
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4HV1(CNG)	Engine		X	X	X	X	X	
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4HK1-TC (C/Rail)	Engine		X	X	X			
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4HL1-TC (C/Rail)	Engine		X	X	X			
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4HL1-NA (C/Rail)	Engine		X	X	X			
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		MIMAMORI	Engine		X	X	X			
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		Hybrid System	Engine		X	X	X			
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		Transmission	Smoother-E		X	X	X			
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		Transmission	Smoother / Smoother-E Auto Shift		X	X	X			
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		Chassis	ABS / ASR		X	X	X			
ISUZU		(5) 2005	(Off-Road) Industrial Engine		4JJ1-TC (C/Rail_TIER3)	Engine		X					

ISUZU		(5) 2005	(Off-Road) Industrial Engine		4HK1-TC (C/Rail_TIER3)	Engine		X	X	X			
ISUZU		(5) 2005	(Off-Road) Industrial Engine		6HK1-TC (C/Rail_TIER3)	Engine		X	X	X			
ISUZU		(5) 2005	(Off-Road) Industrial Engine		6UZ1-TC (C/Rail_TIER3)	Engine		X	X	X			
ISUZU		(5) 2005	(Off-Road) Industrial Engine		6WG1-TC (C/Rail_TIER3)	Engine		X	X	X			
ISUZU		(4) 2004	(UE) Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1	Powertrain		X	X	X			
ISUZU		(4) 2004	(UE) Rodeo/Amigo, Wizard/MU		3.5L V6 6VE1 Hitachi	Powertrain		X	X	X			
ISUZU		(4) 2004	(UE) Rodeo/Amigo, Wizard/MU		Chassis	TPMS (Tire Pressure Monitoring System)		X	X	X	X	X	
ISUZU		(4) 2004	(UE) Rodeo/Amigo, Wizard/MU		Chassis	ABS		X	X	X	X		
ISUZU		(4) 2004	(UE) Rodeo/Amigo, Wizard/MU		Body	Immobiliser		X	X	X			
ISUZU		(4) 2004	(UP) Axiom		3.5L V6 6VE1 Hitachi	Powertrain		X	X	X			
ISUZU		(4) 2004	(UP) Axiom		Chassis	ABS		X	X	X	X		
ISUZU		(4) 2004	(UP) Axiom		Body	Immobiliser		X	X	X			
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-T Denso	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JA1-TC Bosch	Powertrain		X	X	X			
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.XL L4 HV240	Powertrain		X	X	X	X	X	
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.5L V6 6VE1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AT JR405E	Powertrain		X	X	X	X	X	
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AW30-40LE	Powertrain		X	X	X			
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X	
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Immobiliser		X	X	X			
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Airbag		X	X	X	X		
ISUZU		(4) 2004	(N*) ELF, NPR, NQR,VFR		4JH1-TC Bosch	Engine		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(4) 2004	(N*) ELF, NPR, NQR,VFR		4JG2	Engine			X	X	X	X	
ISUZU		(4) 2004	(N*) ELF, NPR, NQR,VFR		4HF1(CNG)	Engine		X	X	X	X	X	
ISUZU		(4) 2004	(N*) ELF, NPR, NQR,VFR		4HG1(LPG)	Engine		X	X	X	X	X	
ISUZU		(4) 2004	(N*) ELF, NPR, NQR,VFR		4JG2(LPG)	Engine		X	X	X	X	X	
ISUZU		(4) 2004	(N*) ELF, NPR, NQR,VFR		4HL1-TC (C/Rail)	Engine		X	X	X			
ISUZU		(4) 2004	(N*) ELF, NPR, NQR,VFR		4HL1-NA (C/Rail)	Engine		X	X	X			
ISUZU		(4) 2004	(N*) ELF, NPR, NQR,VFR		MIMAMORI	Engine		X	X	X			
ISUZU		(4) 2004	(N*) ELF, NPR, NQR,VFR		Hybrid System	Engine		X	X	X			
ISUZU		(4) 2004	(N*) ELF, NPR, NQR,VFR		Chassis	ABS / ASR		X	X	X			
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		3.2L V6 6VD1	Powertrain		X	X	X			
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		3.5L V6 6VE1	Powertrain		X	X	X			
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X	* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		4L30E	Powertrain		X	X	X			
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser		X	X	X			
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser (DDS)		X	X	X			
ISUZU		(3) 2003	(UE) Rodeo/Amigo, Wizard/MU		2.2L L4 X22SE	Powertrain		X	X	X	X	X	
ISUZU		(3) 2003	(UE) Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1	Powertrain		X	X	X			

ISUZU		(3) 2003	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain		X	X	X	X	X	* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(3) 2003	(UE) Rodeo/Amigo, Wizard/MU		4L30E	Powertrain		X	X	X			
ISUZU		(3) 2003	(UE) Rodeo/Amigo, Wizard/MU		Body	Immobiliser		X	X	X			
ISUZU		(3) 2003	(UP) Axiom		3.5L V6 6VE1	Powertrain		X	X	X			
ISUZU		(3) 2003	(UP) Axiom		4L30E	Powertrain		X	X	X			
ISUZU		(3) 2003	(UP) Axiom		Chassis	ABS		X	X	X	X		
ISUZU		(3) 2003	(UP) Axiom		Body	Immobiliser		X	X	X			
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-T Denso	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JA1-TC Bosch	Powertrain		X					
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.XL L4 SOHC	Powertrain		X	X	X	X	X	
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.5L V6 6VE1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AT JR405E	Powertrain		X	X	X	X	X	
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AW30-40LE	Powertrain		X	X	X			
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X	
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Immobiliser		X	X	X			
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Airbag		X	X	X	X		
ISUZU		(3) 2003	(TBR).		2.XL L4 HV240	Powertrain		X	X	X	X	X	
ISUZU		(3) 2003	(N*) ELF, NPR, NQR,VFR		4JH1-TC Bosch	Engine		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(3) 2003	(N*) ELF, NPR, NQR,VFR		4HL1/4HJ1(COMMON R	Engine		X	X	X			
ISUZU		(3) 2003	(N*) ELF, NPR, NQR,VFR		4HL1/4HJ1(Vehicle Interf	Engine		X	X	X			
ISUZU		(3) 2003	(N*) ELF, NPR, NQR,VFR		4JG2	Engine			X	X	X	X	
ISUZU		(3) 2003	(N*) ELF, NPR, NQR,VFR		Chassis	ABS / ASR		X	X	X			
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		3.2L V6 6VD1	Powertrain		X	X	X			
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		3.5L V6 6VE1	Powertrain		X	X	X			
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X	* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		4L30E	Powertrain		X	X	X			
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser		X	X	X			
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser (DDS)		X	X	X			
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		2.2L L4 X22SE	Powertrain		X	X	X	X	X	
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1	Powertrain		X	X	X			
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain		X	X	X	X	X	* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		4L30E	Powertrain		X	X	X			
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		Chassis	ABS		X	X	X	X		
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		Body	Immobiliser		X	X	X			
ISUZU		(2) 2002	(UP) Axiom		3.5L V6 6VE1	Powertrain		X	X	X			
ISUZU		(2) 2002	(UP) Axiom		4L30E	Powertrain		X	X	X			
ISUZU		(2) 2002	(UP) Axiom		Chassis	ABS		X	X	X	X		

ISUZU		(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JH1-TC Bosch	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JH1-T Denso	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JA1-TC Bosch	Powertrain		X					
ISUZU		(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	AT JR405E	Powertrain		X	X	X	X	X	
ISUZU		(2) 2002	TF/UC Thailand	4JH1-T Denso	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(2) 2002	(TBR).	2.2L L4 HV240	Powertrain		X	X	X			
ISUZU		(2) 2002	(N*) ELF, NPR, NQR,VFR	4JH1-TC Bosch	Engine		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(2) 2002	(N*) ELF, NPR, NQR,VFR	4HL1/4HJ1(COMMON R	Engine		X	X	X			
ISUZU		(2) 2002	(N*) ELF, NPR, NQR,VFR	4HL1/4HJ1(Vehicle Interf	Engine		X	X	X			
ISUZU		(2) 2002	(N*) ELF, NPR, NQR,VFR	Chassis	ABS / ASR		X	X	X			
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo	3.2L V6 6VD1	Powertrain		X	X	X			
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo	3.5L V6 6VE1	Powertrain		X	X	X			
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo	3.0L L4 4JX1	Powertrain		X	X	X	X	X	* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo	4L30E	Powertrain		X	X	X			
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo	Body	Immobiliser		X	X	X			
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo	Body	Immobiliser (DDS)		X	X	X			
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU	2.2L L4 X22SE	Powertrain		X	X	X	X	X	
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU	3.2L V6 6VD1	Powertrain		X	X	X			
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU	3.0L L4 4JX1	Powertrain		X	X	X	X	X	*1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU	4L30E	Powertrain		X	X	X			
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU	Chassis	ABS		X	X	X	X		
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU	Body	Immobiliser		X	X	X			
ISUZU		(1) 2001	(UG) V-Cross	3.2L V6 6VD1	Powertrain		X	X	X	X	X	
ISUZU		(1) 2001	(UG) V-Cross	3.5L V6 6VE1	Powertrain		X	X	X	X	X	
ISUZU		(1) 2001	(UG) V-Cross	4L30E	Powertrain		X	X	X	X	X	
ISUZU		(1) 2001	(UC) Frontier, LAO-Rodeo	3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(1) 2001	TF/UC Thailand	4JH1-T Denso	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(1) 2001	(TF) LUV	4JH1-TC Bosch	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(1) 2001	(TF) LUV	4JA1-TC Bosch	Powertrain		X	X	X			
ISUZU		(1) 2001	(TF) LUV	3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(1) 2001	(TF) LUV	Body	Immobiliser		X	X	X			
ISUZU		(1) 2001	(N*) ELF, NPR, NQR,VFR	4JH1-TC Bosch	Engine		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(1) 2001	(N*) ELF, NPR, NQR,VFR	Chassis	ABS / ASR		X	X	X			
ISUZU		(Y) 2000	(UB) Trooper, Bighorn, Jackaroo	3.2L V6 6VD1	Powertrain		X	X	X			
ISUZU		(Y) 2000	(UB) Trooper, Bighorn, Jackaroo	3.5L V6 6VE1	Powertrain		X	X	X			

ISUZU		(Y) 2000	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X	* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(Y) 2000	(UB) Trooper, Bighorn, Jackaroo		4L30E	Powertrain		X	X	X			
ISUZU		(Y) 2000	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser		X	X	X			
ISUZU		(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU		2.2L L4 X22SE	Powertrain		X	X	X	X	X	
ISUZU		(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1	Powertrain		X	X	X			
ISUZU		(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain		X	X	X	X	X	*1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU		4L30E	Powertrain		X	X	X			
ISUZU		(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU		Chassis	ABS		X	X	X	X		
ISUZU		(Y) 2000	(UG) V-Cross		3.2L V6 6VD1	Powertrain		X	X	X	X	X	
ISUZU		(Y) 2000	(UG) V-Cross		3.5L V6 6VE1	Powertrain		X	X	X	X	X	
ISUZU		(Y) 2000	(UG) V-Cross		4L30E	Powertrain		X	X	X	X	X	
ISUZU		(Y) 2000	(UC) Frontier, LAO-Rodeo		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(Y) 2000	(UC) Frontier, LAO-Rodeo		Body	Immobiliser		X	X	X			
ISUZU		(Y) 2000	(TF) LUV		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(X) 1999	(UB) Trooper, Bighorn, Jackaroo		3.2L V6 6VD1	Powertrain		X	X	X	X	X	
ISUZU		(X) 1999	(UB) Trooper, Bighorn, Jackaroo		3.5L V6 6VE1	Powertrain		X	X	X	X	X	
ISUZU		(X) 1999	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X	* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(X) 1999	(UB) Trooper, Bighorn, Jackaroo		4L30E	Powertrain		X	X	X	X	X	
ISUZU		(X) 1999	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser		X	X	X			
ISUZU		(X) 1999	(UE) Rodeo/Amigo, Wizard/MU		2.2L L4 X22SE	Powertrain		X	X	X	X	X	
ISUZU		(X) 1999	(UE) Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1	Powertrain		X	X	X	X	X	
ISUZU		(X) 1999	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain		X	X	X	X	X	*1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(X) 1999	(UE) Rodeo/Amigo, Wizard/MU		4L30E	Powertrain		X	X	X	X	X	
ISUZU		(X) 1999	(UE) Rodeo/Amigo, Wizard/MU		Chassis	ABS		X	X	X	X		
ISUZU		(X) 1999	(UG) V-Cross		3.2L V6 6VD1	Powertrain		X	X	X	X	X	
ISUZU		(X) 1999	(UG) V-Cross		3.5L V6 6VE1	Powertrain		X	X	X	X	X	
ISUZU		(X) 1999	(UG) V-Cross		4L30E	Powertrain		X	X	X	X	X	
ISUZU		(X) 1999	(UC) Frontier, LAO-Rodeo		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(X) 1999	(TF) LUV		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(W) 1998	(UB) Trooper, Bighorn, Jackaroo		3.2L V6 6VD1	Powertrain		X	X	X	X	X	
ISUZU		(W) 1998	(UB) Trooper, Bighorn, Jackaroo		3.5L V6 6VE1	Powertrain		X	X	X	X	X	
ISUZU		(W) 1998	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X	*1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(W) 1998	(UB) Trooper, Bighorn, Jackaroo		4L30E	Powertrain		X	X	X	X	X	
ISUZU		(W) 1998	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser		X	X	X			
ISUZU		(W) 1998	(UE) Rodeo/Amigo, Wizard/MU		2.2L L4 X22SE	Powertrain		X	X	X	X	X	
ISUZU		(W) 1998	(UE) Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1	Powertrain		X	X	X	X	X	

ISUZU		(W) 1998	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain		X	X	X	X	X	*1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(W) 1998	(UE) Rodeo/Amigo, Wizard/MU		4L30E	Powertrain		X	X	X	X	X	
ISUZU		(W) 1998	(UE) Rodeo/Amigo, Wizard/MU		Chassis	ABS		X	X	X	X		
ISUZU		(W) 1998	(UC) Frontier, LAO-Rodeo		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(W) 1998	(TF) LUV		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(W) 1998	(TF) LUV		2.2L L4 SOHC	Powertrain		X	X	X	X	X	