

How to read this list:	
Mark	Description
X	Function is supported.
*	Function is added or developed newly

Function List													
Automaker:				KIA									
Software Version:				V4.2									
Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions
KIA	ASIA	2003	BESTA(TP)		D 2.5 TCI	Engine Control			X	X	X	X	
KIA	ASIA	2002	BESTA(TP)		D 2.5 TCI	Engine Control			X	X	X	X	
KIA	ASIA	2002	BESTA(TP)		D 2.5 TCI	Automatic Transaxle			X	X	X		
KIA	ASIA	2001	BESTA(TP)		D 2.5 TCI	Engine Control			X	X	X	X	
KIA	ASIA	2001	BESTA(TP)		D 2.5 TCI	Automatic Transaxle			X	X	X		
KIA	ASIA	2000	BESTA(TP)		D 2.5 TCI	Engine Control			X	X	X	X	
KIA	ASIA	2000	BESTA(TP)		D 2.5 TCI	Automatic Transaxle			X	X	X		
KIA	ASIA	1999	BESTA(TP)		D 2.5 TCI	Engine Control			X	X	X	X	
KIA	ASIA	1999	BESTA(TP)		D 2.5 TCI	Automatic Transaxle			X	X	X		
KIA	ASIA	1998	BESTA(TP)		D 2.5 TCI	Engine Control			X	X	X	X	
KIA	ASIA	1998	BESTA(TP)		D 2.5 TCI	Automatic Transaxle			X	X	X		
KIA	ASIA	1997	BESTA(TP)		D 2.5 TCI	Engine Control			X	X	X	X	
KIA	ASIA	1997	BESTA(TP)		D 2.5 TCI	Automatic Transaxle			X	X	X		
KIA	ASIA	2011	Cee'd(ED)		G 2.0 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2011	Cee'd(ED)		G 2.0 DOHC	Air Conditioner(Single)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 2.0 DOHC	Air Conditioner(Double)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 2.0 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	Cee'd(ED)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2011	Cee'd(ED)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2011	Cee'd(ED)		G 2.0 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	Cee'd(ED)		G 1.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2011	Cee'd(ED)		G 1.4 DOHC	Air Conditioner(Single)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.4 DOHC	Air Conditioner(Double)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	Cee'd(ED)		G 1.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2011	Cee'd(ED)		G 1.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	

KIA	ASIA	2011	Cee'd(ED)		G 1.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	Cee'd(ED)		G 1.6 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2011	Cee'd(ED)		G 1.6 DOHC	Air Conditioner(Single)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.6 DOHC	Air Conditioner(Double)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.6 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	Cee'd(ED)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2011	Cee'd(ED)		G 1.6 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	ISG(-)/CPF(-)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	ISG(-)/CPF(+)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	ISG(+)/CPF(-)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	ISG(+)/CPF(+)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	Airbag Control		X	X	X	X		
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	Air Conditioner(Single)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	Air Conditioner(Double)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	Body Control Module		X			X	X	
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	Immobilizer					X		
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 1.6 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2011	Cee'd(ED)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 2.0 TCI-D	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2011	Cee'd(ED)		D 2.0 TCI-D	Air Conditioner(Single)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 2.0 TCI-D	Air Conditioner(Double)		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 2.0 TCI-D	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	Cee'd(ED)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2011	Cee'd(ED)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2011	Cee'd(ED)		D 2.0 TCI-D	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	Cee'd(ED)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2010	Cee'd(ED)		G 2.0 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	Cee'd(ED)		G 2.0 DOHC	Air Conditioner(Single)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 2.0 DOHC	Air Conditioner(Double)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 2.0 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	Cee'd(ED)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	Cee'd(ED)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2010	Cee'd(ED)		G 2.0 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	Cee'd(ED)		G 1.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	

KIA	ASIA	2010	Cee'd(ED)		G 1.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	Cee'd(ED)		G 1.4 DOHC	Air Conditioner(Single)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.4 DOHC	Air Conditioner(Double)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	Cee'd(ED)		G 1.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2010	Cee'd(ED)		G 1.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	Cee'd(ED)		G 1.6 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	Cee'd(ED)		G 1.6 DOHC	Air Conditioner(Single)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.6 DOHC	Air Conditioner(Double)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.6 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	Cee'd(ED)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2010	Cee'd(ED)		G 1.6 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	ISG(-)/CPF(-)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	ISG(-)/CPF(+)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	ISG(+)/CPF(-)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	ISG(+)/CPF(+)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	Airbag Control		X	X	X	X		
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	Air Conditioner(Single)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	Air Conditioner(Double)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	Body Control Module		X			X	X	
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	Immobilizer					X		
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 1.6 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2010	Cee'd(ED)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 2.0 TCI-D	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2010	Cee'd(ED)		D 2.0 TCI-D	Air Conditioner(Single)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 2.0 TCI-D	Air Conditioner(Double)		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 2.0 TCI-D	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	Cee'd(ED)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2010	Cee'd(ED)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2010	Cee'd(ED)		D 2.0 TCI-D	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	Cee'd(ED)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2009	Cee'd(ED)		G 2.0 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	Cee'd(ED)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	

KIA	ASIA	2009	Cee'd(ED)		G 2.0 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	Cee'd(ED)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	Cee'd(ED)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2009	Cee'd(ED)		G 2.0 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	Cee'd(ED)		G 1.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 1.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	Cee'd(ED)		G 1.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 1.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	Cee'd(ED)		G 1.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	Cee'd(ED)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2009	Cee'd(ED)		G 1.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 1.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	Cee'd(ED)		G 1.6 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	Cee'd(ED)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 1.6 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	Cee'd(ED)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	Cee'd(ED)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2009	Cee'd(ED)		G 1.6 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U	Body Control Module		X			X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U	Immobilizer					X		
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U	Transmitter Code Saving					X		
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U2	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U2	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U2	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U2	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U2	Airbag Control		X	X	X	X		
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U2	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U2	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U2	Body Control Module		X			X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U2	Immobilizer					X		
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U2	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 1.6 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2009	Cee'd(ED)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 2.0 TCI-D	Electronic Stability Program		X	X	X	X	X	

KIA	ASIA	2009	Cee'd(ED)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2009	Cee'd(ED)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 2.0 TCI-D	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	Cee'd(ED)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2009	Cee'd(ED)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2009	Cee'd(ED)		D 2.0 TCI-D	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2009	Cee'd(ED)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2008	Cee'd(ED)		G 2.0 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	Cee'd(ED)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 2.0 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	Cee'd(ED)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2008	Cee'd(ED)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2008	Cee'd(ED)		G 2.0 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	Cee'd(ED)		G 1.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 1.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	Cee'd(ED)		G 1.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 1.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	Cee'd(ED)		G 1.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2008	Cee'd(ED)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2008	Cee'd(ED)		G 1.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 1.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	Cee'd(ED)		G 1.6 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	Cee'd(ED)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 1.6 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	Cee'd(ED)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2008	Cee'd(ED)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2008	Cee'd(ED)		G 1.6 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	Cee'd(ED)		D 1.6 TCI-U	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		D 1.6 TCI-U	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		D 1.6 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		D 1.6 TCI-U	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		D 1.6 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2008	Cee'd(ED)		D 1.6 TCI-U	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		D 1.6 TCI-U	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	Cee'd(ED)		D 1.6 TCI-U	Body Control Module		X			X	X	
KIA	ASIA	2008	Cee'd(ED)		D 1.6 TCI-U	Immobilizer					X		
KIA	ASIA	2008	Cee'd(ED)		D 1.6 TCI-U	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		D 1.6 TCI-U	Transmitter Code Saving					X		
KIA	ASIA	2008	Cee'd(ED)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	

KIA	ASIA	2008	Cee'd(ED)		D 2.0 TCI-D	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2008	Cee'd(ED)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		D 2.0 TCI-D	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	Cee'd(ED)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2008	Cee'd(ED)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2008	Cee'd(ED)		D 2.0 TCI-D	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2008	Cee'd(ED)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2007	Cee'd(ED)		G 2.0 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	Cee'd(ED)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 2.0 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	Cee'd(ED)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2007	Cee'd(ED)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2007	Cee'd(ED)		G 2.0 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	Cee'd(ED)		G 1.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 1.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	Cee'd(ED)		G 1.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 1.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	Cee'd(ED)		G 1.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2007	Cee'd(ED)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2007	Cee'd(ED)		G 1.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 1.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	Cee'd(ED)		G 1.6 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	Cee'd(ED)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 1.6 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	Cee'd(ED)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2007	Cee'd(ED)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2007	Cee'd(ED)		G 1.6 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	Cee'd(ED)		D 1.6 TCI-U	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		D 1.6 TCI-U	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		D 1.6 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		D 1.6 TCI-U	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		D 1.6 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2007	Cee'd(ED)		D 1.6 TCI-U	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		D 1.6 TCI-U	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	Cee'd(ED)		D 1.6 TCI-U	Body Control Module		X			X	X	
KIA	ASIA	2007	Cee'd(ED)		D 1.6 TCI-U	Immobilizer					X		
KIA	ASIA	2007	Cee'd(ED)		D 1.6 TCI-U	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		D 1.6 TCI-U	Transmitter Code Saving					X		
KIA	ASIA	2007	Cee'd(ED)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	

KIA	ASIA	2007	Cee'd(ED)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		D 2.0 TCI-D	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2007	Cee'd(ED)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		D 2.0 TCI-D	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	Cee'd(ED)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2007	Cee'd(ED)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2007	Cee'd(ED)		D 2.0 TCI-D	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2007	Cee'd(ED)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2006	Cee'd(ED)		G 2.0 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	Cee'd(ED)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		G 2.0 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2006	Cee'd(ED)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2006	Cee'd(ED)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2006	Cee'd(ED)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2006	Cee'd(ED)		G 1.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		G 1.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	Cee'd(ED)		G 1.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		G 1.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2006	Cee'd(ED)		G 1.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2006	Cee'd(ED)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2006	Cee'd(ED)		G 1.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2006	Cee'd(ED)		G 1.6 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	Cee'd(ED)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		G 1.6 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2006	Cee'd(ED)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2006	Cee'd(ED)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2006	Cee'd(ED)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2006	Cee'd(ED)		D 1.6 TCI-U	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		D 1.6 TCI-U	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		D 1.6 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		D 1.6 TCI-U	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		D 1.6 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2006	Cee'd(ED)		D 1.6 TCI-U	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		D 1.6 TCI-U	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2006	Cee'd(ED)		D 1.6 TCI-U	Body Control Module		X			X	X	
KIA	ASIA	2006	Cee'd(ED)		D 1.6 TCI-U	Immobilizer					X		
KIA	ASIA	2006	Cee'd(ED)		D 1.6 TCI-U	Transmitter Code Saving					X		
KIA	ASIA	2006	Cee'd(ED)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		D 2.0 TCI-D	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		D 2.0 TCI-D	Airbag Control		X	X	X	X		

KIA	ASIA	2006	Cee'd(ED)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	Cee'd(ED)		D 2.0 TCI-D	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2006	Cee'd(ED)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2006	Cee'd(ED)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2006	Cee'd(ED)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2009	CERATO(LD)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	CERATO(LD)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2009	CERATO(LD)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	CERATO(LD)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2009	CERATO(LD)		D 1.6 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		D 1.6 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		D 1.6 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		D 1.6 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2009	CERATO(LD)		D 1.6 TCI-U	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	CERATO(LD)		D 1.6 TCI-U	Immobilizer					X		
KIA	ASIA	2008	CERATO(LD)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	CERATO(LD)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2008	CERATO(LD)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	CERATO(LD)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2008	CERATO(LD)		D 1.6 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		D 1.6 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		D 1.6 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		D 1.6 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2008	CERATO(LD)		D 1.6 TCI-U	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	CERATO(LD)		D 1.6 TCI-U	Immobilizer					X		
KIA	ASIA	2007	CERATO(LD)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	

KIA	ASIA	2007	CERATO(LD)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	CERATO(LD)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2007	CERATO(LD)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	CERATO(LD)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2007	CERATO(LD)		D 1.6 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		D 1.6 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		D 1.6 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		D 1.6 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2007	CERATO(LD)		D 1.6 TCI-U	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	CERATO(LD)		D 1.6 TCI-U	Immobilizer					X		
KIA	ASIA	2006	CERATO(LD)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CERATO(LD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2006	CERATO(LD)		G 2.0 DOHC	Unleaded GEN(CVVT-)		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 2.0 DOHC	Unleaded GEN(CVVT+)		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 2.0 DOHC	Unleaded EOBD(CVVT-)		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 2.0 DOHC	Unleaded EOBD(CVVT+)		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 2.0 DOHC	Leaded All(CVVT-)		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 2.0 DOHC	Leaded All(CVVT+)		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CERATO(LD)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2006	CERATO(LD)		D 1.6 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		D 1.6 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		D 1.6 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		D 1.6 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CERATO(LD)		D 1.6 TCI-U	Immobilizer					X		
KIA	ASIA	2006	CERATO(LD)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		D 2.0 TCI-D	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CERATO(LD)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2006	CERATO(LD)		D 1.5 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		D 1.5 TCI-U	Automatic Transaxle		X	X	X	X	X	

KIA	ASIA	2006	CERATO(LD)		D 1.5 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	CERATO(LD)		D 1.5 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CERATO(LD)		D 1.5 TCI-U	Immobilizer					X		
KIA	ASIA	2005	CERATO(LD)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	CERATO(LD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2005	CERATO(LD)		G 2.0 DOHC	Unleaded GEN(CVVT-)		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 2.0 DOHC	Unleaded GEN(CVVT+)		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 2.0 DOHC	Unleaded EOBD(CVVT-)		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 2.0 DOHC	Unleaded EOBD(CVVT+)		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 2.0 DOHC	Leaded All(CVVT-)		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 2.0 DOHC	Leaded All(CVVT+)		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	CERATO(LD)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2005	CERATO(LD)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		D 2.0 TCI-D	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2005	CERATO(LD)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2005	CERATO(LD)		D 1.5 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		D 1.5 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		D 1.5 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	CERATO(LD)		D 1.5 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2005	CERATO(LD)		D 1.5 TCI-U	Immobilizer					X		
KIA	ASIA	2004	CERATO(LD)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	CERATO(LD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2004	CERATO(LD)		G 2.0 DOHC	Unleaded GEN(CVVT-)		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 2.0 DOHC	Unleaded GEN(CVVT+)		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 2.0 DOHC	Unleaded EOBD(CVVT-)		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 2.0 DOHC	Unleaded EOBD(CVVT+)		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 2.0 DOHC	Leaded All(CVVT-)		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 2.0 DOHC	Leaded All(CVVT+)		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	CERATO(LD)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2004	CERATO(LD)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	CERATO(LD)		D 2.0 TCI-D	Anti-Lock Brake		X	X	X	X	X	

KIA	ASIA	2004	CERATO(LD)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2004	CERATO(LD)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2003	CERATO(LD)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2003	CERATO(LD)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2003	CERATO(LD)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2003	CERATO(LD)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	CERATO(LD)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	CERATO(LD)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	CERATO(LD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2000	CLARUS(FE)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2000	CLARUS(FE)		G 2.0 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	2000	CLARUS(FE)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	2000	CLARUS(FE)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2000	CLARUS(FE)		G 1.8 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	2000	CLARUS(FE)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	1999	CLARUS(FE)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	1999	CLARUS(FE)		G 2.0 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	1999	CLARUS(FE)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	1999	CLARUS(FE)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	1999	CLARUS(FE)		G 1.8 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	1999	CLARUS(FE)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	1998	CLARUS(FE)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	1998	CLARUS(FE)		G 2.0 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	1998	CLARUS(FE)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	1998	CLARUS(FE)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	1998	CLARUS(FE)		G 1.8 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	1998	CLARUS(FE)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	1997	CLARUS(FE)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	1997	CLARUS(FE)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	1996	CLARUS(FE)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	1996	CLARUS(FE)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	1995	CLARUS(FE)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	2002	ENTERPRISE(DB)		G 3.0 DOHC	Engine Control			X	X	X		
KIA	ASIA	2001	ENTERPRISE(DB)		G 3.0 DOHC	Engine Control			X	X	X		
KIA	ASIA	2000	ENTERPRISE(DB)		G 2.5 DOHC	Engine Control			X	X	X		
KIA	ASIA	2000	ENTERPRISE(DB)		G 3.0 DOHC	Engine Control			X	X	X		
KIA	ASIA	2000	ENTERPRISE(DB)		G 3.6 DOHC	Engine Control			X	X	X		
KIA	ASIA	1999	ENTERPRISE(DB)		G 2.5 DOHC	Engine Control			X	X	X		
KIA	ASIA	1999	ENTERPRISE(DB)		G 3.0 DOHC	Engine Control			X	X	X		
KIA	ASIA	1999	ENTERPRISE(DB)		G 3.6 DOHC	Engine Control			X	X	X		
KIA	ASIA	1998	ENTERPRISE(DB)		G 3.6 DOHC	Engine Control			X	X	X		
KIA	ASIA	1997	ENTERPRISE(DB)		G 3.0 DOHC	Engine Control			X	X	X		
KIA	ASIA	1997	ENTERPRISE(DB)		G 3.6 DOHC	Engine Control			X	X	X		
KIA	ASIA	2002	JOICE(NO)		G 2.0 DOHC	Unleaded EURO-3		X	X	X	X	X	
KIA	ASIA	2002	JOICE(NO)		G 2.0 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	2002	JOICE(NO)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2001	JOICE(NO)		G 2.0 DOHC	Unleaded EURO-3		X	X	X	X	X	
KIA	ASIA	2001	JOICE(NO)		G 2.0 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	2001	JOICE(NO)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2000	JOICE(NO)		G 2.0 DOHC	Unleaded EURO-3		X	X	X	X	X	

KIA	ASIA	2000	JOICE(NO)		G 2.0 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	2000	JOICE(NO)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	1999	JOICE(NO)		G 2.0 DOHC	Unleaded EURO-3		X	X	X	X	X	
KIA	ASIA	1999	JOICE(NO)		G 2.0 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	1999	JOICE(NO)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 2.7 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 2.7 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 2.7 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 2.9 C/R-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 2.9 C/R-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 2.9 C/R-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 2.9 C/R-J	Immobilizer					X		
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 3.0 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 3.0 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 3.0 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 3.0 IDI-J	Immobilizer					X		
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Engine Control			X	X	X	X	
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 2.7 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 2.7 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 2.7 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 2.9 C/R-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 2.9 C/R-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 2.9 C/R-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 2.9 C/R-J	Immobilizer					X		
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 3.0 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 3.0 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 3.0 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 3.0 IDI-J	Immobilizer					X		
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Engine Control			X	X	X	X	
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 2.7 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 2.7 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 2.7 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 2.9 C/R-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 2.9 C/R-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 2.9 C/R-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 2.9 C/R-J	Immobilizer					X		
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 3.0 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 3.0 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 3.0 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 3.0 IDI-J	Immobilizer					X		
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Engine Control			X	X	X	X	
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 2.7 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 2.7 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 2.7 IDI-J	Anti-Lock Brake		X	X	X	X	X	

KIA	ASIA	2007	K2500/K2700/K3000/K300		D 3.0 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 3.0 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 3.0 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 3.0 IDI-J	Immobilizer					X		
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Engine Control			X	X	X	X	
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 2.9 C/R-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 2.9 C/R-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 2.9 C/R-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	K2500/K2700/K3000/K300		D 2.9 C/R-J	Immobilizer					X		
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 2.7 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 2.7 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 2.7 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 3.0 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 3.0 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 3.0 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 3.0 IDI-J	Immobilizer					X		
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Engine Control			X	X	X	X	
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 2.9 C/R-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 2.9 C/R-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 2.9 C/R-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	K2500/K2700/K3000/K300		D 2.9 C/R-J	Immobilizer					X		
KIA	ASIA	2005	K2500/K2700/K3000/K300		D 2.7 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	K2500/K2700/K3000/K300		D 2.7 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	K2500/K2700/K3000/K300		D 2.7 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	K2500/K2700/K3000/K300		D 3.0 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	K2500/K2700/K3000/K300		D 3.0 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	K2500/K2700/K3000/K300		D 3.0 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	K2500/K2700/K3000/K300		D 3.0 IDI-J	Immobilizer					X		
KIA	ASIA	2005	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Engine Control			X	X	X	X	
KIA	ASIA	2005	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	K2500/K2700/K3000/K300		D 2.7 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2004	K2500/K2700/K3000/K300		D 2.7 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	K2500/K2700/K3000/K300		D 2.7 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	K2500/K2700/K3000/K300		D 3.0 IDI-J	Engine Control		X	X	X	X	X	
KIA	ASIA	2004	K2500/K2700/K3000/K300		D 3.0 IDI-J	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	K2500/K2700/K3000/K300		D 3.0 IDI-J	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	K2500/K2700/K3000/K300		D 3.0 IDI-J	Immobilizer					X		
KIA	ASIA	2004	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Engine Control			X	X	X	X	
KIA	ASIA	2004	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	K2500/K2700/K3000/K300		D 2.5 TCI-4D56	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Electronic Stability Program		X	X	X	X	X	

KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Power Distribution Module						X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Power Distribution Module						X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Power Distribution Module						X	
KIA	ASIA	2010	Optima/Magentis(MG)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	Optima/Magentis(MG)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		D 2.0 TCI-D	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2010	Optima/Magentis(MG)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		D 2.0 TCI-D	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2010	Optima/Magentis(MG)		D 2.0 TCI-D	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2010	Optima/Magentis(MG)		D 2.0 TCI-D	Smart Key Code Saving					X		
KIA	ASIA	2010	Optima/Magentis(MG)		D 2.0 TCI-D	Power Distribution Module						X	
KIA	ASIA	2010	Optima/Magentis(MG)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	

KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Power Distribution Module						X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Power Distribution Module						X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Power Distribution Module						X	
KIA	ASIA	2009	Optima/Magentis(MG)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	Optima/Magentis(MG)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		D 2.0 TCI-D	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2009	Optima/Magentis(MG)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		D 2.0 TCI-D	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2009	Optima/Magentis(MG)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2009	Optima/Magentis(MG)		D 2.0 TCI-D	Smart Key Unit		X	X	X	X	X	

KIA	ASIA	2009	Optima/Magentis(MG)		D 2.0 TCI-D	Smart Key Code Saving					X		
KIA	ASIA	2009	Optima/Magentis(MG)		D 2.0 TCI-D	Power Distribution Module						X	
KIA	ASIA	2009	Optima/Magentis(MG)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.0 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.4 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.7 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.7 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.7 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2008	Optima/Magentis(MG)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	Optima/Magentis(MG)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		D 2.0 TCI-D	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2008	Optima/Magentis(MG)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		D 2.0 TCI-D	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2008	Optima/Magentis(MG)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2008	Optima/Magentis(MG)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	

KIA	ASIA	2007	Optima/Magentis(MG)		G 2.0 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.4 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.7 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.7 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.7 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2007	Optima/Magentis(MG)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	Optima/Magentis(MG)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		D 2.0 TCI-D	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2007	Optima/Magentis(MG)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		D 2.0 TCI-D	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2007	Optima/Magentis(MG)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2007	Optima/Magentis(MG)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.0 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.4 DOHC	Electronic Control Suspension		X	X	X	X	X	

KIA	ASIA	2006	Optima/Magentis(MG)		G 2.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.7 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.7 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.7 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2006	Optima/Magentis(MG)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2006	Optima/Magentis(MG)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		D 2.0 TCI-D	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2006	Optima/Magentis(MG)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		D 2.0 TCI-D	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2006	Optima/Magentis(MG)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2006	Optima/Magentis(MG)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.0 DOHC	Unleaded(Automatic Transaxle)		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.0 DOHC	Unleaded(Manual Transaxle)		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.0 DOHC	Leaded(Manual Transaxle)		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.0 DOHC	Leaded(Automatic Transaxle)		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.0 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.0 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.7 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.7 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.7 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded EOBD(ZrO2)		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.5 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded EOBD(TiO2)		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.5 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.5 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2006	Optima/Magentis(MS)		G 2.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.0 DOHC	Unleaded(Automatic Transaxle)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.0 DOHC	Unleaded(Manual Transaxle)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.0 DOHC	Leaded(Manual Transaxle)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.0 DOHC	Leaded(Automatic Transaxle)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.0 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	

KIA	ASIA	2005	Optima/Magentis(MS)		G 2.0 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.4 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.4 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.7 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.7 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.7 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded EOBD(ZrO2)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.5 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded EOBD(TiO2)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.5 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.5 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2005	Optima/Magentis(MS)		G 2.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.0 DOHC	Unleaded(Automatic Transaxle)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.0 DOHC	Unleaded(Manual Transaxle)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.0 DOHC	Leaded(Manual Transaxle)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.0 DOHC	Leaded(Automatic Transaxle)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.0 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.0 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.4 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.4 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.7 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.7 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.7 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded EOBD(ZrO2)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.5 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded EOBD(TiO2)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.5 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.5 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2004	Optima/Magentis(MS)		G 2.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.0 DOHC	Unleaded(Automatic Transaxle)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.0 DOHC	Unleaded(Manual Transaxle)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.0 DOHC	Leaded(Manual Transaxle)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.0 DOHC	Leaded(Automatic Transaxle)		X	X	X	X	X	

KIA	ASIA	2003	Optima/Magentis(MS)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.0 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.0 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.4 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.4 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.7 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.7 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.7 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded EOBD(ZrO2)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.5 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded EOBD(TiO2)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.5 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.5 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2003	Optima/Magentis(MS)		G 2.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.0 DOHC	Unleaded(Automatic Transaxle)		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.0 DOHC	Unleaded(Manual Transaxle)		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.0 DOHC	Leaded(Manual Transaxle)		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.0 DOHC	Leaded(Automatic Transaxle)		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.0 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.0 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.4 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.4 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.7 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.7 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.7 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.5 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.5 DOHC	Anti-Lock Brake(Bosch)		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.5 DOHC	Anti-Lock Brake(Mando)		X	X	X	X	X	
KIA	ASIA	2002	Optima/Magentis(MS)		G 2.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.0 DOHC	Unleaded(Automatic Transaxle)		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.0 DOHC	Unleaded(Manual Transaxle)		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.0 DOHC	Leaded(Manual Transaxle)		X	X	X	X	X	

KIA	ASIA	2001	Optima/Magentis(MS)		G 2.0 DOHC	Leaded(Automatic Transaxle)		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.5 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.5 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2001	Optima/Magentis(MS)		G 2.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	PICANTO(SA)		G 1.0 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.0 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.0 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.0 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.0 SOHC	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.0 SOHC	ABS/ESP(MGH-60)		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.0 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	PICANTO(SA)		G 1.0 SOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.0 SOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	PICANTO(SA)		G 1.0 SOHC	Immobilizer(Bosch)					X		
KIA	ASIA	2010	PICANTO(SA)		G 1.1 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.1 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.1 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.1 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.1 SOHC	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.1 SOHC	ABS/ESP(MGH-60)		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.1 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	PICANTO(SA)		G 1.1 SOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		G 1.1 SOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	PICANTO(SA)		G 1.1 SOHC	Immobilizer					X		
KIA	ASIA	2010	PICANTO(SA)		D 1.1 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		D 1.1 TCI-U	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		D 1.1 TCI-U	ABS/ESP(MGH-60)		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		D 1.1 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2010	PICANTO(SA)		D 1.1 TCI-U	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	PICANTO(SA)		D 1.1 TCI-U	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	PICANTO(SA)		D 1.1 TCI-U	Immobilizer(Bosch)					X		
KIA	ASIA	2009	PICANTO(SA)		G 1.0 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		G 1.0 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		G 1.0 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		G 1.0 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		G 1.0 SOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		G 1.0 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	PICANTO(SA)		G 1.0 SOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		G 1.0 SOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	PICANTO(SA)		G 1.0 SOHC	Immobilizer(Bosch)					X		

KIA	ASIA	2009	PICANTO(SA)		G 1.1 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		G 1.1 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		G 1.1 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		G 1.1 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		G 1.1 SOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		G 1.1 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	PICANTO(SA)		G 1.1 SOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		G 1.1 SOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	PICANTO(SA)		G 1.1 SOHC	Immobilizer					X		
KIA	ASIA	2009	PICANTO(SA)		D 1.1 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		D 1.1 TCI-U	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		D 1.1 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2009	PICANTO(SA)		D 1.1 TCI-U	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	PICANTO(SA)		D 1.1 TCI-U	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	PICANTO(SA)		D 1.1 TCI-U	Immobilizer(Bosch)					X		
KIA	ASIA	2008	PICANTO(SA)		G 1.0 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.0 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.0 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.0 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.0 SOHC	ABS/ESP(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.0 SOHC	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.0 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	PICANTO(SA)		G 1.0 SOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.0 SOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	PICANTO(SA)		G 1.0 SOHC	Immobilizer					X		
KIA	ASIA	2008	PICANTO(SA)		G 1.1 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.1 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.1 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.1 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.1 SOHC	ABS/ESP(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.1 SOHC	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.1 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	PICANTO(SA)		G 1.1 SOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		G 1.1 SOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	PICANTO(SA)		G 1.1 SOHC	Immobilizer					X		
KIA	ASIA	2008	PICANTO(SA)		D 1.1 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		D 1.1 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		D 1.1 TCI-U	ABS/ESP(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		D 1.1 TCI-U	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		D 1.1 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2008	PICANTO(SA)		D 1.1 TCI-U	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(SA)		D 1.1 TCI-U	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	PICANTO(SA)		D 1.1 TCI-U	Immobilizer					X		
KIA	ASIA	2007	PICANTO(SA)		G 1.0 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		G 1.0 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		G 1.0 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		G 1.0 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		G 1.0 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		G 1.0 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	PICANTO(SA)		G 1.0 SOHC	Electronic Power Steering		X	X	X	X		

KIA	ASIA	2007	PICANTO(SA)		G 1.0 SOHC	Immobilizer					X		
KIA	ASIA	2007	PICANTO(SA)		G 1.1 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		G 1.1 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		G 1.1 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		G 1.1 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		G 1.1 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		G 1.1 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	PICANTO(SA)		G 1.1 SOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	PICANTO(SA)		G 1.1 SOHC	Immobilizer					X		
KIA	ASIA	2007	PICANTO(SA)		D 1.1 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		D 1.1 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		D 1.1 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(SA)		D 1.1 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2007	PICANTO(SA)		D 1.1 TCI-U	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	PICANTO(SA)		D 1.1 TCI-U	Immobilizer					X		
KIA	ASIA	2006	PICANTO(SA)		G 1.0 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		G 1.0 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		G 1.0 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		G 1.0 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		G 1.0 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		G 1.0 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	PICANTO(SA)		G 1.0 SOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2006	PICANTO(SA)		G 1.0 SOHC	Immobilizer					X		
KIA	ASIA	2006	PICANTO(SA)		G 1.1 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		G 1.1 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		G 1.1 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		G 1.1 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		G 1.1 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		G 1.1 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	PICANTO(SA)		G 1.1 SOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2006	PICANTO(SA)		G 1.1 SOHC	Immobilizer					X		
KIA	ASIA	2006	PICANTO(SA)		D 1.1 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		D 1.1 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		D 1.1 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(SA)		D 1.1 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2006	PICANTO(SA)		D 1.1 TCI-U	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2006	PICANTO(SA)		D 1.1 TCI-U	Immobilizer					X		
KIA	ASIA	2005	PICANTO(SA)		G 1.0 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2005	PICANTO(SA)		G 1.0 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2005	PICANTO(SA)		G 1.0 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2005	PICANTO(SA)		G 1.0 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	PICANTO(SA)		G 1.0 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	PICANTO(SA)		G 1.0 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	PICANTO(SA)		G 1.0 SOHC	Immobilizer					X		
KIA	ASIA	2005	PICANTO(SA)		G 1.1 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2005	PICANTO(SA)		G 1.1 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2005	PICANTO(SA)		G 1.1 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2005	PICANTO(SA)		G 1.1 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	PICANTO(SA)		G 1.1 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	PICANTO(SA)		G 1.1 SOHC	Airbag Control		X	X	X	X		

KIA	ASIA	2005	PICANTO(SA)		G 1.1 SOHC	Immobilizer					X		
KIA	ASIA	2004	PICANTO(SA)		G 1.0 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2004	PICANTO(SA)		G 1.0 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2004	PICANTO(SA)		G 1.0 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2004	PICANTO(SA)		G 1.0 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	PICANTO(SA)		G 1.0 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	PICANTO(SA)		G 1.0 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	PICANTO(SA)		G 1.0 SOHC	Immobilizer					X		
KIA	ASIA	2004	PICANTO(SA)		G 1.1 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2004	PICANTO(SA)		G 1.1 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2004	PICANTO(SA)		G 1.1 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2004	PICANTO(SA)		G 1.1 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	PICANTO(SA)		G 1.1 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	PICANTO(SA)		G 1.1 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	PICANTO(SA)		G 1.1 SOHC	Immobilizer					X		
KIA	ASIA	2003	PICANTO(SA)		G 1.1 SOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2003	PICANTO(SA)		G 1.1 SOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2003	PICANTO(SA)		G 1.1 SOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2003	PICANTO(SA)		G 1.1 SOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	PICANTO(SA)		G 1.1 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	PICANTO(SA)		G 1.1 SOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	PICANTO(SA)		G 1.1 SOHC	Immobilizer					X		
KIA	ASIA	2006	PREGIO(FP)		D 2.5 TCI	Engine Control			X	X	X	X	
KIA	ASIA	2006	PREGIO(FP)		D 2.5 TCI	Immobilizer					X		
KIA	ASIA	2006	PREGIO(FP)		D 2.7 J2	Engine Control			X	X	X	X	
KIA	ASIA	2006	PREGIO(FP)		D 2.7 J2	Immobilizer					X		
KIA	ASIA	2005	PREGIO(FP)		D 2.5 TCI	Engine Control			X	X	X	X	
KIA	ASIA	2005	PREGIO(FP)		D 2.7 J2	Engine Control			X	X	X	X	
KIA	ASIA	2004	PREGIO(FP)		D 2.5 TCI	Engine Control			X	X	X	X	
KIA	ASIA	2004	PREGIO(FP)		D 2.7 J2	Engine Control			X	X	X	X	
KIA	ASIA	2003	PREGIO(FP)		D 2.5 TCI	Engine Control			X	X	X	X	
KIA	ASIA	2003	PREGIO(FP)		D 2.7 J2	Engine Control			X	X	X	X	
KIA	ASIA	2002	PREGIO(FP)		D 2.5 TCI	Engine Control			X	X	X	X	
KIA	ASIA	2002	PREGIO(FP)		D 2.7 J2	Engine Control			X	X	X	X	
KIA	ASIA	2001	PREGIO(FP)		D 2.7 J2	Engine Control			X	X	X	X	
KIA	ASIA	2000	PREGIO(FP)		D 2.7 J2	Engine Control			X	X	X	X	
KIA	ASIA	1999	PREGIO(FP)		D 2.7 J2	Engine Control			X	X	X	X	
KIA	ASIA	1998	PREGIO(FP)		D 2.7 J2	Engine Control			X	X	X	X	
KIA	ASIA	1997	PREGIO(FP)		D 2.7 J2	Engine Control			X	X	X	X	
KIA	ASIA	2004	PRIDE(PRD)		G 1.3 SOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2003	PRIDE(PRD)		G 1.3 SOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2002	PRIDE(PRD)		G 1.3 SOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2001	PRIDE(PRD)		G 1.3 SOHC	Immobilizer							
KIA	ASIA	2000	PRIDE(PRD)		G 1.3 SOHC	Immobilizer							
KIA	ASIA	1999	PRIDE(PRD)		G 1.3 SOHC	Immobilizer							
KIA	ASIA	1998	PRIDE(PRD)		G 1.3 SOHC	Immobilizer							
KIA	ASIA	2001	RETONA(JL)		G 2.0 DOHC	Engine Control			X	X	X		
KIA	ASIA	2001	RETONA(JL)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2001	RETONA(JL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	2001	RETONA(JL)		D 2.0 TCI	Automatic Transaxle			X	X	X		

KIA	ASIA	2001	RETONA(JL)		D 2.0 TCI	Immobilizer							
KIA	ASIA	2000	RETONA(JL)		G 2.0 DOHC	Engine Control			X	X	X		
KIA	ASIA	2000	RETONA(JL)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2000	RETONA(JL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	2000	RETONA(JL)		D 2.0 TCI	Automatic Transaxle			X	X	X		
KIA	ASIA	2000	RETONA(JL)		D 2.0 TCI	Immobilizer							
KIA	ASIA	1999	RETONA(JL)		G 2.0 DOHC	Engine Control			X	X	X		
KIA	ASIA	1999	RETONA(JL)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	1999	RETONA(JL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	1999	RETONA(JL)		D 2.0 TCI	Automatic Transaxle			X	X	X		
KIA	ASIA	1999	RETONA(JL)		D 2.0 TCI	Immobilizer							
KIA	ASIA	1998	RETONA(JL)		D 2.0 TCI	Automatic Transaxle			X	X	X		
KIA	ASIA	1998	RETONA(JL)		D 2.0 TCI	Immobilizer							
KIA	ASIA	2006	RIO(BC)		G 1.3 SOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.3 SOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.3 SOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.3 SOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.3 SOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.3 SOHC	Leaded All			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.3 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	RIO(BC)		G 1.3 SOHC	Airbag Control(Left Hand)		X	X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.3 SOHC	Airbag Control(Right Hand)		X	X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.3 SOHC	Immobilizer							
KIA	ASIA	2006	RIO(BC)		G 1.5 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.5 DOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.5 DOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.5 DOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.5 DOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.5 DOHC	Leaded All			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	RIO(BC)		G 1.5 DOHC	Airbag Control(Left Hand)		X	X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.5 DOHC	Airbag Control(Right Hand)		X	X	X	X		
KIA	ASIA	2006	RIO(BC)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	2005	RIO(BC)		G 1.3 SOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.3 SOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.3 SOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.3 SOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.3 SOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.3 SOHC	Leaded All			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.3 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	RIO(BC)		G 1.3 SOHC	Airbag Control(Left Hand)		X	X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.3 SOHC	Airbag Control(Right Hand)		X	X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.3 SOHC	Immobilizer							
KIA	ASIA	2005	RIO(BC)		G 1.5 DOHC	Unleaded (Immobilizer+)			X	X	X		

KIA	ASIA	2005	RIO(BC)		G 1.5 DOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.5 DOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.5 DOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.5 DOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.5 DOHC	Leaded All			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	RIO(BC)		G 1.5 DOHC	Airbag Control(Left Hand)		X	X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.5 DOHC	Airbag Control(Right Hand)		X	X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	2005	RIO(BC)		G 1.6 DOHC	Engine Control			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.6 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2005	RIO(BC)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	RIO(BC)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.3 SOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.3 SOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.3 SOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.3 SOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.3 SOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.3 SOHC	Leaded All			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.3 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	RIO(BC)		G 1.3 SOHC	Airbag Control(Left Hand)		X	X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.3 SOHC	Airbag Control(Right Hand)		X	X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.3 SOHC	Immobilizer							
KIA	ASIA	2004	RIO(BC)		G 1.5 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.5 DOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.5 DOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.5 DOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.5 DOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.5 DOHC	Leaded All			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	RIO(BC)		G 1.5 DOHC	Airbag Control(Left Hand)		X	X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.5 DOHC	Airbag Control(Right Hand)		X	X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	2004	RIO(BC)		G 1.6 DOHC	Engine Control			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.6 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2004	RIO(BC)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	RIO(BC)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.3 SOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.3 SOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.3 SOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.3 SOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.3 SOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.3 SOHC	Leaded All			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Left			X	X	X		

KIA	ASIA	2003	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.3 SOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	RIO(BC)		G 1.3 SOHC	Airbag Control(Left Hand)		X	X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.3 SOHC	Airbag Control(Right Hand)		X	X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.3 SOHC	Immobilizer							
KIA	ASIA	2003	RIO(BC)		G 1.5 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.5 DOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.5 DOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.5 DOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.5 DOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.5 DOHC	Leaded All			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	RIO(BC)		G 1.5 DOHC	Airbag Control(Left Hand)		X	X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.5 DOHC	Airbag Control(Right Hand)		X	X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	2003	RIO(BC)		G 1.6 DOHC	Engine Control			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.6 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2003	RIO(BC)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	RIO(BC)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Leaded All			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Anti-Lock Brake(Left Hand)							
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Anti-Lock Brake(Right Hand)							
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Airbag Control(Left Hand)		X	X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Airbag Control(Right Hand)		X	X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.3 SOHC	Immobilizer							
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Leaded All			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Anti-Lock Brake(Left Hand)							
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Anti-Lock Brake(Right Hand)							
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Airbag Control(Left Hand)		X	X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Airbag Control(Right Hand)		X	X	X	X		
KIA	ASIA	2002	RIO(BC)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Unleaded(MAP)			X	X	X		

KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Leaded All			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Anti-Lock Brake(Left Hand)							
KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Anti-Lock Brake(Right Hand)							
KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Airbag Control(Left Hand)		X	X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Airbag Control(Right Hand)		X	X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.3 SOHC	Immobilizer							
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Leaded All			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Anti-Lock Brake(Left Hand)							
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Anti-Lock Brake(Right Hand)							
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Airbag Control(Left Hand)		X	X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Airbag Control(Right Hand)		X	X	X	X		
KIA	ASIA	2001	RIO(BC)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	2000	RIO(BC)		G 1.3 SOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.3 SOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.3 SOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.3 SOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.3 SOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.3 SOHC	Leaded All			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.3 SOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.3 SOHC	Anti-Lock Brake(Left Hand)							
KIA	ASIA	2000	RIO(BC)		G 1.3 SOHC	Anti-Lock Brake(Right Hand)							
KIA	ASIA	2000	RIO(BC)		G 1.3 SOHC	Immobilizer							
KIA	ASIA	2000	RIO(BC)		G 1.5 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.5 DOHC	Unleaded(MAF)			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.5 DOHC	Unleaded(MAP)			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.5 DOHC	Unleaded Right Hand(MAF)			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.5 DOHC	Unleaded Left Hand(MAP)			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.5 DOHC	Leaded All			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Left			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.5 DOHC	Automatic Transaxle(Right			X	X	X		
KIA	ASIA	2000	RIO(BC)		G 1.5 DOHC	Anti-Lock Brake(Left Hand)							
KIA	ASIA	2000	RIO(BC)		G 1.5 DOHC	Anti-Lock Brake(Right Hand)							
KIA	ASIA	2000	RIO(BC)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	2011	RIO(JB)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	RIO(JB)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	RIO(JB)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	RIO(JB)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	RIO(JB)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	

KIA	ASIA	2011	RIO(JB)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2011	RIO(JB)		G 1.6 DOHC	Power Steering		X	X	X	X		
KIA	ASIA	2011	RIO(JB)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2011	RIO(JB)		G 1.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	RIO(JB)		G 1.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	RIO(JB)		G 1.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	RIO(JB)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	RIO(JB)		G 1.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2011	RIO(JB)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2011	RIO(JB)		G 1.4 DOHC	Power Steering		X	X	X	X		
KIA	ASIA	2011	RIO(JB)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2011	RIO(JB)		D 1.5 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	RIO(JB)		D 1.5 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	RIO(JB)		D 1.5 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2011	RIO(JB)		D 1.5 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2011	RIO(JB)		D 1.5 TCI-U	Power Steering		X	X	X	X		
KIA	ASIA	2011	RIO(JB)		D 1.5 TCI-U	Immobilizer					X		
KIA	ASIA	2010	RIO(JB)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	RIO(JB)		G 1.6 DOHC	Power Steering		X	X	X	X		
KIA	ASIA	2010	RIO(JB)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2010	RIO(JB)		G 1.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		G 1.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		G 1.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		G 1.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	RIO(JB)		G 1.4 DOHC	Power Steering		X	X	X	X		
KIA	ASIA	2010	RIO(JB)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2010	RIO(JB)		D 1.5 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		D 1.5 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		D 1.5 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2010	RIO(JB)		D 1.5 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2010	RIO(JB)		D 1.5 TCI-U	Power Steering		X	X	X	X		
KIA	ASIA	2010	RIO(JB)		D 1.5 TCI-U	Immobilizer					X		
KIA	ASIA	2009	RIO(JB)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		G 1.6 DOHC	Anti-Lock Brake(MGH-25)		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		G 1.6 DOHC	Anti-Lock Brake(MGH-40)		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	RIO(JB)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2009	RIO(JB)		G 1.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		G 1.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		G 1.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	

KIA	ASIA	2009	RIO(JB)		G 1.4 DOHC	Anti-Lock Brake(MGH-25)		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		G 1.4 DOHC	Anti-Lock Brake(MGH-40)		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	RIO(JB)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2009	RIO(JB)		D 1.5 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		D 1.5 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		D 1.5 TCI-U	Anti-Lock Brake(MGH-25)		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		D 1.5 TCI-U	Anti-Lock Brake(MGH-40)		X	X	X	X	X	
KIA	ASIA	2009	RIO(JB)		D 1.5 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2009	RIO(JB)		D 1.5 TCI-U	Immobilizer					X		
KIA	ASIA	2008	RIO(JB)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		G 1.6 DOHC	Anti-Lock Brake(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		G 1.6 DOHC	Anti-Lock Brake(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	RIO(JB)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2008	RIO(JB)		G 1.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		G 1.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		G 1.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		G 1.4 DOHC	Anti-Lock Brake(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		G 1.4 DOHC	Anti-Lock Brake(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	RIO(JB)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2008	RIO(JB)		D 1.5 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		D 1.5 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		D 1.5 TCI-U	Anti-Lock Brake(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		D 1.5 TCI-U	Anti-Lock Brake(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	RIO(JB)		D 1.5 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2008	RIO(JB)		D 1.5 TCI-U	Immobilizer					X		
KIA	ASIA	2007	RIO(JB)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	RIO(JB)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2007	RIO(JB)		G 1.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		G 1.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		G 1.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		G 1.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	RIO(JB)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2007	RIO(JB)		D 1.5 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		D 1.5 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		D 1.5 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	RIO(JB)		D 1.5 TCI-U	Airbag Control		X	X	X	X		

KIA	ASIA	2007	RIO(JB)		D 1.5 TCI-U	Immobilizer					X		
KIA	ASIA	2006	RIO(JB)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	RIO(JB)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2006	RIO(JB)		G 1.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		G 1.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		G 1.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		G 1.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	RIO(JB)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2006	RIO(JB)		D 1.5 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		D 1.5 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		D 1.5 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	RIO(JB)		D 1.5 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2006	RIO(JB)		D 1.5 TCI-U	Immobilizer					X		
KIA	ASIA	2005	RIO(JB)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	RIO(JB)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2005	RIO(JB)		G 1.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		G 1.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		G 1.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		G 1.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		G 1.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		G 1.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	RIO(JB)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2005	RIO(JB)		D 1.5 TCI-U	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		D 1.5 TCI-U	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		D 1.5 TCI-U	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	RIO(JB)		D 1.5 TCI-U	Airbag Control		X	X	X	X		
KIA	ASIA	2005	RIO(JB)		D 1.5 TCI-U	Immobilizer					X		
KIA	ASIA	2000	SEPHIA II(FB22)		G 1.5 DOHC	Engine Control			X	X	X		
KIA	ASIA	2000	SEPHIA II(FB22)		G 1.5 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2000	SEPHIA II(FB22)		G 1.5 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	2000	SEPHIA II(FB22)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	2000	SEPHIA II(FB22)		G 1.8 DOHC	Engine Control			X	X	X		
KIA	ASIA	2000	SEPHIA II(FB22)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2000	SEPHIA II(FB22)		G 1.8 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	2000	SEPHIA II(FB22)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	1999	SEPHIA II(FB22)		G 1.5 DOHC	Engine Control			X	X	X		
KIA	ASIA	1999	SEPHIA II(FB22)		G 1.5 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	1999	SEPHIA II(FB22)		G 1.5 DOHC	Anti-Lock Brake			X	X	X	X	

KIA	ASIA	1999	SEPHIA II(FB22)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	1999	SEPHIA II(FB22)		G 1.8 DOHC	Engine Control			X	X	X		
KIA	ASIA	1999	SEPHIA II(FB22)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	1999	SEPHIA II(FB22)		G 1.8 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	1999	SEPHIA II(FB22)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	1998	SEPHIA II(FB22)		G 1.5 DOHC	Engine Control			X	X	X		
KIA	ASIA	1998	SEPHIA II(FB22)		G 1.5 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	1998	SEPHIA II(FB22)		G 1.5 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	1998	SEPHIA II(FB22)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	1998	SEPHIA II(FB22)		G 1.8 DOHC	Engine Control			X	X	X		
KIA	ASIA	1998	SEPHIA II(FB22)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	1998	SEPHIA II(FB22)		G 1.8 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	1998	SEPHIA II(FB22)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	1998	SEPHIA(FB12)		G 1.6 DOHC	Immobilizer							
KIA	ASIA	1998	SEPHIA(FB12)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	1998	SEPHIA(FB12)		G 1.5 SOHC	Immobilizer							
KIA	ASIA	1998	SEPHIA(FB12)		G 1.6 SOHC	Immobilizer							
KIA	ASIA	1998	SEPHIA(FB12)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	1997	SEPHIA(FB12)		G 1.6 DOHC	Immobilizer							
KIA	ASIA	1997	SEPHIA(FB12)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	1997	SEPHIA(FB12)		G 1.5 SOHC	Immobilizer							
KIA	ASIA	1997	SEPHIA(FB12)		G 1.6 SOHC	Immobilizer							
KIA	ASIA	1997	SEPHIA(FB12)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	1996	SEPHIA(FB12)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	1996	SEPHIA(FB12)		G 1.5 SOHC	Immobilizer							
KIA	ASIA	1996	SEPHIA(FB12)		G 1.6 SOHC	Immobilizer							
KIA	ASIA	1995	SEPHIA(FB12)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	1995	SEPHIA(FB12)		G 1.5 SOHC	Immobilizer							
KIA	ASIA	1995	SEPHIA(FB12)		G 1.6 SOHC	Immobilizer							
KIA	ASIA	2004	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Engine Control			X	X	X		
KIA	ASIA	2004	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2004	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	2004	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Airbag Control(Autonet)	X		X	X	X		
KIA	ASIA	2004	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	2004	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2004	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2004	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Leaded All			X	X	X		
KIA	ASIA	2004	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2004	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	2004	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Airbag Control(Autonet)	X		X	X	X		
KIA	ASIA	2004	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2003	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Engine Control			X	X	X		
KIA	ASIA	2003	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2003	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Anti-Lock Brake							
KIA	ASIA	2003	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	2003	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2003	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2003	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Leaded All			X	X	X		
KIA	ASIA	2003	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2003	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Anti-Lock Brake							

KIA	ASIA	2003	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2002	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Engine Control			X	X	X		
KIA	ASIA	2002	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2002	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Anti-Lock Brake							
KIA	ASIA	2002	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	2002	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2002	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2002	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Leaded All			X	X	X		
KIA	ASIA	2002	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2002	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Anti-Lock Brake							
KIA	ASIA	2002	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.5 DOHC	Engine Control			X	X	X		
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.5 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.5 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.5 DOHC	Immobilizer							
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Engine Control			X	X	X		
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Leaded All			X	X	X		
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Anti-Lock Brake			X	X	X	X	
KIA	ASIA	2001	SHUMA/SPECTRA(SD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Electronic Power Steering		X	X	X	X		

KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Body Control Module		X			X	X	
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Immobilizer					X		
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Smart Key Code Saving					X		
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	SOUL(AM)		D 1.6 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2010	SOUL(AM)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		G 2.0 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2010	SOUL(AM)		G 2.0 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2010	SOUL(AM)		G 2.0 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	SOUL(AM)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	SOUL(AM)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2010	SOUL(AM)		G 2.0 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	SOUL(AM)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		G 1.6 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2010	SOUL(AM)		G 1.6 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2010	SOUL(AM)		G 1.6 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	SOUL(AM)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	SOUL(AM)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2010	SOUL(AM)		G 1.6 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	SOUL(AM)		D 1.6 TCI-U2	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		D 1.6 TCI-U2	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		D 1.6 TCI-U2	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		D 1.6 TCI-U2	Electronic Stability Program		X	X	X	X	X	

KIA	ASIA	2010	SOUL(AM)		D 1.6 TCI-U2	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2010	SOUL(AM)		D 1.6 TCI-U2	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2010	SOUL(AM)		D 1.6 TCI-U2	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	SOUL(AM)		D 1.6 TCI-U2	Body Control Module		X			X	X	
KIA	ASIA	2010	SOUL(AM)		D 1.6 TCI-U2	Immobilizer					X		
KIA	ASIA	2010	SOUL(AM)		D 1.6 TCI-U2	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	SOUL(AM)		D 1.6 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2009	SOUL(AM)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		G 2.0 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2009	SOUL(AM)		G 2.0 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2009	SOUL(AM)		G 2.0 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	SOUL(AM)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	SOUL(AM)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2009	SOUL(AM)		G 2.0 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	SOUL(AM)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		G 1.6 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2009	SOUL(AM)		G 1.6 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2009	SOUL(AM)		G 1.6 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	SOUL(AM)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	SOUL(AM)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2009	SOUL(AM)		G 1.6 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	SOUL(AM)		D 1.6 TCI-U2	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		D 1.6 TCI-U2	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		D 1.6 TCI-U2	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		D 1.6 TCI-U2	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		D 1.6 TCI-U2	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2009	SOUL(AM)		D 1.6 TCI-U2	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2009	SOUL(AM)		D 1.6 TCI-U2	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	SOUL(AM)		D 1.6 TCI-U2	Body Control Module		X			X	X	
KIA	ASIA	2009	SOUL(AM)		D 1.6 TCI-U2	Immobilizer					X		
KIA	ASIA	2009	SOUL(AM)		D 1.6 TCI-U2	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2009	SOUL(AM)		D 1.6 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2004	SPORTAGE(AL)		G 2.0 DOHC	Unleaded		X	X	X	X		
KIA	ASIA	2004	SPORTAGE(AL)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2004	SPORTAGE(AL)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	SPORTAGE(AL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	2004	SPORTAGE(AL)		D 2.0 RF-TCI	Automatic Transaxle			X	X	X		
KIA	ASIA	2004	SPORTAGE(AL)		D 2.0 RF-TCI	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	SPORTAGE(AL)		D 2.0 RF-TCI	Immobilizer							
KIA	ASIA	2003	SPORTAGE(AL)		G 2.0 DOHC	Unleaded		X	X	X	X		

KIA	ASIA	2003	SPORTAGE(AL)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2003	SPORTAGE(AL)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	SPORTAGE(AL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	2003	SPORTAGE(AL)		D 2.0 RF-TCI	Automatic Transaxle			X	X	X		
KIA	ASIA	2003	SPORTAGE(AL)		D 2.0 RF-TCI	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	SPORTAGE(AL)		D 2.0 RF-TCI	Immobilizer							
KIA	ASIA	2002	SPORTAGE(AL)		G 2.0 DOHC	Unleaded		X	X	X	X		
KIA	ASIA	2002	SPORTAGE(AL)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2002	SPORTAGE(AL)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2002	SPORTAGE(AL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	2002	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Automatic Transaxle			X	X	X		
KIA	ASIA	2002	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2002	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Immobilizer							
KIA	ASIA	2002	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Automatic Transaxle			X	X	X		
KIA	ASIA	2002	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2002	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Airbag Control		X	X	X	X		
KIA	ASIA	2002	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Immobilizer							
KIA	ASIA	2001	SPORTAGE(AL)		G 2.0 DOHC	Unleaded		X	X	X	X		
KIA	ASIA	2001	SPORTAGE(AL)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2001	SPORTAGE(AL)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2001	SPORTAGE(AL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	2001	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Automatic Transaxle			X	X	X		
KIA	ASIA	2001	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2001	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Immobilizer							
KIA	ASIA	2001	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Automatic Transaxle			X	X	X		
KIA	ASIA	2001	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2001	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Immobilizer							
KIA	ASIA	2000	SPORTAGE(AL)		G 2.0 DOHC	Unleaded			X	X	X		
KIA	ASIA	2000	SPORTAGE(AL)		G 2.0 DOHC	Engine Control(AUS)			X	X	X		
KIA	ASIA	2000	SPORTAGE(AL)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2000	SPORTAGE(AL)		G 2.0 DOHC	Automatic Transaxle(AUS)			X	X	X		
KIA	ASIA	2000	SPORTAGE(AL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	2000	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Automatic Transaxle			X	X	X		
KIA	ASIA	2000	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Immobilizer							
KIA	ASIA	2000	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Automatic Transaxle			X	X	X		
KIA	ASIA	2000	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Immobilizer							
KIA	ASIA	1999	SPORTAGE(AL)		G 2.0 DOHC	Unleaded			X	X	X		
KIA	ASIA	1999	SPORTAGE(AL)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	1999	SPORTAGE(AL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	1999	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Automatic Transaxle			X	X	X		
KIA	ASIA	1999	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Immobilizer							
KIA	ASIA	1999	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Automatic Transaxle			X	X	X		
KIA	ASIA	1999	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Immobilizer							
KIA	ASIA	1998	SPORTAGE(AL)		G 2.0 DOHC	Unleaded			X	X	X		
KIA	ASIA	1998	SPORTAGE(AL)		G 2.0 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	1998	SPORTAGE(AL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	1998	SPORTAGE(AL)		G 2.0 SOHC	Engine Control			X	X	X		
KIA	ASIA	1998	SPORTAGE(AL)		G 2.0 SOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	1998	SPORTAGE(AL)		G 2.0 SOHC	Immobilizer							
KIA	ASIA	1998	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Automatic Transaxle			X	X	X		

KIA	ASIA	1998	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Immobilizer							
KIA	ASIA	1998	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Automatic Transaxle			X	X	X		
KIA	ASIA	1998	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Immobilizer							
KIA	ASIA	1998	SPORTAGE(AL)		HW	Engine Control			X	X	X		
KIA	ASIA	1998	SPORTAGE(AL)		HW	Automatic Transaxle			X	X	X		
KIA	ASIA	1998	SPORTAGE(AL)		HW	Immobilizer							
KIA	ASIA	1997	SPORTAGE(AL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	1997	SPORTAGE(AL)		G 2.0 SOHC	Immobilizer							
KIA	ASIA	1997	SPORTAGE(AL)		D 2.0 RE(RF-TCI)	Immobilizer							
KIA	ASIA	1997	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Immobilizer							
KIA	ASIA	1997	SPORTAGE(AL)		HW	Immobilizer							
KIA	ASIA	1996	SPORTAGE(AL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	1996	SPORTAGE(AL)		G 2.0 SOHC	Immobilizer							
KIA	ASIA	1996	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Immobilizer							
KIA	ASIA	1996	SPORTAGE(AL)		HW	Immobilizer							
KIA	ASIA	1995	SPORTAGE(AL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	1995	SPORTAGE(AL)		G 2.0 SOHC	Immobilizer							
KIA	ASIA	1995	SPORTAGE(AL)		D 2.0 RT(RF-TCI)	Immobilizer							
KIA	ASIA	1995	SPORTAGE(AL)		HW	Immobilizer							
KIA	ASIA	1994	SPORTAGE(AL)		G 2.0 DOHC	Immobilizer							
KIA	ASIA	1994	SPORTAGE(AL)		G 2.0 SOHC	Immobilizer							
KIA	ASIA	1994	SPORTAGE(AL)		HW	Immobilizer							
KIA	ASIA	1993	SPORTAGE(AL)		G 2.0 SOHC	Immobilizer							
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Unleaded GEN		*	*	*	*	*	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Unleaded EOBD		*	*	*	*	*	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Leaded All		*	*	*	*	*	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	4WD Control		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Smart Junction Box		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Smart Parking Assist System		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Unleaded GEN		*	*	*	*	*	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Unleaded EOBD		*	*	*	*	*	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Leaded All		*	*	*	*	*	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Electronic Power Steering		X	X	X	X		

KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	4WD Control		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Smart Junction Box		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Smart Parking Assist System		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Engine Control		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	4WD Control		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Body Control Module		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Smart Junction Box		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Immobilizer					X		
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Smart Parking Assist System		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		G 1.6 GDI	Transmitter Code Saving					X		
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	High Power(CPF-)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	High Power(CPF+)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Low Power(CPF+)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Low Power(CPF-)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Air Conditioner(GEN)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Air Conditioner(EURO)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	4WD Control		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Body Control Module		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Smart Junction Box		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Immobilizer					X		
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Smart Parking Assist System		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 2.0 TCI-R	Transmitter Code Saving					X		
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Air Conditioner		X	X	X	X	X	

KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	4WD Control		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Body Control Module		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Smart Junction Box		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Immobilizer					X		
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Smart Parking Assist System		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE(SL)		D 1.7 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	4WD Control		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Smart Junction Box		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Smart Parking Assist System		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	4WD Control		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Smart Junction Box		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Smart Parking Assist System		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Airbag Control(Event #2)		X	X	X	X		

KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	4WD Control		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Body Control Module		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Smart Junction Box		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Immobilizer					X		
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Smart Parking Assist System		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		G 1.6 GDI	Transmitter Code Saving					X		
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	High Power(CPF-)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	High Power(CPF+)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Low Power(CPF+)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Low Power(CPF-)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Air Conditioner(GEN)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Air Conditioner(EURO)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	4WD Control		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Body Control Module		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Smart Junction Box		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Immobilizer					X		
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Smart Parking Assist System		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 2.0 TCI-R	Transmitter Code Saving					X		
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	4WD Control		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Body Control Module		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Smart Junction Box		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Immobilizer					X		
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Smart Parking Assist System		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE(SL)		D 1.7 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	Airbag Control(Event #1)		X	X	X	X		

KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Power Steering		X	X	X	X		
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Body Control Module		X			X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Immobilizer					X		
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Smart Key Code Saving					X		
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.6 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	Power Steering		X	X	X	X		
KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	Body Control Module		X			X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	Immobilizer					X		
KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	Smart Key Code Saving					X		
KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	Tire Pressure Monitoring		X	X	X	X	X	

KIA	ASIA	2011	VENGA(YN)		D 1.4 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	Immobilizer					X		
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Power Steering		X	X	X	X		
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Body Control Module		X			X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Immobilizer					X		
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Smart Key Code Saving					X		
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.6 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	Power Steering		X	X	X	X		
KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	Body Control Module		X			X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	Immobilizer					X		

KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	Smart Key Code Saving					X		
KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	VENGA(YN)		D 1.4 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2007	CARENS(FJ)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	CARENS(FJ)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	CARENS(FJ)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	CARENS(FJ)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	CARENS(FJ)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	CARENS(FJ)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	CARENS(FJ)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2007	CARENS(FJ)		G 1.6 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2007	CARENS(FJ)		G 1.6 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2007	CARENS(FJ)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	CARENS(FJ)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	CARENS(FJ)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	CARENS(FJ)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2007	CARENS(FJ)		G 1.8 DOHC	Unleaded EURO-4			X	X	X		
KIA	ASIA	2007	CARENS(FJ)		G 1.8 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2007	CARENS(FJ)		G 1.8 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2007	CARENS(FJ)		G 1.8 DOHC	Leaded All			X	X	X		
KIA	ASIA	2007	CARENS(FJ)		G 1.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	CARENS(FJ)		G 1.8 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	CARENS(FJ)		G 1.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	CARENS(FJ)		G 1.8 DOHC	Immobilizer					X		
KIA	ASIA	2007	CARENS(FJ)		D 2.0 TCI	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	CARENS(FJ)		D 2.0 TCI	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	CARENS(FJ)		D 2.0 TCI	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	CARENS(FJ)		D 2.0 TCI	Airbag Control		X	X	X	X		
KIA	ASIA	2007	CARENS(FJ)		D 2.0 TCI	Immobilizer					X		
KIA	ASIA	2006	CARENS(FJ)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	CARENS(FJ)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2006	CARENS(FJ)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	CARENS(FJ)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CARENS(FJ)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	CARENS(FJ)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CARENS(FJ)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2006	CARENS(FJ)		G 1.6 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2006	CARENS(FJ)		G 1.6 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2006	CARENS(FJ)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CARENS(FJ)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	CARENS(FJ)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CARENS(FJ)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2006	CARENS(FJ)		G 1.8 DOHC	Unleaded EURO-4			X	X	X		
KIA	ASIA	2006	CARENS(FJ)		G 1.8 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2006	CARENS(FJ)		G 1.8 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2006	CARENS(FJ)		G 1.8 DOHC	Leaded All			X	X	X		
KIA	ASIA	2006	CARENS(FJ)		G 1.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CARENS(FJ)		G 1.8 DOHC	Anti-Lock Brake		X	X	X	X	X	

KIA	ASIA	2006	CARENS(FJ)		G 1.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CARENS(FJ)		G 1.8 DOHC	Immobilizer					X		
KIA	ASIA	2006	CARENS(FJ)		D 2.0 TCI	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	CARENS(FJ)		D 2.0 TCI	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CARENS(FJ)		D 2.0 TCI	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	CARENS(FJ)		D 2.0 TCI	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CARENS(FJ)		D 2.0 TCI	Immobilizer					X		
KIA	ASIA	2005	CARENS(FJ)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2005	CARENS(FJ)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2005	CARENS(FJ)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2005	CARENS(FJ)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	CARENS(FJ)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	CARENS(FJ)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	CARENS(FJ)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2005	CARENS(FJ)		G 1.6 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2005	CARENS(FJ)		G 1.6 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2005	CARENS(FJ)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	CARENS(FJ)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	CARENS(FJ)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	CARENS(FJ)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2005	CARENS(FJ)		G 1.8 DOHC	Unleaded EURO-4			X	X	X		
KIA	ASIA	2005	CARENS(FJ)		G 1.8 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2005	CARENS(FJ)		G 1.8 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2005	CARENS(FJ)		G 1.8 DOHC	Leaded All			X	X	X		
KIA	ASIA	2005	CARENS(FJ)		G 1.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	CARENS(FJ)		G 1.8 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	CARENS(FJ)		G 1.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	CARENS(FJ)		G 1.8 DOHC	Immobilizer					X		
KIA	ASIA	2005	CARENS(FJ)		D 2.0 TCI	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	CARENS(FJ)		D 2.0 TCI	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	CARENS(FJ)		D 2.0 TCI	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	CARENS(FJ)		D 2.0 TCI	Airbag Control		X	X	X	X		
KIA	ASIA	2005	CARENS(FJ)		D 2.0 TCI	Immobilizer					X		
KIA	ASIA	2004	CARENS(FJ)		G 1.6 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2004	CARENS(FJ)		G 1.6 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2004	CARENS(FJ)		G 1.6 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2004	CARENS(FJ)		G 1.6 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	CARENS(FJ)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	CARENS(FJ)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2004	CARENS(FJ)		G 1.8 DOHC	Unleaded EURO-4			X	X	X		
KIA	ASIA	2004	CARENS(FJ)		G 1.8 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2004	CARENS(FJ)		G 1.8 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2004	CARENS(FJ)		G 1.8 DOHC	Leaded All			X	X	X		
KIA	ASIA	2004	CARENS(FJ)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2004	CARENS(FJ)		G 1.8 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	CARENS(FJ)		G 1.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	CARENS(FJ)		G 1.8 DOHC	Immobilizer					X		
KIA	ASIA	2004	CARENS(FJ)		D 2.0 TCI	Engine Control		X	X	X	X	X	
KIA	ASIA	2004	CARENS(FJ)		D 2.0 TCI	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	CARENS(FJ)		D 2.0 TCI	Anti-Lock Brake		X	X	X	X	X	

KIA	ASIA	2004	CARENS(FJ)		D 2.0 TCI	Airbag Control		X	X	X	X		
KIA	ASIA	2004	CARENS(FJ)		D 2.0 TCI	Immobilizer					X		
KIA	ASIA	2003	CARENS(FJ)		G 1.8 DOHC	Unleaded EURO-4			X	X	X		
KIA	ASIA	2003	CARENS(FJ)		G 1.8 DOHC	Unleaded (Immobilizer-)			X	X	X		
KIA	ASIA	2003	CARENS(FJ)		G 1.8 DOHC	Unleaded (Immobilizer+)			X	X	X		
KIA	ASIA	2003	CARENS(FJ)		G 1.8 DOHC	Leaded All			X	X	X		
KIA	ASIA	2003	CARENS(FJ)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2003	CARENS(FJ)		G 1.8 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	CARENS(FJ)		G 1.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	CARENS(FJ)		G 1.8 DOHC	Immobilizer					X		
KIA	ASIA	2003	CARENS(FJ)		D 2.0 TCI	Engine Control		X	X	X	X	X	
KIA	ASIA	2003	CARENS(FJ)		D 2.0 TCI	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	CARENS(FJ)		D 2.0 TCI	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	CARENS(FJ)		D 2.0 TCI	Airbag Control		X	X	X	X		
KIA	ASIA	2003	CARENS(FJ)		D 2.0 TCI	Immobilizer					X		
KIA	ASIA	2002	CARENS(FJ)		G 1.8 DOHC	Engine Control(Automatic		X	X	X	X		
KIA	ASIA	2002	CARENS(FJ)		G 1.8 DOHC	Engine Control(Manual		X	X	X	X		
KIA	ASIA	2002	CARENS(FJ)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2002	CARENS(FJ)		G 1.8 DOHC	Anti-Lock Brake							
KIA	ASIA	2002	CARENS(FJ)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	2001	CARENS(FJ)		G 1.8 DOHC	Engine Control(Automatic		X	X	X	X		
KIA	ASIA	2001	CARENS(FJ)		G 1.8 DOHC	Engine Control(Manual		X	X	X	X		
KIA	ASIA	2001	CARENS(FJ)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2001	CARENS(FJ)		G 1.8 DOHC	Anti-Lock Brake							
KIA	ASIA	2001	CARENS(FJ)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	2000	CARENS(FJ)		G 1.8 DOHC	Engine Control			X	X	X		
KIA	ASIA	2000	CARENS(FJ)		G 1.8 DOHC	Automatic Transaxle			X	X	X		
KIA	ASIA	2000	CARENS(FJ)		G 1.8 DOHC	Anti-Lock Brake							
KIA	ASIA	2000	CARENS(FJ)		G 1.8 DOHC	Immobilizer							
KIA	ASIA	2006	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(GEN)			X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(Gasolene)			X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(EURO-3)		X	X	X	X		
KIA	ASIA	2006	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake(EURO-3)		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		G 2.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer(Gasolene)							
KIA	ASIA	2006	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer(Bosch)					X		
KIA	ASIA	2006	CARNIVAL(GQ)		G 3.5 DOHC	Engine Control(Middle East)		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		G 3.5 DOHC	Engine Control(CHINA)		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		G 3.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CARNIVAL(GQ)		D 2.9 TCI-J3	Engine Control(Common Rail)		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle			X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(EURO-3)		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(Common Rail)		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(GQ)		D 2.9 TCI-J3	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer(Common Rail)					X		
KIA	ASIA	2006	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer(J3-TCI)							

KIA	ASIA	2005	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(GEN)			X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(Gasolene)			X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(EURO-3)		X	X	X	X		
KIA	ASIA	2005	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake(EURO-3)		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		G 2.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer(Gasolene)							
KIA	ASIA	2005	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer(Bosch)					X		
KIA	ASIA	2005	CARNIVAL(GQ)		G 3.5 DOHC	Engine Control(Middle East)		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		G 3.5 DOHC	Engine Control(CHINA)		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		G 3.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	CARNIVAL(GQ)		D 2.9 TCI-J3	Engine Control(Common Rail)		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle			X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(EURO-3)		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(Common Rail)		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(GQ)		D 2.9 TCI-J3	Airbag Control		X	X	X	X		
KIA	ASIA	2005	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer(Common Rail)					X		
KIA	ASIA	2005	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer(J3-TCI)							
KIA	ASIA	2004	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(GEN)			X	X	X	X	
KIA	ASIA	2004	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(Gasolene)			X	X	X	X	
KIA	ASIA	2004	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(EURO-3)		X	X	X	X		
KIA	ASIA	2004	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake(EURO-3)		X	X	X	X	X	
KIA	ASIA	2004	CARNIVAL(GQ)		G 2.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer(Gasolene)							
KIA	ASIA	2004	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer(Bosch)					X		
KIA	ASIA	2004	CARNIVAL(GQ)		G 3.5 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2004	CARNIVAL(GQ)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	CARNIVAL(GQ)		G 3.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	CARNIVAL(GQ)		G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	CARNIVAL(GQ)		D 2.9 TCI-J3	Engine Control(Common Rail)		X	X	X	X	X	
KIA	ASIA	2004	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle			X	X	X	X	
KIA	ASIA	2004	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(EURO-3)		X	X	X	X	X	
KIA	ASIA	2004	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(Common Rail)		X	X	X	X	X	
KIA	ASIA	2004	CARNIVAL(GQ)		D 2.9 TCI-J3	Airbag Control		X	X	X	X		
KIA	ASIA	2004	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer(Common Rail)					X		
KIA	ASIA	2004	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer(J3-TCI)							
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.4 DOHC	Engine Control			X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.4 DOHC	Anti-Lock Brake(EURO-3)		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.4 DOHC	Immobilizer(Gasolene)							
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.4 DOHC	Immobilizer(Bosch)					X		
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(GEN)			X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(Gasolene)			X	X	X	X	

KIA	ASIA	2003	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(EURO-3)		X	X	X	X		
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake(EURO-3)		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer(Gasolene)							
KIA	ASIA	2003	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer(Bosch)					X		
KIA	ASIA	2003	CARNIVAL(GQ)		G 3.5 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		G 3.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	CARNIVAL(GQ)		D 2.9 TCI-J3	Engine Control(Common Rail)		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle			X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(EURO-3)		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(Common Rail)		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(GQ)		D 2.9 TCI-J3	Airbag Control		X	X	X	X		
KIA	ASIA	2003	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer(Common Rail)					X		
KIA	ASIA	2003	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer(J3-TCI)							
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.4 DOHC	Engine Control			X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.4 DOHC	Anti-Lock Brake(EURO-3)		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.4 DOHC	Anti-Lock Brake(Common Rail)		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.4 DOHC	Immobilizer							
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.4 DOHC	Immobilizer(Bosch)					X		
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(GEN)			X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(EURO)			X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(EURO-3)		X	X	X	X		
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake(EURO-3)		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake(Common Rail)		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer							
KIA	ASIA	2002	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer(Bosch)					X		
KIA	ASIA	2002	CARNIVAL(GQ)		D 2.9 TCI-J3	Engine Control(Common Rail)		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle			X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(EURO-3)		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(Common Rail)		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(GQ)		D 2.9 TCI-J3	Airbag Control		X	X	X	X		
KIA	ASIA	2002	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer(Common Rail)					X		
KIA	ASIA	2002	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer(J3-TCI)							
KIA	ASIA	2001	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(GEN)			X	X	X	X	
KIA	ASIA	2001	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(EURO)			X	X	X	X	
KIA	ASIA	2001	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle(GEN)		X	X	X	X	X	
KIA	ASIA	2001	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle(EURO)		X	X	X	X	X	
KIA	ASIA	2001	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake(GEN)		X	X	X	X	X	
KIA	ASIA	2001	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake(EURO)		X	X	X	X	X	

KIA	ASIA	2001	CARNIVAL(GQ)		G 2.5 DOHC	Airbag Control(GEN)		X	X	X	X		
KIA	ASIA	2001	CARNIVAL(GQ)		G 2.5 DOHC	Airbag Control(EURO)		X	X	X	X		
KIA	ASIA	2001	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer							
KIA	ASIA	2001	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle(GEN)			X	X	X		
KIA	ASIA	2001	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle(EURO)			X	X	X		
KIA	ASIA	2001	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(GEN)		X	X	X	X	X	
KIA	ASIA	2001	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(EURO)		X	X	X	X	X	
KIA	ASIA	2001	CARNIVAL(GQ)		D 2.9 TCI-J3	Airbag Control(GEN)		X	X	X	X		
KIA	ASIA	2001	CARNIVAL(GQ)		D 2.9 TCI-J3	Airbag Control(EURO)		X	X	X	X		
KIA	ASIA	2001	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer							
KIA	ASIA	2000	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(GEN)			X	X	X	X	
KIA	ASIA	2000	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(EURO)			X	X	X	X	
KIA	ASIA	2000	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle(GEN)		X	X	X	X	X	
KIA	ASIA	2000	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle(EURO)		X	X	X	X	X	
KIA	ASIA	2000	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake(GEN)		X	X	X	X	X	
KIA	ASIA	2000	CARNIVAL(GQ)		G 2.5 DOHC	Anti-Lock Brake(EURO)		X	X	X	X	X	
KIA	ASIA	2000	CARNIVAL(GQ)		G 2.5 DOHC	Airbag Control(GEN)		X	X	X	X		
KIA	ASIA	2000	CARNIVAL(GQ)		G 2.5 DOHC	Airbag Control(EURO)		X	X	X	X		
KIA	ASIA	2000	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer							
KIA	ASIA	2000	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle(GEN)			X	X	X		
KIA	ASIA	2000	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle(EURO)			X	X	X		
KIA	ASIA	2000	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(GEN)		X	X	X	X	X	
KIA	ASIA	2000	CARNIVAL(GQ)		D 2.9 TCI-J3	Anti-Lock Brake(EURO)		X	X	X	X	X	
KIA	ASIA	2000	CARNIVAL(GQ)		D 2.9 TCI-J3	Airbag Control(GEN)		X	X	X	X		
KIA	ASIA	2000	CARNIVAL(GQ)		D 2.9 TCI-J3	Airbag Control(EURO)		X	X	X	X		
KIA	ASIA	2000	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer							
KIA	ASIA	1999	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(GEN)			X	X	X	X	
KIA	ASIA	1999	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(EURO)			X	X	X	X	
KIA	ASIA	1999	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle(GEN)		X	X	X	X	X	
KIA	ASIA	1999	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle(EURO)		X	X	X	X	X	
KIA	ASIA	1999	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer							
KIA	ASIA	1999	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle(GEN)			X	X	X		
KIA	ASIA	1999	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle(EURO)			X	X	X		
KIA	ASIA	1999	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer							
KIA	ASIA	1998	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(GEN)			X	X	X	X	
KIA	ASIA	1998	CARNIVAL(GQ)		G 2.5 DOHC	Engine Control(EURO)			X	X	X	X	
KIA	ASIA	1998	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle(GEN)		X	X	X	X	X	
KIA	ASIA	1998	CARNIVAL(GQ)		G 2.5 DOHC	Automatic Transaxle(EURO)		X	X	X	X	X	
KIA	ASIA	1998	CARNIVAL(GQ)		G 2.5 DOHC	Immobilizer							
KIA	ASIA	1998	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle(GEN)			X	X	X		
KIA	ASIA	1998	CARNIVAL(GQ)		D 2.9 TCI-J3	Automatic Transaxle(EURO)			X	X	X		
KIA	ASIA	1998	CARNIVAL(GQ)		D 2.9 TCI-J3	Immobilizer							
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Automatic Transaxle (4-Shift)		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Automatic Transaxle (6-Shift)		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Airbag Control(Event #2)		X	X	X	X		

KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Electronic Power		X	X	X	X		
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Power Steering		X	X	X	X		
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Body Control Module(KOUP)		X			X	X	
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Body Control Module(5DR)		X			X	X	
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Automatic Transaxle (4-Shift)		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Automatic Transaxle (6-Shift)		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Electronic Power		X	X	X	X		
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Power Steering		X	X	X	X		
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Body Control Module(KOUP)		X			X	X	
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Body Control Module(5DR)		X			X	X	
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2011	FORTE(TD)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Electronic Power		X	X	X	X		
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Power Steering		X	X	X	X		
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Body Control Module(KOUP)		X			X	X	
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Leaded All		X	X	X	X	X	

KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Electronic Power		X	X	X	X		
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Power Steering		X	X	X	X		
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Body Control Module(KOUP)		X			X	X	
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2010	FORTE(TD)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Power Steering		X	X	X	X		
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2009	FORTE(TD)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	SORENTO(BL)		G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.8 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.8 DOHC	Airbag Control		X	X	X	X		

KIA	ASIA	2009	SORENTO(BL)		G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.8 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	SORENTO(BL)		G 3.8 DOHC	4WD Control		X	X	X			
KIA	ASIA	2009	SORENTO(BL)		G 3.8 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2009	SORENTO(BL)		G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	SORENTO(BL)		G 3.3 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.3 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.3 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.3 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.3 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.3 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	SORENTO(BL)		G 3.3 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.3 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	SORENTO(BL)		G 3.3 DOHC	4WD Control		X	X	X			
KIA	ASIA	2009	SORENTO(BL)		G 3.3 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	SORENTO(BL)		G 3.3 DOHC	Immobilizer					X		
KIA	ASIA	2009	SORENTO(BL)		G 3.3 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	SORENTO(BL)		D 2.5 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		D 2.5 WGT	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2009	SORENTO(BL)		D 2.5 WGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		D 2.5 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2009	SORENTO(BL)		D 2.5 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		D 2.5 WGT	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	SORENTO(BL)		D 2.5 WGT	4WD Control		X	X	X			
KIA	ASIA	2009	SORENTO(BL)		D 2.5 WGT	Body Control Module		X			X	X	
KIA	ASIA	2009	SORENTO(BL)		D 2.5 WGT	Immobilizer					X		
KIA	ASIA	2009	SORENTO(BL)		D 2.5 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		D 2.5 WGT	Transmitter Code Saving					X		
KIA	ASIA	2009	SORENTO(BL)		D 2.5 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		D 2.5 VGT	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2009	SORENTO(BL)		D 2.5 VGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		D 2.5 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2009	SORENTO(BL)		D 2.5 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		D 2.5 VGT	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	SORENTO(BL)		D 2.5 VGT	4WD Control		X	X	X			
KIA	ASIA	2009	SORENTO(BL)		D 2.5 VGT	Body Control Module		X			X	X	
KIA	ASIA	2009	SORENTO(BL)		D 2.5 VGT	Immobilizer					X		
KIA	ASIA	2009	SORENTO(BL)		D 2.5 VGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2009	SORENTO(BL)		D 2.5 VGT	Transmitter Code Saving					X		
KIA	ASIA	2008	SORENTO(BL)		G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.8 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	SORENTO(BL)		G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.8 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	SORENTO(BL)		G 3.8 DOHC	4WD Control		X	X	X			
KIA	ASIA	2008	SORENTO(BL)		G 3.8 DOHC	Body Control Module		X			X	X	

KIA	ASIA	2008	SORENTO(BL)		G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2008	SORENTO(BL)		G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	SORENTO(BL)		G 3.3 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.3 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.3 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.3 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.3 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.3 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	SORENTO(BL)		G 3.3 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.3 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	SORENTO(BL)		G 3.3 DOHC	4WD Control		X	X	X			
KIA	ASIA	2008	SORENTO(BL)		G 3.3 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2008	SORENTO(BL)		G 3.3 DOHC	Immobilizer					X		
KIA	ASIA	2008	SORENTO(BL)		G 3.3 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	SORENTO(BL)		D 2.5 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		D 2.5 WGT	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2008	SORENTO(BL)		D 2.5 WGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		D 2.5 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2008	SORENTO(BL)		D 2.5 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		D 2.5 WGT	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	SORENTO(BL)		D 2.5 WGT	4WD Control		X	X	X			
KIA	ASIA	2008	SORENTO(BL)		D 2.5 WGT	Body Control Module		X			X	X	
KIA	ASIA	2008	SORENTO(BL)		D 2.5 WGT	Immobilizer					X		
KIA	ASIA	2008	SORENTO(BL)		D 2.5 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		D 2.5 WGT	Transmitter Code Saving					X		
KIA	ASIA	2008	SORENTO(BL)		D 2.5 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		D 2.5 VGT	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2008	SORENTO(BL)		D 2.5 VGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		D 2.5 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2008	SORENTO(BL)		D 2.5 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		D 2.5 VGT	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	SORENTO(BL)		D 2.5 VGT	4WD Control		X	X	X			
KIA	ASIA	2008	SORENTO(BL)		D 2.5 VGT	Body Control Module		X			X	X	
KIA	ASIA	2008	SORENTO(BL)		D 2.5 VGT	Immobilizer					X		
KIA	ASIA	2008	SORENTO(BL)		D 2.5 VGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2008	SORENTO(BL)		D 2.5 VGT	Transmitter Code Saving					X		
KIA	ASIA	2007	SORENTO(BL)		G 3.3 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.3 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.3 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.3 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.3 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.3 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	SORENTO(BL)		G 3.3 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.3 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	SORENTO(BL)		G 3.3 DOHC	4WD Control		X	X	X			
KIA	ASIA	2007	SORENTO(BL)		G 3.3 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.3 DOHC	Immobilizer					X		
KIA	ASIA	2007	SORENTO(BL)		G 3.3 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	SORENTO(BL)		G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	

KIA	ASIA	2007	SORENTO(BL)		G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.8 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	SORENTO(BL)		G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.8 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	SORENTO(BL)		G 3.8 DOHC	4WD Control		X	X	X			
KIA	ASIA	2007	SORENTO(BL)		G 3.8 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2007	SORENTO(BL)		G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2007	SORENTO(BL)		G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	SORENTO(BL)		D 2.5 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		D 2.5 WGT	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2007	SORENTO(BL)		D 2.5 WGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		D 2.5 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2007	SORENTO(BL)		D 2.5 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		D 2.5 WGT	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	SORENTO(BL)		D 2.5 WGT	4WD Control		X	X	X			
KIA	ASIA	2007	SORENTO(BL)		D 2.5 WGT	Body Control Module		X			X	X	
KIA	ASIA	2007	SORENTO(BL)		D 2.5 WGT	Immobilizer					X		
KIA	ASIA	2007	SORENTO(BL)		D 2.5 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		D 2.5 WGT	Transmitter Code Saving					X		
KIA	ASIA	2007	SORENTO(BL)		D 2.5 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		D 2.5 VGT	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2007	SORENTO(BL)		D 2.5 VGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		D 2.5 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2007	SORENTO(BL)		D 2.5 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		D 2.5 VGT	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	SORENTO(BL)		D 2.5 VGT	4WD Control		X	X	X			
KIA	ASIA	2007	SORENTO(BL)		D 2.5 VGT	Body Control Module		X			X	X	
KIA	ASIA	2007	SORENTO(BL)		D 2.5 VGT	Immobilizer					X		
KIA	ASIA	2007	SORENTO(BL)		D 2.5 VGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2007	SORENTO(BL)		D 2.5 VGT	Transmitter Code Saving					X		
KIA	ASIA	2006	SORENTO(BL)		G 2.4 DOHC	UnLeaded All		X	X	X	X	X	
KIA	ASIA	2006	SORENTO(BL)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	SORENTO(BL)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2006	SORENTO(BL)		G 2.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	SORENTO(BL)		G 2.4 DOHC	Airbag Control		*	*	*	*		
KIA	ASIA	2006	SORENTO(BL)		G 2.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2006	SORENTO(BL)		G 2.4 DOHC	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2006	SORENTO(BL)		G 3.5 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	SORENTO(BL)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2006	SORENTO(BL)		G 3.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	SORENTO(BL)		G 3.5 DOHC	Airbag Control		*	*	*	*		
KIA	ASIA	2006	SORENTO(BL)		G 3.5 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2006	SORENTO(BL)		G 3.5 DOHC	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2006	SORENTO(BL)		D 2.5 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	SORENTO(BL)		D 2.5 WGT	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2006	SORENTO(BL)		D 2.5 WGT	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	SORENTO(BL)		D 2.5 WGT	Airbag Control		*	*	*	*		
KIA	ASIA	2006	SORENTO(BL)		D 2.5 WGT	Electronic Power Steering		X	X	X	X		

KIA	ASIA	2006	SORENTO(BL)		D 2.5 WGT	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2006	SORENTO(BL)		D 2.5 WGT	Immobilizer					X		
KIA	ASIA	2006	SORENTO(BL)		D 2.5 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2006	SORENTO(BL)		D 2.5 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	SORENTO(BL)		D 2.5 VGT	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2006	SORENTO(BL)		D 2.5 VGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2006	SORENTO(BL)		D 2.5 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2006	SORENTO(BL)		D 2.5 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	SORENTO(BL)		D 2.5 VGT	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2006	SORENTO(BL)		D 2.5 VGT	4WD Control		X	X	X			
KIA	ASIA	2006	SORENTO(BL)		D 2.5 VGT	Body Control Module		X			X	X	
KIA	ASIA	2006	SORENTO(BL)		D 2.5 VGT	Immobilizer					X		
KIA	ASIA	2006	SORENTO(BL)		D 2.5 VGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2006	SORENTO(BL)		D 2.5 VGT	Transmitter Code Saving					X		
KIA	ASIA	2005	SORENTO(BL)		G 2.4 DOHC	UnLeaded All		X	X	X	X	X	
KIA	ASIA	2005	SORENTO(BL)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2005	SORENTO(BL)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2005	SORENTO(BL)		G 2.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	SORENTO(BL)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	SORENTO(BL)		G 2.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2005	SORENTO(BL)		G 2.4 DOHC	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2005	SORENTO(BL)		G 3.5 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	SORENTO(BL)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2005	SORENTO(BL)		G 3.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	SORENTO(BL)		G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	SORENTO(BL)		G 3.5 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2005	SORENTO(BL)		G 3.5 DOHC	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2005	SORENTO(BL)		D 2.5 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	SORENTO(BL)		D 2.5 WGT	Automatic Transaxle		X	X	X	X		
KIA	ASIA	2005	SORENTO(BL)		D 2.5 WGT	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	SORENTO(BL)		D 2.5 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2005	SORENTO(BL)		D 2.5 WGT	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2005	SORENTO(BL)		D 2.5 WGT	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2005	SORENTO(BL)		D 2.5 WGT	Immobilizer					X		
KIA	ASIA	2005	SORENTO(BL)		D 2.5 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2004	SORENTO(BL)		G 2.4 DOHC	UnLeaded All		X	X	X	X	X	
KIA	ASIA	2004	SORENTO(BL)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2004	SORENTO(BL)		G 2.4 DOHC	Automatic Transaxle (4-Shift)		X	X	X	X	X	
KIA	ASIA	2004	SORENTO(BL)		G 2.4 DOHC	Automatic Transaxle(5-Shift)		X	X	X	X		
KIA	ASIA	2004	SORENTO(BL)		G 2.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	SORENTO(BL)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	SORENTO(BL)		G 2.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2004	SORENTO(BL)		G 2.4 DOHC	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2004	SORENTO(BL)		G 3.5 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2004	SORENTO(BL)		G 3.5 DOHC	Automatic Transaxle (4-Shift)		X	X	X	X	X	
KIA	ASIA	2004	SORENTO(BL)		G 3.5 DOHC	Automatic Transaxle(5-Shift)		X	X	X	X		
KIA	ASIA	2004	SORENTO(BL)		G 3.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	SORENTO(BL)		G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	SORENTO(BL)		G 3.5 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2004	SORENTO(BL)		G 3.5 DOHC	4WD Control(TOD-AT)			X	X			

KIA	ASIA	2004	SORENTO(BL)		D 2.5 WGT	Engine Control(WGT F/L)		X	X	X	X	X	
KIA	ASIA	2004	SORENTO(BL)		D 2.5 WGT	Engine Control(WGT)		X	X	X	X	X	
KIA	ASIA	2004	SORENTO(BL)		D 2.5 WGT	Automatic Transaxle (4-Shift)		X	X	X	X	X	
KIA	ASIA	2004	SORENTO(BL)		D 2.5 WGT	Automatic Transaxle(5-Shift)		X	X	X	X		
KIA	ASIA	2004	SORENTO(BL)		D 2.5 WGT	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2004	SORENTO(BL)		D 2.5 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2004	SORENTO(BL)		D 2.5 WGT	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2004	SORENTO(BL)		D 2.5 WGT	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2004	SORENTO(BL)		D 2.5 WGT	Immobilizer					X		
KIA	ASIA	2004	SORENTO(BL)		D 2.5 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2003	SORENTO(BL)		G 2.4 DOHC	UnLeaded All		X	X	X	X	X	
KIA	ASIA	2003	SORENTO(BL)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2003	SORENTO(BL)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	SORENTO(BL)		G 2.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	SORENTO(BL)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	SORENTO(BL)		G 2.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2003	SORENTO(BL)		G 2.4 DOHC	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2003	SORENTO(BL)		G 3.5 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2003	SORENTO(BL)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	SORENTO(BL)		G 3.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	SORENTO(BL)		G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2003	SORENTO(BL)		G 3.5 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2003	SORENTO(BL)		G 3.5 DOHC	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2003	SORENTO(BL)		D 2.5 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2003	SORENTO(BL)		D 2.5 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2003	SORENTO(BL)		D 2.5 WGT	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2003	SORENTO(BL)		D 2.5 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2003	SORENTO(BL)		D 2.5 WGT	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2003	SORENTO(BL)		D 2.5 WGT	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2003	SORENTO(BL)		D 2.5 WGT	Immobilizer					X		
KIA	ASIA	2003	SORENTO(BL)		D 2.5 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2002	SORENTO(BL)		G 3.5 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2002	SORENTO(BL)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2002	SORENTO(BL)		G 3.5 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2002	SORENTO(BL)		G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2002	SORENTO(BL)		G 3.5 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2002	SORENTO(BL)		G 3.5 DOHC	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2002	SORENTO(BL)		D 2.5 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2002	SORENTO(BL)		D 2.5 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2002	SORENTO(BL)		D 2.5 WGT	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2002	SORENTO(BL)		D 2.5 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2002	SORENTO(BL)		D 2.5 WGT	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2002	SORENTO(BL)		D 2.5 WGT	4WD Control(TOD-AT)			X	X			
KIA	ASIA	2002	SORENTO(BL)		D 2.5 WGT	Immobilizer					X		
KIA	ASIA	2002	SORENTO(BL)		D 2.5 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	

KIA	ASIA	2012	NEW CARENS(UN)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2012	NEW CARENS(UN)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2012	NEW CARENS(UN)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2012	NEW CARENS(UN)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2012	NEW CARENS(UN)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2012	NEW CARENS(UN)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2012	NEW CARENS(UN)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2012	NEW CARENS(UN)		D 1.6 TCI-U2	Engine Control		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		D 1.6 TCI-U2	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		D 1.6 TCI-U2	Airbag Control		X	X	X	X		
KIA	ASIA	2012	NEW CARENS(UN)		D 1.6 TCI-U2	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		D 1.6 TCI-U2	Body Control Module		X			X	X	
KIA	ASIA	2012	NEW CARENS(UN)		D 1.6 TCI-U2	Immobilizer					X		
KIA	ASIA	2012	NEW CARENS(UN)		D 1.6 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2012	NEW CARENS(UN)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		D 2.0 TCI-D	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2012	NEW CARENS(UN)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	NEW CARENS(UN)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2012	NEW CARENS(UN)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2012	NEW CARENS(UN)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2011	NEW CARENS(UN)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2011	NEW CARENS(UN)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2011	NEW CARENS(UN)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	NEW CARENS(UN)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2011	NEW CARENS(UN)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2011	NEW CARENS(UN)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2011	NEW CARENS(UN)		G 1.6 DOHC	Transmitter Code Saving					X		

KIA	ASIA	2011	NEW CARENS(UN)		D 1.6 TCI-U2	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		D 1.6 TCI-U2	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		D 1.6 TCI-U2	Airbag Control		X	X	X	X		
KIA	ASIA	2011	NEW CARENS(UN)		D 1.6 TCI-U2	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		D 1.6 TCI-U2	Body Control Module		X			X	X	
KIA	ASIA	2011	NEW CARENS(UN)		D 1.6 TCI-U2	Immobilizer					X		
KIA	ASIA	2011	NEW CARENS(UN)		D 1.6 TCI-U2	Transmitter Code Saving					X		
KIA	ASIA	2011	NEW CARENS(UN)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		D 2.0 TCI-D	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2011	NEW CARENS(UN)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	NEW CARENS(UN)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2011	NEW CARENS(UN)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2011	NEW CARENS(UN)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2010	NEW CARENS(UN)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	NEW CARENS(UN)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2010	NEW CARENS(UN)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	NEW CARENS(UN)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	NEW CARENS(UN)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2010	NEW CARENS(UN)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2010	NEW CARENS(UN)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	NEW CARENS(UN)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		D 2.0 TCI-D	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2010	NEW CARENS(UN)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	NEW CARENS(UN)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2010	NEW CARENS(UN)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2010	NEW CARENS(UN)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2009	NEW CARENS(UN)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	NEW CARENS(UN)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	

KIA	ASIA	2009	NEW CARENS(UN)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2009	NEW CARENS(UN)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	NEW CARENS(UN)		G 1.6 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 1.6 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 1.6 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 1.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 1.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 1.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	NEW CARENS(UN)		G 1.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 1.6 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2009	NEW CARENS(UN)		G 1.6 DOHC	Immobilizer					X		
KIA	ASIA	2009	NEW CARENS(UN)		G 1.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	NEW CARENS(UN)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		D 2.0 TCI-D	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2009	NEW CARENS(UN)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	NEW CARENS(UN)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2009	NEW CARENS(UN)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2009	NEW CARENS(UN)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2008	NEW CARENS(UN)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.0 DOHC	Leaded		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.0 DOHC	ABS/ESP(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.0 DOHC	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	NEW CARENS(UN)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2008	NEW CARENS(UN)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	NEW CARENS(UN)		G 2.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.4 DOHC	ABS/ESP(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.4 DOHC	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	NEW CARENS(UN)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2008	NEW CARENS(UN)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2008	NEW CARENS(UN)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	NEW CARENS(UN)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		D 2.0 TCI-D	ABS/ESP(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		D 2.0 TCI-D	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2008	NEW CARENS(UN)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	NEW CARENS(UN)		D 2.0 TCI-D	Body Control Module		X			X	X	

KIA	ASIA	2008	NEW CARENS(UN)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2008	NEW CARENS(UN)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2007	NEW CARENS(UN)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	NEW CARENS(UN)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.0 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2007	NEW CARENS(UN)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	NEW CARENS(UN)		G 2.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.4 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.4 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	NEW CARENS(UN)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.4 DOHC	Body Control Module		X			X	X	
KIA	ASIA	2007	NEW CARENS(UN)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2007	NEW CARENS(UN)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	NEW CARENS(UN)		D 2.0 TCI-D	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		D 2.0 TCI-D	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		D 2.0 TCI-D	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		D 2.0 TCI-D	Airbag Control		X	X	X	X		
KIA	ASIA	2007	NEW CARENS(UN)		D 2.0 TCI-D	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	NEW CARENS(UN)		D 2.0 TCI-D	Body Control Module		X			X	X	
KIA	ASIA	2007	NEW CARENS(UN)		D 2.0 TCI-D	Immobilizer					X		
KIA	ASIA	2007	NEW CARENS(UN)		D 2.0 TCI-D	Transmitter Code Saving					X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Anti-Lock Brake(MEB-2)		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Electronic Stability		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Unleaded GEN		X	X	X	X	X	

KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Anti-Lock Brake(MEB-2)		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Electronic Stability		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Immobilizer					X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		G 3.5 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Anti-Lock Brake(MEB-2)		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Electronic Stability		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Front Area Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Rear Area Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Driver Door Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Assist Door Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Integrated Memory System			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Immobilizer					X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.9 VGT	Transmitter Code Saving					X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Anti-Lock Brake(MEB-2)		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Electronic Stability		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Airbag Control		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Instrument Panel Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Front Area Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Rear Area Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Driver Door Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Assist Door Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Integrated Memory System			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Immobilizer					X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)		D 2.2 TCI-R	Power Sliding Door-LH		X	X	X	X		

KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Power Tail Gate		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Transmitter Code Saving					X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Anti-Lock Brake(MEB-2)		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Electronic Stability		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Front Area Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Rear Area Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Driver Door Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Assist Door Module			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Integrated Memory System			X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Immobilizer					X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2012	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Transmitter Code Saving					X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Anti-Lock Brake(MEB-2)		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Electronic Stability		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Anti-Lock Brake(MEB-2)		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Electronic Stability		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Rear Area Module			X	X	X		

KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Immobilizer					X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	G 3.5 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Anti-Lock Brake(MEB-2)		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Electronic Stability		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Front Area Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Rear Area Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Driver Door Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Assist Door Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Integrated Memory System			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Immobilizer					X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Transmitter Code Saving					X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Anti-Lock Brake(MEB-2)		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Electronic Stability		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Airbag Control		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Instrument Panel Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Front Area Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Rear Area Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Driver Door Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Assist Door Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Integrated Memory System			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Immobilizer					X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Power Tail Gate		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Transmitter Code Saving					X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Anti-Lock Brake(MEB-2)		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Electronic Stability		X	X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Air Conditioner		X	X	X	X	X	

KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Front Area Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Rear Area Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Driver Door Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Assist Door Module			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Integrated Memory System			X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Immobilizer					X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2011	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Transmitter Code Saving					X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Anti-Lock Brake(MEB-2)		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Electronic Stability		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	ABS(MEB-2)		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	ESP(MEB-2)		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Transmitter Code Saving					X		

KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	ABS(MEB-2)		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	ESP(MEB-2)		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Air Conditioner		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Front Area Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Rear Area Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Driver Door Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Assist Door Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Integrated Memory System			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Immobilizer					X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Transmitter Code Saving					X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	ABS(MEB-2)		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	ESP(MEB-2)		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Airbag Control		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Instrument Panel Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Front Area Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Rear Area Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Driver Door Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Assist Door Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Integrated Memory System			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Immobilizer					X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Power Tail Gate		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.2 TCI-R	Transmitter Code Saving					X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	ABS(MEB-2)		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	ESP(MEB-2)		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Front Area Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Rear Area Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Driver Door Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Assist Door Module			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Integrated Memory System			X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Immobilizer					X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-LH		X	X	X	X		

KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2010	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Transmitter Code Saving					X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Front Area Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Rear Area Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Driver Door Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Assist Door Module			X	X	X		

KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Integrated Memory System			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Immobilizer					X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Transmitter Code Saving					X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Front Area Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Rear Area Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Driver Door Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Assist Door Module			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Integrated Memory System			X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Immobilizer					X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2009	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Transmitter Code Saving					X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Instrument Panel Module			X	X	X		

KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Front Area Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Rear Area Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Driver Door Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Assist Door Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Integrated Memory System			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Immobilizer					X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Transmitter Code Saving					X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Front Area Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Rear Area Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Driver Door Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Assist Door Module			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Integrated Memory System			X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Immobilizer					X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2008	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Transmitter Code Saving					X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Airbag Control		X	X	X	X		

KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Front Area Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Rear Area Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Driver Door Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Assist Door Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Integrated Memory System			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Immobilizer					X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Transmitter Code Saving					X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	ABS/ESP		X	X	X	X	X	

KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Front Area Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Rear Area Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Driver Door Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Assist Door Module			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Integrated Memory System			X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Immobilizer					X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2007	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Transmitter Code Saving					X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Instrument Panel Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Front Area Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Rear Area Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Driver Door Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Assist Door Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Power Tail Gate		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	G 2.7 DOHC	Transmitter Code Saving					X		

KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Front Area Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Rear Area Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Driver Door Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Assist Door Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Integrated Memory System			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Immobilizer					X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 VGT	Transmitter Code Saving					X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	ABS/ESP		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Instrument Panel Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Front Area Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Rear Area Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Driver Door Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Assist Door Module			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Integrated Memory System			X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Immobilizer					X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-LH		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Sliding Door-RH		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Power Tail Gate		X	X	X	X		
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Fuel Fired Heater			X	X	X	X	
KIA	ASIA	2006	CARNIVAL/SEDONA(VQ)	D 2.9 WGT	Transmitter Code Saving					X		
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Immobilizer					X		
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Power Distribution Module						X	
KIA	ASIA	2012	NEW SORENTO(XM)	G 3.5 DOHC	Automatic Headlamp Leveling		X	X	X	X	X	

KIA	ASIA	2012	NEW SORENTO(XM)		G 3.5 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		G 3.5 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Power Distribution Module						X	
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	4WD Control		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Immobilizer					X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Smart Key Unit		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Smart Key Code Saving					X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Power Distribution Module						X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.2 TCI-R	Transmitter Code Saving					X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Airbag(Event #2)		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Airbag(Event #1)		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Power Steering		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	4WD Control		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Immobilizer					X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Smart Key Unit		X	X	X	X		
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Smart Key Code Saving					X		

KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Power Distribution Module						X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2012	NEW SORENTO(XM)		D 2.0 TCI-R	Transmitter Code Saving					X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Immobilizer					X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Power Distribution Module						X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 3.5 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Power Distribution Module						X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	4WD Control		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Instrument Panel Module		X	X	X	X	X	

KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Immobilizer					X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Smart Key Unit		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Smart Key Code Saving					X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Power Distribution Module						X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.2 TCI-R	Transmitter Code Saving					X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Airbag(Event #2)		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Airbag(Event #1)		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Power Steering		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	4WD Control		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Immobilizer					X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Smart Key Unit		X	X	X	X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Smart Key Code Saving					X		
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Power Distribution Module						X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2011	NEW SORENTO(XM)		D 2.0 TCI-R	Transmitter Code Saving					X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Power Distribution Module						X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Air Conditioner		X	X	X	X	X	

KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Immobilizer					X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Power Distribution Module						X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		G 3.5 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	4WD Control		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Immobilizer					X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Smart Key Unit		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Smart Key Code Saving					X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Power Distribution Module						X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.2 TCI-R	Transmitter Code Saving					X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Airbag(Event #2)		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Airbag(Event #1)		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Power Steering		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	4WD Control		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Immobilizer					X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Smart Key Unit		X	X	X	X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Smart Key Code Saving					X		
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Power Distribution Module						X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2010	NEW SORENTO(XM)		D 2.0 TCI-R	Transmitter Code Saving					X		
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Airbag Control(Event #1)		X	X	X	X		

KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Power Distribution Module						X	
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Engine Control(CPF-)		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Engine Control(CPF+)		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	4WD Control		X	X	X	X		
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Immobilizer					X		
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Smart Key Unit		X	X	X	X		
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Smart Key Code Saving					X		
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Power Distribution Module						X	
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Tire Pressure Monitoring		X	X	X	X	X	
KIA	ASIA	2009	NEW SORENTO(XM)		D 2.2 TCI-R	Transmitter Code Saving					X		
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	UnLeaded All		*	*	*	*	*	
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Leaded All		*	*	*	*	*	
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Electric Parking Brake		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Driver Door Module		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Assist Door Module		X	X	X	X		
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Steering Column Module							
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Power Seat Module		X	X	X	X		
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Lane Departure Warning		X	X	X	X		

KIA	ASIA	2012	CADENZA(VG)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	UnLeaded All		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Electric Parking Brake		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Driver Door Module		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Assist Door Module		X	X	X	X		
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Steering Column Module							
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Power Seat Module		X	X	X	X		
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Immobilizer					X		
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Lane Departure Warning		X	X	X	X		
KIA	ASIA	2012	CADENZA(VG)		G 3.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Unleaded		X	X	X	X	X	
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Leaded		X	X	X	X	X	
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Airbag Control(Event #1)		X	X	X	X		
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Airbag Control(Event #2)		X	X	X	X		
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Driver Door Module		X	X	X	X	X	
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Assist Door Module		X	X	X	X		
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Instrument Panel Module		X	X	X	X	X	
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Steering Coulmn Module							
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Cluster Module		X	X	X	X	X	
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Power Seat Module		X	X	X	X		
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Immobilizer					X		
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Smart Key Unit		X	X	X	X	X	
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Power Distribution Module		X	X	X	X	X	
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Automatic Headlamp Leveling		X	X	X	X	X	
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	LDWS		X	X	X	X		
KIA	ASIA	2011	CADENZA(VG)		G 2.4 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Electronic Power Steering		X	X	X	X		

KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	4WD Control(EST)		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	4WD Control(TOD)		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Instrument Panel Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Front Area Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Rear Area Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Driver Door Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Assist Door Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	User Option					X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Steering Column Module			X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Immobilizer					X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Power Distribution Module						X	
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 4.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	4WD Control(EST)		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	4WD Control(TOD)		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Instrument Panel		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Instrument Panel		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Front Area Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Rear Area Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Driver Door Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Assist Door Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	User Option					X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Steering Column Module			X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Power Distribution Module						X	
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Airbag Control		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Electronic Control Suspension		X	X	X	X	X	

KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	4WD Control(EST)		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	4WD Control(TOD)		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Instrument Panel Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Front Area Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Rear Area Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Driver Door Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Assist Door Module		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Integrated Memory System			X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	User Option					X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Steering Column Module			X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Immobilizer					X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Smart Key Unit		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Smart Key Code Saving					X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Power Distribution Module						X	
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2010	BORREGO(HM)		D 3.0 TCI-S	Transmitter Code Saving					X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	4WD Control(EST)		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	4WD Control(TOD)		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Instrument Panel Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Front Area Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Rear Area Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Driver Door Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Assist Door Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	User Option					X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Steering Column Module			X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Immobilizer					X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Power Distribution Module						X	
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 4.6 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	4WD Control(EST)		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	4WD Control(TOD)		X	X	X	X		

KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Instrument Panel		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Instrument Panel		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Front Area Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Rear Area Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Driver Door Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Assist Door Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Integrated Memory System			X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	User Option					X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Steering Column Module			X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Power Distribution Module						X	
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Airbag Control		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	4WD Control(EST)		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	4WD Control(TOD)		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Instrument Panel Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Front Area Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Rear Area Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Driver Door Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Assist Door Module		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Integrated Memory System			X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	User Option					X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Steering Column Module			X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Immobilizer					X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Smart Key Unit		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Smart Key Code Saving					X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Power Distribution Module						X	
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2009	BORREGO(HM)		D 3.0 TCI-S	Transmitter Code Saving					X		
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Power Window Assistance			X	X	X	X	

KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Power Distribution Module						X	
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2010	OPIRUS(GH)		G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Power Distribution Module						X	
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2010	OPIRUS(GH)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Power Distribution Module						X	
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2009	OPIRUS(GH)		G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	

KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Smart Key Unit		X	X	X	X		
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Power Distribution Module						X	
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2009	OPIRUS(GH)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Interface Unit		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2008	OPIRUS(GH)		G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Power Window Assistance			X	X	X	X	

KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Interface Unit		X	X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2008	OPIRUS(GH)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Leaded		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Immobilizer					X		
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Interface Unit		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2007	OPIRUS(GH)		G 3.8 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Electronic Power Steering		X	X	X	X		
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Interface Unit		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2007	OPIRUS(GH)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Automatic Transaxle		X	X	X	X	X	

KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Electronic Power Steering							
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Immobilizer					X		
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2006	OPIRUS(GH)		G 3.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Electronic Power Steering							
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Immobilizer					X		
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2006	OPIRUS(GH)		G 3.5 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Electronic Power Steering							
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2006	OPIRUS(GH)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Engine Control		X	X	X	X	X	

KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Electronic Power Steering							
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Immobilizer					X		
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2005	OPIRUS(GH)		G 3.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Electronic Power Steering							
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Immobilizer					X		
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2005	OPIRUS(GH)		G 3.5 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Electronic Power Steering							
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2005	OPIRUS(GH)		G 2.7 DOHC	Transmitter Code Saving					X		

KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Electronic Power Steering							
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Immobilizer					X		
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2004	OPIRUS(GH)		G 3.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Electronic Power Steering							
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Immobilizer					X		
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Automatic Headlamp Leveling		X	X	X	X		
KIA	ASIA	2004	OPIRUS(GH)		G 3.5 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Engine Control		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Electronic Power Steering							
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Electronic Control Suspension		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Body Control Module		X	X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Power Window Main			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Power Window Assistance			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Tilt & Telescope			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Power Seat Module			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Immobilizer					X		
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Smart Key Unit			X	X	X	X	
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Smart Key Code Saving					X		
KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Automatic Headlamp Leveling		X	X	X	X		

KIA	ASIA	2004	OPIRUS(GH)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	SPORTAGE(KM)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	SPORTAGE(KM)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.0 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2010	SPORTAGE(KM)		G 2.0 DOHC	ETACS		X			X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2010	SPORTAGE(KM)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	SPORTAGE(KM)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.7 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2010	SPORTAGE(KM)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.7 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2010	SPORTAGE(KM)		G 2.7 DOHC	ETACS		X			X	X	
KIA	ASIA	2010	SPORTAGE(KM)		G 2.7 DOHC	Immobilizer			X	X	X		
KIA	ASIA	2010	SPORTAGE(KM)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 WGT	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 WGT	4WD Control		X	X	X	X		
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 WGT	ETACS		X			X	X	
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 WGT	Immobilizer					X		
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 WGT	Transmitter Code Saving					X		
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 VGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 VGT	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 VGT	4WD Control		X	X	X	X		
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 VGT	ETACS		X			X	X	
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 VGT	Immobilizer					X		
KIA	ASIA	2010	SPORTAGE(KM)		D 2.0 VGT	Transmitter Code Saving					X		
KIA	ASIA	2009	SPORTAGE(KM)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.0 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	SPORTAGE(KM)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.0 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2009	SPORTAGE(KM)		G 2.0 DOHC	ETACS		X			X	X	

KIA	ASIA	2009	SPORTAGE(KM)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2009	SPORTAGE(KM)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	SPORTAGE(KM)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.7 DOHC	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2009	SPORTAGE(KM)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.7 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2009	SPORTAGE(KM)		G 2.7 DOHC	ETACS		X			X	X	
KIA	ASIA	2009	SPORTAGE(KM)		G 2.7 DOHC	Immobilizer			X	X	X		
KIA	ASIA	2009	SPORTAGE(KM)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 WGT	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 WGT	4WD Control		X	X	X	X		
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 WGT	ETACS		X			X	X	
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 WGT	Immobilizer					X		
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 WGT	Transmitter Code Saving					X		
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 VGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 VGT	Electronic Stability Program		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 VGT	4WD Control		X	X	X	X		
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 VGT	ETACS		X			X	X	
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 VGT	Immobilizer					X		
KIA	ASIA	2009	SPORTAGE(KM)		D 2.0 VGT	Transmitter Code Saving					X		
KIA	ASIA	2008	SPORTAGE(KM)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.0 DOHC	ABS/ESP(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.0 DOHC	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2008	SPORTAGE(KM)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.0 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2008	SPORTAGE(KM)		G 2.0 DOHC	ETACS		X			X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2008	SPORTAGE(KM)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	SPORTAGE(KM)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.7 DOHC	ABS/ESP(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.7 DOHC	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.7 DOHC	Airbag Control		X	X	X	X		

KIA	ASIA	2008	SPORTAGE(KM)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.7 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2008	SPORTAGE(KM)		G 2.7 DOHC	ETACS		X			X	X	
KIA	ASIA	2008	SPORTAGE(KM)		G 2.7 DOHC	Immobilizer			X	X	X		
KIA	ASIA	2008	SPORTAGE(KM)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 WGT	ABS/ESP(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 WGT	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 WGT	4WD Control		X	X	X	X		
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 WGT	ETACS		X			X	X	
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 WGT	Immobilizer					X		
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 WGT	Transmitter Code Saving					X		
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 VGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 VGT	ABS/ESP(MGH-25)		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 VGT	ABS/ESP(MGH-40)		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 VGT	4WD Control		X	X	X	X		
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 VGT	ETACS		X			X	X	
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 VGT	Immobilizer					X		
KIA	ASIA	2008	SPORTAGE(KM)		D 2.0 VGT	Transmitter Code Saving					X		
KIA	ASIA	2007	SPORTAGE(KM)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	SPORTAGE(KM)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.0 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2007	SPORTAGE(KM)		G 2.0 DOHC	ETACS		X			X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2007	SPORTAGE(KM)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	SPORTAGE(KM)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.7 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2007	SPORTAGE(KM)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.7 DOHC	4WD Control		X	X	X	X		
KIA	ASIA	2007	SPORTAGE(KM)		G 2.7 DOHC	ETACS		X			X	X	
KIA	ASIA	2007	SPORTAGE(KM)		G 2.7 DOHC	Immobilizer			X	X	X		
KIA	ASIA	2007	SPORTAGE(KM)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 WGT	Anti-Lock Brake		X	X	X	X	X	

KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 WGT	4WD Control		X	X	X	X		
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 WGT	ETACS		X			X	X	
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 WGT	Immobilizer					X		
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 WGT	Transmitter Code Saving					X		
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 VGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 VGT	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 VGT	Airbag Control		X	X	X	X		
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 VGT	4WD Control		X	X	X	X		
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 VGT	ETACS		X			X	X	
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 VGT	Immobilizer					X		
KIA	ASIA	2007	SPORTAGE(KM)		D 2.0 VGT	Transmitter Code Saving					X		
KIA	ASIA	2006	SPORTAGE(KM)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	SPORTAGE(KM)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.0 DOHC	4WD Control		X	X	X			
KIA	ASIA	2006	SPORTAGE(KM)		G 2.0 DOHC	ETACS		X			X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2006	SPORTAGE(KM)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2006	SPORTAGE(KM)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.7 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2006	SPORTAGE(KM)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.7 DOHC	4WD Control		X	X	X			
KIA	ASIA	2006	SPORTAGE(KM)		G 2.7 DOHC	ETACS		X			X	X	
KIA	ASIA	2006	SPORTAGE(KM)		G 2.7 DOHC	Immobilizer			X	X	X		
KIA	ASIA	2006	SPORTAGE(KM)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 WGT	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 WGT	4WD Control		X	X	X			
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 WGT	ETACS		X			X	X	
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 WGT	Immobilizer					X		
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 WGT	Transmitter Code Saving					X		
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 VGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 VGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 VGT	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 VGT	Airbag Control		X	X	X	X		

KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 VGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 VGT	4WD Control		X	X	X	X		
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 VGT	ETACS		X			X	X	
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 VGT	Immobilizer					X		
KIA	ASIA	2006	SPORTAGE(KM)		D 2.0 VGT	Transmitter Code Saving					X		
KIA	ASIA	2005	SPORTAGE(KM)		G 2.0 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.0 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.0 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.0 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.0 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.0 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	SPORTAGE(KM)		G 2.0 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.0 DOHC	4WD Control		X	X	X			
KIA	ASIA	2005	SPORTAGE(KM)		G 2.0 DOHC	ETACS		X			X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.0 DOHC	Immobilizer					X		
KIA	ASIA	2005	SPORTAGE(KM)		G 2.0 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2005	SPORTAGE(KM)		G 2.7 DOHC	Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.7 DOHC	Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.7 DOHC	Leaded All		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.7 DOHC	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.7 DOHC	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.7 DOHC	Airbag Control		X	X	X	X		
KIA	ASIA	2005	SPORTAGE(KM)		G 2.7 DOHC	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.7 DOHC	4WD Control		X	X	X			
KIA	ASIA	2005	SPORTAGE(KM)		G 2.7 DOHC	ETACS		X			X	X	
KIA	ASIA	2005	SPORTAGE(KM)		G 2.7 DOHC	Immobilizer			X	X	X		
KIA	ASIA	2005	SPORTAGE(KM)		G 2.7 DOHC	Transmitter Code Saving					X		
KIA	ASIA	2005	SPORTAGE(KM)		D 2.0 WGT	Engine Control		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		D 2.0 WGT	Automatic Transaxle		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		D 2.0 WGT	Anti-Lock Brake		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		D 2.0 WGT	Airbag Control		X	X	X	X		
KIA	ASIA	2005	SPORTAGE(KM)		D 2.0 WGT	Air Conditioner		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE(KM)		D 2.0 WGT	4WD Control		X	X	X			
KIA	ASIA	2005	SPORTAGE(KM)		D 2.0 WGT	ETACS		X			X	X	
KIA	ASIA	2005	SPORTAGE(KM)		D 2.0 WGT	Immobilizer					X		
KIA	ASIA	2005	SPORTAGE(KM)		D 2.0 WGT	Transmitter Code Saving					X		
KIA	ASIA	2006	PRIDE		ENGINE CONTROL			X	X	X	X	X	
KIA	ASIA	2003	PRIDE		ENGINE CONTROL	1.3L SOHC CASOLINE MAP		X	X	Manual	X		
KIA	ASIA	2003	PRIDE		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2002	PRIDE		ENGINE CONTROL	1.3L SOHC CASOLINE MAP		X	X	Manual	X		
KIA	ASIA	2002	PRIDE		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	All Model year	VISTO		ENGINE CONTROL	UNLEAD ALL			X	X	X	X	1.RESETTING ADAPTIVE VALUES
KIA	ASIA	All Model year	VISTO		ENGINE CONTROL	UNLEAD IMMO			X	X	X	X	
KIA	ASIA	All Model year	VISTO		ENGINE CONTROL	LEAD ALL			X	X	X	X	1.RESETTING ADAPTIVE VALUES 2.IDLE CO ADJUSTMENT
KIA	ASIA	All Model year	VISTO		AUTOMATIC TRANSAXLE				X	X	X	X	
KIA	ASIA	All Model year	VISTO		ANTI-LOCK BRAKE SYSTEM				X	X	X	X	1. HCU AIR BLEEDING MODE
KIA	ASIA	All Model year	VISTO		SRS-AIRBAG			X	X	X	X		1. ACTIVE DTC INFORMATION 2. HISTORY DTC INFORMATION

KIA	ASIA	2008	PICANTO(MORNING)		ENGINE CONTROL	1.1L VGT DIESEL CAN		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(MORNING)		ENGINE CONTROL	1.0L/1.1L EOBD		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(MORNING)		ENGINE CONTROL	1.0L/1.1L GEN		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(MORNING)		ENGINE CONTROL	1.0L/1.1L LEAD		X	X	X	X	X	
KIA	ASIA	2008	PICANTO(MORNING)		AUTOMATIC TRANSAXLE			X	X	X	X	X	
KIA	ASIA	2008	PICANTO(MORNING)					X	X	X	X	X	
KIA	ASIA	2008	PICANTO(MORNING)		ABS/ESP								
KIA	ASIA	2008	PICANTO(MORNING)		SRS-AIRBAG			X	X	X			CRASHING INFORMATION
KIA	ASIA	2008	PICANTO(MORNING)		ELEC.POWER STEERING			X	X	X	X	X	
KIA	ASIA	2008	PICANTO(MORNING)		IMMOBILIZER						X		
KIA	ASIA	2008	PICANTO(MORNING)								X		
KIA	ASIA	2008	PICANTO(MORNING)		CODE SAVING								CODE SAVING
KIA	ASIA	2007	PICANTO(MORNING)		ENGINE CONTROL	1.1L VGT DIESEL CAN		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(MORNING)		ENGINE CONTROL	1.1L VGT DIESEL KWP							
KIA	ASIA	2007	PICANTO(MORNING)		ENGINE CONTROL	1.0L/1.1L SOHC EOBD		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(MORNING)		ENGINE CONTROL	1.0L/1.1L SOHC GEN		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(MORNING)		ENGINE CONTROL	1.0L/1.1L SOHC LEAD		X	X	X	X	X	
KIA	ASIA	2007	PICANTO(MORNING)		AUTOMATIC TRANSAXLE	GASOLINE		X	X	X	X	X	RESETTING ADAPTIVE VALUES
KIA	ASIA	2007	PICANTO(MORNING)		AUTOMATIC TRANSAXLE	DIESEL		X	X	X	X	X	RESETTING ADAPTIVE VALUES
KIA	ASIA	2007	PICANTO(MORNING)		ANTI-LOCK BRAKE SYSTEM								
KIA	ASIA	2007	PICANTO(MORNING)		SRS-AIRBAG			X	X	X			1.CRASHING INFORMATION
KIA	ASIA	2007	PICANTO(MORNING)		ELEC.POWER STEERING			X	X	X	X		
KIA	ASIA	2007	PICANTO(MORNING)		IMMOBILIZER	GASOLINE					X		
KIA	ASIA	2007	PICANTO(MORNING)		IMMOBILIZER	DIESEL					X		
KIA	ASIA	2007	PICANTO(MORNING)		CODE SAVING								X
KIA	ASIA	2006	PICANTO(MORNING)		ENGINE CONTROL	1.1L VGT DIESEL CAN		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(MORNING)		ENGINE CONTROL	1.1L VGT DIESEL KWP		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(MORNING)		ENGINE CONTROL	1.0L/1.1L SHOHC EOBD		X	X	X	X	X	1. FREEZE FRAME DATA
KIA	ASIA	2006	PICANTO(MORNING)		ENGINE CONTROL	1.0L/1.1L SHOHC GEN		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(MORNING)		ENGINE CONTROL	1.0L/1.1L SHOHC LEAD		X	X	X	X	X	1.IDLE CO ADJUSTMENT
KIA	ASIA	2006	PICANTO(MORNING)		AUTOMATIC TRANSAXLE	GASOLINE		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(MORNING)		AUTOMATIC TRANSAXLE	DIESEL		X	X	X	X	X	
KIA	ASIA	2006	PICANTO(MORNING)		ANTI-LOCK BRAKE SYSTEM			X	X	X	X	X	1. HCU AIR BLEEDING MODE
KIA	ASIA	2006	PICANTO(MORNING)		SRS-AIRBAG			X	X	X	X		
KIA	ASIA	2006	PICANTO(MORNING)		ELEC.POWER STEERING			X	X	X	X		
KIA	ASIA	2006	PICANTO(MORNING)		IMMOBILIZER	GASOLINE					X		
KIA	ASIA	2006	PICANTO(MORNING)			DIESEL					X		
KIA	ASIA	2006	PICANTO(MORNING)		CODE SAVING								X
KIA	ASIA	2004~2005	PICANTO(MORNING)		ENGINE CONTROL	1.0L/1.1L SHOHC EOBD		X	X	X	X	X	1. FREEZE FRAME DATA
KIA	ASIA	2004~2005	PICANTO(MORNING)		ENGINE CONTROL	1.0L/1.1L SHOHC GEN		X	X	X	X	X	
KIA	ASIA	2004~2005	PICANTO(MORNING)		ENGINE CONTROL	1.0L/1.1L SHOHC LEAD		X	X	X	X	X	1.IDLE CO ADJUSTMENT
KIA	ASIA	2004~2005	PICANTO(MORNING)		AUTOMATIC TRANSAXLE			X	X	X	X	X	
KIA	ASIA	2004~2005	PICANTO(MORNING)		ANTI-LOCK BRAKE SYSTEM			X	X	X	X	X	1. HCU AIR BLEEDING MODE
KIA	ASIA	2004~2005	PICANTO(MORNING)		SRS-AIRBAG			X	X	X	X		
KIA	ASIA	2004~2005	PICANTO(MORNING)		IMMOBILIZER						X		
KIA	ASIA	2004~2005	PICANTO(MORNING)		CODE SAVING								X
KIA	ASIA	All Model year	AVELLA		ENGINE CONTROL	1.3L/1.5L GASOLINE MAP		X	X	Manual	X		
KIA	ASIA	All Model year	AVELLA		AUTOMATIC TRANSAXLE				X	Manual			
KIA	ASIA	All Model year	AVELLA		ANTI-LOCK BRAKE SYSTEM				X	X	X	X	
KIA	ASIA	2009	RIO		ENGINE CONTROL	1.6L DOHC ALL			X	X	X	X	

KIA	ASIA	2009	RIO		AUTOMATIC TRANSAXLE				X	X	X	X	
KIA	ASIA	2009	RIO		ANTI-LOCK BRAKE SYSTEM				X	X	X		
KIA	ASIA	2009	RIO		SRS-AIRBAG				X	X	X		
KIA	ASIA	2007	RIO		ENGINE CONTROL	1.6L CVVT EOBD		X	X	X	X	X	
KIA	ASIA	2007	RIO		ENGINE CONTROL	1.6L CVVT GEN		X	X	X	X	X	
KIA	ASIA	2007	RIO		ENGINE CONTROL	1.6L CVVT LEAD		X	X	X	X	X	
KIA	ASIA	2007	RIO		ENGINE CONTROL	1.4L DOHC EOBD		X	X	X	X	X	
KIA	ASIA	2007	RIO		ENGINE CONTROL	1.4L DOHC GEN		X	X	X	X	X	1.RESETTING ADAPTIVE VALUES
KIA	ASIA	2007	RIO		ENGINE CONTROL	1.4L DOHC LEAD		X	X	X	X	X	1.RESETTING ADAPTIVE VALUES 2.IDLE CO ADJUSTMENT
KIA	ASIA	2007	RIO		ENGINE CONTROL	1.5L VGT DIESEL		X	X	X	X	X	
KIA	ASIA	2007	RIO		AUTOMATIC TRANSAXLE			X	X	X	X	X	
KIA	ASIA	2007	RIO		ANTI-LOCK BRAKE SYSTEM								
KIA	ASIA	2007	RIO		SRS-AIRBAG			X	X	X			1.CRASHING INFORMATION
KIA	ASIA	2007	RIO		IMMOBILIZER						X		
KIA	ASIA	2007	RIO		BODE SAVING								X
KIA	ASIA	2006	RIO		ENGINE CONTROL	1.6L CVVT EOBD		X	X	X	X	X	1.RESETTING ADAPTIVE VALUES
KIA	ASIA	2006	RIO		ENGINE CONTROL	1.6L CVVT GEN		X	X	X	X	X	1.RESETTING ADAPTIVE VALUES
KIA	ASIA	2006	RIO		ENGINE CONTROL	1.6L CVVT LEAD		X	X	X	X	X	1.RESETTING ADAPTIVE VALUES 2.IDLE CO ADJUSTMENT
KIA	ASIA	2006	RIO		ENGINE CONTROL	1.4L DOHC EOBD		X	X	X	X	X	1.RESETTING ADAPTIVE VALUES
KIA	ASIA	2006	RIO		ENGINE CONTROL	1.4L DOHC GEN		X	X	X	X	X	1.RESETTING ADAPTIVE VALUES
KIA	ASIA	2006	RIO		ENGINE CONTROL	1.4L DOHC LEAD		X	X	X	X	X	1.RESETTING ADAPTIVE VALUES 2.IDLE CO ADJUSTMENT
KIA	ASIA	2006	RIO		ENGINE CONTROL	U 1.5L VGT DIESEL		X	X	X	X	X	
KIA	ASIA	2006	RIO		AUTOMATIC TRANSAXLE			X	X	X	X	X	1.RESETTING ADAPTIVE VALUES
KIA	ASIA	2006	RIO		ANTI-LOCK BRAKE SYSTEM			X	X	X	X	X	1. HCU AIR BLEEDING MODE
KIA	ASIA	2006	RIO		SRS-AIRBAG			X	X	X	X		
KIA	ASIA	2006	RIO		IMMOBILIZER					X			
KIA	ASIA	2006	RIO		CODE SAVING								X
KIA	ASIA	2004~2005	RIO		ENGINE CONTROL	1.3L/1.5L GASOLINE MAP			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2004~2005	RIO		ENGINE CONTROL	1.3L/1.5L MAF			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2004~2005	RIO		ENGINE CONTROL	1.3L/1.5L GASOL. W.IMMO			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2004~2005	RIO		ENGINE CONTROL	1.3L/1.5L GASOLINE LEAD			X	X	X		1. FREEZE FRAME DATA 2. IDLE CO ADJUSTMENT
KIA	ASIA	2004~2005	RIO		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2004~2005	RIO		ANTI-LOCK BRAKE SYSTEM	16PIN OBD2 CONNECTOR		X	X	X	X	X	1. HCU AIR BLEEDING MODE
KIA	ASIA	2004~2005	RIO		ANTI-LOCK BRAKE SYSTEM	20PIN RED KIA CONNECTOR		X	X	X	X	X	1. HCU AIR BLEEDING MODE
KIA	ASIA	2004~2005	RIO		SRS-AIRBAG			X	X	X	X		1. ACTIVE DTC INFORMATION 2. HISTORY DTC INFORMATION
KIA	ASIA	2004~2005	RIO		CODE SAVING								X
KIA	ASIA	2003	RIO		ENGINE CONTROL	1.3L/1.5L GASOLINE MAP			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2003	RIO		ENGINE CONTROL	1.3L/1.5L MAF			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2003	RIO		ENGINE CONTROL	1.3L/1.5L GASOL. W.IMMO			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2003	RIO		ENGINE CONTROL	1.3L/1.5L GASOLINE LEAD			X	X	X		1. FREEZE FRAME DATA 2. IDLE CO ADJUSTMENT
KIA	ASIA	2003	RIO		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2003	RIO		ANTI-LOCK BRAKE SYSTEM	16PIN OBD2 CONNECTOR		X	X	X	X	X	1. HCU AIR BLEEDING MODE
KIA	ASIA	2003	RIO		ANTI-LOCK BRAKE SYSTEM	20PIN RED KIA CONNECTOR		X	X	X	X	X	1. HCU AIR BLEEDING MODE

KIA	ASIA	2003	RIO		SRS-AIRBAG			X	X	X	X		1. ACTIVE DTC INFORMATION 2. HISTORY DTC INFORMATION
KIA	ASIA	2003	RIO		CODE SAVING								X
KIA	ASIA	2001~2002	RIO		ENGINE CONTROL	1.3L/1.5L GASOLINE MAP			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2001~2002	RIO		ENGINE CONTROL	1.3L/1.5L MAF			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2001~2002	RIO		ENGINE CONTROL	1.3L/1.5L(RHD) MAP			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2001~2002	RIO		ENGINE CONTROL	1.3L/1.5L(RHD) MAF			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2001~2002	RIO		ENGINE CONTROL	1.3L/1.5L GASOL. W.IMMO			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2001~2002	RIO		ENGINE CONTROL	1.3L/1.5L GASOLINE LEAD			X	X	X		1. FREEZE FRAME DATA 2. IDLE CO ADJUSTMENT
KIA	ASIA	2001~2002	RIO		AUTOMATIC TRANSAXLE	TCU LHD			X	X	X		
KIA	ASIA	2001~2002	RIO		AUTOMATIC TRANSAXLE	TCU RHD			X	X	X		
KIA	ASIA	2001~2002	RIO		ANTI-LOCK BRAKE SYSTEM	ABS LHD		X	X	X	X	X	
KIA	ASIA	2001~2002	RIO		ANTI-LOCK BRAKE SYSTEM	ABS RHD		X	X	X	X	X	
KIA	ASIA	2001~2002	RIO		SRS-AIRBAG	A/BAG LHD		X	X	X	X		1. ACTIVE DTC INFORMATION 2. HISTORY DTC INFORMATION
KIA	ASIA	2001~2002	RIO		SRS-AIRBAG	A/BAG RHD		X	X	X	X		1. ACTIVE DTC INFORMATION 2. HISTORY DTC INFORMATION
KIA	ASIA	2000	RIO		ENGINE CONTROL	1.3L/1.5L GASOLINE MAP			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2000	RIO		ENGINE CONTROL	1.3L/1.5L MAF			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2000	RIO		ENGINE CONTROL	1.3L/1.5L(RHD) MAP			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2000	RIO		ENGINE CONTROL	1.3L/1.5L(RHD) MAF			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2000	RIO		ENGINE CONTROL	1.3L/1.5L GASOL. W.IMMO			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2000	RIO		ENGINE CONTROL	1.3L/1.5L GASOLINE LEAD			X	X	X		1. FREEZE FRAME DATA 2. IDLE CO ADJUSTMENT
KIA	ASIA	2000	RIO		AUTOMATIC TRANSAXLE	TCU LHD			X	X	X		
KIA	ASIA	2000	RIO		AUTOMATIC TRANSAXLE	TCU RHD			X	X	X		
KIA	ASIA	2000	RIO		ANTI-LOCK BRAKE SYSTEM	ABS LHD		X	X	X	X	X	
KIA	ASIA	2000	RIO		ANTI-LOCK BRAKE SYSTEM	ABS RHD		X	X	X	X	X	
KIA	ASIA	2000	RIO		SRS-AIRBAG	A/BAG LHD			X	X			
KIA	ASIA	2000	RIO		SRS-AIRBAG	A/BAG RHD			X	X			
KIA	ASIA	2004	SEPHIA(MENTOR)		ENGINE CONTROL	1.6L DOHC NON IMMO			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2004	SEPHIA(MENTOR)		ENGINE CONTROL	1.6L DOHC W/IMMO			X	X	X		1.FREEZE FRAME DATA 2.MONITORING TEST(EURO.ONLY)
KIA	ASIA	2004	SEPHIA(MENTOR)		ENGINE CONTROL	1.6L DOHC LEAD			X	X	X		1. FREEZE FRAME DATA 2. IDLE CO ADJUSTMENT
KIA	ASIA	2004	SEPHIA(MENTOR)		ENGINE CONTROL	1.8L DOHC GASOLINE TED			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2004	SEPHIA(MENTOR)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2004	SEPHIA(MENTOR)		ANTI-LOCK BRAKE SYSTEM			X	X	X	X	X	
KIA	ASIA	2004	SEPHIA(MENTOR)		SRS-AIRBAG				X	X			
KIA	ASIA	2004	SEPHIA(MENTOR)		IMMOBILIZER	1.6L DOHC SMARTRA					X		
KIA	ASIA	2004	SEPHIA(MENTOR)		CODE SAVING								X
KIA	ASIA	2003	SEPHIA(MENTOR)		ENGINE CONTROL	1.6L DOHC NON IMMO			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2003	SEPHIA(MENTOR)		ENGINE CONTROL	1.6L DOHC W/IMMO			X	X	X		1.FREEZE FRAME DATA 2.MONITORING TEST(EURO.ONLY)
KIA	ASIA	2003	SEPHIA(MENTOR)		ENGINE CONTROL	1.6L DOHC LEAD			X	X	X		1. FREEZE FRAME DATA 2. IDLE CO ADJUSTMENT
KIA	ASIA	2003	SEPHIA(MENTOR)		ENGINE CONTROL	1.8L DOHC GASOLINE TED			X	X	X		1. FREEZE FRAME DATA

KIA	ASIA	2003	SEPHIA(MENTOR)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2003	SEPHIA(MENTOR)		ANTI-LOCK BRAKE SYSTEM			X	X	X	X	X	
KIA	ASIA	2003	SEPHIA(MENTOR)		SRS-AIRBAG				X	X			
KIA	ASIA	2003	SEPHIA(MENTOR)		IMMOBILIZER	1.6L DOHC SMARTRA					X		
KIA	ASIA	2003	SEPHIA(MENTOR)		CODE SAVING								X
KIA	ASIA	2002	SEPHIA(MENTOR)		ENGINE CONTROL	1.6L DOHC NON IMMO			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2002	SEPHIA(MENTOR)		ENGINE CONTROL	1.6L DOHC W/IMMO			X	X	X		1.FREEZE FRAME DATA 2.MONITORING TEST(EURO.ONLY)
KIA	ASIA	2002	SEPHIA(MENTOR)		ENGINE CONTROL	1.6L DOHC LEAD			X	X	X		1.FREEZE FRAME DATA 2.IDLE CO ADJUSTMENT
KIA	ASIA	2002	SEPHIA(MENTOR)		ENGINE CONTROL	1.8L DOHC GASOLINE TED			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2002	SEPHIA(MENTOR)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2002	SEPHIA(MENTOR)		ANTI-LOCK BRAKE SYSTEM			X	X	X	X	X	
KIA	ASIA	2002	SEPHIA(MENTOR)		SRS-AIRBAG				X	X			
KIA	ASIA	2002	SEPHIA(MENTOR)		IMMOBILIZER	1.6L DOHC SMARTRA					X		
KIA	ASIA	2001	SEPHIA(MENTOR)		ENGINECONTROL	1.6L DOHC NON IMMO			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2001	SEPHIA(MENTOR)		ENGINECONTROL	1.6L DOHC W/IMMO			X	X	X		1.FREEZE FRAME DATA 2.MONITORING TEST(EURO.ONLY)
KIA	ASIA	2001	SEPHIA(MENTOR)		ENGINECONTROL	1.6L DOHC LEAD			X	X	X		1. FREEZE FRAME DATA 2.IDLE CO ADJUSTMENT
KIA	ASIA	2001	SEPHIA(MENTOR)		ENGINECONTROL	1.8L DOHC GASOLINE TED			X	X	X		1. FREEZE FRAME DATA
KIA	ASIA	2001	SEPHIA(MENTOR)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2001	SEPHIA(MENTOR)		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2001	SEPHIA(MENTOR)		SRS-AIRBAG				X	X			
KIA	ASIA	2001	SEPHIA(MENTOR)		IMMOBILIZER	1.6L DOHC SMARTRA					X		
KIA	ASIA	2000	SEPHIA(MENTOR)		ENGINECONTROL	1.5LGASOLINEBFD/BFE			X	X	X		
KIA	ASIA	2000	SEPHIA(MENTOR)		ENGINECONTROL	1.8LDOHCGASOLINETED			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	2000	SEPHIA(MENTOR)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2000	SEPHIA(MENTOR)		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2000	SEPHIA(MENTOR)		SRS-AIRBAG				X	X			
KIA	ASIA	1999	SEPHIA(MENTOR)		ENGINECONTROL	1.5LGASOLINEBFD/BFE			X	X	X		
KIA	ASIA	1999	SEPHIA(MENTOR)		ENGINECONTROL	1.8LDOHCGASOLINETED			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	1999	SEPHIA(MENTOR)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	1999	SEPHIA(MENTOR)		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	1999	SEPHIA(MENTOR)		SRS-AIRBAG				X	X			
KIA		1998	SEPHIA(MENTOR)		ENGINECONTROL	1.5LGASOLINEBFD/BFE			X	X	X		
KIA	ASIA	1998	SEPHIA(MENTOR)		ENGINECONTROL	1.8LDOHCGASOLINETED			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	1998	SEPHIA(MENTOR)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	1998	SEPHIA(MENTOR)		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	1998	SEPHIA(MENTOR)		SRS-AIRBAG				X	X			
KIA		Before1998	SEPHIA(MENTOR)		ENGINECONTROL	1.5L/1.6LENG(MTM)AFM1			X	Manual			
KIA	ASIA	Before1998	SEPHIA(MENTOR)		ENGINECONTROL	1.5L/1.6LENG(ATM)AFM1			X	Manual			
KIA		2004	SHUMA(SPECTRA)		ENGINECONTROL	1.6LDOHCNONIMMO			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	2004	SHUMA(SPECTRA)		ENGINECONTROL	1.6LDOHCW/IMMO			X	X	X		1.FREEZEFRAME DATA 2.MONITORING TEST(EURO.ONLY)
KIA	ASIA	2004	SHUMA(SPECTRA)		ENGINECONTROL	1.6LDOHCLEAD			X	X	X		1.FREEZEFRAME DATA 2.IDLE CO ADJUSTMENT
KIA	ASIA	2004	SHUMA(SPECTRA)		ENGINECONTROL	1.8LDOHCGASOLINETED			X	X	X		1.FREEZEFRAME DATA

KIA	ASIA	2004	SHUMA(SPECTRA)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2004	SHUMA(SPECTRA)		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2004	SHUMA(SPECTRA)		SRS-AIRBAG				X	X			
KIA	ASIA	2004	SHUMA(SPECTRA)		IMMOBILIZER	1.6LDOHCSMARTRA					X		
KIA	ASIA	2004	SHUMA(SPECTRA)		CODESAVING								X
KIA	ASIA	2003	SHUMA(SPECTRA)		ENGINECONTROL	1.6LDOHCNONIMMO			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	2003	SHUMA(SPECTRA)		ENGINECONTROL	1.6LDOHCW/IMMO			X	X	X		1.FREEZEFRAME DATA 2.MONITORING TEST(EURO.ONLY)
KIA	ASIA	2003	SHUMA(SPECTRA)		ENGINECONTROL	1.6LDOHCLEAD			X	X	X		1.FREEZEFRAME DATA 2.IDLE CO ADJUSTMENT
KIA	ASIA	2003	SHUMA(SPECTRA)		ENGINECONTROL	1.8LDOHCGASOLINETED			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	2003	SHUMA(SPECTRA)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2003	SHUMA(SPECTRA)		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2003	SHUMA(SPECTRA)		SRS-AIRBAG				X	X			
KIA	ASIA	2003	SHUMA(SPECTRA)		IMMOBILIZER	1.6LDOHCSMARTRA					X		
KIA	ASIA	2003	SHUMA(SPECTRA)		CODESAVING								X
KIA	ASIA	2002	SHUMA(SPECTRA)		ENGINECONTROL	1.6LDOHCNONIMMO			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	2002	SHUMA(SPECTRA)		ENGINECONTROL	1.6LDOHCW/IMMO			X	X	X		1.FREEZEFRAME DATA 2.MONITORING TEST(EURO.ONLY)
KIA	ASIA	2002	SHUMA(SPECTRA)		ENGINECONTROL	1.6LDOHCLEAD			X	X	X		1.FREEZEFRAME DATA 2.IDLECO ADJUSTMENT
KIA	ASIA	2002	SHUMA(SPECTRA)		ENGINECONTROL	1.8LDOHCGASOLINETED			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	2002	SHUMA(SPECTRA)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2002	SHUMA(SPECTRA)		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2002	SHUMA(SPECTRA)		SRS-AIRBAG				X	X			
KIA	ASIA	2002	SHUMA(SPECTRA)		IMMOBILIZER	1.6LDOHCSMARTRA					X		
KIA	ASIA	2001	SHUMA(SPECTRA)		ENGINECONTROL	1.6LDOHCNONIMMO			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	2001	SHUMA(SPECTRA)		ENGINECONTROL	1.6LDOHCW/IMMO			X	X	X		1.FREEZEFRAME DATA 2.MONITORING TEST(EURO.ONLY)
KIA	ASIA	2001	SHUMA(SPECTRA)		ENGINECONTROL	1.6LDOHCLEAD			X	X	X		1.FREEZEFRAME DATA 2.IDLECO ADJUSTMENT
KIA	ASIA	2001	SHUMA(SPECTRA)		ENGINECONTROL	1.8LDOHCGASOLINETED			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	2001	SHUMA(SPECTRA)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2001	SHUMA(SPECTRA)		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2001	SHUMA(SPECTRA)		SRS-AIRBAG				X	X			
KIA	ASIA	2001	SHUMA(SPECTRA)		IMMOBILIZER	1.6LDOHCSMARTRA					X		
KIA	ASIA	2000	SHUMA(SPECTRA)		ENGINECONTROL	1.5LGASOLINEBFD/BFE			X	X	X		
KIA	ASIA	2000	SHUMA(SPECTRA)		ENGINECONTROL	1.8LDOHCGASOLINETED			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	2000	SHUMA(SPECTRA)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2000	SHUMA(SPECTRA)		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2000	SHUMA(SPECTRA)		SRS-AIRBAG				X	X			
KIA	ASIA	1999	SHUMA(SPECTRA)		ENGINECONTROL	1.5LGASOLINEBFD/BFE			X	X	X		
KIA	ASIA	1999	SHUMA(SPECTRA)		ENGINECONTROL	1.8LDOHCGASOLINETED			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	1999	SHUMA(SPECTRA)		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	1999	SHUMA(SPECTRA)		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	1999	SHUMA(SPECTRA)		SRS-AIRBAG				X	X			
KIA	ASIA	1999	SHUMA(SPECTRA)		IMMOBILIZER	1.6LDOHCSMARTRA					X		
KIA	ASIA	2007	CERATO		ENGINECONTROL	UNLEAD2.0LGEN		X	X	X	X	X	
KIA	ASIA	2007	CERATO		ENGINECONTROL	UNLEAD2.0LEOBD		X	X	X	X	X	
KIA	ASIA	2007	CERATO		ENGINECONTROL	LEAD2.0LALL		X	X	X	X	X	

KIA	ASIA	2007	CERATO		ENGINECONTROL	UNLEAD1.6LGEN		X	X	X	X	X	
KIA	ASIA	2007	CERATO		ENGINECONTROL	UNLEAD1.6LEOBD		X	X	X	X	X	
KIA	ASIA	2007	CERATO		ENGINECONTROL	LEAD1.6LALL		X	X	X	X	X	
KIA	ASIA	2007	CERATO		ENGINECONTROL	1.6LDIESEL(VGT)EURO-4		X	X	X	X	X	
KIA	ASIA	2007	CERATO		AUTOMATICTRANSAXLE	1.6LGASOLINE		X	X	X	X	X	
KIA	ASIA	2007	CERATO		AUTOMATICTRANSAXLE	2.0LGASOLINE		X	X	X	X	X	
KIA	ASIA	2007	CERATO		AUTOMATICTRANSAXLE	1.6LDIESEL		X	X	X	X	X	
KIA	ASIA	2007	CERATO		CODESAVING								X
KIA	ASIA	2006	CERATO		ENGINECONTROL	1.6LDIESEL(VGT)EURO-4		X	X	X	X	X	
KIA	ASIA	2006	CERATO		ENGINECONTROL	2.0LDIESELALL		X	X	X	X	X	
KIA	ASIA	2006	CERATO		ENGINECONTROL	1.5LDIESELALL		X	X	X	X	X	
KIA	ASIA	2006	CERATO		ENGINECONTROL	1.6LDOHCEOBD			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2006	CERATO		ENGINECONTROL	1.6LDOHCGEN			X	X	X	X	
KIA	ASIA	2006	CERATO		ENGINECONTROL	1.6LDOHCLEAD			X	X	X	X	1.IDLECO ADJUSTMENT
KIA	ASIA	2006	CERATO		ENGINECONTROL	2.0LDOHC(+CVVT)EOBD		X	X	X	X	X	1.FREEZEFRAME DATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2006	CERATO		ENGINECONTROL	2.0LDOHC(-CVVT)EOBD		X	X	X	X	X	1.RESETTING ADAPTIVEVALUES 2.VERSION CONFIGUREATION
KIA	ASIA	2006	CERATO		ENGINECONTROL	2.0LDOHC(+CVVT)GEN		X	X	X	X	X	1.FREEZEFRAME DATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2006	CERATO		ENGINECONTROL	2.0LDOHC(-CVVT)GEN		X	X	X	X	X	1.RESETTING ADAPTIVEVALUES 2.VERSION CONFIGUREATION
KIA	ASIA	2006	CERATO		ENGINECONTROL	2.0LDOHC(+CVVT)LEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2006	CERATO		ENGINECONTROL	2.0LDOHC(-CVVT)LEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2006	CERATO		AUTOMATIC TRANSAXLE	1.6LDOHCALL			X	X	X	X	
KIA	ASIA	2006	CERATO		AUTOMATIC TRANSAXLE	2.0LDOHCALL		X	X	X	X	X	
KIA	ASIA	2006	CERATO		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	1.HCUAIRBLEEDING MODE
KIA	ASIA	2006	CERATO		SRS-AIRBAG			X	X	X	X		
KIA	ASIA	2006	CERATO		IMMOBILIZER	2.0L/1.5LDIESELALL					X		
KIA	ASIA	2006	CERATO		IMMOBILIZER	1.6LDOHCALL					X		
KIA	ASIA	2006	CERATO		IMMOBILIZER	2.0LDOHCALL					X		
KIA	ASIA	2006	CERATO		CODESAVING								X
KIA	ASIA	2005	CERATO		ENGINECONTROL	2.0LDIESELALL		X	X	X	X	X	
KIA	ASIA	2005	CERATO		ENGINECONTROL	1.5LDIESELALL		X	X	X	X	X	
KIA	ASIA	2005	CERATO		ENGINECONTROL	1.6LDOHCEOBD			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2005	CERATO		ENGINECONTROL	1.6LDOHCGEN			X	X	X	X	
KIA	ASIA	2005	CERATO		ENGINECONTROL	1.6LDOHCLEAD			X	X	X	X	1.IDLECO ADJUSTMENT
KIA	ASIA	2005	CERATO		ENGINECONTROL	2.0LDOHC(+CVVT)EOBD		X	X	X	X	X	1.FREEZEFRAME DATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2005	CERATO		ENGINECONTROL	2.0LDOHC(-CVVT)EOBD		X	X	X	X	X	1.RESETTING ADAPTIVEVALUES 2.VERSION CONFIGUREATION

KIA	ASIA	2005	CERATO		ENGINECONTROL	2.0LDOHC(+CVVT)GEN		X	X	X	X	X	1.FREEZEFRAME DATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2005	CERATO		ENGINECONTROL	2.0LDOHC(-CVVT)GEN		X	X	X	X	X	1.RESETTING ADAPTIVEVALUES 2.VERSION CONFIGUREATION
KIA	ASIA	2005	CERATO		ENGINECONTROL	2.0LDOHC(+CVVT)LEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2005	CERATO		ENGINECONTROL	2.0LDOHC(-CVVT)LEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2005	CERATO		AUTOMATIC TRANSAXLE	1.6LDOHCALL			X	X	X	X	
KIA	ASIA	2005	CERATO		AUTOMATIC TRANSAXLE	2.0LDOHCALL		X	X	X	X	X	
KIA	ASIA	2005	CERATO		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	1.HCUAIRBLEEDING MODE
KIA	ASIA	2005	CERATO		SRS-AIRBAG			X	X	X	X		
KIA	ASIA	2005	CERATO		IMMOBILIZER	2.0L/1.5LDIESELALL					X		
KIA	ASIA	2005	CERATO		IMMOBILIZER	1.6LDOHCALL					X		
KIA	ASIA	2005	CERATO		IMMOBILIZER	2.0LDOHCALL					X		
KIA	ASIA	2005	CERATO		CODESAVING								X
KIA	ASIA	2004	CERATO		ENGINECONTROL	2.0LDIESELALL		X	X	X	X	X	
KIA	ASIA	2004	CERATO		ENGINECONTROL	1.6LDOHCEOBD			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2004	CERATO		ENGINECONTROL	1.6LDOHCGEN			X	X	X	X	
KIA	ASIA	2004	CERATO		ENGINECONTROL	1.6LDOHCLEAD			X	X	X	X	1.IDLECO ADJUSTMENT
KIA	ASIA	2004	CERATO		ENGINECONTROL	2.0LDOHC(+CVVT)EOBD		X	X	X	X	X	1.FREEZEFRAME DATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2004	CERATO		ENGINECONTROL	2.0LDOHC(-CVVT)EOBD		X	X	X	X	X	1.RESETTING ADAPTIVEVALUES 2.VERSION CONFIGUREATION
KIA	ASIA	2004	CERATO		ENGINECONTROL	2.0LDOHC(+CVVT)GEN		X	X	X	X	X	1.FREEZEFRAME DATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2004	CERATO		ENGINECONTROL	2.0LDOHC(-CVVT)GEN		X	X	X	X	X	1.RESETTING ADAPTIVEVALUES 2.VERSION CONFIGUREATION
KIA	ASIA	2004	CERATO		ENGINECONTROL	2.0LDOHC(+CVVT)LEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2004	CERATO		ENGINECONTROL	2.0LDOHC(-CVVT)LEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2004	CERATO		AUTOMATIC TRANSAXLE	1.6LDOHCALL			X	X	X	X	
KIA	ASIA	2004	CERATO		AUTOMATIC TRANSAXLE	2.0LDOHCALL		X	X	X	X	X	
KIA	ASIA	2004	CERATO		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	1.HCUAIRBLEEDING MODE
KIA	ASIA	2004	CERATO		SRS-AIRBAG			X	X	X	X		
KIA	ASIA	2004	CERATO		CODESAVING								X
KIA	ASIA	2004	CERATO		IMMOBILIZER	2.0L/1.5LDIESELALL					X		
KIA	ASIA	2004	CERATO		IMMOBILIZER	1.6LDOHCALL					X		
KIA	ASIA	2004	CERATO		IMMOBILIZER	2.0LDOHCALL					X		
KIA	ASIA	2012	CARENS		G 2.0 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G 2.0 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G 2.0 DOHC	ENGINE/Leaded All		X	X	X	X	X	

KIA	ASIA	2012	CARENS		G 2.0 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G 2.0 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G 2.0 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2012	CARENS		G 2.0 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G 2.0 DOHC	BCM		X			X	X	
KIA	ASIA	2012	CARENS		G 2.0 DOHC	IMMO					X		
KIA	ASIA	2012	CARENS		G 2.0 DOHC	CODE					X		
KIA	ASIA	2012	CARENS		G1.6 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G1.6 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G1.6 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G1.6 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G1.6 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G1.6 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2012	CARENS		G1.6 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G1.6 DOHC	BCM		X			X	X	
KIA	ASIA	2012	CARENS		G1.6 DOHC	IMMO					X		
KIA	ASIA	2012	CARENS		G1.6 DOHC	CODE					X		
KIA	ASIA	2012	CARENS		G 1.6 TCI-U2	ENGINE		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G 1.6 TCI-U2	ESP		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G 1.6 TCI-U2	AIRBAG		X	X	X	X		
KIA	ASIA	2012	CARENS		G 1.6 TCI-U2	AIRCON		X	X	X	X	X	
KIA	ASIA	2012	CARENS		G 1.6 TCI-U2	BCM		X			X	X	
KIA	ASIA	2012	CARENS		G 1.6 TCI-U2	IMMO					X		
KIA	ASIA	2012	CARENS		G 1.6 TCI-U2	CODE					X		
KIA	ASIA	2012	CARENS		D 2.0 TCI-R	ENGINE		X	X	X	X	X	
KIA	ASIA	2012	CARENS		D 2.0 TCI-R	AT		X	X	X	X	X	
KIA	ASIA	2012	CARENS		D 2.0 TCI-R	ESP		X	X	X	X	X	
KIA	ASIA	2012	CARENS		D 2.0 TCI-R	AIRBAG		X	X	X	X		
KIA	ASIA	2012	CARENS		D 2.0 TCI-R	AIRCON		X	X	X	X	X	
KIA	ASIA	2012	CARENS		D 2.0 TCI-R	BCM		X			X	X	
KIA	ASIA	2012	CARENS		D 2.0 TCI-R	IMMO					X		
KIA	ASIA	2012	CARENS		D 2.0 TCI-R	CODE					X		
KIA	ASIA	2011	CARENS		G 2.0 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G 2.0 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G 2.0 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G 2.0 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G 2.0 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G 2.0 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2011	CARENS		G 2.0 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G 2.0 DOHC	BCM		X			X	X	
KIA	ASIA	2011	CARENS		G 2.0 DOHC	IMMO					X		
KIA	ASIA	2011	CARENS		G 2.0 DOHC	CODE					X		
KIA	ASIA	2011	CARENS		G1.6 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G1.6 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G1.6 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G1.6 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G1.6 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G1.6 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2011	CARENS		G1.6 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G1.6 DOHC	BCM		X			X	X	

KIA	ASIA	2011	CARENS		G1.6 DOHC	IMMO					X		
KIA	ASIA	2011	CARENS		G1.6 DOHC	CODE					X		
KIA	ASIA	2011	CARENS		G 1.6 TCI-U2	ENGINE		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G 1.6 TCI-U2	ESP		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G 1.6 TCI-U2	AIRBAG		X	X	X	X		
KIA	ASIA	2011	CARENS		G 1.6 TCI-U2	AIRCON		X	X	X	X	X	
KIA	ASIA	2011	CARENS		G 1.6 TCI-U2	BCM		X			X	X	
KIA	ASIA	2011	CARENS		G 1.6 TCI-U2	IMMO					X		
KIA	ASIA	2011	CARENS		G 1.6 TCI-U2	CODE					X		
KIA	ASIA	2011	CARENS		D 2.0 TCI-R	ENGINE		X	X	X	X	X	
KIA	ASIA	2011	CARENS		D 2.0 TCI-R	AT		X	X	X	X	X	
KIA	ASIA	2011	CARENS		D 2.0 TCI-R	ESP		X	X	X	X	X	
KIA	ASIA	2011	CARENS		D 2.0 TCI-R	AIRBAG		X	X	X	X		
KIA	ASIA	2011	CARENS		D 2.0 TCI-R	AIRCON		X	X	X	X	X	
KIA	ASIA	2011	CARENS		D 2.0 TCI-R	BCM		X			X	X	
KIA	ASIA	2011	CARENS		D 2.0 TCI-R	IMMO					X		
KIA	ASIA	2011	CARENS		D 2.0 TCI-R	CODE					X		
KIA	ASIA	2010	CARENS		G 2.0 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	CARENS		G 2.0 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	CARENS		G 2.0 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2010	CARENS		G 2.0 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2010	CARENS		G 2.0 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2010	CARENS		G 2.0 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2010	CARENS		G 2.0 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2010	CARENS		G 2.0 DOHC	BCM		X			X	X	
KIA	ASIA	2010	CARENS		G 2.0 DOHC	IMMO					X		
KIA	ASIA	2010	CARENS		G 2.0 DOHC	CODE					X		
KIA	ASIA	2010	CARENS		G 1.6 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	CARENS		G 1.6 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	CARENS		G 1.6 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2010	CARENS		G 1.6 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2010	CARENS		G 1.6 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2010	CARENS		G 1.6 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2010	CARENS		G 1.6 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2010	CARENS		G 1.6 DOHC	BCM		X			X	X	
KIA	ASIA	2010	CARENS		G 1.6 DOHC	IMMO					X		
KIA	ASIA	2010	CARENS		G 1.6 DOHC	CODE					X		
KIA	ASIA	2010	CARENS		D 2.0 TCI-D	ENGINE		X	X	X	X	X	
KIA	ASIA	2010	CARENS		D 2.0 TCI-D	AT		X	X	X	X	X	
KIA	ASIA	2010	CARENS		D 2.0 TCI-D	ESP		X	X	X	X	X	
KIA	ASIA	2010	CARENS		D 2.0 TCI-D	AIRBAG		X	X	X	X		
KIA	ASIA	2010	CARENS		D 2.0 TCI-D	AIRCON		X	X	X	X	X	
KIA	ASIA	2010	CARENS		D 2.0 TCI-D	BCM		X			X	X	
KIA	ASIA	2010	CARENS		D 2.0 TCI-D	IMMO					X		
KIA	ASIA	2010	CARENS		D 2.0 TCI-D	CODE					X		
KIA	ASIA	2009	CARENS		G 2.0 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	CARENS		G 2.0 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	CARENS		G 2.0 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2009	CARENS		G 2.0 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2009	CARENS		G 2.0 DOHC	ESP		X	X	X	X	X	

KIA	ASIA	2009	CARENS		G 2.0 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2009	CARENS		G 2.0 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2009	CARENS		G 2.0 DOHC	BCM		X			X	X	
KIA	ASIA	2009	CARENS		G 2.0 DOHC	IMMO					X		
KIA	ASIA	2009	CARENS		G 2.0 DOHC	CODE					X		
KIA	ASIA	2009	CARENS		G 1.6 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	CARENS		G 1.6 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	CARENS		G 1.6 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2009	CARENS		G 1.6 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2009	CARENS		G 1.6 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2009	CARENS		G 1.6 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2009	CARENS		G 1.6 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2009	CARENS		G 1.6 DOHC	BCM		X			X	X	
KIA	ASIA	2009	CARENS		G 1.6 DOHC	IMMO					X		
KIA	ASIA	2009	CARENS		G 1.6 DOHC	CODE					X		
KIA	ASIA	2009	CARENS		D 2.0 TCI-D	ENGINE		X	X	X	X	X	
KIA	ASIA	2009	CARENS		D 2.0 TCI-D	AT		X	X	X	X	X	
KIA	ASIA	2009	CARENS		D 2.0 TCI-D	ESP		X	X	X	X	X	
KIA	ASIA	2009	CARENS		D 2.0 TCI-D	AIRBAG		X	X	X	X		
KIA	ASIA	2009	CARENS		D 2.0 TCI-D	AIRCON		X	X	X	X	X	
KIA	ASIA	2009	CARENS		D 2.0 TCI-D	BCM		X			X	X	
KIA	ASIA	2009	CARENS		D 2.0 TCI-D	IMMO					X		
KIA	ASIA	2009	CARENS		D 2.0 TCI-D	CODE					X		
KIA	ASIA	2008	CARENS		G 2.0 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	CARENS		G 2.0 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	CARENS		G 2.0 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2008	CARENS		G 2.0 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2008	CARENS		G 2.0 DOHC	ABSESP		X	X	X	X	X	
KIA	ASIA	2008	CARENS		G 2.0 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2008	CARENS		G 2.0 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2008	CARENS		G 2.0 DOHC	BCM		X			X	X	
KIA	ASIA	2008	CARENS		G 2.0 DOHC	IMMO					X		
KIA	ASIA	2008	CARENS		G 2.0 DOHC	CODE					X		
KIA	ASIA	2008	CARENS		G 2.4 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	CARENS		G 2.4 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	CARENS		G 2.4 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2008	CARENS		G 2.4 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2008	CARENS		G 2.4 DOHC	ABSESP		X	X	X	X	X	
KIA	ASIA	2008	CARENS		G 2.4 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2008	CARENS		G 2.4 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2008	CARENS		G 2.4 DOHC	BCM		X			X	X	
KIA	ASIA	2008	CARENS		G 2.4 DOHC	IMMO					X		
KIA	ASIA	2008	CARENS		G 2.4 DOHC	CODE					X		
KIA	ASIA	2008	CARENS		D 2.0 TCI-D	ENGINE		X	X	X	X	X	
KIA	ASIA	2008	CARENS		D 2.0 TCI-D	AT		X	X	X	X	X	
KIA	ASIA	2008	CARENS		D 2.0 TCI-D	ABSESP		X	X	X	X	X	
KIA	ASIA	2008	CARENS		D 2.0 TCI-D	AIRBAG		X	X	X	X		
KIA	ASIA	2008	CARENS		D 2.0 TCI-D	AIRCON		X	X	X	X	X	
KIA	ASIA	2008	CARENS		D 2.0 TCI-D	BCM		X			X	X	
KIA	ASIA	2008	CARENS		D 2.0 TCI-D	IMMO					X		

KIA	ASIA	2008	CARENS		D 2.0 TCI-D	CODE					X		
KIA	ASIA	2007	CARENS		G 2.0 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	CARENS		G 2.0 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	CARENS		G 2.0 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2007	CARENS		G 2.0 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2007	CARENS		G 2.0 DOHC	ABSESP		X	X	X	X	X	
KIA	ASIA	2007	CARENS		G 2.0 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2007	CARENS		G 2.0 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2007	CARENS		G 2.0 DOHC	BCM		X			X	X	
KIA	ASIA	2007	CARENS		G 2.0 DOHC	IMMO					X		
KIA	ASIA	2007	CARENS		G 2.0 DOHC	CODE					X		
KIA	ASIA	2007	CARENS		G 2.4 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2007	CARENS		G 2.4 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2007	CARENS		G 2.4 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2007	CARENS		G 2.4 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2007	CARENS		G 2.4 DOHC	ABS		X	X	X	X	X	
KIA	ASIA	2007	CARENS		G 2.4 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2007	CARENS		G 2.4 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2007	CARENS		G 2.4 DOHC	BCM		X			X	X	
KIA	ASIA	2007	CARENS		G 2.4 DOHC	IMMO					X		
KIA	ASIA	2007	CARENS		G 2.4 DOHC	CODE					X		
KIA	ASIA	2007	CARENS		D 2.0 TCI-D	ENGINE		X	X	X	X	X	
KIA	ASIA	2007	CARENS		D 2.0 TCI-D	AT		X	X	X	X	X	
KIA	ASIA	2007	CARENS		D 2.0 TCI-D	ABS		X	X	X	X	X	
KIA	ASIA	2007	CARENS		D 2.0 TCI-D	AIRBAG		X	X	X	X		
KIA	ASIA	2007	CARENS		D 2.0 TCI-D	AIRCON		X	X	X	X	X	
KIA	ASIA	2007	CARENS		D 2.0 TCI-D	BCM		X			X	X	
KIA	ASIA	2007	CARENS		D 2.0 TCI-D	IMMO					X		
KIA	ASIA	2007	CARENS		D 2.0 TCI-D	CODE					X		
KIA	ASIA	2006	CARENS		ENGINECONTROL	2.0LDIESEL(CAN)EURO-4		X	X	X	X	X	
KIA	ASIA	2006	CARENS		ENGINECONTROL	2.0LDIESEL(KWP)EURO-4		X	X	X	X	X	
KIA	ASIA	2006	CARENS		ENGINECONTROL	2.0LCVVTALL		X	X	X	X	X	1.FREEZEFRAMEDATA
KIA	ASIA	2006	CARENS		ENGINECONTROL	2.0LDIESELALL(EURO-3)		X	X	X	X	X	
KIA	ASIA	2006	CARENS		ENGINECONTROL	1.6LDOHCEOBD(W/IMMO)			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2006	CARENS		ENGINECONTROL	1.6LDOHCEOBD(NONIMMO)			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2006	CARENS		ENGINECONTROL	1.8LDOHCNONIMMO			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2006	CARENS		ENGINECONTROL	1.8LDOHCW/IMMO			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2006	CARENS		ENGINECONTROL	1.8LDOHCEURO-IV			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2006	CARENS		ENGINECONTROL	1.8LDOHCLEAD			X	X	X		1.FREEZEFRAMEDATA 2.IDLECO ADJUSTMENT
KIA	ASIA	2006	CARENS		AUTOMATIC TRANSAXLE	DISEL		X	X	X	X	X	
KIA	ASIA	2006	CARENS		AUTOMATIC TRANSAXLE	GASOLIN			X	X	X		
KIA	ASIA	2006	CARENS		ANTI-LOCK BRAKESYSTEM	16PINOBD2CONNECTOR		X	X	X	X	X	1.HCUAIRBLEEDING MODE
KIA	ASIA	2006	CARENS		ANTI-LOCK BRAKESYSTEM	20PINREDKIACONNECTOR		X	X	X	X	X	1.HCUAIRBLEEDING MODE
KIA	ASIA	2006	CARENS		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.CRASHING INFORMATION
KIA	ASIA	2006	CARENS		IMMOBILIZER	DISEL					X		
KIA	ASIA	2006	CARENS		IMMOBILIZER	GASOLIN					X		

KIA	ASIA	2006	CARENS		CODESAVING								X
KIA	ASIA	2005	CARENS		ENGINECONTROL	2.0LCVVTALL		X	X	X	X	X	1.FREEZEFRAMEDATA
KIA	ASIA	2005	CARENS		ENGINECONTROL	2.0LDIESELALL		X	X	X	X	X	
KIA	ASIA	2005	CARENS		ENGINECONTROL	1.6LDOHCEOBD(W/IMMO)			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2005	CARENS		ENGINECONTROL	1.6LDOHCEOBD(NONIMMO)			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2005	CARENS		ENGINECONTROL	1.8LDOHCNONIMMO			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2005	CARENS		ENGINECONTROL	1.8LDOHCW/IMMO			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2005	CARENS		ENGINECONTROL	1.8LDOHCEURO-IV			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2005	CARENS		ENGINECONTROL	1.8LDOHCLEAD			X	X	X		1.FREEZEFRAMEDATA 2.IDLECO ADJUSTMENT
KIA	ASIA	2005	CARENS		AUTOMATIC TRANSAXLE	DISEL		X	X	X	X	X	
KIA	ASIA	2005	CARENS		AUTOMATIC TRANSAXLE	GASOLIN			X	X	X		
KIA	ASIA	2005	CARENS		ANTI-LOCK BRAKESYSTEM	16PINOBD2CONNECTOR		X	X	X	X	X	1.HCUAIRBLEEDING MODE
KIA	ASIA	2005	CARENS		ANTI-LOCK BRAKESYSTEM	20PINREDKIACONNECTOR		X	X	X	X	X	1.HCUAIRBLEEDING MODE
KIA	ASIA	2005	CARENS		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.CRASHING INFORMATION
KIA	ASIA	2005	CARENS		IMMOBILIZER	DISEL					X		
KIA	ASIA	2005	CARENS		IMMOBILIZER	GASOLIN					X		
KIA	ASIA	2005	CARENS		CODESAVING								X
KIA	ASIA	2004	CARENS		ENGINECONTROL	2.0LDIESELALL		X	X	X	X	X	
KIA	ASIA	2004	CARENS		ENGINECONTROL	1.6LDOHCEOBD(W/IMMO)			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2004	CARENS		ENGINECONTROL	1.6LDOHCEOBD(NONIMMO)			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2004	CARENS		ENGINECONTROL	1.8LDOHCNONIMMO			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2004	CARENS		ENGINECONTROL	1.8LDOHCW/IMMO			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2004	CARENS		ENGINECONTROL	1.8LDOHCEURO-IV			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2004	CARENS		ENGINECONTROL	1.8LDOHCLEAD			X	X	X		1.FREEZEFRAMEDATA 2.IDLECO ADJUSTMENT
KIA	ASIA	2004	CARENS		AUTOMATIC TRANSAXLE	DISEL		X	X	X	X	X	
KIA	ASIA	2004	CARENS		AUTOMATIC TRANSAXLE	GASOLIN			X	X	X		
KIA	ASIA	2004	CARENS		ANTI-LOCK BRAKESYSTEM	16PINOBD2CONNECTOR		X	X	X	X	X	1.HCUAIRBLEEDING MODE
KIA	ASIA	2004	CARENS		ANTI-LOCK BRAKESYSTEM	20PINREDKIACONNECTOR		X	X	X	X	X	1.HCUAIRBLEEDING MODE
KIA	ASIA	2004	CARENS		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.CRASHING INFORMATION
KIA	ASIA	2004	CARENS		IMMOBILIZER	DISEL					X		
KIA	ASIA	2004	CARENS		IMMOBILIZER	GASOLIN					X		
KIA	ASIA	2004	CARENS		CODESAVING								X
KIA	ASIA	2003	CARENS		ENGINECONTROL	2.0LDIESELALL		X	X	X	X	X	
KIA	ASIA	2003	CARENS		ENGINECONTROL	1.8LDOHCNONIMMO			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2003	CARENS		ENGINECONTROL	1.8LDOHCW/IMMO			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2003	CARENS		ENGINECONTROL	1.8LDOHCEURO-IV			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2003	CARENS		ENGINECONTROL	1.8LDOHCLEAD			X	X	X		1.FREEZEFRAMEDATA 2.IDLECO ADJUSTMENT
KIA	ASIA	2003	CARENS		AUTOMATIC TRANSAXLE	DISEL		X	X	X	X		
KIA	ASIA	2003	CARENS		AUTOMATIC TRANSAXLE	GASOLIN			X	X	X		
KIA	ASIA	2003	CARENS		ANTI-LOCK BRAKESYSTEM	16PINOBD2CONNECTOR		X	X	X	X		1.HCUAIRBLEEDING MODE

KIA	ASIA	2003	CARENS		ANTI-LOCK BRAKESYSTEM	20PINREDKIACONNECTOR		X	X	X	X		1.HCUAIRBLEEDING MODE
KIA	ASIA	2003	CARENS		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.CRASHING INFORMATION
KIA	ASIA	2003	CARENS		IMMOBILIZER	DISEL					X		
KIA	ASIA	2003	CARENS		IMMOBILIZER	GASOLIN					X		
KIA	ASIA	2003	CARENS		CODESAVING								X
KIA	ASIA	2002	CARENS		ENGINECONTROL	1.8LDOHCM/T			X	X	X		1.FREEZEFRAMEDATA 2.MONITORING TEST(EURO.ONLY) 3.VEHICLEINFORM.(EURO.ONLY)
KIA	ASIA	2002	CARENS		ENGINECONTROL	1.8LDOHC			X	X	X		1.FREEZEFRAMEDATA 2.MONITORING TEST(EURO.ONLY) 3.VEHICLEINFORM.(EURO.ONLY)
KIA	ASIA	2002	CARENS		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2002	CARENS		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2002	CARENS		SRS-AIRBAG				X	X			
KIA	ASIA	2001	CARENS		ENGINECONTROL	1.8LDOHCM/T			X	X	X		1.FREEZEFRAMEDATA 2.MONITORING TEST(EURO.ONLY) 3.VEHICLEINFORM.(EURO.ONLY)
KIA	ASIA	2001	CARENS		ENGINECONTROL	1.8LDOHC			X	X	X		1.FREEZEFRAMEDATA 2.MONITORING TEST(EURO.ONLY) 3.VEHICLEINFORM.(EURO.ONLY)
KIA	ASIA	2001	CARENS		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2001	CARENS		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2001	CARENS		SRS-AIRBAG				X	X			
KIA	ASIA	2000	CARENS		ENGINECONTROL	1.8LDOHCGASOLINETED			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2000	CARENS		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2000	CARENS		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2000	CARENS		SRS-AIRBAG				X	X			
KIA	ASIA	1999	CARENS		ENGINECONTROL	1.8LDOHCGASOLINETED			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	1999	CARENS		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	1999	CARENS		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	1999	CARENS		SRS-AIRBAG				X	X			
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	EPS		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	4WD		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	BCM		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	IMMO					X		
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	PIC		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	AHLS		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	SPAS		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	TPMS		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.0 DOHC	CODE					X		
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	

KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	EPS		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	4WD		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	BCM		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	IMMO					X		
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	PIC		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	AHLS		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	SPAS		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	TPMS		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 2.4 DOHC	CODE					X		
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	ENGINE		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	ESP		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	AIRBAG		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	AIRCON		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	EPS		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	4WD		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	BCM		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	IMMO					X		
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	PIC		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	AHLS		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	SPAS		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	TPMS		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		G 1.6 GDI	CODE					X		
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	ENGINE/HIGH POWER (CPF-)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	ENGINE/HIGH POWER (CPF+)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	ENGINE/LOW POWER(CPF+)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	ENGINE/LOW POWER(CPF-)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	AT		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	ESP		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	AIRBAG		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	AIRCON		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	EPS		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	4WD		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	BCM		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	IMMO					X		
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	PIC		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	AHLS		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	SPAS		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	TPMS		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 2.0 TCI-D	CODE					X		
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	ENGINE CONTROL(CPF-)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	ENGINE CONTROL(CPF+)		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	ESP		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	AIRBAG		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	AIRCON		X	X	X	X	X	

KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	EPS		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	4WD		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	BCM		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	IMMO					X		
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	PIC		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	AHLS		X	X	X	X		
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	SPAS		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	TPMS		X	X	X	X	X	
KIA	ASIA	2012	SPORTAGE		D 1.7 TCI-U2	CODE					X		
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	EPS		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	4WD		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	BCM		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	IMMO					X		
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	PIC		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	AHLS		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	SPAS		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	TPMS		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.0 DOHC	CODE					X		
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	EPS		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	4WD		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	BCM		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	IMMO					X		
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	PIC		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	AHLS		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	SPAS		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	TPMS		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 2.4 DOHC	CODE					X		
KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	ENGINE		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	ESP		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	AIRBAG		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	AIRCON		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	EPS		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	4WD		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	BCM		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	IMMO					X		
KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	PIC		X	X	X	X	X	

KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	AHLS		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	SPAS		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	TPMS		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		G 1.6 GDI	CODE					X		
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	ENGINE/HIGH POWER (CPF-)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	ENGINE/HIGH POWER (CPF+)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	ENGINE/LOW POWER(CPF+)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	ENGINE/LOW POWER(CPF-)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	AT		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	ESP		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	AIRBAG		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	AIRCON		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	EPS		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	4WD		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	BCM		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	IMMO					X		
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	PIC		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	AHLS		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	SPAS		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	TPMS		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 2.0 TCI-D	CODE					X		
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	ENGINE CONTROL(CPF-)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	ENGINE CONTROL(CPF+)		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	ESP		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	AIRBAG		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	AIRCON		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	EPS		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	4WD		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	BCM		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	IMMO					X		
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	PIC		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	AHLS		X	X	X	X		
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	SPAS		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	TPMS		X	X	X	X	X	
KIA	ASIA	2011	SPORTAGE		D 1.7 TCI-U2	CODE					X		
KIA	ASIA	2010	SPORTAGE		G 2.0 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		G 2.0 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		G 2.0 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		G 2.0 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		G 2.0 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		G 2.0 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2010	SPORTAGE		G 2.0 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		G 2.0 DOHC	4WD		X	X	X	X		
KIA	ASIA	2010	SPORTAGE		G 2.0 DOHC	ETACS		X			X	X	
KIA	ASIA	2010	SPORTAGE		G 2.0 DOHC	IMMO					X		
KIA	ASIA	2010	SPORTAGE		G 2.0 DOHC	CODE					X		
KIA	ASIA	2010	SPORTAGE		G 2.7 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		G 2.7 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		G 2.7 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		G 2.7 DOHC	AT		X	X	X	X	X	

KIA	ASIA	2010	SPORTAGE		G 2.7 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		G 2.7 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2010	SPORTAGE		G 2.7 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		G 2.7 DOHC	4WD		X	X	X	X		
KIA	ASIA	2010	SPORTAGE		G 2.7 DOHC	ETACS		X			X	X	
KIA	ASIA	2010	SPORTAGE		G 2.7 DOHC	IMMO			X	X	X		
KIA	ASIA	2010	SPORTAGE		G 2.7 DOHC	CODE					X		
KIA	ASIA	2010	SPORTAGE		D 2.0 WGT	ENGINE		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		D 2.0 WGT	AT		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		D 2.0 WGT	ESP		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		D 2.0 WGT	AIRBAG		X	X	X	X		
KIA	ASIA	2010	SPORTAGE		D 2.0 WGT	AIRCON		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		D 2.0 WGT	4WD		X	X	X	X		
KIA	ASIA	2010	SPORTAGE		D 2.0 WGT	ETACS		X			X	X	
KIA	ASIA	2010	SPORTAGE		D 2.0 WGT	IMMO					X		
KIA	ASIA	2010	SPORTAGE		D 2.0 WGT	CODE					X		
KIA	ASIA	2010	SPORTAGE		D 2.0 VGT	ENGINE		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		D 2.0 VGT	AT		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		D 2.0 VGT	ESP		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		D 2.0 VGT	AIRBAG		X	X	X	X		
KIA	ASIA	2010	SPORTAGE		D 2.0 VGT	AIRCON		X	X	X	X	X	
KIA	ASIA	2010	SPORTAGE		D 2.0 VGT	4WD		X	X	X	X		
KIA	ASIA	2010	SPORTAGE		D 2.0 VGT	ETACS		X			X	X	
KIA	ASIA	2010	SPORTAGE		D 2.0 VGT	IMMO					X		
KIA	ASIA	2010	SPORTAGE		D 2.0 VGT	CODE					X		
KIA	ASIA	2009	SPORTAGE		ENGINECONTROL	2.0LDOHCEOBD			X	X	X	X	
KIA	ASIA	2009	SPORTAGE		ENGINECONTROL	2.0LDOHCGEN			X	X	X	X	
KIA	ASIA	2009	SPORTAGE		ENGINECONTROL	2.0LDOHCLEAD			X	X	X	X	
KIA	ASIA	2009	SPORTAGE		ENGINECONTROL	2.7LDOHCEOBD			X	X	X	X	
KIA	ASIA	2009	SPORTAGE		ENGINECONTROL	2.7LDOHCGEN			X	X	X	X	
KIA	ASIA	2009	SPORTAGE		ENGINECONTROL	2.7LDOHCLEAD			X	X	X	X	
KIA	ASIA	2009	SPORTAGE		AUTOMATICTRANSAXLE	2.0DOHC			X	X	X	X	
KIA	ASIA	2009	SPORTAGE		AUTOMATICTRANSAXLE	2.7DOHC			X	X	X	X	
KIA	ASIA	2009	SPORTAGE		ABS/ESP				X	X	X		
KIA	ASIA	2009	SPORTAGE		SRS-AIRBAG				X	X	X		
KIA	ASIA	2008	SPORTAGE		ENGINECONTROL	2.0LDIESEL(CAN)EURO-4		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE		ENGINECONTROL	2.0LDIESEL(KWP)EURO-4			X	X			
KIA	ASIA	2008	SPORTAGE		ENGINECONTROL	2.0LDIESELEURO-3			X	X			
KIA	ASIA	2008	SPORTAGE		ENGINECONTROL	2.0LCVVTBOBD		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE		ENGINECONTROL	2.0LCVVTGEN		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE		ENGINECONTROL	2.0LCVVTLEAD		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE		ENGINECONTROL	2.7LV6EOBD			X	X	X	X	
KIA	ASIA	2008	SPORTAGE		ENGINECONTROL	2.7LV6GEN			X	X		X	
KIA	ASIA	2008	SPORTAGE		ENGINECONTROL	2.7LV6LEAD			X	X		X	
KIA	ASIA	2008	SPORTAGE		AUTOMATICTRANSAXLE	2.0LDIESEL(VGT)EURO-4		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE		AUTOMATICTRANSAXLE	2.0LDIESEL/2.7GASOLINE		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE		AUTOMATICTRANSAXLE	2.0LGASOLINE(PCM)		X	X	X	X	X	
KIA	ASIA	2008	SPORTAGE		ABS/ESP								
KIA	ASIA	2008	SPORTAGE		SRS-AIRBAG			X	X	X			CRASHINGINFORMATION
KIA	ASIA	2008	SPORTAGE		FULLAUTOAIR/CON.			X	X	X			

KIA	ASIA	2008	SPORTAGE		4WHEELDRIVE(4WD)				X				
KIA	ASIA	2008	SPORTAGE		IMMOBILIZER	DIESELALL			X	X			
KIA	ASIA	2008	SPORTAGE		IMMOBILIZER	2.0LCVVTALL			X	X			
KIA	ASIA	2008	SPORTAGE		IMMOBILIZER	2.7LV6ALL			X	X			
KIA	ASIA	2008	SPORTAGE		BODYCONTROLMODULE(ETACS)			X	X	X	X		
KIA	ASIA	2008	SPORTAGE		CODESAVING								X
KIA	ASIA	2007	SPORTAGE		ENGINECONTROL	2.0LDIESEL(CAN)EURO-4		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE		ENGINECONTROL	2.0LDIESEL(KWP)EURO-4			X	X			
KIA	ASIA	2007	SPORTAGE		ENGINECONTROL	2.0LDIESELEURO-3			X	X			
KIA	ASIA	2007	SPORTAGE		ENGINECONTROL	2.0LCVVTBOBD		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE		ENGINECONTROL	2.0LCVVTGEN		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE		ENGINECONTROL	2.0LCVVTLEAD		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE		ENGINECONTROL	2.7LV6BOBD			X	X	X	X	
KIA	ASIA	2007	SPORTAGE		ENGINECONTROL	2.7LV6GEN			X	X		X	
KIA	ASIA	2007	SPORTAGE		ENGINECONTROL	2.7LV6LEAD			X	X		X	
KIA	ASIA	2007	SPORTAGE		AUTOMATICTRANSAXLE	2.0LDIESEL(VGT)EURO-4		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE		AUTOMATICTRANSAXLE	2.0LDIESEL/2.7GASOLINE		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE		AUTOMATICTRANSAXLE	2.0LGASOLINE(PCM)		X	X	X	X	X	
KIA	ASIA	2007	SPORTAGE		ABS/ESP								
KIA	ASIA	2007	SPORTAGE		SRS-AIRBAG			X	X	X			CRASHINGINFORMATION
KIA	ASIA	2007	SPORTAGE		FULLAUTOAIR/CON.			X	X	X			
KIA	ASIA	2007	SPORTAGE		4WHEELDRIVE(4WD)				X				
KIA	ASIA	2007	SPORTAGE		IMMOBILIZER	DIESELALL			X	X			
KIA	ASIA	2007	SPORTAGE		IMMOBILIZER	2.0LCVVTALL			X	X			
KIA	ASIA	2007	SPORTAGE		IMMOBILIZER	2.7LV6ALL			X	X			
KIA	ASIA	2007	SPORTAGE		BODYCONTROLMODULE(ETACS)			X	X	X	X		
KIA	ASIA	2007	SPORTAGE		CODESAVING								X
KIA	ASIA	2006	SPORTAGE		ENGINECONTROL	2.0LDIESEL(CAN)EURO-4		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE		ENGINECONTROL	2.0LDIESEL(KWP)EURO-4			X	X			
KIA	ASIA	2006	SPORTAGE		ENGINECONTROL	2.0LDIESELEURO-3			X	X			
KIA	ASIA	2006	SPORTAGE		ENGINECONTROL	2.0LCVVTBOBD		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2006	SPORTAGE		ENGINECONTROL	2.0LCVVTGEN		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2006	SPORTAGE		ENGINECONTROL	2.0LCVVTLEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2006	SPORTAGE		ENGINECONTROL	2.7LV6BOBD			X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2006	SPORTAGE		ENGINECONTROL	2.7LV6GEN			X	X		X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2006	SPORTAGE		ENGINECONTROL	2.7LV6LEAD			X	X		X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION

KIA	ASIA	2006	SPORTAGE		AUTOMATICTRANSAXLE	2.0LDIESEL(VGT)EURO-4		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE		AUTOMATICTRANSAXLE	2.0LDIESEL/2.7GASOLINE		X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE		AUTOMATICTRANSAXLE	2.0LGASOLINE(PCM)		X	X	X	X	X	1.RESETTING ADAPTIVEVALUES
KIA	ASIA	2006	SPORTAGE		BRAKESYS(ABS/TCS/ESP)			X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE		SRS-AIRBAG			X	X	X			
KIA	ASIA	2006	SPORTAGE		FULLAUTOAIR/CON.			X	X	X	X	X	
KIA	ASIA	2006	SPORTAGE		4WHEELDRIVE(4WD)			X	X	X			
KIA	ASIA	2006	SPORTAGE		IMMOBILIZER	DIESELALL					X		
KIA	ASIA	2006	SPORTAGE		IMMOBILIZER	2.0LCVVTALL					X		
KIA	ASIA	2006	SPORTAGE		IMMOBILIZER	2.7LV6ALL			X	X	X		
KIA	ASIA	2006	SPORTAGE		BODYCONTROLMODULE(ETA CS)			X			X	X	
KIA	ASIA	2006	SPORTAGE		CODESAVING								X
KIA	ASIA	2005	SPORTAGE		ENGINECONTROL	2.0LDISELALL		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE		ENGINECONTROL	2.0LCVVTBOBD		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2005	SPORTAGE		ENGINECONTROL	2.0LCVVTGEN		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2005	SPORTAGE		ENGINECONTROL	2.0LCVVTLEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2005	SPORTAGE		ENGINECONTROL	2.7LV6EOBD		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2005	SPORTAGE		ENGINECONTROL	2.7LV6GEN		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2005	SPORTAGE		ENGINECONTROL	2.7LV6LEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2005	SPORTAGE		AUTOMATICTRANSAXLE	2.0LDIESEL/2.7GASOLINE		X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE		AUTOMATICTRANSAXLE	2.0LGASOLINE(PCM)		X	X	X	X	X	1.RESETTING ADAPTIVEVALUES
KIA	ASIA	2005	SPORTAGE		BRAKESYS(ABS/TCS/ESP)			X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE		SRS-AIRBAG			X	X	X			
KIA	ASIA	2005	SPORTAGE		FULLAUTOAIR/CON.			X	X	X	X	X	
KIA	ASIA	2005	SPORTAGE		4WHEELDRIVE(4WD)			X	X	X			
KIA	ASIA	2005	SPORTAGE		IMMOBILIZER	DIESELALL							
KIA	ASIA	2005	SPORTAGE		IMMOBILIZER	2.0LCVVTALL					X		
KIA	ASIA	2005	SPORTAGE		IMMOBILIZER	2.7LV6ALL			X	X	X		
KIA	ASIA	2005	SPORTAGE		BODYCONTROLMODULE(ETA CS)			X			X	X	
KIA	ASIA	2005	SPORTAGE		CODESAVING								X
KIA	ASIA	2003	SPORTAGE		ENGINECONTROL	2.0LDOHC(AFM)BOSCH			X	X	X		1.FREEZEFRAMEDATA 2.MONITORING TEST(EURO.ONLY) 3.VEHICLE INFORM(EURO.ONLY)
KIA	ASIA	2003	SPORTAGE		ENGINECONTROL	2.0LDOHC(HFM)LEAD			X	X	X	X	
KIA	ASIA	2003	SPORTAGE		ENGINECONTROL	2.0LDIESELRF-TCI			X	Manual			
KIA	ASIA	2003	SPORTAGE		AUTOMATIC TRANSAXLE	TCUGASOLINE			X	X	X		

KIA	ASIA	2003	SPORTAGE		AUTOMATIC TRANSAXLE	TCUDIESEL			X	X	X		
KIA	ASIA	2003	SPORTAGE		ANTI-LOCK BRAKESYSTEM	ABSGASOLINE		X	X	X	X	X	1.HCUAIRBLEEDINGMODE
KIA	ASIA	2003	SPORTAGE		ANTI-LOCK BRAKESYSTEM	ABSDIESEL		X	X	X	X	X	1.HCUAIRBLEEDINGMODE
KIA	ASIA	2003	SPORTAGE		IMMOBILIZER						X		Normal coding Neutralization Code change Key only matching
KIA	ASIA	2002	SPORTAGE		ENGINECONTROL	2.OLDOHC(AFM)BOSCH			X	X	X		1.FREEZEFRAMEDATA 2.MONITORING TEST(EURO.ONLY) 3.VEHICLE INFORM(EURO.ONLY)
KIA	ASIA	2002	SPORTAGE		ENGINECONTROL	2.OLDOHC(HFM)LEAD			X	X	X	X	
KIA	ASIA	2002	SPORTAGE		ENGINECONTROL	2.OLDIESELRF-TCI			X	Manual			
KIA	ASIA	2002	SPORTAGE		AUTOMATIC TRANSAXLE	TCUGASOLINE			X	X	X		
KIA	ASIA	2002	SPORTAGE		AUTOMATIC TRANSAXLE	TCUDIESEL			X	X	X		
KIA	ASIA	2002	SPORTAGE		ANTI-LOCK BRAKESYSTEM	ABSGASOLINE		X	X	X	X	X	1.HCUAIRBLEEDINGMODE
KIA	ASIA	2002	SPORTAGE		ANTI-LOCK BRAKESYSTEM	ABSDIESEL		X	X	X	X	X	1.HCUAIRBLEEDINGMODE
KIA	ASIA	2002	SPORTAGE		IMMOBILIZER						X		Normal coding Neutralization Code change Key only matching
KIA	ASIA	2001	SPORTAGE		ENGINECONTROL	2.OLDOHC(AFM)BOSCH			X	X	X		1.FREEZEFRAMEDATA 2.MONITORING TEST(EURO.ONLY) 3.VEHICLE INFORM(EURO.ONLY)
KIA	ASIA	2001	SPORTAGE		ENGINECONTROL	2.OLDOHC(HFM)LEAD			X	X	X	X	
KIA	ASIA	2001	SPORTAGE		ENGINECONTROL	2.OLDIESELRF-TCI			X	Manual			
KIA	ASIA	2001	SPORTAGE		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2001	SPORTAGE		ANTI-LOCK BRAKESYSTEM	ABSGASOLINE		X	X	X	X	X	1.HCUAIRBLEEDINGMODE
KIA	ASIA	2001	SPORTAGE		ANTI-LOCK BRAKESYSTEM	ABSDIESEL		X	X	X	X	X	1.HCUAIRBLEEDINGMODE
KIA	ASIA	2001	SPORTAGE		IMMOBILIZER						X		Normal coding Neutralization Code change Key only matching
KIA	ASIA	2000	SPORTAGE		ENGINECONTROL	2.OLDOHC(HFM)UNLEAD			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2000	SPORTAGE		ENGINECONTROL	UNLEAD(AUS)			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	2000	SPORTAGE		ENGINECONTROL	2.OLDOHC(HFM)UNLEAD			X	X	X	X	
KIA	ASIA	2000	SPORTAGE		ENGINECONTROL	2.OLDIESELRF-TCI			X	Manual			
KIA	ASIA	2000	SPORTAGE		AUTOMATIC TRANSAXLE	GASOLIN/DIESEL			X	X	X		
KIA	ASIA	2000	SPORTAGE		AUTOMATIC TRANSAXLE	UNLEAD(AUS)			X	X	X		
KIA	ASIA	2000	SPORTAGE		IMMOBILIZER						X		Normal coding Neutralization Code change Key only matching
KIA	ASIA	1999	SPORTAGE		ENGINECONTROL	2.OLDOHC(AFM)BOSCH			X	X	X		1.FREEZEFRAMEDATA 2.MONITORING TEST(EURO.ONLY) 3.VEHICLE INFORM(EURO.ONLY)
KIA	ASIA	1999	SPORTAGE		ENGINECONTROL	2.OLDOHC(HFM)LEAD			X	X	X	X	
KIA	ASIA	1999	SPORTAGE		ENGINECONTROL	2.OLDIESELRF-TCI			X	Manual			
KIA	ASIA	1999	SPORTAGE		AUTOMATIC TRANSAXLE				X	X	X		

KIA	ASIA	1999	SPORTAGE		IMMOBILIZER						X		Normal coding Neutralization Code change Key only matching
KIA	ASIA	1998	SPORTAGE		ENGINECONTROL	2.OLDOHC(AFM)BOSCH			X	X	X		1.FREEZEFRAMEDATA 2.MONITORING TEST(EURO.ONLY) 3.VEHICLE INFORM(EURO.ONLY)
KIA	ASIA	1998	SPORTAGE		ENGINECONTROL	2.OLDOHC(HFM)LEAD			X	X	X	X	
KIA	ASIA	1998	SPORTAGE		ENGINECONTROL	2.OLDIESELRF-TCI			X	Manual			
KIA	ASIA	1998	SPORTAGE		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	1998	SPORTAGE		IMMOBILIZER						X		Normal coding Neutralization Code change Key only matching
KIA	ASIA	2000	CLARUS		ENGINECONTROL	1.8LGASOLINE		X	X	X	X	X	
KIA	ASIA	2000	CLARUS		ENGINECONTROL	2.0LGASOLINE		X	X	X	X	X	
KIA	ASIA	2000	CLARUS		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	2000	CLARUS		ANTI-LOCK BRAKESYSTEM				X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2000	CLARUS		SRS-AIRBAG				X	X			
KIA	ASIA	1999	CLARUS		ENGINECONTROL	1.8LGASOLINE		X	X	X	X	X	
KIA	ASIA	1999	CLARUS		ENGINECONTROL	2.0LGASOLINE		X	X	X	X	X	
KIA	ASIA	1999	CLARUS		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	1999	CLARUS		ANTI-LOCK BRAKESYSTEM				X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	1999	CLARUS		SRS-AIRBAG				X	X			
KIA	ASIA	1998	CLARUS		ENGINECONTROL	1.8LGASOLINE		X	X	X	X	X	
KIA	ASIA	1998	CLARUS		ENGINECONTROL	2.0LGASOLINE		X	X	X	X	X	
KIA	ASIA	1998	CLARUS		AUTOMATIC TRANSAXLE				X	X	X		
KIA	ASIA	1998	CLARUS		ANTI-LOCK BRAKESYSTEM				X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	1998	CLARUS		SRS-AIRBAG				X	X			
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.7 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.7 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.7 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.7 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.7 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.7 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.7 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.7 DOHC	ECS		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.7 DOHC	BCM		X			X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.7 DOHC	IMMO					X		
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.7 DOHC	PIC		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.7 DOHC	CODE					X		
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.0 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.0 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.0 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.0 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.0 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.0 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.0 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.0 DOHC	ECS		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.0 DOHC	BCM		X			X	X	

KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.0 DOHC	IMMO					X		
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.0 DOHC	PIC		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.0 DOHC	CODE					X		
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.4 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.4 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.4 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.4 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.4 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.4 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.4 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.4 DOHC	ECS		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.4 DOHC	BCM		X			X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.4 DOHC	IMMO					X		
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.4 DOHC	PIC		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		G 2.4 DOHC	CODE					X		
KIA	ASIA	2010	OPTIMA (MAGENTIS)		D 2.0 TCI-D	ENGINE		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		D 2.0 TCI-D	AT		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		D 2.0 TCI-D	ESP		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		D 2.0 TCI-D	AIRBAG		X	X	X	X		
KIA	ASIA	2010	OPTIMA (MAGENTIS)		D 2.0 TCI-D	AIRCON		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		D 2.0 TCI-D	ECS		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		D 2.0 TCI-D	BCM		X			X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		D 2.0 TCI-D	IMMO					X		
KIA	ASIA	2010	OPTIMA (MAGENTIS)		D 2.0 TCI-D	PIC		X	X	X	X	X	
KIA	ASIA	2010	OPTIMA (MAGENTIS)		D 2.0 TCI-D	CODE					X		
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.7 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.7 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.7 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.7 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.7 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.7 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.7 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.7 DOHC	ECS		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.7 DOHC	BCM		X			X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.7 DOHC	IMMO					X		
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.7 DOHC	PIC		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.7 DOHC	CODE					X		
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.0 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.0 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.0 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.0 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.0 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.0 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.0 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.0 DOHC	ECS		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.0 DOHC	BCM		X			X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.0 DOHC	IMMO					X		
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.0 DOHC	PIC		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.0 DOHC	CODE					X		
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.4 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	

KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.4 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.4 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.4 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.4 DOHC	ESP		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.4 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.4 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.4 DOHC	ECS		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.4 DOHC	BCM		X			X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.4 DOHC	IMMO					X		
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.4 DOHC	PIC		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		G 2.4 DOHC	CODE					X		
KIA	ASIA	2009	OPTIMA (MAGENTIS)		D 2.0 TCI-D	ENGINE		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		D 2.0 TCI-D	AT		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		D 2.0 TCI-D	ESP		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		D 2.0 TCI-D	AIRBAG		X	X	X	X		
KIA	ASIA	2009	OPTIMA (MAGENTIS)		D 2.0 TCI-D	AIRCON		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		D 2.0 TCI-D	ECS		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		D 2.0 TCI-D	BCM		X			X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		D 2.0 TCI-D	IMMO					X		
KIA	ASIA	2009	OPTIMA (MAGENTIS)		D 2.0 TCI-D	PIC		X	X	X	X	X	
KIA	ASIA	2009	OPTIMA (MAGENTIS)		D 2.0 TCI-D	CODE					X		
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.7 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.7 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.7 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.7 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.7 DOHC	ABS		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.7 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.7 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.7 DOHC	ECS		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.7 DOHC	BCM		X			X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.7 DOHC	IMMO					X		
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.7 DOHC	CODE					X		
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.0 DOHC	ENGINE/Unleaded GEN		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.0 DOHC	ENGINE/Unleaded EOBD		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.0 DOHC	ENGINE/Leaded All		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.0 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.0 DOHC	ABS		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.0 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.0 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.0 DOHC	ECS		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.0 DOHC	BCM		X			X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.0 DOHC	IMMO					X		
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.0 DOHC	CODE					X		
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.4 DOHC	ENGINE		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.4 DOHC	AT		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.4 DOHC	ABS		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.4 DOHC	AIRBAG		X	X	X	X		
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.4 DOHC	AIRCON		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.4 DOHC	ECS		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.4 DOHC	BCM		X			X	X	

KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.4 DOHC	IMMO					X		
KIA	ASIA	2008	OPTIMA (MAGENTIS)		G 2.4 DOHC	CODE					X		
KIA	ASIA	2008	OPTIMA (MAGENTIS)		D 2.0 TCI-D	ENGINE		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		D 2.0 TCI-D	AT		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		D 2.0 TCI-D	ESP		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		D 2.0 TCI-D	AIRBAG		X	X	X	X		
KIA	ASIA	2008	OPTIMA (MAGENTIS)		D 2.0 TCI-D	AIRCON		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		D 2.0 TCI-D	ECS		X	X	X	X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		D 2.0 TCI-D	BCM		X			X	X	
KIA	ASIA	2008	OPTIMA (MAGENTIS)		D 2.0 TCI-D	IMMO					X		
KIA	ASIA	2008	OPTIMA (MAGENTIS)		D 2.0 TCI-D	CODE					X		
KIA	ASIA	2007	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDIESEL(VGT)EURO-4		X	X	X	X	X	
KIA	ASIA	2007	OPTIMA (MAGENTIS)		ENGINECONTROL	UNLEAD2.0LEOBD		X	X	X	X	X	
KIA	ASIA	2007	OPTIMA (MAGENTIS)		ENGINECONTROL	UNLEAD2.0LGEN		X	X	X	X	X	1.RESETTING ADAPTIVE VALUES 2.VERSION CONFIGUREATION
KIA	ASIA	2007	OPTIMA (MAGENTIS)		ENGINECONTROL	LEAD2.0LALL		X	X	X	X	X	
KIA	ASIA	2007	OPTIMA (MAGENTIS)		ENGINECONTROL	UNLEAD2.4LEOBD		X	X	X	X	X	
KIA	ASIA	2007	OPTIMA (MAGENTIS)		ENGINECONTROL	UNLEAD2.7LEOBD		X	X	X	X	X	
KIA	ASIA	2007	OPTIMA (MAGENTIS)		ENGINECONTROL	UNLEAD2.7LGEN		X	X	X	X	X	
KIA	ASIA	2007	OPTIMA (MAGENTIS)		ENGINECONTROL	LEAD2.7LALL		X	X	X	X	X	
KIA	ASIA	2007	OPTIMA (MAGENTIS)		AUTOMATICTRANSAXLE	2.0LDIESEL(VGT)EURO-4		X	X	X	X	X	
KIA	ASIA	2007	OPTIMA (MAGENTIS)		AUTOMATICTRANSAXLE	2.0LCVVT		X	X	X	X	X	
KIA	ASIA	2007	OPTIMA (MAGENTIS)		AUTOMATICTRANSAXLE	2.4LCVVT		X	X	X	X	X	
KIA	ASIA	2007	OPTIMA (MAGENTIS)		AUTOMATICTRANSAXLE	2.7LCVVT		X	X	X	X	X	
KIA	ASIA	2007	OPTIMA (MAGENTIS)		ANTI-LOCKBRAKESYSTEM								
KIA	ASIA	2007	OPTIMA (MAGENTIS)		SRS-AIRBAG			X	X	X			1.CRASHINGINFORMATION
KIA	ASIA	2007	OPTIMA (MAGENTIS)		CODESAVING								X
KIA	ASIA	2006	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDIESEL(VGT)EURO-4		X	X	X	X	X	
KIA	ASIA	2006	OPTIMA (MAGENTIS)		ENGINECONTROL	UNLEAD2.0LEOBD		X	X	X	X	X	
KIA	ASIA	2006	OPTIMA (MAGENTIS)		ENGINECONTROL	UNLEAD2.0LGEN		X	X	X	X	X	
KIA	ASIA	2006	OPTIMA (MAGENTIS)		ENGINECONTROL	LEAD2.0LALL		X	X	X	X	X	
KIA	ASIA	2006	OPTIMA (MAGENTIS)		ENGINECONTROL	UNLEAD2.4LEOBD		X	X	X	X	X	
KIA	ASIA	2006	OPTIMA (MAGENTIS)		ENGINECONTROL	UNLEAD2.7LEOBD			X	X	X	X	
KIA	ASIA	2006	OPTIMA (MAGENTIS)		ENGINECONTROL	UNLEAD2.7LGEN			X	X	X	X	
KIA	ASIA	2006	OPTIMA (MAGENTIS)		ENGINECONTROL	LEAD2.7LALL			X	X	X	X	
KIA	ASIA	2006	OPTIMA (MAGENTIS)		AUTOMATICTRANSAXLE	2.0LDIESEL(VGT)EURO-4		X	X	X	X	X	
KIA	ASIA	2006	OPTIMA (MAGENTIS)		AUTOMATICTRANSAXLE	2.7LCVVT			X	X	X	X	
KIA	ASIA	2006	OPTIMA (MAGENTIS)		ANTI-LOCKBRAKESYSTEM								
KIA	ASIA	2006	OPTIMA (MAGENTIS)		SRS-AIRBAG			X	X	X			1.CRASHINGINFORMATION
KIA	ASIA	2006	OPTIMA (MAGENTIS)		CODESAVING								X
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		ENGINECONTROL	1.8LGASOLINE		X	X	X	X	X	
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		ENGINECONTROL	2.7LV6GASOLINE		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6(Tio2)EURO-III		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6(Zio2)EURO-III		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION

KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6GENERAL		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6LEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		ENGINECONTROL	2.4DOHCMELCO			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCA/TMELCO			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCA/TLEAD			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCM/TMELCO			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCM/TLEAD			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		AUTOMATIC TRANSAXLE	TCUFOR2.5L/2.7LGASOL.		X	X	X	X	X	
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		AUTOMATIC TRANSAXLE	TCUFOR2.4LGASOLINE		X	X	X	X	X	
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		AUTOMATIC TRANSAXLE	TCUFOR2.0LGASOLINE		X	X	X	X	X	
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	2004~2005	OPTIMA (MAGENTIS)		CODESAVING								X
KIA	ASIA	2003	OPTIMA (MAGENTIS)		ENGINECONTROL	2.7LV6GASOLINE		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2003	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6(Tio2)EURO-III		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2003	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6(Zio2)EURO-III		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2003	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6GENERAL		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2003	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6LEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2003	OPTIMA (MAGENTIS)		ENGINECONTROL	2.4DOHCMELCO			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2003	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCA/TMELCO			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2003	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCA/TLEAD			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2003	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCM/TMELCO			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2003	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCM/TLEAD			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2003	OPTIMA (MAGENTIS)		AUTOMATIC TRANSAXLE	TCUFOR2.5L/2.7LGASOL.		X	X	X	X	X	
KIA	ASIA	2003	OPTIMA (MAGENTIS)		AUTOMATIC TRANSAXLE	TCUFOR2.4LGASOLINE		X	X	X	X	X	
KIA	ASIA	2003	OPTIMA (MAGENTIS)		AUTOMATIC TRANSAXLE	TCUFOR2.0LGASOLINE		X	X	X	X	X	
KIA	ASIA	2003	OPTIMA (MAGENTIS)		ANTI-LOCK BRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2003	OPTIMA (MAGENTIS)		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	2003	OPTIMA (MAGENTIS)		CODESAVING								X
KIA	ASIA	2002	OPTIMA (MAGENTIS)		ENGINECONTROL	2.7LV6GASOLINE		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION

KIA	ASIA	2002	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6(Tio2)EURO-III		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2002	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6(Zio2)EURO-III		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2002	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6GENERAL		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2002	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6LEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGUREATION
KIA	ASIA	2002	OPTIMA (MAGENTIS)		ENGINECONTROL	2.4DOHCMELCO			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2002	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCA/TMELCO			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2002	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCA/TLEAD			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2002	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCM/TMELCO			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2002	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCM/TLEAD			X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2002	OPTIMA (MAGENTIS)		AUTOMATIC TRANSAXLE	TCUFOR2.5L/2.7LGASOL.		X	X	X	X	X	
KIA	ASIA	2002	OPTIMA (MAGENTIS)		AUTOMATIC TRANSAXLE	TCUFOR2.4LGASOLINE		X	X	X	X	X	
KIA	ASIA	2002	OPTIMA (MAGENTIS)		AUTOMATIC TRANSAXLE	TCUFOR2.0LGASOLINE		X	X	X	X	X	
KIA	ASIA	2002	OPTIMA (MAGENTIS)		ANTI-LOCK BRAKESYSTEM				X	X	X	X	1.HCUAIRBLEEDINGMODE
KIA	ASIA	2002	OPTIMA (MAGENTIS)		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6EURO-III		X	X	X	X	X	
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6GENERAL		X	X	X	X	X	
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		ENGINECONTROL	2.5LV6LEAD		X	X	X	X	X	
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		ENGINECONTROL	2.4LDOHCMELCO			X	X	X	X	
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCA/TMELCO			X	X	X	X	
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCA/TLEAD			X	X	X	X	
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCM/TMELCO			X	X	X	X	
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		ENGINECONTROL	2.0LDOHCM/TLEAD			X	X	X	X	
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		AUTOMATICTRANSAXLE	TCUFOR2.5LGASOL.		X	X	X	X	X	
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		AUTOMATICTRANSAXLE	TCUFOR2.4LGASOLINE		X	X	X	X	X	
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		AUTOMATICTRANSAXLE	TCUFOR2.0LGASOLINE		X	X	X	X	X	
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		ANTI-LOCK BRAKESYSTEM				X	X	X	X	1.HCUAIRBLEEDINGMODE
KIA	ASIA	2000~2001	OPTIMA (MAGENTIS)		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	1998	ELAN		ENGINECONTROL				X	X	X	X	
KIA	ASIA	1998	ELAN		SRS-AIRBAG				X	X			
KIA	ASIA	1997	ELAN		ENGINECONTROL				X	X	X	X	
KIA	ASIA	1997	ELAN		SRS-AIRBAG				X	X			
KIA	ASIA	All Model year	POTENTIA		ENGINECONTROL	2.0LDOHC(HFM)UNLEAD			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	All Model year	POTENTIA		ENGINECONTROL	2.0LDOHC(HFM)LEAD		X	X	X	X	X	
KIA	ASIA	All Model year	POTENTIA		AUTOMATICTRANSAXLE				X	Manual			
KIA	ASIA	All Model year	POTENTIA		ANTI-LOCKBRAKESYSTEM	ABS5			X	X	X	X	
KIA	ASIA	All Model year	POTENTIA		ANTI-LOCKBRAKESYSTEM	ABS/ASR5(INCULDETCs)			X	X	X	X	
KIA	ASIA	All Model year	ENTERPRISE		ENGINECONTROL	2.5LGASOLINEJ5D			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	All Model year	ENTERPRISE		ENGINECONTROL	3.0LGASOLINEJED			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	All Model year	ENTERPRISE		ENGINECONTROL	OBD-II98-99MY			X	X	X		1.FREEZEFRAME DATA
KIA	ASIA	All Model year	ENTERPRISE		AUTOMATICTRANSAXLE				X	Manual			

KIA	ASIA	All Model year	ENTERPRISE		ANTI-LOCKBRAKESYSTEM	3.0LGASOLINEJED			X	X	X	X	
KIA	ASIA	All Model year	ENTERPRISE		ANTI-LOCKBRAKESYSTEM	3.6LGASOLINEJ6D			X	X	X	X	
KIA	ASIA	2007	CARNIVAL(SEDONA)		ENGIENCONTROL	2.7/3.8LGASOLINEEOBD		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL(SEDONA)		ENGIENCONTROL	2.7/3.8LGASOLINEGEN		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL(SEDONA)		ENGIENCONTROL	2.7/3.8LGASOLINELEAD		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL(SEDONA)		ENGIENCONTROL	J2.9VGT(DIESEL)C/RAIL		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL(SEDONA)		ENGIENCONTROL	J2.9WGT (DIESEL) C/RAIL		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU2.7/3.8L(GASOLINE)		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU2.7/3.8L(DIESEL)		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU2.9WGT(DIESEL)		X	X	X	X	X	
KIA	ASIA	2007	CARNIVAL(SEDONA)		ANTI-SKIDBRAKESYSTEM								
KIA	ASIA	2007	CARNIVAL(SEDONA)		SRS-AIRBAG	LONGBODYAIRBAG							1.CRASHINGINFORMATION
KIA	ASIA	2007	CARNIVAL(SEDONA)		SRS-AIRBAG	SHORTBODYAIRBAG							1.CRASHINGINFORMATINO
KIA	ASIA	2007	CARNIVAL(SEDONA)		CODESAVING								X
KIA	ASIA	2006	CARNIVAL(SEDONA)		ENGINECONTROL	2.7/3.8LGASOLINEEOBD			X	X	X	X	
KIA	ASIA	2006	CARNIVAL(SEDONA)		ENGINECONTROL	2.7/3.8LGASOLINEGEN			X	X	X	X	
KIA	ASIA	2006	CARNIVAL(SEDONA)		ENGINECONTROL	2.7/3.8LGASOLINELEAD			X	X	X	X	
KIA	ASIA	2006	CARNIVAL(SEDONA)		ENGINECONTROL	J2.9VGT(DIESEL)C/RAIL		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(SEDONA)		ENGINECONTROL	J2.9WGT (DIESEL) C/RAIL		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU2.7/3.8L(GASOLINE)		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU2.9WGT (DIESEL)		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU2.9VGT(DIESEL)		X	X	X	X	X	
KIA	ASIA	2006	CARNIVAL(SEDONA)		ANTI-SKIDBRAKESYSTEM								
KIA	ASIA	2006	CARNIVAL(SEDONA)		SRS-AIRAG								
KIA	ASIA	2006	CARNIVAL(SEDONA)		CODESAVING								X
KIA	ASIA	2005	CARNIVAL(SEDONA)		ENGINECONTROL	3.5LGASOLINECHINA		X	X	X	X	X	1.FREEZEFRAMEDATA 2.IDLERPMADJUSTNODE
KIA	ASIA	2005	CARNIVAL(SEDONA)		ENGINECONTROL	3.5LGASOLINEM/EAST		X	X	X	X	X	1.FREEZEFRAMEDATA 2.IDLERPMADJUSTNODE
KIA	ASIA	2005	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LV6EURO-III		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LGASOLINEKV6			X	X	X	X	
KIA	ASIA	2005	CARNIVAL(SEDONA)		ENGINECONTROL	2.9LDIESEL C/RAIL		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(SEDONA)		ENGINECONTROL	3.0LDIESELJ3TCI			X	Manual			
KIA	ASIA	2005	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	3.5LGASOLINEM/EAST		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	GASOLIN		X	X	X	X	X	
KIA	ASIA	2005	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	DIESEL			X	X	X	X	
KIA	ASIA	2005	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABS		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2005	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABSEURO-III		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2005	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABSC/RAIL		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2005	CARNIVAL(SEDONA)		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	2004	CARNIVAL(SEDONA)		ENGINECONTROL	3.5LGASOLINEM/EAST		X	X	X	X	X	1.FREEZEFRAMEDATA 2.IDLERPMADJUSTNODE
KIA	ASIA	2004	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LV6EURO-III		X	X	X	X	X	
KIA	ASIA	2004	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LGASOLINEKV6			X	X	X	X	
KIA	ASIA	2004	CARNIVAL(SEDONA)		ENGINECONTROL	2.9LDIESEL C/RAIL		X	X	X	X	X	
KIA	ASIA	2004	CARNIVAL(SEDONA)		ENGINECONTROL	3.0LDIESELJ3TCI			X	Manual			
KIA	ASIA	2004	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	3.5LGASOLINEM/EAST		X	X	X	X	X	
KIA	ASIA	2004	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	GASOLIN		X	X	X	X	X	

KIA	ASIA	2004	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	DIESEL			X	X	X	X	
KIA	ASIA	2004	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABS		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2004	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABSEURO-III		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2004	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABSC/RAIL		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2004	CARNIVAL(SEDONA)		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	2003	CARNIVAL(SEDONA)		ENGINECONTROL	3.5LGASOLINEM/EAST		X	X	X	X	X	1.FREEZEFRAMEDATA 2.IDLERPMADJUSTNODE
KIA	ASIA	2003	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LV6EURO-III		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LGASOLINEKV6			X	X	X	X	
KIA	ASIA	2003	CARNIVAL(SEDONA)		ENGINECONTROL	2.9LDIESEL/RAIL		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(SEDONA)		ENGINECONTROL	3.0LDIESELJ3TCI			X	Manual			
KIA	ASIA	2003	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	3.5LGASOLINEM/EAST		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	GASOLIN		X	X	X	X	X	
KIA	ASIA	2003	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	DIESEL			X	X	X	X	
KIA	ASIA	2003	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABS		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2003	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABSEURO-III		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2003	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABSC/RAIL		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2003	CARNIVAL(SEDONA)		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	2002	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LV6EURO-III		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LGASOLINEKV6			X	X	X	X	
		2002	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LGASOLINE(GENERAL)KV6			X	X	X	X	1.IDLECO ADJUSTMENT
KIA	ASIA	2002	CARNIVAL(SEDONA)		ENGINECONTROL	2.9LDIESEL/RAIL		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(SEDONA)		ENGINECONTROL	3.0LDIESELJ3TCI			X	Manual			
		2002	CARNIVAL(SEDONA)		ENGINECONTROL	3.0LDIESEL(GEN.)J4TCI			X	Manual			
KIA	ASIA	2002	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	GASOLIN		X	X	X	X	X	
KIA	ASIA	2002	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	DIESEL			X	X	X	X	
KIA	ASIA	2002	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABS		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2002	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABSEURO-III		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2002	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABSC/RAIL		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2002	CARNIVAL(SEDONA)		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LGASOLINE(EUROPE)KV6			X	X	X	X	
KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LGASOLINE(GENERAL)KV6			X	X	X	X	1.IDLECO ADJUSTMENT
KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		ENGINECONTROL	3.0LDIESEL(EUROPE)J3TCI			X	Manual			
KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		ENGINECONTROL	3.0LDIESEL(GEN.)J4TCI			X	Manual			
KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU(GENERAL)GAS		X	X	X	X	X	
KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU(EUROPE)GAS		X	X	X	X	X	
KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU(GENERAL)DIESEL			X	X	X		
KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU(EUROPE)DIESEL			X	X	X		
KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABS(EUROPE)		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABS(GENERAL)GAS		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABS(GENERAL)DIESEL		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		SRS-AIRBAG	A/BAG(EUROPE)		X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION

KIA	ASIA	2000~2001	CARNIVAL(SEDONA)		SRS-AIRBAG	A/BAG(GENERAL)		X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LGASOLINE(EUROPE)KV6			X	X	X	X	
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		ENGINECONTROL	2.5LGASOLINE(GENERAL)KV6			X	X	X	X	1.IDLECO ADJUSTMENT
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		ENGINECONTROL	3.0LDIESEL(EUROPE)J3TCI			X	Manual			
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		ENGINECONTROL	3.0LDIESEL(GEN.)J4TCI			X	Manual			
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU(GENERAL)GAS		X	X	X	X	X	
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU(EUROPE)GAS		X	X	X	X	X	
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU(GENERAL)DIESEL			X	X	X		
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		AUTOMATICTRANSAXLE	TCU(EUROPE)DIESEL			X	X	X		
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABS(EUROPE)		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABS(GENERAL)GAS		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		ANTI-LOCKBRAKESYSTEM	ABS(GENERAL)DIESEL		X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		SRS-AIRBAG	A/BAG(EUROPE)		X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	1998~1999	CARNIVAL(SEDONA)		SRS-AIRBAG	A/BAG(GENERAL)		X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	All Model year	RETONA		ENGINECONTROL	2.0LGASOLINE			X	X	X		1.FREEZEFRAMEDATA
KIA	ASIA	All Model year	RETONA		ENGINECONTROL	2.0LDIESELRF-TCI			X	Manual			
KIA	ASIA	All Model year	RETONA		AUTOMATICTRANSAXLE				X	X	X		
KIA	ASIA	All Model year	JOICE		ENGINECONTROL	2.0LGASOLINEEURO-III			X	X	X	X	1.FREEZEFRAMEDATA
KIA	ASIA	All Model year	JOICE		ANTI-LOCKBRAKESYSTEM				X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	All Model year	JOICE		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	2006	PREGIO(BESTA)		ENGINECONTROL	2.5LDIESEL(4D56TCI)		X	X	X	X	X	
KIA	ASIA	2004~2005	PREGIO(BESTA)		ENGINECONTROL	2.5LDIESEL(4D56TCI)		X	X	X	X	X	
KIA	ASIA	2003	PREGIO(BESTA)		ENGINECONTROL	2.5LDIESEL(4D56TCI)		X	X	X	X	X	
KIA	ASIA	2002	PREGIO(BESTA)		ENGINECONTROL	2.5LDIESEL(4D56TCI)		X	X	X	X	X	
KIA	ASIA	2008	K2500/K2900		ENGINECONTROL	J2.9WGT(DIESEL)C/RAIL		X	X	X	X	X	
KIA	ASIA	2007	K2500/K2900		ENGINECONTROL	2.5LDIESEL(4D56TCI)		X	X	X	X	X	
KIA	ASIA	2006	K2500/K2900		ENGINECONTROL	2.5LDIESEL(4D56TCI)		X	X	X	X	X	
KIA	ASIA	2004~2005	K2500/K2900		ENGINECONTROL	2.5LDIESEL(4D56TCI)		X	X	X	X	X	
KIA	ASIA	2003	K2500/K2900		ENGINECONTROL	2.5LDIESEL(4D56TCI)		X	X	X	X	X	
KIA	ASIA	2002	K2500/K2900		ENGINECONTROL	2.5LDIESEL(4D56TCI)		X	X	X	X	X	
KIA	ASIA	2011	SORENTO		ENGINECONTROL	UNLEAD 2.4L EOBD			X	X	X	X	
KIA	ASIA	2011	SORENTO		ENGINECONTROL	UNLEAD 2.4L GEN			X	X	X	X	
KIA	ASIA	2011	SORENTO		ENGINECONTROL	LEAD 2.4L ALL			X	X	X	X	
KIA	ASIA	2011	SORENTO		AUTOMATICTRANSAXLE				X	X	X	X	
KIA	ASIA	2011	SORENTO		ANTI-LOCKBRAKESYSTEM				X	X	X		
KIA	ASIA	2011	SORENTO		SRS-AIRBAG				X	X	X		
KIA	ASIA	2010	SORENTO		ENGINECONTROL	UNLEAD 2.4L EOBD			X	X	X	X	
KIA	ASIA	2010	SORENTO		ENGINECONTROL	UNLEAD 2.4L GEN			X	X	X	X	
KIA	ASIA	2010	SORENTO		ENGINECONTROL	LEAD 2.4L ALL			X	X	X	X	
KIA	ASIA	2010	SORENTO		AUTOMATICTRANSAXLE				X	X	X	X	
KIA	ASIA	2010	SORENTO		ANTI-LOCKBRAKESYSTEM				X	X	X		
KIA	ASIA	2010	SORENTO		SRS-AIRBAG				X	X	X		
KIA	ASIA	2009	SORENTO		ENGINECONTROL	UNLEAD 2.4L EOBD			X	X	X	X	

KIA	ASIA	2009	SORENTO		ENGINECONTROL	UNLEAD 2.4L GEN			X	X	X	X	
KIA	ASIA	2009	SORENTO		ENGINECONTROL	LEAD 2.4L ALL			X	X	X	X	
KIA	ASIA	2009	SORENTO		AUTOMATICTRANSAXLE				X	X	X	X	
KIA	ASIA	2009	SORENTO		ANTI-LOCKBRAKESYSTEM				X	X	X		
KIA	ASIA	2009	SORENTO		SRS-AIRBAG				X	X	X		
KIA	ASIA	2008	SORENTO		ENGINECONTROL	UNLEAD3.3L/3.8LEOBD		X	X	X	X	X	
KIA	ASIA	2008	SORENTO		ENGINECONTROL	UNLEAD3.3L/3.8LGEN		X	X	X	X	X	
KIA	ASIA	2008	SORENTO		ENGINECONTROL	LEAD3.3L/3.8LALL		X	X	X	X	X	
KIA	ASIA	2008	SORENTO		ENGINECONTROL	2.5LDIESEL(CAN)EURO-4		X	X	X	X	X	
KIA	ASIA	2008	SORENTO		AUTOMATICTRANSAXLE	GASOLINE(CAN)BOSCH		X	X	X	X	X	
KIA	ASIA	2008	SORENTO		ANTI-LOCKBRAKESYSTEM			X	X	X	X		
KIA	ASIA	2008	SORENTO		SRS-AIRBAG			X	X	X	X		
KIA	ASIA	2007	SORENTO		ENGINECONTROL	UNLEAD3.3L/3.8LEOBD		X	X	X	X	X	
KIA	ASIA	2007	SORENTO		ENGINECONTROL	UNLEAD3.3L/3.8LGEN		X	X	X	X	X	
KIA	ASIA	2007	SORENTO		ENGINECONTROL	LEAD3.3L/3.8LALL		X	X	X	X	X	
KIA	ASIA	2007	SORENTO		ENGINECONTROL	2.5LDIESEL(CAN)EURO-4		X	X	X	X	X	
KIA	ASIA	2007	SORENTO		AUTOMATICTRANSAXLE	GASOLINE(CAN)BOSCH		X	X	X	X	X	
KIA	ASIA	2007	SORENTO		ANTI-LOCKBRAKESYSTEM			X	X	X	X		
KIA	ASIA	2007	SORENTO		SRS-AIRBAG			X	X	X	X		
KIA	ASIA	2007	SORENTO		CODESAVING								X
KIA	ASIA	2004~2005	SORENTO		ENGINECONTROL	ENGINEDIESEL(A-ENG)		X	X	X	X	X	
KIA	ASIA	2004~2005	SORENTO		ENGINECONTROL	3.5LV6GASOLINEALL		X	X	X	X	X	1.FREEZEFRAME DATA 2.IDLERPMADJUST MODE
KIA	ASIA	2004~2005	SORENTO		ENGINECONTROL	2.4LGASOLINEUNLEAD		X	X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2004~2005	SORENTO		ENGINECONTROL	2.4LGASOLINELEAD		X	X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2004~2005	SORENTO		AUTOMATICTRANSAXLE	AUTO.TRANSAXLE(4GEARS)		X	X	X	X	X	
KIA	ASIA	2004~2005	SORENTO		AUTOMATICTRANSAXLE	AUTO.TRANSAXLE(5GEARS)		X	X	X	X		
KIA	ASIA	2004~2005	SORENTO		ANTI-LOCKBRAKESYSTEM			X	X	X	X	X	
KIA	ASIA	2004~2005	SORENTO		SRS-AIRBAG			X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	2004~2005	SORENTO		ELEC.POWERSTEERING			X	X	X	X		
KIA	ASIA	2004~2005	SORENTO		4WHEELDRIVE(4WD)	4WD(TOD-AUTO)			X	X			
KIA	ASIA	2004~2005	SORENTO		FUELFIREDEHEATER				X	X	X	X	
KIA	ASIA	2004~2005	SORENTO		CODESAVING								X
KIA	ASIA	2003	SORENTO		ENGINECONTROL	ENGINEDIESEL(A-ENG)		X	X	X	X	X	
KIA	ASIA	2003	SORENTO		ENGINECONTROL	3.5LV6GASOLINEALL		X	X	X	X	X	1.FREEZEFRAME DATA 2.IDLERPMADJUST MODE
KIA	ASIA	2003	SORENTO		ENGINECONTROL	2.4LGASOLINEUNLEAD		X	X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2003	SORENTO		ENGINECONTROL	2.4LGASOLINELEAD		X	X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2003	SORENTO		AUTOMATICTRANSAXLE			X	X	X	X	X	
KIA	ASIA	2003	SORENTO		ANTI-LOCKBRAKESYSTEM			X	X	X	X		
KIA	ASIA	2003	SORENTO		SRS-AIRBAG			X	X	X	X	X	
KIA	ASIA	2003	SORENTO		ELEC.POWERSTEERING			X	X	X	X		1.ACTIVEDTC INFORMATION 2.HISTORYDTC INFORMATION
KIA	ASIA	2003	SORENTO		4WHEELDRIVE(4WD)	4WD(TOD-AUTO)		X	X	X	X		
KIA	ASIA	2003	SORENTO		FUELFIREDEHEATER				X	X			
KIA	ASIA	2003	SORENTO		CODESAVING								X
KIA	ASIA	2007	OPIRUS(AMANTI)		ENGINECONTROL	GASOLINEEOBD		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(AMANTI)		ENGINECONTROL	GASOLINEGEN		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(AMANTI)		ENGINECONTROL	GASOLINELEAD		X	X	X	X	X	

KIA	ASIA	2007	OPIRUS(AMANTI)		AUTOMATICTRANSAXLE	GASOLINE		X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(AMANTI)		BRAKESYS(ABS/TCS/ESP)			X	X	X	X	X	
KIA	ASIA	2007	OPIRUS(AMANTI)		SRS-AIRBAG			X	X	X	X		1.HISTORYDTC INFORMATION 2.CRASHING INFORMATION
KIA	ASIA	2006	OPIRUS(AMANTI)		ENGINECONTROL	2.7LV6EOBD		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(AMANTI)		ENGINECONTROL	2.7LV6GEN		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(AMANTI)		ENGINECONTROL	2.7LV6LEAD		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(AMANTI)		ENGINECONTROL	3.5LEOBD		X	X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2006	OPIRUS(AMANTI)		ENGINECONTROL	3.5LV6GEN		X	X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2006	OPIRUS(AMANTI)		AUTOMATICTRANSAXLE			X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(AMANTI)		BRAKESYS(ABS/TCS/ESP)			X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(AMANTI)		SRS-AIRBAG			X	X	X	X		1.HISTORYDTC INFORMATION 2.CRASHING INFORMATION
KIA	ASIA	2006	OPIRUS(AMANTI)		BODYELECTRIC.SYS(ETAC)	BODY CONTROL MODULE		X	X	X	X	X	
KIA	ASIA	2006	OPIRUS(AMANTI)		BODYELECTRIC.SYS(ETAC)	DRIVER POWER WINDOW			X	X	X	X	
KIA	ASIA	2006	OPIRUS(AMANTI)		BODYELECTRIC.SYS(ETAC)	PASSENGER POWER WINDOW			X	X	X	X	
KIA	ASIA	2006	OPIRUS(AMANTI)		BODYELECTRIC.SYS(ETAC)	DRIVER POWER SEAT			X	X	X	X	
KIA	ASIA	2006	OPIRUS(AMANTI)		BODYELECTRIC.SYS(ETAC)	TILT & TELESCOPE			X	X	X	X	
KIA	ASIA	2006	OPIRUS(AMANTI)		IMMOBILIZER						X		
KIA	ASIA	2004~2005	OPIRUS(AMANTI)		ENGINECONTROL	3.5LV6EOBD		X	X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2004~2005	OPIRUS(AMANTI)		ENGINECONTROL	3.5LV6GEN		X	X	X	X	X	1.FREEZEFRAME DATA
KIA	ASIA	2004~2005	OPIRUS(AMANTI)		ENGINECONTROL	2.7LV6EOBD		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGURATION
KIA	ASIA	2004~2005	OPIRUS(AMANTI)		ENGINECONTROL	2.7LV6GEN		X	X	X	X	X	1.FREEZEFRAMEDATA 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGURATION
KIA	ASIA	2004~2005	OPIRUS(AMANTI)		ENGINECONTROL	2.7LV6LEAD		X	X	X	X	X	1.IDLECO ADJUSTMENT 2.RESETTING ADAPTIVEVALUES 3.VERSION CONFIGURATION 4.FREEZEFRAMEDATA
KIA	ASIA	2004~2005	OPIRUS(AMANTI)		BODYELECTRIC.SYS(ETAC)	BODY CONTROL MODULE		X	X	X	X	X	
KIA	ASIA	2004~2005	OPIRUS(AMANTI)		BODYELECTRIC.SYS(ETAC)	DRIVER POWER WINDOW			X	X	X	X	
KIA	ASIA	2004~2005	OPIRUS(AMANTI)		BODYELECTRIC.SYS(ETAC)	PASSENGER POWER WINDOW			X	X	X	X	
KIA	ASIA	2004~2005	OPIRUS(AMANTI)		BODYELECTRIC.SYS(ETAC)	DRIVER POWER SEAT			X	X	X	X	
KIA	ASIA	2004~2005	OPIRUS(AMANTI)		BODYELECTRIC.SYS(ETAC)	TILT & TELESCOPE			X	X	X	X	
KIA	ASIA	2004~2005	OPIRUS(AMANTI)		IMMOBILIZER						X		
KIA	ASIA	2004~2006	BONGO-III		ENGINECONTROL(DIESEL)			X	X	X	X	X	
KIA	ASIA	2004~2006	BONGO-III		ANTI-LOCKBRAKESYSTEM			X	X	X	X	X	1.HCUAIR BLEEDINGMODE
KIA	ASIA	2007	CEE'D		ENGINECONTROL	BETA2.0L		X	X	X	X	X	
KIA	ASIA	2007	CEE'D		ENGINECONTROL	GAMMA1.4L/1.6L		X	X	X	X	X	
KIA	ASIA	2007	CEE'D		ENGINECONTROL	U1.6LDIESEL(-CPF)		X	X	X	X	X	
KIA	ASIA	2007	CEE'D		ENGINECONTROL	U1.6LDIESEL(+CPF)		X	X	X	X	X	
KIA	ASIA	2007	CEE'D		ENGINECONTROL	2.0LDIESEL(CAN)EURO-4		X	X	X	X	X	
KIA	ASIA	2007	CEE'D		AUTOMATCITRANSAXLE	1.4/1.6GASOLINE		X	X	X	X	X	
KIA	ASIA	2007	CEE'D		AUTOMATCITRANSAXLE	2.0LGASOLIN		X	X	X	X	X	
KIA	ASIA	2007	CEE'D		CODESAVING								X

KIA	ASIA	2010	BORREGO		ENGINECONTROL	G3.8DOHC			X	X	X	X	
KIA	ASIA	2010	BORREGO		ENGINECONTROL	G4.6DOHC			X	X	X	X	
KIA	ASIA	2009	BORREGO		ENGINECONTROL	G3.8DOHC			X	X	X	X	
KIA	ASIA	2009	BORREGO		ENGINECONTROL	G4.6DOHC			X	X	X	X	
KIA	ASIA	2010	BORREGO		AUTOMATCITRANSAXLE	G3.8DOHC			X	X	X	X	
KIA	ASIA	2010	BORREGO		AUTOMATCITRANSAXLE	G4.6DOHC			X	X	X	X	
KIA	ASIA	2009	BORREGO		AUTOMATCITRANSAXLE	G3.8DOHC			X	X	X	X	
KIA	ASIA	2009	BORREGO		AUTOMATCITRANSAXLE	G4.6DOHC			X	X	X	X	