

How to read this list:	
Mark	Description
X	Function is supported.
*	Function is added or developed newly

Function List													
Automaker:				HOLDEN									
Software Version:				V2.3									
Brand	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions
HOLDEN	ALL	2011	VE and WM Series	ALL	ALL	Engine(V6 Engine)		*	*	*	*	*	1.Fuel Trim Reset 2.Reset Engine Oil Life 3.Throttle Body Relearn
HOLDEN	ALL	2011	VE and WM Series	ALL	ALL	Engine(V8 GENIV)		*	*	*	*	*	
HOLDEN	ALL	2011	VE and WM Series	ALL	ALL	Transmission(Automatic Transmission)		*	*	*	*	*	
HOLDEN	ALL	2011	VE and WM Series	ALL	ALL	Chassis(EBCM (Electronic Brake Control Module))		*	*	*	*	*	Calibrate Steering Angle Sensor
HOLDEN	ALL	2011	VE and WM Series	ALL	ALL	Body(BCM (Body Control Module))		*	*	*	*	*	
HOLDEN	ALL	2011	VE and WM Series	ALL	ALL	Body(RFA (Remote Function Actuator))		*	*	*	*	*	
HOLDEN	ALL	2011	VE and WM Series	ALL	ALL	Body(SDM (Sensing and Diagnostic Module))		*	*	*	*	*	
HOLDEN	ALL	2011	VE and WM Series	ALL	ALL	Body(IPC (Instrument Panel Cluster))		*	*	*	*	*	1.Reset Service Interval
HOLDEN	ALL	2011	VE and WM Series	ALL	ALL	Body(HVAC (Heating Ventilation And Cooling))		*	*	*	*	*	1.Calibrate HVAC Doors 2.Blower Operating Time Reset
HOLDEN	ALL	2011	VE and WM Series	ALL	ALL	Body(Park Assist)		*	*	*	*	*	
HOLDEN	ALL	2011	VE and WM Series	ALL	ALL	Infotainment System(Audio System)		*	*	*	*	*	
HOLDEN	ALL	2010	VE and WM Series	ALL	ALL	Engine(V6 Engine)		*	*	*	*	*	1.Fuel Trim Reset 2.Reset Engine Oil Life 3.Throttle Body Relearn
HOLDEN	ALL	2010	VE and WM Series	ALL	ALL	Engine(V8 GENIV)		*	*	*	*	*	
HOLDEN	ALL	2010	VE and WM Series	ALL	ALL	Transmission(Automatic Transmission)		*	*	*	*	*	
HOLDEN	ALL	2010	VE and WM Series	ALL	ALL	Chassis(EBCM (Electronic Brake Control Module))		*	*	*	*	*	Calibrate Steering Angle Sensor
HOLDEN	ALL	2010	VE and WM Series	ALL	ALL	Body(BCM (Body Control Module))		*	*	*	*	*	
HOLDEN	ALL	2010	VE and WM Series	ALL	ALL	Body(RFA (Remote Function Actuator))		*	*	*	*	*	
HOLDEN	ALL	2010	VE and WM Series	ALL	ALL	Body(SDM (Sensing and Diagnostic Module))		*	*	*	*	*	
HOLDEN	ALL	2010	VE and WM Series	ALL	ALL	Body(IPC (Instrument Panel Cluster))		*	*	*	*	*	1.Reset Service Interval
HOLDEN	ALL	2010	VE and WM Series	ALL	ALL	Body(HVAC (Heating Ventilation And Cooling))		*	*	*	*	*	1.Calibrate HVAC Doors 2.Blower Operating Time Reset

HOLDEN	ALL	2010	VE and WM Series	ALL	ALL	Body(Park Assist)		*	*	*	*	*	
HOLDEN	ALL	2010	VE and WM Series	ALL	ALL	Infotainment System(Audio System)		*	*	*	*	*	
HOLDEN	ALL	2009	VE and WM Series	ALL	ALL	Engine(V6 Engine)		*	*	*	*	*	1.Fuel Trim Reset 2.Reset Engine Oil Life 3.Throttle Body Relearn
HOLDEN	ALL	2009	VE and WM Series	ALL	ALL	Engine(V8 GENIV)		*	*	*	*	*	
HOLDEN	ALL	2009	VE and WM Series	ALL	ALL	Transmission(Automatic Transmission)		*	*	*	*	*	
HOLDEN	ALL	2009	VE and WM Series	ALL	ALL	Chassis(EBCM (Electronic Brake Control Module))		*	*	*	*	*	Calibrate Steering Angle Sensor
HOLDEN	ALL	2009	VE and WM Series	ALL	ALL	Body(BCM (Body Control Module))		*	*	*	*	*	
HOLDEN	ALL	2009	VE and WM Series	ALL	ALL	Body(RFA (Remote Function Actuator))		*	*	*	*		
HOLDEN	ALL	2009	VE and WM Series	ALL	ALL	Body(SDM (Sensing and Diagnostic Module))		*	*	*	*		
HOLDEN	ALL	2009	VE and WM Series	ALL	ALL	Body(IPC (Instrument Panel Cluster))		*	*	*	*	*	1.Reset Service Interval
HOLDEN	ALL	2009	VE and WM Series	ALL	ALL	Body(HVAC (Heating Ventilation And Cooling))		*	*	*	*	*	1.Calibrate HVAC Doors 2.Blower Operating Time Reset
HOLDEN	ALL	2009	VE and WM Series	ALL	ALL	Body(Park Assist)		*	*	*	*	*	
HOLDEN	ALL	2009	VE and WM Series	ALL	ALL	Infotainment System(Audio System)		*	*	*	*	*	
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	Engine(V6 Engine)		X	X	X	X	X	1.Fuel Trim Reset 2.Reset Engine Oil Life 3.Throttle Body Relearn
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	Engine(V8 GENIV)		X	X	X	X	X	
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	1.Fuel Gauge Calibration 2.Configuration 3.Reset Service Interval 4.Reset Trip Computer Settings
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	Chassis(EBCM (Electronic Brake Control Module))		X	X	X	X	X	
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	Body(BCM (Body Control Module))		X	X	X	X	X	
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	Body(Theft Deterrent)		X	X	X	X		
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	Body(RFA (Remote Function Actuator))		X	X	X	X		
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	Body(SDM (Sensing and Diagnostic Module))		X	X	X	X		
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	Body(IPC (Instrument Panel Cluster))		X	X	X	X	X	1.Reset Service Interval
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	Body(HVAC (Heating Ventilation And Cooling))		X	X	X	X	X	1.Calibrate HVAC Doors 2.Blower Operating Time Reset
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	Body(Park Assist)		X	X	X	X	X	
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	Infotainment System(Audio System)		X	X	X	X	X	
HOLDEN	ALL	2008	VE and WM Series	ALL	ALL	SIC (Secondary Information Centre)		X	X	X	X		1.Learn VIN 2.Display Type
HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Engine(V6 Engine)		X	X	X	X	X	1.Fuel Trim Reset 2.Reset Engine Oil Life 3.Throttle Body Relearn
HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Engine(V8 GENIV)		X	X	X	X	X	



SERVICE SOLUTIONS

HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	1.Fuel Gauge Calibration 2.Configuration 3.Reset Service Interval 4.Reset Trip Computer Settings
HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Chassis(EBCM (Electronic Brake Control Module))		X	X	X	X	X	
HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Body(BCM (Body Control Module))		X	X	X	X	X	
HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Body(Theft Deterrent)		X	X	X	X		
HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Body(RFA (Remote Function Actuator))		X	X	X	X		
HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Body(SDM (Sensing and Diagnostic Module))		X	X	X	X		
HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Body(IPC (Instrument Panel Cluster))		X	X	X	X	X	1.Reset Service Interval
HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Body(HVAC (Heating Ventilation And Cooling))		X	X	X	X	X	1.Calibrate HVAC Doors 2.Blower Operating Time Reset
HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Body(Park Assist)		X	X	X	X	X	
HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Infotainment System(Audio System)		X	X	X	X	X	
HOLDEN	ALL	2007	VE and WM Series	ALL	ALL	Infotainment System(SIC (Secondary Information Centre))		X	X	X	X		1.Learn VIN 2.Display Type
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Engine(V6 Engine)		X	X	X	X	X	1.Fuel Trim Reset 2.Reset Engine Oil Life 3.Throttle Body Relearn
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	1.Reset Engine Oil Life
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Engine(V8 GEN IV)		X	X	X	X	X	1.Reset Engine Oil Life
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	1.Fuel Gauge Calibration 2.Configuration 3.Reset Service Interval 4.Reset Trip Computer Settings
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Chassis(ABS/TC/ESP 8.0)		X	X	X	X	X	
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	1.User Settings 2.Options 3.Key Program
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Body(SRS)		X	X	X	X		
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Body(Instrument)		X	X	X	X	X	1.Fuel Gauge Calibration 2.Configuration 3.Reset Service Interval 4.Reset Trip Computer Settings
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Body(Occupant Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2006	VZ and WL Series	ALL	ALL	Body(Audio System)		X	X	X	X	X	
HOLDEN	ALL	2005	VZ and WL Series	ALL	ALL	Engine(V6 Engine)		X	X	X	X	X	1.Fuel Trim Reset 2.Reset Engine Oil Life 3.Throttle Body Relearn
HOLDEN	ALL	2005	VZ and WL Series	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	1.Reset Engine Oil Life

HOLDEN	ALL	2005	VZ and WL Series	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	1.Fuel Gauge Calibration 2.Configuration 3.Reset Service Interval 4.Reset Trip Computer Settings
HOLDEN	ALL	2005	VZ and WL Series	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2005	VZ and WL Series	ALL	ALL	Chassis(ABS/TC/ESP 8.0)		X	X	X	X	X	
HOLDEN	ALL	2005	VZ and WL Series	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
HOLDEN	ALL	2005	VZ and WL Series	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	1.User Settings 2.Options 3.Key Program
HOLDEN	ALL	2005	VZ and WL Series	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2005	VZ and WL Series	ALL	ALL	Body(SRS)		X	X	X	X		
HOLDEN	ALL	2005	VZ and WL Series	ALL	ALL	Body(Instrument)		X	X	X	X	X	1.Fuel Gauge Calibration 2.Configuration 3.Reset Service Interval 4.Reset Trip Computer Settings
HOLDEN	ALL	2005	VZ and WL Series	ALL	ALL	Body(Occupant Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2005	VZ and WL Series	ALL	ALL	Body(Audio System)		X	X	X	X	X	
HOLDEN	ALL	2004	VY Series	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2004	VY Series	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2004	VY Series	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2004	VY Series	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2004	VY Series	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
HOLDEN	ALL	2004	VY Series	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	1.User Settings 2.Options 3.Key Program
HOLDEN	ALL	2004	VY Series	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2004	VY Series	ALL	ALL	Body(SRS)		X	X	X	X		
HOLDEN	ALL	2004	VY Series	ALL	ALL	Body(Instrument)		X	X	X	X	X	1.Fuel Gauge Calibration 2.Configuration 3.Reset Service Interval 4.Reset Trip Computer Settings 5.Reset to Vehicle Build Settings
HOLDEN	ALL	2004	VY Series	ALL	ALL	Body(Occupant Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2004	VY Series	ALL	ALL	Body(Audio System)		X	X	X	X	X	
HOLDEN	ALL	2004	WK Series	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2004	WK Series	ALL	ALL	(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2004	WK Series	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2004	WK Series	ALL	ALL	(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2004	WK Series	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	

HOLDEN	ALL	2004	WK Series	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	1.User Settings 2.Options 3.Key Program
HOLDEN	ALL	2004	WK Series	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2004	WK Series	ALL	ALL	Body(SRS)		X	X	X	X		
HOLDEN	ALL	2004	WK Series	ALL	ALL	Body(Instrument)		X	X	X	X	X	1.Fuel Gauge Calibration 2.Configuration 3.Reset Service Interval 4.Reset Trip Computer Settings 5.Reset to Vehicle Build Settings
HOLDEN	ALL	2004	WK Series	ALL	ALL	Body(Occupant Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2004	WK Series	ALL	ALL	Body(Audio System)		X	X	X	X	X	
HOLDEN	ALL	2004	V2 Series	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2004	V2 Series	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2004	V2 Series	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2004	V2 Series	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2004	V2 Series	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
HOLDEN	ALL	2004	V2 Series	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	1.User Settings 2.Options 3.Key Program
HOLDEN	ALL	2004	V2 Series	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2004	V2 Series	ALL	ALL	Body(SRS)		X	X	X	X		
HOLDEN	ALL	2004	V2 Series	ALL	ALL	Body(Instrument)		X	X	X	X	X	1.Fuel Gauge Calibration 2.Configuration 3.Reset Service Interval 4.Reset Trip Computer Settings 5.Reset to Vehicle Build Settings
HOLDEN	ALL	2004	V2 Series	ALL	ALL	Body(Occupant Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2004	V2 Series	ALL	ALL	Body(Audio System)		X	X	X	X	X	
HOLDEN	ALL	2003	VY Series	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2003	VY Series	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2003	VY Series	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2003	VY Series	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2003	VY Series	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
HOLDEN	ALL	2003	VY Series	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	1.User Settings 2.Options 3.Key Program
HOLDEN	ALL	2003	VY Series	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2003	VY Series	ALL	ALL	Body(SRS)		X	X	X	X		

													1.Fuel Gauge Calibration 2.Configuration 3.Reset Service Interval 4.Reset Trip Computer Settings 5.Reset to Vehicle Build Settings
HOLDEN	ALL	2003	VY Series	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	2003	VY Series	ALL	ALL	Body(Occupant Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2003	VY Series	ALL	ALL	Body(Audio System)		X	X	X	X	X	
HOLDEN	ALL	2003	V2 Series	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2003	V2 Series	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2003	V2 Series	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2003	V2 Series	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2003	V2 Series	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
HOLDEN	ALL	2003	V2 Series	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	1.User Settings 2.Options 3.Key Program
HOLDEN	ALL	2003	V2 Series	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2003	V2 Series	ALL	ALL	Body(SRS)		X	X	X	X		
HOLDEN	ALL	2003	V2 Series	ALL	ALL	Body(Instrument)		X	X	X	X	X	1.Fuel Gauge Calibration 2.Configuration 3.Reset Service Interval 4.Reset Trip Computer Settings 5.Reset to Vehicle Build Settings
HOLDEN	ALL	2003	V2 Series	ALL	ALL	Body(Occupant Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2003	V2 Series	ALL	ALL	Body(Audio System)		X	X	X	X	X	3.Reset Service Interval
HOLDEN	ALL	2003	WH Statesman & Caprice	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2003	WH Statesman & Caprice	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2003	WH Statesman & Caprice	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2003	WH Statesman & Caprice	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2003	WH Statesman & Caprice	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
HOLDEN	ALL	2003	WH Statesman & Caprice	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	1.Rear Wiper Control 2.Antenna Height Memory 3.Two Stage Unlock 4.Set Key To Priority 1 5.Twilight Sentinel 6.Battery Saver Shut Down Time 7.Pre Delivery Mode 8.Ignition Off Courtesy Lamp 9.Approach Illumination 10.BCM Link To PCM 11.Key Program
HOLDEN	ALL	2003	WH Statesman & Caprice	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2003	WH Statesman & Caprice	ALL	ALL	Body(SRS)		X	X	X	X		

													1. Instrument Configuration 2. Options 3. Reset Service Interval 4. Reset User Calibration 5. Fuel Gauge Calibration
HOLDEN	ALL	2003	WH Statesman & Caprice	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	2003	WH Statesman & Caprice	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2002	VX Commodore	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2002	VX Commodore	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2002	VX Commodore	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2002	VX Commodore	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2002	VX Commodore	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
													1. Rear Wiper Control 2. Antenna Height Memory 3. Two Stage Unlock 4. Set Key To Priority 1 5. Twilight Sentinel 6. Battery Saver Shut Down Time 7. Pre Delivery Mode 8. Ignition Off Courtesy Lamp 9. Approach Illumination 10. BCM Link To PCM 11. Key Program
HOLDEN	ALL	2002	VX Commodore	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	2002	VX Commodore	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2002	VX Commodore	ALL	ALL	Body(SRS)		X	X	X	X		
													1. Instrument Configuration 2. Options 3. Reset Service Interval 4. Reset User Calibration 5. Fuel Gauge Calibration
HOLDEN	ALL	2002	VX Commodore	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	2002	VX Commodore	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2002	VU Utility	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2002	VU Utility	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2002	VU Utility	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2002	VU Utility	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2002	VU Utility	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	

													1 .Rear Wiper Control 2 .Antenna Height Memory 3 .Two Stage Unlock 4 .Set Key To Priority 1 5 .Twilight Sentinel 6 .Battery Saver Shut Down Time 7 .Pre Delivery Mode 8 .Ignition Off Courtesy Lamp 9 .Approach Illumination 10. BCM Link To PCM 11. Key Program
HOLDEN	ALL	2002	VU Utility	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	2002	VU Utility	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2002	VU Utility	ALL	ALL	Body(SRS)		X	X	X	X		
													1. Instrument Configuration 2. Options 3. Reset Service Interval 4. Reset User Calibration 5. Fuel Gauge Calibration
HOLDEN	ALL	2002	VU Utility	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	2002	VU Utility	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2002	V2 Series	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2002	V2 Series	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2002	V2 Series	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2002	V2 Series	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2002	V2 Series	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
													1 .Rear Wiper Control 2 .Antenna Height Memory 3 .Two Stage Unlock 4 .Set Key To Priority 1 5 .Twilight Sentinel 6 .Battery Saver Shut Down Time 7 .Pre Delivery Mode 8 .Ignition Off Courtesy Lamp 9 .Approach Illumination 10. BCM Link To PCM 11. Key Program
HOLDEN	ALL	2002	V2 Series	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	2002	V2 Series	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2002	V2 Series	ALL	ALL	Body(SRS)		X	X	X	X		
													1. Instrument Configuration 2. Options 3. Reset Service Interval 4. Reset User Calibration 5. Fuel Gauge Calibration
HOLDEN	ALL	2002	V2 Series	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	2002	V2 Series	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2002	WH Statesman & Caprice	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2002	WH Statesman & Caprice	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	

HOLDEN	ALL	2002	WH Statesman & Caprice	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2002	WH Statesman & Caprice	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2002	WH Statesman & Caprice	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
													1 .Rear Wiper Control 2 .Antenna Height Memory 3 .Two Stage Unlock 4 .Set Key To Priority 1 5 .Twilight Sentinel 6 .Battery Saver Shut Down Time 7 .Pre Delivery Mode 8 .Ignition Off Courtesy Lamp 9 .Approach Illumination 10.BCM Link To PCM 11.Key Program
HOLDEN	ALL	2002	WH Statesman & Caprice	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	2002	WH Statesman & Caprice	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2002	WH Statesman & Caprice	ALL	ALL	Body(SRS)		X	X	X	X		
													1.Instrument Configuration 2.Options 3.Reset Service Interval 4.Reset User Calibration 5.Fuel Gauge Calibration
HOLDEN	ALL	2002	WH Statesman & Caprice	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	2002	WH Statesman & Caprice	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2001	VX Commodore	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2001	VX Commodore	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2001	VX Commodore	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2001	VX Commodore	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2001	VX Commodore	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
													1 .Rear Wiper Control 2 .Antenna Height Memory 3 .Two Stage Unlock 4 .Set Key To Priority 1 5 .Twilight Sentinel 6 .Battery Saver Shut Down Time 7 .Pre Delivery Mode 8 .Ignition Off Courtesy Lamp 9 .Approach Illumination 10.BCM Link To PCM 11.Key Program
HOLDEN	ALL	2001	VX Commodore	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	2001	VX Commodore	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2001	VX Commodore	ALL	ALL	Body(SRS)		X	X	X	X		
													1.Instrument Configuration 2.Options 3.Reset Service Interval 4.Reset User Calibration 5.Fuel Gauge Calibration
HOLDEN	ALL	2001	VX Commodore	ALL	ALL	Body(Instrument)		X	X	X	X	X	

HOLDEN	ALL	2001	VX Commodore	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2001	VU Utility	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2001	VU Utility	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2001	VU Utility	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2001	VU Utility	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2001	VU Utility	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
													1 .Rear Wiper Control 2 .Antenna Height Memory 3 .Two Stage Unlock 4 .Set Key To Priority 1 5 .Twilight Sentinel 6 .Battery Saver Shut Down Time 7 .Pre Delivery Mode 8 .Ignition Off Courtesy Lamp 9 .Approach Illumination 10. BCM Link To PCM 11.Key Program
HOLDEN	ALL	2001	VU Utility	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	2001	VU Utility	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2001	VU Utility	ALL	ALL	Body(SRS)		X	X	X	X		
													1. Instrument Configuration 2.Options 3.Reset Service Interval 4.Reset User Calibration 5.Fuel Gauge Calibration
HOLDEN	ALL	2001	VU Utility	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	2001	VU Utility	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2001	WH Statesman & Caprice	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2001	WH Statesman & Caprice	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2001	WH Statesman & Caprice	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2001	WH Statesman & Caprice	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2001	WH Statesman & Caprice	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
													1 .Rear Wiper Control 2 .Antenna Height Memory 3 .Two Stage Unlock 4 .Set Key To Priority 1 5 .Twilight Sentinel 6 .Battery Saver Shut Down Time 7 .Pre Delivery Mode 8 .Ignition Off Courtesy Lamp 9 .Approach Illumination 10. BCM Link To PCM 11.Key Program
HOLDEN	ALL	2001	WH Statesman & Caprice	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	2001	WH Statesman & Caprice	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2001	WH Statesman & Caprice	ALL	ALL	Body(SRS)		X	X	X	X		



SERVICE SOLUTIONS

													1. Instrument Configuration 2. Options 3. Reset Service Interval 4. Reset User Calibration 5. Fuel Gauge Calibration
HOLDEN	ALL	2001	WH Statesman & Caprice	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	2001	WH Statesman & Caprice	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Engine(V6 Supercharged)		X	X	X	X	X	
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Engine(V8)		X	X	X	X	X	
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Engine(V6 LPG)		X	X	X	X	X	
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
													1 .Rear Wiper Control 2 .Antenna Height Memory 3 .Two Stage Unlock 4 .Set Key To Priority 1 5 .Twilight Sentinel 6 .Battery Saver Shut Down Time 7 .Pre Delivery Mode 8 .Ignition Off Courtesy Lamp 9 .Approach Illumination 10. BCM Link To PCM 11. Key Program
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Body(SRS)		X	X	X	X		
													1. Instrument Configuration 2. Options 3. Reset Service Interval 4. Reset User Calibration 5. Fuel Gauge Calibration
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	2000	VT Commodore	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Engine(V6 Supercharged)		X	X	X	X	X	
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Engine(V8)		X	X	X	X	X	
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Engine(V6 LPG)		X	X	X	X	X	
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	

													1 .Rear Wiper Control 2 .Antenna Height Memory 3 .Two Stage Unlock 4 .Set Key To Priority 1 5 .Twilight Sentinel 6 .Battery Saver Shut Down Time 7 .Pre Delivery Mode 8 .Ignition Off Courtesy Lamp 9 .Approach Illumination 10.BCM Link To PCM 11.Key Program
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Body(SRS)		X	X	X	X		
													1.Instrument Configuration 2.Options 3.Reset Service Interval 4.Reset User Calibration 5.Fuel Gauge Calibration
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	2000	WH Statesman & Caprice	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Engine(V6 Supercharged)		X	X	X	X	X	
HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Engine(V8)		X	X	X	X	X	
HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Engine(V6 LPG)		X	X	X	X	X	
HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
													1 .Rear Wiper Control 2 .Antenna Height Memory 3 .Two Stage Unlock 4 .Set Key To Priority 1 5 .Twilight Sentinel 6 .Battery Saver Shut Down Time 7 .Pre Delivery Mode 8 .Ignition Off Courtesy Lamp 9 .Approach Illumination 10.BCM Link To PCM 11.Key Program
HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Body(SRS)		X	X	X	X		
													1.Instrument Configuration 2.Options 3.Reset Service Interval 4.Reset User Calibration 5.Fuel Gauge Calibration
HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Body(Instrument)		X	X	X	X	X	

HOLDEN	ALL	1999	VT Commodore	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	1999	VS Commodore	ALL	ALL	Engine(V8)		X	X	X	X	X	
HOLDEN	ALL	1999	VS Commodore	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Engine(V6 Supercharged)		X	X	X	X	X	
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Engine(V8)		X	X	X	X	X	
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Engine(V6 LPG)		X	X	X	X	X	
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Engine(V8 GEN III)		X	X	X	X	X	
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Transmission(GEN III Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
													1 .Rear Wiper Control 2 .Antenna Height Memory 3 .Two Stage Unlock 4 .Set Key To Priority 1 5 .Twilight Sentinel 6 .Battery Saver Shut Down Time 7 .Pre Delivery Mode 8 .Ignition Off Courtesy Lamp 9 .Approach Illumination 10.BCM Link To PCM 11.Key Program
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Body(Powertrain Interface Module)		X	X	X	X	X	
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Body(SRS)		X	X	X	X		
													1.Instrument Configuration 2.Options 3.Reset Service Interval 4.Reset User Calibration 5.Fuel Gauge Calibration
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	1999	WH Statesman & Caprice	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	1998	VT Commodore	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	1998	VT Commodore	ALL	ALL	Engine(V6 Supercharged)		X	X	X	X	X	
HOLDEN	ALL	1998	VT Commodore	ALL	ALL	Engine(V8)		X	X	X	X	X	
HOLDEN	ALL	1998	VT Commodore	ALL	ALL	Engine(V6 LPG)		X	X	X	X	X	
HOLDEN	ALL	1998	VT Commodore	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	1998	VT Commodore	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	



SERVICE SOLUTIONS

													1 .Rear Wiper Control 2 .Antenna Height Memory 3 .Two Stage Unlock 4 .Set Key To Priority 1 5 .Twilight Sentinel 6 .Battery Saver Shut Down Time 7 .Pre Delivery Mode 8 .Ignition Off Courtesy Lamp 9 .Approach Illumination 10. BCM Link To PCM 11. Key Program
HOLDEN	ALL	1998	VT Commodore	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	1998	VT Commodore	ALL	ALL	Body(SRS)		X	X	X	X		
													1. Instrument Configuration 2. Options 3. Reset Service Interval 4. Reset User Calibration 5. Fuel Gauge Calibration
HOLDEN	ALL	1998	VT Commodore	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	1998	VT Commodore	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	1998	VS Commodore	ALL	ALL	Engine(V8)		X	X	X	X	X	
HOLDEN	ALL	1998	VS Commodore	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	1997	VT Commodore	ALL	ALL	Engine(V6)		X	X	X	X	X	
HOLDEN	ALL	1997	VT Commodore	ALL	ALL	Engine(V6 Supercharged)		X	X	X	X	X	
HOLDEN	ALL	1997	VT Commodore	ALL	ALL	Engine(V8)		X	X	X	X	X	
HOLDEN	ALL	1997	VT Commodore	ALL	ALL	Engine(V6 LPG)		X	X	X	X	X	
HOLDEN	ALL	1997	VT Commodore	ALL	ALL	Transmission(Automatic Transmission)		X	X	X	X	X	
HOLDEN	ALL	1997	VT Commodore	ALL	ALL	Chassis(ABS/ETC)		X	X	X	X	X	
													1 .Rear Wiper Control 2 .Antenna Height Memory 3 .Two Stage Unlock 4 .Set Key To Priority 1 5 .Twilight Sentinel 6 .Battery Saver Shut Down Time 7 .Pre Delivery Mode 8 .Ignition Off Courtesy Lamp 9 .Approach Illumination 10. BCM Link To PCM 11. Key Program
HOLDEN	ALL	1997	VT Commodore	ALL	ALL	Body(Body Control Module)		X	X	X	X	X	
HOLDEN	ALL	1997	VT Commodore	ALL	ALL	Body(SRS)		X	X	X	X		
													1. Instrument Configuration 2. Options 3. Reset Service Interval 4. Reset User Calibration 5. Fuel Gauge Calibration
HOLDEN	ALL	1997	VT Commodore	ALL	ALL	Body(Instrument)		X	X	X	X	X	
HOLDEN	ALL	1997	VT Commodore	ALL	ALL	Body(Electronic Climate Control)		X	X	X	X	X	
HOLDEN	ALL	-1996	VS Commodore	ALL	ALL	Engine(V6)			X	X	X	X	

HOLDEN	ALL	-1996	VS Commodore	ALL	ALL	Engine(V8)			X	X	X	X	
HOLDEN	ALL	-1996	VS Commodore	ALL	ALL	Transmission(Automatic Transmission)			X	X	X	X	
HOLDEN	ALL	-1996	VS Commodore	ALL	ALL	Chassis(ABS/ETC)			X	X	X	X	
HOLDEN	ALL	-1996	VS Commodore	ALL	ALL	Body(Body Control Module)			X	X	X	X	1. Key Program
HOLDEN	ALL	-1996	VS Commodore	ALL	ALL	Body(SRS)		X	X	X	X		
HOLDEN	ALL	-1996	VR Commodore	ALL	ALL	Engine(V6)			X	X	X	X	
HOLDEN	ALL	-1996	VR Commodore	ALL	ALL	Engine(V8)			X	X	X	X	
HOLDEN	ALL	-1996	VR Commodore	ALL	ALL	Transmission(Automatic Transmission)			X	X	X	X	
HOLDEN	ALL	-1996	VR Commodore	ALL	ALL	Chassis(ABS/ETC)			X	X	X	X	
HOLDEN	ALL	-1996	VR Commodore	ALL	ALL	Body(Body Control Module)			X	X	X	X	1. Key Program
HOLDEN	ALL	-1996	VR Commodore	ALL	ALL	Body(SRS)		X	X	X	X		