

How to read this list:														
Mark	Description													
X	Function is supported.													
*	Function is added or developed newly													
FunctionList														
Automaker:				BMW										
Software Version:				V8.7										
Automa ker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actual ions	Special Functions	
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Quick test	Quick test								
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Drive	Quick test (Only for Drive systems)		X	X	X				
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Drive	CAS Car Access System		X	X	X	X	X		
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Drive	DME/DDE Motor Electronics		X	X	X	X	X		
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Drive	EGS transmission control		X	X	X	X	X		
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Drive	EKP Fuel pump		X	X	X	X	X		
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Chassis	Quick test (Only for Chassis systems)		X	X	X				
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Chassis	AL active steering		X	X	X	X	X		
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Chassis	ARS Dynamic Drive 2		X	X	X	X	X		
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Chassis	DSC Dynamic Stability Control		X	X	X	X	X		
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	Quick test (Only for Body systems)		X	X	X				
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	RAD2-B0 User interface		X	X	X	X	X		
BMW	All	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	RAD2-GW Gateway		X	X	X	X			

BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	CDC CD Changer		X	X	X	X		
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	CID Central Information Display		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	CON Controller		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	DWA anti-theft alarm system		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	SINE Siren with tilt sensor		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	FRM/FRM2 Footwell module		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	FZD Function centre, roof		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	JBE Junction-box electronics		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	INSTR Instrument cluster		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	M-ASK-NAV Navigation system		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	MRS Multiple Restraint System		X	X	X	X		
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	RLSS Solar Rain/Light Sensor		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	SMFA Seat module, driver		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	SMBF Seat module, passenger		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	TCU Telematic control unit		X	X	X	X	X	
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	SHD Sliding/tilting sunroof		X	X	X	X	X	

BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	MOST-system analysis		X		X			
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Body	CAN /byteflight		X	X				
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							1 Engine oil X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							2 Microfilter X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							3 Front brake X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							4 Rear brake X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							5 Diesel filter X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							6 Spark plugs X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							8 Brake fluid X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							9 Vehicle check X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							10 Vehicle inspection: X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							11 Exhaust emission inspection: X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance>Delete transport mode							Delete transport mode X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Drive\Digital Motor Electronics							Learning Valvetronic limit positions X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Drive\Diesel Electronics							Injector rate matching X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Chassis\Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	A11	2004-2010	1 Series_E 87	116i, 118i, 120d, 118d, 123d	Service functions	Body\IHKA Integrated automatic heating/air conditioning							Run-in protection for A/C compressor X
BMW	A11	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Quick test	Quick test		X	X	X			

BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Drive	EKPS Fuel-pump control		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Drive	GWS Gear selector switch		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Chassis	DSC(Bosch)Dynamic Stability Control		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Chassis	EPS Electronic Power Steering		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Chassis	ICM Integronic Power Steering		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Chassis	EHC Electronic ride-high control		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Chassis	VDM Vertical dynamics management		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Chassis	SVT Servotronic		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	AMPT Top Hi-Fi amplifier		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	SWW Lane change warning		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	INSTR Instrument cluster		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	ACSM Crash Safety Module		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	FZD function centre, roof		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	CID Central Information Display		X	X	X	X	X	

BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	ZGM Central Gateway Module		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	CON Controller		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	CIC/CHAMP Car headunit column		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	DVDC DVD Changer		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	SMFA Seat module, driver		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	SMBF Seat module, passenger		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	TRSVc All round view camera		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Body	ACC Active cruise control		X	X	X	X	X	
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							1 Engine oil X
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							3 Front brake X
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							4 Rear brake X
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							8 Brake fluid X
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							10 Vehicle inspection: X
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							11 Exhaust emission inspection: X
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Service functions	Maintenance\CBS reset							12 Vehicle check-linked X
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Service functions	Drive\EGS transmission control							Adjustment X
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Service functions	Body\Power supply							Register Battery Change X
BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Service functions	Body\IHKA							Drainfill the refrigerant Circuit X

BMW	All	after 2010	1 Series_F 20	116i, 118i, 120d, 118d, 123d	Service functions	Body\IHKA							Run-in protection for AC compressor X
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Quick test	Quick test		X	X	X			
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Drive	EML Electronic engine-power control		X	X	X			
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Drive	ECS transmission control		X	X	X	X	X	
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Drive	GR Cruise control		X	X	X			
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Chassis	EDC Electroic Damper Control		X	X	X	X	X	
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Chassis	RDC/RDW Tyre pressure check		X	X	X			
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Chassis	EPS Electronic Power Steering		X	X	X	X		

BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Chassis	MFL Multi-function steering wheel		X			X		
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Chassis	SVT Servotronic		X					
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Body	IHKA/IHKB Integrated heating/air conditioning		X	X	X	X	X	
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Body	CVM Convertible top module		X	X	X	X		
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Body	NAV Navigation computer		X	X	X	X		
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is, 320i, 320is, 323i, 325, M3, 333i	Body	SHD Sliding/tinting sunroof		X	X	X			

BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Service functions	EGS transmission control							Clear adaptations X
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Service functions	Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Service functions	Instrument cluster							Reset service interval indicator X
BMW	All	1988-1990	3 Series_E 30	316i, 318i, 318is , 320i, 320is, 323 i, 325, M3, 333i	Service functions	Light Check Module							Read out operating data X
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 32 0i, 323i, 323ti, 3 25tds, 328i, M3,	Quick test	Quick test		X	X	X			
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 32 0i, 323i, 323ti, 3 25tds, 328i, M3,	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 32 0i, 323i, 323ti, 3 25tds, 328i, M3,	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 32 0i, 323i, 323ti, 3 25tds, 328i, M3,	Drive	EML Electronic engine-power control		X	X	X			
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 32 0i, 323i, 323ti, 3 25tds, 328i, M3,	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 32 0i, 323i, 323ti, 3 25tds, 328i, M3,	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 32 0i, 323i, 323ti, 3 25tds, 328i, M3,	Drive	GR Cruise control		X	X	X			

BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Chassis	EDC Electroic Damper Control		X	X	X	X	X	
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Chassis	RDC/RDW Tyre pressure check		X	X	X			
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Chassis	EPS Electronic Power Steering		X	X	X	X		
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Chassis	MFL Multi-function steering wheel		X			X		
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Chassis	SVT Servotronic		X					
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			

BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	IHKA/IHKR Integrated heating/air conditioning		X	X	X	X	X	
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	KOM/IKE/IKI/INSTR (Instrument cluster)		X	X	X	X	X	
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	CVM Convertible top module		X	X	X	X		
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	NAV Navigation computer		X	X	X	X		
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	SHD Sliding/titing sunroof		X	X	X			
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	SMF/SM/SLM (Seat memory, driver)		X	X	X	X	X	
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	MID Multi Information Display		X	X	X			
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 320i, 323i, 323ti, 325tds, 328i, M3,	Body	SZM Switching center, center console		X	X	X	X		

BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 32 0i, 323i, 323ti, 3 25tds, 328i, M3,	Service functions	Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 32 0i, 323i, 323ti, 3 25tds, 328i, M3,	Service functions	Instrument cluster							Reset service interval indicator X
BMW	All	1991-1998	3 Series_E 36 (With Z3)	316g, 316i, 318i, 318is, 318tds, 32 0i, 323i, 323ti, 3 25tds, 328i, M3,	Service functions	Light Check Module							Read out operating data X
BMW	All	1999-2006	3 Series_E 46		Quick test	Quick test		X	X	X			
BMW	All	1999-2006	3 Series_E 46		Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	1999-2006	3 Series_E 46		Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	1999-2006	3 Series_E 46		Drive	EML Electronic engine-power control		X	X	X			
BMW	All	1999-2006	3 Series_E 46		Drive	EGS transmission control		X	X	X	X	X	
BMW	All	1999-2006	3 Series_E 46		Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	1999-2006	3 Series_E 46		Drive	GR Cruise control		X	X	X			
BMW	All	1999-2006	3 Series_E 46		Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	1999-2006	3 Series_E 46		Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	1999-2006	3 Series_E 46		Chassis	EDC Electronic Damper Control		X	X	X	X	X	
BMW	All	1999-2006	3 Series_E 46		Chassis	EHC/EHC2 (Electronic ride-level control)		X	X	X	X	X	
BMW	All	1999-2006	3 Series_E 46		Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	1999-2006	3 Series_E 46		Chassis	MPL Multi-function steering wheel		X			X		

BMW	A11	1999-2006	3 Series_E 46		Body	Quick test (Only for Body systems)		X	X	X			
BMW	A11	1999-2006	3 Series_E 46		Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	A11	1999-2006	3 Series_E 46		Body	IHKA/IHKB Integrated heating/air conditioning		X	X	X	X	X	
BMW	A11	1999-2006	3 Series_E 46		Body	MRS/AirBag (Multiple Restraint System)		X	X	X			
BMW	A11	1999-2006	3 Series_E 46		Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	A11	1999-2006	3 Series_E 46		Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	A11	1999-2006	3 Series_E 46		Body	PDC Park Distance Control		X	X	X	X	X	
BMW	A11	1999-2006	3 Series_E 46		Body	FID Read-compartment information display		X	X	X			
BMW	A11	1999-2006	3 Series_E 46		Body	NAV Navigation computer		X	X	X	X		
BMW	A11	1999-2006	3 Series_E 46		Body	BM/MIR (On-board monitor/Multi-Information Radio)		X	X	X	X	X	
BMW	A11	1999-2006	3 Series_E 46		Body	SZM Switching center,center console		X	X	X	X		
BMW	A11	1999-2006	3 Series_E 46		Body	SMF/SM/SLM (Seat memory ,driver)		X	X	X	X	X	
BMW	A11	1999-2006	3 Series_E 46		Body	SPMFT Mirror memory, driver		X	X	X	X	X	
BMW	A11	1999-2006	3 Series_E 46		Body	SPMBT Mirror memory, passenger		X	X	X	X	X	
BMW	A11	1999-2006	3 Series_E 46		Body	RAD Radio		X	X	X	X	X	
BMW	A11	1999-2006	3 Series_E 46		Body	SES Language-input system		X	X	X		X	
BMW	A11	1999-2006	3 Series_E 46		Body	SHD Sliding/titing sunroof		X	X	X			
BMW	A11	1999-2006	3 Series_E 46		Body	TCU/ULF/TEL/BIT (Telematic Control unit)		X	X	X			

BMW	All	1999-2006	3 Series_E 46		Body	VID Video module		X	X	X			
BMW	All	1999-2006	3 Series_E 46		Body	RLS Rain/Light Sensor		X	X	X	X		
BMW	All	1999-2006	3 Series_E 46		Body	CVM Convertible-top module		X	X	X	X		
BMW	All	1999-2006	3 Series_E 46		Service functions	Digital Motor Electronics							1.Clear adaptations X
BMW	All	1999-2006	3 Series_E 46		Service functions	Digital Motor Electronics							2.CO adjustment X
BMW	All	1999-2006	3 Series_E 46		Service functions	EGS transmission control							Disable/enable key X
BMW	All	1999-2006	3 Series_E 46		Service functions	Electronic car immobilisation system							Clear adaptations X
BMW	All	1999-2006	3 Series_E 46		Service functions	Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	1999-2006	3 Series_E 46		Service functions	Instrument cluster							Reset service interval indicator X
BMW	All	1999-2006	3 Series_E 46		Service functions	Light Check Module							Read out operating data X
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Quick test	Quick test							
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Drive	CAS Car Access System		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Drive	DME/DDE Motor Electronics		*	*	*	*	*	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Drive	EGS transmission control		X	X	X	X	X	

BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Drive	EKPS Fuel pump		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Chassis	AL active steering		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Chassis	ARS Dynamic Drive 2		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Chassis	DSC Dynamic Stability Control		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Chassis	EPS Electronic Power Steering		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	RAD2-B0 User interface		*	*	*	*	*	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	RAD2-GW Gateway		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	CIC User interface		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	CIC-GW Gateway		X	X	X	X	X	

BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	CDC CD Changer		X	X	X	X		
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	CID Central Information Display		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	CON Controller		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	DWA anti-theft alarm system		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	SINE Siren with tilt sensor		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	FRM/FRM2 Footwell module		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	FZD Function centre, roof		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	IHKA Integrated automatic heating/air conditioning		*	*	*	*	*	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	JBE Junction-box electronics		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	INSTR Instrument cluster		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	M-ASK-NAV Navigation system		X	X	X	X	X	

BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	MRS Multiple Restraint System		X	X	X	X		
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	RLSS Solar Rain/Light Sensor		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	SMFA Seat module, driver		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	SMBF Seat module, passenger		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	TCU Telematic control unit		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	SHD Sliding/tilting sunroof		X	X	X	X	X	
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	MOST-system analysis		X		X			
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	CAN /byteflight		X	X				
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	FLA High Beam Assist		X	X	X	X	X	
BMW	ALL	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Body	CBX-MEDIA Combox multimedia		*	*	*	*	*	

[illegible]

BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Maintenance\CBS correction vehicle data							CBS correction vehicle data X
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Drive\Digital Motor Electronics							Learning Valvetronic limit positions X
BMW		2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Drive\Diesel Electronics							Injector rate matching X
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Chassis\Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Body\IHKA Integrated automatic heating/air conditioning							Run-in protection for A/C compressor X
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Chassis\Wheel-slip control system							Lateral acceleration sensor adjustment X
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Chassis\Wheel-slip control system							Longitudinal acceleration sensor adjustment X
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Chassis\Wheel-slip control system							Bleeding procedure X
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Chassis\Wheel-slip control system							DSC unit adjustment X
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Body\FZD function center, roof							Sunroof initialization X
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Body\FZD function center, roof							Rain/light sensor initialization X

BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Body\JBE Junction-box electronics								Start windows initialization X
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Car key memory								Car key memory X
BMW	All	2005-2009	3 Series_E 90/E91/E 92/E93	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Driver\CAS Car access system								CAS_DME_DDE_Alignment X
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Quick test	Quick test		X	X	X				
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Drive	Quick test (Only for Drive systems)		X	X	X				
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X		
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Drive	DME2/DME2 Digital motor electronics 2		X	X	X	X	X		
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Drive	EGS transmission control		X	X	X	X	X		
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Drive	EKPS Fuel-pump control		X	X	X	X	X		
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Drive	GWS Gear selector switch		X	X	X	X	X		
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Chassis	DSC (Bosch) Dynamic Stability Control		X	X	X	X	X		

BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Chassis	EPS Electronic Power Steering		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Chassis	ICM Integronic Power Steering		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Chassis	RDC/RDW Tyre pressure check		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Chassis	EHC Electronic ride-high control		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Chassis	VDM Vertical dynamics management		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Chassis	SVT Servotronic		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	AMPT Top Hi-Fi amplifier		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	SWW Lane change warning		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	INSTR Instrument cluster		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	ACSM Crash Safety Module		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	FZD function centre, roof		X	X	X	X	X	

BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	CID Central Information Display		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	ZGM Central Gateway Module		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	CON Controller		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	CIC/CHAMP Car headunit column		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	DVDC DVD Changer		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	SMFA Seat module, driver		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	SMBF Seat module, passenger		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	TRSVCA All round view camera		X	X	X	X	X	
BMW	All	after 2010	3 Series_F30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	VM Video Module		X	X	X	X	X	

BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Body	ACC Active cruise control		X	X	X	X	X	
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Service functions	Maintenance\CBS reset							1 Engine oil X
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Service functions	Maintenance\CBS reset							3 Front brake X
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Service functions	Maintenance\CBS reset							4 Rear brake X
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Service functions	Maintenance\CBS reset							8 Brake fluid X
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Service functions	Maintenance\CBS reset							10 Vehicle inspection: X
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Service functions	Maintenance\CBS reset							11 Exhaust emission inspection: X
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Service functions	Maintenance\CBS reset							12 Vehicle check-linked X
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Service functions	Drive\EGS transmission control							Adjustment X
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Service functions	Body\Power supply							Register Battery Change X
BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si, 320d, 323i, 325i, 330i, 330xi, 335i, 335xi, 330d	Service functions	Body\IHKA							Drainfill the refrigerant Circuit X

BMW	All	after 2010	3 Series_F 30	318i, 320i, 320si , 320d, 323i, 325i , 330i, 330xi, 335 i, 335xi, 330d	Service functions	Body\IHKA							Run-in protection for AC compressor X
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Quick test	Quick test		X	X	X			
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Drive	EML Electronic engine-power control		X	X	X			
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Drive	GR Cruise control		X	X	X			
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Chassis	EDC Electroic Damper Control		X	X	X	X	X	
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Chassis	RDC/RDW Tyre pressure check		X	X	X			
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Chassis	EPS Electronic Power Steering		X	X	X	X		
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Chassis	MFL Multi-function steering wheel		X			X		
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Chassis	SVT Servotronic		X					
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	Quick test (Only for Body systems)		X	X	X			

BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	IHKA/IHKR Integrated heating/air conditioning		X	X	X	X	X	
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	CVM Convertible top module		X	X	X	X		
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	NAV Navigation computer		X	X	X	X		
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	SHD Sliding/titing sunroof		X	X	X			
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	SMF/SM/SLM (Seat memory, driver)		X	X	X	X	X	
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	MID Multi Information Display		X	X	X			
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	SZM Switching center, center console		X	X	X	X		
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	RLS/AIC (Rain/Light Sensor/Automatic interval Control)		X	X	X	X		
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	TCU/ULF/TEL/BIT (Telematic Control unit)		X	X	X			
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	BM/MIR (On-board monitor/Multi-Information Radio)		X	X	X	X	X	
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	VID Video module		X	X	X			
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	RAD Radio		X	X	X	X	X	

BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	STH park heating		X					
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	DSP Digital Sound Processor		X					
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Body	SES Language-input system		X	X	X		X	
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Service functions	Digital Motor Electronics							1.Clear adaptations X
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Service functions	Digital Motor Electronics							2.CO adjustment X
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Service functions	EGS transmission control							Clear adaptations X
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Service functions	Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Service functions	Instrument cluster							Reset service interval indicator X
BMW	All	before 1988	5 Series_E 28	518i, 520i, 520d, 525i, 528i, 535i, 525d, M5	Service functions	Light Check Module							Read out operating data X
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Quick test	Quick test		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Drive	EML Electronic engine-power control		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Drive	GR Cruise control		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	

BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Chassis	EDC Electroic Damper Control		X	X	X	X	X	
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Chassis	RDC/RDW Tyre pressure check		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Chassis	EPS Electronic Power Steering		X	X	X	X		
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Chassis	MFL Multi-function steering wheel		X			X		
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Chassis	SVT Servotronic		X					
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	IHKA/IHKB Integrated heating/air conditioning		X	X	X	X	X	
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	CVM Convertible top module		X	X	X	X		
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	NAV Navigation computer		X	X	X	X		
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	SHD Sliding/titing sunroof		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	SMF/SM/SLM (Seat memory, driver)		X	X	X	X	X	

BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	MID Multi Information Display		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	SZM Switching center, center console		X	X	X	X		
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	RLS/AIC (Rain/Light Sensor/Automatic interval Control)		X	X	X	X		
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	TCU/ULF/TEL/BIT (Telematic Control unit)		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	BM/MIR (On-board monitor/Multi-Information Radio)		X	X	X	X	X	
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	VID Video module		X	X	X			
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	RAD Radio		X	X	X	X	X	
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	STH park heating		X					
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	DSP Digital Sound Processor		X					
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Body	SES Language-input system		X	X	X		X	
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Service functions	Digital Motor Electronics							1.Clear adaptations X
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Service functions	Digital Motor Electronics							2.CO adjustment X
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Service functions	EGS transmission control							Clear adaptations X
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Service functions	Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Service functions	Instrument cluster							Reset service interval indicator X
BMW	All	1988-1996	5 Series_E 34	518i, 520i, 525i, 525d, 528i, 530i, 535i, 540i, M5	Service functions	Light Check Module							Read out operating data X
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 525d, 530d, 530d	Quick test	Quick test		X	X	X			

BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Drive	EML Electronic engine-power control		X	X	X			
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Drive	GR Cruise control		X	X	X			
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Chassis	EDC Electroic Damper Control		X	X	X	X	X	
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Chassis	RDC/RDW Tyre pressure check		X	X	X			

BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Chassis	EPS Electronic Power Steering		X	X	X	X		
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Chassis	MFL Multi-function steering wheel		X			X		
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Chassis	SVT Servotronic		X					
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	IHKA/IHKB Integrated heating/air conditioning		X	X	X	X	X	
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	CVM Convertible top module		X	X	X	X		

BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	NAV Navigation computer		X	X	X	X		
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	SHD Sliding/titing sunroof		X	X	X			
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	SMF/SM/SLM (Seat memory, driver)		X	X	X	X	X	
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	MID Multi Information Display		X	X	X			
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	SZM Switching center, center console		X	X	X	X		
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	RLS/AIC (Rain/Light Sensor/Automatic interval Control)		X	X	X	X		
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	TCU/ULF/TEL/BIT (Telematic Control unit)		X	X	X			
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	BM/MIR (On-board monitor/Multi-Information Radio)		X	X	X	X	X	
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	VID Video module		X	X	X			
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	RAD Radio		X	X	X	X	X	

BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	STH park heating		X					
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	DSP Digital Sound Processor		X					
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Body	SES Language-input system		X	X	X		X	
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Service functions	Digital Motor Electronics							1.Clear adaptations X
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Service functions	Digital Motor Electronics							2.CO adjustment X
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Service functions	EGS transmission control							Clear adaptations X
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Service functions	Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Service functions	Instrument cluster							Reset service interval indicator X
BMW	All	1996-2004	5 Series_E 39	520i, 523i, 525i, 528i, 530i, 535i, 540i, M5, 520d, 52 5d, 530d, 530d	Service functions	Light Check Module							Read out operating data X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Quick test	Quick test		X	X	X			
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	Quick test (Only for Drive systems)		X	X	X			

BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	CAS Car Access System		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	DME/DDE Motor Electronics		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	GWS Gear selector switch		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	EKPS Fuel-pump control		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	AL active steering		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	ARS Dynamic Drive		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	DSC Dynamic Stability Control		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	AHL Adaptive directional headlights		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	INSTR Instrument cluster		X	X	X	X	X	

BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	LM2 Lights module 2		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	KBM Body basic module		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	KGM Body Gateway Module		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	ACSM/MRS Crash Safety Module		X	X	X	X		
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	M-ASK-GW Gateway		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	CHAMP-GW Gateway		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	M-ASK-BO User interface		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	CHAMP-BO User interface		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	M-ASK-NAV Navigation system		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	MPM Micro-power module		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	CDC CD Changer		X	X	X		X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	CID Central Information Display		X	X	X	X	X	

BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	RLS Rain/Light Sensor		X	X	X	X		
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SGM-SIM Safety and Gateway Module(SIM)		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SGM-ZGM Safety and Gateway Module (ZGM)		X	X	X			
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SFZ Satellite vehicle center		X	X	X	X		
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SBSL Satellite, B-pillar, left		X	X	X	X		
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SBSR Satellite, B-pillar, right		X	X	X	X		
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SZL Switch center, steering column		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SZM Switching center, center console		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SINE Siren and tilt sensor		X	X	X	X		
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SHD Sliding/tilting sunroof		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SMFA Seat module, driver		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SMBF Seat module, passenger		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	TCU Telematic control unit		X	X	X	X	X	

BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	ULF Universal charging and hands-free facility		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	TMFA Door module, driver		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	TMBF Door module, front passenger		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	CCC-GW Gateway		X	X		X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	CCC-ANT Aerial tuner		X			X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	CCC-ASK Audio system controller		X				X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	CCC-A Applications		X			X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	CON Controller		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	DWA antitheft alarm system		X		X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	FZD function centre, roof		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	HUD Head-Up Display		X	X	X	X	X	
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	ALBBF Active backrest width, front passenger		X	X	X	X		
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	ALBFA Active backrest width, driver		X	X	X	X		

BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Body	SHZH Independent/auxiliary heater		X	X	X	X	X	
BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Body	HKL Rear-lid module		X	X	X	X	X	
BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Body	DAB Digital tuner		X	X	X	X	X	
BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Body	JBE Junction-box electronics		X	X	X	X	X	
BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Body	VM Video Module		X	X	X	X	X	
BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Body	MOST system analysis				X			
BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Body	CAN /byteflight			X				
BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Service functions	Maintenance\CBS reset							1 Engine oil X
BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Service functions	Maintenance\CBS reset							2 Microfilter X
BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Service functions	Maintenance\CBS reset							3 Front brake X
BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Service functions	Maintenance\CBS reset							4 Rear brake X
BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Service functions	Maintenance\CBS reset							5 Diesel filter X
BMW	All	After 2004	5 Series_E60/E61	520d, 520i, 523i, 525d, 525i, 525xd, 530d, 530i, 535i, M5	Service functions	Maintenance\CBS reset							6 Spark plugs X

BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS reset							7 Coolant X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS reset							8 Brake fluid X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS reset							9 Vehicle check X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS reset							10 Vehicle inspection: X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS reset							11 Exhaust emission inspection: X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\Delete transport mode							Delete transport mode X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS correction vehicle data							CBS correction vehicle data X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Drive\Diesel Electronics							Injector rate matching X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Body\IHKA Integrated automatic heating/air conditioning							Run-in protection for A/C compressor X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Chassis\Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Chassis\Wheel-slip control system							Bleed Routine X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Chassis\Wheel-slip control system							Longitudinal acceleration sensor adjustment X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Drive\Diesel Electronics							Regeneration Particular Filter X

BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Drive\Diesel Electronics							Replacement particulate filter X
BMW	All	After 2004	5 Series_E 60/E61	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Body\PM Power module							Register battery replacement X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Quick test	Quick test		X	X	X			
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	DME2/DME2 Digital motor electronics 2		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	CAS Car Access System		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	EKPS Fuel-pump control		X	X	X	X	X	
		after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	VTG Transfer case		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Drive	GWS Gear selector switch		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	DSC(Bosch)Dynamic Stability Control		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	EMF Parking brake		X	X	X	X	X	

BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	EPS Electronic Power Steering		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	EHC Electronic Ride-Height Control		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	ICM Integronic Power Steering		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	SME Accumulator management electronics		X	X	X	X		
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	AL active steering		X	X	X	X		
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	RDC/RDW Tyre pressure check		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	EDCSVL Damper satellite, front left		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	EDCSVR Damper satellite, front right		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	EDCSHL Damper satellite, rear left		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	EDCSHR Damper satellite, rear right		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	VDM Vertical dynamics management		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Chassis	SVT Servotronic		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	AMPT Top Hi-Fi amplifier		X	X	X	X	X	

BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SWW Lane change warning		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	INSTR Instrument cluster		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	ACSM Crash Safety Module		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	FRM Footwell module		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	JBE Junction-box electronics		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	FZD function centre, roof		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	CID Central Information Display		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	ZGM Central Gateway Module		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SZL Switch center, steering column		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	CON Controller		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	CIC/CHAMP Car headunit column		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	PDC Park Distance Control		X	X	X	X	X	

BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	DVDC DVD Changer		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SMFA Seat module, driver		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	SMBF Seat module, passenger		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	TR SVC All round view camera		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	HKL Rear-lid module		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	FKA Rear-cabin automatic A/C		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	FD Rear-compartment display		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	FD2 Rear-compartment display2		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	VM Video Module		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	VSW Video switch		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	ACC Active cruise control		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	RSE Rear seat entertainment		X	X	X	X	X	
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Body	HSR Rear-axle slip-angle control		*	*	*	*		

BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS reset							1 Engine oil X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS reset							3 Front brake X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS reset							4 Rear brake X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS reset							8 Brake fluid X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS reset							10 Vehicle inspection: X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS reset							11 Exhaust emission inspection: X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Maintenance\CBS reset							12 Vehicle check-linked X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Drive\EGS transmission control							Adjustment X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Chassis\EMF Parking brake\							Renewal of an actuator on brake caliper X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Chassis\EMF Parking brake\							Renewal of the brake caliper or brake pads X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Body\Power supply							Register Battery Change X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Body\IHKA							Drainfill the refrigerant Circuit X
BMW	All	after 2010	5 Series_F 10/F11/1 8	520d, 520i, 523i, 525d, 525i, 525xd , 530d, 530i, 535i , M5	Service functions	Body\IHKA							Run-in protection for AC compressor X

BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Quick test	Quick test		X	X	X			
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Drive	DME2/DME2 Digital motor electronics 2		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Drive	CAS Car Access System		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Drive	EKPS Fuel-pump control		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Drive	VTG Transfer case		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Drive	GWS Gear selector switch		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	DSC(Bosch)Dynamic Stability Control		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	EMF Parking brake		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	EPS Electronic Power Steering		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	EHC Electronic Ride-Height Control		X	X	X	X	X	

BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	ICM Integronic Power Steering		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	SME Accumulator management electronics		X	X	X	X		
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	AL active steering		X	X	X	X		
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	RDC/RDW Tyre pressure check		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	EDCSVL Damper satellite, front left		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	EDCSVR Damper satellite, front right		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	EDCSHL Damper satellite, rear left		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	EDCSHR Damper satellite, rear right		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	VDM Vertical dynamics management		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Chassis	SVT Servotronic		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	AMPT Top Hi-Fi amplifier		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	SWW Lane change warning		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	INSTR Instrument cluster		X	X	X	X	X	

BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	ACSM Crash Safety Module		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	FRM Footwell module		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	JBE Junction-box electronics		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	FZD function centre, roof		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	CID Central Information Display		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	ZGM Central Gateway Module		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	SZL Switch center, steering column		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	CON Controller		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	CIC/CHAMP Car headunit column		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	DVDC DVD Changer		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	SMFA Seat module, driver		X	X	X	X	X	

BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	SMBF Seat module, passenger		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	TRSVC All round view camera		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	HKL Rear-lid module		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	FKA Rear-cabin automatic A/C		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	FD Rear-compartment display		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	FD2 Rear-compartment display2		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	VM Video Module		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	VSW Video switch		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	ACC Active cruise control		X	X	X	X	X	
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	RSE Rear seat entertainment		X	X	X	X	X	
BMW	All	after 2010	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Body	HSR Rear-axle slip-angle control		*	*	*	*		
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Maintenance\CBS reset							1 Engine oil X
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Maintenance\CBS reset							3 Front brake X

BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Maintenance\CBS reset							4 Rear brake X
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Maintenance\CBS reset							8 Brake fluid X
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Maintenance\CBS reset							10 Vehicle inspection: X
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Maintenance\CBS reset							11 Exhaust emission inspection: X
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Maintenance\CBS reset							12 Vehicle check-linked X
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Drive\EGS transmission control							Adjustment X
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Chassis\EMF Parking brake\							Renewal of an actuator on brake caliper X
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Chassis\EMF Parking brake\							Renewal of the brake caliper or brake pads X
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Body\Power supply							Register Battery Change X
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Body\IHKA							Drainfill the refrigerant Circuit X
BMW	All	after 2008	5GT Series_F 07	3. 0d, 3. 0dx, 3. 5d , 3. 5dx, 3. 5i, 3. 5 ix, 5. 0i, 5. 0ix	Service functions	Body\IHKA							Run-in protection for AC compressor X
BMW	All	Before 1989	6 Series_E 24	630i, 645Ci, 650i	Quick test	Quick test		X	X	X			
BMW	All	Before 1989	6 Series_E 24	630i, 645Ci, 650i	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	Before 1989	6 Series_E 24	630i, 645Ci, 650i	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	

BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Drive	EML Electronic engine-power control		X	X	X			
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Drive	GR Cruise control		X	X	X			
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Chassis	EDC Electroic Damper Control		X	X	X	X	X	
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Chassis	RDC/RDW Tyre pressure check		X	X	X			
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Chassis	EPS Electronic Power Steering		X	X	X	X		
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Chassis	MPL Multi-function steering wheel		X			X		
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Chassis	SVT Servotronic		X					
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Body	IHKA/IHKB Integrated heating/air conditioning		X	X	X	X	X	
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Body	KOM/IKE/IKI/INSTR (Instrument cluster)		X	X	X	X	X	
BMW	All	Before 1989	6 Series_E , 24	630i, 645Ci, 650i	Body	LSZ/LCM (Lights switching center)		X	X		X	X	

BMW	All	Before 1989	6 Series_E 24	630i, 645Ci, 650i	Service functions	ECS transmission control							Clear adaptations X
BMW	All	Before 1989	6 Series_E 24	630i, 645Ci, 650i	Service functions	Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	Before 1989	6 Series_E 24	630i, 645Ci, 650i	Service functions	Instrument cluster							Reset service interval indicator X
BMW	All	Before 1989	6 Series_E 24	630i, 645Ci, 650i	Service functions	Light Check Module							Read out operating data X
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Quick test	Quick test		X	X	X			
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Drive	CAS Car Access System		X	X	X	X		
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Drive	DME Motor Electronics		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Drive	ECS transmission control		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Drive	VTC Valvetronic		X					
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Drive	VTC2 Valvetronic 2		X					
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Drive	EKP Fuel pump		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Chassis	AL active steering		X	X	X	X		
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Chassis	ARS Dynamic Drive 2		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Chassis	DSC Dynamic Stability Control		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	AHL Adaptive directional headlights		X	X	X	X	X	

BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	INSTR Instrument cluster		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	LM Lights module 2		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	KBM Body basic module		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	MPM Micro-power module		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	CVM Convertible top module		X	X	X	X		
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	CCC-GW Gateway		X	X		X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	CCC-ANT Aerial tuner		X			X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	CCC-ASK Audio system controller		X				X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	CCC-A Applications		X			X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	CID Central Information Display		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	CON Controller		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	DWA antitheft alarm system		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	RLS Rain/Light Sensor		X	X	X	X		
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	SGM-SIM Safety and Gateway Module (SIM)		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	SGM-ZGM Safety and Gateway Module (ZGM)		X	X	X			
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	SFZ Satellite vehicle center		X	X	X	X		

BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	SBSL Satellite, B-pillar, left		X	X	X	X		
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	SBSR Satellite, B-pillar, right		X	X	X	X		
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	SZL Switch center, steering column		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	SZM Switching center, center console		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	TCU Telematic control unit		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	TMFA Door module, driver		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	TMBF Door module, front passenger		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	VM Video Module		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	SHD Slide/tilt sunroof 2		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	CCC-B0 User interface		X	X	X	X	X	
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	MOST system analysis				X			
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	AMP Amplifier				X			
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	HUD Head-Up Display		X	X	X	X		
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Body	CAN / byteflight			X				
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Service functions	Maintenance\CBS reset							1 Engine oil X
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Service functions	Maintenance\CBS reset							2 Microfilter X
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Service functions	Maintenance\CBS reset							3 Front brake X
BMW	All	After 2003	6 Series_E 63/E64	630Ci/630i, 645Ci, 650i, M6	Service functions	Maintenance\CBS reset							4 Rear brake X

[illegible]

BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Quick test	Quick test		X	X	X			
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Drive	DME2/DME2 Digital motor electronics 2		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Drive	CAS Car Access System		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Drive	EKPS Fuel-pump control		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Drive	VTG Transfer case		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Drive	GWS Gear selector switch		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	DSC (Bosch) Dynamic Stability Control		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	EMF Parking brake		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	EPS Electronic Power Steering		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	EHC Electronic Ride-Height Control		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	ICM Integronic Power Steering		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	SME Accumulator management electronics		X	X	X	X		
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	AL active steering		X	X	X	X		
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	RDC/RDW Tyre pressure check		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	EDCSVL Damper satellite, front left		X	X	X	X	X	

BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	EDCSVR Damper satellite, front right		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	EDCSHL Damper satellite, rear left		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	EDCSHR Damper satellite, rear right		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	VDM Vertical dynamics management		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Chassis	SVT Servotronic		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	AMPT Top Hi-Fi amplifier		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	SWW Lane change warning		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	INSTR Instrument cluster		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	ACSM Crash Safety Module		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	FRM Footwell module		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	JBE Junction-box electronics		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	FZD function centre, roof		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	CID Central Information Display		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	ZGM Central Gateway Module		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	SZL Switch center, steering column		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	CON Controller		X	X	X	X	X	
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Body	CIC/CHAMP Car headunit column		X	X	X	X	X	

BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Service functions	Maintenance\CBS reset							10 Vehicle inspection: X
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Service functions	Maintenance\CBS reset							11 Exhaust emission inspection: X
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Service functions	Maintenance\CBS reset							12 Vehicle check-linked X
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Service functions	Drive\EGS transmission control							Adjustment X
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Service functions	Chassis\EMF Parking brake\							Renewal of an actuator on brake caliper X
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Service functions	Chassis\EMF Parking brake\							Renewal of the brake caliper or brake pads X
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Service functions	Body\Power supply							Register Battery Change X
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Service functions	Body\IHKA							Drainfill the refrigerant Circuit X
BMW	All	after 2008	6 Series_F 12/F13	640d, 640i, 650i, 650ix	Service functions	Body\IHKA							Run-in protection for AC compressor X
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Quick test	Quick test		X	X	X			
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Drive	EML Electronic engine-power control		X	X	X			
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Drive	GR Cruise control		X	X	X			
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	

BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Chassis	EDC Electroic Damper Control		X	X	X	X	X	
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Chassis	RDC/RDW Tyre pressure check		X	X	X			
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Chassis	MFL Multi-function steering wheel		X			X		
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Chassis	SVT Servotronic		X					
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	IHKA/IHKR Integrated heating/air conditioning		X	X	X	X	X	
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	CVM Convertible top module		X	X	X	X		
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	NAV Navigation computer		X	X	X	X		
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	SHD Sliding/titing sunroof		X	X	X			
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	SMF/SM/SLM (Seat memory, driver)		X	X	X	X	X	
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	MID Multi Information Display		X	X	X			

BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	SZM Switching center, center console		X	X	X	X		
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	RLS/AIC (Rain/Light Sensor/Automatic interval Control)		X	X	X	X		
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	TCU/ULF/TEL/BIT (Telematic Control unit)		X	X	X			
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	BM/MIR (On-board monitor/Multi-Information Radio)		X	X	X	X	X	
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	VID Video module		X	X	X			
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	RAD Radio		X	X	X	X	X	
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	STH park heating		X					
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	DSP Digital Sound Processor		X					
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Body	SES Language-input system		X	X	X		X	
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Service functions	Digital Motor Electronics							1. Clear adaptations X
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Service functions	Digital Motor Electronics							2. CO adjustment X
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Service functions	EGS transmission control							Clear adaptations X
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Service functions	Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Service functions	Instrument cluster							Reset service interval indicator X
BMW	All	1977 - 1986	7 Series_E 23	725i, 728i, 728i, 730i, 732i, 733i, 735i, 745i	Service functions	Light Check Module							Read out operating data X
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Quick test	Quick test		X	X	X			
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	

BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Drive	EML Electronic engine-power control		X	X	X			
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Drive	GR Cruise control		X	X	X			
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Chassis	EDC Electroic Damper Control		X	X	X	X	X	
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Chassis	RDC/RDW Tyre pressure check		X	X	X			
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Chassis	MFL Multi-function steering wheel		X			X		
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Chassis	SVT Servotronic		X					
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Body	IHKA/IHKB Integrated heating/air conditioning		X	X	X	X	X	
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Body	LRA Automatic headlight vertical aim control		X	X	X			

BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Service functions	Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Service functions	Instrument cluster							Reset service interval indicator X
BMW	All	1987 - 1994	7 Series_E 32	730i, 735i, 740i, 750i	Service functions	Light Check Module							Read out operating data X
BMW	All	1994 - 2001	7 Series_E 38	725tds, 728i/728 iL, 730i/730iL, 7 35i/735iL, 735i/ 735iL, 730d, 740i /740iL, 750iL	Quick test	Quick test		X	X	X			
BMW	All	1994 - 2001	7 Series_E 38	725tds, 728i/728 iL, 730i/730iL, 7 35i/735iL, 735i/ 735iL, 730d, 740i /740iL, 750iL	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	1994 - 2001	7 Series_E 38	725tds, 728i/728 iL, 730i/730iL, 7 35i/735iL, 735i/ 735iL, 730d, 740i /740iL, 750iL	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	1994 - 2001	7 Series_E 38	725tds, 728i/728 iL, 730i/730iL, 7 35i/735iL, 735i/ 735iL, 730d, 740i /740iL, 750iL	Drive	EML Electronic engine-power control		X	X	X			
BMW	All	1994 - 2001	7 Series_E 38	725tds, 728i/728 iL, 730i/730iL, 7 35i/735iL, 735i/ 735iL, 730d, 740i /740iL, 750iL	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	1994 - 2001	7 Series_E 38	725tds, 728i/728 iL, 730i/730iL, 7 35i/735iL, 735i/ 735iL, 730d, 740i /740iL, 750iL	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	1994 - 2001	7 Series_E 38	725tds, 728i/728 iL, 730i/730iL, 7 35i/735iL, 735i/ 735iL, 730d, 740i /740iL, 750iL	Drive	GR Cruise control		X	X	X			

BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Chassis	Quick test (Only for Chassis systems)							
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Chassis	EHC Electronic Height Control		X	X	X	X	X	
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Chassis	EDC Electronic Damper Control		X	X	X	X	X	
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Chassis	MFL Multi-function steering wheel		X			X		
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Chassis	SVT Servotronic		X					
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Body	Quick test (Only for Body systems)							
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Body	MRS/AirBag (Multiple Restraint System)		X	X	X			

BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Body	IHKA/IHKR Integrated heating/air conditioning		X	X	X	X	X	
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Body	NAV Navigation computer		X	X	X	X		
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Body	SZM Switching center, center console		X	X	X	X		
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Body	AHL Adaptive directional headlights		X	X	X	X	X	
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Body	BM/MIR (On-board monitor/Multi-Information Radio)		X	X	X	X	X	

BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Service functions	Digital Motor Electronics							2.CO adjustment X
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Service functions	Drive\EGS transmission control							Disable/enable key X
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Service functions	Drive\Electronic car immobilisation system							Clear adaptations X
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Service functions	Chassis\Wheel-slip control system							1.Adjustment, steering-angle sensor X
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Service functions	Chassis\Wheel-slip control system							2.Adjust transversal-acceleration sensor X
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Service functions	Body\Instrument cluster							Reset service interval indicator X
BMW	All	1994 - 2001	7 Series_E38	725tds, 728i/728iL, 730i/730iL, 735i/735iL, 735i/735iL, 730d, 740i/740iL, 750iL	Service functions	Body\Light Check Module							Read out operating data X
BMW	All	2001 - 2008	7 Series_E65/E66/E67/E68	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Quick test	Quick test		X	X	X			
BMW	All	2001 - 2008	7 Series_E65/E66/E67/E68	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Drive	Quick test (Only for Drive systems)		X	X	X			

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Drive	CAS Car Access System		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Drive	DME Digital Motor Electronics		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Drive	DDE Diesel Electronics		*	*	*	*	*	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Drive	EGS transmission management		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Drive	VTC Valvetronic		X			X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Drive	VTC2 Valvetronic 2		X			X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Chassis	ACC/ACC2 Active Cruise Control		X	X	X			
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Chassis	LRR Long Range Radar		X	X	X			

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Chassis	ARS Dynamic Drive		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Chassis	EDC Damper Control		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Chassis	CIM Chassis integration Module		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Chassis	DSC Dynamic Stability Control		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Chassis	EHC Ride level(Height) Control		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Chassis	EMF Parking brake		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Chassis	RDC Tire pressure control		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	AHM Trailer module		X	X	X	X	X	

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	AMP Amplifier		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	ANT Antenna/antenna tuner		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	ASK Audio system controller		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	BZM Control center, center console		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	FBZM Rear compartment, control center, center console		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	CD Control Display		X	X	X		X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	CD-GW Control Display(Gateway)		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	CDC CD Changer		X	X	X		X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	CON Controller		X	X	X	X	X	

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	DWA antitheft alarm system		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	HKL Rear-lid lift		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	INSTR Intrument cluster		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	LM Lights Module		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	NAV Navigation system		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	JNAV Navigation system, Japan		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	KNAV Navigation system, Korea		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	PDC Park distance control		X	X	X	X	X	

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	PM Power module		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	RLS Rain/light sensor		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SASL Satellite, A-pillar, left		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SASR Satellite, A-pillar, right		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SBSL Satellite, B-pillar, left		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SBSR Satellite, B-pillar, right		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SFZ Satellite vehicle center		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SSBF Satellite, seat, passenger		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SSFA Satellite, seat, driver		X	X	X	X		

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SSH Satellite, seat, rear		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	STVL Satellite, door, front left		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	STVR Satellite, door, front right		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SHD Sliding/tilting sunroof		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SINE Siren and tilt sensor		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SMFA Seat module, driver		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SMBF Seat module, passenger		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SMFAH Seat module, driver's side, rear		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SMBFH Seat module, passenger's side, rear		X	X	X	X	X	

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SZL Switch center, steering column		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	TEL Telephone		X	X	X		X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	TMBFT Door module, passenger door		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	TMBFH Door module, passenger's side, rear		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	TMFAT Door module, driver's door		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	TMFAH Door module, driver's side, rear		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	VM Video Module		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	WIM Wiper module		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	ZGM Central Gateway Module		X	X	X			

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SIM Safety and information module		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	CA Comfort Access		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	FCON Rear compartment controller		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	FKA Rear-compartment air conditioning		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	FD Rear-compartment display		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SG-FD-GW Control unit, rear-compartment display(gateway)		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SG-FD Control unit, rear-compartment display		X	X	X		X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SHZH Independent/auxiliary heater		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	KHI Headphones interface		X	X	X	X	X	

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SVS Language processing system		X	X	X		X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	DVD CD Changer		X	X	X		X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	FBI Flexible Bus Interface		X	X	X		X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	NVE Night Vision Electronics		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	NVK Night vision camera		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	CEM Clean Energy Module		X	X	X	X		
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	DAB Digital tuner		X	X	X		X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SDARS Satellite tuner (US)		X	X	X	X	X	
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SECI Supplementary control unit 1		X	X	X			

BMW	A11	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	SEC2 Supplementary control unit 2		X	X	X			
BMW	A11	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	MOST system analysis			X	X			
BMW	A11	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Body	CAN /byteflight			X				
BMW	A11	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Maintenance\CBS reset							1 Engine oil X
BMW	A11	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Maintenance\CBS reset							2 Microfilter X
BMW	A11	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Maintenance\CBS reset							3 Front brake X
BMW	A11	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Maintenance\CBS reset							4 Rear brake X
BMW	A11	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Maintenance\CBS reset							5 Diesel filter X
BMW	A11	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Maintenance\CBS reset							6 Spark plugs X

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Maintenance\CBS reset								7 Coolant X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Maintenance\CBS reset								8 Brake fluid X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Maintenance\CBS reset								9 Vehicle check X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Maintenance\CBS reset								10 Vehicle inspection: X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Maintenance\CBS reset								11 Exhaust emission inspection: X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Maintenance>Delete transport mode								Delete transport mode X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Maintenance\CBS correction vehicle data								CBS correction vehicle data X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Drive\Digital Motor Electronics								1.DME-CAS Adjustment X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Drive\Digital Motor Electronics								2.Idle speed Adjustment X

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Chassis\Dynamic Drive							2.Learn sensor values X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Body\IHKA Integrated automatic heating/air conditioning							Run-in protection for A/C compressor X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Initialize power windows							Initialize power windows X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Drive\CAS Car Access System							1.CAS reset X 2.ELV steering lock fault counter reset X 3.Reset starter interlock X 4.Key number X 5.Enable/Disable key X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Unlock,on removal of RC X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Entrance aid,tilt direction X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Automatic locking\car X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Automatic locking\key 1 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Automatic locking\key 2 X

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Automatic locking\key 3 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Automatic locking\key 4 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Relock 2 minutes after unlocking if doors unopened\key 1 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Relock 2 minutes after unlocking if doors unopened\key 2 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Relock 2 minutes after unlocking if doors unopened\key 3 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Relock 2 minutes after unlocking if doors unopened\key 4 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Selective central locking/convenient access\car X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Selective central locking/convenient access\key 1 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory							Selective central locking/convenient access\key 2 X

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Selective central locking/convenient access\key 3 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Selective central locking/convenient access\key 4 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Compartment sensor X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Tilt sensor X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Arming/disarming X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Arm visually X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Arm acoustically X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Arm visually doors/lids closed X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Arm acoustically doors/lids closed X

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Disarm visually X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Disarm Acoustically X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Daytime driving lights (ECE) X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Daytime driving lights (US) X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Home lightsduration X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Automatic driving lights control X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Soft on/off X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Driver's window\One touch open X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Driver's window\One touch close X

[illegible]

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Key memory of heat/AC/ventilation X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Recirculated air memory X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Set fan power X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Correction set temperature X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								A/C on with ignition on key 1 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								A/C on with ignition on key 2 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								A/C on with ignition on key 3 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								A/C on with ignition on key 4 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Auto fan control on with ignition on Key 1 X

BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Auto fan control on with ignition on Key 2 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Auto fan control on with ignition on Key 3 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Auto fan control on with ignition on Key 4 X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Volume level X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Seat/memory position X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Easy entry steering wheel\Longitudinal X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	Car/Key memory								Easy entry steering wheel\Tilting X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	PM Power module								Display history of battery replacement X
BMW	All	2001 - 2008	7 Series_E 65/E66/E 67/E68	730d, 730i, 730Ld , 730Li, 735i, 735 Li, 740i, 740Li, 7 45i, 745Li, 750i, 750Li, 760i, 760L i	Service functions	PM Power module								Register battery replacement X

BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Quick test	Quick test		X	X	X			
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Drive	DME2/DME2 Digital motor electronics 2		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Drive	CAS Car Access System		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Drive	EKPS Fuel-pump control		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Drive	VTG Transfer case		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Drive	GWS Gear selector switch		X	X	X	X	X	

BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	DSC (Bosch) Dynamic Stability Control		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	EMF Parking brake		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	EPS Electronic Power Steering		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	EHC Electronic Ride-Height Control		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	ICM Integronic Power Steering		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	SME Accumulator management electronics		X	X	X	X		
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	AL active steering		X	X	X	X		
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	RDC/RDW Tyre pressure check		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	EDCSVL Damper satellite, front left		X	X	X	X	X	

BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	EDCSVR Damper satellite, front right		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	EDCSHL Damper satellite, rear left		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	EDCSHR Damper satellite, rear right		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	VDM Vertical dynamics management		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Chassis	SVT Servotronic		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	AMPT Top Hi-Fi amplifier		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	SWW Lane change warning		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	INSTR Instrument cluster		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	ACSM Crash Safety Module		X	X	X	X	X	

BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	FRM Footwell module		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	JBE Junction-box electronics		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	FZD function centre, roof		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	CID Central Information Display		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	ZGM Central Gateway Module		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	SZL Switch center, steering column		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	CON Controller		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	CIC/CHAMP Car headunit column		X	X	X	X	X	

BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	DVDC DVD Changer		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	SMFA Seat module, driver		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	SMBF Seat module, passenger		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	TRSVC All round view camera		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	HKL Rear-lid module		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	FKA Rear-cabin automatic A/C		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	FD Rear-compartment display		X	X	X	X	X	
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Body	FD2 Rear-compartment display2		X	X	X	X	X	

BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Maintenance\CBS reset								10 Vehicle inspection: X
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Maintenance\CBS reset								11 Exhaust emission inspection: X
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Maintenance\CBS reset								12 Vehicle check-linked X
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Drive\EGS transmission control								Adjustment X
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Chassis\EMF Parking brake\								Renewal of an actuator on brake caliper X
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Chassis\EMF Parking brake\								Renewal of the brake caliper or brake pads X
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Body\Power supply								Register Battery Change X
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Body\IHKA								Drainfill the refrigerant Circuit X
BMW	All	after 2008	7 Series_F01/F02	730d, 730i, 730Ld, 730Li, 735i, 735Li, 740i, 740Li, 745i, 745Li, 750i, 750Li, 760i, 760Li	Service functions	Body\IHKA								Run-in protection for AC compressor X

BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Quick test	Quick test		X	X	X			
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Drive	EML Electronic engine-power control		X	X	X			
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Drive	GR Cruise control		X	X	X			
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Chassis	EDC Electroic Damper Control		X	X	X	X	X	
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Chassis	MFL Multi-function steering wheel		X	X	X			
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Chassis	SVT Servotronic		X					
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Chassis	RDC/RDW Tyre pressure check		X			X		
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Chassis	EPS Electronic Power Steering		X	X	X	X		
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			

BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	IHKA/IHKB Integrated heating/air conditioning		X	X	X	X	X	
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	KOM/IKE/IKI/INSTR (Instrument cluster)		X	X	X	X	X	
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	CVM Convertible top module		X	X	X	X		
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	NAV Navigation computer		X	X	X	X		
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	SHD Sliding/tinting sunroof		X	X	X			
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	SMF/SM/SLM (Seat memory, driver)		X	X	X	X	X	
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	MID Multi Information Display		X	X	X			
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	SZM Switching center, center console		X	X	X	X		
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	RLS/AIC (Rain/Light Sensor/Automatic interval Control)		X	X	X	X		
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	TCU/ULF/TEL/BIT (Telematic Control unit)		X	X	X			
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	BM/MIR (On-board monitor/Multi-Information Radio)		X	X	X	X	X	
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	VID Video module		X	X	X			
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	RAD Radio		X	X	X	X	X	
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	STH park heating		X					
BMW	All	1989 - 1999	8 Series_E 31	850i, 850Ci, 850C Si	Body	DSP Digital Sound Processor		X					

BMW	All	1989 - 1999	8 Series_E31	850i, 850Ci, 850C Si	Body	SES Language-input system		X	X	X		X	
BMW	All	1989 - 1999	8 Series_E31	850i, 850Ci, 850C Si	Service functions	Drive\Digital Motor Electronics							1.Clear adaptations X
BMW	All	1989 - 1999	8 Series_E31	850i, 850Ci, 850C Si	Service functions	Drive\Digital Motor Electronics							2.CO adjustment X
BMW	All	1989 - 1999	8 Series_E31	850i, 850Ci, 850C Si	Service functions	Drive\EGS transmission control							Clear adaptations X
BMW	All	1989 - 1999	8 Series_E31	850i, 850Ci, 850C Si	Service functions	Chassis\Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	1989 - 1999	8 Series_E31	850i, 850Ci, 850C Si	Service functions	Body\Instrument cluster							Reset service interval indicator X
BMW	All	1989 - 1999	8 Series_E31	850i, 850Ci, 850C Si	Service functions	Body\Light Check Module							Read out operating data X
BMW	All	After 2010	X Series_X1-E84	2.0i	Quick test	Quick test		X	X	X			
BMW	All	After 2010	X Series_X1-E84	2.0i	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	After 2010	X Series_X1-E84	2.0i	Drive	CAS Car Access System		X	X	X	X	X	
BMW	All	After 2010	X Series_X1-E84	2.0i	Drive	DME Motor Electronics		X	X	X	X	X	
BMW	All	After 2010	X Series_X1-E84	2.0i	Drive	EGS 6HPTU transmission control		X	X	X	X	X	
BMW	All	After 2010	X Series_X1-E84	2.0i	Drive	GWS Gear selector switch		X	X	X	X	X	
BMW	All	After 2010	X Series_X1-E84	2.0i	Drive	VTG Transfer case		X	X	X	X	X	
BMW	All	After 2010	X Series_X1-E84	2.0i	Chassis	DSC (Bosch) Dynamic Stability Control		X	X	X	X	X	
BMW	All	After 2010	X Series_X1-E84	2.0i	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	After 2010	X Series_X1-E84	2.0i	Body	MRS Multiple Restraint System		X	X	X	X		
BMW	All	After 2010	X Series_X1-E84	2.0i	Body	CCC-GW Gateway		X	X	X	X	X	

BMW	All	After 2010	X Series_X 1-E84	2.0i	Body	FRM Footwell module		X	X	X	X	X	
BMW	All	After 2010	X Series_X 1-E84	2.0i	Body	FLA High Beam Assist		X	X	X	X	X	
BMW	All	After 2010	X Series_X 1-E84	2.0i	Body	FZD Function centre, roof		X	X	X	X	X	
BMW	All	After 2010	X Series_X 1-E84	2.0i	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	After 2010	X Series_X 1-E84	2.0i	Body	JBE Junction Box electronics		X	X	X	X	X	
BMW	All	After 2010	X Series_X 1-E84	2.0i	Body	KOMBI Instrument cluster		X	X	X	X	X	
BMW	All	After 2010	X Series_X 1-E84	2.0i	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	After 2010	X Series_X 1-E84	2.0i	Body	SINE Siren with tilt sensor		X	X	X	X	X	
BMW	All	After 2010	X Series_X 1-E84	2.0i	Service functions	Maintenance\CBS reset							1 Engine oil X
BMW	All	After 2010	X Series_X 1-E84	2.0i	Service functions	Maintenance\CBS reset							3 Front brake X
BMW	All	After 2010	X Series_X 1-E84	2.0i	Service functions	Maintenance\CBS reset							4 Rear brake X
BMW	All	After 2010	X Series_X 1-E84	2.0i	Service functions	Maintenance\CBS reset							8 Brake fluid X
BMW	All	After 2010	X Series_X 1-E84	2.0i	Service functions	Maintenance\CBS reset							9 Vehicle check X
BMW	All	After 2010	X Series_X 1-E84	2.0i	Service functions	Maintenance\CBS reset							10 Vehicle inspection: X
BMW	All	After 2010	X Series_X 1-E84	2.0i	Service functions	Maintenance\CBS reset							11 Exhaust emission inspection: X
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Quick test	Quick test		X	X	X			
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	Quick test (Only for Drive systems)		X	X	X			

BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	VTG Transfer case		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	EHC Electronic Height Control		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	MFL Multi-function steering wheel		X			X		
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	SVT Servotronic		X					
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	MRS/AirBag (Multiple Restraint System)		X	X	X			

BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	IHKR/IHKR Integrated heating/air conditioning		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	MID Multi Information Display		X	X	X			
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	NAV Navigation computer		X	X	X	X		
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	AHL Adaptive directional headlights		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	BM/MIR (On-board monitor/Multi-Information Radio)		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	SZM Switching center, center console		X	X	X	X		
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	SMF/SM/SLM (Seat memory, driver)		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	SHD Sliding/titing sunroof		X	X	X			
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	SES Language-input system		X	X	X		X	

BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	RLS/AIC (Rain/Light Sensor/Automatic interval Control)		X	X	X	X		
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	RAD Radio		X	X	X	X	X	
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	DSP Digital Sound Processor		X					
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	TCU/ULF/TEL/BIT (Telematic Control unit)		X	X	X			
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	VID Video module		X	X	X			
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Drive\Digital Motor Electronics							1.Clear adaptations X 2.CO adjustment X
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Drive\EGS transmission control							Clear adaptations X
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Chassis\Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Body\Instrument cluster							Reset service interval indicator X
BMW	All	After 2003	X Series_X 3-E83	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Body\Light Check Module							Read out operating data X
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Quick test	Quick test		X	X	X			
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	

BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	DME2/DME2 Digital motor electronics 2		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	CAS Car Access System		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	EKPS Fuel-pump control		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	VTG Transfer case		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Drive	GWS Gear selector switch		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	DSC (Bosch) Dynamic Stability Control		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	EMF Parking brake		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	EPS Electronic Power Steering		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	ICM Integrative Power Steering		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	RDC/RDW Tyre pressure check		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	EHC Electronic ride-high control		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	VDM Vertical dynamics management		X	X	X	X	X	

BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Chassis	SVT Servotronic		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	AMPT Top Hi-Fi amplifier		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	SWW Lane change warning		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	INSTR Instrument cluster		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	ACSM Crash Safety Module		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	FRM Footwell module		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	JBE Junction-box electronics		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	FZD function centre, roof		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	CID Central Information Display		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	ZGM Central Gateway Module		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	SZL Switch center, steering column		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	CON Controller		X	X	X	X	X	

BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	CIC/CHAMP Car headunit column		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	DVDC DVD Changer		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	SMFA Seat module, driver		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	SMBF Seat module, passenger		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	TRSVC All round view camera		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	HKL Rear-lid module		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	VM Video Module		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	ACC Active cruise control		X	X	X	X	X	
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Body	HSR Rear-axle slip-angle control		*	*	*	*		
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Maintenance\CBS reset							1 Engine oil X
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Maintenance\CBS reset							3 Front brake X
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Maintenance\CBS reset							4 Rear brake X

BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Maintenance\CBS reset							8 Brake fluid X
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Maintenance\CBS reset							10 Vehicle inspection: X
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Maintenance\CBS reset							11 Exhaust emission inspection: X
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Maintenance\CBS reset							12 Vehicle check-linked X
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Drive\EGS transmission control							Adjustment X
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Chassis\EMF Parking brake\							Renewal of an actuator on brake caliper X
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Chassis\EMF Parking brake\							Renewal of the brake caliper or brake pads X
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Body\Power supply							Register Battery Change X
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Body\IHKA							Drainfill the refrigerant Circuit X
BMW	All	after 2010	X Series_X 3-F25	X3 2.0i, X3 2.5i, X3 2.5si, X3 3.0i, X3 2.0d	Service functions	Body\IHKA							Run-in protection for AC compressor X
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Quick test	Quick test		X	X	X			
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Drive	EWS Vehicle immobilizer		X	X	X	X		

BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Drive	VTG Transfer case		X	X	X	X	X	
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Chassis	EHC Electronic Height Control		X	X	X	X	X	
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Chassis	MFL Multi-function steering wheel		X			X		
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Chassis	SVT Servotronic		X					
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Body	MRS/AirBag(Multiple Restraint System)		X	X	X			
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Body	IHKA/IHKR Integrated heating/air conditioning		X	X	X	X	X	
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Body	MID Multi Information Display		X	X	X			
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Body	NAV Navigation computer		X	X	X	X		
BMW	All	After 1999	X Series_X 5-E53	3.0i, 4.4i, 4.6is , 4.8is, 3.0d	Body	AHL Adaptive directional headlights		X	X	X	X	X	

[illegible]

BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Quick test	Quick test		X	X	X			
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Drive	CAS Car Access System		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Drive	DME Motor Electronics		*	*	*	*	*	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Drive	EGS 6HPTU transmission control		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Drive	GWS Gear selector switch		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Drive	VTG Transfer case		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Drive	VTC Valvetronic		X					
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Drive	VTC2 Valvetronic 2		X					
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Chassis	AL active front steering (AFS70)		X	X	X	X		
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Chassis	DSC(Bosch)Dynamic Stability Control		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Chassis	ARS Dynamic Drive		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Chassis	EDCSHL Damper satellite, rear left		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Chassis	EDCSHR Damper satellite, rear right		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Chassis	EDCSVL Damper satellite, front left		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Chassis	EDCSVR Damper satellite, front right		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Chassis	EHC Electronic Ride-Height Control		X	X	X	X	X	

BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Chassis	VDM Vertical Dynamics Management		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Chassis	EMF Parking brake		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Chassis	RDC Type Pressure control		X	X	X	X		
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	ACSM Crash Safety Module		X	X	X	X		
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	AMPT Top Hi-Fi amplifier		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	CCC-B0 User interface		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	CCC-GW Gateway		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	CCC-A Applications		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	CCC-ANT Aerial tuner		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	CCC-ASK Audio system controller		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	CDC CD Changer		X	X	X		X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	CA Comfort access system		X	X	X	X		
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	CID Central Information Display		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	FD Rear-cabin display		X	X	X	X		
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	RSE Rear Seat Entertainment		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	CON Controller		X	X	X	X	X	
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	FRM2 Footwell module 2		X	X	X	X	X	

BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	FLA High Beam Assist		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	HUD Head-Up Display		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	FZD Function centre, roof		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	FKA Rear heater/air conditioning		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	JBE2 Junction Box electronics 2		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	INSTR Instrument cluster		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	RFK Reversing camera		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	RLSS Rain/light solar sensor		X	X	X	X		
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	SMFA Seat module, driver		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	SMBF Seat module, passenger		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	TCU Telematic Control Unit		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	VM Video Module		X	X	X	X	X	
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	MOST system analysis				X			
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Body	CAN communication analysis			X				
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Maintenance\CBS reset							1 Engine oil X
BMW	A11	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Maintenance\CBS reset							3 Front brake X

BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Maintenance\CBS reset							4 Rear brake X
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Maintenance\CBS reset							8 Brake fluid X
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Maintenance\CBS reset							9 Vehicle check X
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Maintenance\CBS reset							10 Vehicle inspection: X
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Maintenance\CBS reset							11 Exhaust emission inspection: X
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Drive\CAS Car Access System							1. CAS reset X 2. ELV steering lock fault counter reset X 3. Reset starter interlock X 4. Key number X 5. Enable/Disable key X
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Maintenance\CBS correction vehicle data							CBS correction vehicle data X
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Drive\Diesel Electronics							Injector rate matching X
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Body\Power supply							Register Battery Change X
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Chassis\EMF Parking brake							initialization X
BMW	All	After 2006	X Series_X 5-E70	3.0si, 4.8i	Service functions	Chassis\Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Quick test	Quick test		X	X	X			
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Drive	CAS Car Access System		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Drive	DME Motor Electronics		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Drive	DDE Diesel Electronics		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Drive	EGS 6HPTU transmission control		X	X	X	X	X	

BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Drive	GWS Gear selector switch		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Drive	VTG Transfer case		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Drive	QMVHL Lateral-moment distribution, rear axle		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Drive	EKPS Fuel-pump control		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Chassis	AL active front steering (AFS70)		X	X	X	X		
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Chassis	DSC (Bosch) Dynamic Stability Control		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Chassis	ARS Dynamic Drive		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Chassis	EDCSHL Damper satellite, rear left		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Chassis	EDCSHR Damper satellite, rear right		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Chassis	EDCSVL Damper satellite, front left		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Chassis	EDCSVR Damper satellite, front right		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Chassis	EHC Electronic Ride-Height Control		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Chassis	EMF Parking brake		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Chassis	VDM Vertical Dynamics Management		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Chassis	ICM Integrated Chassis Management		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	ACSM Crash Safety Module		X	X	X	X		

BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	AMPH Hi-Fi amplifier		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	CCC-B0 User interface		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	CCC-GW Gateway		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	CCC-A Applications		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	CCC-ANT Aerial tuner		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	CCC-ASK Audio system controller		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	DAB Digital tuner		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	CDC CD Changer		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	DVD-C DVD changer		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	CID Central Information Display		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	CON Controller		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	FRM2 Footwell module 2		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	FLA High Beam Assist		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	HUD Head-Up Display		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	FZD Function centre, roof		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	JBE2 Junction Box electronics 2		X	X	X	X	X	
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Body	INSTR Instrument cluster		X	X	X	X	X	

BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Service functions	Maintenance\CBS reset							10 Vehicle inspection: X
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Service functions	Maintenance\CBS reset							11 Exhaust emission inspection: X
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Service functions	Maintenance\CBS correction vehicle data							CBS correction vehicle data X
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Service functions	Drive\CAS Car Access System							1.CAS reset X 2.ELV steering lock fault counter reset X 3.Reset starter interlock X 4.Key number X 5.Enable/Disable key X
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Service functions	Body\Power supply							Register Battery Change X
BMW	All	After 2007	X Series_X 6-E71	3.0si, 3.0sd	Service functions	Chassis\EMF Parking brake							initialization X
BMW	All	After 2009	X Series_X 6-E72		Quick test	Quick test		*	*	*			
BMW	All	After 2009	X Series_X 6-E72		Drive	Quick test (Only for Drive systems)		*	*	*			
BMW	All	After 2009	X Series_X 6-E72		Drive	CAS Car Access System		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Drive	DME Motor Electronics		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Drive	GWS Gear selector switch		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Drive	EKPS Fuel-pump control		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Chassis	Quick test (Only for Chassis systems)		*	*	*			
BMW	All	After 2009	X Series_X 6-E72		Chassis	DSC(Bosch)Dynamic Stability Control		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Chassis	EHC Electronic Ride-Height Control		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Chassis	EMF Parking brake		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Chassis	RDC Type Pressure control		*	*	*	*	*	

BMW	All	After 2009	X Series_X 6-E72		Chassis	EPS Electronic Power Steering		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	Quick test (Only for Body systems)		*	*	*			
BMW	All	After 2009	X Series_X 6-E72		Body	AMPT Amplifier		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	CA Comfort access system		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	CIC Car information computer		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	CIC-GW Gateway		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	CID Central Information Display		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	CON Controller		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	DVD-C DVD changer		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	EKK Electric A/C compressor		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	FD Rear-cabin display		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	FKA Rear-compartment air conditioning		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	FLA High Beam Assist		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	FRM Dirver's side footwell module		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	FZD Roof function centre		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	HIM Hybrid interface module		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	HKL Rear-lid module		*	*	*	*	*	
BMW	All	After 2009	X Series_X 6-E72		Body	HUD Head-up display		*	*	*	*	*	

[illegible]

BMW	All	After 2009	X Series_X 6-E72		Service functions	Maintenance\CBS reset							Il Exhaust emission inspection: X
BMW	All	After 2009	X Series_X 6-E72		Service functions	Maintenance\CBS correction vehicle data							CBS correction vehicle data X
BMW	All	After 2009	X Series_X 6-E72		Service functions	Drive\CAS Car Access System							1.CAS reset X 2.ELV steering lock fault counter reset X 3.Reset starter interlock X 4.Key number X 5.Enable/Disable key X
BMW	All	After 2009	X Series_X 6-E72		Service functions	Body\Power supply							Register Battery Change X
BMW	All	After 2009	X Series_X 6-E72		Service functions	Chassis\EMF Parking brake							initialization X
BMW	All	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z3_2.5	Quick test	Quick test		X	X	X			
BMW	All	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z3_2.5	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z3_2.5	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z3_2.5	Drive	EML Electronic engine-power control		X	X	X			
BMW	All	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z3_2.5	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z3_2.5	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z3_2.5	Drive	GR Cruise control		X	X	X			
BMW	All	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z3_2.5	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z3_2.5	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z3_2.5	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z3_2.5	Chassis	EDC Electroic Damper Control		X	X	X	X	X	
BMW	All	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z3_2.5	Chassis	RDC/RDW Tyre pressure check		X	X	X			

BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Chassis	EPS Electronic Power Steering		X	X	X	X		
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Chassis	MFL Multi-function steering wheel		X			X		
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Chassis	SVT Servotronic		X					
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	Quick test (Only for Body systems)		X	X	X			
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	IHKA/IHKB Integrated heating/air conditioning		X	X	X	X	X	
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	CVM Convertible top module		X	X	X	X		
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	NAV Navigation computer		X	X	X	X		
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	SHD Sliding/tinting sunroof		X	X	X			
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	SMF/SM/SLM (Seat memory, driver)		X	X	X	X	X	
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	MID Multi Information Display		X	X	X			
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	SZM Switching center,center console		X	X	X	X		
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3,Z3_3.0,Z 3_2.5	Body	RLS/AIC (Rain/Light Sensor/Automatic interval Control)		X	X	X	X		

BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Body	TCU/ULF/TEL/BIT (Telematic Control unit)		X	X	X			
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Body	BM/MIR (On-board monitor/Multi-Information Radio)		X	X	X	X	X	
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Body	VID Video module		X	X	X			
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Body	RAD Radio		X	X	X	X	X	
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Body	STH park heating		X					
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Body	DSP Digital Sound Processor		X					
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Body	SES Language-input system		X	X	X		X	
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Service functions	Drive\Digital Motor Electronics							1.Clear adaptations X
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Service functions	Drive\Digital Motor Electronics							2.CO adjustment X
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Service functions	Drive\EGS transmission control							Clear adaptations X
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Service functions	Chassis\Wheel-slip control system							Adjustment, steering-angle sensor X
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Service functions	Body\Instrument cluster							Reset service interval indicator X
BMW	A11	1989-1991	Z Series_Z 1-E30	Z3_2.3, Z3_3.0, Z 3_2.5	Service functions	Body\Light Check Module							Read out operating data X
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Quick test	Quick test		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Drive	EML Electronic engine-power control		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Drive	EGS transmission control		X	X	X	X	X	

BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Drive	GR Cruise control		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Chassis	EDC Electroic Damper Control		X	X	X	X	X	
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Chassis	RDC/RDW Tyre pressure check		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Chassis	EPS Electronic Power Steering		X	X	X	X		
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Chassis	MFL Multi-function steering wheel		X			X		
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Chassis	SVT Servotronic		X					
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	Quick test (Only for Body systems)		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	IHKA/IHKB Integrated heating/air conditioning		X	X	X	X	X	
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	KOM/IKE/IK1/INSTR (Instrument cluster)		X	X	X	X	X	
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	CVM Convertible top module		X	X	X	X		

BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	NAV Navigation computer		X	X	X	X		
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	SHD Sliding/tilting sunroof		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	SMF/SM/SLM (Seat memory, driver)		X	X	X	X	X	
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	MID Multi Information Display		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	SZM Switching center, center console		X	X	X	X		
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	RLS/AIC (Rain/Light Sensor/Automatic interval Control)		X	X	X	X		
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	TCU/ULF/TEL/BIT (Telematic Control unit)		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	BM/MIR (On-board monitor/Multi-Information Radio)		X	X	X	X	X	
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	VID Video module		X	X	X			
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	RAD Radio		X	X	X	X	X	
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	STH park heating		X					
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	DSP Digital Sound Processor		X					
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Body	SES Language-input system		X	X	X		X	
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Service functions	Drive\Digital Motor Electronics							1.Clear adaptations X
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Service functions	Drive\Digital Motor Electronics							2.CO adjustment X
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Service functions	Drive\EGS transmission control							Clear adaptations X
BMW	A11	1996-2002	Z Series_Z 3-E36	Z3_2.3, Z3_3.0, Z 3_2.5	Service functions	Chassis\Wheel-slip control system							Adjustment, steering-angle sensor X

BMW	All	1996-2002	Z Series_Z 3-E36	Z3_2.3,Z3_3.0,Z 3_2.5	Service functions	Body\Instrument cluster							Reset service interval indicator X
BMW	All	1996-2002	Z Series_Z 3-E36	Z3_2.3,Z3_3.0,Z 3_2.5	Service functions	Body\Light Check Module							Read out operating data X
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Quick test	Quick test		X	X	X			
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Drive	EML Electronic engine-power control		X	X	X			
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Drive	EWS Vehicle immobilizer		X	X	X	X		
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Chassis	EPS Electronic Power Steering		X	X	X	X		
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Chassis	MFL Multi-function steering wheel		X			X		
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	Quick test (Only for Body systems)		X	X	X			
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	CVM Convertible top module		X	X	X	X		
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	BM/MIR (On-board monitor/Multi-Information Radio)		X	X	X	X	X	
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	IHKA/IHKB Integrated heating/air conditioning		X	X	X	X	X	

BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	SBSL Satellite,B-pillar, left		X	X	X	X		
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	SBSR Satellite,B-pillar, right		X	X	X	X		
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	NAV Navigation computer		X	X	X	X		
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	SMF/SM/SLM (Seat memory ,driver)		X	X	X	X	X	
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	MID Multi Information Display		X	X	X			
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	SZM Switching center,center console		X	X	X	X		
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	RLS/AIC (Rain/Light Sensor/Automatic interval Control)		X	X	X	X		
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	TCU/ULF/TEL/BIT (Telematic Control unit)		X	X	X			
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	VID Video module		X	X	X			
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	RAD Radio		X	X	X	X	X	
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	STH park heating		X					
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	DSP Digital Sound Processor		X					
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i ,Z4_3.0i	Body	SES Language-input system		X	X	X		X	

BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i,Z4_3.0i	Body	SHD Sliding/titing sunroof		X	X	X			
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i,Z4_3.0i	Service functions	Chassis\Wheel-slip control system							Adjustment,steering-angle sensor X
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i,Z4_3.0i	Service functions	Body\Instrument cluster							Reset service interval indicator X
BMW	All	After 2002	Z Series_Z 4-E85	Z4_2.2i,Z4_2.5i,Z4_3.0i	Service functions	Body\Light Check Module							Read out operating data X
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Quick test	Quick test		X	X	X			
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Drive	CAS Car Access System		X	X	X	X		
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Drive	EGS transmission control		X	X	X	X	X	
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Drive	EKPS Fuel-pump control		X	X	X	X	X	
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Chassis	DSC Dynamic Stability Control		X	X	X	X		
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Chassis	EMF Parking brake		X	X	X	X	X	
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Body	IHKA Integrated automatic heating/air conditioning		X	X	X	X	X	
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Body	INSTR Instrument cluster		X	X	X	X	X	
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X	X	X	
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Body	CTM Soft top module		X	X	X	X	X	
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Body	FRM Footwell module		X	X	X	X	X	
BMW	All	2009	Z Series_Z 4-E89	Z4_3.0i	Body	JBE Junction Box electronics		X	X	X	X	X	

BMW	A11	2009	Z Series_Z 4-E89	Z4_3.0i	Body	FZD Function centre, roof		X	X	X	X	X	
BMW	A11	2009	Z Series_Z 4-E89	Z4_3.0i	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	A11	2009	Z Series_Z 4-E89	Z4_3.0i	Body	DWA anti-theft alarm system		X	X	X	X	X	
BMW	A11	2009	Z Series_Z 4-E89	Z4_3.0i	Service functions	Maintenance\CBS reset							1 Engine oil X
BMW	A11	2009	Z Series_Z 4-E89	Z4_3.0i	Service functions	Maintenance\CBS reset							3 Front brake X
BMW	A11	2009	Z Series_Z 4-E89	Z4_3.0i	Service functions	Maintenance\CBS reset							4 Rear brake X
BMW	A11	2009	Z Series_Z 4-E89	Z4_3.0i	Service functions	Maintenance\CBS reset							8 Brake fluid X
BMW	A11	2009	Z Series_Z 4-E89	Z4_3.0i	Service functions	Maintenance\CBS reset							9 Vehicle check X
BMW	A11	2009	Z Series_Z 4-E89	Z4_3.0i	Service functions	Maintenance\CBS reset							10 Vehicle inspection: X
BMW	A11	2009	Z Series_Z 4-E89	Z4_3.0i	Service functions	Maintenance\CBS reset							11 Exhaust emission inspection: X
BMW	A11	2009	Z Series_Z 4-E89	Z4_3.0i	Service functions	Chassis\EMF Parking brake							Startup X
BMW	A11	2009	Z Series_Z 4-E89	Z4_3.0i	Service functions	Chassis\EMF Parking brake							Workshop mode X
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Quick test	Quick test		X	X	X			
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Drive	Quick test (Only for Drive systems)		X	X	X			
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Drive	DME/DDE (Motor/Diesel Electronics)		X	X	X	X	X	
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Drive	EML Electronic engine-power control		X	X	X			
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Drive	EGS transmission control		X	X	X	X	X	
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Drive	EWS Vehicle immobilizer		X	X	X	X		

BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Chassis	Quick test (Only for Chassis systems)		X	X	X			
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Chassis	ABS/ASC/DSC (Dynamic Stability Control)		X	X	X	X	X	
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Chassis	LEW/LWS (Steering angle sensor)		X	X	X	X		
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Chassis	EPS Electronic Power Steering		X	X	X	X		
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Chassis	MFL Multi-function steering wheel		X			X		
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	Quick test (Only for Body systems)		X	X	X			
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	ZKE/GM (Central body electronics/GM base module)		X	X	X	X	X	
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	CVM Convertible top module		X	X	X	X		
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	BM/MIR (On-board monitor/Multi-Information Radio)		X	X	X	X	X	
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	IHKA/IHKB Integrated heating/air conditioning		X	X	X	X	X	
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	KOM/IKE/IKI/INSTR(Instrument cluster)		X	X	X	X	X	
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	LSZ/LCM (Lights switching center)		X	X		X	X	
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	LRA Automatic headlight vertical aim control		X	X	X			
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	SBSL Satellite, B-pillar, left		X	X	X	X		
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	SBSR Satellite, B-pillar, right		X	X	X	X		
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	MRS/AirBag/SIM (Multiple Restraint System)		X	X	X			
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	PDC Park Distance Control		X	X	X	X	X	
BMW	A11	2000-2003	Z Series_Z 8-E52	Z8_S62	Body	NAV Navigation computer		X	X	X	X		

[illegible]