

# Bars Professional



**JAGUAR**

VERSION: 2V04 DATE: DEC, 2012

## MODELS LIST:

S-TYPE	2000 ~ 2001	2.5L Normally aspirated V6
	2002 ~ 2003	3.0L normally aspirated V6
		4.2L normally aspirated V8
		4.2L supercharged V8
	2004 ~ 2006	2.5L normally aspirated V6
		3.0L normally aspirated V6
		4.2L super charge V8
	2006 ~ 2008	2.5L normally aspirated V6
		3.0L normally aspirated V6
		4.2L normally aspirated V8
		4.2L supercharge V8
		Diesel fuel capability
MODEL X-TYPE	2001	2.0L AJ61
	2001	2.5L AJ61
	2001	3.0L AJ61
	2003	2.0L AJ61
	2003	2.5L AJ61
	2003	3.0L AJ61
	2004 - 2008	2.0L AJ61
	2004 - 2008	2.5L AJ61
	2004 - 2008	3.0L AJ61
	2004 - 2008	2.0L Duratorq TDCi
	2004 - 2008	2.2L Duratorq TDCi
	2008	2.0L AJ61
	2008	2.5L AJ61

	2008	3.0L AJ61
	2008	2.0L Duratorq TDCi
	2008	2.2L Duratorq TDCi
	2009	2.0L AJ61
	2009	2.5L AJ61
	2009	3.0L AJ61
	2009	2.0L Duratorq TDCi
	2009	2.2L Duratorq TDCi
MODEL XJ-Series	1998	1998 4.0L
	2002.5	3.0L Normally aspirated V6
	2002.5	3.5L Normally aspirated V8
	2002.5	4.2L Normally aspirated V8
	2002.5	4.2L Supercharged V8
	2005	3.0L Normally aspirated V6
	2005	3.5L Normally aspirated V8
	2005	4.2L Normally aspirated V8
	2005	4.2L Supercharged V8
	2006	3.0L Normally aspirated V6
	2006	3.5L Normally aspirated V8
	2006	4.2L Normally aspirated V8
	2006	4.2L Supercharged V8
	2006	2.7L Diesel V6
	2008 - 2009	3.0L Normally aspirated V6
	2008 - 2009	3.5L Normally aspirated V8
	2008 - 2009	4.2L Supercharged V8
	2008 - 2009	Diesel V6
	2010 - 2011	3.0L Normally aspirated V6
MODEL XJ8-TYPE	2000	4.0L
	2001~2002	3.2L
MODEL XKR-TYPE	2003	4.2L Normally aspirated V8
MODEL XKR-TYPE	2003	4.2L Supercharged V8
	2006 ~ 2009	Normally aspirated V8 3.5L
	2006 ~ 2009	Normally aspirated V8 4.2L

	2006 ~ 2009	Supercharged V8
	2010 ~ 2011	Normally aspirated V8
	2010 ~ 2011	Supercharged V8
MODEL XF-TYPE	2008	Normally aspirated V6
		Supercharged V8
		Diesel V6
	2010 - 2011	Normally aspirated V8 4.2L

**Models equipped with OBD-II Connector, SELECT BY MODEL:**

<b>S-TYPE</b>		<b>MODEL</b>	<b>YEAR</b>	<b>SYSTEM</b>	<b>READ FAULT CODE</b>	<b>CLEAR FAULT CODE</b>	<b>DATA STREAM</b>	<b>CODING</b>	<b>Activation</b>		
					+	+	+	+	+		
S-TYPE	00 – 01			ENGINE	+	+	+				
				AT	+	+	+				
				ABS	+	+	+				
				SRS	+	+	+				
				GEM (Generic Electric Module)	+	+	+				
				DDM (Drivers Door Module)	+	+	+				
				DSM (Driver Seat Module)	+	+	+				
				REM (Rear Electric Module)	+	+	+				
				CCM (Climate Control System)	+	+	+				
				ACM (Audio Control Module)	+	+	+				
				ICM (Instrument Pack System)	+	+	+				
				MCM (Message Center Control Module)	+	+	+				
				PAM (Parking aid control module)	+	+	+				
				Suspension	+	+	+				

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE 2.5L Normally aspirated V6	2002 ~ 2003	ENGINE	+	+	+		+
		AT	+	+	+		
		ABS	+	+	+		+
		RCM/SRS	+	+	+		
		ICM (Instrument Pack System)	+	+	+		+
		Climate control module	+	+	+		
		General electronics control	+	+			
		Driver's door module	+	+			
		Driver seat module	+	+			
		Rear electronic control module	+	+			
		ACM ( Audio control module )	+	+			
		Electronic parking brake	+	+			
		Intrusion sensor	+	+			
		Steering column lock module	+	+			
MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE 3.0L normally aspirated V6	2002 ~ 2003	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		RCM/SRS	+	+	+		
		ICM ( Instrument pack system )	+	+	+		
		Climate control module	+	+	+		
		General electronics control module	+	+			
		Driver's door module	+	+			
		Driver seat module	+	+			
		Rear electronic control module	+	+			
		ACM ( Audio control module )	+	+			
		Electronic parking brake	+	+			
		Navigation control module	+	+			
		Headlamp levelling system	+	+			
		PAM (Parking aid control module)	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE 4.2L normally aspirated V8	2002 ~2003	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		RCM/SRS	+	+	+		
		ICM (Instrument pack system)	+	+	+		
		Climate control module	+	+	+		
		General electronics control module	+	+			
		Driver's door module	+	+			
		Driver's seat module	+	+			
		Rear electronic control module	+	+			
		ACM (Audio control module)	+	+			
		Electronic parking brake	+	+			
		Intrusion sensor module	+	+			
		Steering column lock module	+	+			
		PAM (Parking aid control module)	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE 4.2L supercharged V8	2002 ~ 2003	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		RCM/SRS	+	+	+		
		ICM (Instrument pack system)	+	+	+		
		Climate control module	+	+	+		
		General electronics control module	+	+			
		Driver's door module	+	+			
		Driver's seat module	+	+			
		Rear electronic control module	+	+			
		ACM (Audio control module)	+	+			
		Electronic parking brake	+	+			
		Intrusion sensor module	+	+			
		Steering column lock module	+	+			
		Navigation control module	+	+			
		Headlamp levelling system	+	+			
		Adaptive damping ride control	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE 2.5L normally aspirated V6	2004 ~2006	ENGINE	+	+	+		+
		AT	+	+	+		
		ABS	+	+	+		+
		RCM/SRS	+	+	+		
		ICM (Instrument pack system)	+	+	+	+	
		Climate control module	+	+	+	+	
		Parking brake control module	+	+			
		General electronics control module	+	+			
		Intrusion sensor module	+	+			
		Headlamp levelling system	+	+			
		ACM (Audio control module)	+	+			
		Driver's door module	+	+			
		Rear electronic control module	+	+			
		Steering column lock module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE 3.0L normally aspirated V6	2004 ~2006	ENGINE	+	+	+		+
		AT	+	+	+		
		ABS	+	+	+		+
		SRS	+	+	+		
		GEM (Generic Electric Module)	+	+	+		
		DDM (Drivers Door Module)	+	+	+		
		DSM (Driver Seat Module)	+	+	+		
		REM (Rear Electric Module)	+	+	+		
		ACM (Audio Control Module)	+	+	+		
		SSM (Adaptive Damping Ride Control)	+	+	+		
		HLM (Headlamp Leveling System)	+	+	+		
		Instrument cluster control module	+	+	+		+
		Climate control module	+	+	+		+

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE 4.2L normally aspirated V8	2004 ~ 2006	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		RCM/SRS	+	+	+		
		ICM (Instrument pack system)	+	+	+		
		Climate control module	+	+	+		
		Parking brake control module	+	+			
		General electronics control module	+	+			
		Intrusion sensor module	+	+			
		Driver's door module	+	+			
		Driver's seat module	+	+			
		Rear electronic control module	+	+			
		PAM(Parking aid control module)	+	+			
		ACM (Audio control module)	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE 4.2L supercharge V8	2004 ~ 2006	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		RCM/SRS	+	+	+		
		ICM (Instrument pack system)	+	+	+		
		Climate control module	+	+	+		
		Parking brake control module	+	+			
		General electronics control module	+	+			
		Intrusion sensor module	+	+			
		Driver's seat module	+	+			
		Rear electronic control module	+	+			
		PAM (Parking aid control module)	+	+			
		ACM (Audio control module)	+	+			
		Headlamp levelling system	+	+			
		Navigation control module	+	+			
		Adaptive damping ride control	+	+			
		Steering column lock module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE Diesel fuel capability	2004 ~ 2006	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		ICM (Instrument Pack System)	+	+	+		
		AC	+	+	+		
		RCM/SRS	+	+	+		
		Parking brake control module	+	+			
		General electronics control module	+	+			
		Intrusion sensor module	+	+			
		Driver's door module	+	+			
		Driver's seat module	+	+			
		Rear electronic control module	+	+			
		PAM (Parking aid control module)	+	+			
		ACM(Audio control module)	+	+			
		Headlamp levelling system	+	+			
		Navigation control module	+	+			
		Steering column lock module	+	+			
		Auxiliary heater control module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE 2.5L normally aspirated V6	2006 ~ 2008	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		ICM (Instrument pack system)	+	+	+		
		AC	+	+	+		
		Parking brake control module	+	+			
		RCM/SRS	+	+	+		
		Intrusion sensor module	+	+			
		PAM (Parking aid control module)	+	+			
		ACM (Audio control module)	+	+			
		Driver's door module	+	+			
		General electronics control module	+	+			
		Rear electronic control module	+	+			
		Tire pressure monitor module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE 3.0L normally aspirated V6	2006 ~ 2008	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		ICM(Instrument pack system)	+	+	+		
		AC	+	+	+		
		Parking brake control module	+	+			
		RCM/SRS	+	+	+		
		Intrusion sensor module	+	+			
		PAM(Parking aid control module)	+	+			
		ACM(Audio control module)	+	+			
		Driver's door module	+	+			
		Driver's seat module	+	+			
		General electronics control module	+	+			
		Rear electronic control module	+	+			
		Navigation control module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE 4.2L normally aspirated V8	2006 ~ 2008	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		ICM(Instrument pack system)	+	+	+		
		AC	+	+	+		
		Parking brake control module	+	+			
		RCM/SRS	+	+	+		
		Intrusion sensor module	+	+			
		PAM(Parking aid control module)	+	+			
		ACM(Audio control module)	+	+			
		Driver's seat module	+	+			
		General electronics control module	+	+			
		Rear electronic control module	+	+			
		Navigation control module	+	+			
		Tire pressure monitor module	+	+			
		Steering column lock module	+	+			
		Headlamp levelling system	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE 4.2L supercharge V8	2006 ~ 2008	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		ICM(Instrument pack system)	+	+	+		
		AC	+	+	+		
		Parking brake control module	+	+			
		RCM/SRS	+	+	+		
		Intrusion sensor module	+	+			
		PAM(Parking aid control module)	+	+			
		ACM(Audio control module)	+	+			
		Driver's door module	+	+			
		Driver's seat module	+	+			
		General electronics control module	+	+			
		Rear electronic control module	+	+			
		Navigation control module	+	+			
		Tire pressure monitor module	+	+			
		Adaptive damping ride control	+	+			
		Headlamp levelling system	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
S-TYPE Diesel fuel capability	2006 ~ 2008	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		ICM(Instrument pack system)	+	+	+		
		AC	+	+	+		
		Parking brake control module	+	+			
		RCM/SRS	+	+	+		
		Intrusion sensor module	+	+			
		PAM(Parking aid control module)	+	+			
		ACM(Audio control module)	+	+			
		Driver's door module	+	+			
		Driver's seat module	+	+			
		General electronics control module	+	+			
		Rear electronic control module	+	+			
		Navigation control module	+	+			
		Tire pressure monitor module	+	+			
		Steering column lock module	+	+			
		Headlamp levelling system	+	+			
		Auxiliary heater control module	+	+			

**X-TYPE**

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 2.0L AJ61	2001	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		SRS	+	+	+		
		GEM (Generic Electric Module)	+	+			
		ACM (Audio Control Module)	+	+	+		
		ICM (Instrument Pack System)	+	+	+		
		Climate control module	+	+			
		Headlamp levelling system	+	+			
		PAM(Parking aid control module)	+	+			
		Intrusion sensor module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 2.5L AJ61	2001	ENGINE	+	+	+		
		ABS	+	+	+		
		SRS	+	+	+		
		GEM (Generic Electric Module)	+	+			
		ACM (Audio Control Module)	+	+			
		ICM (Instrument Pack System)	+	+	+		
		Climate control module	+	+	+		
		Navigation control module	+	+			
		Intrusion sensor module	+	+			
		AT	+	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 3.0L AJ61	2001	ENGINE	+	+	+		
		ABS	+	+	+		
		RCM/SRS(Restrain control module)	+	+	+		
		ICM(Instrument pack system)	+	+	+		
		GEM (Generic elec. module)	+	+			
		ACM (Audio control module)	+	+			
		Climate control module	+	+	+		
		Navigation control module	+	+			
		Intrusion sensor module	+	+			
		PAM(Parking aid control module)	+	+			
		AT	+	+	+	+	

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 2.0L AJ61	2003	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		RCM/SRS(Restrain control module)	+	+	+		
		ICM(Instrument pack system)	+	+	+		
		GEM (Generic elec. module)	+	+			
		ACM (Audio control module)	+	+			
		Climate contrl module	+	+	+		
		Intrusion sensor module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 2.5L AJ61	2003	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		SRS	+	+	+		
		GEM (Generic Electric Module)	+	+	+		
		ACM (Audio Control Module)	+	+	+		
		ICM (Instrument Pack System)	+	+	+		+
		Climate control module	+	+	+		
		Headlamp levelling system	+	+			
		PAM(Parking aid control module)	+	+			
		Intrusion sensor module	+	+			
		Navigation control module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 3.0L AJ61	2003	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		SRS	+	+	+		
		GEM (Generic Electric Module)	+	+	+		
		ACM (Audio Control Module)	+	+	+		
		ICM (Instrument Pack System)	+	+	+		+
		Climate control module	+	+	+		
		Headlamp levelling system	+	+			
		PAM(Parking aid control module)	+	+			
		Intrusion sensor module	+	+			
		Navigation control module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 2.0L AJ61	2004 - 2008	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		RCM/SRS(Restrain control module)	+	+	+		
		ICM(Instrument pack system)	+	+	+		
		GEM (Generic elec. module)	+	+			
		ACM (Audio control module)	+	+			
		Climate contrl module	+	+	+		
		PAM(Parking aid control module)	+	+			
		Intrusion sensor module	+	+			
		Driver's seat module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 2.5L AJ61	2004 - 2008	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		SRS	+	+	+		
		GEM (Generic Electric Module)	+	+			
		ACM (Audio Control Module)	+	+			
		ICM (Instrument Pack System)	+	+	+		
		Climate control module	+	+	+		
		Intrusion sensor module	+	+			
		Driver's seat module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 3.0L AJ61	2004 – 2008	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		SRS	+	+	+		
		GEM (Generic Electric Module)	+	+			
		ACM (Audio Control Module)	+	+			
		ICM (Instrument Pack System)	+	+	+		
		Climate control module	+	+	+		
		PAM(Parking aid control module)	+	+			
		Intrusion sensor module	+	+			
		Driver's seat module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	Activation
X-TYPE 2.0L Duratorq TDCi	2004 – 2008	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		SRS	+	+	+	
		GEM (Generic Electric Module)	+	+	+	
		ACM (Audio Control Module)	+	+	+	
		ICM (Instrument Pack System)	+	+	+	+
		Climate control module	+	+	+	
		PAM(Parking aid control module)	+	+		
		Intrusion sensor module	+	+		
		Driver's seat module	+	+		
		Fuel fired heater module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	Activation
X-TYPE 2.2L Duratorq TDCi	2004 – 2008	ENGINE	+	+	+	
		ABS	+	+	+	
		SRS	+	+	+	
		GEM (Generic Electric Module)	+	+		
		ACM (Audio Control Module)	+	+		
		ICM (Instrument Pack System)	+	+	+	
		Climate control module	+	+	+	
		PAM(Parking aid control module)	+	+		
		Intrusion sensor module	+	+		
		Driver's seat module	+	+		
		Fuel fired heater module	+	+		
		Navigation control module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 2.0L AJ61	2008	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		RCM/SRS(Restrain control module)	+	+	+		
		ICM(Instrument pack system)	+	+	+		
		GEM (Generic elec. module)	+	+			
		ACM (Audio control module)	+	+			
		Climate control module	+	+	+		
		Headlamp levelling system	+	+			
		PAM(Parking aid control module)	+	+			
		Intrusion sensor module	+	+			
		Driver's seat module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 2.5L AJ61	2008	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		SRS	+	+	+		
		GEM (Generic Electric Module)	+	+			
		ACM (Audio Control Module)	+	+			
		ICM (Instrument Pack System)	+	+	+		
		Climate control module	+	+	+		
		Intrusion sensor module	+	+			
		Driver's seat module	+	+			
		Navigation control module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 3.0L AJ61	2008	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		SRS	+	+	+		
		GEM (Generic Electric Module)	+	+			
		ACM (Audio Control Module)	+	+			
		ICM (Instrument Pack System)	+	+	+		
		Climate control module	+	+	+		
		Driver's seat module	+	+			
		Headlamp levelling system	+	+			
		Intrusion sensor module	+	+			
		Navigation control module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	Activation
X-TYPE 2.0L Duratorq TDCi	2008	ENGINE	+	+	+	
		ABS	+	+	+	
		SRS	+	+	+	
		GEM (Generic Electric Module)	+	+		
		ACM (Audio Control Module)	+	+		
		ICM (Instrument Pack System)	+	+	+	
		Climate control module	+	+	+	
		Driver's seat module	+	+		
		Intrusion sensor module	+	+		
		Fuel fired heater module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	Activation
X-TYPE 2.2L Duratorq TDCi	2008	ENGINE	+	+	+	
		ABS	+	+	+	
		SRS	+	+	+	
		GEM (Generic Electric Module)	+	+		
		ACM (Audio Control Module)	+	+		
		ICM (Instrument Pack System)	+	+	+	
		Climate control module	+	+	+	
		Driver's seat module	+	+		
		Fuel fired heater module	+	+		
		Intrusion sensor module	+	+		
		Navigation control module	+	+		
		Headlamp levelling system	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 2.0L AJ61	2009	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		RCM/SRS(Restrain control module)	+	+	+		
		ICM(Instrument pack system)	+	+	+		
		GEM (Generic elec. module)	+	+			
		ACM (Audio control module)	+	+			
		Climate control module	+	+	+		
		PAM(Parking aid control module)	+	+			
		Intrusion sensor module	+	+			
		Driver's seat module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 2.5L AJ61	2009	ENGINE	+	+	+		
		ABS	+	+	+		
		SRS	+	+	+		
		GEM (Generic Electric Module)	+	+			
		ACM (Audio Control Module)	+	+			
		ICM (Instrument Pack System)	+	+	+		
		Climate control module	+	+	+		
		Intrusion sensor module	+	+			
		Driver's seat module	+	+			
		AT	+	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING	Activation
X-TYPE 3.0L AJ61	2009	ENGINE	+	+	+		
		AT	+	+	+		
		ABS	+	+	+		
		SRS	+	+	+		
		GEM (Generic Electric Module)	+	+			
		ACM (Audio Control Module)	+	+			
		ICM (Instrument Pack System)	+	+	+		
		Climate control module	+	+	+		
		Driver's seat module	+	+			
		Headlamp levelling system	+	+			
		Intrusion sensor module	+	+			
		Navigation control module	+	+			

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	Activation
X-TYPE 2.0L Duratorq TDCi	2009	ENGINE	+	+	+	
		ABS	+	+	+	
		SRS	+	+	+	
		GEM (Generic Electric Module)	+	+		
		ACM (Audio Control Module)	+	+		
		ICM (Instrument Pack System)	+	+	+	
		Climate control module	+	+	+	
		Navigation control module	+	+		
		Intrusion sensor module	+	+		
		Fuel fired heater module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	Activation
X-TYPE 2.2L Duratorq TDCi	2009	ENGINE	+	+	+	
		ABS	+	+	+	
		SRS	+	+	+	
		GEM (Generic Electric Module)	+	+		
		ACM (Audio Control Module)	+	+		
		ICM (Instrument Pack System)	+	+	+	
		Climate control module	+	+	+	
		Driver's seat module	+	+		
		Fuel fired heater module	+	+		
		Intrusion sensor module	+	+		

**XJ-TYPE**

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 4.0L	1998	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		ICM (Instrument Pack System)	+	+	+	
		Body processor module	+	+	+	
		RCM/SRS	+	+		
		Climate control module	+	+	+	

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 3.0L Normally aspirated V6	2002.5	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate contrl module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Air suspension module	+	+		
		RCM/SRS(Restrain control modult)	+	+	+	
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Left lighting control module	+	+		
		Right lighting control module	+	+		
		Driver's door module	+	+		
		Electronic parking brake	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Navigation control module	+	+		
		Rear electronic control module	+	+		
		Steering column lock module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 3.5L Normally aspirated V8	2002.5	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate contrl module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Air suspension module	+	+		
		RCM/SRS(Restrain control modult)	+	+	+	
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Left lighting control module	+	+		
		Right lighting control module	+	+		
		Driver's door module	+	+		
		Electronic parking brake	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Navigation control module	+	+		
		Rear electronic control module	+	+		
		Steering column lock module	+	+		
		Adaptive speed control module	+	+		
		Driver's seat module	+	+		
		Rear seat control module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 4.2L Normally aspirated V8	2002.5	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate contrl module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Air suspension module	+	+		
		RCM/SRS(Restrain control modult)	+	+	+	
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Left lighting control module	+	+		
		Right lighting control module	+	+		
		Driver's door module	+	+		
		Electronic parking brake	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Navigation control module	+	+		
		Rear electronic control module	+	+		
		Steering column lock module	+	+		
		Adaptive speed control module	+	+		
		Driver's seat module	+	+		
		Rear seat control module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 4.2L Supercharged V8	2002.5	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate contrl module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Air suspension module	+	+		
		RCM/SRS(Restrain control module)	+	+	+	
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Left lighting control module	+	+		
		Right lighting control module	+	+		
		Driver's door module	+	+		
		Electronic parking brake	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Navigation control module	+	+		
		Rear electronic control module	+	+		
		Driver's seat module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 3.0L Normally aspirated V6	2005	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate control module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Air suspension module	+	+		
		RCM/SRS(Restrain control module)	+	+	+	
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Left lighting control module	+	+		
		Right lighting control module	+	+		
		Driver's door module	+	+		
		Electronic parking brake	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Steering column lock module	+	+		
		Rear electronic control module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 3.5L Normally aspirated V8	2005	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate control module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Air suspension module	+	+		
		RCM/SRS(Restrain control module)	+	+	+	
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Left lighting control module	+	+		
		Right lighting control module	+	+		
		Driver's door module	+	+		
		Electronic parking brake	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Steering column lock module	+	+		
		Rear electronic control module	+	+		
		Navigation control module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 4.2L Normally aspirated V8	2005	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate control module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Air suspension module	+	+		
		RCM/SRS(Restrain control module)	+	+	+	
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Left lighting control module	+	+		
		Right lighting control module	+	+		
		Driver's door module	+	+		
		Electronic parking brake	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Rear electronic control module	+	+		
		Driver's seat module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 4.2L Supercharged V8	2005	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate control module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Adaptive speed control module	+	+		
		Air suspension module	+	+		
		Rear climate control module	+	+		
		RCM/SRS(Restrain control module)	+	+	+	
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Left lighting control module	+	+		
		Right lighting control module	+	+		
		Driver's door module	+	+		
		Electronic parking brake	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Navigation control module	+	+		
		Rear electronic control module	+	+		
		Driver's seat module	+	+		
		Steering column lock module	+	+		
		Rear seat control module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 3.0L Normally aspirated V6	2006	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Heating ventilation and air conditioning control module	+	+	+	
		Parking brake control module	+	+		
		Tire pressure monitor module	+	+		
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Driver's door module	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Steering column lock module	+	+		
		Rear electronic control module	+	+		
		Navigation control module	+	+		
		Driver's seat module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 3.5L Normally aspirated V8	2006	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate control module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Parking brake control module	+	+		
		Tire pressure monitor module	+	+		
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Driver's door module	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Rear electronic control module	+	+		
		Navigation control module	+	+		
		Driver's seat module	+	+		
		Steering column lock module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 4.2L Normally aspirated V8	2006	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate control module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Parking brake control module	+	+		
		Tire pressure monitor module	+	+		
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Left lighting control module	+	+		
		Right lighting control module	+	+		
		Driver's door module	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Rear electronic control module	+	+		
		Navigation control module	+	+		
		Driver's seat module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 4.2L Supercharged V8	2006	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate control module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Parking brake control module	+	+		
		Tire pressure monitor module	+	+		
		Adaptive speed control module	+	+		
		Rear climate control module	+	+		
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Driver's door module	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Rear electronic control module	+	+		
		Navigation control module	+	+		
		Driver's seat module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 2.7L Diesel V6	2006	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		ICM (Instrument Pack System)	+	+	+	
		AC	+	+	+	
		Auxiliary heater control module	+	+		
		Parking brake control module	+	+		
		Tire pressure monitor module	+	+		
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Driver's door module	+	+		
		Steering column lock module	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Navigation control module	+	+		
		Rear electronic control module	+	+		
		Driver's seat module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 3.0L Normally aspirated V6	2008 - 2009	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate control module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Parking brake control module	+	+		
		Tire pressure monitor module	+	+		
		Driver's climate seat module	+	+		
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Driver's door module	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Navigation control module	+	+		
		Rear electronic control module	+	+		
		Driver's seat module	+	+		
		Steering column lock module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 3.5L Normally aspirated V8	2008 - 2009	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate control module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Parking brake control module	+	+		
		Tire pressure monitor module	+	+		
		Driver's climate seat module	+	+		
		Rear climate control module	+	+		
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Left lighting control module	+	+		
		Right lighting control module	+	+		
		Driver's door module	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Rear electronic control module	+	+		
		Navigation control module	+	+		
		Driver's seat module	+	+		
		Steering column lock module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 4.2L Supercharged V8	2008 - 2009	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Climate control module	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Parking brake control module	+	+		
		Tire pressure monitor module	+	+		
		Driver's climate seat module	+	+		
		Rear climate control module	+	+		
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Driver's door module	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Rear electronic control module	+	+		
		Driver's seat module	+	+		
		Steering column lock module	+	+		
		Rear seat control module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE Diesel V6	2008 - 2009	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		ICM (Instrument Pack System)	+	+	+	
		AC	+	+	+	
		Parking brake control module	+	+		
		Tire pressure monitor module	+	+		
		Driver's climate seat module	+	+		
		Auxiliary heater control module	+	+		
		Intrusion sensor module	+	+		
		PAM(Parking aid control module)	+	+		
		Driver's door module	+	+		
		ACM (Audio control module)	+	+		
		GEM (Generic elec. module)	+	+		
		Rear electronic control module	+	+		
		Driver's seat module	+	+		
		Steering column lock module	+	+		
		Navigation control module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ-TYPE 3.0L Normally aspirated V6	2010 - 2011	ENGINE	+	+		
		AT	+	+		
		ABS	+	+		
		Instrument Pack System	+	+		
		Parking brake control module	+	+		
		Speed control module	+	+		
		Headlamp control module	+	+		
		Restraints control module	+	+		
		Vehicle immobilizer control module	+	+		
		Gear shift module	+	+		
		Restraints occupant classification system module	+	+		
		Rear differential control module	+	+		
		Body control module	+	+		
		Ride level control module	+	+		
		Safety belt pretensioner control module B - Driver side	+	+		
		Safety belt pretensioner control module B - Passenger side	+	+		
		Adaptive damping control module	+	+		
		Audio amplifier module	+	+		
		Driver's climate seat module	+	+		
		Headlamp control module	+	+		
		Passenger's seat module	+	+		
		Rear climate seat module	+	+		
		Rear heating ventilation and air conditioning control module	+	+		
		Side object detection control module - left	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
		Side object detection control module - right	+	+		
		Rear gate(trunk) module	+	+		
		Driver's door module	+	+		
		Heating ventilation and air conditioning control module	+	+		
		Integrated control panel	+	+		
		Keyless vehicle module	+	+		
		Parking assist control module	+	+		
		Passenger's door module	+	+		
		Driver's seat module	+	+		

**XJ8-TYPE**

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ8-TYPE 4.0L	2000	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XJ8-TYPE 3.2L	2001 - 2002	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		ICM (Instrument Pack System)	+	+	+	
		Body processor module	+	+	+	

**XKR-TYPE**

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XKR-TYPE Supercharged V8	2003	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		Adaptive speed control module	+	+		
		RCM/SRS(Restrain control modult)	+	+	+	
		PAM(Parking aid control module)	+	+		
		Left lighting control module	+	+		
		Right lighting control module	+	+		
		Climate control system	+	+	+	
		Driver's door module	+	+		
		Body processor module	+	+		
		Passenger's door module	+	+		
		Secutity locking module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XKR-TYPE Normally aspirated V8	2003	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		RCM/SRS	+	+	+	
		ICM(Instrument pack system)	+	+	+	
		PAM(Parking aid control module)	+	+		
		Driver's door module	+	+		
		Driver's seat module	+	+		
		Left lighting control module	+	+		
		Right lighting control module	+	+		
		Body processor module	+	+		
		Passenger's door module	+	+		
		Secutity locking module	+	+		
		Climate control system	+	+	+	

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XKR-TYPE Normally aspirated V8 3.5L	2006-2009	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Instrument Pack System	+	+	+	
		Parking brake control module	+	+		
		Speed control module	+	+		
		Headlamp control module	+	+		
		Impact classification system	+	+		
		Restraints control module	+	+	+	
		Vehicle immobilizer control module	+	+		
		Driver's door module	+	+		
		Driver's seat module	+	+		
		Central junction box(body control module)	+	+		
		Folding top control module	+	+		
		Heating ventilation and air conditioning control module	+	+	+	
		Integrated control panel	+	+		
		Keyless vehicle module	+	+		
		Parking assist control module	+	+		
		Passenger's door module	+	+		
		Passenger's seat module	+	+		
		Tire pressure monitor module	+	+		
		Auxiliary junction box(body control module)	+	+		
		Infotainment control module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XKR-TYPE Normally aspirated V8 4.2L	2006-2009	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Instrument Pack System	+	+	+	
		Parking brake control module	+	+		
		Speed control module	+	+		
		Headlamp control module	+	+		
		Impact classification system	+	+		
		Restraints control module	+	+	+	
		Vehicle immobilizer control module	+	+		
		Driver's door module	+	+		
		Driver's seat module	+	+		
		Central junction box(body control module)	+	+		
		Folding top control module	+	+		
		Heating ventilation and air conditioning control module	+	+	+	
		Integrated control panel	+	+		
		Keyless vehicle module	+	+		
		Parking assist control module	+	+		
		Passenger's door module	+	+		
		Passenger's seat module	+	+		
		Tire pressure monitor module	+	+		
		Auxiliary junction box(body control module)	+	+		
		Infotainment control module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XKR-TYPE Supercharged V8	2006-2009	ENGINE	+	+	+	
		AT	+	+	+	
		ABS	+	+	+	
		Instrument Pack System	+	+	+	
		Parking brake control module	+	+		
		Speed control module	+	+		
		Headlamp control module	+	+		
		Impact classification system	+	+		
		Restraints control module	+	+	+	
		Vehicle immobilizer control module	+	+		
		Driver's door module	+	+		
		Driver's seat module	+	+		
		Central junction box(body control module)	+	+		
		Folding top control module	+	+		
		Heating ventilation and air conditioning control module	+	+	+	
		Integrated control panel	+	+		
		Keyless vehicle module	+	+		
		Parking assist control module	+	+		
		Passenger's door module	+	+		
		Passenger's seat module	+	+		
		Tire pressure monitor module	+	+		
		Auxiliary junction box(body control module)	+	+		
		Infotainment control module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XKR-TYPE Normally aspirated V8	2010-2011	ENGINE	+	+		
		AT	+	+		
		ABS	+	+		
		Instrument Pack System	+	+		
		Parking brake control module	+	+		
		Speed control module	+	+		
		Headlamp control module	+	+		
		Impact classification system	+	+		
		Restraints control module	+	+		
		Vehicle immobilizer control module	+	+		
		Gear shift module	+	+		
		Restraints occupant classification system module	+	+		
		Rear differential control module	+	+		
		Driver's door module	+	+		
		Driver's seat module	+	+		
		Central junction box(body control module)	+	+		
		Folding top control module	+	+		
		Heating ventilation and air conditioning control module	+	+		
		Integrated control panel	+	+		
		Keyless vehicle module	+	+		
		Parking assist control module	+	+		
		Passenger's door module	+	+		
		Passenger's seat module	+	+		
		Tire pressure monitor module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
		Auxiliary junction box(body control module)	+	+		
		Driver's climate seat module	+	+		
		Infotainment control module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XKR-TYPE Supercharged V8	2010-2011	ENGINE	+	+		
		AT	+	+		
		ABS	+	+		
		Instrument Pack System	+	+		
		Parking brake control module	+	+		
		Speed control module	+	+		
		Headlamp control module	+	+		
		Impact classification system	+	+		
		Restraints control module	+	+		
		Vehicle immobilizer control module	+	+		
		Gear shift module	+	+		
		Restraints occupant classification system module	+	+		
		Rear differential control module	+	+		
		Driver's door module	+	+		
		Driver's seat module	+	+		
		Central junction box(body control module)	+	+		
		Folding top control module	+	+		
		Heating ventilation and air conditioning control module	+	+		
		Integrated control panel	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
		Keyless vehicle module	+	+		
		Parking assist control module	+	+		
		Passenger's door module	+	+		
		Passenger's seat module	+	+		
		Tire pressure monitor module	+	+		
		Auxiliary junction box(body control module)	+	+		
		Driver's climate seat module	+	+		
		Infotainment control module	+	+		

**XF-TYPE**

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XF-TYPE Normally aspirated V6	2008	ENGINE	+	+		
		AT	+	+		
		ABS	+	+		
		ICM (Instrument Pack System)	+	+		
		Parking brake control module	+	+		
		Gear shift module	+	+		
		Speed control module	+	+		
		Restraints control module	+	+		
		Restraints occupant classification system module	+	+		
		Headlamp control module	+	+		
		Impact classification system	+	+		
		Vehicle immobilizer control module	+	+		
		Central junction box	+	+		
		Auxiliary junction box	+	+		
		Driver's climate seat module	+	+		
		AC	+	+		
		Parking assist control module	+	+		
		Infotainment control module	+	+		
		Integrated control module	+	+		
		Driver's door module	+	+		
		Tire pressure monitor module	+	+		
		Driver's seat module	+	+		
		Keyless vehicle module	+	+		
		Passenger's door module	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
		Side object detection control module - left	+	+		
		Side object detection control module - right	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XF-TYPE Supercharged V8	2008	ENGINE	+	+		
		AT	+	+		
		ABS	+	+		
		ICM(Instrument Pack System)	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XF-TYPE Diesel V6	2008	ENGINE	+	+		
		AT	+	+		
		ABS	+	+		
		ICM(Instrument Pack System)	+	+		

MODEL	YEAR	SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
XF-TYPE Normally aspirated V8 4.2L	2010 - 2011	ENGINE	+	+		
		AT	+	+		
		ABS	+	+		
		Instrument Pack System	+	+		
		Parking brake control module	+	+		
		Speed control module	+	+		
		Headlamp control module	+	+		
		Impact classification system	+	+		
		Restraints control module	+	+		
		Vehicle immobilizer control module	+	+		
		Gear shift module	+	+		
		Restraints occupant classification system module	+	+		
		Driver's door module	+	+		
		Driver's seat module	+	+		
		Central junction box(body control module)	+	+		
		Heating ventilation and air conditioning control module	+	+		
		Integrated control panel	+	+		
		Keyless vehicle module	+	+		
		Passenger's door module	+	+		
		Tire pressure monitor module	+	+		
		Auxiliary junction box(body control module)	+	+		
		Driver's climate seat module	+	+		
		Side object detection control module - left	+	+		
		Side object detection control module - right	+	+		
		Infotainment control module	+	+		
		Rear differential control module	+	+		

**Models equipped with OBD-II Connector, SELECT BY SYSTEM:** (for unknown models / versions only)

SYSTEM	READ FAULT CODE	CLEAR FAULT CODE	DATA STREAM	CODING
ENGINE	+	+		
AT	+	+		
ABS	+	+		
SRS	+	+		