

Bars Professional



MERCEDES-BENZ 1987–2012

VERSION: 3V04 DATE: MAR., 2013

AVAILABLE MODELS LIST

MODELS	CHASSIS TYPE
A-class	168, 169
B-class	245
C-class	201, 202, 203, 203-CAN, 204
E-class	124, 210, 211, 212, 207 (coupe)
S-class	126, 140, 220, 220-CAN, 221
SLK-class	170, 171, 172
CLK-class	208, 209, 209-CAN
SL-class	107, 129, 230, 230-CAN
SLR	199
SLS	197
CLS-class	219
CL-class	215, 215-CAN, 216
R-class	251
M-class	163, 164, 166
G-class	463
GL-class	X164
GLK-class	X204
V-class and Transporter (MB-3)	SPRINTER, VITO, VANEQ, VITO 638 / 639, VIANO 639, SPRINTER 906, VITO / VIANO China 636

* If the models are not listed here, users could select the related models.

* V-class and Transpoter can be found in MB-3 software.

* MB-2 software include the following models: 204, 207(coupe), 172, 197, 166

* MB-1 software include all the models but MB-2 modes and V-class.

A-class, 168 with *QUICK SERVICE

	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE					
ECM/MSM (Engine Control Monolith)	+	+	+	+	
CDI 1 (Common Rail Diesel Injection)	+	+			
ACS (Automatic Clutch System)	+	+		+	
FTC (Front Transmission Control)	+	+			
GRM (Gear Recognition Module)	+	+	+		
CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
ATA (Anti-Thief Alarm)	+	+			
LCP (Lower Control)	+	+	+		
RFL (Radio Frequency Locking)		+			
INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+		Service Reset / Oil Quality	
PTS (Parktronic System)	+	+			
D2B (AUDIO System)	+	+		+	
CDC (CD Changer)		+			
CTEL1 (Cellular Telephone 1)		+			
CTEL2 (Cellular Telephone 2)		+			
APS (Auto Pilot)		+			
SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1	+	+	+		
DCM 2	+	+	+		
DCM 3	+	+	+		
DCM 4	+	+	+		
AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	+	+			
STH (Stationary Heater)		+			

*QUICK SERVICE: Perform "Service Reset" within seconds.

A-class, 169 with *QUICK SERVICE

	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE					
FCVT (Continuously variable automatic transmission)	+	+			
SIM266 (Engine system)	+	+			
ESM (Electronic Selector Module)	+	+		+	
CDI A(Common Rail Diesel Injection)		+			
CDI 4(Common Rail Diesel Injection)	+	+			
CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
ES (Electrical power steering)	+	+			
BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
CGW (Central gateway)		+			
EIS (Electronic ignition switch, without Keyless Go)	+	+			
OCP (Overhead control panel)	+	+			
SAM (Signal acquisition and actuation module)	+	+			
HRA-FL		+			
HRA-FR		+			
INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+		Service Reset	
PTS (Parktronic System)	+	+			
SCM(Steering column module)	+	+			
ASSYST-PLUS	+	+		Service Reset	
SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
DCM RL		+			
DCM RR		+			
AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC(Convenience automatic air conditioning)	+	+	+	+	

B-class, 245 with *QUICK SERVICE

	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE					
FCVT (Continuously variable automatic transmission)	+	+			
SIM266 (Engine system)	+	+			
ESM (Electronic Selector Module)	+	+		+	
CDI A(Common Rail Diesel Injection)		+			
CDI 4(Common Rail Diesel Injection)	+	+			
CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
ES (Electrical power steering)	+	+			
BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
CGW (Central gateway)	+	+			
EIS (Electronic ignition switch, without Keyless Go)	+	+			
OCP (Overhead control panel)	+	+			
SAM (Signal acquisition and actuation module)	+	+			
XALWA-L (Xenon headlamp, left)	+	+			
XALWA-R (Xenon headlamp, right)	+	+			
AHE (Trailer recognition)	+	+			
INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+		Service Reset	
ASSYST PLUS (PLUS Active Service System)	+	+		Service Reset	
PTS (Parktronic System)	+	+			
SCM(Steering column module)	+	+			
SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1	+	+	+		
DCM 2	+	+	+		
DCM 3	+	+	+		
DCM 4	+	+	+		
AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC(Convenience automatic air conditioning)	+	+	+	+	

C-class, 201

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CIS-E		+			
ELR (Diesel Injection Electronic ISC)		+			
ESCM		+			
ASD (Automatic Locking Differential)		+			
AB (SRS / Airbag)		+			
Climate Control		+			

C-class, 202

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI	+	+	+	+	
HFM-SFI	+	+	+	+	+
PMS/PEC	+	+			
ME 2.0 / 2.1	+	+	+	+	+
SIM4LE	+	+		+	
EA / CC / ISC (with LH-SFI / HFM-SFI)	+	+			
DM	+	+		+	
EAG 722.5 (5-speed automatic ETC)	+	+	+		
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
IFI / ERE (Electronic Inline injection)	+	+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	+	+			
ASR	+	+			
ETS	+	+			
ESP (Electronic Stability Program)	+	+			
BAS (Brake Assist System)	+	+			
ADS (Adaptive Damping System)		+			

C-class, 202 (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
EIS (Electronic Ignition Switch)	+	+		+	
ATA (Anti-Thief Alarm)	+ (before 97)	+			
PSE	+ (before 97)	+			
SAM	+	+	+	+	
OCP	+	+	+		
LCP (Lower Control)	+	+	+		
HRA		+			
SVMCM		+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
PTS (Parktronic System)	+	+			
D2B (AUDIO System)	+	+		+	
CDC (CD Changer)		+			
CTEL1 (Cellular Telephone 1)		+			
CTEL2 (Cellular Telephone 2)		+			
VCS	+				
TELE AID(K-wire)	+				
DN(K-wire)		+			
APS (Auto Pilot)		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1	+	+	+		
DCM 2	+	+	+		
DCM 3	+	+	+		
DCM 4	+	+	+		
ESA-FL	+	+			
ESA-FR	+	+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	+	+		+	
STH (Stationary Heater)	+	+			

C-class, 203-CAN with *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	+	+	+	+	+
ME 2.8 / 2.8 AMG	+	+	+	+	
ME 9.7	+	+	+	+	
SIM4LE	+	+		+	
SIM271	+	+			
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
EGS 722.9	+	+		+	
ESM (Electronic Selector Module)	+	+		+	
DTR (Distronic)		+			
CDI 3		+			
CDI 4		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+	+	+	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		+			
EIS (Electronic Ignition Switch) / KG (keyless)	+	+		+	
AB (SRS / Airbag)	+	+			
SAM-FRONT	+	+	+		
SAM-REAR	+	+			
OCP	+	+		+	
LCP (Lower Control)	+	+			
UCP (Upper Control)	+	+			
HRA-FL	+	+			
HRA-FR		+			
WSS (Weight Sensing System)	+	+		+	
AHE (Trailer recognition)		+			
SVMCM		+			

*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

C-class, 203-CAN with *SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+		+ (more workshop functions)	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
MOST - AGW	+	+		+	
MOST - COMMAND / AUDIO		+			
MOST - CDC (CD Changer)		+			
MOST - HFS (Handsfree System and Microphone)		+			
MOST - CTEL (Cellular Telephone)		+			
MOST - VCS (Voice Control)		+			
MOST - NAVI (Navigation)		+			
MOST - SOUND (Bose SOUND System)		+			
MOST - TV (TV Tuner)		+			
MOST - SDAR (Satellite Radio)		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
DCM RL	+	+	+		
DCM RR	+	+	+		
ESA - Driver	+	+			
ESA - Passenger	+	+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+	+	+	
STH (Stationary Heater)	+	+			

C-class, 203 (non-CAN) with *QUICK SERVICE and *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	+	+	+	+	+
ME 2.8 / 2.8 AMG	+	+	+	+	
SIM4LE	+	+		+	
SIM4LSE	+	+		+	
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
ESM (Electronic Selector Module)	+	+		+	
DTR (Distronic)		+			
CDI 2 (Common Rail Diesel Injection)	+	+	+		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+		+	
BAS (Brake Assist System)	+	+			
VP (Vacuum Pump Brake Booster)	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	+	+		+	
AB (SRS / Airbag)	+	+			
KG (keyless Go)	+	+			
PSE	+ (before 97)	+			
SAM-FRONT	+	+	+	+	
SAM-REAR	+	+		+	
OCP	+	+		+	
LCP	+	+			
UCP	+	+			
HRA-FL	+	+			
HRA-FR		+			
AHE (Trailer recognition)		+			
SVMCM		+			

*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

*QUICK SERVICE: Perform "Service Reset" within seconds.

C-class, 203 (non-CAN) with QUICK SERVICE & SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+	+	+ (more workshop functions)	+
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
D2B (AUDIO System)	+	+		+ (include TV on Drive)	
CDC (CD Changer)		+			
CTEL1 (Cellular Telephone 1)		+			
CTEL2 (Cellular Telephone 2)		+			
VCS		+			
TELE AID / E-Call		+			
TV		+			
SOUND		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
DCM RL	+	+	+		
DCM RR	+	+	+		
ESA – Driver	+	+			
ESA – Passneger	+	+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC / HEAT	+	+	+	+	
REAR AC		+			
STH (Stationary Heater)	+	+			

C-class, 204 with *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	+	+	+	+	
ME 9.7AMG	+	+			
MED9.7		+			
MED40	+	+			
SIM271	+	+			
ME2.7.2	+	+			
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
EGS 722.9	+	+		+	
ESM (Electronic Selector Module)	+	+		+	
FSCU(Fuel pump)	+	+			
CDI 3		+			
CDI 4		+			
CDI 6		+			
CDID 2	+	+			
CDID 3		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABR(Adaptive Brake)	+	+			
TPC(Tire Pressure Control)	+	+			
ADS(Adaptive damping system)	+	+			
ESP(Electric stability program)	+	+		+	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	+	+			
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)	+	+			
SAM-FRONT	+	+	+		
SAM-REAR	+	+			
OCP	+	+	+	+	
COU	+	+			
WSS (Weight Sensing System)	+	+			+
AHE (Trailer recognition)	+	+			+
SVMCM		+			
RevETR-LF	+	+			
RevETR-RF	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
XALWA-L	+	+			
XALWA-R	+	+			
KG	+	+			
PSD (Control module 'Panoramic sliding roof')	+	+		+	

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	+	+	+	+ (Service reset)	
SCM (Steering Column Module)	+	+	+		
PTS (Parktronic System)	+	+	+		
RFK	+	+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+	+	
DCM FR	+	+	+	+	
DCM RL	+	+	+		
DCM RR	+	+	+		
ESA – Driver	+	+	+		
ESA – Passenger		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+	+	+	

*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

E-class, 124

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI	+	+	+	+	
HFM-SFI	+	+	+	+	+
PMS/PEC	+	+			
EA / CC / ISC (with LH-SFI / HFM-SFI)	+	+			
DM	+ (digital mode only)	+		+	
EAG 722.5 (5-speed automatic ETC)	+ (digital mode only)	+	+		
BM	+ (digital mode only)	+		+	
CFI/CIS		+			
ESCM		+			
DI		+			
ELR (Diesel Injection)		+			
IFI / ERE (Electronic Inline injection)	+	+			
EDS (Electronic Diesel System)		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	+	+			
ASR	+	+			
ASD (Automatic Locking Differential)		+			
4MATIC (4-Wheel Drive)		+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (Airbag)	+ (digital mode only)	+		+ (digital mode only)	
RCL (DAS2, Code 888)		+			
CST		+			
ATA	+	+			

CLIMATE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CLIMATE (Air conditioning)		+			

E-class, 210 with QUICK SERVICE & SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI	+	+	+	+	
HFM-SFI	+	+	+	+	+
PMS/PEC	+	+			
ME 2.0 / 2.1	+	+	+	+	+
ME 2.8 / 2.8 AMG	+	+	+	+	
SIM4LE	+	+			
EA / CC / ISC (with LH-SFI / HFM-SFI)	+	+			
DM	+	+		+	
EAG 722.5 (5-speed automatic ETC)	+	+	+		
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
ESM	+	+		+	
CDI 2	+	+	+		
IFI / ERE (Electronic Inline injection)	+	+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	+	+			
ASR	+	+			
ETS	+	+			
ESP (Electronic Stability Program)	+	+			
BAS (Brake Assist System)	+	+			
ADS (Adaptive Damping System)		+			
VP (Vacuum Pump Brake Booster)	+	+			
SPS (Speed Sensitive Power Steering)		+			
TPC (Tire Pressure monitor)	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
EIS (Electronic Ignition Switch)	+	+		+	
ATA (Anti-Thief Alarm)	+ (before 97)	+	+		
KFB	+	+			
PSE	+	+			
SAM	+	+	+	+	
OCP	+	+	+		
LCP (Lower Control)	+	+	+		
HRA		+			
SVMCM		+			
RCL/RFL		+			

E-class, 210 (cont.)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
PTS (Parktronic System)	+	+			
D2B (AUDIO System)	+	+		+	
CDC (CD Changer)		+			
CTEL1 (Cellular Telephone 1)		+			
CTEL2 (Cellular Telephone 2)		+			
VCS		+			
TELE AID(K-wire)		+			
DN(K-wire)		+			
ICS		+			
TV (TV tuner)		+			
APS (Auto Pilot)		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1	+	+		+	
DCM 2	+	+		+	
DCM 3	+	+		+	
DCM 4	+	+		+	
ESA-FL	+	+			
ESA-FR	+	+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / TAC (Tempmatic Air conditioning)	+	+			
STH (Stationary Heater)	+	+			

E-class, 211-CAN with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	+	+	+	+	+
ME 2.8 / 2.8 AMG	+	+	+	+	
ME 9.7	+	+	+	+	
ME 9.7 AMG	+	+			
MED 9.7		+			
SIM4LE	+	+		+	
SIM4LSE	+	+		+	
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
EGS 722.9	+	+		+	
ESM (Electronic Selector Module)	+	+		+	
DTR (Distrionic)		+			
DTR (Distrionic) CAN version		+			
CDI 2	+	+	+		
CDI 3		+			
CDI 4		+			
CDI 5		+			
CDI D		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
AIRmatic	+	+		+	
TPC	+	+			
SBC	+	+		+	
ABR	+	+			
ENR(Electronic level control)	+	+		+	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		+		+	
EIS (Electronic Ignition Switch) and KG	+	+		+	
AB (SRS / Airbag)	+	+			
SAM-Drive	+	+	+	+	
SAM-Passenger	+	+	+	+	
SAM-Rear	+	+	+	+	
OCP	+	+		+	
LCP (Lower Control)	+	+			
UCP (Upper Control)	+	+			
HRA	+	+			
RevETR-LF		+			
RevETR-RF		+			
WSS (Weight Sensing System)	+	+		+	
BCM (Battery control module)	+	+			
AHE	+	+			
System Diagnosis		+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
XALWA-L	+	+			
XALWA-R	+	+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	+	+		+	
ASSYST (Active Service System)	+	+			
ASSYST PLUS (PLUS Active Service System)		+		+	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
MOST – AGW	+	+		+	
MOST – COMMAND / AUDIO		+			
MOST – CDC (CD Changer)		+			
MOST – HFS (Handsfree System and Microphone)		+			
MOST – CTEL (Cellular Telephone)		+			
MOST – VCS (Voice Control)		+			
MOST – NAVI (Navigation)		+			
MOST – SOUND (Bose SOUND System)		+			
MOST – TV (TV Tuner)		+			
MOST – SDAR (Satellite Radio)		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
DCM RL	+	+	+		
DCM RR	+	+	+		
ESA – Driver	+	+			
ESA – Passenger	+	+			
DS-FL (Front Left Dynamic Seat)	+	+			
DS-FR (Front Right Dynamic Seat)	+	+			
DSP (Pneumatic pump for Dynamic Seat)	+	+			
TLC (Trunk Lid Control)	+	+			
HS (Seat Heater)	+	+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	+	+	+	+	
HSW	+	+			
STH	+	+			

E-class, 212-CAN with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	+	+	+	+	
ME 9.7 AMG	+	+			
MED 9.7		+			
MED 17.7	+	+			
MED40	+	+			
EGS 722.9	+	+		+	
FSCU(Fuel pump)	+	+			
ESM (Electronic Selector Module)	+	+			
ISM (Intelligent servo module)	+	+		+	
SGR(Radar sensors control unit)		+			
DTR (Distronic)	+	+			
DSI (DIRECT SELECT interface)		+			
SIM271(Engine)	+	+			
CDID 2	+	+			
CDID 3		+			
CDI 6		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
AIRmatic		+			
TPM	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	+	+			
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)	+	+			
KG	+	+			
SAM-Drive	+	+			
SAM-Rear	+	+			
XALWA-L	+	+			
XALWA-R	+	+			
WSS (Weight Sensing System)	+	+		+	
OCP	+	+		+	
RevETR-LF	+	+			
RevETR-RF	+	+			
PSD(Panoramic sliding roof)	+	+		+	
AHE		+			
KDS(Trunk lid control)	+	+			
SG-FOND(Rear control unit)	+	+			
SVMCM		+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	+	+		OIL RESET	
SCM (Steering Column Module)	+	+			
DSI(DIRECT SELECT interface)		+			
PTS (Parktronic System)	+	+			
MFK(Multifunction camera)	+	+			
NSA(Night View Assist)	+	+			
MOST – UCI(Media interface)	+	+			
MOST – COMMAND	+	+			
MOST – ZBE[COU](Audio/COMAND operating unit)	+	+			
MOST – ZAN(Audio/COMAND display)	+	+			
MOST – DAB(Digital Audio Broadcasting)		+			
MOST – SDAR(Satellite digital audio radio)		+			
MOST – SOUND (SOUND Systen)		+			
MOST – TV (TV Tuner)		+			
MOST – DTA(TELEAID)		+			
MOST – DTA (TELEAID) - Emergency call		+			
MOST – DTA (TELEAID) - MB Info / Breakdown assistance		+			
MOST – DTA (TELEAID) - Stolen vehicle tracking		+			
MOST – DTA (TELEAID) - Vehicle remote unlocking/locking		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
DCM RL	+	+	+		
DCM RR	+	+	+		
ESA – Driver	+	+			
ESA – Passenger	+	+			
AMKS-LF– Active multicontour seat (Driver)	+	+			
AMKS-RF - Active multicontour seat (Passenger)	+	+			
PPAMKS - Pneumatic pump for active multicontour seat	+	+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	+	+		+	
LRH[HSW] (Heated steering wheel)		+			

E-class(Coupe), 207-CAN with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	+	+	+	+	
ME 9.7 AMG	+	+			
MED 9.7		+			
MED 17.7	+	+			
EGS 722.9	+	+		+	
FSCU(Fuel pump)	+	+			
ESM (Electronic Selector Module)	+	+			
SGR(Radar sensors control unit)		+			
DTR (Distronic)	+	+			
SIM271(Engine)	+	+			
CDID 2	+	+			
CDID 3		+			
CDI 6		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
ADS (Adaptive damping system)	+	+			
TPC	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	+	+			
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)	+	+			
KG	+	+			
SAM-Drive	+	+			
SAM-Rear	+	+			
XALWA-L	+	+			
XALWA-R	+	+			
WSS (Weight Sensing System)	+	+		+	
OCP	+	+		+	
RevETR-LF	+	+			
RevETR-RF	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AHE	+	+			
SVMCM	+	+			
SG-FOND(Rear control unit)		+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	+	+		OIL RESET	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
MFK(Multifunction camera)	+	+			
MOST – UCI(Media interface)	+	+			
MOST – COMMAND	+	+			
MOST – ZBE[COU](Audio/COMAND operating unit)	+	+			
MOST – ZAN(Audio/COMAND display)	+	+			
MOST – DAB(Digital Audio Broadcasting)		+			
MOST – SDAR(Satellite digital audio radio)		+			
MOST – SOUND (SOUND System)		+			
MOST – TV (TV Tuner)		+			
MOST – DTA(TELEAID)		+			
MOST – DTA (TELEAID) - Emergency call		+			
MOST – DTA (TELEAID) - MB Info / Breakdown assistance		+			
MOST – DTA (TELEAID) - Stolen vehicle tracking		+			
MOST – DTA (TELEAID) - Vehicle remote unlocking/locking		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM L	+	+	+		
DCM R	+	+	+		
ESA – Driver	+	+			
ESA – Passenger	+	+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	+	+		+	

S-class, 126

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
Engine ESCM		+			
Engine CFI		+			
ELR (Diesel Injection Electronic ISC)		+			
EDS (Electronic Diesel System)		+			
ASD (Automatic Locking Differential)		+			
AB (SRS / Airbag)	+ (digital mode only)	+		+ (digital mode only)	
Climate Control		+			

S-class, 140 with SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI / LH-SFI LEFT	+	+	+	+	
LH-SFI RIGHT	+	+	+	+	
HFM-SFI	+	+	+	+	+
ME 1.0 LEFT BANK	+	+	+	+	+
ME 1.0 RIGHT BANK	+	+	+	+	+
ME 1.0 V8	+	+	+	+	+
ME 2.0 / 2.1	+	+	+	+	+
EA / CC / ISC (with LH-SFI / HFM-SFI)	+	+			
DM	+	+		+	
BM	+	+			
EAG 722.5 (5-speed automatic ETC)	+	+	+		
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
IFI / ERE (Electronic Inline injection)	+	+			
DI		+			
EDS		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	+	+			
ASR	+	+			
ETS	+	+			
ESP (Electronic Stability Program)	+	+			
BAS (Brake Assist System)	+	+			
SPS (Speed Sensitive Power-Steering)		+			
ASD (Automatic Locking Differential)		+			
ADS (Adaptive Damping System)		+			

S-class, 140 with SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
IC (Instrument Cluster)	+	+		+	
ATA (Anti-Thief Alarm)	+	+			
IRC(IR Controller)		+			
RCL(DAS1/X)		+			
RFL(DAS2/X)		+			
CF/KFB		+			
PSE	+	+			
HRA	+	+			
PTS	+	+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / HAU (Automatic Air conditioning)	+	+			
STH (Stationary Heater)	+	+			

S-class, 221-CAN with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	+	+	+	+	
MED9.7		+			
EGS 722.9	+	+		+	
ISM (Intelligent servo module)	+	+	+		
DTR (Distronic)		+			
SGR (Radar sensors control unit)		+			
CDI 4		+			
CDI 5		+			
CDI 6		+			
CDID 3		+			
ME 2.7.2 (V12)	+	+			
ME 17.7	+	+			
MED 17.7	+	+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABR (Adaptive Brake)	+	+			
AIRmatic (Suspension)	+	+	+		
EPB (Electronic parking brake)	+	+			
TPC (Tire Pressure)	+	+			

RBS (Regenerative braking system)	+	+			
EHPS (Electrohydraulic Power Steering)		+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		+			
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)	+	+			
WSS (Weight sensing system)	+	+			
RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			
RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
XALWA-L (Left headlamp)	+	+			
XALWA-R (Right headlamp)	+	+			
KG (keyless Go)	+	+			
SAM-Driver	+	+		+	
SAM-REAR	+	+		+	
PSE (Pneumatic system)		+			
OCP	+	+			
UCP (Upper Control)	+	+			
COU – ZBE (Central operating unit)	+	+			
HBF (Rear control field / panel)		+			
System Diagnosis		+			
BNS (Vehicle power supply control module)	+	+			
AHE (Trailer recognition)		+			
SVMCM		+			
PSD - Panoramic sliding roof		+			
SG-BMS - Battery management system		+			
SG-DDW - DC/DC converter control unit		+			

S-class, 221-CAN with *QUICK SERVICE & *SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
DCM RL	+	+	+		
DCM RR	+	+	+		
ESA – Driver	+	+			
ESA – Passenger	+	+			
ESA – R	+	+			
DS-FL (Front Left Dynamic Seat)		+			
DS-FR (Front Right Dynamic Seat)		+			
DSP (Pneumatic pump for Dynamic Seat)		+			
MKL-HL (Rear left Multicontour backrest)		+			
MKL-HR (Rear right Multicontour backrest)		+			
TLC (Trunk lid control)	+	+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+			
ASSYST (Active Service System)	+	+			
ASSYST PLUS (PLUS Active Service System)		+		+	
NSA (Night View Assist)	+	+			
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
RFK (Backup camera)	+	+			
COMAND		+			
ZAN (Central Display)		+			
TELE-AID		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+	+	+	
KBE-H (Rear A/C operating unit)	+	+			
STH (Stationary Heater)		+			

S-class, 220-CAN with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	+	+	+	+	
ME 2.7	+	+			
ME 9.7	+	+	+	+	
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
EGS 722.9	+	+		+	
ESM (Electronic Selector Module)	+	+		+	
DTR (Distronic)		+			
CDI 2	+	+	+		
CDI 3		+			
CDI 4		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
AIRmatic (Suspension)	+	+	+	+	
ABC (Active Body Control)	+	+	+	+	
TPC (Tire Pressure)	+	+			

S-class, 220-CAN with *QUICK SERVICE & *SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		+		+	
EIS (Electronic Ignition Switch)	+	+		+	
AB (SRS / Airbag)	+	+			
RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			
RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
HRA	+	+			
HLCM-L (Left headlamp)	+	+			
HLCM-R (Right headlamp)	+	+			
KG (keyless Go)	+	+			
SAM-FRONT LEFT	+	+		+	
SAM-FRONT RIGHT	+	+			
SAM-REAR	+	+		+	
PSE (Pneumatic system)	+	+		+	
OCP	+	+			
UCP (Upper Control)	+	+			
System Diagnosis		+			
AHE (Trailer recognition)		+			
SVMCM		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
DCM RL	+	+	+		
DCM RR	+	+	+		
ESA – Driver	+	+			
ESA – Passenger	+	+			
ESA – R	+	+			
DS-FL (Front Left Dynamic Seat)	+	+			
DS-FR (Front Right Dynamic Seat)	+	+			
DSP (Pneumatic pump for Dynamic Seat)	+	+			
OSB-FL (Multicontour backrest front left)	+	+			
OSB-FR (Multicontour backrest front Right)	+	+			
OSB-R (Multicontour backrest rear)	+	+			

S-class, 220-CAN with *QUICK SERVICE & *SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+		Service Reset / Oil Quality	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
MOST – AGW	+	+		+	
MOST – COMMAND / AUDIO		+			
MOST – CDC (CD Changer)		+			
MOST – HFS (Handsfree System and Microphone)		+			
MOST – CTEL (Cellular Telephone)		+			
MOST – VCS (Voice Control)		+			
MOST – NAVI (Navigation)		+			
MOST – SOUND (Bose SOUND System)		+			
MOST – TV (TV Tuner)		+			
MOST – SDAR (Satellite Radio)		+			
D2B	+	+		+	
D2B – CDC (CD Changer)		+			
D2B – CTEL1 (Cellular Telephone)		+			
D2B – CTEL2 (Cellular Telephone)		+			
D2B – VCS (Voice Control)		+			
D2B – SOUND (Bose SOUND System)		+			
D2B – TV (TV Tuner)		+			
D2B – DN		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+	+	+	
KLA (Climate Control)	+	+	+		
REAR AC	+	+			
STH (Stationary Heater)	+	+			
HSW (Heated Steering Wheel)	+	+			

S-class, 220 (non-CAN) with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 1.0	+	+	+	+	+
ME 2.0 / 2.0 V8	+	+	+	+	+
ME 2.8 / 2.8 AMG	+	+	+	+	
ME 2.7	+	+			
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
ESM (Electronic Selector Module)	+	+		+	
DTR (Distronic)		+			
CDI 2	+	+	+		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
AIRmatic (Suspension)	+	+	+	+	
ABC (Active Body Control)	+	+	+	+	
TPC (Tire Pressure)	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)	+	+			
HRA	+	+			
KG (keyless Go)	+	+			
SAM-FRONT LEFT	+	+		+	
SAM-FRONT RIGHT	+	+			
SAM-REAR	+	+		+	
PSE (Pneumatic system)	+	+		+	
OCP	+	+			
UCP (Upper Control)	+	+			
AHE (Trailer recognition)		+			
SVMCM		+			

S-class, 220 (non-CAN) with *QUICK SERVICE & *SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
DCM RL	+	+	+		
DCM RR	+	+	+		
ESA – Driver	+	+			
ESA – Passenger	+	+			
ESA – R	+	+			
OSB-FL (Multicontour backrest front left)	+	+			
OSB-FR (Multicontour backrest front Right)	+	+			
OSB-R (Multicontour backrest rear)	+	+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	+	+		Service Reset / Oil Quality	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
D2B	+	+		+	
D2B – CDC (CD Changer)		+			
D2B – CTEL1 (Cellular Telephone)		+			
D2B – CTEL2 (Cellular Telephone)		+			
D2B – VCS (Voice Control)		+			
D2B – SOUND (Bose SOUND Systen)		+			
D2B – TV (TV Tuner)		+			
D2B – DN		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+	+	+	
KLA (Climate Control)	+	+	+		
REAR AC	+	+			
STH (Stationary Heater)	+	+			
HSW (Heated Steering Wheel)	+	+			
TSTH (Radio Remote Control STH)		+			

SLK-class, 170

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
HFM-SFI	+	+	+	+	+
PMS/PEC	+	+			
ME 2.0 / 2.1	+	+	+	+	+
SIM4LE	+	+			
EAG 722.5 (5-speed automatic ETC)	+	+	+		
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
ESM	+	+		+	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	+	+			
ASR	+	+			
ETS	+	+			
ESP (Electronic Stability Program)	+	+			
BAS (Brake Assist System)	+	+			
VP (Vacuum Pump Brake Booster)	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
ATA (Anti-Thief Alarm)	+	+			
RFL		+			
RFL / DAS2		+			
HRA		+			
VR	+	+	+		
PSE	+	+			
CCM	+	+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
D2B (AUDIO System)	+	+		+	
CDC (CD Changer)		+			
CTEL1 (Cellular Telephone 1)		+			
CTEL2 (Cellular Telephone 2)		+			
VCS		+			
TELE AID(K-wire)		+			

SLK-class, 170 (continued)

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / TAC (Tempmatic Air conditioning)	+	+			

SLK-class, 171-CAN

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	+	+	+	+	
ME 9.7	+	+	+	+	
SIM4LE	+	+			
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
EGS 722.9	+	+		+	
ESM (Electronic Selector Module)	+	+		+	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+		+	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		+			
EIS (Electronic Ignition Switch) / KG (Keyless)	+	+			
AB (SRS / Airbag)	+	+			
VR	+	+			
HRA		+			
OCP	+	+			
UCP (Upper Control)	+	+			
SAM-FRONT	+	+			
SAM-REAR	+	+			
System Diagnosis		+			

SLK-class, 171-CAN (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)		+			
ASSYST (Active Service System)	+	+		+	
ASSYST PLUS (PLUS Active Service System)		+		+ (Service Reset)	
SCM (Steering Column Module)		+			
PTS (Parktronic System)		+			
MOST - AGW	+	+		+	
MOST - COMMAND / AUDIO		+			
MOST - CDC (CD Changer)		+			
MOST - HFS (Handsfree System and Microphone)		+			
MOST - CTEL (Cellular Telephone)		+			
MOST - VCS (Voice Control)		+			
MOST - NAVI (Navigation)		+			
MOST - SOUND (Bose SOUND System)		+			
MOST - TV (TV Tuner)		+			
MOST - SDAR (Satellite Radio)		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	+	+	+		
DCM RIGHT	+	+	+		
ESA - Driver	+	+			
ESA - Passenger	+	+			
HS (Seat heater)	+	+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	+	+	+	+	

SLK-class, 172 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
SIM271(Engine)	+	+			
MED 17.7	+	+			
MED40	+	+			
EGS 722.9	+	+		+	
FSCU(Fuel pump)		+			
ESM (Electronic Selector Module)	+	+			
SGR(Radar sensors control unit)		+			
DTR (Distronic)	+	+			
CDID 2	+	+			
CDID 3		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
ADS (Adaptive damping system)	+	+			
TPM	+	+			
EPB (Electronic parking brake)		+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	+	+			
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)		+			
KG	+	+			
SAM-Drive	+	+			
SAM-Rear	+	+			
RevETR-LF	+	+			
RevETR-RF		+			
AIRSCARF		+			
SG-SW (Headlamp)		+			
VDS (Vario roof)		+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	+	+		OIL RESET	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
MFK(Multifunction camera)	+	+			
MOST – UCI(Media interface)	+	+			
MOST – COMMAND	+	+			
MOST – ZBE[COU](Audio/COMAND operating unit)	+	+			
MOST – ZAN(Audio/COMAND display)	+	+			
MOST – DAB(Digital Audio Broadcasting)		+			
MOST – SDAR(Satellite digital audio radio)		+			
MOST – SOUND (SOUND System)		+			
MOST – TV (TV Tuner)		+			
MOST – DTA(TELEAID)		+			
MOST – DTA (TELEAID) - Emergency call		+			
MOST – DTA (TELEAID) - MB Info / Breakdown assistance		+			
MOST – DTA (TELEAID) - Stolen vehicle tracking		+			
MOST – DTA (TELEAID) - Vehicle remote unlocking/locking		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
ESA – Driver		+			
ESA – Passenger		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)		+			

CLK-class, 208

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	+	+	+	+	+
SIM4LE	+	+			
EAG 722.5 (5-speed automatic ETC)	+	+	+		
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
ESM	+	+		+	
DTR		+			
CDI 2	+	+	+		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
EIS (Electronic Ignition Switch)	+	+		+	
HRA-FL	+ (partial)	+			
HRA-FR	+ (partial)	+			
UCP	+	+			
LCP (Lower Control)		+			
SAM-FRONT	+	+		+	
SAM-REAR	+	+		+	
AHE (Trailer recognition)		+			
RVC(Rollover bar soft top control module)	+	+	+		

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
SCM	+	+			
PTS (Parktronic System)	+	+			
D2B (AUDIO System)	+	+		+	
CDC (CD Changer)		+			
CTEL1 (Cellular Telephone 1)		+			
CTEL2 (Cellular Telephone 2)		+			
VCS		+			
TV (TV tuner)		+			
SOUND		+			

CLK-class, 208 (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	+	+			
DCM RIGHT	+	+			
DCM REAR		+			
ESA LEFT	+	+			
ESA RIGHT	+	+			
TLC		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air conditioning)	+	+			
STH (Stationary Heater)	+	+			

CLK-class, 209

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	+	+	+	+	+
SIM4LE	+	+			
EAG 722.5 (5-speed automatic ETC)	+	+	+		
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
ESM	+	+		+	
DTR		+			
CDI 2	+	+	+		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+		+	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
EIS (Electronic Ignition Switch)	+	+		+	
HRA-FL	+	+			
HRA-FR	+	+			
OCP	+	+			
UCP	+	+			
LCP (Lower Control)	+	+			
SAM-FRONT	+	+		+	
SAM-REAR	+	+		+	
AHE (Trailer recognition)		+			
RVC	+	+			

CLK-class, 209 (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
SCM	+	+			
PTS (Parktronic System)	+	+			
D2B (AUDIO System)	+	+		+	
CDC (CD Changer)		+			
CTEL1 (Cellular Telephone 1)		+			
CTEL2 (Cellular Telephone 2)		+			
VCS		+			
TV (TV tuner)		+			
SOUND		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	+	+			
DCM RIGHT	+	+			
DCM REAR		+			
ESA LEFT	+	+			
ESA RIGHT	+	+			
TLC		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air conditioning)	+	+	+ (partial version)	+ (partial version)	
STH (Stationary Heater) (non-CAN)	+	+			

SL-class, 107

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ENGINE-CFI		+			
AB (SRS / Airbag)	+ (digital mode only)	+		+ (digital mode only)	

SL-class, 129

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI	+	+	+	+	
HFM-SFI	+	+	+	+	+
PMS/PEC	+	+			
ME 2.0 / 2.1	+	+	+	+	+
BM	+	+			
EA / CC / ISC (with LH-SFI / HFM-SFI)	+	+			
DM	+	+		+	
EAG 722.5 (5-speed automatic ETC)	+	+	+		
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
CFI		+			
DI		+			
CDI 2	+	+			
IFI / ERE (Electronic Inline injection)	+	+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	+	+			
ASR	+	+			
ETS	+	+			
ESP (Electronic Stability Program)	+	+			
BAS (Brake Assist System)	+	+			
ADS (Adaptive Damping System)		+			
ASD (Automatic Locking Differential)		+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
IR (IR controller)		+			
ATA (Anti-Thief Alarm)	+ (before 97)	+			
RFL		+			
RCL (DAS2/X)		+			
APS		+			
RB		+			
RST		+			
HRA		+			

SL-class, 129

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
PTS (Parktronic System)	+	+			
D2B (AUDIO System)	+	+		+	
CTEL1 (Cellular Telephone 1)		+			
VCS		+			
TELE AID(K-wire)		+			
DN(K-wire)		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / HAC (Automatic Air conditioning)	+	+			
STH (Stationary Heater)	+	+			

SL-class, 230

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 1.0	+	+	+	+	+
ME 2.0 / 2.0 V8	+	+	+	+	+
ME 2.8 / 2.8 AMG	+	+	+	+	
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
ESM (Electronic Selector Module)	+	+		+	
DTR (Distronic)		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
SBC	+	+		+	
ABC (Active Body Control)	+	+	+	+	
TPC (Tire Pressure)	+	+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	+	+	+		
DCM RIGHT	+	+	+		
ESA – LEFT	+	+			
ESA – RIGHT	+	+			
OSB-FL (Multicontour backrest Left)	+	+			
OSB-FR (Multicontour backrest Right)	+	+			

SL-class, 230 (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)	+	+			
HRA-Front Right		+			
HRA-Front Left		+			
KG (keyless Go)	+	+			
SAM-Driver Side	+	+		+	
SAM-Passenger Side	+	+			
SAM-Rear	+	+		+	
PSE	+	+			
OCP	+	+			
LCP (Lower Control)	+	+	+		
BNS (Vehicle power supply module)		+			
RVC (Rollover bar / Vario Roof)	+	+	+		
System Diagnosis		+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	+	+		+	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
D2B	+	+		+	
D2B – CDC (CD Changer)		+			
D2B – CTEL1 (Cellular Telephone)		+			
D2B – CTEL2 (Cellular Telephone)		+			
D2B – VCS (Voice Control)		+			
D2B – SOUND (Bose SOUND System)		+			
D2B – TELE AID		+			
D2B – TV (TV Tuner)		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+			
STH (Stationary Heater)	+	+			

SL-class, 230-CAN

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	+	+	+	+	
ME 2.8 / 2.8 AMG	+	+	+	+	
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
ESM (Electronic Selector Module)	+	+		+	
DTR (Distronic)		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)		+			
SBC	+	+	+		
ABC (Active Body Control)		+			
TPC (Tire Pressure)		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	+	+	+		
DCM RIGHT	+	+	+		
ESA – LEFT	+	+			
ESA – RIGHT	+	+			
OSB-FL (Multicontour backrest Left)	+	+			
OSB-FR (Multicontour backrest Right)	+	+			

SL-class, 230-CAN(continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW		+			
WSS	+	+		+	
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)		+			
HRA-Front Right		+			
HRA-Front Left		+			
KG (keyless Go)		+			
SAM-Driver Side	+	+		+	
SAM-Passenger Side	+	+			
SAM-Rear	+	+		+	
PSE	+	+			
OCP	+	+			
LCP (Lower Control)	+	+	+		
BNS (Vehicle power supply module)		+			
RVC (Rollover bar / Vario Roof)	+	+	+		
System Diagnosis		+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	+	+		+	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
D2B	+	+		+	
D2B – CDC (CD Changer)		+			
D2B – CTEL1 (Cellular Telephone)		+			
D2B – CTEL2 (Cellular Telephone)		+			
D2B – VCS (Voice Control)		+			
D2B – SOUND (Bose SOUND Systen)		+			
D2B – TELE AID		+			
D2B – TV (TV Tuner)		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+			
STH (Stationary Heater)	+	+			

SLR-class, 199 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 1.0	+	+	+	+	+
ME 2.0 / 2.0 V8	+	+	+	+	+
ME 2.8 / 2.8 AMG	+	+	+	+	
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
ESM (Electronic Selector Module)	+	+		+	
DTR (Distronic)		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
SBC	+	+		+	
ABC (Active Body Control)	+	+	+	+	
TPC (Tire Pressure)	+	+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	+	+	+		
DCM RIGHT	+	+	+		
ESA – LEFT	+	+			
ESA – RIGHT	+	+			
OSB-FL (Multicontour backrest Left)	+	+			
OSB-FR (Multicontour backrest Right)	+	+			

SLR-class, 199 (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)	+	+			
HRA-Front Right		+			
HRA-Front Left		+			
KG (keyless Go)	+	+			
SAM-Driver Side	+	+		+	
SAM-Passenger Side	+	+			
SAM-Rear	+	+		+	
PSE	+	+			
OCP	+	+			
LCP (Lower Control)	+	+	+		
BNS (Vehicle power supply module)		+			
RVC (Rollover bar / Vario Roof)	+	+	+		
System Diagnosis		+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	+	+		+	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
D2B	+	+		+	
D2B – CDC (CD Changer)		+			
D2B – CTEL1 (Cellular Telephone)		+			
D2B – CTEL2 (Cellular Telephone)		+			
D2B – VCS (Voice Control)		+			
D2B – SOUND (Bose SOUND System)		+			
D2B – TELE AID		+			
D2B – TV (TV Tuner)		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+			
STH (Stationary Heater)	+	+			

SLS-class, 197-CAN with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7 AMG	+	+			
EGSHDKG (Transmission)	+	+		+	
UFPCAMG(Fuel pump)	+	+			
DSI (DIRECT SELECT interface)		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
EPB (Electronic parking brake)	+	+			
TPM	+	+			
AIRMATIC		+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	+	+			
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)	+	+			
KG	+	+			
SAM-Drive	+	+	+		
SAM-Rear	+	+			
WSS (Weight Sensing System)	+	+		+	
AMGDRVU (AMG DRIVE UNIT)		+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	+	+	+	OIL RESET	
SCM (Steering Column Module)	+	+	+		
DSI(DIRECT SELECT interface)		+			
PTS (Parktronic System)	+	+			
MOST – UCI(Media interface)	+	+			
MOST – COMMAND	+	+			
MOST – ZBE[COU](Audio/COMAND operating unit)	+	+			
MOST – ZAN(Audio/COMAND display)	+	+			
MOST – DAB(Digital Audio Broadcasting)		+			
MOST – SDAR(Satellite digital audio radio)		+			
MOST – SOUND (SOUND System)		+			
MOST – TV (TV Tuner)		+			
MOST – DTA(TELEAID)		+			
MOST – DTA (TELEAID) - Emergency call		+			
MOST – DTA (TELEAID) - MB Info / Breakdown assistance		+			
MOST – DTA (TELEAID) - Stolen vehicle tracking		+			
MOST – DTA (TELEAID) - Vehicle remote unlocking/locking		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
ESA – Driver	+	+	+		
ESA – Passenger		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)		+			

CLS-class, 219-CAN

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	+	+	+	+	
ME 9.7	+	+	+	+	
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
EGS 722.9	+	+		+	
ESM (Electronic Selector Module)	+	+		+	
DTR (Distronic)		+			
CDI 4		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
AIRMatic	+	+			
SBC	+	+		+	
TPC	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		+			
EIS (Electronic Ignition Switch) / KG(keyless)	+	+			
AB (SRS / Airbag)	+	+			
SAM-Driver		+			
SAM-Passenger		+			
SAM-Rear		+			
RevETR-FL	+	+			
RevETR-FR	+	+			
OCP		+		+	
LCP (Lower Control)		+			
UCP (Upper Control)		+			
HRA		+			
WSS (Weight Sensing System)	+	+		+	
System Diagnosis		+			
BCM	+	+			

*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

*QUICK SERVICE: Perform "Service Reset" within seconds.

CLS-class, 219-CAN (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+			
ASSYST (Active Service System)	+	+			
ASSYST PLUS (PLUS Active Service System)		+		+	
PTS (Parktronic System)		+			
SCM (Steering Column Module)		+			
MOST - AGW	+	+		+	
MOST - COMMAND / AUDIO		+			
MOST - CDC (CD Changer)		+			
MOST - HFS (Handsfree System and Microphone)		+			
MOST - CTEL (Cellular Telephone)		+			
MOST - VCS (Voice Control)		+			
MOST - NAVI (Navigation)		+			
MOST - SOUND (Bose SOUND System)		+			
MOST - TV (TV Tuner)		+			
MOST - SDAR (Satellite Radio)		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
DCM RL	+	+	+		
DCM RR	+	+	+		
ESA - Driver	+	+			
ESA - Passenger	+	+			
DS-FL (Front Left Dynamic Seat)	+	+			
DS-FR (Front Right Dynamic Seat)	+	+			
DSP (Pneumatic pump for Dynamic Seat)	+	+			
TLC (Trunk Lid Control)	+	+			
HS (Seat Heater)	+	+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	+	+			
HSW (Heated Steering Wheel)	+	+			

CL-class, 215 (nonCAN) with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 1.0	+	+	+	+	+
ME 2.0 / 2.0 V8	+	+	+	+	+
ME 2.8 / 2.8 AMG	+	+	+	+	
ME 2.7	+	+			
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
ESM (Electronic Selector Module)	+	+		+	
DTR (Distronic)		+			
CDI 2	+	+	+		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
ABC (Active Body Control)	+	+	+	+	
TPC (Tire Pressure)	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)	+	+			
HRA	+	+			
SAM-FRONT LEFT	+	+		+	
SAM-FRONT RIGHT	+	+			
SAM-REAR	+	+		+	
PSE (Pneumatic system)		+			
OCP	+	+			
UCP (Upper Control)	+	+			
KG	+	+			
AHE (Trailer recognition)		+			
SVMCM		+			

CL-class, 215 (nonCAN) with *QUICK SERVICE & *SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+			
DCM FR	+	+			
DCM RL	+	+			
DCM RR	+	+			
ESA – Driver	+	+			
ESA – Passenger	+	+			
ESA – R	+	+			
OSB-FL (Multicontour backrest front left)	+	+			
OSB-FR (Multicontour backrest front Right)	+	+			
OSB-R (Multicontour backrest rear)	+	+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	+	+		Service Reset / Oil Quality	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
D2B	+	+		+	
D2B – CDC (CD Changer)		+			
D2B – CTEL1 (Cellular Telephone)		+			
D2B – CTEL2 (Cellular Telephone)		+			
D2B – VCS (Voice Control)		+			
D2B – SOUND (Bose SOUND Systen)		+			
D2B – TV (TV Tuner)		+			
D2B – TELE AID		+			
D2B – DN		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+			
KLA (Climate Control)	+	+			
REAR AC	+	+			
STH (Stationary Heater)	+	+			
HSW (Heated Steering Wheel)	+	+			
TSTH (Radio Remote Control STH)		+			

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	+	+	+	+	
ME 2.7	+	+			
ME 9.7	+	+	+	+	
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
EGS 722.9	+	+		+	
ESM (Electronic Selector Module)	+	+			
DTR (Distronic)		+			
CDI 2	+	+	+		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
ABC (Active Body Control)	+	+	+	+	
TPC (Tire Pressure)	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		+			
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)	+	+			
RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			
RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
HRA	+	+			
HLCM-L (Left headlamp)	+	+			
HLCM-R (Right headlamp)	+	+			
KG (keyless Go)	+	+			
SAM-FRONT LEFT	+	+			
SAM-FRONT RIGHT	+	+			
SAM-REAR	+	+			
PSE (Pneumatic system)		+			
OCP	+	+			
UCP (Upper Control)	+	+			
System Diagnosis		+			
AHE (Trailer recognition)		+			
SVMCM		+			

CL-class, 215-CAN with *QUICK SERVICE & *SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+			
DCM FR	+	+			
DCM RL	+	+			
DCM RR	+	+			
ESA – Driver	+	+			
ESA – Passenger	+	+			
ESA – R	+	+			
DS-FL (Front Left Dynamic Seat)	+	+			
DS-FR (Front Right Dynamic Seat)	+	+			
DSP (Pneumatic pump for Dynamic Seat)	+	+			
OSB-FL (Multicontour backrest front left)	+	+			
OSB-FR (Multicontour backrest front Right)	+	+			
OSB-R (Multicontour backrest rear)	+	+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	+	+		Service Reset / Oil Quality	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+		+	
MOST – AGW	+	+			
MOST – COMMAND / AUDIO		+			
MOST – CDC (CD Changer)		+			
MOST – HFS (Handsfree System and Microphone)		+			
MOST – CTEL (Cellular Telephone)		+			
MOST – VCS (Voice Control)		+			
MOST – NAVI (Navigation)		+			
MOST – SOUND (Bose SOUND Systen)		+			
MOST – TV (TV Tuner)		+			
MOST – SDAR (Satellite Radio)		+			
D2B	+	+		+	
D2B – CDC (CD Changer)		+			
D2B – CTEL1 (Cellular Telephone)		+			
D2B – CTEL2 (Cellular Telephone)		+			
D2B – VCS (Voice Control)		+			
D2B – SOUND (Bose SOUND Systen)		+			
D2B – TV (TV Tuner)		+			
D2B – DN		+			

CL-class, 215-CAN with *QUICK SERVICE & *SHORT TEST (continued)

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+			
REAR AC	+	+			
STH (Stationary Heater)	+	+			
HSW (Heated Steering Wheel)	+	+			
TSTH (Radio Remote Control STH)		+			

CL-class, 216 with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
EGS 722.9	+	+		+	
ISM (Intelligent servo module)	+	+	+		
DTR (Distronic)		+			
SGR (Radar sensors control unit)		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABR (Adaptive Brake)	+	+			
ABC		+			
EPB (Electronic parking brake)	+	+			
TPC (Tire Pressure)	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		+			
EIS (Electronic Ignition Switch)	+	+			
AB (SRS / Airbag)	+	+			
WSS (Weight sensing system)	+	+		+	
RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			
RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
XALWA-L (Left headlamp)	+	+			
XALWA-R (Right headlamp)	+	+			
KG (keyless Go)	+	+			
SAM-Driver	+	+			
SAM-REAR	+	+			
OCP	+	+			
UCP (Upper Control)	+	+			
COU – ZBE (Central operating unit)	+	+			
HBF (Rear control field / panel)		+			
System Diagnosis		+			
BNS (Vehicle power supply control module)	+	+			
AHE (Trailer recognition)		+			
SVMCM		+			

CL-class, 216 with *QUICK SERVICE & *SHORT TEST(continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
ESA – Driver	+	+			
ESA – Passenger	+	+			
DS-FL (Front Left Dynamic Seat)		+			
DS-FR (Front Right Dynamic Seat)		+			
DSP (Pneumatic pump for Dynamic Seat)		+			
MKL-HL (Rear left Multicontour backrest)		+			
MKL-HR (Rear right Multicontour backrest)		+			
TLC (Trunk lid control)	+	+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC (Instrument Cluster)	+	+			
ASSYST (Active Service System)	+	+			
ASSYST PLUS (PLUS Active Service System)	+	+		+ (Service reset)	
NSA (Night View Assist)	+	+			
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)	+	+			
RFK (Backup camera)	+	+			
COMAND		+			
ZAN (Central Display)		+			
TELE-AID		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+	+	+	
KBE-H (Rear A/C operating unit)	+	+			
STH (Stationary Heater)		+			

R-class, 251 with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	+	+	+	+	
EGS 722.9	+	+		+	
ISM (Intelligent servo module)	+	+	+		
DTR (Distronic)		+			
CDI 5		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ENR (Electronic level control)	+	+			
AIRmatic (Suspension)	+	+			
ESP	+	+			
TPC (Tire Pressure)		+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		+			
EIS (Electronic Ignition Switch) / KG (Keyless Go)	+	+			
AB (SRS / Airbag)	+	+			
WSS (Weight sensing system)		+		+	
RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			
RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
HRA (Headlamp)		+			
SAM-Front	+	+		+	
SAM-REAR	+	+		+	
OCP	+	+		+	
UCP (Upper Control)	+	+			
HBF (Rear control field / panel)	+	+			
System Diagnosis		+			

R-class, 251 with *QUICK SERVICE & *SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
ESA – Driver	+	+			
ESA – Passenger	+	+			
DS-FL (Front Left Dynamic Seat)	+	+			
DS-FR (Front Right Dynamic Seat)	+	+			
DSP (Pneumatic pump for Dynamic Seat)	+	+			
HS (Seat heater)	+	+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+			
ASSYST (Active Service System)	+	+			
ASSYST PLUS (PLUS Active Service System)		+		+	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)		+			
CM (Compass Module)	+	+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+	+	+	
STH (Stationary Heater)	+	+			
HSW (Heated steering wheel)	+	+			

M-class, 163 with SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	+	+	+	+	+
ME 2.8 / 2.8 AMG	+	+	+	+	
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
EGS 722.6 (5-speed automatic SEQ)	+	+			
ESM	+	+		+	
TC / VG	+	+			
CDI 2	+	+	+		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	+	+			
ASR	+	+			
ETS	+	+			
ESP (Electronic Stability Program)	+	+			
BAS (Brake Assist System)	+	+			
VP (Vacuum Pump Brake Booster)	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
AAM (All Activity Module)	+	+		+	
EAM (Extended Activity Module)	+	+		+	
DAS (Drive Auth. System)	+	+			
LCP (Lower Control)	+	+			
HRA	+	+			
SEM (Security Module)		+			

M-class, 163 with SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
PTS (Parktronic System)	+	+			
D2B (AUDIO System)	+	+		+	
CDC (CD Changer)		+			
CTEL (Cellular Telephone)		+			
VCS		+			
SOUND		+			
TELE-AID		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC (Tempmatic Air conditioning)	+	+	+ (partial version)	+ (partial version)	
STH (Stationary Heater)	+	+			

M-class, 164-CAN with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	+	+	+	+	
ME 9.7	+	+	+	+	
EGS 722.9	+	+		+	
CDI 3		+			
CDI 4		+			
TC / VG		+			
ISM	+	+	+		
HAQ		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
AIRmatic (Suspension)	+	+		+	
TPC (Tire Pressure)		+			

M-class, 164-CAN with *QUICK SERVICE & *SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		+			
EIS (Electronic Ignition Switch) / KG (Keyless Go)	+	+		+	
AB (SRS / Airbag)	+	+			
RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			
RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
HRA		+			
SAM-FRONT	+	+			
SAM-REAR	+	+			
OCP	+	+		+	
UCP (Upper Control)	+	+			
HBF (Rear Control Field)	+	+			
System Diagnosis		+			
WSS (Weight Sensing System)	+	+		+	
AHE (Trailer recognition)		+			
SVMCM		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
ESA – Driver	+	+			
ESA – Passenger	+	+			
DS-FL (Front Left Dynamic Seat)	+	+			
DS-FR (Front Right Dynamic Seat)	+	+			
DSP (Pneumatic pump for Dynamic Seat)	+	+			
HS (Seat Heater)	+	+			

M-class, 164-CAN with *QUICK SERVICE & *SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+			
ASSYST (Active Service System)	+	+			
ASSYST PLUS (PLUS Active Service System)		+		+	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)		+			
CM (Compass Module)	+	+			
MOST - AGW	+	+		+	
MOST - COMMAND / AUDIO		+			
MOST - CDC (CD Changer)		+			
MOST - HFS (Handsfree System and Microphone)		+			
MOST - CTEL (Cellular Telephone)		+			
MOST - VCS (Voice Control)		+			
MOST - NAVI (Navigation)		+			
MOST - SOUND (Bose SOUND System)		+			
MOST - TV (TV Tuner)		+			
MOST - SDAR (Satellite Radio)		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+	+	+	
STH (Stationary Heater)	+	+			
HSW (Heated Steering Wheel)	+	+			

M-class, 166 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	+	+	+	+	
MED 17.7	+	+			
EGS 722.9	+	+		+	
FSCU(Fuel pump)	+	+			
ISM (Intelligent servo module)	+	+			
SGR(Radar sensors control unit)		+			
DTR (Distrionic)	+	+			
TC -Transfer case		+			
CDI 6		+			
CDID 3		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)		+			
AIRmatic (Suspension)		+		+	
TPC (Tire Pressure)	+	+			
EPB (Electronic parking brake)		+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	+	+			
EIS (Electronic Ignition Switch)		+			
AB (SRS / Airbag)		+			
KG		+			
SAM-Drive	+	+			
SAM-Rear	+	+			
RevETR-LF		+			
RevETR-RF		+			
SVMCM		+			
SD(Control module sliding roof)		+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)		+			
SCM (Steering Column Module)		+			
PTS (Parktronic System)		+			
MFK(Multifunction camera)	+	+			
RFK(Backup camera)		+			
NSA(Night View Assist)	+	+			
MOST – UCI(Media interface)	+	+			
MOST – COMMAND	+	+			
MOST – ZBE[COU](Audio/COMAND operating unit)	+	+			
MOST – ZAN(Audio/COMAND display)	+	+			
MOST – DAB(Digital Audio Broadcasting)		+			
MOST – SDAR(Satellite digital audio radio)		+			
MOST – SOUND (SOUND System)		+			
MOST – TV (TV Tuner)		+			
MOST – DTA(TELEAID)		+			
MOST – DTA (TELEAID) - Emergency call		+			
MOST – DTA (TELEAID) - MB Info / Breakdown assistance		+			
MOST – DTA (TELEAID) - Stolen vehicle tracking		+			
MOST – DTA (TELEAID) - Vehicle remote unlocking/locking		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL		+			
DCM FR		+			
DCM RL		+			
DCM RR		+			
ESA – Driver		+			
ESA – Passenger		+			
HKS (Tailgate control)		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)		+		+	
STH (Stationary heater with remote control)		+			

G-class, 463

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	+	+	+	+	+
ME 2.8 / 2.8 AMG	+	+	+	+	
ME 9.7	+	+	+	+	
HFM	+	+	+		
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
ESM	+	+		+	
VGS		+			
CDI 2	+	+	+		
CDI V	+	+			
CDI 4(Common Rail Diesel Injection)	+	+			
CDI 6(Common Rail Diesel Injection)		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	+	+			
ASR	+	+			
ETS	+	+			
ESP (Electronic Stability Program)	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
ATA	+	+			
RFL		+			
EIS	+	+		+	
OCP		+		+	
UCP		+			
SAM-FRONT		+		+	
SAM-REAR		+		+	
AHE		+			
VR	+	+			
SVMCM		+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
D2B (AUDIO System)	+	+		+	
CDC (CD Changer)		+			
CTEL (Cellular Telephone)		+			

VCS		+			
SCM		+			
APS		+			
TV		+			
TELE-AID		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+			
DCM FR	+	+			
DCM RL	+	+	+		
DCM RR	+	+	+		
ESA – Driver		+			
ESA – Passenger		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / TAC (Automatic Air conditioning)	+	+			
STH (Stationary Heater)	+	+			

GL-class, X164-CAN with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	+	+	+	+	
ME 9.7	+	+	+	+	
EGS 722.9	+	+	+	+	
CDI 3		+			
CDI 4		+			
TC / VG		+			
ISM	+	+	+		
HAQ		+			
DTR		+			
FSCU(Fuel pump)		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
AIRmatic (Suspension)	+	+		+	
TPC (Tire Pressure)		+			

GL-class, X164-CAN with *QUICK SERVICE & *SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		+			
EIS (Electronic Ignition Switch)	+	+		+	
AB (SRS / Airbag)	+	+			
RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			
RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
HRA		+			
SAM-FRONT	+	+			
SAM-REAR	+	+			
OCP	+	+		+	
UCP (Upper Control)	+	+			
HBF (Rear Control Field)	+	+			
System Diagnosis		+			
WSS (Weight Sensing System)	+	+		+	
AHE (Trailer recognition)		+			
KG (Keyless Go)		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+	+		
DCM FR	+	+	+		
ESA – Driver	+	+			
ESA – Passenger	+	+			
DS-FL (Front Left Dynamic Seat)	+	+			
DS-FR (Front Right Dynamic Seat)	+	+			
DSP (Pneumatic pump for Dynamic Seat)	+	+			
HS (Seat Heater)	+	+			
ERA (Electric fold-down backrest system)	+	+			
REDC (Rear-end door closing control module)	+	+			

GL-class, X164-CAN with *QUICK SERVICE & *SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+			
ASSYST (Active Service System)	+	+			
ASSYST PLUS (PLUS Active Service System)		+		+	
SCM (Steering Column Module)	+	+			
PTS (Parktronic System)		+			
CM (Compass Module)	+	+			
MOST - AGW	+	+		+	
MOST - COMMAND / AUDIO		+			
MOST - CDC (CD Changer)		+			
MOST - HFS (Handsfree System and Microphone)		+			
MOST - CTEL (Cellular Telephone)		+			
MOST - VCS (Voice Control)		+			
MOST - NAVI (Navigation)		+			
MOST - SOUND (Bose SOUND System)		+			
MOST - TV (TV Tuner)		+			
MOST - SDAR (Satellite Radio)		+			
AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	+	+	+	+	
STH (Stationary Heater)	+	+			
HSW (Heated Steering Wheel)	+	+			

SPRINTER 901,902,903,904,905

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	+	+	+	+	+
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
ESM (Electronic Selector Module)	+	+		+	
CDI 1	+	+		+	
CDI 1.7	+	+			
CDI 2	+	+	+		
IFI	+	+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	+	+			
ASR	+	+			
ETS	+	+			
ESP (Electronic Stability Program)	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
APS		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / TAC (Automatic Air conditioning)	+	+			
STH (Stationary Heater)	+	+			

SPRINTER 906-CAN

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CDI 4		+			
EGS 722.9	+	+	+	+	
ESM (Electronic Selector Module)	+	+			
VG	+	+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
TPC		+		+	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAG(Trailer connection unit)		+			
OCP(Overhead control panel)		+			
EIS(Electronic ignition switch)	+	+			
KE(Keyless Entry)		+			
HRA(Headlamp range adjustment)	+	+			
SCM(Steering column module)		+			
UCP(Upper control panel)		+			
SAM-F	+	+			
AB(Airbag)	+	+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)		+		Service Reset	
MTCO(Modular tachograph)		+			
PTS(Parktronic system)		+			
AGW(Audio gateway)		+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
STL(Left electric sliding door)		+			
STR(Right electric sliding door)		+			
DCM(Door control module)	+	+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC(Automatic air conditioning)	+	+			
PTC(Electric heater booster)	+	+			
STH(Auxiliary heater)	+	+			
ZHZ(Heater booster)	+	+			

VANEQ

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ECM/MSM (Engine Control Monolith)	+	+			
CDI 1 (Common Rail Diesel Injection)	+	+			
ACS (Automatic Clutch System)		+			
FTC (Front Transmission Control)		+			
GRM (Gear Recognition Module)		+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	+	+			
ESM	+	+		+	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
ATA (Anti-Thief Alarm)	+	+			
DAS (Drive Auth. System)	+	+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+		Service Reset / Oil Quality	
PTS (Parktronic System)	+	+			
D2B (AUDIO System)	+	+		+	
CDC (CD Changer)		+			
CTEL1 (Cellular Telephone 1)		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	+	+			
STH (Stationary Heater)		+			

VITO (638)

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	+	+	+	+	+
CDI 1 (Common Rail Diesel Injection)	+	+			
CDI 2 (Common Rail Diesel Injection)	+	+	+		
IFI	+	+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	+	+		Service Reset / Oil Quality	
APS		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	+	+			
STH (Stationary Heater)		+			

VITO / VIANO (639)

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	+	+	+	+	+
CDI 3 (Common Rail Diesel Injection)	+	+			
ETC	+	+			
ESM	+	+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP	+	+			
ENR	+	+			
TPC	+				

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			
OCP		+			
UCP	+	+			
SAM	+	+			
EIS		+			
SDE-H		+			
AAG		+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)		+		Service Reset / Oil Quality	
APS		+			
PTS	+	+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	+	+			
DCM FR	+	+			
ESA – Driver	+	+			
ESA – Passenger		+			
ESD-L (left electric sliding door)		+			
ESD-R (right electric sliding door)		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	+	+			
STH (Stationary Heater)		+			
REAR-AC	+	+			
PTC(Electric heater booster)	+	+			

VITO / VIANO - CHINA (636)

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	+	+	+	+	
EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
ESM (Electronic Selector Module)	+	+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP	+	+			
ENR	+	+			
TPC		+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)		+			
OCP		+			
UCP	+	+			
SAM		+			
EIS		+			
AHE (Trailer recognition)		+			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)		+			
PTS	+	+			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL		+			
DCM FR		+			
ESA – Driver		+			
ESA – Passenger		+			
ESD-L (left electric sliding door)		+			
ESD-R (right electric sliding door)		+			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC		+			
STH (Stationary Heater)		+			

VARIO					
DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	+	+	+	+	+
CDI 1 (Common Rail Diesel Injection)	+	+			
CDI 2 (Common Rail Diesel Injection)	+	+	+		
IFI	+	+			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	+	+			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	+	+			