

ISUZU VEHICLE COVERAGE

MAKER	CAR	SYSTEM1	SYSTEM2	DLC ADAPTER	DTC	CURRENT	ACTUATOR	SPECIAL FUNCTION
ISUZU	AMIGO	ENGINE	2.2L L4 X22SE	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	AMIGO	ENGINE	3.0L L4 4JX1	OBDII 16PIN CONNECTOR	O	O		injector coding
ISUZU	AMIGO	ENGINE	3.2L V6 6VD1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	AMIGO	ENGINE	3.2L V6 6VD1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	AMIGO	ENGINE	3.5L V6 6VE1 HITAC(~02)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AMIGO	ENGINE	4JH1-TC BOSCH(01~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	AMIGO	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	AMIGO	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AMIGO	AUTOMATIC TRANSAXLE	4L30E(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	AMIGO	AUTOMATIC TRANSAXLE	AW30-40LE(~2002MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AMIGO	AUTOMATIC TRANSAXLE	AW30-40LE(2003MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	AMIGO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AMIGO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AMIGO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AMIGO	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AMIGO	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AMIGO	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AXIOM	ENGINE	3.5L V6 6VE1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	AXIOM	ENGINE	3.5L V6 6VE1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	AXIOM	ENGINE	3.5L V6 6VE1 HITAC(~02)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AXIOM	ENGINE	4JH1-TC BOSCH(03~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	AXIOM	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	AXIOM	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AXIOM	AUTOMATIC TRANSAXLE	4L30E(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	AXIOM	AUTOMATIC TRANSAXLE	AW30-40LE(~2002MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AXIOM	AUTOMATIC TRANSAXLE	AW30-40LE(2003MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	AXIOM	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AXIOM	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AXIOM	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AXIOM	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AXIOM	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	AXIOM	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	BIGHORN	ENGINE	3.0L L4 4JX1	OBDII 16PIN CONNECTOR	O	O		injector coding
ISUZU	BIGHORN	ENGINE	3.2L V6 6VD1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	

ISUZU VEHICLE COVERAGE

MAKER	CAR	SYSTEM1	SYSTEM2	DLC ADAPTER	DTC	CURRENT	ACTUATOR	SPECIAL FUNCTION
ISUZU	BIGHORN	ENGINE	3.2L V6 6VD1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	BIGHORN	ENGINE	3.2L V6 6VE1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	BIGHORN	ENGINE	3.2L V6 6VE1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	BIGHORN	ENGINE	3.5L V6 6VE1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	BIGHORN	ENGINE	3.5L V6 6VE1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	BIGHORN	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	BIGHORN	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	BIGHORN	AUTOMATIC TRANSAXLE	4L30E(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	BIGHORN	AUTOMATIC TRANSAXLE	AW30-40LE(~2002MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	BIGHORN	AUTOMATIC TRANSAXLE	AW30-40LE(2003MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	BIGHORN	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	BIGHORN	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	BIGHORN	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	BIGHORN	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	BIGHORN	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	BIGHORN	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	ELF,NPR,NQR,VFR,NL	ENGINE	3.0L 4JJ1-TC(DELPHI)	OBDII 16PIN CONNECTOR	O	O	O	DPD FORCED REGENERATION DPD SLOWLY FORCED REGENERATION DPD REGENERATION DATA RESET INJECTOR CODE CHECK INJECTOR CODE REGISTRATION INJECTOR CODE READ&WRITE(ECU CHANGE) MAF CORRECTION DATA SERVICE MODE MAF DATA READ&WRITE(ECU CHANGE) MAF CORRECTION DATA CHECK ERASING THE LEARNED SUPPLY PUMP
ISUZU	ELF,NPR,NQR,VFR,NL	ENGINE	4HK1-TC(C/RAIL EURO5)	OBDII 16PIN CONNECTOR	O	O	O	DPD NORMAL REGENERATION DPD SLOW REGENERATION DPD STATUS RESET ENGINE OIL EXCHANGE RESET INJECTOR CODING SUPPLY PUMP INITIALIZATION
ISUZU	ELF,NPR,NQR,VFR,NL	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	ELF,NPR,NQR,VFR,NL	BODY	IMMOBILISER	OBDII 16PIN CONNECTOR	O	O		

ISUZU VEHICLE COVERAGE

MAKER	CAR	SYSTEM1	SYSTEM2	DLC ADAPTER	DTC	CURRENT	ACTUATOR	SPECIAL FUNCTION
ISUZU	ELF,NPR,NQR,VFR,NL	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	ELF,NPR,NQR,VFR,NL	CHASSIS	SMOOTHER	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FRONTIER	ENGINE	2.0L L4 SOHC	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	FRONTIER	ENGINE	2.2L L4 SOHC	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	FRONTIER	ENGINE	2.XL L4 HV240	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FRONTIER	ENGINE	3.2L V6 6VD1 HITAC(~02)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FRONTIER	ENGINE	3.5L V6 6VE1 HITAC(~02)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FRONTIER	ENGINE	2.5 TDS (DIESEL)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FRONTIER	ENGINE	4JH1-TC BOSCH(02~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	FRONTIER	ENGINE	4JJ1-TC DELPHI(06~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	FRONTIER	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	FRONTIER	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FRONTIER	AUTOMATIC TRANSAXLE	4L30E(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	FRONTIER	AUTOMATIC TRANSAXLE	AW30-40LE(~2002MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FRONTIER	AUTOMATIC TRANSAXLE	AW30-40LE(2003MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	FRONTIER	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FRONTIER	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FRONTIER	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FRONTIER	BODY	IMMOBILISER	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FRONTIER	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	JACKAROO	ENGINE	3.0L L4 4JX1	OBDII 16PIN CONNECTOR	O	O		injector coding
ISUZU	JACKAROO	ENGINE	3.2L V6 6VD1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	JACKAROO	ENGINE	3.2L V6 6VD1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	JACKAROO	ENGINE	3.2L V6 6VE1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	JACKAROO	ENGINE	3.2L V6 6VE1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	JACKAROO	ENGINE	3.5L V6 6VE1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	JACKAROO	ENGINE	3.5L V6 6VE1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	JACKAROO	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	JACKAROO	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	JACKAROO	AUTOMATIC TRANSAXLE	4L30E(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	JACKAROO	AUTOMATIC TRANSAXLE	AW30-40LE(~2002MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	JACKAROO	AUTOMATIC TRANSAXLE	AW30-40LE(2003MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	JACKAROO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	JACKAROO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		

ISUZU VEHICLE COVERAGE

MAKER	CAR	SYSTEM1	SYSTEM2	DLC ADAPTER	DTC	CURRENT	ACTUATOR	SPECIAL FUNCTION
ISUZU	JACKAROO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	JACKAROO	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	JACKAROO	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	JACKAROO	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LAO-RODEO	ENGINE	2.0L L4 SOHC	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	LAO-RODEO	ENGINE	2.2L L4 SOHC	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	LAO-RODEO	ENGINE	2.XL L4 HV240	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LAO-RODEO	ENGINE	3.2L V6 6VD1 HITAC(~02)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LAO-RODEO	ENGINE	3.5L V6 6VE1 HITAC(~02)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LAO-RODEO	ENGINE	4JH1-TC BOSCH(02~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	LAO-RODEO	ENGINE	4JJ1-TC DELPHI(06~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	LAO-RODEO	AUTOMATIC TRANSAXLE	AT JR405E	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LAO-RODEO	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	LAO-RODEO	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LAO-RODEO	AUTOMATIC TRANSAXLE	4L30E(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	LAO-RODEO	AUTOMATIC TRANSAXLE	AW30-40LE(~2002MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LAO-RODEO	AUTOMATIC TRANSAXLE	AW30-40LE(2003MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	LAO-RODEO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LAO-RODEO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LAO-RODEO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LAO-RODEO	BODY	IMMOBILISER	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LAO-RODEO	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	ENGINE	2.0L L4 SOHC	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	LUV.KB	ENGINE	2.2L L4 SOHC	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	LUV.KB	ENGINE	2.XL L4 HV240	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	ENGINE	3.2L V6 6VD1 HITAC(~02)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	ENGINE	3.5L V6 6VE1 HITAC(~02)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	ENGINE	4JH1-TC BOSCH(02~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	LUV.KB	ENGINE	4JJ1-TC DELPHI(06~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	LUV.KB	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	LUV.KB	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	AUTOMATIC TRANSAXLE	4L30E(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	LUV.KB	AUTOMATIC TRANSAXLE	AW30-40LE(~2002MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	AUTOMATIC TRANSAXLE	AW30-40LE(2003MY~)	OBDII 16PIN CONNECTOR	O	O	O	

ISUZU VEHICLE COVERAGE

MAKER	CAR	SYSTEM1	SYSTEM2	DLC ADAPTER	DTC	CURRENT	ACTUATOR	SPECIAL FUNCTION
ISUZU	LUV.KB	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	BODY	IMMOBILISER	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	LUV.KB	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	ENGINE	2.5L 4JK1-TC(DELPHI)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	ENGINE	2.5L 4JK1-TC(TRANSTRON)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	ENGINE	2.0L L4 SOHC	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	RODEO	ENGINE	2.2L L4 SOHC	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	RODEO	ENGINE	2.2L L4 X22SE	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	RODEO	ENGINE	2.XL L4 HV240	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	ENGINE	3.0L L4 4JX1	OBDII 16PIN CONNECTOR	O	O		injector coding
ISUZU	RODEO	ENGINE	3.2L V6 6VD1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	RODEO	ENGINE	3.2L V6 6VD1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	RODEO	ENGINE	3.2L V6 6VD1 HITAC(~02)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	ENGINE	3.5L V6 6VE1 HITAC(~02)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	ENGINE	2.5 TDS (DIESEL)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	ENGINE	4JH1-TC BOSCH(01~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	RODEO	ENGINE	4JJ1-TC DELPHI(06~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	RODEO	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	RODEO	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	AUTOMATIC TRANSAXLE	4L30E(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	RODEO	AUTOMATIC TRANSAXLE	AW30-40LE(~2002MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	AUTOMATIC TRANSAXLE	AW30-40LE(2003MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	RODEO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		

ISUZU VEHICLE COVERAGE

MAKER	CAR	SYSTEM1	SYSTEM2	DLC ADAPTER	DTC	CURRENT	ACTUATOR	SPECIAL FUNCTION
ISUZU	RODEO	BODY	IMMOBILISER	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	BODY	IMMOBILISER(DELPHI)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	RODEO	BODY	IMMOBILISER(TRANSTRON)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	MU	ENGINE	2.2L L4 X22SE	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	MU	ENGINE	3.0L L4 4JX1	OBDII 16PIN CONNECTOR	O	O		injector coding
ISUZU	MU	ENGINE	3.2L V6 6VD1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	MU	ENGINE	3.2L V6 6VD1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	MU	ENGINE	3.5L V6 6VE1 HITAC(~02)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	MU	ENGINE	4JH1-TC BOSCH(01~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	MU	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	MU	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	MU	AUTOMATIC TRANSAXLE	4L30E(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	MU	AUTOMATIC TRANSAXLE	AW30-40LE(~2002MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	MU	AUTOMATIC TRANSAXLE	AW30-40LE(2003MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	MU	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	MU	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	MU	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	MU	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	MU	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	MU	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	TROOPER	ENGINE	3.0L L4 4JX1	OBDII 16PIN CONNECTOR	O	O		injector coding
ISUZU	TROOPER	ENGINE	3.2L V6 6VD1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	TROOPER	ENGINE	3.2L V6 6VD1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	TROOPER	ENGINE	3.2L V6 6VE1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	TROOPER	ENGINE	3.2L V6 6VE1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	TROOPER	ENGINE	3.5L V6 6VE1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	TROOPER	ENGINE	3.5L V6 6VE1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	TROOPER	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	TROOPER	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	TROOPER	AUTOMATIC TRANSAXLE	4L30E(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	TROOPER	AUTOMATIC TRANSAXLE	AW30-40LE(~2002MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	TROOPER	AUTOMATIC TRANSAXLE	AW30-40LE(2003MY~)	OBDII 16PIN CONNECTOR	O	O	O	

ISUZU VEHICLE COVERAGE

MAKER	CAR	SYSTEM1	SYSTEM2	DLC ADAPTER	DTC	CURRENT	ACTUATOR	SPECIAL FUNCTION
ISUZU	TROOPER	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	TROOPER	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	TROOPER	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	TROOPER	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	TROOPER	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	TROOPER	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	V-CROSS	ENGINE	3.2L V6 6VD1	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	V-CROSS	ENGINE	3.5L V6 6VE1	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	V-CROSS	AUTOMATIC TRANSAXLE	4L30E	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	V-CROSS	AUTOMATIC TRANSAXLE	4L30E	OBDII 16PIN CONNECTOR	O	O		
ISUZU	V-CROSS	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	V-CROSS	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	V-CROSS	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	V-CROSS	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	V-CROSS	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	V-CROSS	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	WIZARD	ENGINE	2.2L L4 X22SE	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	WIZARD	ENGINE	3.0L L4 4JX1	OBDII 16PIN CONNECTOR	O	O		injector coding
ISUZU	WIZARD	ENGINE	3.2L V6 6VD1(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	WIZARD	ENGINE	3.2L V6 6VD1(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	WIZARD	ENGINE	3.5L V6 6VE1 HITAC(~02)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	WIZARD	ENGINE	4JH1-TC BOSCH(01~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	WIZARD	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	WIZARD	AUTOMATIC TRANSAXLE	4L30E(~1999MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	WIZARD	AUTOMATIC TRANSAXLE	4L30E(2000MY~)	OBDII 16PIN CONNECTOR	O	O	O	AT oil reset
ISUZU	WIZARD	AUTOMATIC TRANSAXLE	AW30-40LE(~2002MY)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	WIZARD	AUTOMATIC TRANSAXLE	AW30-40LE(2003MY~)	OBDII 16PIN CONNECTOR	O	O	O	
ISUZU	WIZARD	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	WIZARD	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	WIZARD	CHASSIS	ANTI-LOCK BRAKE SYSTEM	OBDII 16PIN CONNECTOR	O	O		
ISUZU	WIZARD	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	WIZARD	CHASSIS	TOD	OBDII 16PIN CONNECTOR	O	O		
ISUZU	WIZARD	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	D-Max	ENGINE	2.5L 4JK1-TC(DELPHI)	OBDII 16PIN CONNECTOR	O	O		

ISUZU VEHICLE COVERAGE

MAKER	CAR	SYSTEM1	SYSTEM2	DLC ADAPTER	DTC	CURRENT	ACTUATOR	SPECIAL FUNCTION
ISUZU	D-Max	ENGINE	2.5L 4JK1-TC(TRANSTRON)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	D-Max	ENGINE	3.0L 4JJ1-TC(TransTron)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	D-Max	BODY	IMMOBILISER(DELPHI)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	D-Max	BODY	IMMOBILISER(TRANSTRON)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	D-Max	BODY	Immobiliser(V6 Engine)	OBDII 16PIN CONNECTOR	O	O		
ISUZU	D-Max	BODY	AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	D-Max	CHASSIS	ABS	OBDII 16PIN CONNECTOR	O	O		
ISUZU	D-Max	TRANSMISSION	AT JR405E	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FORWARD	ENGINE	6HK1	OBDII 16PIN CONNECTOR	O	O	O	INJECTOR READ INJECTOR WRITE
ISUZU	FORWARD	BODY	SRS-AIRBAG	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FORWARD	BODY	IMMOBILISER	OBDII 16PIN CONNECTOR	O	O		
ISUZU	FORWARD	BODY	BODY CONTROL MODULE	OBDII 16PIN CONNECTOR	O	O		ENGINE OIL DISTANCE RESETTNG TRANSMISSION OIL DISTANCE RESETTNG FUEL CONSUMPTION DATA RESETTNG ACCUMULATED ENGINE RUNTIME RESETTNG ENG LOG DATA FORCE RECORDING T/M LOG DATA FORCE RECORDING ACCUMULATED ENG LOG DATA CLEARING ACCUMULATED T/M LOG DATA CLEARING RECORDING DTC DATA CLEARING ALL ACCUMULATION DATA CLEARING
ISUZU	FORWARD	CHASSIS	ABS	OBDII 16PIN CONNECTOR	O	O		