

**PEUGEOT
VER. 2.28**

● : Support
- : NOT SUPPORT

MODEL	SYSTEM		TYPE	SUB TYPE	ID	DTC	CD	ACT	SP	
106 REMODELAGE	DME (ENGINE CONTROL)	PETROL	CDY BOSCH MA3.1		-	●	●	●	-	
			CDZ BOSCH MA3.1		-	●	●	●	-	
			HDY BOSCH MA3.1		-	●	●	●	-	
			HDZ BOSCH MA3.1		-	●	●	●	-	
			HFX BOSCH MA7.4.4		-	●	●	●	-	
			KFW SAGEM S2000		-	●	●	●	-	
			KFX BOSCH MP7.3		-	●	●	●	-	
			KFX MM1AP		-	●	●	●	-	
			NFX MM1AP		-	●	●	●	-	
			NFX MM48P		-	●	●	●	-	
			NFZ BOSCH MP5.2		-	●	●	●	-	
		DIESEL	VJU BOSCH VP20		-	●	●	●	-	
	VJX BOSCH VP20			-	●	●	●	-		
	TCU(AUTO TRANSMISSION)				-	●	●	-	-	
	ABS(ANTI LOCK BRAKE)		ABS TEVES MKIVGI		-	●	●	-	-	
	SRS(AIR BAG)		ABS TEVES MK20E		-	●	●	-	-	
	PROTECT THE VEHICLE		PEUGEOT IMMOBILISER	CDY	-	●	●	-	-	
				CDZ	-	●	●	-	-	
				HDY	-	●	●	-	-	
				HDZ	-	●	●	-	-	
				HFX	-	●	●	-	-	
				KFW	-	●	●	-	-	
				KFX MM1AP	-	●	●	-	-	
KFX BOSCH MP7.3				-	●	●	-	-		
NFW				-	●	●	-	-		
NFX MM1AP				-	●	●	-	-		
NFX MM4.8P				-	●	●	-	-		
NFZ				-	●	●	-	-		
VJU				-	●	●	-	-		
VJX				-	●	●	-	-		
VJY	-	●	●	-	-					
VJZ	-	●	●	-	-					
HEATING/VENTILATION		WEBASTO ADDITIONAL HEATING		-	●	●	-	-		
107	POWER STEERING				●	●	●	-	-	
	GEARBOX				-	●	●	●	-	
	DME (ENGINE CONTRL)	PETROL	PETROL		-	●	●	●	-	
		DIESEL	DIESEL		●	●	●	●	-	
	CODED ANTI START				-	●	●	-	-	
	ABS OR ESP		ABS BOSCH 8.0 C1		-	●	●	●	-	
	ESP BOSCH 8.0 C1			-	●	●	●	-		
1007	AIRBAG				●	●	●	-	-	
	AUTOSCAN				-	-	-	-	-	
	DME (ENGINE CONTROL)	PETROL	KFV SAGEM 2000 PM2	1.4	●	●	●	●	-	
			NFU BOSCH ME7.4.4	1.6	●	●	●	●	-	
			NFU BOSHC ME7.4.5		-	●	●	●	●	●
			KFV J34P		-	●	●	●	●	-
			KFU MM6LPL		-	●	●	●	●	-
		DIESEL	8HZ SIEMENS SID 804	1.4	●	●	●	●	-	
			8HX SID 806 DV4		-	●	●	●	●	-
			8HZ DIS 806 DV4		-	●	●	●	●	-
	9HZ BOSCH EDC16C3			-	●	●	●	●	●	
	TCU(AUTO TRANSMISSION)		CONTROLLED BREABOX(BVMP)		-	●	●	●	●	
	ABS(ANTI LOCK BRAKE)		MK 60 ESP		-	●	●	●	●	
	ABS MK70.1			-	●	●	●	●	●	
	SRS(AIR BAG)				-	●	●	-	●	
	BSI(BUILT-IN SYSTEM INTERFACE)				-	●	●	●	●	
	INSTRUMENT PANEL				-	●	●	●	●	
	CLIMATE CONTROL				-	●	●	●	-	
	PARKING ASSISTANCE				-	●	●	●	●	
	UNDER INFLATION DETECTION				-	●	●	-	●	
	POWER STEERING				-	●	●	●	-	
	MULTIFUNCTION DISPLAY				-	●	●	●	-	
	STEERING WHEEL SWITCH MODULE				-	●	●	●	-	
	RADIO				-	●	●	●	-	
	CD PLAYER				-	●	-	●	-	
	HANDS FREE KITS				-	●	●	●	-	
	TELEMATICS ECU				-	●	●	-	-	
MULTIPLYED ADDING PUMP				-	●	●	●	●		
ALARM				-	●	●	●	-		
RAIN/BRIGHTNESS SENSOR				-	●	-	-	-		
206	DEM (ENGINE CONTROL)	PETROL	7LZ MM5NP		-	●	●	●	-	
			HFX MM4.8P		-	●	●	●	-	
			RFR MM4.8P		-	●	●	●	-	
			RFN MM4.8P		-	●	●	●	-	
			HFX MM1AP		-	●	●	●	-	
			HFZ MM1AP		-	●	●	●	-	
			K6C MM1AP		-	●	●	●	-	
			KFW SAGEM S2000		-	●	●	●	-	
			K6D SAGEM S2000		-	●	●	●	-	
			KFX BOSCH MP7.3		-	●	●	●	-	
			KFX MM1AP		-	●	●	●	-	
			M6A BPSCH ,E7.4.4		-	●	●	●	-	
			NFU BOSCH ME7.4.4		-	●	●	●	-	
			NFZ BOSCH MP7.2		-	●	●	●	-	
			NFU MM6LP		-	●	●	●	-	
			RFK MM6LP		-	●	●	●	-	
			RFN MM6LP		-	●	●	●	-	

207	DEM(ENGINE CONTROL)	DIESEL	WJY LUCAS DCN2	-	●	●	●	-
			WJZ LUCAS DCN2	-	●	●	●	-
			RHY BOSCH EDC15C2	-	●	●	●	-
			8HX EDC16C3	-	●	●	●	-
			8HZ BOSCH DEC16C3	-	●	●	●	-
	TCU(AUTO TRANSMISSION)		AL4	●	●	●	●	-
	ABS(ANTI LOCK BRAKE)		ABS TEVES	-	●	●	-	-
			ABS MK70	-	●	●	-	-
	SRS(AIR BAG)		ESP MK60	-	●	●	-	-
			AIR BAG AND SEAT BELT	-	●	-	-	-
			SIDE AIR BAG(RIGHT SIDE)	-	●	-	-	-
			SIDE AIR BAG (LEFT SIDE)	-	●	-	-	-
	DRIVER INFO/COMMUNICATION		MULTI-FUNCTION DISPLAY	-	●	●	-	-
			ON-BOARD NAVIGATION SYSTEM	-	●	●	-	-
	CONTROL THE OPENINGS		ELECTIC RETRACTABLE ROOF	-	●	●	-	-
	RADIO			-	●	●	-	-
	AUTOSCAN			-	-	●	-	-
306 REMODELAGE	DEM (ENGINE CONTROL)	PETROL	N6A BOSCH ME7.4.5	-	●	●	●	●
			N6B BOSCH ME7.4.5	-	●	●	●	●
			NFU BOSCH ME7.4.5	-	●	●	●	●
			5FY MED17.4	-	●	●	●	●
			5FY MED17.4	-	●	●	-	-
			KFU MM7LPC	-	●	●	-	-
			KFV J34P	-	●	●	●	-
			5FW MEV17.4	-	●	●	●	-
			8FS MEV17.4	-	●	●	●	-
	DEM(ENGINE CONTROL)	DIESEL	8HZ BOSCH EDC16C3 EURO4	-	●	●	●	-
			9HX BOSCH EDC16C3	-	●	●	●	-
			9HY BOSCH EDC16C3 EURO4	-	●	●	●	-
			9HZ BOSCH EDC16C3	-	●	●	●	●
	TCU(AUTO TRANSMISSION)		CONTROLLED GEABOX(BVMP)	-	●	●	●	-
			AL4	-	●	●	-	●
	ABS(ANTI LOCK BRAKE)		ABS MK70	-	●	●	●	●
			ESP MK60-0	-	●	●	●	●
	SRS(AIR BAG)			-	●	●	-	●
	BSI(BUILT-IN SYSTEM INTERFACE)			-	●	●	●	●
	INSTRUMENT PANEL			-	●	●	●	●
	CLIMATE CONTROL			-	●	●	●	-
	PARKING ASSISTANCE			-	●	●	●	●
	UNDER INFLATION DETECTION			-	●	●	-	●
	POWER STEERING			-	●	●	-	-
	MULTIFUNCTION DISPLAY			-	●	●	-	-
	RADIO			-	●	●	●	-
	CD PLAYER			-	●	-	●	-
	STEERING WHEEL SWITCH MODULE			-	●	●	●	-
	HANDS FREE KITS			-	●	●	●	-
	TELEMATICS ECU			-	●	●	-	-
	MULTIPLEXED ADDING PUMP			-	●	●	-	●
	ALARM			-	●	●	●	-
	RAIN/BRIGHTNESS SENSOR			-	●	-	-	-
306 REMODELAGE	DME (ENGINE CONTROL)	PETROL	KFW SAGEM S2000	-	●	●	●	-
			K6D SAGE, S2000	-	●	●	●	-
			KFX BOSCH MP7.3	-	●	●	●	-
			KFX MM1AP	-	●	●	●	-
			LFY BOSCH MP7.3	-	●	●	●	-
			NFT BOSCH M7.4.4	-	●	●	●	-
			NFV BOSCH M7.4.4	-	●	●	●	-
			NFZ BOSCH MP5.2	-	●	●	●	-
			NFZ BOSCH MP7.2	-	●	●	●	-
			R6E BOSCH MP5.2	-	●	●	●	-
			RFS MM1AP	-	●	●	●	-
			RFV BOSCH MP5.2	-	●	●	●	-
		DIESEL	DHV BOSCH VP20	-	●	●	●	-
			DHY BOSCH VP20	-	●	●	●	-
			RHY BOSCH EDC15C2	-	●	●	●	-
			WJY LUCAS DCN2	-	●	●	●	-
	TCU(AUTO TRANSMISSION)		WJZ LUCAG DCN2	-	●	●	●	-
	ABS(ANTI LOCK BRAKE)			-	●	●	-	-
	SRS(AIR BAG)		AIR BAG AND SEAT BELT	-	●	-	-	-
			SIDE AIR BAG(RIGHT SIDE)	-	●	-	-	-
			SIDE AIR BAG (LEFT SIDE)	-	●	-	-	-
	PROTECT THE VEHICLE	PEUGEOT IMMOBILISER	A9A	-	●	●	-	-
			DHV	-	●	●	-	-
			DHY	-	●	●	-	-
			DJY	-	●	●	-	-
			KFX MM1AP	-	●	●	-	-
			KFX BOSCH MP7.3	-	●	●	-	-
			KFX SAGEM SL96	-	●	●	-	-
			L6A	-	●	●	-	-
			LFY SAGEM SL96	-	●	●	-	-
			LFY BOSCH MP 7.3	-	●	●	-	-
			LFZ	-	●	●	-	-
			NFT	-	●	●	-	-
			NFV	-	●	●	-	-
			NFZ BOSCH MP5.2	-	●	●	-	-
			NFZ BOSCH MP7.2	-	●	●	-	-
			R6E	-	●	●	-	-
			RFS	-	●	●	-	-
			RFV	-	●	●	-	-
			RHY	-	●	●	-	-
			WJY	-	●	●	-	-
			WJZ	-	●	●	-	-
			N6A BOSCH ME7.4.4	-	●	●	●	-
			NFU BOSCH ME7.4.4	-	●	●	●	-
			KFW SAGEM S2000	-	●	●	●	-

307

DME (ENGINE CONTROL)	PETROL	K6D SAGEM S2000		-	●	●	●	-
		RFN MM48P		-	●	●	●	-
		RFN MM4MP2		-	●	●	●	-
		KFU MM6LP		-	●	●	●	-
		RFK MM6LP		-	●	●	●	-
		RFN MM6LP		-	●	●	●	-
		RFN MM6LP		-	●	●	●	-
		N6A BOSCH ME7.4.5		-	●	●	●	●
		N6B BOSCH ME7.4.5		-	●	●	●	●
		NFU BOSCH ME7.4.5		-	●	●	●	●
		KFU MM6LP		-	●	●	●	-
		RFJ MM6LPB		-	●	●	●	●
		KFU MM6LPC		-	●	●	●	-
		NFU OR N6A N6B ME7.4.9		-	●	●	●	●
	NFU,N6A,N6B ME7.4.9 FLEX FUEL		-	●	●	●	●	
	DIESEL	8HZ BOSCH EDC16C3		-	●	●	●	-
		9HZ BOSCH EDC16C3		-	●	●	●	-
		9HY BOSCH EDC16C3		-	●	●	●	-
		RHS BOSCH EDC15C2		-	●	●	●	-
		RHY BOSCH EDC15C2		-	●	●	●	-
		RHZ BOSCH EDC15C2		-	●	●	●	-
		RHY SIEMENS SID 801		-	●	●	●	-
		RHR SIEMENS SID 803		-	●	●	●	-
		9HV BOSCH EDC16C3		-	●	●	●	●
		9HX BOSCH EDC16C3		-	●	●	●	-
		9HY BOSCH EDC16C3 EURO3		-	●	●	●	-
		9HY BOSCH EDC16C3 EURO4		-	●	●	●	-
RHL DCM3.4			-	●	●	●	●	
RHR DCM3.4		-	●	●	●	●		
TCU(AUTO LOCK BRAKE)			-	●	●	-	-	
ABS(ANTI LOCK BRAKE)	ABS BOSCH 5.3		-	●	●	-	-	
	ABS BOSCH 8		-	●	●	●	●	
	ABS BOSCH 8.1		-	●	●	●	●	
	ESP BOSCH 5.7		-	●	●	-	-	
	ESP BOSCH 8		-	●	●	●	●	
SRS(AIR BAG)	ESP BOSCH 8.1		-	●	●	●	●	
				-	●	●	-	●
BSI (BUILT-IN SYSTEM INTERFACE)	BSI DEFAULT		-	●	●	●	●	
	SW VERS : 10 -> 18		-	●	●	●	●	
	SW VERS : 20 -> 21		-	●	●	●	●	
	SW VERS : 31 SW INDEX : 0		-	●	●	●	●	
	SW VERS : 32 SW INDEX : 2		-	●	●	●	●	
	SW VERS : 33 SW INDEX : 5		-	●	●	●	●	
	SW VERS : 34 SW INDEX : 0		-	●	●	●	●	
	SW VERS : 34 SW INDEX : 20		-	●	●	●	●	
	SW VERS : 35 SW INDEX : 0		-	●	●	●	●	
SW VERS : 35 SW INDEX : 20		-	●	●	●	●		
CLIMATE CONTROL			-	●	●	●	-	
UNDER INFLATION DETECTION			-	●	●	●	●	
MULTIFUNCTION DISPLAY			-	●	●	●	-	
STEERING WHEEL SWITCH MODULE			-	●	●	●	-	
DIESEL ADDITIVE FUNCTION	MARWEL		-	●	●	●	●	
	CAN SYSTEM		-	●	●	●	●	
ALARM			-	●	●	●	-	
DRIVER INFO/COMMUNICATION	DISPLAY /TELEMATIC		-	●	●	-	-	
	PARK AID		-	●	●	-	-	
	RADIO		-	●	●	●	-	
	CD PLAYER		-	●	●	●	-	
	INSTRUMENT PANEL		-	●	●	●	●	
VISIBILITY/LIGHTING		DRIVING SCHOOL	-	●	●	-	-	
ROLL-OVER ECU			-	●	●	-	-	
CONTROL THE OPENINGS	DRIVER DOOR MODULE		-	●	●	●	-	
	PASSENGER DOOR MODULE		-	●	●	●	-	
	RETRACTABLE ROOF		-	●	●	-	-	
	SUN ROOF		-	●	●	●	●	
HEATING/VENTILATION			-	●	●	-	-	
ELECTRIC PUMP UNIT			-	●	●	-	-	
HANDS FREE KITS			-	●	●	●	-	
MULTIPLEXED ADDING PUMP			-	●	●	●	●	
RAIN/BRIGHTNESS SENSOR			-	●	-	-	-	

308

AUTOSCAN				-	-	-	-	-
DME (ENGINE CONTROL)	PETROL	N6A BOSCH ME7.4.4		-	●	●	●	●
		N6B BOSCH ME7.4.5		-	●	●	●	●
		NFU BOSCH ME7.4.4		-	●	●	●	●
		RFJ MM6LPN		-	●	●	●	●
		5FW MEV17.4		-	●	●	●	-
		8FS MEV17.4		-	●	●	●	-
		5FY MED17.4		-	●	●	●	-
	5FX MED17.4		-	●	●	●	-	
		9HV BOSCH EDC16C3		-	●	●	●	●
		9HX BOSCH EDC16C3		-	●	●	●	●
		9HY BOSCH EDC16C3		-	●	●	●	-
		9HZ BOSCH EDC16C3		-	●	●	●	-
		RHL DCM3.4		-	●	●	●	●
		RHR DCM3.4		-	●	●	●	●
		AM6 GEARBOX		-	●	●	●	●
TCU(AUTO LOCK BRAKE)		CFC300P GRARBOX		-	●	●	●	-
		AL4		-	●	●	-	●
ABS(ANTI LOCK BRAKE)		ABS BOSCH 8.1		-	●	●	●	●
		ESP BOSCH 8.1		-	●	●	●	●
SRS(AIR BAG)				-	●	●	-	●
BSI(BUILT-IN SYSTEM INTERFACE)				-	●	●	●	●
CLIMATE CONTROL				-	●	●	●	-
PARKING ASSISTANCE				-	●	●	-	●
INSTRUMENT PANEL				-	●	●	●	●
ELECTROPUMP ASSEMBLY				-	●	●	●	-
UNDER INFLATION DETECTION				-	●	●	-	●

	MULTIFUNCTION DISPLAY					-	●	●	●	-
	RADIO					-	●	●	●	-
	DRIVER SEAT MEMORY UNIT					-	●	●	●	-
	HANDS FREE KITS					-	●	●	●	-
	TELEMATICS ECU					-	●	●	●	-
	STEERING WHEEL SWITCH MODULE					-	●	●	-	-
	CD CHANGER					-	●	-	●	-
	ALARM					-	●	●	●	-
	DRIVER DOOR CONTROL PANEL					-	●	●	●	-
	LAND DEPARTURE WARNING					-	●	●	-	●
	RAIN/BRIGHTNESS SENSOR					-	●	-	-	-
3008	AUTOSCAN					-	-	-	-	-
	DME (ENGINE CONTROL)	PETROL	5FW MEV17.4			-	●	●	●	-
			5FX MEV17.4			●	●	●	●	-
			5FS MEV17.4			●	●	●	●	-
			5FV MEV17.4			●	●	●	●	-
		DIESEL	9HZ Bosch EDC16C3			-	●	●	●	●
			RHH DCM3.5			●	●	●	●	-
	RHE DCM3.5				●	●	●	●	-	
	BUINLT-IN SYSTEM INTERFACE					●	●	●	●	-
	AUDIO AMPLIFIER					●	●	-	●	-
	MULTIFUNCTION DISPLAY		EMF_A			●	●	●	●	-
			EMF_C			●	●	●	●	-
	AIRBAG ECU					●	●	●	●	-
	SWITCH MODULE STEERING WHEEL					●	●	●	●	-
	RAIN SENSOR / BRIGHTNESS					●	-	-	-	-
	AUTOMATIC TRANSMISSION COTROL UNIT		CFC300P GEARBOX			●	●	●	●	-
			AM6 EURO5 GEARBOX			●	●	●	●	-
			AT6 EURO5 GEARBOX			●	●	●	●	-
	CARPHONE HANDS FREE KIT					●	●	●	●	-
	RADIO					●	●	●	●	-
	TELEMATICS		RNGE RADIO NAVIGATION			●	●	●	●	-
			NG4 AUDIO/NAVIGATION			●	●	●	●	-
	SERVICES MODULE					●	●	●	●	-
	ALARM					●	●	●	●	-
	ABS OR ESP ECU		ESP 8.1			●	●	●	●	-
			ANTI-SLIP MODE SELECTOR			●	●	●	●	-
	HIGH HEAD VSION					●	●	●	●	-
	CONTROL PANEL					●	●	●	●	-
	INSTRUMENT PANEL		WITH MATRIX DISPLAY			●	●	●	●	-
	ASSISTANCE IN COMPLYINGE(ARTIV)					●	●	●	-	-
	WIPER					●	●	●	●	-
	DRIVER'S DOOR MODULE					●	●	●	●	-
	MULTIFLEXED ADDITIVE PUMP					●	●	●	●	-
	AUTOMATIC HEADLAMPS CORRECTOR					●	●	●	●	-
	LAND DEPARTURE WARNING SYSTEM					●	●	●	●	-
	AIR CONDITIONING ECU					●	●	●	●	-
	PARKING AID					●	●	●	-	-
	BATTERY CHARGE STATUS UNIT					●	●	●	●	-
	POWER STEERING					●	●	●	●	-
	UNDER INFLATION DETECTION					●	●	●	-	-
	CD PLAYER					●	●	-	●	-
	ELECTRIC PARKING BRAKE					●	●	●	●	-
NOT FASTEDNED WARNING LIGHT(TNB)					●	●	-	●	-	
406	DME (ENGINE CONTROL)	PETROL	LFX MM1AP			-	●	●	●	-
			LFY BOSCH MP5.1.1			-	●	●	●	-
			LFY BOSCH MP5.2			-	●	●	●	-
			LFY BOSCH MP7.3			-	●	●	●	-
			R6E BOSCH MP5.2			-	●	●	●	-
			RFV BOSCH MP5.1.1			-	●	●	●	-
			RFV BOSCH MP5.2			-	●	●	●	-
			RGX BOSCH MP3.2			-	●	●	●	-
	DME (ENGINE CONTROL)	DIESEL	DHX BOSCH VP20			-	●	●	●	-
			P8C LUCAS EPIC			-	●	●	●	-
			RHZ BOSCH DEC15C2			-	●	●	●	-
	TCU(AUTO TRANSMISSION)		4HP20			-	●	●	-	-
			AL4			-	●	●	-	-
	ABS(ANTI LOCK BRAKE)		ABS5 BOSCH			-	●	-	-	-
			ABS BOSCH 5.3			-	●	●	-	-
	SRS(AIR BAG)		AIR BAG AND SEAT BELT			-	●	-	-	-
			SIDE AIR BAG(RIGHT SIDE)			-	●	-	-	-
			SIDE AIR BAG (LEFT SIDE)			-	●	-	-	-
	CLIMATE CONTROL		CLIM_D9			●	●	●	●	-
	INSTRUMENT		VDO			●	●	●	●	-
	DIESEL ADDITIVE FUNCTION		MARWEL			-	●	●	-	-
	PEUGEOT IMMOBILISER		BFZ			-	●	●	-	-
			DHV			-	●	●	-	-
			DHW			-	●	●	-	-
			DHX			-	●	●	-	-
			L6A			-	●	●	-	-
			LFX			-	●	●	-	-
			LFY.BOSCH MP5.2			-	●	●	-	-
			LFY.BOSCH MP7.3			-	●	●	-	-
			LFY.SAGEM SL96			-	●	●	-	-
			P8C			-	●	●	-	-
			R6E			-	●	●	-	-
			RFV			-	●	●	-	-
			RGX			-	●	●	-	-
			RHZ			-	●	●	-	-
			XFZ			-	●	●	-	-
			3FZ MM4MP2			-	●	●	●	-
			6FZ SAGEM S2000			-	●	●	●	-
			RLZ SIMENS SIRIUS 91			-	●	●	●	-
			LFX MM1AP			-	●	●	●	-
			LFY BOSCH MP5.2			-	●	●	●	-

406
NOUVELLE

DEM(ENGINE CONTROL)	PETROL	LFY BOSCH MP7.3		-	●	●	●	-
		R6E BOSCH MP5.2		-	●	●	●	-
		R6F MM4.8P		-	●	●	●	-
		RFR MM4.8P		-	●	●	●	-
		RFN MM4.8P		-	●	●	●	-
		RFV BOSCH MP5.2		-	●	●	●	-
		XFX BOSCH ME7.4.6		-	●	●	●	-
		4HX BOSCH EDC15C2		-	●	●	●	-
		RHY BOSCH EDC15C2		-	●	●	●	-
		RHZ BOSCH EDC15C2		-	●	●	●	-
	DIESEL	4HP20		-	●	●	●	-
		AL4		-	●	●	●	-
		ABS BOSCH 5.3		-	●	●	●	-
		ESP BOSCH 5.3		-	●	●	●	-
		AIR BAG AND SEAT BELT		-	●	●	●	-
		SIDE AIR BAG(RIGHT SIDE)		-	●	●	●	-
		SIDE AIR BAG (LEFT SIDE)		-	●	●	●	-
		3FZ		-	●	●	●	-
		4HX		-	●	●	●	-
		6FZ		-	●	●	●	-
		BFZ		-	●	●	●	-
		L6A		-	●	●	●	-
		LFX		-	●	●	●	-
		LFY. BOSCH LMP5.2		-	●	●	●	-
		LFY. BOSCH LMP7.3		-	●	●	●	-
		LFY. SAGEM SL96		-	●	●	●	-
		R6E		-	●	●	●	-
		R6F		-	●	●	●	-
		RFN		-	●	●	●	-
		RFR		-	●	●	●	-
		RFV		-	●	●	●	-
		RHY		-	●	●	●	-
		RHZ		-	●	●	●	-
		RLZ		-	●	●	●	-
		XFZ		-	●	●	●	-
		XFZ		-	●	●	●	-
		SW VERS : 4 SW INDEX : 24		-	●	●	●	-
		SW VERS : 4 SW INDEX : 27		-	●	●	●	-
		MULTI-FUNCTION DISPLAY		-	●	●	●	-
	DRIVER INFO/COMMUNICATION	RADIO		-	●	●	●	-
		CD PLAYER		-	●	●	●	-
		INSTRUMENT PANEL		-	●	●	●	-
		ON-BOARD NAVIGATION SYSTEM		-	●	●	●	-
		HEATING/VENTILATION		-	●	●	●	-
406 COUPE	DME	PETROL	RFV BOSCH MP5.2	-	●	●	●	-
	TCU(AUTO TRANSMISSION)		4HP20	-	●	●	●	-
			AL4	-	●	●	●	-
	ABS(ANTI LOCK BRAKE)		ABS5 BOSCH	-	●	●	●	-
			ABS BOSCH 5.3	-	●	●	●	-
	SRS(AIR BAG)		AIR BAG AND SEAT BELT	-	●	●	●	-
			SIDE AIR BAG(RIGHT SIDE)	-	●	●	●	-
			SIDE AIR BAG (LEFT SIDE)	-	●	●	●	-
	CLIMATE CONTROL			●	●	●	●	-
	INSTRUMENT PANEL			●	●	●	●	-
407	DME (ENGINE CONTROL)	PETROL	R6E	-	●	●	●	-
			RFV	-	●	●	●	-
			XFZ	-	●	●	●	-
		DIESEL	RFJ MM4MP2	●	●	●	●	-
			RFN MM6LP2	●	●	●	●	-
			RFJ MM6LPB	-	●	●	●	●
			3FY MM6LPB	-	●	●	●	●
			6FY MM6LPB	-	●	●	●	●
			RHR SIEMENS SID 803	●	●	●	●	-
			9HZ BOSCH EDC16C3	-	●	●	●	●
			4HP BOSCH EDC16CP39	-	●	●	●	●
			4HR BOSCH EDC16CP39	-	●	●	●	●
			4HS BOSCH EDC16CP39	-	●	●	●	●
			4HT BOSCH EDC16CP39	-	●	●	●	●
			RHL DCM3.4	-	●	●	●	●
			RHR DCM3.4	-	●	●	●	●
			UHZ SIEMENS SID201	-	●	●	●	●
			9HY BOSCH EDC16C3	-	●	●	●	●
			9HY BOSCH EDC16C3 EURO4	-	●	●	●	-
	TCU(AUTO TRANSMISSION)		AM6	●	●	●	●	-
			BVA AL4 AT8	-	●	●	●	●
			4HP20	-	●	●	●	-
			ESP 8	-	●	●	●	●
			ESP 8.1	●	●	●	●	●
	SRS(AIR BAG)			-	●	●	●	●
	BSI(BUILT-IN SYSTEM INTERFACE)			-	●	●	●	●
	POWE STEERING			●	●	●	●	-
	PARKING ASSISTANCE			-	●	●	●	●
	CLIMATE CONTROL			-	●	●	●	●
	UNDER INFLATION DETECTION			-	●	●	●	●
	MULTIFUNCTION DISPLAY			-	●	●	●	-
	DRIVER SEAT MEMORY UNIT			-	●	●	●	-
	RADIO			-	●	●	●	-
	CD PLAYER			-	●	●	●	-
	INSTRUMENT PANEL			●	●	●	●	●
	HANDS FREE KITS			-	●	●	●	-
	STEERING WHEEL SWITCH MODULE			-	●	●	●	-
	TELEMATICS ECU			-	●	●	●	-
	DIESEL ADDITIVE FUNCTION			-	●	●	●	-
	BATTERY CHAEGER STATUS UNIT			-	●	●	●	-
	ALARM			-	●	●	●	-

	DRIVER DOOR MODULE				-	●	●	●	-	
	PASSENGER DOOR MODULE				-	●	●	●	-	
	SUN ROOF				-	●	●	●	●	
	WINDSCREEN WIPER				-	●	●	●	●	
	RAIN/BRIGHTNESS SENSOR				-	●	-	-	-	
4007	AUTOSCAN				-	-	-	-	-	
	Heating/ventilation				●	●	●	●	-	
	Built-in System interface				●	●	●	●	-	
	RADIO				●	●	●	●	-	
	INSTRUMENT PANEL				●	●	●	●	-	
	HANDS FREE KITS				●	●	●	●	-	
	ENGINE CONTROL				●	●	●	●	-	
	GEAR BOX				●	●	●	●	-	
	4x4 TRANSMISSION				●	●	●	-	-	
	GEAR LEVEL(DTC)				●	●	●	-	-	
	CODED-ANTI START				●	●	●	-	-	
	DRIVER'S DOOR PANEL				●	●	●	-	-	
	PASSENGER DOOR PANEL				●	●	●	-	-	
	REAH LH DOOR SWITCH PANEL				●	●	●	-	-	
	REAH RH DOOR SWITCH PANEL				●	●	●	-	-	
	SUN ROOF				●	●	●	-	-	
	AIR BAG				●	●	●	●	-	
	ABS OR ESP ECU				●	●	●	●	-	
	FLYWHEEL ANGEL SENSOR				●	-	-	-	-	
607	DME (ENGINE CONTROL)	PETROL	3FZ MM4MP2		-	●	●	●	-	
			RFN MM4MP2		-	●	●	●	-	
			RFN MM48P		-	●	●	●	-	
			R6F MM4.8P		-	●	●	●	-	
		XFX BOSCH ME7.4.6		-	●	●	●	-		
		DIESEL	4HX BOSCH EDC15C2		-	●	●	●	-	
	RHS BOSCH EDC15C2			-	●	●	●	-		
	RHZ BOSCH EDC15C2			-	●	●	●	-		
	TCU(AUTO TRANSMISSION)			4HP20		-	●	●	-	-
	ABS(ANTI LOCK BRAKE)			ABS BOSCH 5.3		-	●	●	-	-
				ESP BOSCH 5.3		-	●	●	-	-
	SRS(AIR BAG)					-	●	●	-	-
	BSI (BUILT-IN SYSTEM INTERFACE)		3FZ		-	●	●	●	-	-
			4HX		-	●	●	●	-	-
			R6F		-	●	●	●	-	-
			RHS		-	●	●	●	-	-
			RFN		-	●	●	●	-	-
			AFX		-	●	●	●	-	-
			RHZ EDC 15C2		-	●	●	●	-	-
			SAGEM SW VER : 255		-	●	●	●	-	-
	DIESEL ADDITIVE FUNCTION			MARWEL		-	●	●	-	-
	DRIVER INFO/COMMUNICATION		MULTI-FUNCTION DISPLAY		-	●	●	●	-	-
			PARK AID		-	●	●	●	-	-
			RADIO		-	●	●	●	-	-
			CD PLAYER		-	●	●	●	-	-
			INSTRUMENT PANEL		-	●	●	●	-	-
			RADIO TELEPHONE		-	●	●	●	-	-
			HANDS FREE KIT		-	●	●	●	-	-
			ON-BOARD NAVIGATION SYSTEM		-	●	●	●	-	-
	VISIBILITY/LIGHTING			HEADLAMP HEIGHT CORRECTOR		-	●	●	-	-
	CONTROL THE OPENINGS			DIRVER DOOR MODULE		-	●	●	-	-
				PASSENGER DOOR MODULE		-	●	●	-	-
	HEATING/VENTILATION					-	●	●	-	-
	CLIMATE CONTROL			CLIM_Z8		●	●	●	●	-
STORING OF DRIVING POSITION					-	●	●	-	-	
607 REMODELAGE	AUTOSCAN				-	-	-	-	-	
	ENGINE CONTROL	PETROL	3FY MM6LPB		-	●	●	●	-	
			AM6 GEARBOX		-	●	●	●	●	
			ESP BOSCH 8.1		-	●	●	●	●	
	SRS(AIR BAG)				-	●	●	●	●	
	BSI(BUILT-IN SYSTEM INTERFACE)				-	●	●	●	●	
	PARKING ASSISTANCE				-	●	●	-	●	
	DRIVER SEAT MEMORY UNIT				-	●	●	●	-	
	CLIMATE CONTROL				-	●	●	●	-	
	UNDER INFLATION DETECTION				-	●	●	-	●	
	POWER STEERING				-	●	●	●	-	
	SUSPENSION CSS				-	●	●	●	●	
	MULTIFUNCTION DISPLAY				-	●	●	●	-	
	RADIO				-	●	●	●	-	
	CD PLAYER				-	●	●	●	-	
	INSTRUMENT PANEL				-	●	●	●	●	
	STEERING WHEEL SWITCH MODULE				-	●	●	●	-	
	HANDS FREE KITS				-	●	●	●	-	
	TELEMATICS ECU				-	●	●	-	-	
	DIESEL ADDITIVE FUNCTION				-	●	●	●	-	
	ALARM				-	●	●	●	-	
	DRIVER DOOR MODULE				-	●	●	●	-	
	PASSENGER DOOR MODULE				-	●	●	●	-	
	RAIN/BRIGHTNESS SENSOR				-	●	-	-	-	
806	DME (ENGINE CONTRL)	PETROL	RFN MM4.9P		-	●	●	●	-	
			R6F MM4.8P		-	●	●	●	-	
			RFV BOSCH MP7.3		-	●	●	●	-	
			RGX BOSCH MP3.2		-	●	●	●	-	
		DIESEL	DHX BOSCH VP20		-	●	●	●	-	
			P8C LUCAS EPIC		-	●	●	●	-	
			RHW BOSCH DEC15C2		-	●	●	●	-	
			RHZ BOSCH EDC15C2		-	●	●	●	-	
	TCU(AUTO TRANSMISSION)			AL4		-	●	●	-	-
	ABS(ANTI LOCK BRAKE)			ABS BOSCH 5.3		-	●	●	-	-
SRS(AIR BAG)					-	●	-	-	-	
HEATING/VENTILATION			WEBASTO ADDITIONAL HEATING		-	●	●	-	-	
			RFN MM48P		-	●	●	●	-	
			3FZ MM4MP2		-	●	●	●	-	

807	DME (ENGINE CONTROL)	PETROL	RFN MM4MP2		-	●	●	●	-
			3FZ MM6LP		-	●	●	●	-
			RFN MM6LP		-	●	●	●	-
			XFW BOSCH ME746		-	●	●	●	-
			RFJ MM6LPB		-	●	●	●	-
		DIESEL	RHW BOSCH EDC 15C2		-	●	●	●	-
			RHM BOSCH EDC 15C2		-	●	●	●	-
			RHT BOSCH EDC 15C2		-	●	●	●	-
			4HW BOSCH EDC 15C2		-	●	●	●	-
			RHR SIEMENS SID 803		-	●	●	●	●
			RHL SIEMENS SID 803		-	●	●	●	●
			RHK SIEMENS SID 803		-	●	●	●	●
			4HP BOSCH EDC16CP39		-	●	●	●	●
			4HR BOSCH EDC16CP39		-	●	●	●	●
			4HS BOSCH EDC16CP39		-	●	●	●	●
	4HT BOSCH EDC16CP39		-	●	●	●	●		
	TCU(AUTO TRANSMISSION)		4HP20		-	●	●	-	-
			AL4		-	●	●	-	-
	ABS(ANTI LOCK BRAKE)		ABS BOSCH 5.7		-	●	-	-	-
			ESP BOSCH 5.7		-	●	●	-	-
			ESP BOSCH 8		-	●	●	●	●
	SRS(AIR BAG)				-	-	-	-	-
	BSI (BUILT-IN SYSTEM INTERFACE)		BSI DEFAULT		-	●	●	●	●
			SW VERS : 24 SW INDEX : 10		●	●	●	●	●
			SW VERS : 27 SW INDEX : 14		●	●	●	●	●
			SW VERS : 30 SW INDEX : 10		●	●	●	●	●
	DIESEL ADDITIVE FUNCTION		MARWEL		●	●	●	●	●
			CAN SYSTEM		-	●	●	●	-
	ALARM				-	●	●	●	-
	DRIVER INFO/COMMUNICATION		DISPLAY/TELEMATICS		-	●	●	-	-
			RADIO/TELEMATYIC RECEIVE CTRL		-	●	●	-	-
			PARK AID		-	●	●	-	-
			WARNING LIGHTS & ODOMETER ECU		-	●	●	●	-
			INSTRUMENT PANEL		-	●	●	●	●
			CD PLAYER		-	●	-	-	-
	VISIBILITY/LIGHTING		RIGHT HEADLAMP BEAM CORRECTOR		-	●	●	-	-
			LEFT HEADLAMP BEAM CORRECTOR		-	●	●	-	-
	CONTROL THE OPENINGS		DIRVER DOOR MODULE		-	●	●	●	-
			PASSENGER DOOR MODULE		-	●	●	●	-
			SLIDING SIDE DOOR		-	●	●	-	-
			FRONT SUNROOF		-	●	●	●	-
			REAR SUNROOF		-	●	●	●	-
			MIDDLE SUNROOF		-	●	●	●	-
HEATING/VENTILATION		WEBASTO ADDITIONAL HEATING		-	●	●	-	-	
		CLIMATE CONTRL		-	●	●	●	-	
STORING OF DRIVING POSITION				-	●	●	-	-	
PARKING ASSISTANCE				-	●	●	●	●	
DRIVER SEAT MEMORY UNIT				-	●	●	●	-	
UNDER INFLATION DETECTION				-	●	●	-	●	
POWER STEERING				-	●	●	●	-	
MULTIFUNCTION DISPLAY				-	●	●	●	-	
STEERING WHEEL SWITCH MODULE				-	●	●	●	-	
HANDS FREE KITS				-	●	●	●	-	
RAIN/BRIGHTNESS SENSOR				-	●	-	-	-	
PARTNER	DME (ENGINE CONTRL)	PETROL	HDY BOSCH MA3.1		-	●	●	●	-
			HDZ BOSCH MA3.1		-	●	●	●	-
			HFX BOSCH M7.4.4		-	●	●	●	-
			KFW SAGEM S2000		-	●	●	●	-
			K6D SAGEM S2000		-	●	●	●	-
			KFX BOSCH MP7.3		-	●	●	●	-
			KFX MM1AP		-	●	●	●	-
			LFX MM1AP		-	●	●	●	-
		DIESEL	N6A BOSCH ME7.4.4		-	●	●	●	-
			NFU BOSCH ME7.4.4		-	●	●	●	-
			RHY SIEMENS SID801		-	●	●	●	-
			RHY BOSCH EDC15C2		-	●	●	●	-
			WJY LUCAS DCN2		-	●	●	●	-
			WJZ LUCAS DCN2		-	●	●	●	-
	ABS(ANTI LOCK BRAKE)		ABS5 BOSCH		-	●	-	-	-
		ABS5.3 BOSCH		-	●	●	-	-	
BSI(BUILT-IN SYSTEM INTERFACE)		SIEMENS		-	●	-	-	-	
INSTRUMENT		MAGNETI MARELLI		●	●	●	●	●	
SRS(AIR BAG)				●	●	●	●	-	
EXPERT	AUTOSCAN				-	-	-	-	-
	DME(ENGINE CONTROL)	PETROL	R6F MM4.8P		-	●	●	●	-
			RFN MM4.8P		-	●	●	●	-
		DIESEL	DXH BOSCH VP20		-	●	●	●	-
			RHW BOSCH EDC15C2		-	●	●	●	-
			RHX BOSCH EDC15C2		-	●	●	●	-
			RHZ BOSCH EDC15C2		-	●	●	●	-
			WJY LUCAS DCN2		-	●	●	●	-
			RHK SIEMENS SID 803		-	●	●	●	●
	TCU(AUTO TRANSMISSION)		AL4		-	●	●	-	-
	ABS(ANTI LOCK BRAKE)		ABS BOSCH 5.3		-	●	●	-	-
			ABS BOSCH 8		-	●	●	●	●
			ESP BOSCH 8		-	●	●	●	●
			ABS BOSCH 8.1		-	●	●	●	●
			ESP BOSCH 8.1		-	●	●	●	●
	SRS(AIR BAG)				-	●	●	-	●
	CLIMATE CONTROL				-	●	●	●	●
	POWER STEERING				-	●	●	●	-
	BSI(BUILT-IN SYSTEM INTERFACE)				-	●	●	●	●
	MULTIFUNCTION DISPLAY				-	●	●	●	-
	RADIO				-	●	●	●	-
	INSTRUMENT PANEL				-	●	●	●	-
STEERING WHEEL SWITCH MODULE				-	●	●	●	-	
RAIN/BRIGHTNESS SENSOR				-	●	-	-	-	

BOXER	DME (ENGINE CONTRL)	PETROL	MM4.8P 2L UNLEADED PETORL		-	●	●	●	-
			MM48P 2L ESSENCE PLOMBEE		-	●	●	●	-
			8140.43S BOSCH EDC 15C7		-	●	●	●	-
			MM48P 2L DUAL FUEL(LPG)		-	●	●	●	-
		DIESEL	2.0L HDI BOSCH EDC15C7		-	●	●	●	-
			2.2L HDI BOSCH EDC15C7		-	●	●	●	-
			2.8L HDI BOSCH EDC15C7		-	●	●	●	-
			4HP20		-	●	●	●	-
		TCU(AUTO TRANSMISSION)			-	●	●	●	-
		ABS(ANTI LOCK BRAKE)		ABS BOSCH 5.3	-	●	●	●	-
206 +	SRS(AIR BAG)				-	●	●	●	-
	DME (ENGINE CONTRL)	PETROL			-	●	●	●	●
		DIESEL			-	●	●	●	●
	TCU(AUTO TRANSMISSION)				-	●	●	●	-
	ABS(ANTI LOCK BRAKE)				-	●	●	●	-
	SRS(AIR BAG)				-	●	●	●	-
	MULTIFUNCTION DISPLAY				-	●	●	●	-
EXPERT 2	RADIO				-	●	●	●	-
	DME (ENGINE CONTRL)	PETROL			-	●	●	●	●
		DIESEL			-	●	●	●	●
	ABS(ANTI LOCK BRAKE)				-	●	●	●	●
	SRS(AIR BAG)				-	●	●	●	●
	ALARM				-	●	●	●	●
	PARKING AID				-	●	●	●	●
	HEATING & VENTILATION				-	●	●	●	●
	POWER STEERING			This document is not su	-	●	●	●	●
	PNEUMATIC SUSPENSION				-	●	●	●	●
	RADIO				-	●	●	●	●
	CD PLAYER				-	●	●	●	●
	INSTRUMENT PANEL				-	●	●	●	●
	SWITCH MODULE AT THE STEERING WHEEL				-	●	●	●	●
	TELEMATICS ECU				-	●	●	●	●
	RAIN SENSOR / BRIGHTNESS				-	●	●	●	●
	MULTIFUNCTION DISPLAY				-	●	●	●	●
PARTNER 2	DME (ENGINE CONTRL)	PETROL			-	●	●	●	●
		DIESEL			-	●	●	●	●
	ABS(ANTI LOCK BRAKE)				-	●	●	●	●
	SRS(AIR BAG)				-	●	●	●	●
	PARKING AID				-	●	●	●	●
	POWER STEERING				-	●	●	●	●
	UNDER INFLATION DETECTION				-	●	●	●	●
	MULTIFUNCTION DISPLAY				-	●	●	●	●
	RADIO				-	●	●	●	●
	INSTRUMENT PANEL				-	●	●	●	●
	CD PLAYER				-	●	●	●	●
	HANDS FREE KITS				-	●	●	●	●
	SWITCH MODULE AT THE STEERING WHEEL				-	●	●	●	●
	TELEMATICS ECU				-	●	●	●	●
	BATTERY CHAEGER STATUS UNIT				-	●	●	●	●
	RADIO NAVIGATION				-	●	●	●	●
	ALARM				-	●	●	●	●
	RAIN SENSOR / BRIGHTNESS				-	●	●	●	●
	HEATING & VENTILATION				-	●	●	●	●
	INDEPENDENT TELEMATIC UNIT				-	●	●	●	●