

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		A	Powertrain	[P] 2.0L L4 LSJ	Powertrain Control Module			√	√	√		
				[F] 2.2L L4 L61	Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
				[B] 2.4L L4 LE5	Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
			Chassis	Electronic Brake Control Module				√	√	√		
		K	Body	Supplemental Inflatable Restraint				√	√	√		
		L	Body	Supplemental Inflatable Restraint				√	√	√	√	
		N	Powertrain	[R] 2.0L L4 L34	Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
				[U] 2.0L L4 LMN	5 Speed Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
		S	Aveo	Body	[5] Four-Door Sedan	Supplemental Inflatable Restraint		√	√	√	√	
					[6] Four-Door Hatchback/Liftback	Supplemental Inflatable Restraint		√	√	√	√	
		T	Aveo	Body	[5] Four-Door Sedan	Supplemental Inflatable Restraint		√	√	√	√	
					[6] Four-Door Hatchback/Liftback	Supplemental Inflatable Restraint		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		U	Body	Supplemental Inflatable Restraint				√	√	√		
		V	Body	Supplemental Inflatable Restraint				√	√	√	√	
			WU Impala LTZ	Powertrain	[R] 3.9L V6 LZ8	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[C] 5.3L V8 LS4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
					C67,Single Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Electronic Brake Control Module			√	√	√		
			WJ Monte Carlo LS	Powertrain	[N] 3.5L V6 LZ4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[K] 3.5L V6 LZE	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[C] 5.3L V8 LS4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
					C67,Single Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Electronic Brake Control Module			√	√	√		
					[N] 3.5L V6 LZ4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
	[1] Chevrolet	W	WT Impala LT 3.5 Sedan	Powertrain	[K] 3.5L V6 LZE	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[C] 5.3L V8 LS4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
					C67,Single Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Electronic Brake Control Module			√	√	√		
			WS Impala Police Sedan	Powertrain	[R] 3.9L V6 LZ8	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[C] 5.3L V8 LS4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
					C67,Single Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Electronic Brake Control Module			√	√	√		
			WB Impala LS	Powertrain	[N] 3.5L V6 LZ4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[K] 3.5L V6 LZE	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[C] 5.3L V8 LS4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
				Body	CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
					C67,Single Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Electronic Brake Control Module			√	√	√		
			WC Impala LT	Powertrain	[R] 3.9L V6 LZ8	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[C] 5.3L V8 LS4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
					C67,Single Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Electronic Brake Control Module			√	√	√		
			WD Impala SS	Powertrain	[C] 5.3L V8 LS4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
					C67,Single Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Electronic Brake Control Module			√	√	√		
			WK Monte Carlo LT	Powertrain	[N] 3.5L V6 LZ4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[K] 3.5L V6 LZE	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[C] 5.3L V8 LS4	Engine Control Module		√	√	√	√	√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		Y			[C] 5.3L V8 LS4	Transmission Control Module		√	√	√		√
					Body	CJ3 Dual Zone HVAC,Manual	Body Control Module	√	√	√		
						C67,Single Zone HVAC,Manual	Body Control Module	√	√	√		
				Chassis	Electronic Brake Control Module			√	√	√		
			WL Monte Carlo SS	Powertrain	[C] 5.3L V8 LS4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
						Body Control Module		√	√	√		
				Chassis	Electronic Brake Control Module			√	√	√		
			Powertrain	6 Speed Automatic	Engine Control Module			√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Manual	Engine Control Module			√	√	√	√	√
			Chassis	Electronic Brake Control Module				√	√	√		
		Z	Powertrain	[F] 2.2L L4 L61	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
					[N] 3.5L V6 LZ4	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				[1] 3.9L V6 LZ9	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
			Chassis	Electronic Brake Control Module				√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
Passenger Car		A	Powertrain	[F] 2.2L L4 L61	Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				[B] 2.4L L4 LE5	Manual	Engine Control Module		√	√	√	√	√
					Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
			Chassis	Electronic Brake Control Module				√	√	√		
		M	Powertrain	[X] 2.0L L4 LNF	Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				[B] 2.4L L4 LE5	Manual	Engine Control Module		√	√	√	√	√
					Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
			Chassis	[X] 2.0L L4 LNF	Electronic Brake Control Module			√	√	√		
				[B] 2.4L L4 LE5	Electronic Brake Control Module			√	√	√		
			Powertrain	[2] 3.8L V6 L26	Without Air Pump	Powertrain Control Module		√	√	√		
					With Air Pump	Powertrain Control Module		√	√	√		
				[4] 3.8L V6 L32	Powertrain Control Module			√	√	√		
				[C] 5.3L V8 LS4	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
	[2] Pontiac	W	Body	Automatic	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
					Supplemental Inflatable Restraint			√	√	√	√	
				Manual	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
					Supplemental Inflatable Restraint			√	√	√	√	
		S	Body	Supplemental Inflatable Restraint				√	√	√		
		T	G3	Body	[5] Four-Door Sedan	Supplemental Inflatable Restraint		√	√	√	√	
					[6] Four-Door Hatchback/Liftback	Supplemental Inflatable Restraint		√	√	√	√	
			Wave	Body	[5] Four-Door Sedan	Supplemental Inflatable Restraint		√	√	√	√	
					[6] Four-Door Hatchback/Liftback	Supplemental Inflatable Restraint		√	√	√	√	
		Z	Powertrain	[B] 2.4L L4 LE5	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
				[N] 3.5L V6 LZ4	With Tap Shift	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Without Tap Shift	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				[7] 3.6L V6 LY7	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
						Engine Control Module		√	√	√	√	√
					Automatic							

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
				[1] 3.9L V6 LZ9	Automatic	Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
			Chassis	Electronic Brake Control Module				√	√	√		
	[4] Buick	H	Powertrain	[2] 3.8L V6 L26	Without Air Pump	Engine Control Module		√	√	√	√	√
					With Air Pump	Engine Control Module		√	√	√	√	√
				[Y] 4.6L V8 LD8	Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
			Body	Automatic				√	√	√		
					Manual			√	√	√		
			Chassis					√	√	√		
		W	Powertrain	[7] 3.6L V6 LY7	Engine Control Module			√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[2] 3.8ILV6 L26	Powertrain Control Module		√	√	√		
			Allure	Automatic	Body Control Module			√	√	√		
						Instrument Panel Cluster		√	√	√		
						Supplemental Inflatable Restraint		√	√	√	√	
				Manual	Body Control Module			√	√	√		
						Instrument Panel Cluster		√	√	√		
						Supplemental Inflatable Restraint		√	√	√	√	
						Engine Control Module		√	√	√	√	√

[7] 3.6L V6 LY7

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
			Lacrosse	Powertrain	[1] 3.0L V6 L17	Transmission Control Module		√	√	√		√
					[2] 3.8ILV6 L26	Powertrain Control Module		√	√	√		
				Body	Automatic	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√		
						Supplemental Inflatable Restraint		√	√	√	√	
					Manual	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√		
						Supplemental Inflatable Restraint		√	√	√	√	
				Powertrain	[T] 2.8L V6 LP1	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[7] 3.6L V6 LY7	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	Instrument Panel Cluster			√	√	√		
						Supplemental Inflatable Restraint		√	√	√	√	
			[DM] CTS	Powertrain	[T] 2.8L V6 LP1	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
						Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	Instrument Panel Cluster			√	√	√		
						Supplemental Inflatable Restraint		√	√	√	√	
				Powertrain	[T] 2.8L V6 LP1	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[7] 3.6L V6 LY7	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	Instrument Panel Cluster			√	√	√		
						Supplemental Inflatable Restraint		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
	[6] Cadillac	D	[DR] CTS	Powertrain	[T] 2.8L V6 LP1	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[7] 3.6L V6 LY7	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	Instrument Panel Cluster			√	√	√		
					Supplemental Inflatable Restraint			√	√	√	√	
			[DN] CTS-V	Powertrain	[U] 6.0L V8 LS2	Engine Control Module		√	√	√	√	√
				Body	Instrument Panel Cluster			√	√	√		
					Supplemental Inflatable Restraint			√	√	√	√	
			[DC] STS-V8	Powertrain	Engine Control Module			√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Chassis	Electronic Brake Control Module			√	√	√		
			[DW] STS	Powertrain	[7] 3.6L V6 LY7	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Chassis	Electronic Brake Control Module			√	√	√		
			[DX] STS-V	Powertrain	Engine Control Module			√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Chassis	Electronic Brake Control Module			√	√	√		
			Powertrain	Engine Control Module				√	√	√	√	√
				Transmission Control Module				√	√	√		√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		K	Body	CJ2 Dual Zone HVAC,Auto				√	√	√		
				CJ4 Tri Zone HVAC,Auto				√	√	√		
			Chassis					√	√	√		
		Y	[YV] XLR	Powertrain	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
				Body	Instrument Panel Cluster			√	√	√		
					Supplemental Inflatable Restraint			√	√	√	√	
			Chassis	Electronic Brake Control Module				√	√	√		
			[YX] XLR-V	Powertrain	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
				Body	Instrument Panel Cluster			√	√	√		
					Supplemental Inflatable Restraint			√	√	√	√	
			Chassis	Electronic Brake Control Module				√	√	√		
	A		Powertrain	[P] 2.0L L4 LSJ	Powertrain Control Module			√	√	√		
				[F] 2.2L L4 L61	Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
				[B] 2.4L L4 LE5	Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
	[8] Saturn	M	Body	Body Control Module				√	√	√		
				Instrument Panel Cluster				√	√	√	√	
				Supplemental Inflatable Restraint				√	√	√	√	
			Powertrain	[X] 2.0L L4 LNF	Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
				[B] 2.4L L4 LE5	Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
			Chassis	[X] 2.0L L4 LFN	Electronic Brake Control Module			√	√	√		
				[B] 2.4L L4 LE5	Electronic Brake Control Module			√	√	√		
		Z	Powertrain	[N] 3.5L V6 LZ4	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
				[7] 3.6L V6 LY7	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
			Chassis	Electronic Brake Control Module				√	√	√		
		A	Powertrain	[D] 2.2L L4 L61	Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
					Automatic	Engine Control Module		√	√	√	√	
						Transmission Control Module		√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
				[P] 2.4L L4 LE5	Automatic	Transmission Control Module		√	√	√		
					Manual	Engine Control Module		√	√	√	√	
			Chassis	Electronic Brake Control Module				√	√	√		
		Avalanche	Powertrain		[3] 5.3L V8 LC9	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[0] 5.3L V8 LMG	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[J] 5.3L V8 LY5	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[Y] 6.0L V8 L76	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
			Body		CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√		
					CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
			Chassis		Under 8600 GVW	Electronic Brake Control Module		√	√	√		
					Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		
			Powertrain		[R] 2.0L L4 LLW	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[U] 2.0L L4 LMN	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[F] 2.4L L4 LD9	Engine Control Module		√	√	√	√	√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
			Captiva		[P] 2.4L V6 EDO	Transmission Control Module		√	√	√		√
					[G] 3.2L V6 LU1	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	Automatic	Body Control Module		√	√	√		
					Manual	Body Control Module		√	√	√		
				Chassis	With Traction Control	Electronic Brake Control Module		√	√	√		
					Without Traction Control	Electronic Brake Control Module		√	√	√		
			Silverado	Powertrain	[X] 4.3L V6 LU3	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[C] 4.8L V8 LY2	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[M] 5.3L V8 LH6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[0] 5.3L V8 LMG	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[J] 5.3L V8 LY5	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[Y] 6.0L V8 L76	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[K] 6.0L V8 L76	Engine Control Module		√	√	√	√	√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		C			[M] 6.0L V8 L70	Transmission Control Module		√	√	√		√
				Body	CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√		
					C67 Single Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Under 8600 GVW	Electronic Brake Control Module		√	√	√		
					Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		
			Powertrain		[X] 4.3L V6 LU3	Powertrain Control Module		√	√	√		
					[V] 4.8L V8 LR4	Powertrain Control Module		√	√	√		
					[B] 5.3L V8 L33	Powertrain Control Module		√	√	√		
					[Z] 5.3L V8 L59	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7 Parallel Hybrid	Powertrain Control Module		√	√	√		
					[R] 5.7L V8 L31	Powertrain Control Module		√	√	√		
					[U] 6.0L V8 LQ4	Powertrain Control Module		√	√	√		
					[U] 6.0L V8 LQ4 Dedicated GNG	Powertrain Control Module		√	√	√		
					[N] 6.0L V8 LQ9	Powertrain Control Module		√	√	√		
					[D] 6.6L V8 LBZ Diesel	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[G] 8.1L V8 L18	Powertrain Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Base Radio/C12	Body Control Module		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
			Silverado Classic	Body	Base Radio(CJ2 Dual Zone HVAC,Auto)	Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Base Radio(CJ3 Dual Zone HVAC,Manual)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Base Radio(CJ2 Dual Zone HVAC,Auto,PHT)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio(CJ2 Dual Zone HVAC,Auto)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio(CJ3 Dual Zone HVAC,Manual)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio(CJ2 Dual Zone HVAC,Auto,PHT)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio(CJ2 Dual Zone HVAC,Auto)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
					Navigation Radio(CJ3 Dual Zone HVAC,Manual)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio(CJ2 Dual Zone HVAC,Auto,PHT)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
			Suburban	Powertrain	[3] 5.3L V8 LC9	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[0] 5.3L V8 LMG	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[J] 5.3L V8 LY5	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[Y] 6.0L V8 L76	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[K] 6.0L V8 LY6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√		
					CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Under 8600 GVW	Electronic Brake Control Module		√	√	√		
					Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
			Tahoe	Powertrain	[C] 4.8L V8 LY2	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[0] 5.3L V8 LMG	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[J] 5.3L V8 LY5	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√		
					CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Under 8600 GVW	Electronic Brake Control Module		√	√	√		
					Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		
		Express/Savana		Powertrain	[X] 4.3L V6 LU3	Powertrain Control Module		√	√	√		
					[V] 4.8L V8 LR4	Powertrain Control Module		√	√	√		
					[Z] 5.3L V8 L59	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7	Powertrain Control Module		√	√	√		
					[U] 6.0L V8 LQ4	Powertrain Control Module		√	√	√		
					[2] 6.6L V8 LLY Diesel	Engine Control Module		√	√	√	√	
						Transmission Control Module		√	√	√		
				Body	Base Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		G		Body	Uplevel Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
			Express Access/Savana Pro	Powertrain	[X] 4.3L V6 LU3	Powertrain Control Module		√	√	√		
					[V] 4.8L V8 LR4	Powertrain Control Module		√	√	√		
					[Z] 5.3L V8 L59	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7	Powertrain Control Module		√	√	√		
					[U] 6.0L V8 LQ4	Powertrain Control Module		√	√	√		
					[2] 6.6L V8 LLY Diesel	Engine Control Module		√	√	√	√	√
					Transmission Control Module		√	√	√		√	
				Body	Base Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio	Body Control Module		√	√	√	√	
		Instrument Panel Cluster				√	√	√	√			
		Supplemental Inflatable Restraint		√		√	√	√				
			Express/Savana	Powertrain	[Z] 5.3L V8 L59	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7	Powertrain Control Module		√	√	√		
					Base Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
	Chevrolet Truck	H	Express/Savana	Body		Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
			Express Access/Savana Pro	Powertrain	[Z] 5.3L V8 L59	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7	Powertrain Control Module		√	√	√		
				Body	Base Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
			Avalanche	Powertrain	[3] 5.3L V8 LC9	Powertrain Control Module		√	√	√		
					[0] 5.3L V8 LMG	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[J] 5.3L V8 LMG	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[Y] 6.0L V8 L76	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
				Body	CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Under 8600 GVW	Electronic Brake Control Module		√	√	√		
					Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		
			Silverado	Powertrain	[X] 4.3L V6 LU3	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[C] 4.8L V8 LY2	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[M] 5.3L V8 LY2	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[O] 5.3L V8 LMG	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[J] 5.3L V8 LY5	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[Y] 6.0L V8 L76	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[K] 6.0L V8 L76	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√		
					C67 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Under 8600 GVW	Electronic Brake Control Module		√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
				Chassis	Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		
				Powertrain	[X] 4.3L V6 LU3	Powertrain Control Module		√	√	√		
					[V] 4.8L V8 LR4	Powertrain Control Module		√	√	√		
					[B] 5.3L V8 L33	Powertrain Control Module		√	√	√		
					[Z] 5.3L V8 L59	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7 Parallel Hybrid	Powertrain Control Module		√	√	√		
					[U] 6.0L V8 LQ4	Powertrain Control Module		√	√	√		
					[U] 6.0L V8 LQ4 Dedicated CNG	Powertrain Control Module		√	√	√		
					[N] 6.0L V8 LQ9	Powertrain Control Module		√	√	√		
					[D] 6.6L V8 LBZ Diesel	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[G] 8.1L V8 L18	Powertrain Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Base Radio(CJ2 Dual Zone HVAC,Auto)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Base Radio(CJ3 Dual Zone HVAC,Manual)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
			Silverado Classic	Body	Base Radio(CJ2 Dual Zone HVAC,Auto,PHT)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio(CJ2 Dual Zone HVAC,Auto)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio(CJ3 Dual Zone HVAC,Manual)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio(CJ2 Dual Zone HVAC,Auto,PHT)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio(CJ2 Dual Zone HVAC,Auto)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio(CJ3 Dual Zone HVAC,Manual)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio(CJ2 Dual Zone	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
					HVAC,Auto,PHT)	Supplemental Inflatable Restraint		√	√	√	√	
					[3] 5.3L V8 LC9	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
						Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
						Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
						Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
						Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
						Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[Y] 6.0L V8 LY6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
						Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[K] 6.0L V8 LY6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√		
						Body Control Module		√	√	√		
					CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
						Body Control Module		√	√	√		
					Under 8600 GVW	Electronic Brake Control Module		√	√	√		
						Electronic Brake Control Module		√	√	√		
					Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		
						Electronic Brake Control Module		√	√	√		
					[C] 4.8L V8 LY2	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
						Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
						Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
						Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√

Table

[1] 5.3L V8 LY5

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		L	Table		[9] 3.0L V6 LTV	Transmission Control Module		√	√	√		√
					Body	CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√	
						CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√	
				Chassis	Under 8600 GVW	Electronic Brake Control Module		√	√	√		
					Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		
			Powertrain	[F] 3.4L V6 LNJ	Without All Wheel Drive	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					With All Wheel Drive	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	Body Control Module			√	√	√		
			Chassis	With Traction Control	Electronic Brake Control Module			√	√	√		
				Without Traction Control	Electronic Brake Control Module			√	√	√		
		P	Powertrain	[R] 5.7L V8 L31	Powertrain Control Module			√	√	√		
		Colorado	Powertrain		[9] 2.9L L4 LLV	Powertrain Control Module		√	√	√		
					[E] 3.7L L5 LLR	Powertrain Control Module		√	√	√		
			Body		Base Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		S	TrailBlazer			Supplemental Inflatable Restraint		√	√	√	√	
						[S] 4.2L L6 LL8 Powertrain Control Module		√	√	√		
						[S] 4.2L L6 LL8 Japan Powertrain Control Module		√	√	√		
						[M] 5.3L V8 LH6 Engine Control Module		√	√	√	√	
						[M] 5.3L V8 LH6 Transmission Control Module		√	√	√		
						[H] 6.0L V8 LS2 Engine Control Module		√	√	√	√	√
						[H] 6.0L V8 LS2 Transmission Control Module		√	√	√		√
					Body	CJ2 Dual Zone HVAC,Auto (Uplevel Radio) Body Control Module		√	√	√		
						CJ2 Dual Zone HVAC,Auto (Uplevel Radio) Instrument Panel Cluster		√	√	√	√	
						CJ2 Dual Zone HVAC,Auto (Uplevel Radio) Supplemental Inflatable Restraint		√	√	√	√	
						CJ2 Dual Zone HVAC,Auto (Navigation Radio) Body Control Module		√	√	√		
						CJ2 Dual Zone HVAC,Auto (Navigation Radio) Instrument Panel Cluster		√	√	√	√	
						CJ2 Dual Zone HVAC,Auto (Navigation Radio) Supplemental Inflatable Restraint		√	√	√	√	
						CJ3 Dual Zone HVAC,Manual (Uplevel Radio) Body Control Module		√	√	√		
						CJ3 Dual Zone HVAC,Manual (Uplevel Radio) Instrument Panel Cluster		√	√	√	√	
						CJ3 Dual Zone HVAC,Manual (Uplevel Radio) Supplemental Inflatable Restraint		√	√	√	√	
						CJ3 Dual Zone HVAC,Manual (Navigation Radio) Body Control Module		√	√	√		
						CJ3 Dual Zone HVAC,Manual (Navigation Radio) Instrument Panel Cluster		√	√	√	√	
						CJ3 Dual Zone HVAC,Manual (Navigation Radio) Supplemental Inflatable Restraint		√	√	√	√	
				Powertrain		[9] 2.9L L4 LLV Powertrain Control Module		√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		T	Colorado	Powertrain	[E] 3.7L L5 LLR	Powertrain Control Module		√	√	√		
				Body	Base Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
			TrailBlazer	Powertrain	[S] 4.2L L6 LL8	Powertrain Control Module		√	√	√		
					[S] 4.2L L6 LL8 Japan	Powertrain Control Module		√	√	√		
					[M] 5.3L V8 LH6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[H] 6.0L V8 LS2	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ2 Dual Zone HVAC,Auto (Uplevel Radio)	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					CJ2 Dual Zone HVAC,Auto (Navigation Radio)	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					CJ2 Dual Zone	Body Control Module		√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
					CJ3 Dual Zone HVAC,Manual (Uplevel Radio)	Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
						Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					[X] 4.3L V6 LU3	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[C] 4.8L V8 LY2	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[M] 5.3L V8 LH6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[O] 5.3L V8 LMG	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[J] 5.3L V8 LY5	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[Y] 6.0L V8 LY6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[K] 6.0L V8 LY6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[R] 6.2L V8 LY6	Engine Control Module		√	√	√	√	√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
					[J] 6.2L V8 L02	Transmission Control Module		√	√	√		√
				Body	CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√		
					C67 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Under 8600 GVW	Electronic Brake Control Module		√	√	√		
					Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		
			Powertrain		[X] 4.3L V6 LU3	Powertrain Control Module		√	√	√		
					[V] 4.8L V8 LR4	Powertrain Control Module		√	√	√		
					[B] 5.3L V8 L33	Powertrain Control Module		√	√	√		
					[Z] 5.3L V8 L59	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7 Parallel Hybrid	Powertrain Control Module		√	√	√		
					[R] 5.7L V8 L31	Powertrain Control Module		√	√	√		
					[U] 6.0L V8 LQ4	Powertrain Control Module		√	√	√		
					[U] 6.0L V8 LQ4 Dedicated CNG	Powertrain Control Module		√	√	√		
					[N] 6.0L V8 LQ9	Powertrain Control Module		√	√	√		
					[D] 6.6L V8 LBZ Diesel	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[G] 8.1L V8 L18	Powertrain Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Base Body/C12	Body Control Module		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		C	Sierra Classic	Body	Base Radio(CJ2 Dual Zone HVAC,Auto)	Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Base Radio(CJ3 Dual Zone HVAC,Manual)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Base Radio(CJ2 Dual Zone HVAC,Auto,PHT)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio(CJ2 Dual Zone HVAC,Auto)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio(CJ3 Dual Zone HVAC,Manual)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio(CJ2 Dual Zone HVAC,Auto,PHT)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio(CJ2 Dual Zone HVAC,Auto)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action			
					Navigation Radio(CJ3 Dual Zone HVAC,Manual)	Body Control Module		√	√	√	√				
						Instrument Panel Cluster		√	√	√	√				
						Supplemental Inflatable Restraint		√	√	√	√				
						Navigation Radio(CJ2 Dual Zone HVAC,Auto,PHT)	Body Control Module		√	√	√	√			
							Instrument Panel Cluster		√	√	√	√			
							Supplemental Inflatable Restraint		√	√	√	√			
					Yukon	Powertrain	[C] 4.8L V8 LY2	Engine Control Module		√	√	√	√	√	
								Transmission Control Module		√	√	√		√	
							[0] 5.3L V8 LMG	Engine Control Module		√	√	√	√	√	
								Transmission Control Module		√	√	√		√	
							[J] 5.3L V8 LY5	Engine Control Module		√	√	√	√	√	
								Transmission Control Module		√	√	√		√	
			[8] 6.2L V8 L92	Engine Control Module				√	√	√	√	√			
				Transmission Control Module				√	√	√		√			
			Body	CJ2 Dual Zone HVAC,Auto			Body Control Module		√	√	√				
				CJ3 Dual Zone HVAC,Manual			Body Control Module		√	√	√				
			Chassis	Under 8600 GVW	Electronic Brake Control Module			√	√	√					
				Equal to or Over 8600 GVW	Electronic Brake Control Module			√	√	√					
								[3] 5.3L V8 LC9	Engine Control Module		√	√	√	√	√
									Transmission Control Module		√	√	√		√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
			Yukon XL	Powertrain	[0] 5.3L V8 LMG	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[J] 5.3L V8 LY5	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[Y] 6.0L V8 L76	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[K] 6.0L V8 LY6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[8] 6.2L V8 L92	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√		
					CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Under 8600 GVW	Electronic Brake Control Module		√	√	√		
					Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		
				Powertrain	[X] 4.3L V6 LU3	Powertrain Control Module		√	√	√		
					[V] 4.8L V8 LR4	Powertrain Control Module		√	√	√		
					[Z] 5.3L V8 L59	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7	Powertrain Control Module		√	√	√		
					[U] 6.0L V8 LQ4	Powertrain Control Module		√	√	√		
					[2] 6.6L V8 LLY	Engine Control Module		√	√	√	√	√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
LD Trk, MPV, Incomplete		G	Express/Savana		Diesel	Transmission Control Module		√	√	√		√
				Body	Base Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
			Express Access/Savana Pro	Powertrain	[X] 4.3L V6 LU3	Powertrain Control Module		√	√	√		
					[V] 4.8L V8 LR4	Powertrain Control Module		√	√	√		
					[Z] 5.3L V8 L59	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7	Powertrain Control Module		√	√	√		
					[U] 6.0L V8 LQ4	Powertrain Control Module		√	√	√		
					[2] 6.6L V8 LLY Diesel	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	Base Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		H	Express/Savana	Powertrain	[Z] 5.3L V8 L59	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7	Powertrain Control Module		√	√	√		
				Body	Base Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
			Express Access/Savana Pro	Powertrain	[Z] 5.3L V8 L59	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7	Powertrain Control Module		√	√	√		
				Body	Base Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					[X] 4.3L V6 LU3	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[C] 4.8L V8 LY2	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√

GMC Truck

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
			Sierra	Powertrain	[M] 5.3L V8 LH6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[0] 5.3L V8 LMG	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[J] 5.3L V8 LY5	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[Y] 6.0L V8 LY6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[K] 6.0L V8 LY6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[8] 6.2L V8 L92	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√		
					C67J3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Under 8600 GVW	Electronic Brake Control Module		√	√	√		
					Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		
					[X] 4.3L V6 LU3	Powertrain Control Module		√	√	√		
					[V] 4.8L V8 LR4	Powertrain Control Module		√	√	√		
					[B] 5.3L V8 L33	Powertrain Control Module		√	√	√		
					[Z] 5.3L V8 L59	Powertrain Control Module		√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
				Powertrain	[T] 5.3L V8 LM7	Powertrain Control Module		√	√	√		
					[T] 5.3L V8 LM7 Parallel Hybrid	Powertrain Control Module		√	√	√		
					[R] 5.7L V8 L31	Powertrain Control Module		√	√	√		
					[U] 6.0L V8 LQ4	Powertrain Control Module		√	√	√		
					[U] 6.0L V8 LQ4 Dedicated CNG	Powertrain Control Module		√	√	√		
					[N] 6.0L V8 LQ9	Powertrain Control Module		√	√	√		
					[D] 6.6L V8 LBZ Diesel	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[G] 8.1L V8 L18	Powertrain Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
				Sierra Classic	Base Radio(CJ2 Dual Zone HVAC,Auto)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Base Radio(CJ3 Dual Zone HVAC,Manual)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Base Radio(CJ2 Dual Zone HVAC,Auto,PHT)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Unlevel Radio(CJ2	Body Control Module		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		K		Body	Uplevel Radio(CJ2 Dual Zone HVAC,Auto)	Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio(CJ3 Dual Zone HVAC,Manual)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio(CJ2 Dual Zone HVAC,Auto,PHT)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio(CJ2 Dual Zone HVAC,Auto)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio(CJ3 Dual Zone HVAC,Manual)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio(CJ2 Dual Zone HVAC,Auto,PHT)	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					[C] 4.8L V8 LY2	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[01 5.3L V8 1 MG	Engine Control Module		√	√	√	√	√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
			Yukon	Powertrain	[0] 6.0L V8 LMG	Transmission Control Module		√	√	√		√
					[J] 5.3L V8 LY5	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[8] 6.2L V8 L92	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Body	CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√		
					CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√		
				Chassis	Under 8600 GVW	Electronic Brake Control Module		√	√	√		
					Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		
			Yukon XL	Powertrain	[3] 5.3L V8 LC9	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[0] 5.3L V8 LMG	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[J] 5.3L V8 LY5	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[Y] 6.0L V8 L76	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[K] 6.0L V8 LY6	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					[8] 6.2L V8 L92	Engine Control Module		√	√	√	√	√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		P			[9] 6.2L V8 LLZ	Transmission Control Module		√	√	√		√
					Body	CJ2 Dual Zone HVAC,Auto	Body Control Module		√	√	√	
						CJ3 Dual Zone HVAC,Manual	Body Control Module		√	√	√	
				Chassis	Under 8600 GVW	Electronic Brake Control Module		√	√	√		
					Equal to or Over 8600 GVW	Electronic Brake Control Module		√	√	√		
			Powertrain	[R] 5.7L V8 L31	Powertrain Control Module			√	√	√		
			Body	Supplemental Inflatable Restraint				√	√	√	√	
		S	Canyon	Powertrain	[9] 2.9L L4 LLV	Powertrain Control Module		√	√	√		
					[E] 3.7L L5 LLR	Powertrain Control Module		√	√	√		
				Body	Base Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
				Powertrain	[S] 4.2L L6 LL8	Powertrain Control Module		√	√	√		
						Engine Control Module		√	√	√	√	√
					[M] 5.3L V8 LH6	Transmission Control Module		√	√	√		√
						Body Control Module		√	√	√		
					CJ2 Dual Zone HVAC,Auto (Uplevel Radio)	Instrument Panel Cluster		√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
			Envoy	Body	(Optional Radio)	Supplemental Inflatable Restraint		√	√	√	√	
					CJ2 Dual Zone HVAC,Auto (Navigation Radio)	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					CJ3 Dual Zone HVAC,Manual (Uplevel Radio)	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					CJ3 Dual Zone HVAC,Manual (Navigation Radio)	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
			Canyon	Powertrain	[9] 2.9L L4 LLV	Powertrain Control Module		√	√	√		
					[E] 3.7L L5 LLR	Powertrain Control Module		√	√	√		
				Body	Base Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Uplevel Radio	Body Control Module		√	√	√	√	
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
				Powertrain	[S] 4.2L L6 LL8	Powertrain Control Module		√	√	√		
					[M] 5.3L V8 L H6	Engine Control Module		√	√	√	√	√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
	T		Envoy	Body	[M] 3.5L V6 LHO	Transmission Control Module		√	√	√		√
					CJ2 Dual Zone HVAC,Auto (Uplevel Radio)	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					CJ2 Dual Zone HVAC,Auto (Navigation Radio)	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					CJ3 Dual Zone HVAC,Manual (Uplevel Radio)	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					CJ3 Dual Zone HVAC,Manual (Navigation Radio)	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
	A		Powertrain	[L] 3.5L V6 LX9	Powertrain Control Module			√	√	√		
			Body	Automatic	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
					Supplemental Inflatable Restraint			√	√	√	√	
				Manual	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
					Supplemental Inflatable Restraint			√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
	Buick	S	Powertrain	[S] 4.2L L6 LL8	Powertrain Control Module			√	√	√		
				[M] 5.3L V8 LH6	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
			Body	CJ2 Dual Zone HVAC,Auto	Uplevel Radio	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
				CJ3 Dual Zone HVAC,Manual	Uplevel Radio	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
			Powertrain	[S] 4.2L L6 LL8	1 Speed Active	Powertrain Control Module		√	√	√		
					4 Button Selectable	Powertrain Control Module		√	√	√		
				[M] 5.3L V8 LH6	1 Speed Active	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					4 Button Selectable	Engine Control Module		√	√	√	√	√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		T			Transmission Control Module	Transmission Control Module		√	√	√		√
			Body	CJ2 Dual Zone HVAC,Auto	Uplevel Radio	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
				CJ3 Dual Zone HVAC,Manual	Uplevel Radio	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					Navigation Radio	Body Control Module		√	√	√		
						Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
		V	Powertrain	[W] 3.9L V6 LGD	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
				[1] 3.9L V6 LZ9	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
			Body	Base Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
				Uplevel Radio	Body Control Module			√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
			Body	Opel Vaux Radio	Instrument Panel Cluster			√	√	√		
				Navigation Radio	Body Control Module			√	√	√		
	Cadillac	C	Powertrain	[8] 6.2L V8 L92	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
			Body	Body Control Module				√	√	√		
			Chassis	Electronic Brake Control Module				√	√	√		
		E	Powertrain	[7] 3.6L V6 LY7	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
				[A] 4.6L V8 LH2	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
			Body	Body Control Module				√	√	√		
			Chassis	Electronic Brake Control Module				√	√	√		
		K	Powertrain	[8] 6.2L V8 L92	With Automatic Transfer Case	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Without Automatic Transfer Case	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
			Body	Body Control Module				√	√	√		
			Chassis	Electronic Brake Control Module				√	√	√		
				[W] 3.9L V6 LGD	Engine Control Module			√	√	√	√	√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
	Saturn	V	Powertrain	[1] 3.9L V6 L08	Transmission Control Module			√	√	√		√
				[1] 3.9L V6 LZ9	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
			Body	Base Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
				Uplevel Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
				Navigation Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
		Z	VUE	Body	Instrument Panel Cluster						√	
			VUE Hybrid	Powertrain	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
				Body	Instrument Panel Cluster						√	
	Cadillac Incomplete	Hearse	Powertrain	Engine Control Module				√	√	√	√	√
				Transmission Control Module				√	√	√		√
			Body	Body Control Module				√	√	√		
			Chassis	Electronic Brake Control Module				√	√	√		
		Limousine	Powertrain	Engine Control Module				√	√	√	√	√
				Transmission Control Module				√	√	√		√
			Body	Body Control Module				√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
	Pontiac APV	L	Chassis	Electronic Brake Control Module				√	√	√		
			Powertrain	[F] 3.4L V6 LNJ	Without All Wheel Drive	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					With All Wheel Drive	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
			Body	Body Control Module				√	√	√		
			Chassis	With Traction Control	Electronic Brake Control Module			√	√	√		
				Without Traction Control	Electronic Brake Control Module			√	√	√		
		U	Powertrain	[W] 3.9L V6 LGD	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
				[1] 3.9L V6 LZ9	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
			Body	Base Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
				Uplevel Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
				Navigation Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
			Powertrain	[W] 3.9L V6 LGD	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		V	Powertrain	[1] 3.9L V6 LZ9	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
			Body	Base Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
				Uplevel Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
				Navigation Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
	Chevrolet MPV	U	Powertrain	[W] 3.9L V6 LGD	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
				[1] 3.9L V6 LZ9	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
			Body	Base Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
				Uplevel Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
				Navigation Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
			Powertrain	[W] 3.9L V6 LGD	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		V	Powertrain	[1] 3.9L V6 LZ9	Engine Control Module			√	√	√	√	√
					Transmission Control Module			√	√	√		√
			Body	Base Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
				Uplevel Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
				Navigation Radio	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√		
	Hummer	Hummer H2	Powertrain	[U] 6.0L V8 LQ4	Powertrain Control Module			√	√	√		
			Body	Uplevel Radio	SUV	Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					SUT	Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
				Navigation Radio	SUV	Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
					SUT	Instrument Panel Cluster		√	√	√	√	
						Supplemental Inflatable Restraint		√	√	√	√	
		Hummer H3 (VIN 1-3 =	Powertrain	[E] 3.7L L5 LLR	Powertrain Control Module			√	√	√		
				[E] 3.7L L5 LLR Japan	Powertrain Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√	√	

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action				
		Chevrolet Equinox (VIN 1-3 = 5GT)	Body	Uplevel Radio	Supplemental Inflatable Restraint			√	√	√	√					
				Navigation Radio	Instrument Panel Cluster			√	√	√	√					
					Supplemental Inflatable Restraint			√	√	√	√					
		Hummer H3 (VIN 1-3 = ADM)	Powertrain	[E] 3.7L L5 LLR	Powertrain Control Module			√	√	√						
			Body	Uplevel Radio	Instrument Panel Cluster			√	√	√	√					
					Supplemental Inflatable Restraint			√	√	√	√					
				Navigation Radio	Instrument Panel Cluster			√	√	√	√					
					Supplemental Inflatable Restraint			√	√	√	√					
					SAAB	Powertrain	[S] 4.2L L6 LL8	1 Speed Active	Powertrain Control Module			√	√	√		
								4 Button Selectable	Powertrain Control Module			√	√	√		
	[M] 5.3L V8 LH6	1 Speed Active	Engine Control Module					√	√	√	√	√				
			Transmission Control Module					√	√	√		√				
		4 Button Selectable	Engine Control Module					√	√	√	√	√				
			Transmission Control Module					√	√	√		√				
	Body	Uplevel Radio	Without HID Headlamps	Body Control Module				√	√	√						
				Instrument Panel Cluster				√	√	√	√					
				Supplemental Inflatable Restraint				√	√	√	√					
			With HID Headlamps	Body Control Module				√	√	√						
				Instrument Panel Cluster			√	√	√	√						
				Supplemental Inflatable Restraint			√	√	√	√						

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		Body	Navigation Radio	Without HID Headlamps	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√	√	
					Supplemental Inflatable Restraint			√	√	√	√	
				With HID Headlamps	Body Control Module			√	√	√		
					Instrument Panel Cluster			√	√	√	√	
					Supplemental Inflatable Restraint			√	√	√	√	
	Holden	Captiva Maxx	Powertrain	[K] 3.2L V6 LU1	5 Speed Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
			Body	Automatic	Body Control Module			√	√	√		
				Manual	Body Control Module			√	√	√		
			Chassis	Without Traction Control	Electronic Brake Control Module			√	√	√		
				With Traction Control	Electronic Brake Control Module			√	√	√		
		Captiva	Powertrain	[G] 3.2L V6 LU1	5 Speed Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√	√	√
			Body	Automatic	Body Control Module			√	√	√		
				Manual	Body Control Module			√	√	√		
			Chassis	Without Traction Control	Electronic Brake Control Module			√	√	√		
				With Traction Control	Electronic Brake Control Module			√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action		
	Opel	Powertrain	[F] 2.0L L4 LLW	5 Speed Automatic	Without All Wheel Drive	Engine Control Module		√	√	√	√	√		
						Transmission Control Module		√	√	√		√		
					With All Wheel Drive	Engine Control Module		√	√	√	√	√		
						Transmission Control Module		√	√	√		√		
				Manual	Without All Wheel Drive	Engine Control Module		√	√	√	√	√		
					With All Wheel Drive	Engine Control Module		√	√	√	√	√		
			[T] 2.4L L4 LD9	5 Speed Automatic	Without All Wheel Drive	Engine Control Module		√	√	√	√	√		
						Transmission Control Module		√	√	√		√		
					With All Wheel Drive	Engine Control Module		√	√	√	√	√		
						Transmission Control Module		√	√	√		√		
				Manual	Without All Wheel Drive	Engine Control Module		√	√	√	√	√		
					With All Wheel Drive	Engine Control Module		√	√	√	√	√		
			[K] 3.2L V6 LU1	5 Speed Automatic	Without All Wheel Drive	Engine Control Module		√	√	√	√	√		
						Transmission Control Module		√	√	√		√		
					With All Wheel Drive	Engine Control Module		√	√	√	√	√		
						Transmission Control Module		√	√	√		√		
				Manual	Without All Wheel Drive	Engine Control Module		√	√	√	√	√		
					With All Wheel Drive	Engine Control Module		√	√	√	√	√		
					Automatic	Uplevel Radio	With Cellular Telephone	Body Control Module		√	√	√		
							Without Cellular Telephone	Body Control Module		√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		Body	Automatic	Navigation Radio	With Cellular Telephone	Body Control Module		√	√	√		
					Without Cellular Telephone	Body Control Module		√	√	√		
			Manual	Uplevel Radio	With Cellular Telephone	Body Control Module		√	√	√		
					Without Cellular Telephone	Body Control Module		√	√	√		
				Navigation Radio	With Cellular Telephone	Body Control Module		√	√	√		
					Without Cellular Telephone	Body Control Module		√	√	√		
		Chassis	Without Traction Control	Electronic Brake Control Module				√	√	√		
			With Traction Control	Electronic Brake Control Module				√	√	√		
		Powertrain	[F] 2.0L L4 LLW	5 Speed Automatic	Without All Wheel Drive	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					With All Wheel Drive	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Manual	Without All Wheel Drive	Engine Control Module		√	√	√	√	√
					With All Wheel Drive	Engine Control Module		√	√	√	√	√
			[T] 2.4L L4 LD9	5 Speed Automatic	Without All Wheel Drive	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					With All Wheel Drive	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Manual	Without All Wheel Drive	Engine Control Module		√	√	√	√	√
					With All Wheel Drive	Engine Control Module		√	√	√	√	√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
	Vauxhall		[K] 3.2L V6 LU1	5 Speed Automatic	Without All Wheel Drive	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
					With All Wheel Drive	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				Manual	Without All Wheel Drive	Engine Control Module		√	√	√	√	√
					With All Wheel Drive	Engine Control Module		√	√	√	√	√
		Body	Automatic	Uplevel Radio	With Cellular Telephone	Body Control Module		√	√	√		
					Without Cellular Telephone	Body Control Module		√	√	√		
				Navigation Radio	With Cellular Telephone	Body Control Module		√	√	√		
					Without Cellular Telephone	Body Control Module		√	√	√		
			Manual	Uplevel Radio	With Cellular Telephone	Body Control Module		√	√	√		
					Without Cellular Telephone	Body Control Module		√	√	√		
				Navigation Radio	With Cellular Telephone	Body Control Module		√	√	√		
					Without Cellular Telephone	Body Control Module		√	√	√		
		Chassis	Without Traction Control	Electronic Brake Control Module				√	√	√		
			With Traction Control	Electronic Brake Control Module				√	√	√		
				[6] 5.2L L4 Diesel	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√		
				[U] 6.0L V8 LQ4	Powertrain Control Module			√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		C-WT5500	Powertrain	[2] 6.6L V8 LLY Diesel	5 Speed Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
				[3] 7.8L L6 LG4	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√		
				[G] 8.1L V8 L18	Automatic	Powertrain Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Powertrain Control Module		√	√	√		
		T-B7 Chassis	Powertrain	[6] 5.2L L4 Diesel	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√			
					Manual	Engine Control Module		√	√	√		
				[U] 6.0L V8 LQ4	Powertrain Control Module			√	√	√		
				[2] 6.6L V8 LLY Diesel	5 Speed Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				[3] 7.8L L6 LG4	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√		
				[G] 8.1L V8 L18	Automatic	Powertrain Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Powertrain Control Module		√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
	[C] Chevrolet Truck	D-C Series	Powertrain	[6] 5.2L L4 Diesel	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√			
					Manual	Engine Control Module		√	√	√		
				[U] 6.0L V8 LQ4	Powertrain Control Module			√	√	√		
				[2] 6.6L V8 LLY Diesel	5 Speed Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				[3] 7.8L L6 LG4	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√		
				[G] 8.1L V8 L18	Automatic	Powertrain Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Powertrain Control Module		√	√	√		
			Body	Instrument Panel Cluster				√	√	√	√	
				Supplemental Inflatable Restraint				√	√	√	√	
			Powertrain	[6] 5.2L L4 Diesel	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√			
					Manual	Engine Control Module		√	√	√		
				[U] 6.0L V8 LQ4	Powertrain Control Module			√	√	√		
				[2] 6.6L V8 LLY Diesel	5 Speed Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action	
Medium Duty		C-T Series	Powertrain	[3] 7.8L L6 LG4	Automatic	Engine Control Module		√	√	√			
						Transmission Control Module		√	√	√		√	
					Manual	Engine Control Module		√	√	√			
				[G] 8.1L V8 L18	Automatic	Powertrain Control Module		√	√	√			
						Transmission Control Module		√	√	√		√	
					Manual	Powertrain Control Module		√	√	√			
			Body	Instrument Panel Cluster					√	√	√	√	
				Supplemental Inflatable Restraint					√	√	√	√	
			B-W4 Series	Powertrain	[6] 5.2L L4 Diesel	Automatic	Engine Control Module		√	√	√		
		Transmission Control Module						√	√				
		Manual				Engine Control Module		√	√	√			
		[U] 6.0L V8 LQ4			Powertrain Control Module				√	√	√		
		[2] 6.6L V8 LLY Diesel			5 Speed Automatic	Engine Control Module		√	√	√	√	√	
						Transmission Control Module		√	√	√		√	
		[3] 7.8L L6 LG4			Automatic	Engine Control Module		√	√	√			
						Transmission Control Module		√	√	√		√	
					Manual	Engine Control Module		√	√	√			
		[G] 8.1L V8 L18			Automatic	Powertrain Control Module			√	√	√		
						Transmission Control Module			√	√	√		√
					Manual	Powertrain Control Module			√	√	√		

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
Truck		C-WT5500	Powertrain	[6] 5.2L L4 Diesel	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√			
					Manual	Engine Control Module		√	√	√		
				[U] 6.0L V8 LQ4	Powertrain Control Module			√	√	√		
				[2] 6.6L V8 LLY Diesel	5 Speed Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				[3] 7.8L L6 LG4	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√		
				[G] 8.1L V8 L18	Automatic	Powertrain Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Powertrain Control Module		√	√	√		
		T-B7 Chassis	Powertrain	[6] 5.2L L4 Diesel	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√			
					Manual	Engine Control Module		√	√	√		
				[U] 6.0L V8 LQ4	Powertrain Control Module			√	√	√		
				[2] 6.6L V8 LLY Diesel	5 Speed Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				[3] 7.8L L6 LG4	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√	√		√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
	[T] GMC Truck	D-C Series			Manual	Engine Control Module		√	√	√		
				[G] 8.1L V8 L18	Automatic	Powertrain Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Powertrain Control Module		√	√	√		
			Powertrain	[6] 5.2L L4 Diesel	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√			
					Manual	Engine Control Module		√	√	√		
				[U] 6.0L V8 LQ4	Powertrain Control Module			√	√	√		
				[2] 6.6L V8 LLY Diesel	5 Speed Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				[3] 7.8L L6 LG4	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√		
				[G] 8.1L V8 L18	Automatic	Powertrain Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Powertrain Control Module		√	√	√		
			Body	Instrument Panel Cluster				√	√	√	√	
				Supplemental Inflatable Restraint				√	√	√	√	
				[6] 5.2L L4 Diesel	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√			

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
		C-T Series	Powertrain		Manual	Engine Control Module		√	√	√		
				[U] 6.0L V8 LQ4	Powertrain Control Module			√	√	√		
				[2] 6.6L V8 LLY Diesel	5 Speed Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				[3] 7.8L L6 LG4	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Engine Control Module		√	√	√		
				[G] 8.1L V8 L18	Automatic	Powertrain Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Powertrain Control Module		√	√	√		
			Body	Instrument Panel Cluster				√	√	√	√	
				Supplemental Inflatable Restraint				√	√	√	√	
		B-W4 Series	Powertrain	[6] 5.2L L4 Diesel	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√			
					Manual	Engine Control Module		√	√	√		
				[U] 6.0L V8 LQ4	Powertrain Control Module			√	√	√		
				[2] 6.6L V8 LLY Diesel	5 Speed Automatic	Engine Control Module		√	√	√	√	√
						Transmission Control Module		√	√	√		√
				[3] 7.8L L6 LG4	Automatic	Engine Control Module		√	√	√		
						Transmission Control Module		√	√	√		√

GM车系_V34.01_版本可测车型一览表

Menu_1	Menu_2	Menu_3	Menu_4	Menu_5	Menu_6	Menu_7	Menu_8	Read DTC	Clear DTC	Data Stream	Id Info	Action
					Manual	Engine Control Module		√	√	√		
				[G] 8.1L V8 L18	Automatic	Powertrain Control Module		√	√	√		
						Transmission Control Module		√	√	√		√
					Manual	Powertrain Control Module		√	√	√		
Workhorse	6 - W22 Series	Powertrain	[G] 8.1L V8 L18	Powertrain Control Module				√	√	√		
				Transmission Control Module				√	√	√		√
	A - W24 Series	Powertrain	[G] 8.1L V8 L18	Powertrain Control Module				√	√	√		
				Transmission Control Module				√	√	√		√
	A - W25 Series	Powertrain	[G] 8.1L V8 L18	Powertrain Control Module				√	√	√		
				Transmission Control Module				√	√	√		√
	D - W42 Series	Powertrain	[V] 4.8L V8 LR4	Powertrain Control Module				√	√	√		
			[U] 6.0L V8 LQ4	Powertrain Control Module				√	√	√		
	E - W16 Series	Powertrain	[G] 8.1L V8 L18	Powertrain Control Module				√	√	√		
	E - W18 Series	Powertrain	[U] 6.0L V8 LQ4	Powertrain Control Module				√	√	√		
			[G] 8.1L V8 L18	Powertrain Control Module				√	√	√		
	F - R26 Series	Powertrain	[G] 8.1L V8 L18	Powertrain Control Module				√	√	√		
				Transmission Control Module				√	√	√		√
	G - W62 Series	Powertrain	[G] 8.1L V8 L18	Powertrain Control Module				√	√	√		
				Transmission Control Module				√	√	√		√