

KIA V38.10 Diagnostics List (Note:For reference only)

Areas	Vehicle	System	Sub System	Functions												
				System Info.	Read Dtc	Clear Dtc	Data stream	Actu ation	Air bleed	Impact Info.	CPF SERVICE REGENERA TION	RESETTING ADAPTIVE VALUES	FREEZE FRAME DATA	PASS. AIRB AG REALTIME INFO.	CRASHING INFORMATI ON	
		ABS(1999-2004)			√	√	√	√								
		SRS(1999-2004)			√	√										
	CARENS	Engine	LEAD 2.4L ALL(2007~2009)	√	√	√	√	√					√	√		
			UNLEAD 2.4L GEN(2007~2009)	√	√	√	√	√					√	√		
			UNLEAD 2.4L EOBD(2007~2009)	√	√	√	√	√					√	√		
			LEAD 2.0L ALL(2007~2009)	√	√	√	√	√					√	√		
			UNLEAD 2.0L GEN(2007~2009)	√	√	√	√	√					√	√		
			UNLEAD 2.0L EOBD(2007~2009)	√	√	√	√	√					√	√		
			2.0L DIESEL(KWP) EURO-4(2007~2009)	√	√	√	√	√								
			2.0L DIESEL(CAN)(2007~2009)	√	√	√	√	√				√				

KIA V38.10 Diagnostics List (Note:For reference only)

Areas	Vehicle	System	Sub System	Functions												
				System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Air bleed	Impact Info.	CPF SERVICE REGENERATION	RESETTING ADAPTIVE VALUES	FREEZE FRAME DATA	PASS. AIRB AG REALTIME INFO.	CRASHING INFORMATION	
			1.8L DOHC EURO-IV (2003-05)		√	√	√									
			1.8L DOHC LEAD (2003-05)		√	√	√									
			1.8L DOHC M/T (2001-02)		√	√	√									
			1.8L DOHC (2001-02)		√	√	√									
			1.8L DOHC GASOLINE TED (1999-2000)		√	√	√									
	AT		DIESEL (2003-05)		√	√	√	√								
			GASOLINE (1999-2005)		√	√	√									
			1.8L LPG (2004-2005)		√	√	√									
			2.0L LPG (2004-2005)		√	√	√	√								
			2007		√	√										
			2.0/2.4 SIEMENS(2007~2009)	√	√	√	√	√				√				

KIA V38.10 Diagnostics List (Note:For reference only)

Areas	Vehicle	System	Sub System	Functions												
				System Info.	Read Dtc	Clear Dtc	Data stream	Actu ation	Air bleed	Impact Info.	CPF SERVICE REGENERA TION	RESETTING ADAPTIVE VALUES	FREEZE FRAME DATA	PASS. AIRB AG REALTIME INFO.	CRASHING INFORMATI ON	
			GASOLINE (2002-04)		√	√	√	√								
			DIESEL (2002-04)		√	√	√	√								
			TCU(GENERAL) GAS (1998-2001)		√	√	√	√								
			TCU(EUROPE) GAS (1998-2001)		√	√	√	√								
			TCU(GENERAL) DIESEL (1998-2001)		√	√	√									
			TCU(EUROPE) DIESEL (1998-2001)		√	√	√									
	ABS		ABS(2002-04)		√	√	√	√	√							
			ABS EURO-II(2002-04)		√	√	√	√	√							
			ABS C/RAIL(2002-04)		√	√	√	√	√							
			ABS(EUROPE) (1998-2001)		√	√	√	√	√							
			ABS(GENERAL) GAS (1998-2001)		√	√	√	√	√							

KIA V38.10 Diagnostics List (Note:For reference only)

Areas	Vehicle	System	Sub System	Functions											
				System Info.	Read Dtc	Clear Dtc	Data stream	Actu ation	Air bleed	Impact Info.	CPF SERVICE REGENERATION	RESETTING ADAPTIVE VALUES	FREEZE FRAME DATA	PASS. AIRB AG REALTIME INFO.	CRASHING INFORMATI ON
		ABS(2003-04)		√	√	√	√	√	√						
		SRS(2003-04)		√	√	√	√								
		ELEC. POWER STEERING(2003-04)		√	√	√	√								
		4WD(2003-04)			√	√									
		FUEL FIRED HEATER(2003-04)			√	√	√	√							
	OPIRUS	Engine(2004~2005)	3.5L V6 EOBD		√	√	√	√							
			3.5L V6 GEN		√	√	√	√							
			2.7L		√	√									
			2007		√	√									
		AT	(2004~2005)		√	√	√	√							
			2007		√	√									
		ABS/TCS/ESP (2004~2007)			√	√	√	√							
		SRS	(2004~2005)		√	√	√								
			2007		√	√									
		BODY CONTROL MODULE(2004~2007)	BODY CONTROL MODULE	√	√	√	√	√							
			DRIVER POWER WINDOW		√	√	√	√							

KIA V38.10 Diagnostics List (Note:For reference only)

Areas	Vehicle	System	Sub System	Functions												
				System Info.	Read Dtc	Clear Dtc	Data stream	Actu ation	Air bleed	Impact Info.	CPF SERVICE REGENERA TION	RESETTING ADAPTIVE VALUES	FREEZE FRAME DATA	PASS. AIRB AG REALTIME INFO.	CRASHING INFORMATI ON	
		ABS(2004~2005)		√	√	√	√	√	√							
		SRS(2004~2005)		√	√	√					√					
CERATO (SPECTRA)		Engine(2007~2008)	UNLEAD 2.0L GEN	√	√	√	√	√								
			UNLEAD 2.0L EOBD	√	√	√	√	√								
			LEAD 2.0L ALL	√	√	√	√	√								
			LEAD 1.6L GEN	√	√	√	√	√								
			LEAD 1.6L EOBD	√	√	√	√	√								
			LEAD 1.6L ALL	√	√	√	√	√								
			DIESEL VGT	√	√	√	√	√								
		AT(2007~2008)	1.6 GASOLINE	√	√	√	√	√								
			2.0 GASOLINE	√	√	√	√	√								
			1.6 DIESEL	√	√	√	√	√								
			ABS(2007~2008)		√	√	√	√	√							
			SRS(2007~2008)			√	√	√								
			AC(2007~2008)		√	√	√	√	√							
			Engine(2004~2007)	2.0L/1.6L GASOLINE		√	√									
				1.6L DIESEL(VGT) EURO-4		√	√									
				2.0L Diesel Eng. All	√	√	√	√	√							

KIA V38.10 Diagnostics List (Note:For reference only)

Areas	Vehicle	System	Sub System	Functions												
				System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Air bleed	Impact Info.	CPF SERVICE REGENERATION	RESETTING ADAPTIVE VALUES	FREEZE FRAME DATA	PASS. AIRBAG REALTIME INFO.	CRASHING INFORMATION	
		SRS			√	√	√									
		A/C			√	√	√	√								
		ELEC. POWER STEERING			√	√										
		ELEC. CONTROL SUSPENSION			√	√										
		AHLS		√	√	√	√									
		SMART KEY	INTERBASE UNIT (IFU)	√			√	√								
	LOTZE	Engine	1.8/2.0 & 2.4+ET		√	√	√	√								
			LPI (EMS ECU)		√	√	√	√								
			LPI (IFB ECU)		√	√	√	√								
		AT	1.8/2.0 & 2.4+ET		√	√	√	√								
			Diesel CAN BUS		√	√	√	√								
		ABS			√	√	√	√								
		SRS			√	√					√					
	BONGO III	Engine	2.5 (TCI)	√	√	√	√	√								
			2.9 (COMMON RAIL)	√	√	√	√	√								
		AT		√	√	√	√									
		ABS		√	√	√	√	√								

(*):Tested;

(?):Manual on website(www.x431.com)

The final interpretation of the products belongs to LAUNCH TECH CO.,LTD.

CONNECTOR	X431	DIAGUN
SMART OBD	Use for the cars of 16-PIN Diagnostic socket	N/A
KIA-20	Use for the cars of 20PIN Diagnostic socket	Use for the cars of 20PIN Diagnostic socket
OBD 16C	N/A	N/A
CANBUS II	Use for the cars of 16-PIN Diagnostic socket	N/A
diagun connector	N/A	Use for the cars of 16-PIN Diagnostic socket
SUPER 16	Use for the cars of 16-PIN Diagnostic socket	N/A