

Mazda **V34.60** Diagnostics List (Note:For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	MAZDA6(EURO STG3-4 and General)	PCM		√	√	√	√	1.Program Setting 2.Immo. 3.DPF 4.ETB/EGR Initialization 5.Data Reset	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS/TCS		√	√	√	√	1.Program Setting 2.Initialization	
		RCM		√	√	√		1.Program Setting	
		GEM		√	√	√			
		LCM		√	√				
		4x4		√	√				
		FFH		√	√	√			
		LHID		√	√	√			
		RHID		√	√	√			
		RKE		√	√	√			
	ATENZA(JPN)/MAZDA6(General)	PCM		√	√	√	√	1.Program Setting	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting 2.Initialization	
		RCM		√	√	√		1.Program Setting	
		GEM		√	√	√			
		4x4		√	√				
	MPV(JPN/GENERAL)	PCM		√	√	√	√		
		TCM		√	√	√	√		
		ABS/TCS		√	√	√	√		

Mazda **V34.60** Diagnostics List (Note:For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actu ation	Special Functions	Others
	MPV(Europe/General)	PCM		√	√	√	√		
		FFH		√	√	√			
		ABS/TCS		√	√	√	√		
	MAZDA6(North America/General)	PCM		√	√	√	√	1.ProgramSetting 2.EVAP Test	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting	
		RCM		√	√	√		1.Program Setting	
		GEM		√	√	√			
		4x4		√	√				
	MAZDA2(EURO STG3/4 Specs.)	PCM		√	√	√			
		TCM		√	√	√			
		ICM		√	√	√			
		ABS/TCS		√	√	√			
		RCM		√	√	√			
	MAZDA3(EURO STG3/4/5 and General specs.)	PCM		√	√	√	√	1.Program Setting 2.DPF 3.ETB/EGR Initialization 4.Data Reset	
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting 2.Initialization	
		RCM		√	√	√		1.Program Setting	
		EPS		√	√	√		1.Program Setting	
		GEM		√	√	√		1.Program Setting	
		FFH		√	√	√			
		FACM		√	√	√			

Mazda **V34.60** Diagnostics List (Note:For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	AXELA-MAZDA3(Japan-General Specs.)	EATC		√	√				
		PCM		√	√	√	√	1.Program Setting	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting 2.Initialization	
		EPS		√	√	√		1.Program Setting	
		RCM		√	√	√		1.Program Setting	
		GEM		√	√	√		1.Program Setting	
		4X4		√	√				
	MAZDA3(North America/General)	PCM		√	√	√	√	1.Program Setting 2.EVAP Test	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting 2.Initialization	
		EPS		√	√	√		1.Program Setting	
		RCM		√	√	√		1.Program Setting	
		GEM		√	√	√			
	Escape/Tribute(-2006/3)	PCM		√	√	√	√	1.Program Setting	
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting	
		GEM		√	√	√			
		RCM		√	√	√		1.Program Setting	
	BONGO/BONGO BRAUNY/SPECTRON	PCM		√	√	√	√	1.DPF 2.ETB/EGR Initialization 3.Data Reset	

Mazda **V34.60** Diagnostics List (Note:For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
		TCM		√	√	√	√		
		ABS		√	√	√	√		
	MPV(North America/General)	PCM		√	√	√	√	1.Program Setting 2.EVAP Test	
		TCM		√	√	√	√		
		ABS		√	√	√	√	1.Program Setting	
		RCM		√	√	√		1.Program Setting	
	TITAN DASH	PCM		√	√	√	√		
		TCM		√	√	√	√		
	MAZDA5(EURO STG3/4/5 and General specs.)	PCM		√	√	√	√	1.Program Setting 2.DPF 3.ETB/EGR Initialization 4.Data Reset	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting 2.Initialization	
		RCM		√	√	√		1.Program Setting	
		GEM		√	√	√		1.Program Setting	
		EPS		√	√	√		1.Program Setting	
		FFH		√	√	√			
	PREMACY/MAZDA5(Japan General specs.)	PCM		√	√	√	√	1.Program Setting	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting 2.Initialization	
		RCM		√	√	√		1.Program Setting	
		GEM		√	√	√			

Mazda **V34.60** Diagnostics List (Note:For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	MAZDA5(North America Specs.)	EPS		√	√	√		1.Program Setting	
		PCM		√	√	√	√	1.Program Setting 2.EVAP Test	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting	
		RCM		√	√	√		1.Program Setting	
		GEM		√	√	√			
	MX-5(Europe/General Specs.)	PCM		√	√	√	√	1.Program Setting	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting 2.Initialization	
		RCM		√	√	√		1.Program Setting	
		RHT		√	√	√			
		RKE		√	√	√			
	ROADSTER/MX-5(Japan/General Specs.)	PCM		√	√	√	√	1.Program Setting	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting 2.Initialization	
		RCM		√	√	√		1.Program Setting	
		RHT		√	√	√			
		RKE		√	√	√			
		PCM		√	√	√	√	1.Program Setting 2.EVAP Test	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	

Mazda **V34.60** Diagnostics List (Note:For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
2001-	MX-5(North America/General Specs.)	ABS		√	√	√	√	1.Program Setting 2.Initialization	
		RCM		√	√	√		1.Program Setting	
		RHT		√	√	√			
		RKE		√	√	√			
	RX-8(North America Specs.)	PCM		√	√	√	√	1.Program Setting 2.EVAP Test	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting	
		RCM		√	√	√		1.Program Setting	
		EPS		√	√	√			
		SASM		√	√				
	MPV/Mazda8(JPN/General)	PCM		√	√	√	√	1.Program Setting	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√		
		RCM		√	√	√		1.Program Setting	
		GEM		√	√	√			
		4X4		√	√				
	RX-8(Europe/General/Japan Specs.)	PCM		√	√	√	√	1.Program Setting	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting 2.Initialization	
		RCM		√	√	√		1.Program Setting	
		EPS		√	√	√			
		SASM		√	√				

Mazda **V34.60** Diagnostics List (Note:For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
		LCM		√	√	√			
		TPM		√	√	√			
		RKE		√	√	√			
	Escape/Tribute(2006/4-)	PCM		√	√	√	√	1.Program Setting	
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√	1.Program Setting	
		RCM		√	√	√			
		GEM		√	√	√		1.Program Setting	
	CX-7(North America/General Specs.)	PCM		√	√	√	√	1.Program Setting 2.EVAP Test	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√		
		RCM		√	√	√		1.Program Setting	
		GEM		√	√	√			
		4X4		√	√				
	CX-7(Japan/General Specs.)	PCM		√	√	√	√	1.Program Setting	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√		
		RCM		√	√	√		1.Program Setting	
		GEM		√	√	√			
		4X4		√	√				
		PCM		√	√	√	√	1.Program Setting	
		TCM		√	√	√	√		
		ICM		√	√	√		1.Program Setting	
		ABS		√	√	√	√		
		RCM		√	√	√		1.Program Setting	

Mazda **V34.60** Diagnostics List (Note:For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	CX-9(North America/General Specs.)	GEM		√	√	√			
		4X4		√	√				
		AM		√	√				
		LCM		√	√	√			
		LTM		√	√				
		BSML		√	√				
		BSMR		√	√				
	CX-7(Europe/General Specs.)	PCM		√	√	√	√	1.Program Setting	
		ICM		√	√	√		1.Program Setting	
		ABS/TCS		√	√	√	√		
		RCM		√	√	√		1.Program Setting	
		GEM		√	√	√		1.Program Setting	
		4X4		√	√				
	DEMIO(JPN)–VERISA(JPN)- MAZDA2(General)	PCM		√	√	√	√	1.Program Setting	
		ICM		√	√	√		1.Program Setting	
		ABS/TCS		√	√	√	√		
		RCM		√	√	√		1.Program Setting	
		EPS		√	√	√		1.Program Setting	
		4X4		√	√				
	BT-50/Ranger	PCM		√	√	√	√	1.Program Setting 2.Injection	
		TCM		√	√	√	√		
		ABS/TCS		√	√	√	√		
		RCM		√	√	√			
	PROTEGE	PCM		√	√	√			
		ABS		√	√	√			
		PCM		√	√	√			
		TCM		√	√	√			

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	DEMIO(JPN)/MAZDA2(General)	ICM		√	√	√			
		ABS/TCS		√	√	√			
		RCM		√	√	√			
		GEM		√	√	√			
		EPS		√	√	√			
		RKE		√	√	√			
		VSM		√	√	√			
	MAZDA2(Europe)	PCM		√	√	√			
		TCM		√	√	√			
		ICM		√	√	√			
		ABS/TCS		√	√	√			
		RCM		√	√	√			
		GEM		√	√	√			
		EPS		√	√	√			
		RKE		√	√	√			
		VSM		√	√	√			
	MAZDA6(Europe and General)	PCM		√	√	√			
		TCM		√	√	√			
		ICM		√	√	√			
		ABS/TCS		√	√	√			
		RCM		√	√	√			
		GEM		√	√	√			
		EPS		√	√	√			
		EATC		√	√	√			
		RKE		√	√	√			
		LCM		√	√				
		FFH		√	√	√			
	626/626 WAGON/TEI STAR	PCM		√	√	√			

Mazda **V34.60** Diagnostics List (Note:For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	020/020 WAGON/TELESTAR	ABS		√	√	√			
	LASER/323/TIERRA	PCM		√	√	√			
		ABS		√	√	√			
	PREMACY/IXION	PCM		√	√	√			
		ABS		√	√	√			
	PREMACY	PCM		√	√	√			
		ABS		√	√	√			
	Biante(Japan)	PCM		√	√	√			
		TCM		√	√	√			
		ICM		√	√	√			
		ABS/TCS		√	√	√			
		RCM		√	√	√			
		GEM		√	√	√			
		EPS		√	√	√			
		EATC		√	√	√			
		RKE		√	√	√			
		4X4		√	√				
	MAZDA3(China/General)	PCM		√	√	√			
		ICM		√	√	√			
		ABS/TCS		√	√	√			
		RCM		√	√	√			
		GEM		√	√	√			
		EPS		√	√	√			
		RKE		√	√	√			
	FAMILIA/LASER	PCM		√	√	√			
		ABS		√	√	√			
	MX-5	PCM		√	√	√			
		ABS		√	√	√			

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	AZ/WAGON(MJ)	PCM		√	√	√			
		ABS		√	√	√			
		RCM		√	√	√			
	XEDOS9	PCM		√	√	√			
		ABS		√	√	√			
	CAPELLA/CAPELLA W/TELSTAR /TELSTAR W	PCM		√	√	√			
		ABS		√	√	√			
	DEMIO/121 DEMIO/121	PCM		√	√	√			
		ABS		√	√	√			
		EPS		√	√	√			
	DEMIO/FESTIVA MINI WAGON	PCM		√	√	√			
		ABS		√	√	√			
	FRIENDEE/FREDA/BONGO FRIENDEE	PCM		√	√	√			
		TCM		√	√	√			
	BONGO BRAUNY/ECONOVAN/MAZDA E-SERIES	PCM		√	√	√			
		TCM		√	√	√			
		ABS		√	√	√			
	Fiesta/Mazda 121/Bantam	PCM		√	√	√			
		ABS		√	√	√			
		GEM		√	√	√			
		ECS		√	√	√			
		HEC		√	√	√			
	MX-5 MIATA	PCM		√	√	√			
		ABS		√	√	√			
	ROADSTER/MX-5	PCM		√	√	√			
		ABS		√	√	√			
		4X4		√	√				

Mazda **V34.60** Diagnostics List (Note:For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	Escape/Tribute/Maverick	PCM		√	√	√	√	1.Program Setting 2.Immo.	
		ABS		√	√	√		1.Program Setting 2.Initialization	
		RCM		√	√	√		1.Program Setting	
		ICM		√	√	√		1.Program Setting	
		GEM		√	√	√			
		PAM		√	√	√			
	(All MY05)Escape/Tribute/Maverick/ Mariner	4X4		√	√				
		PCM		√	√	√			
		ABS		√	√	√			
		RCM		√	√	√			
		ICM		√	√	√			
		GEM		√	√	√			
		PAM		√	√	√			
	MAZDA6(China)	ABS		√	√	√			
		EATC		√	√	√			
		EPS		√	√	√			
		GEM		√	√	√			
		ICM		√	√	√			
		LCM		√	√				
		PCM		√	√	√			
		RCM		√	√	√			
		RKE		√	√	√			
	Millenia	ABS		√	√	√			
		PCM		√	√	√			
		PCM		√	√	√	√		

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	01. 01 GY AT MPV(CALIF.)	ABS		√	√	√	√		
		CCM		√	√				
	02.01 GY A T MPV(FED,CAN BUSADA)	PCM		√	√	√			
		ABS		√	√	√			
		CCM		√	√				
		PCM		√	√	√	√		
	03.01 ZM MT PROTEG	ABS		√	√	√	√		
		CCM		√	√				
		PCM		√	√	√	√		
		ABS		√	√	√	√		
	04.01 ZM AT PROTEGE	CCM		√	√				
		PCM		√	√	√	√		
		ABS		√	√	√	√		
		CCM		√	√				
	05.01 FP MT PROTEGE	PCM		√	√	√	√		
		ABS		√	√	√	√		
		CCM		√	√				
		PCM		√	√	√	√		
	06. 01 FP AT PROTEGE	ABS		√	√	√	√		
		CCM		√	√				
	07. 01 FS MT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	08. 01 FS AT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	09. 01 KL MT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	10. 01 KL AT 626	PCM		√	√	√			
		ABS		√	√	√	√		
		PCM		√	√	√	√		
		ABS		√	√	√	√		
	11. 01 BP MT MIATA	CCM		√	√				

Mazda **V34.60** Diagnostics List (Note:For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	12. 01 BP AT MIATA	PCM		√	√	√	√		
		ABS		√	√	√	√		
		CCM		√	√				
	13. 01 KL AT MILLENIA	PCM		√	√	√	√		
		ABS		√	√	√	√		
		CCM		√	√				
		A/C		√	√				
	14. 01 KJ AT MILLENIA	PCM		√	√	√	√		
		ABS		√	√	√	√		
		CCM		√	√				
		A/C		√	√				
	15. 01 YF MT TRIBUTE(EP)	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		ICM		√	√	√			
		RCM	√	√	√	√	√		
	16. 01 YF AT TRIBUTE(EP)	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		ICM		√	√	√			
		RCM	√	√	√	√	√		
	17. 01 AJ AT TRIBUTE(EP)	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		ICM		√	√	√			
		RCM	√	√	√	√	√		
		PCM		√	√	√			
		ABS		√	√	√	√		

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	18. 01 2.3L AT B2300	GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
		-4X4	√	√	√	√	√		
	19. 01 2.3L MT B2300	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
		-4X4	√	√	√	√	√		
	20. 01 2.5L AT B2500	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
		-4X4	√	√	√	√	√		
	21. 01 2.5L MT B2500	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
		-4X4	√	√	√	√	√		
	22. 01 3.0L AT B3000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
		-4X4	√	√	√	√	√		

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
2001- VIN#10:1	23. 01 3.0L MT B3000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
		-4X4	√	√	√	√	√		
	24. 01 4.0L AT B4000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
		-4X4	√	√	√	√	√		
	25. 01 4.0L MT B4000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
		-4X4	√	√	√	√	√		
	121 (DB) B3(MT/AT)	PCM		√	√				
		TCM		√	√				
	121 (DB) B5(MT/AT)	PCM		√	√				
		TCM		√	√				
	121 (DB) B5(MT/AT) DB1053	PCM		√	√				
	121/121 DEMIO(DW) B3(MT)	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	121/121 DEMIO(DW) B3(AT)	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	121/121 DEMIO(DW) B5(MT)	PCM		√	√	√	√		

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	121/121 DEMIO(DW) B5(AT)	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	121/121 DEMIO(DW) B3(MT) DW1052	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	121/121 DEMIO(DW) B3(AT) DW1052	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	121/121 DEMIO(DW) B3(MT) DW1032#203028	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	121/121 DEMIO(DW) B3(AT) DW1032#203028	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	121/121 DEMIO(DW) B5(MT) DW1052	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	121/121 DEMIO(DW) B5(AT) DW1052	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	121/121 DEMIO(DW) B5(MT) DW1032#203028	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	121/121 DEMIO(DW) B5(AT) DW1032#203028	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BG) B3(MT/AT)	PCM		√	√				
		ABS		√	√				
		TCM		√	√				
	323 (BG) B6(MT/AT)	PCM		√	√				
		ABS		√	√				
		TCM		√	√				
	323 (BG) BP(MT/AT)	PCM		√	√				
		ABS		√	√				
		TCM		√	√				
	323 (BG) AND BP-SOHC(AT) RG10P2	PCM		√	√				

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	323 (BA) B3(MT)	ABS		√	√				
	323 (BA) B3(MT)	PCM		√	√	√	√		
		ABS		√	√				
	323 (BJ) B3(MT)	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BJ) ZL(MT)	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BJ) ZL(AT)	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BJ) ZM(MT)	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BJ) ZM(AT)	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BJ) FP(MT)	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BJ) FP(AT)	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BJ) RF-I(MT)	PCM		√	√	√	√		
	323 (BJ) B3(MT) #200001	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BJ) ZL(MT) #200001	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BJ) ZL(AT) #200001	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BJ) ZM(MT) #200001	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BJ) ZM(AT) #200001	PCM		√	√	√	√		
		ABS	√	√	√	√	√		

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	323 (BJ) FP(MT) #200001	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	323 (BJ) FP(AT) #200001	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	MX-5 (NB) BP(MT)	PCM		√	√	√	√		
	MX-5 (NB) BP(AT)	PCM		√	√	√	√		
	MX-5 (NB) BP(MT) NB30P2	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	MPV(LW) FS(AT)	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	MPV(LW) GY(AT)	PCM		√	√	√	√		
	B-SERIES(UF) G6(MT)	PCM		√	√	√	√		
	B-SERIES(UF) G6(AT)	PCM		√	√	√	√		
	B-SERIES(UF) F2(MT)	PCM		√	√	√	√		
	B-SERIES(UN) G6(MT)	PCM		√	√	√	√		
	B-SERIES(UN) G6(MT)	PCM		√	√	√	√		
	B-SERIES(UN) F2(MT)	PCM		√	√	√	√		
	E-SERIES (SR) FE-EGI(MT)	PCM		√	√	√	√		
	E-SERIES(SK,SL) FE-EGI(MT)	PCM		√	√	√	√		
	E-SERIES(SK,SL) FE-EGI(MT)	PCM		√	√	√	√		
	BONGO FRIENDEE(SG) J5(AT)	PCM		√	√	√	√		
	BONGO FRIENDEE(SG) J5(AT) SG10J4	PCM		√	√	√	√		
		A/C		√	√				
		ABS		√	√				
		TCM		√	√	√	√		
	PREMACY (CP) FP(AT)	PCM		√	√	√	√		
		ABS		√	√	√	√		
	626 (GF) FS(MT)	PCM		√	√	√			

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	626 (GF) FS(AT)	PCM		√	√	√			
	626 (GF) FS(MT) #200001	PCM		√	√	√	√		
		ABS	√	√	√	√	√		
	626 (GF) FS(AT) #200001	PCM		√	√	√	√		
		ABS		√	√	√	√		
	626 WAGON(GW) FS(MT)	PCM		√	√	√			
	626 WAGON(GW) FS(AT)	PCM		√	√	√			
	626 WAGON(GW) FS(MT) #200001	PCM		√	√	√			
	1. 00 GY AT MPV(CALIF.)	PCM		√	√	√	√		
		ABS		√	√	√	√		
		CCM		√	√				
	2. 00 GY AT MPV (FED,CAN BUSADA)	PCM		√	√	√	√		
		ABS		√	√	√	√		
		CCM		√	√				
	3 00 ZM MT PROTEGE	PCM		√	√	√	√		
		ABS		√	√	√	√		
		CCM		√	√				
	4 00 ZM AT PROTEGE	PCM		√	√	√	√		
		ABS		√	√	√	√		
		CCM		√	√				
	5 00 FP MT PROTEGE	PCM		√	√	√	√		
		ABS		√	√	√	√		
		CCM		√	√				
	6 00 FP AT PROTEGE	PCM		√	√	√	√		
		ABS		√	√	√	√		
		CCM		√	√				
	7 00 FS MT 626	PCM		√	√	√			

Mazda V34.60 Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
2000- VIN#10:Y	7 00 FS MT 626	ABS		√	√	√	√		
	8 00 FS AT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	9 00 KL MT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	10 00 KL AT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	11 00 BP MT MIATA	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	12 00 BP AT MIATA	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	13 00 KL AT MILLENIA	PCM		√	√	√	√		
		A/C		√	√				
		ABS		√	√	√	√		
		CCM		√	√				
	14 00 KJ AT MILLENIA	PCM		√	√	√	√		
		A/C		√	√				
		ABS		√	√	√	√		
		CCM		√	√				
	15 00 2.5L AT B2500	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		PATS		√	√	√			
		RAP	√	√	√	√	√		
		PCM		√	√	√			

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	16 00 2.5L MT B2500	ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		PATS		√	√	√			
		RAP	√	√	√	√	√		
	17 00 3.0L AT B3000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		PATS		√	√	√			
		RAP	√	√	√	√	√		
	18 00 3.0L MT B3000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		PATS		√	√	√			
		RAP	√	√	√	√	√		
	20 00 4.0 L AT B4000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		PATS		√	√	√			
		RAP	√	√	√	√	√		
	20 00 4.0 L MT B4000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		PATS		√	√	√			

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
		RAP	√	√	√	√	√		
	1 99 ZM MT PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	2 99 ZM AT PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	3 99 FP MT PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	4 99 FP AT PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	5 99 FS MT 626	PCM		√	√	√			
		ABS		√	√				
	6 99 FS AT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	7 99 KL MT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	8 99 KL AT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	9 99 BP MT MIATA	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	10 99 BP AT MIATA	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
		PCM		√	√	√	√		

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
1999- VIN#10:X	11 99 JE AT MPV	ABS		√	√				
		CCM		√	√				
	12 99 KL AT MILLENIA	PCM		√	√	√	√		
		A/C		√	√				
		ABS		√	√				
		CCM		√	√				
		PCM		√	√	√	√		
	13 99 KJ AT MILLENIA	A/C		√	√				
		ABS		√	√				
		CCM		√	√				
		PCM		√	√	√	√		
	14 99 KL AT MILLENIA(NEW ABS)	A/C		√	√				
		ABS		√	√	√	√		
		CCM		√	√				
		PCM		√	√	√	√		
	15 99 KJ AT MILLENIA(NEW ABS)	A/C		√	√				
		ABS		√	√	√	√		
		CCM		√	√				
		PCM		√	√	√	√		
	16 99 2.5L AT B2500	ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		PATS		√	√	√			
		RAP	√	√	√	√	√		
		RCM	√	√	√	√	√		
		PCM		√	√	√			
	17 99 2.5L MT B2500	ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		PATS		√	√	√			
		PCM		√	√	√			

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
		RAP	√	√	√	√	√		
		RCM	√	√	√	√	√		
	18 99 3.0L AT B3000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		PATS		√	√	√			
		RAP	√	√	√	√	√		
		RCM	√	√	√	√	√		
	19 99 3.0L MT B3000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		PATS		√	√	√			
		RAP	√	√	√	√	√		
		RCM	√	√	√	√	√		
	20 99 4.0L AT B4000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		PATS		√	√	√			
		RAP	√	√	√	√	√		
		RCM	√	√	√	√	√		
	21 99 4.0L MT B4000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		PATS		√	√	√			
		RAP	√	√	√	√	√		
		RCM	√	√	√	√	√		
	1 98 Z5 MT PROTEGE	PCM		√	√	√	√		
		ABS		√	√				

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
1998- VIN#10:	2 98 Z5 ECAT PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
	3 98 BP MT PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	4 98 BP ECAT PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	5 98 FS MT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	6 98 FS ECAT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	7 98 KL MT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	8 98 KL ECAT 626	PCM		√	√	√			
		ABS		√	√	√	√		
	9 98 JE ECAT MPV	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	10 98 KL ECAT MILLENIA	PCM		√	√	√	√		
		A/C		√	√				
		ABS		√	√				
		CCM		√	√				
	11 98 KJ ECAT MILLENIA	PCM		√	√	√	√		
		A/C		√	√				
		ABS		√	√				
		CCM		√	√				
		PCM		√	√	√			

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
W	12 98 2.5L AT B2500	ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	13 98 2.5L MT B2500	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	14 98 3.0L AT B3000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	15 98 3.0L MT B3000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	16 98 4.0L AT B4000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	17 98 4.0L MT B4000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
		RAP	√	√	√	√	√		
	1 97 Z5 MT 323/PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
	2 97 Z5 ECAT 323/PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
	3 97 BP MT 323/PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
	4 97 BP ECAT 323/PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
	5 97 FS MT 626/MX-6	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	6 97 FS ECAT 626/MX-6	PCM		√	√	√			
		ABS		√	√				
		CCM		√	√				
	7 97 KL MT 626/MX-6	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	8 97 KL ECAT 626/MX-6	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	9 97 BP MT MIATA	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	10 97 BP ECAT MIATA	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
		PCM		√	√	√	√		

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
1997- VIN#10:V	11 97 JE ECAT MPV	ABS		√	√				
		CCM		√	√				
	12 97 KL ECAT MILLENIA	PCM		√	√	√	√		
		A/C		√	√				
		ABS		√	√				
		CCM		√	√				
	13 97 KJ ECAT MILLENIA	PCM		√	√	√	√		
		A/C		√	√				
		ABS		√	√				
		CCM		√	√				
	14 97 2.3L AT B2300	PCM		√	√	√			
		ABS		√	√				
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	15 97 2.3L MT B2300	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	16 97 3.0L AT B3000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	17 97 3.0L MT B3000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	18 97 4.0L AT B4000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	19 97 4.0L AT B4000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	1 96 Z5 MT 323/PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	2 96 Z5 ECAT 323/PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	3 96 BP MT 323/PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	4 96 BP ECAT 323/PROTEGE	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	5 96 FS MT 626/MX-6	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
		PCM		√	√	√			

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
1996- VIN#10:T	6 96 FS ECAT 626/MX-6	ABS		√	√				
		CCM		√	√				
	7 96 KL MT 626/MX-6	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	8 96 KL ECAT 626/MX-6	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
	9 96 ECAT 929	PCM		√	√	√	√		
		A/C		√	√				
		ABS		√	√				
		CCM		√	√				
	10 96 BP MT MIATA	PCM		√	√	√	√		
		ABS		√	√				
	11 96 BP ECAT MIATA	PCM		√	√	√	√		
		ABS		√	√				
	12 96 B6 MT MX-3	PCM		√	√	√	√		
		ABS		√	√				
	13 96 B6 ECAT MX-3	PCM		√	√	√	√		
		ABS		√	√				
	14 96 K8 MT MX-3	PCM		√	√	√	√		
		ABS		√	√				
	15 96 K8 ECAT MX-3	PCM		√	√	√	√		
		ABS		√	√				
	16 96 JE ECAT MPV	PCM		√	√	√	√		
		ABS		√	√				
		CCM		√	√				
		P CM		√	√	√	√		

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	17 96 KL ECAT MILLENIA	A/C		√	√				
		ABS		√	√				
		CCM		√	√				
	18 96 KJ ECAT MILLENIA	PCM		√	√	√	√		
		A/C		√	√				
		ABS		√	√				
		CCM		√	√				
	19 96 2.3L AT B2300	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	20 96 2.3L MT B2300	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	21 96 3.0L AT B3000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	22 96 3.0L MT B3000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
		PCM		√	√	√			

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	23 96 4.0L AT B4000	ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	24 96 4.0L MT B4000	PCM		√	√	√			
		ABS		√	√	√	√		
		GEM	√	√	√	√	√		
		IABM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	1 95 Z5 MT 323/PROTEGE	PCM		√	√				
		ABS		√	√				
		CCM		√	√				
	2 95 Z5 ECAT 323/PROTEGE	PCM		√	√				
		ABS		√	√				
		CCM		√	√				
	3 95 BP MT 323/PROTEGE	PCM		√	√				
		ABS		√	√				
		CCM		√	√				
	4 95 BP ECAT 323/PROTEGE	PCM		√	√				
		ABS		√	√				
		CCM		√	√				
	5 95 FS MT 626/MX-6	PCM		√	√				
		ABS		√	√				
		CCM		√	√				
	6 95 FS ECAT 626/MX-6	PCM		√	√				
		ABS		√	√				
		CCM		√	√				
		PCM		√	√				

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
1995- VIN#10:S	7 95 KL 626/MX-6	ABS		√	√				
		CCM		√	√				
		TCM		√	√				
	8 95 ALL 929	PCM		√	√				
		A/C		√	√				
		ABS		√	√				
		CCM		√	√				
		TCM		√	√				
	9 95 B6 MX-3	PCM		√	√				
		ABS		√	√				
		TCM		√	√				
	10 95 K8 MX-3	PCM		√	√				
		ABS		√	√				
		T CM		√	√				
	11 95 ALL MIATA	PCM		√	√				
		ABS		√	√				
		TCM		√	√				
	12 95 ALL RX-7	PCM		√	√				
		ABS		√	√				
		CCM		√	√				
		TCM		√	√				
	13 95 G6 MPV	PCM		√	√				
	14 95 JE MPV	PCM		√	√				
		TCM		√	√				
	15 95 KL MILLENIA	PCM		√	√				
		A/C		√	√				
		ABS		√	√				
		CCM		√	√				

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	16 95 KJ MILLENIA	PCM		√	√				
		A/C		√	√				
		ABS		√	√				
		CCM		√	√				
	17 95 2.3L AT B2300	PCM		√	√	√			
		ABS		√	√	√			
		GEM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	18 95 2.3L MT B2300	PCM		√	√	√			
		ABS	√	√	√	√	√		
		GEM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	19 95 3.0L AT B3000	PCM		√	√	√			
		ABS	√	√	√	√	√		
		GEM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	20 95 3.0L MT B3000	PCM		√	√	√			
		ABS	√	√	√	√	√		
		GEM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	21 95 4.0L AT B4000	PCM		√	√	√			
		ABS	√	√	√	√	√		
		GEM	√	√	√	√	√		
		RAP	√	√	√	√	√		
	22 95 4.0L MT B4000	PCM		√	√	√			
		ABS	√	√	√	√	√		
		GEM	√	√	√	√	√		
		RAP	√	√	√	√	√		

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
1994- VIN#10:R	1 94 ALL 323/PROTEGE	PCM		√	√				
		TCM		√	√				
	2 94 FS MT 626/MX-6	PCM		√	√				
		ABS		√	√				
		CCM		√	√				
	3 94 FS ECAT 626/MX-6	PCM		√	√				
		ABS		√	√				
		C CM		√	√				
	4 94 KL 626/MX-6	PCM		√	√				
		ABS		√	√				
		CCM		√	√				
		TCM		√	√				
	5 94 ALL 929	PCM		√	√				
		A/C		√	√				
		CCM		√	√				
		TCM		√	√				
	6 94 B6 MX-3	PCM		√	√				
		ABS		√	√				
		TCM		√	√				
	7 94 K8 MX-3	PCM		√	√				
		ABS		√	√				
		TCM		√	√				
	8 94 ALL MIATA	PCM		√	√				
		TCM		√	√				
	9 94 ALL RX-7	PCM		√	√				
		CCM		√	√				
		TCM		√	√				
	10 94 G6 MPV	PCM		√	√				

Mazda **V34.60** Diagnostics List (Note: For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
	10 94 3.0L MPV	TCM		√	√				
	11 94 JE MPV	PCM		√	√				
		TCM		√	√				
	12 94 4.0L NAVAJO	PCM		√	√				
		ABS		√	√				
	13 94 2.3L 49S B2300	PCM		√	√				
	14 94 2.3L CAL B2300	PCM		√	√				
	15 94 3.0L B3000	PCM		√	√				
	16 94 4.0L 49S B4000	PCM		√	√				
	17 94 4.0L CAL B4000	PCM		√	√				
1993- VIN#10:P	93 ALL VEHICLES EXCEPT NAVAJO	PC M		√	√				
		A/C		√	√				
		ABS		√	√				
		CCM		√	√				
		TCM		√	√				
	93 4.0L 49S NAVAJO	PCM		√	√				
		ABS		√	√				
	93 4.0L CAL NAVAJO	PCM		√	√				
		ABS		√	√				
1992- VIN#10:N	92 ALL VEHICLES EXCEPT NAVAJO	PCM		√	√				
		A/C		√	√				
		ABS		√	√				
		CCM		√	√				
		TCM		√	√				
1991- VIN#10:M	91 ALL VEHICLES EXCEPT NAVAJO	PCM		√	√				
		TCM		√	√				
1990- VIN#10:L	90 ALL VEHICLES	PCM		√	√				
		TCM		√	√				

Mazda **V34.60** Diagnostics List (Note:For reference only)

Menu			Functions						
Year	Vehicle	System	Sys. Info.	Read code	Clear code	Data stream	Actuation	Special Functions	Others
1989-VIN#10:K	89 ALL VEHICLES	PCM		√	√				
		TCM		√	√				
1988-VIN#10:J	88 ALL VEHICLES	PCM		√	√				
		TCM		√	√				

(*):Tested;

(?):Manual on website(www.x431.com)

Note:All description rights reserved by LAUNCH TECH.CO.,LTD

CONNECTOR	X431	DIAGUN
SMART OBD	N/A	N/A
MAZDA 17	Use for the cars of 17-PIN Diagnostic socket	N/A
OBD 16C	N/A	N/A
CANBUS II	Use for the cars of 16-PIN Diagnostic socket	N/A
diagun connector	N/A	Use for the cars of 16-PIN Diagnostic socket
SUPER 16	Use for the cars of 16-PIN Diagnostic socket	N/A