

Renault **V37.50** Diagnostics List

(Note:For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
TWINGO	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√	√			
TWINGO phase 2	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√	√			
MODUS	Injection	√	√	√	√	√			
	a.b.s	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	variable p.a.s	√	√	√	√		√		
	instrument panel	√	√	√	√	√	√		
	airbag/pretensioners	√	√	√	√		√		
	UPC	√	√	√	√		√		
	UCH	√	√	√	√	√	√		
CLIO	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	automatic gearbox	√	√	√	√	√			

Renault **V37.50** Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
	engine immobiliser	√	√	√	√	√			√
	airbag/pretensioners	√	√	√	√	√			
CLIO 2	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	diesel injection	√	√	√	√	√	√	√	√
	interconnection unit	√	√	√	√	√	√		
	airbag/pretensioners	√	√	√	√	√			
CLIO II PH 2/3/4	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√		√	
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	diesel injection	√	√	√	√	√	√	√	√
	interconnection unit	√	√	√	√	√	√	√	
	airbag/pretensioners	√	√	√	√	√	√	√	
	discharge lamp	√	√	√	√	√			
CLIO III	Injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	variable p.a.s	√	√	√	√		√		
	instrument panel	√	√	√	√	√			

Renault **V37.50** Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
	airbag/pretensioners	√	√	√	√		√	√	
	UPC	√	√	√	√	√			
	UCH	√	√	√	√	√			
	LIGHTING	√	√	√	√	√	√	√	
THALIA/SYMBL	petrol injection	√	√	√	√	√			
	diesel injection	√	√	√	√	√			
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				
CLIO V6	petrol injection	√	√	√	√	√			
	air conditioning	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√	√			
CLIO V6 PH 2	petrol injection	√	√	√	√	√			
	air conditioning	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	interconnection unit	√	√	√	√	√			
	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√			
	air conditioning	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			

Renault **V37.50** Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
MEGANE/SCENIC	engine immobiliser	√	√	√	√	√		√	√
	diesel injection	√	√	√	√		√	√	√
	interconnection unit	√	√	√	√	√		√	
	airbag/pretensioners	√	√	√	√		√		√
	hood control	√	√	√	√	√			
	tyres	√	√	√	√	√	√	√	
MEGANE II	Injection	√	√	√	√	√			
	air conditioning	√	√	√	√		√	√	
	a.b.s	√	√	√	√	√			
	variable p.a.s	√	√	√	√				
	instrument panel	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√		√	√	
	uch	√	√	√	√	√			
	upc	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√	√		
	sunroof	√	√	√	√	√	√	√	
SCENIC II	Injection	√	√	√	√	√	√		
	air conditioning	√	√	√	√		√	√	
	a.b.s	√	√	√	√	√			
	variable p.a.s	√	√	√	√				
	instrument panel	√	√	√	√		√	√	
	airbag/pretensioners	√	√	√	√	√	√	√	
	upc	√	√	√	√	√	√		
	parking brake	√	√	√	√	√			
	parking assis	√	√		√	√	√	√	

Renault **V37.50** Diagnostics List

(Note:For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
	uch	√	√	√	√	√	√	√	
LAUGNA	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√			
	air conditioning	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√			
	instrument panel	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	diesel injection	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√	√			√
LAGUNA phae 2	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√			
	air conditioning	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√			
	instrument panel	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√		√	
	engine immobiliser	√	√	√	√	√			
	diesel injection	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				
LAGUNA II	injection	√	√	√	√	√	√		√
	a.b.s	√	√	√	√	√			
	air conditioning	√	√	√	√	√		√	
	instrument panel	√	√	√	√	√		√	
	automatic gearbox	√	√	√	√	√		√	
	UCH	√	√	√	√	√			

Renault **V37.50** Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
	airbag/pretensioners	√	√	√	√		√		√
	discharge lamp	√	√	√	√	√		√	
	parking assistance	√	√	√	√				
	heater	√	√	√	√	√			
LAGUNA II PH2	injection	√	√	√	√	√	√	√	
	a.b.s	√	√	√	√	√	√	√	
	air conditioning	√	√	√	√	√	√	√	
	instrument panel	√	√	√	√	√	√	√	
	automatic gearbox	√	√	√	√	√		√	
	uch	√	√	√	√	√	√	√	
	airbag/pretensioners	√	√	√	√	√	√	√	
	parking brake	√	√	√	√	√	√	√	
	lighting	√	√	√	√	√	√		
	parking assistance	√	√	√	√				
SAFRANE	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√			
	instrument panel	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				
	door management	√	√	√	√	√			
	discharge lamp	√	√	√	√	√			
	petrol injection	√	√	√	√	√	√		

Renault **V37.50** Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
VEL SATIS	diesel injection	√	√	√	√	√	√	√	
	a.b.s	√	√	√	√	√			
	air conditioning	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√			
	instrument panel	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				
	door management	√	√	√	√	√			
	discharge lamp	√	√	√	√	√			
	tyres	√	√	√	√	√			
	heat	√	√	√	√	√			
	parking assistance	√	√	√	√				
	parking brake	√	√	√	√	√			
AVANTIME	petrol injection	√	√	√	√	√	√		
	diesel injection	√	√	√	√	√	√	√	
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	instrument panel	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				
	heat	√	√	√	√	√			

Renault **V37.50** Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
	discharge lamp	√	√	√	√	√			
ESPACE	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	instrument panel	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	diesel injection	√	√	√	√	√	√	√	
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				
	door management	√	√	√	√	√			
	heat	√	√	√	√	√			
	discharge lamp	√	√	√	√	√			
ESPACE IV	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√	√	√	
	air conditioning	√	√	√	√	√	√	√	
	variable p.a.s	√	√	√	√	√	√		
	instrument panel	√	√	√	√	√	√	√	
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√	√	√	
	diesel injection	√	√	√	√	√			√
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√		√	√	
	door management	√	√	√	√	√			
	discharge lamp	√	√	√	√	√			

Renault **V37.50** Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
	tyres	√	√	√	√	√			
	parking assistance	√	√	√	√				
	heat	√	√	√	√	√			
	lighting	√	√	√	√	√	√	√	
	hands free kit	√	√	√	√	√	√	√	
	parking brake	√	√	√	√	√	√	√	
KANGOO	petrol injection	√	√	√	√	√	√	√	
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	diesel injection	√	√	√	√	√	√	√	√
	interconnection unit	√	√	√	√	√			
	heat	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√		√		√
KANGOO MUX	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	diesel injection	√	√	√	√	√	√	√	√
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√		√		√
TRAFIC	airbag/pretensioners	√	√	√	√				
	petrol injection	√	√	√	√	√	√		
	diesel injection	√	√	√	√	√	√	√	

Renault **V37.50** Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
	engine immobiliser	√	√	√	√	√			
TRAFIC II	airbag/pretensioners	√	√	√	√				
	petrol injection	√	√	√	√	√	√		
	diesel injection	√	√	√	√	√	√	√	
	a.b.s	√	√	√	√				
	engine immobiliser	√	√	√	√	√			
	interconnection unit	√	√	√	√	√	√		
	heat	√	√	√	√	√			
MASTER	airbag/pretensioners	√	√	√	√				
	diesel injection	√	√	√	√	√	√	√	
	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	interconnection unit	√	√	√	√	√		√	
	engine immobiliser	√	√	√	√	√		√	
MASTER PH 2	diesel injection	√	√	√	√	√	√	√	
	a.b.s	√	√	√	√	√		√	
	interconnection unit	√	√	√	√	√	√	√	
	engine immobiliser	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√	√	√	√	
	UCH	√	√	√	√	√	√		
MASTER RWD	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				
	engine immobiliser	√	√	√	√	√			
	interconnection unit	√	√	√	√	√			

Renault **V37.50** Diagnostics List (Note:For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
MASCOTT	airbag/pretensioners	√	√	√	√				
	engine immobiliser	√	√	√	√	√			
SPIDER	engine immobiliser	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				
	petrol injection	√	√	√	√	√			
SUPER 5	petrol injection	√	√	√	√	√	√		
EXTRA	airbag/pretensioners	√	√	√	√				
	engine immobiliser	√	√	√	√	√			
	petrol injection	√	√	√	√	√	√		
	automatic gearbox	√	√	√	√	√			
R19	engine immobiliser	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
R21/SAVANNA	petrol injection	√	√	√	√	√	√		
R25	petrol injection	√	√	√	√	√	√		
ALPINE	petrol injection	√	√	√	√	√	√		

(*):Tested;

(?):Manual on website(www.x431.com)

Note:All description rights reserved by LAUNCH TECH.CO.,LTD

CONNECTOR	X431	DIAGUN
OBD 16C	Follow the connector indication in the software	N/A
CANBUS II	Follow the connector indication in the software	N/A
DIAGUN CONNECTOR	N/A	All 16pin DLC
SUPER 16	All 16pin DLC	N/A