

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	ALTO	ENGINE	HA12S	F6A-NA	98.10 -- 00.12	√	√	√	√			
				F6A-TURBO	99.10 -- 00.12	√	√	√	√			
					98.10 -- 00.12	√	√	√	√			
			HA12V	F6A-NA	99.10 -- 00.12	√	√	√	√			
			HA22S	K6A-TURBO	98.10 -- 00.12	√	√	√	√			
						√	√	√	√			
				K6A-NA-リ-ンパ- ン	98.10 -- 01.04	√	√	√	√			
				K6A-TURBO-VVT	98.10 -- 99.10	√	√	lis	√			
				K6A-NA	98.10 -- 99.10	√	√	√	√			
						√	√	√	√			
				K6A-NA-VVT	99.10 -- 00.12	√	√	√	√			
						√	√	√	√			
			HA23S	K6A-NA	00.12 --	√	√	√	√	√		
				K6A-NA-VVT	00.12 -- 02.04	√	√	√	√	√		
				K6A-NA-リ-ンパ- ン	01.04 --	√	√	√	√	√		
				K6A-NA-VVT U-LEV	02.04 -- 03.06	√	√	√	√			
						√	√	√	√	√		
			HA23V	K6A-NA	00.12 --	√	√	√	√	√		
				K6A-NA-VVT U-LEV	02.04 -- 03.06	√	√	√	√	√		
						√	√	√	√	√		
		A/T	HA22S(Only 2WD)		99.10 -- 00.12	√	√	√	√			
			HA12V		98.10 -- 99.10	√	√	√	√			
			HA22S		99.05 -- 01.04	√	√	√	√			
			HA23S		01.04 -- 01.06	√	√	√	√			
			HA12V		98.10 -- 00.12	√	√	√	√			
			HA12S		98.10 -- 01.04	√	√	√	√			

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
		ABS	HA22S		98.10 -- 01.04	√	√	√	√			
			HA23V		00.12 --	√	√	√	√	√		
			HA23S		00.12 --	√	√	√	√	√		
		SRS	HA12V		98.10 -- 00.12	√	√	√	√			
			HA12S		98.10 -- 01.04	√	√	√	√			
			HA22S		98.10 -- 01.04	√	√	√	√			
			HA23V		00.12 --	√	√	√	√			
			HA23S		00.12 --	√	√	√	√			
	JIMNY	ENGINE	JB23W	K6A-TURBO	98.10 -- 99.10	√	√	√	√			
					99.10 -- 02.01	√	√	√	√			
					02.01 --	√	√	√	√	√		
		A/T	JB23W		98.10 --	√	√	√	√			
		ABS	JB23W		98.10 -- 00.04	√	√	√	√			
					00.04 --	√	√	√	√	√		
		SRS	JB23W		98.10 --	√	√	√	√			
	JIMNY WIDE	ENGINE	JB33W	G13B	98.01 -- 00.04	√	√	√	√			
			JB43W	M13A-NA-VVT	00.04 --	√	√	√	√	√		
		A/T	JB33W		98.01 -- 00.04	√	√	√	√			
			JB43W		00.04 --	√	√	√	√			
		ABS	JB33W		98.01 -- 00.04	√	√	√	√			
			JB43W		00.04 --	√	√	√	√	√		
		SRS	JB33W		98.10 -- 00.04	√	√	√	√			
			JB43W		00.04 --	√	√	√	√			
	JIMNY 1300 SIERRA	ABS	JB32W		96.09 -- 98.01	√	√	√	√			

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	JIMNY 660	ABS			96.09 -- 98.10	√	√	√	√			
			HN21S	K6A-TURBO	98.10 -- 01.04	√	√	√	√			
				K6A-TURBO	98.10 -- 01.04(4WD)	√	√	√	√			
				K6A-TURBO	98.10 -- 99.10(2WD)	√	√	√	√			
				K6A-NA	98.10 -- 99.03	√	√	√	√			
				K6A-NA-VVT	00.10 -- 01.04	√	√	√	√	√		
				K6A-TURBO-NS control	99.10 -- 01.04(2WD)	√	√	√	√			
				K6A-NA-VVT	00.10 -- 01.04	√	√	√	√			
			HN11S	F6A-TURBO	98.10 -- 01.04	√	√	√	√			
				F6A-TURBO	98.10 -- 99.10	√	√	√	√			
				F6A-TURBO	99.10 -- 01.04	√	√	√	√			
			HN12S	F6A-TURBO	01.04 -- 01.11	√	√	√	√			
				F6A-TURBO	01.04 -- 01.11	√	√	√	√	√		
		ENGINE		K6A-NA-VVT	01.04 -- 01.11	√	√	√	√	√		
				K6A-NA-VVT	01.04 -- 01.11	√	√	√	√	√		
				K6A-TURBO	01.04 -- 01.11	√	√	√	√	√		
				K6A-TURBO	01.04 -- 01.11(4WD)	√	√	√	√	√		
				K6A-TURBO-NS control	01.04 -- 01.11(2WD)	√	√	√	√	√		
				K6A-NA-VVT	01.11 -- 02.11	√	√	√	√	√		
				K6A-NA-VVT	01.11 -- 02.04	√	√	√	√	√		

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	Kei		HN22S	K6A-M TURBO	01.11 --	√	√	√	√	√		
				K6A-TURBO	01.11 --	√	√	√	√	√		
				K6A-M TURBO	01.11 -- 03.05	√	√	√	√	√		
				K6A-TURBO	01.11 -- 03.05	√	√	√	√	√		
				K6A-TURBO anti-alip control(2WD)	01.11 -- 03.05	√	√	√	√	√		
				K6A-NA-VVT U-LEV	02.04 -- 03.06(2WD)	√	√	√	√	√		
				K6A-NA-VVT U-LEV	02.11 -- (2WD)	√	√	√	√	√		
				K6A-M TURBO	03.05 --	√	√	√	√	√		
				K6A-TURBO	03.05 --	√	√	√	√	√		
				K6A-TURBO anti-alip control(2WD)	03.05 --	√	√	√	√	√		
				K6A-NA-VVT U-LEV	03.06 -- (2WD)	√	√	√	√	√		
		A/T	HN11S		99.03 -- 99.10	√	√	√	√			
		ABS	HN11S		00.10 -- 01.04	√	√	√	√	√		
			HN21S		00.10 -- 01.04	√	√	√	√	√		
			HN12S		01.04 --	√	√	√	√	√		
			HN22S		01.04 --	√	√	√	√	√		
			HN11S		98.10 -- 00.10	√	√	√	√			
			HN21S		98.10 -- 00.10	√	√	√	√			
			HN22S		01.04 --	√	√	√	√	√		

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
		SRS	HN11S		98.10 -- 01.04	√	√	√	√			
			HN21S		98.10 -- 01.04	√	√	√	√			
			HN12S		01.04 --	√	√	√	√			
			HN22S		01.04 --	√	√	√	√			
		EMCD	HN22S		02.11 -- 03.03	√	√	√	√			
			MC11S	F6A-NA	98.10 -- 99.10	√	√	√	√			
				F6A-TURBO	98.10 -- 00.12	√	√	√	√			
				F6A-TURBO	98.10 -- 00.12	√	√	√	√			
				F6A-TURBO	99.10 -- 00.12	√	√	√	√			
			MC21S	K6A-NA	98.10 -- 99.10	√	√	√	√			
				K6A-NA-VVT	98.10 -- 00.12	√	√	√	√			
				K6A-TURBO	98.10 -- 00.12	√	√	√	√			
				K6A-TURBO-NS control	98.10 -- 99.10	√	√	√	√			
				K6A-NA-VVT	99.04 -- 00.12	√	√	√	√			
				K6A-TURBO	99.10 -- 00.12	√	√	√	√			
				K6A-TURBO-NS control	99.10 -- 00.12	√	√	√	√			
			MC11S repit	F6A-NA-CNG	99.07 -- 01.03	√	√	√	√			
			MC12S	F6A-TURBO	00.12 -- 01.11	√	√	√	√			
				F6A-TURBO	00.12 -- 01.11	√	√	√	√	√		
				K6A-NA-VVT	00.12 -- 01.11	√	√	√	√	√		
				K6A-NA-VVT	00.12 -- 01.11	√	√	√	√	√		
				K6A-TURBO	00.12 -- 01.11	√	√	√	√	√		
				K6A-TURBO	00.12 -- 01.11(4WD)	√	√	√	√	√		

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	WAGON R	ENGINE	MC22S	K6A-TURBO-NS control	00.12 -- 01.11(2WD)	√	√	√	√	√		
				K6A-NA-VVT	01.11 -- (4WD)	√	√	√	√	√		
				K6A-NA-VVT	01.11 -- 02.09(2WD)	√	√	√	√	√		
				K6A-NA-VVT	01.11 -- 03.06(4WD)	√	√	√	√	√		
				K6A-NA-VVT	01.11 -- 02.04(2WD)	√	√	√	√	√		
				K6A-M TURBO	01.11 -- 03.05	√	√	√	√	√		
				K6A-TURBO	01.11 -- 03.05	√	√	√	√	√		
				K6A-TURBO anti-alip control(2WD)	01.11 -- 03.05	√	√	√	√	√		
				K6A-NA-VVT U-LEV	02.04 -- (2WD)	√	√	√	√	√		
				K6A-NA-VVT U-LEV	02.04 -- 03.06(2WD)	√	√	√	√	√		
				K6A-NA-VVT U-LEV	02.09 -- (2WD)	√	√	√	√	√		
				K6A-NA(无VVT) U-LEV	02.09 -- (2WD)	√	√	√	√	√		
				K6A-HEV anti-alip control additional locking function	02.09 -- (2WD)	√	√	√	√	√		

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
				K6A-M TURBO	03.05 --	√	√	√	√	√		
				K6A-TURBO	03.05 --	√	√	√	√	√		
				K6A-TURBO anti-alip control(2WD)	03.05 --	√	√	√	√	√		
				K6A-NA-VVT	03.06 -- (4WD)	√	√	√	√	√		
				K6A-NA-VVT U-LEV	03.06 -- (2WD)	√	√	√	√	√		
			MC22S repit	K6A-NA-VVT-CNG	01.03 -- 03.05	√	√	√	√	√		
				K6A-NA-VVT-CNG	03.06 --	√	√	√	√	√		
		A/T	MC21S		98.10 -- 99.10	√	√	√	√			
					98.10 -- 01.06	√	√	√	√			
		ABS	MC11S		98.10 -- 00.12	√	√	√	√			
			MC21S		98.10 -- 00.12	√	√	√	√			
			MC12S		00.12 --	√	√	√	√	√		
			MC22S		00.12 --	√	√	√	√	√		
		SRS	MC11S		98.10 -- 00.12	√	√	√	√			
			MC21S		98.10 -- 00.12	√	√	√	√			
			MC12S		00.12 --	√	√	√	√			
			MC22S		00.12 --	√	√	√	√			
					01.05 --	√	√	√	√			
			DA52V	F6A-NA	99.01 -- 01.09	√	√	√	√			
				F6A-TURBO	99.01 -- 01.09	√	√	√	√			
				F6A-TURBO	99.01 -- 01.09	√	√	√	√			
				F6A-NA	99.01 -- 01.09	√	√	√	√			

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
EVERY		ENGINE	DB52V	F6A-TURBO	99.01 -- 01.09	√	√	√	√			
				F6A-TURBO	99.01 -- 01.09	√	√	√	√			
			DA52V repit	F6A-NA-CNG	99.12 -- 01.11	√	√	√	√			
			DA62V	K6A-NA	01.09 --	√	√	√	√	√		
				K6A-TURBO	01.09 -- (MT)	√	√	√	√	√		
				K6A-TURBO	01.09 -- 03.06(AT)	√	√	√	√	√		
				K6A-TURBO	03.06 -- (AT)	√	√	√	√	√		
			DA62V repit	K6A-NA-CNG	01.11 --	√	√	√	√	√		
				K6A-NA-CNG	01.11 --	√	√	√	√	√		
		A/T	DA52V		99.11 -- 01.09	√	√	√	√			
			DB52V		99.11 -- 01.09	√	√	√	√			
			DA62V		01.09 --	√	√	√	√			
		ABS	DA52V		99.11 -- 01.09	√	√	√	√			
			DB52V		99.11 -- 01.09	√	√	√	√			
			DA62V		01.09 --	√	√	√	√	√		
		SRS	DA52V	two seats airbag	00.05 -- 01.09	√	√	√	√			
			DB52V	and two seats	00.05 -- 01.09	√	√	√	√			
			DA62V	pretensioner	01.09 --	√	√	√	√			
			DA52V	driver seat airbag	99.01 -- 00.05	√	√	√	√			
			DB52V	or two seats airbag	99.01 -- 00.05	√	√	√	√			
		ENGINE	DA52T	F6A-NA	99.01 -- 01.09	√	√	√	√			
				F6A-TURBO	99.01 -- 01.09	√	√	√	√			
						√	√	√	√			
			DB52T	F6A-NA	99.01 -- 01.09	√	√	√	√			
				F6A-TURBO	99.01 -- 01.09	√	√	√	√			

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	CARRY					√	√	√	√			
			DA62T	K6A-NA	01.09 -- 02.04	√	√	√	√	√		
				K6A-TURBO	01.09 -- 02.05	√	√	√	√	√		
			DA63T	K6A-NA	02.05 --	√	√	√	√	√		
		ABS	DA52T		00.05 -- 01.09	√	√	√	√	√		
			DB52T		00.05 -- 01.09	√	√	√	√	√		
		SRS	DA52T	two seats airbag and two seats pretensioner	00.05 -- 01.09	√	√	√	√			
			DB52T		00.05 -- 01.09	√	√	√	√			
			DA62T		01.09 -- 02.04	√	√	√	√			
			DA63T		02.05 --	√	√	√	√			
			DA52T	driver seat airbag or two seats airbag	99.01 -- 00.05	√	√	√	√			
			DB52T		99.01 -- 00.05	√	√	√	√			
	EVERY WAGON	ENGINE	DA52W	F6A-TURBO	99.06 -- 01.09(MT)	√	√	√	√			
				F6A-TURBO	99.06 -- 01.09(3AT)	√	√	√	√			
			DA62W	K6A-NA	01.09 --	√	√	√	√	√		
				K6A-TURBO	01.09 -- (MT)	√	√	√	√	√		
				K6A-TURBO	01.09 -- 03.06(AT)	√	√	√	√	√		
				K6A-TURBO	03.06 -- (AT)	√	√	√	√	√		
		A/T	DA52W		99.11 -- 01.09	√	√	√	√			
			DA62W		01.09 --	√	√	√	√	√		
		ABS	DA52W		99.11 -- 01.09	√	√	√	√			
			DA62W		01.09 --	√	√	√	√	√		

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
JAPAN	MR WAGON	ENGINE	MF21S	K6A-NA-VVT	01.12 -- 03.06(4WD)	√	√	√	√	√		
				K6A-NA-VVT	01.12 -- 02.04(2WD)	√	√	√	√	√		
				K6A-M TURBO	01.12 -- 03.05	√	√	√	√	√		
				K6A-TURBO	02.06 -- 03.05	√	√	√	√	√		
				K6A-TURBO anti-alip control(2WD)	02.06 -- 03.05	√	√	√	√	√		
				K6A-NA-VVT U-LEV	02.04 -- (2WD)	√	√	√	√	√		
				K6A-NA-VVT U-LEV	02.04 -- 03.06(2WD)	√	√	√	√	√		
				K6A-M TURBO	03.05 --	√	√	√	√	√		
				K6A-TURBO		√	√	√	√	√		
				K6A-TURBO anti-alip control(2WD)	03.05 --	√	√	√	√	√		
				K6A-NA-VVT	03.06 -- (4WD)	√	√	√	√	√		
				K6A-NA-VVT U-LEV	03.06 -- (2WD)	√	√	√	√	√		
		ABS	MF21S		01.12 --	√	√	√	√	√		
				two seats airbag and two seats pretensioner	01.12 --	√	√	√	√			

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
		SRS	MF21S	two seats airbag and two seats pretensioner and driver seat CRD	01.07 --	√	√	√	√			
	LAPIN	ENGINE	HE21S	K6A-NA-VVT	02.01 -- 03.06(4WD)	√	√	√	√	√		
				K6A-NA-VVT	02.01 -- 02.04(2WD)	√	√	√	√	√		
				K6A-M TURBO	02.10 -- 03.05	√	√	√	√	√		
				K6A-NA-VVT U-LEV	02.04 -- (2WD)	√	√	√	√	√		
				K6A-NA-VVT U-LEV	02.04 -- 03.06(2WD)	√	√	√	√	√		
				K6A-M TURBO	03.05 --	√	√	√	√	√		
				K6A-TURBO	03.05 --	√	√	√	√	√		
				K6A-NA-VVT	03.06 -- (4WD)	√	√	√	√	√		
				K6A-NA-VVT U-LEV	03.06 -- (2WD)	√	√	√	√	√		
		ABS	HE21S		02.01 --	√	√	√	√	√		
		SRS	HE21S		02.01 --	√	√	√	√			
			EC22S	K6A-NA-VVT U-LEV	03.01 --	√	√	√	√	√		
				K6A-NA(no VVT) U-LEV	03.01 --	√	√	√	√	√		

Suzuki V26.10 Diagnostics List (Note:For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	TWIN	ENGINE		K6A-HEV anti-alip control additional locking function	03.01 --	√	√	√	√	√		
			EC22S改装	K6A-NA-VVT U-LEV	03.01 --	√	√	√	√	√		
				K6A-NA(no VVT) U-LEV	03.01 --	√	√	√	√	√		
				K6A-HEV anti-alip control additional locking function	03.01 --	√	√	√	√	√		
		ABS	EC22S		03.01 --	√	√	√	√	√		
		SRS	EC22S		03.01 --	√	√	√	√			
			TA01W	G16A	96.02 -- 96.10	√	√	√	√			
					96.10 -- 97.11(OnlyMT)	√	√	√	√			
					96.10 -- 97.11(OnlyAT)	√	√	√	√			
			TA01R	G16A	96.02 -- 96.10	√	√	√	√			
					96.10 -- 97.11(OnlyMT)	√	√	√	√			
					96.10 -- 97.11(OnlyAT)	√	√	√	√			
			TD01W	G16A	96.02 -- 96.10	√	√	√	√			
					96.10 -- 97.11(OnlyMT)	√	√	√	√			

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	ESCUDO	ENGINE	TA11W	H20A	96.10 -- 97.11(OnlyAT)	√	√	√	√			
					96.02 -- 96.10(OnlyAT)	√	√	√	√			
					96.02 -- 96.10(OnlyAT)	√	√	√	√			
			TD11W	H20A	96.02 -- 96.10(OnlyAT)	√	√	√	√			
					96.02 -- 96.10(OnlyAT)	√	√	√	√			
			TA51W	J20A	96.10 -- 97.11(OnlyAT)	√	√	√	√			
					96.10 -- 97.11(OnlyAT)	√	√	√	√			
					97.11 -- 00.04	√	√	√	√			
			TD51W	J20A	96.10 -- 97.11(OnlyAT)	√	√	√	√			
					96.10 -- 97.11(OnlyAT)	√	√	√	√			
					97.11 -- 00.04	√	√	√	√			
			TD61W	H25A	96.10 -- 98.03	√	√	√	√			
					98.02 -- 00.04	√	√	√	√			
			TD62W	H25A	98.02 -- 00.04	√	√	√	√			
					00.04 --	√	√	√	√	√		
			TA02W	G16A	97.11 -- 00.04	√	√	√	√			
					00.04 -- 00.12	√	√	√	√	√		

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
			TD02W	G16A	97.11 -- 00.04	√	√	√	√			
			TD52W	J20A	97.11 -- 00.04	√	√	√	√			
			TA52W	J20A	00.12 -- 02.11	√	√	√	√	√		
			TL52W	J20A	00.04 --	√	√	√	√	√		
		A/T	TA01W		96.02 -- 96.10	√	√	√	√			
			TA01R		96.02 -- 96.10	√	√	√	√			
			TD01W		96.02 -- 96.10	√	√	√	√			
			TA02W		00.04 -- 00.12	√	√	√	√			
			TA52W		00.12 -- 02.11	√	√	√	√			
			TL52W		00.04 --	√	√	√	√			
		ABS	TA02W		00.04 -- 00.12	√	√	√	√	√		
			TA52W		00.12 -- 02.11	√	√	√	√	√		
			TL52W		00.04 --	√	√	√	√	√		
			TD62W		00.04 --	√	√	√	√	√		
		SRS	all vehicles		97.11 -- 02.11	√	√	√	√			
			TL52W		02.11 --	√	√	√	√			
			TD62W		02.11 --	√	√	√	√			
		A/C	TL52W		02.11 --	√	√	√	√			
			TD62W		02.11 --	√	√	√	√			
		BCM	TL52W		02.11 -- 03.06	√	√	√	√	√		
			TD62W		02.11 -- 03.06	√	√	√	√	√		
			TL52W		03.06 --	√	√	√	√	√		
			TD62W		03.06 --	√	√	√	√	√		
	X-90	ENGINE	LB11S	G16A	95.10 -- 97.11	√	√	√	√			
					96.02 -- 97.05	√	√	√	√			

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
CULTUS CRECENT		ENGINE	GA11S	G13B	97.05 -- 98.05(Only MT,CVT)	√	√	√	√			
					97.05 -- 98.05(3AT)	√	√	√	√			
			GC21S	G15A	96.02 -- 97.05	√	√	√	√			
			GC21W	G15A	96.02 -- 97.05	√	√	√	√			
			GD31S	G16A	96.02 -- 97.05	√	√	√	√			
			GD31W	G16A	96.02 -- 97.05	√	√	√	√			
			GB31S	G16A	96.02 -- 97.05	√	√	√	√			
			GC41W	J18A	96.02 -- 02.07	√	√	√	√			
			GA21S	G15A	97.05 -- 98.05	√	√	√	√			
			GB21S	G15A	97.05 -- 98.05	√	√	√	√			
			GC21S	G16A	97.05 -- 98.05	√	√	√	√			
			GD21S	G16A	97.05 -- 98.05	√	√	√	√			
		A/T	GB31S		96.02 -- 98.05	√	√	√	√			
			GC21S		96.02 -- 98.05	√	√	√	√			
			GD31S		96.02 -- 98.05	√	√	√	√			
			GC21W		96.02 -- 98.05	√	√	√	√			
			GD31W		96.02 -- 98.05	√	√	√	√			
			GC41W		96.02 -- 02.07	√	√	√	√			
			GA11S		96.10 -- 99.06	√	√	√	√			
					98.05 -- 99.06	√	√	√	√			
		ABS			96.02 -- 97.05	√	√	√	√			
					97.05 -- 00.04	√	√	√	√			
		EPS	GA11S		97.05 -- 00.04	√	√	√	√			
		SRS	all vehicles		97.05 -- 02.07	√	√	√	√			

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	CULTUS	ENGINE	GA11S	G13B	98.05 -- 00.04(only MT,CVT)	√	√	√	√			
					98.05 -- 00.04	√	√	√	√			
			GC21S	G15A	98.05 -- 01.10	√	√	√	√			
			GC21W	G15A	98.05 -- 02.07	√	√	√	√			
			GD31S	G16A	98.05 -- 01.10	√	√	√	√			
			GB31S	G16A	98.05 -- 01.10	√	√	√	√			
			GD31W	G16A	98.05 -- 02.07	√	√	√	√			
		A/T	GC21S		98.05 -- 01.10	√	√	√	√			
			GD31S		98.05 -- 01.10	√	√	√	√			
			GB31S		98.05 -- 01.10	√	√	√	√			
			GC21W		98.05 -- 02.07	√	√	√	√			
			GD31W		98.05 -- 02.07	√	√	√	√			
		ABS	GC21S		00.04 -- 01.10	√	√	√	√	√		
			GC21W		00.04 -- 02.07	√	√	√	√	√		
			GC41W		00.04 -- 02.07	√	√	√	√	√		
			GD31S		00.04 -- 01.10	√	√	√	√	√		
			GD31W		00.04 -- 02.07	√	√	√	√	√		
	WAGON R WIDE	ENGINE	MA61S	K10A-NA TURBO	97.02 -- 99.05	√	√	√	√			
			MB61S	K10A-NA TURBO	97.02 -- 99.05	√	√	√	√			
		A/T	MA61S		97.02 -- 99.05	√	√	√	√			
					98.08 -- 99.05	√	√	√	√			
			MB61S		97.02 -- 99.05	√	√	√	√			
					98.08 -- 99.05	√	√	√	√			
		ABS	MA61S		97.02 -- 99.05	√	√	√	√			
			MB61S		97.02 -- 99.05	√	√	√	√			

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
		SRS	MA61S		97.02 -- 99.06	√	√	√	√			
			MB61S		97.02 -- 99.06	√	√	√	√			
	EVERY ⁺	ENGINE	DA32W	G13B	99.06 -- 01.05	√	√	√	√			
		A/T	DA32W		99.06 -- 01.05	√	√	√	√			
		ABS	DA32W		99.06 -- 01.05	√	√	√	√			
		EPS	DA32W		99.06 -- 01.05	√	√	√	√			
		SRS	DA32W		99.06 -- 01.05	√	√	√	√			
	SWIFT	ENGINE	HT51S	M13A-NA-VVT	00.01 -- 03.06	√	√	√	√	√		
					00.01 -- (4WD AT)	√	√	√	√	√		
				M13A-NA-VVT U-LEV	03.06 -- (4WD,AT)	√	√	√	√	√		
			HT81S	M15A-NA-VVT	03.06 --	√	√	√	√	√		
		A/T	HT51S		00.01 -- 01.04	√	√	√	√			
					01.04 --	√	√	√	√			
		ABS	HT51S		00.01 --	√	√	√	√	√		
		EPS	HT51S		00.01 --	√	√	√	√			
		SRS	HT51S		00.01 --	√	√	√	√			
	WAGON R SOLIO	ENGINE	MA34S	M13A-NA-VVT	00.11 --	√	√	√	√	√		
			MA64S	K10A-NA-VVT	00.11 -- 02.10	√	√	√	√	√		
		A/T	MA64S		00.11 -- 02.10	√	√	√	√			
			MA34S		00.11 --	√	√	√	√			
		ABS	MA34S		00.11 --	√	√	√	√	√		
			MA64S		00.11 -- 02.10	√	√	√	√	√		
		EPS	MA34S		00.11 --	√	√	√	√			
			MA64S		00.11 -- 02.10	√	√	√	√			

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
		SRS	MA34S		00.11 --	√	√	√	√			
			MA64S		00.11 -- 02.10	√	√	√	√			
	GRAND ESCUDO	ENGINE	TX92W	H27A	00.12 -- 03.06	√	√	√	√	√		
				H27A U-LEV	03.06 --	√	√	√	√	√		
		A/T	TX92W		03.06 --	√	√	√	√			
		ABS	TX92W		00.12 --	√	√	√	√	√		
		SRS	TX92W		00.12 --	√	√	√	√			
		A/C	TX92W		02.11 --	√	√	√	√			
					02.11 -- 03.06	√	√	√	√	√		
		BCM	TX92W		03.06 --	√	√	√	√			
					03.06 --	√	√	√	√			
		4WD	TX92W		03.06 --	√	√	√	√			
	AERIO	ENGINE	RB21S	M15A-NA-VVT	01.01 --	√	√	√	√	√		
			RA21S	M15A-NA-VVT	01.11 --	√	√	√	√	√		
			RC51S	M18A-NA-VVT	03.01 --	√	√	√	√	√		
			RD51S	M18A-NA-VVT	03.01 --	√	√	√	√	√		
		A/T	RA21S		01.11 --	√	√	√	√			
					01.11 --	√	√	√	√			
					01.01 -- 01.11	√	√	√	√			
			RC51S		03.01 --	√	√	√	√			
			RD51S		03.01 --	√	√	√	√			
		ABS	RB21S		01.01 --	√	√	√	√	√		
			RA21S		01.11 --	√	√	√	√	√		
			RC51S		03.01 --	√	√	√	√	√		
			RD51S		03.01 --	√	√	√	√	√		
		SRS	RB21S		01.01 --	√	√	√	√			
			RA21S		01.11 --	√	√	√	√			

Suzuki V26.10 Diagnostics List (Note:For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
		SRS	RC51S		03.01 --	√	√	√	√			
			RD51S		03.01 --	√	√	√	√			
		A/C	RB21S		02.10 --	√	√	√	√			
			RA21S		02.10 --	√	√	√	√			
			RC51S		03.01 --	√	√	√	√			
			RD51S		03.01 --	√	√	√	√			
	EVERY LANDY	ENGINE	DA32W	G13B	01.05 --	√	√	√	√	√		
		A/T	DA32W		01.05 --	√	√	√	√			
		ABS	DA32W		01.05 --	√	√	√	√	√		
		EPS	DA32W		01.05 --	√	√	√	√			
		SRS	DA32W		01.05 --	√	√	√	√			
	CHEVROLET CRUZE	ENGINE	HR51S	M13A-NA-VVT	01.11 --	√	√	√	√	√		
			HR81S	M15A-NA-VVT	02.12 --	√	√	√	√	√		
		A/T	HR51S		01.11 --	√	√	√	√			
			HR81S		02.12 --	√	√	√	√			
		ABS	HR51S		01.11 --	√	√	√	√	√		
			HR81S		02.12 --	√	√	√	√	√		
		EPS	HR51S		01.11 --	√	√	√	√			
			HR81S		02.12 --	√	√	√	√			
		SRS	HR51S		01.11 --	√	√	√	√			
			HR81S		02.12 --	√	√	√	√			
		EMCD	HR51S		01.11 --	√	√	√	√			
	WAGON R ⁺	ENGINE	MA63S	K10A-NA-VVT	99.05 -- 00.11	√	√	√	√			
				K10A-TURBO-VVT	99.05 -- 00.11	√	√	√	√			
		A/T	MA63S		99.05 -- 00.11	√	√	√	√			
		ABS	MA63S		99.05 -- 00.11	√	√	√	√			

Suzuki V26.10 Diagnostics List (Note: For reference only)

[illegible]

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
OTHER THAN NORTH AMERICA	ALTO	SRS					√	√	√			
		ENGINE					√	√	√			
		SRS					√	√	√			
	JIMNY	ENGINE					√	√	√			
		AT					√	√	√			
		ABS					√	√	√			
	MR WAGON	ENGINE										
		ABS					√	√	√			
		SRS					√	√	√			
	EVERY+/LANDY	ENGINE					√	√	√			
		AT					√	√	√			
		ABS					√	√	√			
	CARRY	ENGINE					√	√	√			
		AT					√	√	√			
		ABS					√	√	√			
	SX4	ENGINE					√	√	√			
		AT					√	√	√			
		ABS					√	√	√			
		SRS					√	√	√			
	GRAND VITARA(JB Series)	ENGINE					√	√	√			
		AT					√	√	√			
		SRS					√	√	√			
		BCM					√	√				
		HVAC					√	√				
		ABS					√	√	√			
		4WD					√	√				

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	SAMURAI	ESP					√	√				
		ENGINE					√	√	√			
		ABS					√	√	√			
	LIANA(AERIO)	ENGINE					√	√	√			
		AT					√	√	√			
		ABS					√	√	√			
		SRS					√	√	√			
		HVAC					√	√	√			
	GRAND VITARA/ XL-7	ENGINE					√	√	√			
		AT					√	√	√			
		SRS					√	√	√			
		BCM					√	√	√			
		HVAC					√	√	√			
		ABS					√	√	√			
		Immobilizer					√	√				
	VERONA	ENGINE			2004-2006		√	√	√			
		AT					√	√	√			
		ABS			2004-2006		√	√	√			
		SRS					√	√	√			
		ISU					√	√	√			
		SSPS					√	√				

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
NORTH AMERICA		TPMS					√	√	√			
	SWIFT	ENGINE			1996-2001		√	√				
	ESTEEM	ENGINE			1996-2002		√	√				
		AT					√	√				
		AIR BAG					√	√				
		ABS			1996-2002		√	√				
	FORENZ A/RENO	ENGINE			2004-2007		√	√				
		AT					√	√				
		ABS			2004-2007		√	√				
		SRS					√	√				
		TPMS					√	√	√			
		SSPS					√	√				
	X-90	ENGINE			1996-1998		√	√				
	AERIO	ENGINE			2002-2007		√	√				
		AT			2002-2007		√	√				
		SRS			2002-2007		√	√				
		HVAC			2003-2007		√	√				
		ABS			2002-2007		√	√				
	SWIFT+	ENGINE			2004-2007		√	√				
		AT			2004-2007		√	√				
		ABS			2004-2007		√	√				
		SRS			2004-2007		√	√				
		ENGINE					√	√	√			
		SRS					√	√	√			
		BCM					√	√	√			

Suzuki V26.10 Diagnostics List (Note: For reference only)

Areas	Vehicle	System	Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	SX4	HVAC					√	√	√			
		ABS					√	√				
		4WD					√	√	√			
		ESP					√	√	√			
	GRAND VITARA(JB Series)	ENGINE			2006-2007		√	√	√			
		AT					√	√				
		SRS					√	√				
		BCM					√	√				
		HVAC					√	√				
		ABS					√	√				
		4WD					√	√				
		ESP					√	√				
	XL-7/GRAND VITARA/VITARA	ENGINE			1999-2006		√	√	√			
		SRS			1999-2006		√	√	√			
		BCM			2003-2006		√	√	√			
		HVAC					√	√	√			
		TPMS					√	√	√			
		ABS			1999-2006		√	√	√			
		4WD					√	√	√			
	SIDE KICK/SIDE KICK	ENGINE			1996-1998		√	√				
		ABS					√	√				

(*): Tested;

(?): Manual on website(www.x431.com)

Note: The final interpretation of the products belongs to LAUNCH TECH CO., LTD.

CONNECTOR	X431	DIAGUN
SMART OBD II -16	ALL SYSTEM	N/A
CANBUS II	ALL SYSTEM	N/A
Diagun connector	N/A	ALL SYSTEM
SUPER -16	ALL SYSTEM	N/A