

## Mahindra **V11.00** Diagnostics List (Note:For reference only)

| Vehicle        | System                                 | Functions  |          |           |             |           |                                                                                                                    |        |
|----------------|----------------------------------------|------------|----------|-----------|-------------|-----------|--------------------------------------------------------------------------------------------------------------------|--------|
|                |                                        | Sys. Info. | Read Dtc | Clear Dtc | Data stream | Actuation | Special Function                                                                                                   | Others |
| <b>SCORPIO</b> | Engine system(2.6)                     | √          | √        | √         | √           |           | 1.ADJUST(*)<br>2.IQA(*)<br>3.VERIFY IQA CODE(*)                                                                    |        |
|                | <b>Engine system(EDC16C39/BAS 2.4)</b> | √          | √        | √         | √           | √         | <b>1.ECU reset(*)<br/>2.Read IQA CODE(*)<br/>3.Write IQA CODE(*)<br/>4.Adjust idle(*)<br/>5.ECU replacement(*)</b> |        |
|                | <b>ABS system</b>                      | √          | √        | √         | √           |           | <b>1.Bleeding mode</b>                                                                                             |        |
| <b>XYLO</b>    | <b>Engine system</b>                   | √          | √        | √         | √           | √         | <b>1.ECU reset(*)<br/>2.Read IQA CODE(*)<br/>3.Write IQA CODE(*)<br/>4.Adjust idle(*)<br/>5.ECU replacement(*)</b> |        |
| <b>LOGAN</b>   | <b>Petrol Engine system</b>            | √          | √        | √         | √           | √         |                                                                                                                    |        |
|                | <b>Diesel Engine system</b>            | √          | √        | √         | √           | √         |                                                                                                                    |        |
|                | <b>BCM system</b>                      | √          | √        | √         | √           | √         |                                                                                                                    |        |

(\*) :Tested;

(?) :Manual on website([www.x431.com](http://www.x431.com))

Note:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD.