

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
DEDRA	'96 1.8 16V 115 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
	'96 1.8 16V 115 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
	'96 1.8 16V 130 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
	'98 1.6 16V	Bosch 5.3 ABS	VCD
		Magneti Marelli IAW 49F injection (1.6 eng.)	CDAS049
DELTA (111)	'96 1.6 16V	Bosch 5.3 ABS	VCD
	'96 1.6 16V	Bosch 5.3 ABS	VCD
	'96 1.8 16V 115 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
	'96 1.8 16V 130 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
	'96 2.0 TURBO 16V	Bosch 5.3 ABS	VCD
	'96 TD	Bosch 5.3 ABS	VCD
	'98 1.6 16V	Bosch 5.3 ABS	VCD
		Magneti Marelli IAW 49F injection (1.6 eng.)	CDAS049
	'98 1.8 16V	Bosch 5.3 ABS	VCD
		Hitachi MPI injection (eng. 1.8 16v '98)	VCDAS001
1.4 TURBO 16V	Engine-Gearbox	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	VCDAS002
		Injection Landi Renzo LC02 Gas	VCDA
	Instrumentation	Marelli instrument panel 3	VCDAS003
		Marelli/Microsoft C3 Convergence	VCDAS004
		Marelli/Microsoft Convergence	VCDAS004
	Safety	Marelli Body Computer 8	VCDAS005
		SIEMENS Airbag 1 (Proxi)	VCDA

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions	
DELTA (181)	1.6 MJET 16V	TRW ABS ESP	VCDAS006	
		Comfort	Denso 3 climate control (Two-zone)	VCDAS007
			TRW 3 Electric Steering	VCDS008
		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
		Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
			Marelli SELESPEED CFC300 Automatic Gearbox	VCDAS010
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
		Comfort	Denso 3 climate control (Two-zone)	VCDAS007
			TRW 3 Electric Steering	VCDS008
		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
	1.8 JTS TB 16V	Engine-Gearbox	Automatic Gearbox AISIN AF40-6	VCDAS011
			Bosch Injection Motronic MeD17.3.1 CF5/EOBD (eng. 1.8)	VCDAS012
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems		Functions
1.9 MJET 16V TWINTB	1.9 MJET 16V TWINTB	Comfort	Denso 3 climate control (Two-zone)	VCDAS007
			TRW 3 Electric Steering	VCDS008
		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
		Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
		Comfort	Denso 3 climate control (Two-zone)	VCDAS007
			TRW 3 Electric Steering	VCDS008
		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
2.0 MJET 16V	2.0 MJET 16V	Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
		Comfort	Denso 3 climate control (Two-zone)	VCDAS007
			TRW 3 Electric Steering	VCDS008
			Tyre Pressure Control TRW 2	VCDAS057

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems		Functions
		Other systems	Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
K	'98 2.4 JTD	Engine-Gearbox	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	CDAS050
			Bosch 5.3 ABS	VCD
		Safety	TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	'99 2.0	Engine-Gearbox	Bosch Motronic ME3.1 injection (eng. 2.0 20V)	CDAS001
			Bosch 5.3 ABS	VCD
		Safety	TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	'99 2.4	Engine-Gearbox	Bosch Motronic ME3.1 injection (eng. 2.0 20v)	CDAS001
			Bosch 5.3 ABS	VCD
		Safety	TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
			TRW MY 97 Air Bag (2F-2P-2L)	VCD
	99 3.0	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
			TRW MY 97 Air Bag (2F-2P-2L)	VCD
	2.0	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions	
2.0 TURBO	2.0 TURBO	Safety	TRW MY 97 Air Bag (2F-2P-S)	VCD
			Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	2.4	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	2.4 TD	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	3.0	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
1.6	1.6	Bosch 5.3 ABS	VCD	
		ESP TRW Lucas ABS	VCDAS013	
		Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	VCDAS014	
		Magneti Marelli IAW 49F injection (1.6 eng.)	CDAS049	
		Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014	
		Marelli Code 2 Electronic Key	VCD	
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	CDA	
		TRW Lucas ABS	VCDAS015	
		VAS 97/3 Door Lock RF alarm/receiver	VCD	
		Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD	

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
LYBRA	1.8	Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD
		Allied MY 97 AirBag (2F-2P-I)	VCD
		Allied MY 97 AirBag (2F-2P-I-S)	VCD
		Bosch 5.3 ABS	VCD
		ESP TRW Lucas ABS	VCDAS013
		Hitachi EOBD injection	CDAS001
		Hitachi MPI injection (eng. 1.8 16v '98)	VCDAS001
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	CDA
	1.9 JTD	TRW Lucas ABS	VCDAS015
		VAS 97/3 Door Lock RF alarm/receiver	VCD
		Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD
	LYBRA DRIAL	Allied MY 97 AirBag (2F-2P-I)	VCD
		Allied MY 97 AirBag (2F-2P-I-S)	VCD
		Bosch 5.3 ABS	VCD
		Bosch Diesel EDC15 injection (1.9 TD d.i. engine)	CDAS050
		Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	VCDAS016
		ESP TRW Lucas ABS	VCDAS013
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	CDA
		TRW Lucas ABS	VCDAS015
		VAS 97/3 Door Lock RF alarm/receiver	VCD
	DRIAL	Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
2.0	2.0	Allied MY 97 Air Bag (2F-2P-2L-I)	VCD
		Allied MY 97 Air Bag (2F-2P-I)	VCD
		Allied MY 97 Air Bag (2F-2P-I-S)	VCD
		Bosch 5.3 ABS	VCD
		Bosch Motronic Me3.1 EOBD injection (eng. 2.0/2.4 20v)	VCDAS001
		ESP TRW Lucas ABS	VCDAS013
		Injection-Bosch Motronic Me3.1 (eng. 2.0/2.4 20v Outside EEC)	VCDAS001
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	CDA
		TRW Lucas ABS	VCDAS015
2.4 JTD	2.4 JTD	VAS 97/3 Door Lock RF alarm/receiver	VCD
		Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD
		Allied MY 97 AirBag (2F-2P-I)	VCD
		Allied MY 97 AirBag (2F-2P-I-S)	VCD
		Bosch 5.3 ABS	VCD
		Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	VCDAS016
		Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	CDAS050
		ESP TRW Lucas ABS	VCDAS013
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	CDA
		TRW Lucas ABS	VCDAS015
		VAS 97/3 Door Lock RF alarm/receiver	VCD
Engine-Gearbox	Engine-Gearbox	Automatic Gearbox Marelli SELESPEED CFC 308F	VCDAS017
		Marelli 6JF EOBD Diesel injection (eng. 1.3 JTD)	VCDAS018
		Marelli Automatic Gearbox SELESPEED CFC208F (1)	CDAS055

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
1.3 JTD	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	CDAS051
		Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	VCDAS019
		Marelli 3 Connect (multi-model)	VCDA
		Marelli instrument panel (Comfort)	VCDAS020
		Marelli instrument panel (Modal)	VCDAS021
		Bosch 8 ABS	VCD
		Bosch 8 VDC ABS	VCDAS045
		Marelli 7 Body Computer	VCDAS047
		Marelli Body Computer 1	VCDAS046
		TRW MY 03 Airbag (2F-2P-2L-2T-I)	VCDA
		TRW MY 03 Airbag (2F-2P-2T-I)	VCDA
		TRW MY 03 Airbag (2F-2P-I)	VCDA
		Denso Climate Control 1 (Two-zone)	VCDAS022
		Marelli/Microsoft Convergence	VCDAS004
		TRW 3 Electric Steering	VCDS008
		Valeo Parking control unit	VCDS023
1.4 16V	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	VCDAS002
		Bosch Motronic ME7.3 H4M EOBD Injection	VCDAS001
		Marelli SELESPEED CFC228F Automatic Gearbox	VCDAS043
		Marelli SELESPEED CFC328 Automatic Gearbox	VCDAS024
		Marelli 3 Connect (multi-model)	VCDA
		Marelli instrument panel (Comfort)	VCDAS020
		Marelli instrument panel (Modal)	VCDAS021
		Bosch 8 ABS	VCD
		Bosch 8 VDC ABS	VCDAS045
		Marelli 7 Body Computer	VCDAS047
		Marelli Body Computer 1	VCDAS046

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions	
MUSA	1.4 8V	TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA	
		TRW MY 03 AirBag (2F-2P-2T-I)	VCDA	
		TRW MY 03 AirBag (2F-2P-I)	VCDA	
		Comfort	Denso Climate Control 1 (Two-zone)	VCDAS022
			Marelli/Microsoft Convergence	VCDAS004
			TRW 3 Electric Steering	VCDS008
		Other systems	Valeo Parking control unit	VCDS023
		Engine-Gearbox	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	VCDAS025
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Marelli instrument panel (Comfort)	VCDAS020
			Marelli instrument panel (Modal)	VCDAS021
		Safety	Bosch 8 ABS	VCD
			Bosch 8 VDC ABS	VCDAS045
			Marelli 7 Body Computer	VCDAS047
			Marelli Body Computer 1	VCDAS046
			TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-I)	VCDA
		Comfort	Denso Climate Control 1 (Two-zone)	VCDAS022
			Marelli/Microsoft Convergence	VCDAS004
			TRW 3 Electric Steering	VCDS008
		Other systems	Valeo Parking control unit	VCDS023
		Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Marelli instrument panel (Comfort)	VCDAS020
			Marelli instrument panel (Modal)	VCDAS021
		Bosch 8 ABS	VCD	

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
1.6 MJET 16V	Safety Bosch 8 VDC ABS Marelli Body Computer TRW MY 03 AirBag (2F-2P-2L-2T-I) TRW MY 03 AirBag (2F-2P-2T-I) TRW MY 03 AirBag (2F-2P-I) Comfort Denso Climate Control 1 (Two-zone) Marelli/Microsoft Convergence TRW 3 Electric Steering Other systems Valeo Parking control unit	Bosch 8 VDC ABS	VCDAS045
		Marelli Body Computer	VCD
		TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA
		TRW MY 03 AirBag (2F-2P-2T-I)	VCDA
		TRW MY 03 AirBag (2F-2P-I)	VCDA
		Denso Climate Control 1 (Two-zone)	VCDAS022
		Marelli/Microsoft Convergence	VCDAS004
		TRW 3 Electric Steering	VCDS008
		Valeo Parking control unit	VCDS023
1.9 JTD	Engine-Gearbox Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.) Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	VCDAS026
		Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	VCDAS027
	Instrumentation Marelli 3 Connect (multi-model) Marelli instrument panel (Comfort) Marelli instrument panel (Modal)	Marelli 3 Connect (multi-model)	VCDA
		Marelli instrument panel (Comfort)	VCDAS020
		Marelli instrument panel (Modal)	VCDAS021
	Safety Bosch 8 ABS Bosch 8 VDC ABS Marelli 7 Body Computer Marelli Body Computer 1 TRW MY 03 AirBag (2F-2P-2L-2T-I) TRW MY 03 AirBag (2F-2P-2T-I) TRW MY 03 AirBag (2F-2P-I)	Bosch 8 ABS	VCD
		Bosch 8 VDC ABS	VCDAS045
		Marelli 7 Body Computer	VCDAS047
		Marelli Body Computer 1	VCDAS046
		TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA
		TRW MY 03 AirBag (2F-2P-2T-I)	VCDA
		TRW MY 03 AirBag (2F-2P-I)	VCDA
	Comfort Denso Climate Control 1 (Two-zone) Marelli/Microsoft Convergence TRW 3 Electric Steering	Denso Climate Control 1 (Two-zone)	VCDAS022
		Marelli/Microsoft Convergence	VCDAS004
		TRW 3 Electric Steering	VCDS008
	Other systems Valeo Parking control unit	Valeo Parking control unit	VCDS023
	Engine-Gearbox Magneti Marelli MM4MP2 PSA Injection Magneti Marelli MM6LP PSA Injection	Magneti Marelli MM4MP2 PSA Injection	CDA
		Magneti Marelli MM6LP PSA Injection	CDAS053

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
2.0 16V		Siemens AL4 TA2000 V PSA Automatic Gearbox	CDAS054
		Marelli DAV PSA Connect control	VCD
		Marelli odometer w. lamps (BTO)	VCDA
		Marelli PSA Connect	VCDAS028
		Marelli PSA instrument panel	VCDA
		Sagem multi-function screen	VCDA
		Bosch 5.7 ESP PSA ABS	CDAS052
		Sagem Body Computer	VCDAS029
		Temic airbag	VCDS030
		Texton alarm 2	VCDA
		Bitron PSA driver's seat	VCDA
		Clarion CD Changer	VCDA
		Clarion/Philips sound system	VCDAS031
		Marelli PSA climate control	VCDA
		Eaton multi-switch stalk unit (COM2000)	VCD
		Marelli PSA Driver's Door	VCDA
		Marelli PSA Passenger's Door	VCDS032
		Texton sliding doors	CDA
		Valeo PSA Parking Control unit	VCDA
		Bosch EDC 15 PSA diesel injection (eng. 16v)	VCDAS033
		Siemens AL4 TA2000 V PSA Automatic Gearbox	CDAS054
		Marelli DAV PSA Connect control	VCD
		Marelli odometer w. lamps (BTO)	VCDA
		Marelli PSA Connect	VCDAS028
		Marelli PSA instrument panel	VCDA
		Sagem multi-function screen	VCDA
		Bosch 5.7 ESP PSA ABS	CDAS052

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions	
PHEDRA	2.0 JTD 16V	Safety	Sagem Body Computer	VCDAS029
			Temic airbag	VCDS030
			Texton alarm 2	VCDA
		Comfort	Bitron PSA driver's seat	VCDA
			Clarion CD Changer	VCDA
			Clarion/Philips sound system	VCDAS031
			Marelli PSA climate control	VCDA
			WEBASTO Heater (PSA)	CDA
		Other systems	Eaton multi-switch stalk unit (COM2000)	VCD
			Marelli diesel additive check	VCDAS034
			Marelli PSA Driver's Door	VCDA
			Marelli PSA Passenger's Door	VCDS032
			Texton sliding doors	CDA
			Valeo PSA Parking Control unit	VCDA
PHEDRA	2.2 JTD 16V	Engine-Gearbox	Bosch EDC 15 PSA diesel injection (eng. 16v)	VCDAS033
		Instrumentation	Marelli DAV PSA Connect control	VCD
			Marelli odometer w. lamps (BTO)	VCDA
			Marelli PSA Connect	VCDAS028
			Marelli PSA instrument panel	VCDA
			Sagem multi-function screen	VCDA
		Safety	Bosch 5.7 ESP PSA ABS	CDAS052
			Sagem Body Computer	VCDAS029
			Temic airbag	VCDS030
			Texton alarm 2	VCDA
		Comfort	Bitron PSA driver's seat	VCDA
			Clarion CD Changer	VCDA
			Clarion/Philips sound system	VCDAS031

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
3.0 V6 24V	Other systems	Marelli PSA climate control	VCDA
		WEBASTO Heater (PSA)	CDA
	Other systems	Eaton multi-switch stalk unit (COM2000)	VCD
		Marelli diesel additive check	VCDAS034
		Marelli PSA Driver's Door	VCDA
		Marelli PSA Passenger's Door	VCDS032
		Texton sliding doors	CDA
	Instrumentation	Valeo PSA Parking Control unit	VCDA
		Bosch Motronic Me7.4.6 PSA Injection	VCDAS035
		Marelli DAV PSA Connect control	VCD
		Marelli odometer w. lamps (BTO)	VCDA
		Marelli PSA Connect	VCDAS028
		Marelli PSA instrument panel	VCDA
		Sagem multi-function screen	VCDA
	Safety	Bosch 5.7 ESP PSA ABS	CDAS052
		Sagem Body Computer	VCDAS029
		Temic airbag	VCDS030
		Texton alarm 2	VCDA
	Comfort	Bitron PSA driver's seat	VCDA
		Clarion CD Changer	VCDA
		Clarion/Philips sound system	VCDAS031
		Marelli PSA climate control	VCDA
	Other systems	Eaton multi-switch stalk unit (COM2000)	VCD
		Marelli PSA Driver's Door	VCDA
		Marelli PSA Passenger's Door	VCDS032
		Texton sliding doors	CDA
		Valeo PSA Parking Control unit	VCDA

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
PHEDRA (180)	2.0 JTD 16V	Engine-Gearbox	Bosch EDC 15 PSA diesel injection (eng. 16v)
			Siemens AL4 TA2000 V PSA Automatic Gearbox
			Siemens Diesel Injection SID803 CF4/EOBD (eng. 16v)
		Comfort	WEBASTO Heater (PSA)
	2.2 JTD 16V	Engine-Gearbox	AISIN AM6 Automatic Gearbox
			Bosch Diesel Injection EDC16CP39 CF4/EOBD (2.2 eng.)
			Bosch EDC 15 PSA diesel injection (eng. 16v)
	2.0 20V TB	Comfort	WEBASTO Heater (PSA)
		Engine-Gearbox	Bosch Motronic Me7.3.1 EOBD injection (2 lambda sensors)
		Safety	ESP TRW Lucas ABS
			Marelli Easy-go Body computer
			Marelli Full Body computer
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)
			TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)
		Comfort	Bitron driving seat
			Bitron passenger seat
			SAGEM SpeedPro power steering
		Other systems	Marelli Boot
			Marelli Driver's Door
			Marelli Passenger Door
			Valeo Parking control unit
		Engine-Gearbox	AISIN YLII 5 Automatic Gearbox
			Bosch Motronic Me3.1 EOBD injection (eng. 2.0/2.4 20v)
		Safety	ESP TRW Lucas ABS
			Marelli Easy-go Body computer
			Marelli Full Body computer
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)
			VCD

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions	
THESSIS	2.4 20V	TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD	
		Bitron driving seat	VCDA	
		Bitron passenger seat	VCDA	
		SAGEM SpeedPro power steering	VCD	
		Marelli Boot	VCDA	
		Marelli Driver's Door	VCDA	
		Marelli Passenger Door	VCDA	
		Valeo Parking control unit	VCDS023	
	2.4 JTD 10V	Engine-Gearbox	Bosch EDC15 CF3/EOBD Diesel injection (eng. 1.9/2.4)	VCDAS016
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
		Comfort	Bitron driving seat	VCDA
	THESIS		Bitron passenger seat	VCDA
			SAGEM SpeedPro power steering	VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
		Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
	Instrumentation		Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	VCDAS039
			Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	VCDAS040
			Nippon Seiki instrument panel (Thesis)	VCDA060
			ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046

LANCIA V15.70 Diagnostics List

(Note: For reference only)

Models	Displacement	Systems		Functions
2.4 JTD 20V	2.4 JTD 20V	Safety	Marelli Full Body computer	VCDAS046
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
		Comfort	Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			SAGEM SpeedPro power steering	VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
3.0 V6 24V	3.0 V6 24V	Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
			Bosch Motronic EOBD ME3.1 Injection (eng. V6)	VCDAS001
		Instrumentation	Nippon Seiki instrument panel (Thesis)	VCDAS060
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
			TRW MY 99 Airbag (2F-4P-I-S-C)	VCD
		Comfort	Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			SAGEM SpeedPro power steering	VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
			AISIN YLII 5 Automatic Gearbox	VCDA

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems		Functions
Y	3.2 V6 24V	Engine-Gearbox	Bosch Motronic ME7.3.1 EOBD Injection	VCDAS001
			Injection-Bosch Motronic Me7.3.1 Outside EEC	VCDAS001
		Instrumentation	Nippon Seiki instrument panel (Thesis)	VCDAS060
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
		Comfort	Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			SAGEM SpeedPro power steering	VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
1.2 CF3	1.1	Bosch 5.3 ABS		
		Magneti Marelli IAW 16F Injection		
	1.2	Bosch 5.3 ABS		
		Fuji MX665 Automatic Transmission (EEC2 engine)		
		Magneti Marelli IAW 16F Injection		
	1.2 16V	Bosch 5.3 ABS		
	1.2 16V CF3	Bosch 5.3 ABS		
		Bosch Motronic ME7.3H4 EOBD injection		
	1.2 CF3	Allied MY 97 Air Bag (2F-2P-2L-S)		
		Allied MY 97 Air Bag (2F-2P-S)		
		Allied MY 97 Airbag (2F-2P)		
		Allied MY 97 Airbag (2F-2P-2L-I)		

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions	
1.2 16V	1.2 C13	Allied MY 97 Airbag (2F-2P-I)	VCD	
		Bosch 5.3 ABS	VCD	
		Fuji MX665 Automatic Transmission (EEC2 engine)	VCD	
		Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014	
	1.4	Allied MY 97 Airbag (2F-2P)	VCD	
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD	
		Allied MY 97 Airbag (2F-2P-I)	VCD	
		Bosch 5.3 ABS	VCD	
1.2 16V	1.2 16V	Engine-Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	VCDAS001
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
			Autoliv AirBag 99 (A) (2F-2P-2L-I)	CDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	CDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	CDA
			Autoliv Airbag MY 99 (2F-2P-2T-I)	CDA
			Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	CDA
			Autoliv MY 99 Airbag (2F-2P-I)	CDA
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli/Finmek Body Computer	VCDAS041
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
		Other systems	Bosch Parking Control Unit	VCDAS042
		Engine-Gearbox	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
			Autoliv AirBag 99 (A) (2F-2P-2L-I)	CDA

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
1.2 8V	1.2 8V	Safety <ul style="list-style-type: none"> Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I) Autoliv Airbag MY 99 (2F-2P-2L-2T-I) Autoliv Airbag MY 99 (2F-2P-2T-I) Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I) Autoliv MY 99 Airbag (2F-2P-I) ESP TRW Lucas ABS Marelli/Finmek Body Computer TRW Lucas ABS 	CDA
			VCDAS013
			VCDAS041
			VCDAS015
		Comfort <ul style="list-style-type: none"> DELPHI Electric Steering Denso Climate Control (Two-zone) 	VCDS044
			VCDAS007
		Other systems <ul style="list-style-type: none"> Bosch Parking Control Unit 	VCDAS042
1.3 JTD	1.3 JTD	Engine-Gearbox <ul style="list-style-type: none"> Marelli 6JF EOBD Diesel injection (eng. 1.3 JTD) Marelli Automatic Gearbox SELESPEED CFC208F (1) Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD) 	VCDAS018
			CDAS055
			CDAS051
		Instrumentation <ul style="list-style-type: none"> Marelli 3 Connect (multi-model) Siemens instrument panel Autoliv AirBag 99 (A) (2F-2P-2L-I) Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I) Autoliv Airbag MY 99 (2F-2P-2L-2T-I) Autoliv Airbag MY 99 (2F-2P-2T-I) Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I) Autoliv MY 99 Airbag (2F-2P-I) ESP TRW Lucas ABS Marelli/Finmek Body Computer TRW Lucas ABS 	VCDA
			VCDAS058
			CDA
			VCDAS013
			VCDAS041
			VCDAS015
			VCDS044
			VCDAS007
		Comfort <ul style="list-style-type: none"> DELPHI Electric Steering Denso Climate Control (Two-zone) 	

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems		Functions
YPSILON	1.4 16V	Other systems	Bosch Parking Control Unit	VCDAS042
		Engine-Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	VCDAS001
			Marelli SELESPEED CFC228F Automatic Gearbox	VCDAS043
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	Autoliv AirBag 99 (A) (2F-2P-2L-I)	CDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	CDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	CDA
			Autoliv Airbag MY 99 (2F-2P-2T-I)	CDA
			Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	CDA
			Autoliv MY 99 Airbag (2F-2P-I)	CDA
			ESP TRW Lucas ABS	VCDAS013
			Marelli/Finmek Body Computer	VCDAS041
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
		Other systems	Bosch Parking Control Unit	VCDAS042
	'06 1.2 8V	Engine-Gearbox	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	VCDAS014
			Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli 7 Body Computer	VCDAS047
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
			Marelli/Microsoft Convergence	VCDAS004

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems		Functions
'06 1.3 JTD	'06 1.3 JTD	Other systems	Bosch Parking Control Unit	VCDAS042
		Engine-Gearbox	Marelli Automatic Gearbox SELESPEED CFC208F (1)	CDAS055
			Marelli Diesel injection 6F3 EOBD (eng. 1.3 JTD)	CDAS051
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli 7 Body Computer	VCDAS047
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
			Marelli/Microsoft Convergence	VCDAS004
		Other systems	Bosch Parking Control Unit	VCDAS042
'06 1.4 16V	'06 1.4 16V	Engine-Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	VCDAS001
			Marelli SELESPEED CFC228F Automatic Gearbox	VCDAS043
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli 7 Body Computer	VCDAS047
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
			Marelli/Microsoft Convergence	VCDAS004
		Other systems	Bosch Parking Control Unit	VCDAS042
		Engine-Gearbox	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	VCDAS025
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
			ESP TRW Lucas ABS	VCDAS013

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems		Functions	
Z	'06 1.4 8V	Safety	Marelli 7 Body Computer	VCDAS047	
			TRW Lucas ABS	VCDAS015	
		Comfort	DELPHI Electric Steering	VCDS044	
			Denso Climate Control (Two-zone)	VCDAS007	
			Marelli/Microsoft Convergence	VCDAS004	
		Other systems	Bosch Parking Control Unit	VCDAS042	
Z	'00 2.0 16v	Magneti Marelli MM4.8P PSA injection			CDA
		Bosch EDC 15 PSA Diesel Injection (2.0 8v v60 eng.)			VCDA
		Bosch EDC 15 PSA Diesel Injection (eng. 16v)			VCDAS033
		Bosch EDC 15 PSA Diesel Injection (eng. 2.0 8v)			VCDA
		WEBASTO Heater (PSA)			CDA

(*) :Tested;

(?) :Manual on website (www.x431.com)

NOTE:The final interpretation of the products belongs to LAUNCH TECH CO. , LTD

N. B. :

V: Control Unit Info

C: Fault Codes

D: Datastream

A: Active Test

S: Additional Functions

- S001 Startup with Code Card
- S002 Startup with Code Card
- S002 Performance limiting
- S002 Neutral signal learn
- S002 Knock counter reset

LANCIA V15.70 Diagnostics List

(Note:For reference only)

Models	Displacement	Systems	Functions
S002	Overboost counter reset		
S002	Self-learnt functions reset		
S002	Zeroing of self-adaption parameters		
S003	Headlamp pos. correct.		
S003	Inputs status		
S003	Servicing information delete		
S003	Reset odometer		
S003	Seat belts alarm exclusion		
S003	Seat belts alarm enable		
S003	Oil change servicing information delete		
S003	Instrument panel replacement		
S004	Audio System Test		
S004	Convergence system Restart		
S005	Siren Serial line check		
S005	Ultrasound sensor check		
S005	Tilt sensor check(if present)		
S005	Dusk and rain sensors check		
S005	Indicators command enable/disable		
S005	Inertia switch rearm(FIS)		
S005	Key programming		
S006	Yaw sensor calibration		
S006	Lateral accel. Sensor calibration		
S006	Pressure sensor calibration		
S006	Accept configuration		
S006	Longit. Acc. Sensor calibration		
S006	Accelerat. And yaw sensors calibration		
S006	Recognition of speed sensor type		

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S007	Conditioner compressor		
S007	Flap actuators learning test		
S007	Pollution sensor test		
S007	Autotest		
S008	Steering angle calibration		
S008	Mounting check		
S009	Startup with Code Card		
S009	Injector codes read		
S009	Neutral signal learn		
S009	Replacement of injector cyl.1		
S009	Replacement of injector cyl.2		
S009	Replacement of injector cyl.3		
S009	Replacement of injector cyl.4		
S009	Injector replacement(per bank)		
S009	Oil change(only for version with DPF)		
S009	EGR valve replacement		
S009	Variable geometry turbo replacement		
S009	Rail pressure sensor replacement		
S009	Replacement Lambda sensor		
S009	Air flow meter sensor replacement		
S009	Differential pressure sensor replacement(only for version with DPF)		
S009	Pre-catalyser replacement(only for version with DPF)		
S009	Particulate filter replacement (only for version with DPF)		
S009	Replacement of particulate filter with built-in pre-catalyzer(only for versions with DPF)		
S009	Particulate filter regeneration(only for version with DPF)		
S009	Resetting distance travelled with Water Temp.w.lamp ON		
S009	Resetting distance travelled with Water in diesel w.lamp ON		

LANCIA V15.70 Diagnostics List

(Note: For reference only)

Models	Displacement	Systems	Functions
S010	Accumulator depressurisation		
S010	Clutch bleed		
S010	End of line / service self-calibration		
S010	Clutch self-calibration enable		
S010	New actuators		
S010	Statistical data deletion		
S010	Clutch replacement		
S010	KIT/Gearbox replacement		
S010	Gearbox replacement		
S010	Tunnel lever replacement		
S010	Steering wheel levers replacement		
S010	Electropump replacement		
S010	Pump relay replacement		
S010	AUTO switch replacement		
S010	ECO/SPORT switch replacement		
S010	Gearbox oil accumulator replacement		
S010	Longitudinal acceleration signal learn		
S011	Gearbox lever position learn		
S011	Self-adaptation parameter erasure		
S012	Startup with Code Card		
S012	Oil change		
S012	Knock counter reset		
S012	Overboost counter reset		
S012	Self-learnt functions reset		
S012	Zeroing of self-adapation parameters		
S013	Steering angle calibration		
S013	Yaw sensor calibration		

LANCIA V15.70 Diagnostics List

(Note: For reference only)

Models	Displacement	Systems	Functions
S013	Lateral accel. Sensor calibration		
S013	Pressure sensor calibration		
S013	Accept configuration		
S013	Longit. Acc. Sensor calibration		
S014	Startup with Code Card		
S014	Lambda sensor check		
S015	Accept configuration		
S016	Startup with Code Card		
S016	Injector classification		
S017	Accumulator depressurisation		
S017	Clutch bleed		
S017	End of line / service self-calibration		
S017	Clutch self-calibration enable		
S017	Calculation of clutch degradation index		
S017	Gearbox replacement		
S017	Hydraulic Kit replacement		
S017	Gearbox and hydraulic KIT replacement		
S017	Clutch replacement		
S017	Tunnel lever replacement		
S017	Electropump replacement		
S017	Pump relay replacement		
S017	ECO switch replacement		
S017	Gearbox oil accumulator replacement		
S017	Selection and/or engagement clutch electrovalve replacement		
S017	Longitudinal acceleration signal learn		
S018	Startup with Code Card		
S018	Self-learnt functions reset		

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S018	Injector codes read		
S018	Cyl.1 injector classification		
S018	Cyl.2 injector classification		
S018	Cyl.3 injector classification		
S018	Cyl.4 injector classification		
S018	Injector classification (4 cyl.blank)		
S019	Startup with Code Card		
S019	Injector codes read		
S019	Neutral signal learn		
S019	Replacement of injector cyl.1		
S019	Replacement of injector cyl.2		
S019	Replacement of injector cyl.3		
S019	Replacement of injector cyl.4		
S019	Injector replacement(per bank)		
S019	Oil change		
S019	Rail pressure sensor replacement		
S019	Replacement Lambda sensor		
S019	Air flow meter sensor replacement		
S019	Phonic wheel replacement		
S019	Differential pressure sensor replacement		
S019	Particulate filter with integrated pre-cat replacement		
S019	Particulate filter regeneration		
S019	Mechanical waste-gate valve replacement		
S019	Replacement of variable geometry turbo and/or turbo posit. Sensor		
S019	Resetting distance travelled with Water Temp. w. lamp ON		
S019	Resetting distance travelled with Water in diesel w. lamp ON		
S020	Headlamp pos. correct.		

LANCIA V15.70 Diagnostics List

(Note:For reference only)

Models	Displacement	Systems	Functions
S020	Inputs status		
S020	Servicing information delete		
S020	Reset odometer		
S020	Seat belts alarm exclusion		
S020	Seat belts alarm Enable		
S020	Instrument panel replacement		
S021	Headlamp pos. correct		
S021	Inputs status		
S021	Reset odometer		
S021	Seat belts alarm exclusion		
S021	Seat belts alarm enable		
S021	Instrument panel replacement		
S022	Flap actuators learning test		
S022	Pollution sensor test		
S023	Tow hook presence disable		
S023	Tow hook presence enable		
S024	Accumulator depressurisation		
S024	Clutch bleed		
S024	End of line / service self-calibration		
S024	Clutch self-calibration enable		
S024	New actuators		
S024	Calculation of clutch degradation index		
S024	Statistical data deletion		
S024	Clutch replacement		
S024	KIT/Gearbox replacement		
S024	Gearbox replacement		
S024	Tunnel lever replacement		

LANCIA V15.70 Diagnostics List

(Note: For reference only)

Models	Displacement	Systems	Functions
S024	Electropump replacement		
S024	Pump relay replacement		
S024	ECO switch replacement		
S024	Gearbox oil accumulator replacement		
S024	Longitudinal acceleration signal learn		
S025	Startup with Code Card		
S025	Phonic wheel learn reset		
S025	Zeroing of self-adaption parameters		
S025	Throttle learn storage		
S025	Vehicle configuration deletion		
S025	Cruise Control Learn		
S025	Air conditioner Learn		
S025	Phase sensor learn zeroing		
S026	Startup with Code Card		
S026	Injector codes read		
S026	Cyl.1 injector classification		
S026	Cyl.2 injector classification		
S026	Cyl.3 injector classification		
S026	Cyl.4 injector classification		
S026	Injector classification (4 cyl.blank)		
S027	Startup with Code Card		
S027	Injector codes read		
S027	Replacement of injector cyl. 1		
S027	Replacement of injector cyl. 2		
S027	Replacement of injector cyl. 3		
S027	Replacement of injector cyl. 4		
S027	Replacement injectors (4 cyl. Bank)		

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S027	Control unit replacement		
S027	Replacement of control unit and injector/s		
S027	Air flow sensor replacement		
S027	Replacement Lambda sensor		
S027	Rail pressure sensor replacement		
S027	Rail pressure sensor and injector/s replacement		
S028	Voice synthesis test		
S028	Cooling fans test		
S028	Automatic emergency call activation		
S028	Manual emergency call activation		
S028	Assistance call activation		
S028	Optical fibre test		
S028	Backup battery replacement		
S028	Personal data deletion		
S028	VIN Code Configuration		
S028	Call buttons Configuration		
S028	Manual System Configuration		
S028	Automatic Configuration Read		
S028	Activation/Deactivation 'Auxiliary video input' procedure		
S029	Dist. To Next Service Zeroing (Coupon)		
S029	Tyre Pressure check	Wheel transmitters learning Looks for faulty wheel transmitter Looks for flat battery on wheel transmitter Maintenance Services config.	
S029	New vehicle preparation	Customer mode Reset distance till next servicing	
S029	Control Unit Replacement	Customer options	

LANCIA V15.70 Diagnostics List <small>(Note:For reference only)</small>			
Models	Displacement	Systems	Functions
S023	Control Unit Replacement	Key programming Closure / Safety Engine / Gearbox Lights / Visibility Various Driver warnings Select the type of vehicle	
S029	Manual System Configuration		
S030	System Configuration Read		
S031	Chassis number		
S032	Stored status deletion		
S033	Part. Filter regeneration		
S034	FAP Replacement		
S034	Additive type configuration		
S034	FAP Temperature Probe presence configuration		
S035	Zeroing of self-adaption parameters		
S036	Additional diesel circuit filling		
S036	Replacement of the additive,or the pump,or the tubes.		
S036	Particulate filter replacement (only for version with DPF)		
S036	EGR valve learn		
S036	Part. Filter regeneration		
S036	Replacement injector/s		
S037	Automatic gearbox replacement		
S037	Automatic gearbox and Control unit replacement		
S037	Automatic gearbox oil replacement		
S038	Part. Filter regeneration		
S039	Startup with Code Card		
S039	Injector codes read		

LANCIA V15.70 Diagnostics List

(Note: For reference only)

Models	Displacement	Systems	Functions
S039	Replacement of injector cyl. 1		
S039	Replacement of injector cyl. 2		
S039	Replacement of injector cyl. 3		
S039	Replacement of injector cyl. 4		
S039	Replacement injector cyl. 5		
S039	Injector replacement (per bank)		
S039	Oil change (only for version with DPF)		
S039	Rail pressure sensor replacement		
S039	Lambda sensor replacement (only for version with lambda sensor)		
S039	Air flow meter replacement (only for version with lambda sensor)		
S039	Differential pressure sensor replacement (only for version with DPF)		
S039	Pre-catalyser replacement (only for version with DPF)		
S039	Particulate filter replacement (only for version with DPF)		
S039	Particulate filter regeneration (only for version with DPF)		
S040	Startup with Code Card		
S040	Injector codes read		
S040	Cyl. 1 injector classification		
S040	Cyl. 2 injector classification		
S040	Cyl. 3 injector classification		
S040	Cyl. 4 injector classification		
S040	Cyl.5 injector classification		
S040	Injector classification (4 cyl. blank)		
S040	Injector classification (5 cyl. blank)		
S041	Siren serial line check		
S041	Ultrasound sensor check		
S041	Tilt sensor check (if present)		
S041	Dusk and rain sensors check		

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S041	Window wash system check		
S041	Country Standards Change		
S042	Sensor vibration time too long		
S043	Accumulator depressurisation		
S043	Clutch bleed		
S043	End of line / service self-calibration		
S043	Clutch self-calibration enable		
S043	New actuators		
S043	Calculation of clutch degradation index		
S043	Statistical data deletion		
S043	Data deletion and return to initial values for clutch replacement		
S043	Data deletion for KIT/Gearbox replacement		
S043	Data deletion for tunnel lever replacement		
S043	Data deletion for pump replacement		
S043	Data deletion for KIT/Pump replacement		
S043	Data deletion for pump relay replacement		
S043	Deletion of statistical data relating to errors		
S044	Servo Mechanism Group Replacement		
S044	Engine - Control Unit Group Replacement		
S045	Steering angle calibration		
S045	Longit.acc.sensor calibration		
S046	Siren serial line check		
S046	Ultrasound sensor check		
S046	Tilt sensor check(if present)		
S046	Dusk and rain sensors check		
S046	Window wash system check		
S047	Dusk and rain sensors check		

LANCIA V15.70 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S047	Window wash system check		
S048	next service km's reset		
S048	Light setting corr.		
S048	trip counter reset		
S049	Startup with Code Card		
S049	Zeroing of self-adaption parameters		
S050	Electronic Key release		
S050	EGR		
S051	Startup with Code Card		
S051	Replacement of injector cyl. 1		
S051	Replacement of injector cyl. 2		
S051	Replacement of injector cyl. 3		
S051	Replacement of injector cyl. 4		
S051	Oil change (only for version with DPF)		
S051	Phonic wheel replacement		
S051	Rail pressure sensor replacement		
S051	Lambda sensor replacement (only for version with lambda sensor)		
S051	Air flow meter replacement (only for version with lambda sensor)		
S051	Differential pressure sensor replacement (only for version with DPF)		
S051	Pre-catalyser replacement (only for version with DPF)		
S051	Particulate filter replacement (only for version with DPF)		
S052	Steering angle calibration		
S052	Test limit speed disable		
S052	Test limit speed restore		
S052	Brake bleed		
S053	Reset self-adapt. param. and idle act		
S054	Oil Counter Write		

LANCIA V15.70 Diagnostics List

(Note: For reference only)

Models	Displacement	Systems	Functions
S054	Self-adaptive parameters		
S054	Sequence EV. 1		
S054	Sequence EV. 2		
S054	Sequence EV. 3		
S054	Sequence EV. 4		
S054	Sequence EV. 5		
S054	Sequence EV. 6		
S054	Heat exchang. Flow EV.		
S055	Accumulator depressurisation		
S055	Clutch bleed		
S055	End of line / service self-calibration		
S055	Clutch self-calibration enable		
S055	New actuators		
S055	Calculation of clutch degradation index		
S055	Engagement lever pin securing screw diagnosis		
S055	Selection lever return diagnosis		
S055	Statistical data deletion		
S055	Deletion of statistical data relating to errors		
S055	Data deletion and return to initial values for clutch replacement		
S055	Data deletion for KIT/Gearbox replacement		
S055	Data deletion for tunnel lever replacement		
S055	Data deletion for pump replacement		
S055	Data deletion for KIT/Pump replacement		
S055	Data deletion for pump relay replacement		
S055	Deletion of CITY switch replacement data		
S055	Deletion of SPORT switch replacement data		
S055	Data deletion for steering wheel levers replacement		

LANCIA V15.70 Diagnostics List

(Note:For reference only)

Models	Displacement	Systems	Functions
S056	Tow hook presence disable		
S056	Tow hook presence enable		
S056	Parking manoeuvre status		
S057	Antenna replacement		
S057	Control unit replacement		
S057	Alarm deletion		
S057	Wheel transmitters learning		
S057	Control unit activation		
S057	Control unit deactivation		
S057	Alarm state check		
S058	Headlamp pos.correct.		
S058	Servicing information delete		
S058	Reset odometer		
S058	Seat belts alarm exclusion		
S058	Seat belts alarm Enable		
S058	Instrument panel replacement		
S059	Tow hook presence disable		
S059	Tow hook presence enable		
S060	Reset odometer		
S060	Servicing information delete		
S060	Odometer write		
S060	Instrument panel replacement		

CONNECTOR	X431/TOOL	DIAGUN
FIAT-3	Old LANCIA Model with 3PIN DLC before 1997	N/A
OBD 16C	LANCIA Model of non-CAN BUS protocol 1997-2005	N/A
SUPER 16	All LANCIA Models with 16PIN DLC	N/A
diagun connector	N/A	All LANCIA Models with 16PIN DLC