

**FORD EUROPEAN
VER. 1.34**

● : SUPPORT
- : NOT SUPPORT

MODEL	SUB MODEL/MODEL YEAR	SYSTEM	SUPPORTED FUNCTION		
			READ DTC	CURRENT DATA	ACTUATOR
CONTINENTAL	1996	POWERTRAIN	●	●	●
		SRS	●	●	-
	1997	POWERTRAIN	●	●	●
		SRS	●	●	-
	1998	POWERTRAIN	●	●	●
		ELEC. CRASH SENSOR(OR IABM)	●	●	-
COUGAR	1997	POWERTRAIN	●	●	●
		POWERTRAIN	●	●	●
	1999	ANTILOCK BRAKE MODULE	●	●	-
		CENTRAL SECURITY MODLE	●	●	-
		ELEC. CRASH SENSOR(OR IABM)	●	●	-
		HYBRID ELEC CLUSTER	●	●	-
CROWN VICTORIA	1996	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		DRIVER DOOR MODULE	●	●	●
		DRIVER SEAT MODULE	●	●	●
		SRS	●	●	-
		LIGHT CONTROL MODULE	●	●	●
	1997	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		DRIVER DOOR MODULE	●	●	●
		DRIVER SEAT MODULE	●	●	●
		SRS	●	●	-
		LIGHT CONTROL MODULE	●	●	●
	1998	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		DRIVER DOOR MODULE	●	●	●
		ELEC. CRASH SENSOR(OR IABM)	●	●	-
		LIGHT CONTROL MODULE	●	●	●
		POWERTRAIN	●	●	●
ECONOLINE	1997	ANTILOCK BRAKE MODULE	●	●	●
		ELEC. CRASH SENSOR(OR IABM)	●	●	-
		POWERTRAIN	●	●	●
	1998	ANTILOCK BRAKE MODULE	●	●	●
		ELEC. CRASH SENSOR(OR IABM)	●	●	-
		POWERTRAIN	●	●	●
	1999	ANTILOCK BRAKE MODULE	●	●	●
		ELEC. CRASH SENSOR(OR IABM)	●	●	-
		POWERTRAIN	●	●	●

**FORD EUROPEAN
VER. 1.34**

● : SUPPORT
- : NOT SUPPORT

MODEL	SUB MODEL/MODEL YEAR		SYSTEM	SUPPORTED FUNCTION				
				READ DTC	CURRENT DATA	ACTUATOR		
ESCORT	1996		POWERTRAIN	●	●	●		
			PASSIVE ANTITHEFT MODULE	●	●	-		
	1997	ELSE	POWERTRAIN	●	●	●		
			ANTILOCK BRAKE MODULE	●	●	-		
			PASSIVE ANTITHEFT MODULE	●	●	-		
			POWERTRAIN	●	●	●		
		1.8L DIESEL	ANTILOCK BRAKE MODULE	●	●	●		
			PASSIVE ANTITHEFT MODULE	●	●	-		
			REMOTE ANTITHEFT MODULE	●	●	-		
			POWERTRAIN	●	●	●		
		2.0L	ANTILOCK BRAKE MODULE	●	●	●		
			REMOTE ANTITHEFT MODULE	●	●	-		
			1998	ELSE	POWERTRAIN	●	●	●
					ANTILOCK BRAKE MODULE	●	●	●
	PASSIVE ANTITHEFT MODULE	●			●	-		
	POWERTRAIN	●			●	●		
	1.8L DIESEL	ANTILOCK BRAKE MODULE		●	●	●		
		PASSIVE ANTITHEFT MODULE		●	●	-		
		REMOTE ANTITHEFT MODULE		●	●	-		
		POWERTRAIN		●	●	●		
	2.0L	ANTILOCK BRAKE MODULE		●	●	●		
		ELEC. CRASH SENSOR(OR IABM)		●	●	-		
		REMOTE ANTITHEFT MODULE		●	●	-		
		1999		ELSE	POWERTRAIN	●	●	●
	ANTILOCK BRAKE MODULE		●		●	●		
	PASSIVE ANTITHEFT MODULE		●		●	-		
	POWERTRAIN		●		●	●		
	1.8L DIESEL		ANTILOCK BRAKE MODULE	●	●	●		
			PASSIVE ANTITHEFT MODULE	●	●	-		
			REMOTE ANTITHEFT MODULE	●	●	-		
			POWERTRAIN	●	●	●		
	2.0L		ANTILOCK BRAKE MODULE	●	●	●		
			ELEC. CRASH SENSOR(OR IABM)	●	●	-		
REMOTE ANTITHEFT MODULE			●	●	-			
EVEREST/ENDEAVOUR					PCM	●	●	-
			TCM	●	●	-		
			ABS	●	●	-		
			SRS	●	●	-		
	EXPEDITION	1998		POWERTRAIN	●	●	●	
			AIR SUSP/EVO (4*2 & 4*4)	●	●	-		
			ANTILOCK BRAKE MODULE	●	●	●		
			GENERIC ELEC MOCULE(OR CTM)	●	●	-		
			SRS	●	●	-		
			REMOTE ANTITHEFT MODULE	●	●	-		
1999			POWERTRAIN	●	●	●		
			AIR SUSP/EVO (4*2 & 4*4)	●	●	-		
			ANTILOCK BRAKE MODULE	●	●	●		
			GENERIC ELEC MOCULE(OR CTM)	●	●	-		
			REMOTE ANTITHEFT MODULE	●	●	-		
			RESTRAINT CONTROL MODULE	●	●	-		
			ELEC AUTO TEMP CONTROL MODULE	●	●	-		

**FORD EUROPEAN
VER. 1.34**

● : SUPPORT
- : NOT SUPPORT

MODEL	SUB MODEL/MODEL YEAR	SYSTEM	SUPPORTED FUNCTION		
			READ DTC	CURRENT DATA	ACTUATOR
EXPLORER	1996	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		AUTO RIDE CONTROL	●	●	-
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		SRS	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
	1997	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		AUTO RIDE CONTROL	●	●	-
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		SRS	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
	1998	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		AUTO RIDE CONTROL	●	●	-
		CENTRAL TIMER MODULE	●	●	-
		DRIVER SEAT MODULE	●	●	-
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		SRS	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
	1999	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		AUTO RIDE CONTROL	●	●	-
		CENTRAL TIMER MODULE	●	●	-
		DRIVER SEAT MODULE	●	●	-
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		PARK AID MODULE	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
		RESTRAINT CONTROL MODULE	●	●	-

**FORD EUROPEAN
VER. 1.34**

● : SUPPORT
- : NOT SUPPORT

MODEL	SUB MODEL/MODEL YEAR		SYSTEM	SUPPORTED FUNCTION		
				READ DTC	CURRENT DATA	ACTUATOR
F-XXX	1997	F-150	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			REMOTE ANTITHEFT MODULE	●	●	-
			SRS	●	●	-
		F-250	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			REMOTE ANTITHEFT MODULE	●	●	-
			SRS	●	●	-
		F-350	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			REMOTE ANTITHEFT MODULE	●	●	-
			SRS	●	●	-
		F-250/350	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			REMOTE ANTITHEFT MODULE	●	●	-
			SRS	●	●	-
	1998	F-150	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			REMOTE ANTITHEFT MODULE	●	●	-
			SRS	●	●	-
		F-250	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			REMOTE ANTITHEFT MODULE	●	●	-
			SRS	●	●	-
		F-350	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			REMOTE ANTITHEFT MODULE	●	●	-
			SRS	●	●	-
		F-250/350	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			REMOTE ANTITHEFT MODULE	●	●	-
			SRS	●	●	-
	1999	F-150	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			CENTRAL TIMER MODULE	●	●	-
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			REMOTE ANTITHEFT MODULE	●	●	-
			RESTRAINT CONTROL MODULE	●	●	-
			POWERTRAIN	●	●	●
		F-250	ANTILOCK BRAKE MODULE	●	●	●
			CENTRAL TIMER MODULE	●	●	-
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			REMOTE ANTITHEFT MODULE	●	●	-
			RESTRAINT CONTROL MODULE	●	●	-
			POWERTRAIN	●	●	●
		F-350	ANTILOCK BRAKE MODULE	●	●	●
			CENTRAL TIMER MODULE	●	●	-
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			REMOTE ANTITHEFT MODULE	●	●	-
			RESTRAINT CONTROL MODULE	●	●	-
			POWERTRAIN	●	●	●
		F-250/350	ANTILOCK BRAKE MODULE	●	●	●
			CENTRAL TIMER MODULE	●	●	-
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			ELEC. CRASH SENSOR(OR IABM)	●	●	-
			OVERHEAD TRIP COMPUTER	●	●	-
			PASSIVE ANTITHEFT MODULE	●	●	-

**FORD EUROPEAN
VER. 1.34**

● : SUPPORT
- : NOT SUPPORT

MODEL	SUB MODEL/MODEL YEAR		SYSTEM	SUPPORTED FUNCTION		
				READ DTC	CURRENT DATA	ACTUATOR
F800	1999		POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
FAIRLANE	1999		POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			BODY CONTROL MODULE	●	●	-
			INSTRUMENT CLUSTER MODULE	●	●	-
FAIRMONT	1999		POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			BODY CONTROL MODULE	●	●	-
			INSTRUMENT CLUSTER MODULE	●	●	-
FALCON FUTURA	1999		POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			BODY CONTROL MODULE	●	●	-
			INSTRUMENT CLUSTER MODULE	●	●	-
FALCON GLI	1999		POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			BODY CONTROL MODULE	●	●	-
			INSTRUMENT CLUSTER MODULE	●	●	-
FIESTA	1996	ELSE	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
		1.8L DIESEL	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
	1997	ELSE	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
		1.8L DIESEL	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
	1998	ELSE	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
		1.8L DIESEL	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
	1999	1.25L CTX	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
		1.25L MTX	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
		1.3L	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			HYBRID ELEC CLUSTER	●	●	-
			PASSIVE ANTITHEFT MODULE	●	●	-
		1.8L DIESEL	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
			REMOTE IMMOBILIZER MODULE	●	●	-
			PASSIVE ANTITHEFT MODULE	●	●	-
	2000	1.25L CTX	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
		1.25L MTX	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
		1.3L	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			HYBRID ELEC CLUSTER	●	●	-
			PASSIVE ANTITHEFT MODULE	●	●	-
		1.8L DIESEL	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
			REMOTE IMMOBILIZER MODULE	●	●	-

**FORD EUROPEAN
VER. 1.34**

● : SUPPORT
- : NOT SUPPORT

MODEL	SUB MODEL/MODEL YEAR		SYSTEM	SUPPORTED FUNCTION		
				READ DTC	CURRENT DATA	ACTUATOR
FIESTA	2001	1.25L CTX	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
		1.25L MTX	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	●
		1.3L	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			HYBRID ELEC CLUSTER	●	●	-
			PASSIVE ANTITHEFT MODULE	●	●	-
		1.8L DIESEL	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
			REMOTE IMMOBILIZER MODULE	●	●	-
			POWERTRAIN	●	●	●
	2002	1.25L CTX	ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
			POWERTRAIN	●	●	●
		1.25L MTX	ANTILOCK BRAKE MODULE	●	●	●
			POWERTRAIN	●	●	●
			POWERTRAIN	●	●	●
		1.3L	ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			HYBRID ELEC CLUSTER	●	●	-
			PASSIVE ANTITHEFT MODULE	●	●	-
			POWERTRAIN	●	●	●
		1.8L DIESEL	ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
			REMOTE IMMOBILIZER MODULE	●	●	-
			POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
	2003	1.25L CTX	PASSIVE ANTITHEFT MODULE	●	●	-
			POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
		1.25L MTX	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			POWERTRAIN	●	●	●
		1.3L	ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			HYBRID ELEC CLUSTER	●	●	-
			PASSIVE ANTITHEFT MODULE	●	●	-
			POWERTRAIN	●	●	●
		1.8L DIESEL	ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
			REMOTE IMMOBILIZER MODULE	●	●	-
			POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
	2004	1.25L CTX	PASSIVE ANTITHEFT MODULE	●	●	-
			POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
		1.25L MTX	POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			POWERTRAIN	●	●	●
		1.3L	ANTILOCK BRAKE MODULE	●	●	●
			GENERIC ELEC MOCULE(OR CTM)	●	●	-
			HYBRID ELEC CLUSTER	●	●	-
			PASSIVE ANTITHEFT MODULE	●	●	-
			POWERTRAIN	●	●	●
		1.8L DIESEL	ANTILOCK BRAKE MODULE	●	●	●
			PASSIVE ANTITHEFT MODULE	●	●	-
			REMOTE IMMOBILIZER MODULE	●	●	-
			POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
	2006		PCM	●	●	-
			ABS	●	●	●
			GEM	●	●	●
			ACM	●	●	-
			EATC	●	●	●
			ICM	●	●	-
			SRM	●	●	-
			TCM	●	●	-

**FORD EUROPEAN
VER. 1.34**

● : SUPPORT
- : NOT SUPPORT

MODEL	SUB MODEL/MODEL YEAR		SYSTEM	SUPPORTED FUNCTION		
				READ DTC	CURRENT DATA	ACTUATOR
FIESTA 3 DOOR	2002		PCM	●	●	-
			ABS	●	●	●
			GEM	●	●	●
			ICM	●	●	-
			TCM	●	●	-
	2006		PCM	●	●	-
			ABS	●	●	●
			GEM	●	●	●
			ACM	●	●	-
			EATC	●	●	●
			ICM	●	●	-
			SRM	●	●	-
			TCM	●	●	-
			PCM	●	●	-
FUSION	2002		ABS	●	●	●
			GEM	●	●	●
			ICM	●	●	-
			TCM	●	●	-
			PCM	●	●	-
	2006		ABS	●	●	●
			GEM	●	●	●
			ACM	●	●	-
			EATC	●	●	●
			ICM	●	●	-
			SRM	●	●	-
			TCM	●	●	-
FOCUS	2000		POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			CENTRAL SECURITY MODULE	●	●	-
			CENTRAL TIMER MODULE	●	●	-
			ELEC. CRASH SENSOR(OR IABM)	●	●	-
			MSG CENTER MODULE	●	●	-
	2001		POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			CENTRAL SECURITY MODLE	●	●	-
			CENTRAL TIMER MODULE	●	●	-
			ELEC. CRASH SENSOR(OR IABM)	●	●	-
			MSG CENTER MODULE	●	●	-
	2002		POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			CENTRAL SECURITY MODLE	●	●	-
			CENTRAL TIMER MODULE	●	●	-
			ELEC. CRASH SENSOR(OR IABM)	●	●	-
			MSG CENTER MODULE	●	●	-
	2003		POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			CENTRAL SECURITY MODLE	●	●	-
			CENTRAL TIMER MODULE	●	●	-
			ELEC. CRASH SENSOR(OR IABM)	●	●	-
			MSG CENTER MODULE	●	●	-
	2004		POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			CENTRAL SECURITY MODLE	●	●	-
			CENTRAL TIMER MODULE	●	●	-
			ELEC. CRASH SENSOR(OR IABM)	●	●	-
			MSG CENTER MODULE	●	●	-
	2005		POWERTRAIN	●	●	●
			ANTILOCK BRAKE MODULE	●	●	●
			SRS	●	●	-
			INSTRUMENT CLUSTER MODULE	●	●	-
			EPS	●	●	-
			POWERTRAIN	●	●	●
	2006		ANTILOCK BRAKE MODULE	●	●	●
			SRS	●	●	-
			INSTRUMENT CLUSTER MODULE	●	●	-
			EPS	●	●	-

**FORD EUROPEAN
VER. 1.34**

● : SUPPORT
- : NOT SUPPORT

MODEL	SUB MODEL/MODEL YEAR	SYSTEM	SUPPORTED FUNCTION		
			READ DTC	CURRENT DATA	ACTUATOR
GRAND MARQUIS	1996	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		DRIVER DOOR MODULE	●	●	●
		DRIVER SEAT MODULE	●	●	●
		SRS	●	●	-
	1997	LIGHT CONTROL MODULE	●	●	●
		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		DRIVER DOOR MODULE	●	●	●
		DRIVER SEAT MODULE	●	●	●
	1998	SRS	●	●	-
		LIGHT CONTROL MODULE	●	●	●
		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		DRIVER DOOR MODULE	●	●	●
	1999	ELEC. CRASH SENSOR(OR IABM)	●	●	-
		LIGHT CONTROL MODULE	●	●	●
		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		DRIVER DOOR MODULE	●	●	●
KA	1998 ~ 2005	ELEC. CRASH SENSOR(OR IABM)	●	●	-
		PASSIVE ANTITHEFT MODULE	●	●	-
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		POWERTRAIN	●	●	●
		RESTRAINT CONTROL MODULE	●	●	-
LS	2000	POWERTRAIN	●	●	●
		POWERTRAIN	●	●	●
LTD	1999	ANTILOCK BRAKE MODULE	●	●	●
		BODY CONTROL MODULE	●	●	-
		INSTRUMENT CLUSTER MODULE	●	●	-
		POWERTRAIN	●	●	●
MONDEO	1996 ~ 1997	ANTILOCK BRAKE MODULE	●	●	●
		PASSIVE ANTITHEFT MODULE	●	●	-
		REMOTE IMMOBILIZER MODULE	●	●	-
		POWERTRAIN	●	●	●
	1998 ~ 2007	ANTILOCK BRAKE MODULE	●	●	●
		REMOTE IMMOBILIZER MODULE	●	●	-
		HYBRID ELEC CLUSTER	●	●	-
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		CENTRAL SECURITY MODLE	●	●	-
		PASSIVE ANTITHEFT MODULE	●	●	-

**FORD EUROPEAN
VER. 1.34**

● : SUPPORT
- : NOT SUPPORT

MODEL	SUB MODEL/MODEL YEAR	SYSTEM	SUPPORTED FUNCTION		
			READ DTC	CURRENT DATA	ACTUATOR
MOUNTAINEER	1997	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		AUTO RIDE CONTROL	●	●	-
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		SRS	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
	1998	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		DRIVER SEAT MODULE	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
		SRS	●	●	-
	1999	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		AUTO RIDE CONTROL	●	●	-
		CENTRAL TIMER MODULE	●	●	-
		DRIVER SEAT MODULE	●	●	-
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
		PARK AID MODULE	●	●	-
MUSTANG	1996	RESTRAINT CONTROL MODULE	●	●	-
		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
	1997	SRS	●	●	-
		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
	1998	SRS	●	●	-
		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
	1999	SRS	●	●	-
		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		RESTRAINT CONTROL MODULE	●	●	-
NAVIGATOR	1998	POWERTRAIN	●	●	●
		AIR SUSP/EVO (4*2 & 4*4)	●	●	-
		ANTILOCK BRAKE MODULE	●	●	●
		DRIVER SEAT MODULE	●	●	-
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		SRS	●	●	-
	1999	REMOTE ANTITHEFT MODULE	●	●	-
		POWERTRAIN	●	●	●
		AIR SUSP/EVO (4*2 & 4*4)	●	●	-
		ANTILOCK BRAKE MODULE	●	●	●
		DRIVER SEAT MODULE	●	●	-
		ELEC AUTO TEMP CONTROL MODULE	●	●	-
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
		RESTRAINT CONTROL MODULE	●	●	-

**FORD EUROPEAN
VER. 1.34**

● : SUPPORT
- : NOT SUPPORT

MODEL	SUB MODEL/MODEL YEAR	SYSTEM	SUPPORTED FUNCTION		
			READ DTC	CURRENT DATA	ACTUATOR
RANGER	1996	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		SRS	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
	1997	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		SRS	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
	1998	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		CENTRAL TIMER MODULE	●	●	-
		ELEC. CRASH SENSOR(OR IABM)	●	●	-
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
	1999	REMOTE ANTITHEFT MODULE	●	●	-
		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		CENTRAL TIMER MODULE	●	●	-
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
TAURUS	1996	REMOTE ANTITHEFT MODULE	●	●	-
		RESTRAINT CONTROL MODULE	●	●	-
		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
	1997	SRS	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
	1998	SRS	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		ELEC. CRASH SENSOR(OR IABM)	●	●	-
	1999	GENERIC ELEC MOCULE(OR CTM)	●	●	-
		SRS	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
		SEMI ACTIVE RIDE CONTROL	●	●	-
THUNDERBIRD	1996	POWERTRAIN	●	●	●
	1997	POWERTRAIN	●	●	●
TOWN CAR	1996	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		DRIVER DOOR MODULE	●	●	●
		DRIVER SEAT MODULE	●	●	●
		SRS	●	●	-
	1997	LIGHT CONTROL MODULE	●	●	●
		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		DRIVER DOOR MODULE	●	●	●
		DRIVER SEAT MODULE	●	●	●
	1998	SRS	●	●	-
		LIGHT CONTROL MODULE	●	●	●
		POWERTRAIN	●	●	●
	1999	ELEC. CRASH SENSOR(OR IABM)	●	●	-
		POWERTRAIN	●	●	●
		RESTRAINT CONTROL MODULE	●	●	-

**FORD EUROPEAN
VER. 1.34**

● : SUPPORT
- : NOT SUPPORT

MODEL	SUB MODEL/MODEL YEAR	SYSTEM	SUPPORTED FUNCTION		
			READ DTC	CURRENT DATA	ACTUATOR
TRACER	1997	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		REMOTE ANTITHEFT MODULE	●	●	-
	1998	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		ELEC. CRASH SENSOR(OR IABM)	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
	1999	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		ELEC. CRASH SENSOR(OR IABM)	●	●	-
TRANSIT	1996 ~ 2005	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		PASSIVE ANTITHEFT MODULE	●	●	-
		REMOTE IMMOBILIZER MODULE	●	●	-
WINDSTAR	1996	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		SRS	●	●	-
	1997	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		SRS	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
	1998	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		GENERIC ELEC MOCULE(OR CTM)	●	●	-
		SRS	●	●	-
		REMOTE ANTITHEFT MODULE	●	●	-
	1999	POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		PARK AID MODULE	●	●	-
		RH POWER SLIDE DOOR MODULE	●	●	-
		LH POWER SLIDE DOOR MODULE	●	●	-
GALAXY	PETROL	POWERTRAIN	●	●	●
	DIESEL	GO TO VW/AUDI SOFTWARE	●	●	-
TOURNEO		POWERTRAIN	●	●	●
		ANTILOCK BRAKE MODULE	●	●	●
		SRS	●	●	-
		CENTRAL SECURITY MODLE	●	●	-
FOCUS C-MAX	ALL MODEL YEARS	POWERTRAIN	●	●	-
		ANTILOCK BRAKE MODULE	●	●	-
		ELEC. CRASH SENSOR(OR IABM)	●	●	-
		INSTRUMENT CLUSTER MODULE	●	●	-
		ELECTRIC POWER STEERING	●	●	-