

## MaxiDiag\_Benz\_V3.00 Function List (Note:For reference only)

## NOTES:

- This function is supported.
- \* This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 11/2005	A-Class	169	Drive	ESM-Electronic selector module	•	•	•	•	•	0
Up to 11/2005	A-Class	169	Drive	FCVT-Continuously variable automatic transmission	•	•		•	•	
Up to 11/2005	A-Class	169	Drive	ME-SFI-Gasoline engine control	•	•		•	•	
Up to 11/2005	A-Class	169	Drive	CDI-Common Rail Diesel Injection	•	•	•		•	
Up to 11/2005	A-Class	169	Chassis	ES-Electrical power steering	•	•		•	•	0
Up to 11/2005	A-Class	169	Chassis	ESP-Electronic stability program	•	•	•	•	•	
Up to 11/2005	A-Class	169	Body	CGW-Central gateway	•	•		•	0	0
Up to 11/2005	A-Class	169	Body	EZS-Electronic ignition switch	•	•		•	•	0
Up to 11/2005	A-Class	169	Body	AB-Airbag	•	•	•	•	•	
Up to 11/2005	A-Class	169	Body	OCP-Overhead control panel	•	•	•	•	•	0
Up to 11/2005	A-Class	169	Body	ATA-Anti-theft alarm system	•	•	•	•	•	0
Up to 11/2005	A-Class	169	Body	SAM-Signal acquisition and actuation module	•	•		•	•	0
Up to 11/2005	A-Class	169	Body	AHE-Trailer recognition	•	•	•	•	•	0
Up to 11/2005	A-Class	169	Body	MSS-Special vehicle multifunction control module	•	•	•		•	0
Up to 11/2005	A-Class	169	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0
Up to 11/2005	A-Class	169	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0
Up to 11/2005	A-Class	169	Body	HRA-FL-Front left headlamp range control	•	•		•	•	0
Up to 11/2005	A-Class	169	Body	System diagnosis (CAN)	•	•		•	•	
Up to 11/2005	A-Class	169	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 11/2005	A-Class	169	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
Up to 11/2005	A-Class	169	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
Up to 11/2005	A-Class	169	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
Up to 11/2005	A-Class	169	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•
Up to 11/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
Up to 11/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 11/2005	A-Class	169	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	•	•	•	•	•	•
Up to 11/2005	A-Class	169	Information and communication	AUDIO	•	•	•	•	•	•
Up to 11/2005	A-Class	169	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
Up to 11/2005	A-Class	169	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
Up to 11/2005	A-Class	169	Information and communication	CDC-CD changer	•	•	0	•	•	•
Up to 11/2005	A-Class	169	Information and communication	VCS-Voice control system	•	•	0	•		•
Up to 11/2005	A-Class	169	Information and communication	SOUND- Sound system	•	•	0	•	•	•
Up to 11/2005	A-Class	169	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•
Up to 11/2005	A-Class	169	Seats and doors	DCM-FL-Door control module front left		•			•	0
Up to 11/2005	A-Class	169	Seats and doors	DCM-FR-Door control module front right		•		•	•	0
Up to 11/2005	A-Class	169	Seats and doors	DCM-RL-Door control module rear left	•	•	•		•	0
Up to 11/2005	A-Class	169	Seats and doors	DCM-RR-Door control module rear right	•	•	•	•	•	0
Up to 11/2005	A-Class	169	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC- Automatic air conditioning/HEAT-Automatic heater	•	•	•	•	•	0
As of 12/2005	A-Class	169	Drive	ESM-Electronic selector module	•	•	•	•	•	0
As of 12/2005	A-Class	169	Drive	FCVT-Continuously variable automatic transmission					•	
As of 12/2005	A-Class	169	Drive	ME-SFI-Gasoline engine control					•	
As of 12/2005	A-Class	169	Drive	TV-TV tuner					•	
As of 12/2005	A-Class	169	Drive	CDI-Common Rail Diesel Injection		•			•	•
As of 12/2005	A-Class	169	Drive	CDI-Common Rail Diesel Injection		•			•	
As of 12/2005	A-Class	169	Drive	N93/4 (Vehicle gateway control unit)		•			0	0
As of 12/2005	A-Class	169	Chassis	ES-Electrical power steering	•	•	•	•	•	0
As of 12/2005	A-Class	169	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
As of 12/2005	A-Class	169	Body	CGW-Central gateway	•	•	•	•	0	0
As of 12/2005	A-Class	169	Body	EZS-Electronic ignition switch		•			•	0
As of 12/2005	A-Class	169	Body	AB-Airbag	•	•	•		•	•
As of 12/2005	A-Class	169	Body	OCP-Overhead control panel	•	•	•	•	•	0
As of 12/2005	A-Class	169	Body	ATA-Anti-theft alarm system	•	•	•	•	•	0
As of 12/2005	A-Class	169	Body	SAM-Signal acquisition and actuation module	•	•	•		•	0
As of 12/2005	A-Class	169	Body	AHE-Trailer recognition	•	•	•		•	0
As of 12/2005	A-Class	169	Body	MSS-Special vehicle multifunction control module	•	•	•		•	0
As of 12/2005	A-Class	169	Body	MSS-Special vehicle multifunction control module	•	•	•		•	0
As of 12/2005	A-Class	169	Body	HRA-FR-Front right headlamp range control	•	•	•		•	0
As of 12/2005	A-Class	169	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 12/2005	A-Class	169	Body	System diagnosis (CAN)						
As of 12/2005	A-Class	169	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
As of 12/2005	A-Class	169	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
As of 12/2005	A-Class	169	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•
As of 12/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	AUDIO	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
As of 12/2005	A-Class	169	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	CDC-CD changer	•	•	0	•	•	•
As of 12/2005	A-Class	169	Information and communication	VCS-Voice control system	•	•	0	•		•
As of 12/2005	A-Class	169	Information and communication	SOUND- Sound system	•	•	0	•	•	•
As of 12/2005	A-Class	169	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	UCI-Media interface	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	DAB-Digital radio	•	•	•	•	•	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 12/2005	A-Class	169	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
As of 12/2005	A-Class	169	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
As of 12/2005	A-Class	169	Seats and doors	DCM-FL-Door control module front left	•		•		•	0
As of 12/2005	A-Class	169	Seats and doors	DCM-FR-Door control module front right			•		•	0
As of 12/2005	A-Class	169	Seats and doors	DCM-RL-Door control module rear left		•	•		•	0
As of 12/2005	A-Class	169	Seats and doors	DCM-RR-Door control module rear right		•	•		•	0
As of 12/2005	A-Class	169	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC- Automatic air conditioning/HEAT-Automatic heater	•	•	•	•	•	0
As of 12/2005	A-Class	169	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)		•	•		•	
As of 12/2005	A-Class	169	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC- Automatic air conditioning/HEAT-Automatic heater	•	•	•	•	•	
ALL	A-Class	168	Drive	ECM-Engine control monolith	•	•	0	•	•	*
ALL	A-Class	168	Drive	ECM-Engine control monolith	•	•	•	•	•	*
ALL	A-Class	168	Drive	ACS-Automatic clutch system	•	•	•	•	•	*
ALL	A-Class	168	Drive	FTC-Front transmission control	•	•	•	•	•	*
ALL	A-Class	168	Drive	FTC2 -Front transmission control2	•	•	•	•	•	•
ALL	A-Class	168	Drive	GRM-Gear recognition module	•	•	•	•	•	*
ALL	A-Class	168	Drive	CDI-Common Rail Diesel Injection		•	•		•	*
ALL	A-Class	168	Chassis	ESP-Electronic stability program		•	0		•	*
ALL	A-Class	168	Chassis	ESP-Electronic stability program		•	0		•	*
ALL	A-Class	168	Body	AB-Airbag		•	0		•	*
ALL	A-Class	168	Body	AB-Airbag		•	0			*
ALL	A-Class	168	Body	RFL-Radio frequency locking/electric central locking		•	0		•	*
ALL	A-Class	168	Body	LCP-Lower control panel		•	0		•	*
ALL	A-Class	168	Body	ATA-Anti-theft alarm system		•	0		•	*
ALL	A-Class	168	Body	APS-Auto pilot system		•	0		•	*
ALL	A-Class	168	Body	HB-Heater booster		•	0			*
ALL	A-Class	168	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*
ALL	A-Class	168	Information and communication	AUDIO	•	•	•	•	•	•
ALL	A-Class	168	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
ALL	A-Class	168	Information and communication	CDC-CD changer	•	•	•	•	0	0
ALL	A-Class	168	Information and communication	PTS-Parktronic system	•	•	•	•	•	*
ALL	A-Class	168		DCM-FL-Door control module front left	•	•	0	•	•	*
ALL	A-Class	168	Seats and doors	DCM-FR-Door control module front right	•	•	0		•	*
ALL	A-Class	168	i	DCM-RL-Door control module rear left	•	•	0		•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	A-Class	168		DCM-RR-Door control module rear right	•	•	0		•	*
ALL	A-Class	168		STH-Stationary heater	•	•	0		•	*
ALL	A-Class	168	Air conditioning	TAC-Automatic temperature control	•	•	•		•	*
Up to 11/2005	B-Class	245	Drive	ESM-Electronic selector module	•	•	•	•	•	0
Up to 11/2005	B-Class	245	Drive	FCVT-Continuously variable automatic transmission	•	•	•	•	•	
Up to 11/2005	B-Class	245	Drive	ME-SFI-Gasoline engine control	•	•	•	•	•	
Up to 11/2005	B-Class	245	Drive	CDI-Common Rail Diesel Injection	•	•	•	•	•	
Up to 11/2005	B-Class	245	Chassis	ES-Electrical power steering	•	•	•	•	•	0
Up to 11/2005	B-Class	245	Chassis	ESP-Electronic stability program	•	•	•		•	
Up to 11/2005	B-Class	245	Body	CGW-Central gateway	•	•	•		0	0
Up to 11/2005	B-Class	245	Body	EZS-Electronic ignition switch		•				0
Up to 11/2005	B-Class	245	Body	AB-Airbag		•				
Up to 11/2005	B-Class	245	Body	OCP-Overhead control panel						0
Up to 11/2005	B-Class	245	Body	ATA-Anti-theft alarm system					•	0
Up to 11/2005	B-Class	245	Body	SAM-Signal acquisition and actuation module		•			•	0
Up to 11/2005	B-Class	245	Body	AHE-Trailer recognition		•	•	•	•	0
Up to 11/2005	B-Class	245	Body	MSS-Special vehicle multifunction control module		•	•	•	•	0
Up to 11/2005	B-Class	245	Body	MSS-Special vehicle multifunction control module		•	•	•	•	0
Up to 11/2005	B-Class	245	Body	XALWA-L-Xenon headlamp, left		•	•	•	•	0
Up to 11/2005	B-Class	245	Body	XALWA-R-Xenon headlamp, right		•	•	•	•	0
Up to 11/2005	B-Class	245	Body	System diagnosis(CAN)		•	•	•	•	
Up to 11/2005	B-Class	245	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 11/2005	B-Class	245	Information and communication	CM-Compass module	•	•	•	•	•	•
Up to 11/2005	B-Class	245	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
Up to 11/2005	B-Class	245	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
Up to 11/2005	B-Class	245	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
Up to 11/2005	B-Class	245	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•
Up to 11/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
Up to 11/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
Up to 11/2005	B-Class	245	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	•	•	•	•	•	•
Up to 11/2005	B-Class	245	Information and communication	AUDIO	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 11/2005	B-Class	245	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
Up to 11/2005	B-Class	245	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
Up to 11/2005	B-Class	245	Information and communication	CDC-CD changer	•	•	0	•	•	•
Up to 11/2005	B-Class	245	Information and communication	VCS-Voice control system	•	•	0	•		•
Up to 11/2005	B-Class	245	Information and communication	SOUND- Sound system	•	•	0	•	•	•
Up to 11/2005	B-Class	245	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
Up to 11/2005	B-Class	245	communication	NAVI-Navigation system	•	•	•	•	•	•
Up to 11/2005	B-Class	245	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
Up to 11/2005	B-Class	245		TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	•	•	•	•		•
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
Up to 11/2005	B-Class	245	Seats and doors	DCM-FL-Door control module front left						0
Up to 11/2005	B-Class	245	Seats and doors	DCM-FR-Door control module front right				•	•	0
Up to 11/2005	B-Class	245		DCM-RL-Door control module rear left	•	•	•	•	•	0
Up to 11/2005	B-Class	245		DCM-RR-Door control module rear right	•	•	•	•	•	0
Up to 11/2005	B-Class	245	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC- Automatic air conditioning/HEAT-Automatic heater	•	•	•	•	•	0
As of 12/2005	B-Class	245	Drive	ESM-Electronic selector module		•	•	•	•	0
		245	Drive	FCVT-Continuously variable automatic transmission	•	•		•	•	
As of 12/2005	B-Class	245		ME-SFI-Gasoline engine control				•	•	•
As of 12/2005	B-Class	245	Drive	ME-SFI-Motor electronics				•	•	
	B-Class	245		ME-SFI-CNG compressed natural gas	•	•		•	•	
	B-Class	245	Drive	BSA-Belt-driven starter/alternator	•	•		•	•	
	B-Class	245		TV-TV tuner	•	•	•	•	•	
As of 12/2005	B-Class	245	Drive	CDI-Common Rail Diesel Injection	•	•	•	•	•	•
	B-Class	245	Drive	CDI-Common Rail Diesel Injection	•	•		•	•	
	B-Class	245	Drive	N93/4 (Vehicle gateway control unit)	•	•	•	•	0	0

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 12/2005	B-Class	245	Chassis	ES-Electrical power steering	•	•	•	•	•	0
As of 12/2005	B-Class	245	Chassis	ESP-Electronic stability program						
As of 12/2005	B-Class	245	Chassis	VP-Vacuum pump brake booster					•	
As of 12/2005	B-Class	245	Chassis	TPC-Tire pressure monitor						
As of 12/2005	B-Class	245	Body	CGW-Central gateway					0	0
As of 12/2005	B-Class	245	Body	EZS-Electronic ignition switch					•	0
As of 12/2005	B-Class	245	Body	AB-Airbag					•	
As of 12/2005	B-Class	245	Body	OCP-Overhead control panel		•			•	0
As of 12/2005	B-Class	245	Body	ATA-Anti-theft alarm system					•	0
As of 12/2005	B-Class	245	Body	SAM-Signal acquisition and actuation module					•	0
As of 12/2005	B-Class	245	Body	AHE-Trailer recognition		•	•	•	•	0
As of 12/2005	B-Class	245	Body	MSS-Special vehicle multifunction control module		•	•	•	•	0
As of 12/2005	B-Class	245	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0
As of 12/2005	B-Class	245	Body	XALWA-L-Xenon headlamp, left	•		•	•	•	0
As of 12/2005	B-Class	245	Body	XALWA-R-Xenon headlamp, right		•	•	•	•	0
As of 12/2005	B-Class	245	Body	System diagnosis (CAN)				•	•	
As of 12/2005	B-Class	245	Body	WSS-Weight sensing system				•	•	
As of 12/2005	B-Class	245	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	CM-Compass module	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
As of 12/2005	B-Class	245	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
As of 12/2005	B-Class	245	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•
As of 12/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	AUDIO	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	COMAND or AUDIO	•	•	0	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 12/2005	B-Class	245	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	CDC-CD changer	•	•	0	•	•	•
As of 12/2005	B-Class	245	Information and communication	VCS-Voice control system	•	•	0	•		•
As of 12/2005	B-Class	245	Information and communication	SOUND- Sound system	•	•	0	•	•	•
As of 12/2005	B-Class	245	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
As of 12/2005	B-Class	245	Information and communication	NAVI-Navigation system	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
As of 12/2005	B-Class	245	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	UCI-Media interface	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	DAB-Digital radio	•	•	•	•	•	0
As of 12/2005	B-Class	245	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
As of 12/2005	B-Class	245	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
As of 12/2005	B-Class	245		DCM-FL-Door control module front left	•	•	•	•	•	0
As of 12/2005	B-Class	245		DCM-FR-Door control module front right	•	•	•	•	•	0
As of 12/2005	B-Class	245	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0
As of 12/2005	B-Class	245	Seats and doors	DCM-RR-Door control module rear right	•	•	•	•	•	0
As of 12/2005	B-Class	245	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC- Automatic air conditioning/HEAT-Automatic heater	•	•	•	•	•	0

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 12/2005	B-Class	245	Air conditioning	Automatic air conditioning/HEAT-Automatic heater	•	•	•	•	•	
As of 12/2005	B-Class	245	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)					•	
ALL	B-Class	246	Drive	PTCU-Common powertrain controller(N127)	•	•	0	•	0	
ALL	B-Class	246	Drive	PTCU-Common powertrain controller(N127)			0		0	
ALL	B-Class	246	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•
ALL	B-Class	246	Drive	ME-Motor electronics 'MED40CNG' for combustion engine 'M274' (N3/10)	•	•	0	•	0	•
ALL	B-Class	246	Drive	FSCU-Fuel pump		•		•	•	
ALL	B-Class	246	Drive	FSCU-Fuel pump	•	•		•	•	
ALL	B-Class	246	Drive	mbrace-mbrace (N123/4)	•	•	0	•	0	
ALL	B-Class	246	Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•
ALL	B-Class	246	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	
ALL	B-Class	246	Drive	CDI-Motor electronics 'CRR1' for combustion engine 'OM607' (N3/9)	•	•	0	•	0	•
ALL	B-Class	246	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	•
ALL	B-Class	246	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•
ALL	B-Class	246	Chassis	EFB-Electronic parking break (N128)	•	•	0	•	0	•
ALL	B-Class	246	Chassis	DTR-DISTRONIC (A89)	•	•	0	•	0	•
ALL	B-Class	246	Chassis	DTR-DISTRONIC (A89)	•	•	0	•	0	•
ALL	B-Class	246	Chassis	TPM-Tire pressure monitor	•	•	0	•	0	•
ALL	B-Class	246	Body	EZS-Electronic ignition switch	•	•	0	•	0	
ALL	B-Class	246	Body	SAM-Signal acquisition and actuation module (N10)	•	•	0	•	0	•
ALL	B-Class	246	Body	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'			0	•	0	
ALL	B-Class	246	Body	IRS-HRA-Outer right rear intelligent radar sensor			0	•	0	
ALL	B-Class	246	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•
ALL	B-Class	246	Body	SRS-Supplemental restraint system (N2/10)	•		0		0	•
ALL	B-Class	246	Body	SG-SW-Control unit 'Headlamp' (N71/1)	•	•	0	•	0	
ALL	B-Class	246	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	B-Class	246	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	B-Class	246	Body	SCM-Steering column module(N80)	•	•	0	•	0	•
ALL	B-Class	246	Body	Trailer recognition module-Trailer recognition (N28/1)	•	•	0	•	0	•
ALL	B-Class	246	Body	ATA-ATA[EDW]/tow-away protection/interior protection(N26/6)	•	•	0	•	0	•
ALL	B-Class	246	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•
ALL	B-Class	246	Information and	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	B-Class	246	Information and communication	DAB-Digital radio	•	•	•	•	•	•
ALL	B-Class	246	Information and communication	DKG-Electronic transmission control for double-plate clutch transmission (N15/13)	•	•	0	•	0	•
ALL	B-Class	246	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	B-Class	246	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	B-Class	246	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	B-Class	246	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	B-Class	246	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•
ALL	B-Class	246	Information and communication	MFK-Multifunction camera	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>
ALL	B-Class	246	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•
ALL	B-Class	246	Information and communication	PTS-Parktronic	•	•	0	•	0	•
ALL	B-Class	246	Information and communication	PTS-PARKTRONIC (N62)	•	•	0	•	0	•
ALL	B-Class	246	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	B-Class	246	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	B-Class	246	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	B-Class	246	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	B-Class	246	Information and communication	Audio-Audio 5 USB(A2)	•	•	0	•	0	•
ALL	B-Class	246		DCU-LF-Left front door (N69/1)	•	•	0	•	0	•
ALL	B-Class	246		DCU-RF-Right front door (N69/2)	•	•	0	•	0	•
ALL	B-Class	246	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function (N32/1)	•	•	0	•	0	•
ALL	B-Class	246	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•
ALL	B-Class	246	Air conditioning	AAC-Air conditioning (N22/7)	•	•	0	•	0	•
ALL	B-Class	246		STH-Stationary heater (A6n1)	•	•	0	•	0	•
ALL	B-Class	246	LIN Bus	UCP-Upper control panel (N72/1)	•	•	0	•	0	•
ALL	B-Class	246	LIN Bus	AISP-Dimming inside rearview mirror (A67)	•	•	0	•	0	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	B-Class	246	LIN Bus	BSN-Battery sensor (B95)	•	•	0		0	
ALL	B-Class	246	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0		0	
ALL	B-Class	246	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•
ALL	B-Class	246	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•
ALL	B-Class	246	LIN Bus	RGLS-Rain/light sensor (B38/2)	•	•	0	•	0	•
ALL	B-Class	246	LIN Bus	OCP-Control unit 'Overhead control panel' (N70)	•	•	0	•	0	•
ALL	B-Class	246	LIN Bus	AS-Alarm siren(H3/1)	•	•	0	•	0	•
ALL	C-Class	204	Drive	ETC-Electronic transmission control	•	•	•		•	•
ALL	C-Class	204	Drive	ETC-Electronic transmission control	•	•	•		•	•
ALL	C-Class	204	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EV0' (N3/10)	•	•	•	•	•	•
ALL	C-Class	204	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•
ALL	C-Class	204	Drive	FSCU-Fuel pump	•	•	•	•	0	•
ALL	C-Class	204	Drive	FSCU-Fuel pump	•	•	•		•	
ALL	C-Class	204	Drive	FSCU-Fuel pump	•	•	•		•	
ALL	C-Class	204	Drive	ESM-Electronic selector module	•	•	•	•	•	•
ALL	C-Class	204	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•
ALL	C-Class	204	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•
ALL	C-Class	204	Drive	MED 17.7-Motor electronics for direct injection 17.7					•	
ALL	C-Class	204	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•
ALL	C-Class	204	Drive	MED 9.7-Motor electronics for direct injection 9.7	•	•	•	•	•	•
ALL	C-Class	204	Drive	FSCU Left-Control unit 'left fuel pump'	•	•	•	•	0	•
ALL	C-Class	204	Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	0	•
ALL	C-Class	204	Drive	DTR-Distronic	•	•		•	•	•
ALL	C-Class	204	Drive	PTCU-Common powertrain controller(N127)	•	•	0	•	0	•
ALL	C-Class	204	Drive	ISM-Shift module (A80)					<b>A</b>	
ALL	C-Class	204	Drive	mbrace-mbrace (N123/4)	•	•	0		0	•
ALL	C-Class	204	Drive	SCR-Selective Catalytic Reduction	•	•	•		•	•
ALL	C-Class	204	Drive	FSCU-Fuel pump					0	
ALL	C-Class	204	Drive	CDID-Common Rail Diesel Injection	•				•	
ALL	C-Class	204	Drive	CDID-Common Rail Diesel Injection					0	
ALL	C-Class	204	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	
ALL	C-Class	204	Drive	ESM-Electronic selector module	•	•	•	•	•	•
ALL	C-Class	204	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	•
ALL	C-Class	204	Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•	
ALL	C-Class	204	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	
ALL	C-Class	204	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	
ALL	C-Class	204	Chassis	ABR-Adaptive Brake	•	•	•	•	•	•
ALL	C-Class	204	Chassis	TPC-Tire pressure monitor		•			•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	C-Class	204	Chassis	TPM - Tire pressure monitor(N88)		•	•			
ALL	C-Class	204	Chassis	AIRMATIC-AIRMATIC						
ALL	C-Class	204	Chassis	ESP-Electronic stability program (N30/4)			0		0	
ALL	C-Class	204	Chassis	EHPS-Electrohydraulic Power Steering			•			
ALL	C-Class	204	Chassis	ES-Electrical power steering (N68)			0		0	
ALL	C-Class	204	Chassis	ESP-Electronic stability program			•	•	•	
ALL	C-Class	204	Chassis	ESP-Regenerative braking system (N30/6)			0		0	
ALL	C-Class	204	Body	CGW-Central gateway			•	•	•	
ALL	C-Class	204	Body	CGW[ZGW]-Central gateway (CGW[ZGW])			0	•	0	
ALL	C-Class	204	Body	CGW-Central gateway			•	•	<b>A</b>	
ALL	C-Class	204	Body	EZS-Electronic ignition switch	•	•	•	•	•	
ALL	C-Class	204	Body	KG-Keyless Go	•	•	•	•	•	
ALL	C-Class	204	Body	KG-KEYLESS GO(N69/5)	•	•	•	•	•	•
ALL	C-Class	204	Body	Trailer recognition module	•	•	•	•	•	
ALL	C-Class	204	Body	AB-Airbag		•	•		•	
ALL	C-Class	204	Body	SRS-Supplemental restraint system (N2/10)	•	•	•	•	<b>A</b>	•
ALL	C-Class	204	Body	SRS-Supplemental restraint system	•	•	•	•	•	•
ALL	C-Class	204	Body	WSS-Weight sensing system	•	•	•	•	•	•
ALL	C-Class	204	Body	OCP-Overhead control panel	•	•	•	•	•	•
ALL	C-Class	204	Body	PSD-Control mudule 'Panoramic sliding roof' (A98)	•	•	•	•	•	•
ALL	C-Class	204	Body	PSD-Control mudule 'Panoramic sliding roof' (A98)	•	•	•	•	•	•
ALL	C-Class	204	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	C-Class	204	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	C-Class	204	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>	
ALL	C-Class	204	Body	REAR SAM-Rear signal acquisition and actuation module	•		•	•	•	
ALL	C-Class	204	Body	Rear SAM-Rear signal acquisition and actuation module			•	•		
ALL	C-Class	204	Body	AHE-Trailer recognition			•		•	
ALL	C-Class	204	Body	MSS-Special vehicle multifunction control module		•	•			
ALL	C-Class	204	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	C-Class	204	Body	RevETR-LF-Left front reversible emergency tensioning retractor(A76)	•	•	•	•	•	•
ALL	C-Class	204	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	C-Class	204	Body	RevETR-RF-Right front reversible emergency tensioning retractor(A76/1)	•	•	•	•	•	•
ALL	C-Class	204	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•
ALL	C-Class	204	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•
ALL	C-Class	204	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	C-Class	204	Body	XALWA-R-Xenon headlamp, right	•			•	•	
ALL	C-Class	204	Body	XALWA-R-Xenon headlamp, right	•	•			•	
ALL	C-Class	204	Body	XALWA-R-Xenon headlamp, right	•	•	•		•	
ALL	C-Class	204	Body	Multifunction control unit-Multifunction control unit (N26/14)	•	•	•	•	•	•
ALL	C-Class	204	Body	EZS-Electronic ignition lock	•	•	•	•	•	•
ALL	C-Class	204	Body	SG-SW-Control unit 'Headlamp' (N71/1)	•		0	•	0	
ALL	C-Class	204	Body	IRS-HRA-Outer right rear intelligent radar sensor	•	•	0	•	0	
ALL	C-Class	204	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•
ALL	C-Class	204	Body	SGR-Radar sensors control unit	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	lack
ALL	C-Class	204	Body	RFK-Backup camera (B84/3)	•	•	0	•	0	•
ALL	C-Class	204	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0	•	0	•
ALL	C-Class	204	Body	SCM-Steering column module(N80)	•	•	0	•	0	•
ALL	C-Class	204	Body	SGR-Radar sensors control unit	•	•	•	•	0	•
ALL	C-Class	204	Information and communication	ES-Electrical power steering	•	•	•	•	•	0
ALL	C-Class	204	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	C-Class	204	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	C-Class	204	Information and communication	ICI-InCar Internet (N125/3)	•	•	0	•	0	•
ALL	C-Class	204	Information and communication	PTS-Parktronic	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	PTS-PARKTRONIC (N62)	•	•	0	•	0	•
ALL	C-Class	204	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	COMAND or AUDIO	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	C-Class	204	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•
ALL	C-Class	204	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	ZBE-Audio/COMAND operating unit(A40/9)	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	TV-TV tuner	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	DAB-Digital radio	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•
ALL	C-Class	204	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	Left rear screen	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	Right rear screen	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
ALL	C-Class	204	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
ALL	C-Class	204	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
ALL	C-Class	204	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	C-Class	204	Information and communication	AMG PM-AMG Performance Media(N125/2)	•	•	0	•	0	•
ALL	C-Class	204	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•
ALL	C-Class	204	Information and communication	Drive-side SAM-Front signal acquisition and actuation module (N10/1)	•	•	0	•	0	•
ALL	C-Class	204	Information and communication	MFK-Multifunction camera	•	•	•	•	•	•
ALL	C-Class	204	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•
ALL	C-Class	204	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•
ALL	C-Class	204	Information and communication	NAVI20 - Navigation(N125/2)	•	•	0	•	0	•
ALL	C-Class	204		DCM-FL-Door control module front left	•	•	•	•	•	•
ALL	C-Class	204		DCU-LF-Left front door	•	•	•	•	•	•
ALL	C-Class	204	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	•
ALL	C-Class	204		DCU-RF-Right front door	•	•	•	•	•	lack
ALL	C-Class	204		DCM-RL-Door control module rear left	•	•	•	•	•	•
ALL	C-Class	204	Seats and doors	DCU-LR-Left rear door	•	•	•	•	•	•
ALL	C-Class	204	Seats and doors	DCM-RR-Door control module rear right	•	•	•	•	•	•
ALL	C-Class	204	Seats and doors	DCU-RR-Right rear door	•				•	
ALL	C-Class	204	Seats and doors	HKS-Tailgate control (N121/1)	•			•	•	
ALL	C-Class	204	Seats and doors	ESA driver	•	•	•	•	•	•
ALL	C-Class	204	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1)	•		0		0	
ALL	C-Class	204	Seats and doors	ESA passenger	•					
ALL	C-Class	204		ESA-Electirc seat adjustment 'Front passenger' (N32/2)	•	•	•	•	•	•
ALL	C-Class	204	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function (N32/2)	•	•	0	•	0	•
ALL	C-Class	204	Air conditioning	Stationary heater	•	•	•	•	•	•
ALL	C-Class	204		AAC-Air conditioning (N22/7)	•	•	•	•	•	•
ALL	C-Class	204		AAC-Air conditioning (N22/7)	•	•	•	•	•	•
ALL	C-Class	204	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)	•	•	0	•	0	
ALL	C-Class	204	BIII BOD	LCP-Lower control panel (S77)			0		0	
ALL	C-Class	204	LIN Bus	GTO-Garage door opener (A67n2)			0		0	
ALL	C-Class	204	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•
ALL	C-Class	204	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•
Up to 08/2003	C-Class	203	Drive	ETC-Electronic transmission control	•	•	0	•	•	*
Up to 08/2003	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 08/2003	C-Class	203	Drive	ESM-Electronic selector module	•	•	•		•	0
Up to 08/2003	C-Class	203	Drive	ME-SFI-Motor electronics	•	•	•		•	
Up to 08/2003	C-Class	203	Drive	DTR-Distronic	•	•	•		•	*
Up to 08/2003	C-Class	203	Drive	ME-SFI-Motor electronics	•	•	•		•	
Up to 08/2003	C-Class	203	Drive	ME-SFI-Motor electronics	•	•	•		•	
Up to 08/2003	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8		•				
Up to 08/2003	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8		•			•	
Up to 08/2003	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection						
Up to 08/2003	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3						
Up to 08/2003	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection						
Up to 08/2003	C-Class	203	Drive	ETC-Electronic transmission control			•		•	
Up to 08/2003	C-Class	203	Chassis	ESP-Electronic stability program			•		•	
Up to 08/2003	C-Class	203	Chassis	ESP-Electronic stability program			•	•	•	
Up to 08/2003	C-Class	203	Chassis	BAS-Brake assist			0	•	•	
Up to 08/2003	C-Class	203	Chassis	VP-Vacuum pump brake booster					•	
Up to 08/2003	C-Class	203	Chassis	ESP-Electronic stability program		•	•		•	
Up to 08/2003	C-Class	203	Body	EZS-Electronic ignition switch			•		•	0
Up to 08/2003	C-Class	203	Body	EZS-Electronic ignition switch			•		•	0
Up to 08/2003	C-Class	203	Body	AB-Airbag	•	•			•	
Up to 08/2003	C-Class	203	Body	OCP-Overhead control panel			•		•	0
Up to 08/2003	C-Class	203	Body	LCP-Lower control panel			•		•	0
Up to 08/2003	C-Class	203	Body	UCP-Upper control panel			•		•	0
Up to 08/2003	C-Class	203	Body	SAM-F-Signal acquisition and actuation module front			•		•	0
Up to 08/2003	C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module			•		•	0
Up to 08/2003	C-Class	203	Body	AHE-Trailer recognition	•	•			•	0
Up to 08/2003	C-Class	203	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0
Up to 08/2003	C-Class	203	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0
Up to 08/2003	C-Class	203	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0
Up to 08/2003	C-Class	203	Body	CGW-Central gateway	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Body	AB-Airbag	•	•	•	•	•	
Up to 08/2003	C-Class	203	Body	WSS-Weight sensing system	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Body	AHE-Trailer recognition	•	•	•	•	•	0
Up to 08/2003	C-Class	203	Body	System diagnosis(CAN)	•		•	•	•	•
	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
Up to 08/2003	C-Class	203	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Information and communication	TV-TV tuner	•	•	•	•		•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 08/2003	C-Class	203	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•
Up to 08/2003	C-Class	203	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
Up to 08/2003	C-Class	203	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
Up to 08/2003	C-Class	203	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Information and communication	AUDIO	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Information and communication	COMAND	•	•	0	•	•	•
Up to 08/2003	C-Class	203	Information and communication	CDC-CD changer	•	•	•	•	0	0
Up to 08/2003	C-Class	203	Information and communication	VCS-Voice control system	•	•	0	•		0
Up to 08/2003	C-Class	203	Information and communication	SOUND- Sound system	•	•	0	•	•	•
Up to 08/2003	C-Class	203	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
Up to 08/2003	C-Class	203	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
Up to 08/2003	C-Class	203	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•
Up to 08/2003	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
Up to 08/2003	C-Class	203	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Information and	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
Up to 08/2003	C-Class	203		AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Information and communication	AUDIO	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
Up to 08/2003	C-Class	203	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 08/2003	C-Class	203	Information and communication	CDC-CD changer	•	•	0	•	•	•
Up to 08/2003	C-Class	203	Information and communication	VCS-Voice control system	•	•	0	•		•
Up to 08/2003	C-Class	203	Information and communication	SOUND- Sound system	•	•	0	•	•	•
Up to 08/2003	C-Class	203	Information and communication	TV-TV tuner	•	•	0	•	•	•
Up to 08/2003	C-Class	203	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
Up to 08/2003	C-Class	203	Information and communication	NAVI-Navigation system	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	•	•	•	•		•
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
Up to 08/2003	C-Class	203	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Seats and doors	DCM-FL-Door control module front left	•	•		•	•	0
Up to 08/2003	C-Class	203	Seats and doors	DCM-FR-Door control module front right	•	•	•		•	0
Up to 08/2003	C-Class	203	Seats and doors	DCM-RL-Door control module rear left	•		•		•	0
Up to 08/2003	C-Class	203	Seats and doors	DCM-RR-Door control module rear right			•		•	0
Up to 08/2003	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
Up to 08/2003	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
Up to 08/2003	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
Up to 08/2003	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
Up to 08/2003	C-Class	203		ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
Up to 08/2003	C-Class	203		ESA driver-Electric seat adjustment driver (with	•	•	•	•	•	0
Up to 08/2003	C-Class	203		AAC-Automatic air conditioning	•	•	•	•	•	•
Up to 08/2003	C-Class	203		STH-Stationary heater	•	•	•	•	•	•
Up to 08/2003	C-Class	203	Air conditioning	STH-Stationary heater	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2003 to 12/2007	C-Class	203	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Drive	ESM-Electronic selector module	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Body	CGW-Central gateway	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Body	EZS-Electronic ignition switch	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Body	AB-Airbag	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Body	OCP-Overhead control panel	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Body	WSS-Weight sensing system	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Body	LCP-Lower control panel	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Body	UCP-Upper control panel	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Body	SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2003 to 12/2007	C-Class	203	Body	AHE-Trailer recognition	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Body	AHE-Trailer recognition	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Body	System diagnosis(CAN)	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
$E_{\text{nom}} = 0.0 / 20.02 + c$	C-Class	203	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
$E_{\text{nom}} = 0.0 / 2002 + c$	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
$E_{\text{nom}} = 0.0 / 2002 + c$	C-Class	203	Information and communication	AUDIO	•	•	•	•	•	•
$E_{\text{nom}} = 0.0 / 20.02 + c$	C-Class	203	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
$E_{nom} = 0.0/2002 + 0.00$	C-Class	203	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
Enam 00/2002 + a	C-Class	203	Information and communication	CDC-CD changer	•	•	0	•	•	•
E 00/2002 +	C-Class	203	Information and communication	VCS-Voice control system	•	•	0	•		•
From 09/2003 to 12/2007	C-Class	203	Information and communication	SOUND- Sound system	•	•	0	•	•	•
From 09/2003 to 12/2007	C-Class	203	Information and communication	TV-TV tuner	•	•	0	•	•	•
From 09/2003 to 12/2007	C-Class	203	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
$E_{\text{nom}} = 0.0 / 2002 + a$	C-Class	203	Information and communication	NAVI-Navigation system	•	•	•	•	•	•
E 00 /0000 + -	C-Class	203	Information and communication	TELE AID-Control unit	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2003 to 12/2007	C-Class	203	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
From 09/2003 to 12/2007	C-Class	203	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
From 09/2003 to 12/2007	C-Class	203	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
E 00/2002 +	C-Class	203	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
$F_{rom} = 00/2003 + 0$	C-Class	203	Information and	CTEL-Cellular telephone	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Seats and doors	DCM-RR-Door control module rear right	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0
Enam 00/2002 +a	C-Class	203	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•
From 09/2003 to 12/2007	C-Class	203	Air conditioning	STH-Stationary heater	•	•	•	•	•	•
	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
As of 01/2008	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
As of 01/2008	C-Class	203	Drive	ESM-Electronic selector module	•	•	•		•	0
As of 01/2008	C-Class	203	Drive	ME-SFI-Motor electronics		•			•	
As of 01/2008	C-Class	203	Drive	ME 9.7-Motor electronics 9.7	•	•	•		•	•
As of 01/2008	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•		•	•
As of 01/2008	C-Class	203	Chassis	ESP-Electronic stability program	•	•			•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 01/2008	C-Class	203	Body	EZS-Electronic ignition switch						0
As of 01/2008	C-Class	203	Body	AB-Airbag	•	•	•		•	
As of 01/2008	C-Class	203	Body	OCP-Overhead control panel	•	•	•		•	0
As of 01/2008	C-Class	203	Body	LCP-Lower control panel	•	•	•		•	0
As of 01/2008	C-Class	203	Body	UCP-Upper control panel	•	•	•	•	•	0
As of 01/2008	C-Class	203	Body	SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0
As of 01/2008	C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0
As of 01/2008	C-Class	203	Body	MSS-Special vehicle multifunction control module	•	•	•		•	0
As of 01/2008	C-Class	203	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	
As of 01/2008	C-Class	203	Body	XALWA-R-Xenon headlamp, right	•	•	•		•	
As of 01/2008	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
As of 01/2008	C-Class	203	Information and communication	PTS-Parktronic system	•	•	•	•	•	0
As of 01/2008	C-Class	203	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
As of 01/2008	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 01/2008	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 01/2008	C-Class	203	Information and communication	AUDIO	•	•	•	•	•	•
As of 01/2008	C-Class	203	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
As of 01/2008	C-Class	203	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of 01/2008	C-Class	203	Information and communication	CDC-CD changer	•	•	0	•	•	•
As of 01/2008	C-Class	203	Information and communication	VCS-Voice control system	•	•	0	•		•
As of 01/2008	C-Class	203	Information and communication	SOUND- Sound system	•	•	0	•	•	•
As of 01/2008	C-Class	203	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
As of 01/2008	C-Class	203	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
As of 01/2008	C-Class	203	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
As of 01/2008	C-Class	203	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
As of 01/2008	C-Class	203	Information and communication	UCI-Media interface	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 01/2008	C-Class	203	Information and communication	DAB-Digital radio	•	•	•	•	•	0
As of 01/2008	C-Class	203	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
As of 01/2008	C-Class	203	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
As of 01/2008	C-Class	203	Seats and doors	DCM-FL-Door control module front left					•	0
As of 01/2008	C-Class	203	Seats and doors	DCM-FR-Door control module front right		•	•		•	0
As of 01/2008	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger		•	•		•	0
As of 01/2008	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver (with	•	•	•		•	0
As of 01/2008	C-Class	203	Air conditioning	AAC-Automatic air conditioning	•	•	•		•	
As of 01/2008	C-Class	203	Air conditioning	STH-Stationary heater	•	•	•		•	
As of 06/97	C-Class	202	Drive	ETC-Electronic transmission control	•	•	0			*
As of 06/97	C-Class	202	Drive	ETC-Electronic transmission control		•	•		•	
As of 06/97	C-Class	202	Drive	ETC-Electronic transmission control		•	0		•	*
As of 06/97	C-Class	202	Drive	ESM-Electronic selector module		•	0		•	*
As of 06/97	C-Class	202	Drive	ME2-SFI-Motor electronics 2	•	•	0		•	*
As of 06/97	C-Class	202	Drive	ME-SFI 2.8-Motor electronics 2.8					•	
As of 06/97	C-Class	202	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•			•	
As of 06/97	C-Class	202	Drive	DFI-Electronic distributor injection system diesel			0			*
As of 06/97	C-Class	202	Drive	IFI-Electronic in-line injection system diesel			0			*
As of 06/97	C-Class	202	Drive	CDI-Common Rail Diesel Injection		•	0			*
As of 06/97	C-Class	202	Drive	ME-SFI-Motor electronics					•	
As of 06/97	C-Class	202	Chassis	ABS-Antilock brake system		•	0		•	*
As of 06/97	C-Class	202	Chassis	ASR-Acceleration Slip Regulation		•	0		•	*
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	•	•	0		•	*
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program		•	•		•	
As of 06/97	C-Class	202	Chassis	ASR-Acceleration Slip Regulation	•	•	0		•	*
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	•	•	0		•	*
As of 06/97	C-Class	202	Chassis	ETS-Electronic traction system		•	0		•	*
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	•	•	0		•	*
As of 06/97	C-Class	202	Chassis	ETS-Electronic traction system		•	0		•	*
As of 06/97	C-Class	202	Chassis	BAS-Brake assist		•	0		•	*
As of 06/97	C-Class	202	Chassis	BAS-Brake assist		•	0		•	
As of 06/97	C-Class	202	Chassis	VP-Vacuum pump brake booster		•	•		•	
As of 06/97	C-Class	202	Body	AB-Airbag		•	0			*
As of 06/97	C-Class	202	Body	EZS-Electronic ignition switch	•	•	0	•	•	*
As of 06/97	C-Class	202	Body	OCP-Overhead control panel	•	•	0	•	•	*
As of 06/97	C-Class	202	Body	LCP-Lower control panel	•	•	0		•	*
As of 06/97	C-Class	202	Body	PSE-Pneumatic system equipment	•	•	0		•	*
As of 06/97	C-Class	202	Body	SAM-Signal acquisition and actuation module	•	•	0	•	•	*
As of 06/97	C-Class	202	Body	MSS-Special vehicle multifunction control module	•		0		•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 06/97	C-Class	202	Body	HRA-Headlamp range adjustment	•	•	0	•		*
As of 06/97	C-Class	202	Body	APS-Auto pilot system	•	•	0			*
As of 06/97	C-Class	202	Body	HB-Heater booster			0			*
As of 06/97	C-Class	202		ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*
As of 06/97	C-Class	202	Information and communication	AUDIO	•	•	•	•	•	•
As of 06/97	C-Class	202	communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
As of 06/97	C-Class	202	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	•	0
As of 06/97	C-Class	202	Information and communication	VCS-Voice control system	•	•	0	•		0
As of 06/97	C-Class	202	Information and communication	CDC-CD changer	•	•	•	•	0	0
As of 06/97	C-Class	202	communication	PTS-Parktronic system	•	•	•	•	•	*
As of 06/97	C-Class	202	communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•
As of 06/97	C-Class	202	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0
As of 06/97	C-Class	202	Information and communication	TELE AID-Emergency call system	•	•	•	•	•	•
As of 06/97	C-Class	202	Information and communication	TELE AID-Telematic system	•	•	0	•		•
	C-Class	202	communication	DN-Dynamic navigation by means of CTEL	•	•	•	•	•	0
As of 06/97	C-Class	202		DCM1-Door control module front driver side	•	•	0	•	•	*
As of 06/97	C-Class	202		DCM2-Door control module front passenger side	•	•	0	•	•	*
As of 06/97	C-Class	202		DCM3-Door control module rear driver side	•	•	0	•	•	*
As of 06/97	C-Class	202		DCM4-Door control module rear passenger side	•	•	0	•	•	*
As of 06/97	C-Class	202		TAC-Automatic temperature control	•	•	0	•		*
As of 06/97	C-Class	202		AAC-Automatic air conditioning	•	•	0	•		*
		202		STH-Stationary heater	•	•	0	•	•	*
	CLK	209		ETC-Electronic transmission control	•	•	•	•		•
Up to 03/2004	CLK	209		ETC-Electronic transmission control	•	•	•	•		•
	CLK	209		SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•
	CLK	209		ETC-Electronic transmission control	•	•	•	•	•	•
-	CLK	209		ESM-Electronic selector module	•	•	•	•	•	0
	CLK	209		ME-SFI-Motor electronics	•	•	•	•	•	•
	CLK	209		ME-SFI-Motor electronics	•	•	•	•	•	•
Up to 03/2004	CLK	209	Drive	DTR-Distronic						*

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 03/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
Up to 03/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	•		•			
Up to 03/2004	CLK	209	Drive	CDI 2-Common Rail Diesel Injection	•	•	•			•
Up to 03/2004	CLK	209	Chassis	ESP-Electronic stability program	•		•			
Up to 03/2004	CLK	209	Body	EZS-Electronic ignition switch	•	•	•	•	•	0
Up to 03/2004	CLK	209	Body	AB-Airbag	•	•	•	•	•	
Up to 03/2004	CLK	209	Body	OCP-Overhead control panel	•	•	•		•	0
Up to 03/2004	CLK	209	Body	LCP-Lower control panel	•	•	•		•	0
Up to 03/2004	CLK	209	Body	UCP-Upper control panel	•	•	•		•	0
Up to 03/2004	CLK	209	Body	SAM-F-Signal acquisition and actuation module front	•	•	•		•	0
Up to 03/2004	CLK	209	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•		•	0
Up to 03/2004	CLK	209	Body	AHE-Trailer recognition	•	•	•		•	0
Up to 03/2004	CLK	209	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0
Up to 03/2004	CLK	209	Body	RVC-Rollover bar soft top control module	•		•			0
Up to 03/2004	CLK	209	Body	HRA-FR-Front right headlamp range control	•					0
Up to 03/2004	CLK	209	Body	HRA-FL-Front left headlamp range control	•					0
Up to 03/2004	CLK	209	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
Up to 03/2004	CLK	209	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
Up to 03/2004	CLK	209	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 03/2004	CLK	209	Information and communication	TV-TV tuner	•	•	•	•		•
Up to 03/2004	CLK	209	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
Up to 03/2004	CLK	209	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
Up to 03/2004	CLK	209	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
Up to 03/2004	CLK	209	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 03/2004	CLK	209	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•
Up to 03/2004	CLK	209	Information and communication	AUDIO	•	•	•	•	•	•
Up to 03/2004	CLK	209	Information and communication	COMAND	•	•	0	•	•	•
Up to 03/2004	CLK	209	Information and communication	CDC-CD changer	•	•	•	•	0	0
Up to 03/2004	CLK	209	Information and communication	VCS-Voice control system	•	•	0	•		0
Up to 03/2004	CLK	209	Information and communication	SOUND- Sound system	•	•	0	•	•	•
Up to 03/2004	CLK	209	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•
Up to 03/2004	CLK	209	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
Up to 03/2004	CLK	209		UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
Up to 03/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment passenger				•	•	0
Up to 03/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
Up to 03/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
Up to 03/2004	CLK	209		ESA driver-Electric seat adjustment driver (with	•	•	•	•	•	0
Up to 03/2004	CLK	209		DCM-L-Door control module left	•	•	•	•	•	0
Up to 03/2004	CLK	209		DCM-R-Door control module right	•	•	•	•	•	0
Up to 03/2004	CLK	209		TLC-Trunk lid control	•	•	•	•	•	•
Up to 03/2004	CLK	209		RCM-Rear control module	•	•	•	•	•	0
Up to 03/2004	CLK	209		AAC-Automatic air conditioning	•	•	•	•	•	•
Up to 03/2004	CLK	209		STH-Stationary heater	•	•	•	•	•	•
As of 04/2004	CLK	209	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
As of 04/2004	CLK	209	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
As of 04/2004	CLK	209	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•
As of 04/2004	CLK	209	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
As of 04/2004	CLK	209	Drive	ESM-Electronic selector module	•	•	•	•	•	0
As of 04/2004	CLK	209	Drive	DTR-Distronic	•	•	•	•	•	•
As of 04/2004	CLK	209	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•
As of 04/2004	CLK	209	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•
As of 04/2004	CLK	209	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•
As of 04/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	
As of 04/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	
As of 04/2004	CLK	209	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	
As of 04/2004	CLK	209	Drive	FSCU Left-Control unit 'Left fuel pump'	•	•	•	•	•	•
As of 04/2004	CLK	209	Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 04/2004	CLK	209	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	
As of 04/2004	CLK	209	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•		•	
As of 04/2004	CLK	209	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•		•	
As of 04/2004	CLK	209	Drive	CDI 2-Common Rail Diesel Injection	•	•	•		•	
As of 04/2004	CLK	209	Chassis	ESP-Electronic stability program	•	•	•		•	
As of 04/2004	CLK	209	Chassis	TPC-Tire pressure monitor		•				
As of 04/2004	CLK	209	Body	EZS-Electronic ignition switch	•	•	•			0
As of 04/2004	CLK	209	Body	AB-Airbag	•	•	•			
As of $04/2004$	CLK	209	Body	OCP-Overhead control panel						0
As of 04/2004	CLK	209	Body	WSS-Weight sensing system		•			•	
As of 04/2004	CLK	209	Body	LCP-Lower control panel	•	•			•	0
As of 04/2004	CLK	209	Body	UCP-Upper control panel	•	•	•	•	•	0
As of 04/2004	CLK	209	Body	SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0
As of 04/2004	CLK	209	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•		•	0
As of 04/2004	CLK	209	Body	AHE-Trailer recognition	•	•	•	•	•	0
As of 04/2004	CLK	209	Body	AHE-Trailer recognition	•	•	•	•	•	0
As of 04/2004	CLK	209	Body	MSS-Special vehicle multifunction control module	•	•		•	•	0
As of 04/2004	CLK	209	Body	RVC-Rollover bar soft top control module	•	•		•	•	0
As of 04/2004	CLK	209	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
As of 04/2004	CLK	209	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0
As of 04/2004	CLK	209	Body	HRA-FL-Front left headlamp range control	•	•		•	•	0
As of 04/2004	CLK	209	Body	On board electrical system(voltage supply)						
As of 04/2004	CLK	209	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
As of 04/2004	CLK	209	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
As of 04/2004	CLK	209	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
As of 04/2004	CLK	209	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 04/2004	CLK	209	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 04/2004	CLK	209	Information and communication	AUDIO	•	•	•	•	•	•
As of 04/2004	CLK	209	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
As of 04/2004	CLK	209	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of 04/2004	CLK	209	Information and communication	CDC-CD changer	•	•	0	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 04/2004	CLK	209	Information and communication	VCS-Voice control system	•	•	0	•		•
As of 04/2004	CLK	209	Information and communication	SOUND- Sound system	•	•	0	•	•	•
As of 04/2004	CLK	209	Information and communication	TV-TV tuner	•	•	0	•	•	•
As of 04/2004	CLK	209	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
As of 04/2004	CLK	209	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
As of 04/2004	CLK	209	Information and communication	NAVI-Navigation system	•	•	•	•	•	•
As of 04/2004	CLK	209	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
As of 04/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment passenger	•					0
As of 04/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•		•	0
As of 04/2004	CLK	209		ESA driver-Electric seat adjustment driver	•		•	•	•	0
As of 04/2004	CLK	209		ESA driver-Electric seat adjustment driver (with	•		•	•	•	0
As of 04/2004	CLK	209		DCM-L-Door control module left	•		•	•	•	0
As of 04/2004	CLK	209		DCM-R-Door control module right			•	•	•	0
As of 04/2004	CLK	209	Seats and doors	TLC-Trunk lid control	•		•	•	•	•
As of 04/2004	CLK	209		RCM-Rear control module	•		•	•	•	0
As of 04/2004	CLK	209		AAC-Automatic air conditioning			•	•	•	•
As of 04/2004	CLK	209		STH-Stationary heater	•		•	•	•	•
ALL	CLK	208	Drive	ETC-Electronic transmission control	•		0	•		*
ALL	CLK	208	Drive	ETC-Electronic transmission control	•	•	•		•	
ALL	CLK	208	Drive	SEQ-Sequentronic automated manual transmission	•	•	•		•	
ALL	CLK	208	Drive	ESM-Electronic selector module	•	•	0	•	•	*
ALL	CLK	208	Drive	ME2-SFI-Motor electronics 2	•	•	0	•	•	*
ALL	CLK	208	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•
ALL	CLK	208	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
ALL	CLK	208	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
ALL	CLK	208	Chassis	ABS-Antilock brake system	•	•	0	•	•	*
ALL	CLK	208	1	ESP-Electronic stability program	•	•	0		•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	CLK	208	Chassis	ESP-Electronic stability program	•	•	•	•	•	
ALL	CLK	208	Chassis	ASR-Acceleration Slip Regulation	•	•	0	•	•	*
ALL	CLK	208	Chassis	BAS-Brake assist	•	•	0		•	*
ALL	CLK	208	Chassis	BAS-Brake assist	•	•	0		•	
ALL	CLK	208	Chassis	VP-Vacuum pump brake booster	•	•	•	•	•	
ALL	CLK	208	Body	AB-Airbag	•	•	0			*
ALL	CLK	208	Body	EZS-Electronic ignition switch	•	•	0	•	•	*
ALL	CLK	208	Body	OCP-Overhead control panel	•	•	0		•	*
ALL	CLK	208	Body	LCP-Lower control panel	•	•	0		•	*
ALL	CLK	208	Body	PSE-Pneumatic system equipment	•	•	0		•	*
ALL	CLK	208	Body	SAM-Signal acquisition and actuation module	•		0		•	*
ALL	CLK	208	Body	HRA-Headlamp range adjustment	•		0			*
ALL	CLK	208	Body	HRA-Headlamp range adjustment	•		0	•	•	0
ALL	CLK	208	Body	APS-Auto pilot system	•		0	•	•	*
ALL	CLK	208	Body	RVC-Rollover bar soft top control module	•	•	0	•		*
ALL	CLK	208	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*
ALL	CLK	208	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	CLK	208	Information and communication	COMAND	•	•	0	•	•	•
ALL	CLK	208	Information and communication	AUDIO	•	•	•	•	•	•
ALL	CLK	208	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0
ALL	CLK	208	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	•	0
ALL	CLK	208	Information and communication	VCS-Voice control system	•	•	0	•		0
ALL	CLK	208	Information and communication	CDC-CD changer	•	•	•	•	0	0
ALL	CLK	208	Information and communication	PTS-Parktronic system	•	•	•	•	•	*
ALL	CLK	208	Information and communication	TV-TV tuner	•	•	•	•		•
ALL	CLK	208	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•
ALL	CLK	208	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0
ALL	CLK	208	Information and communication	TELE AID-Emergency call system	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	CLK	208	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
ALL	CLK	208	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
ALL	CLK	208	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
ALL	CLK	208	Information and communication	DN-Dynamic navigation by means of CTEL	•	•	•	•	•	0
ALL	CLK	208	Seats and doors	DCM1-Door control module front driver side		•	0		•	*
ALL	CLK	208	Seats and doors	DCM2-Door control module front passenger side		•	0		•	*
ALL	CLK	208	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	0	•	•	*
ALL	CLK	208	Seats and doors	ESA-FR-Electric seat adjustment front right	•	•	0	•	•	*
ALL	CLK	208		TAC-Automatic temperature control	•	•	0			*
ALL	CLK	208	Air conditioning	AAC-Automatic air conditioning		•	0			*
ALL	CLK	208	Air conditioning	STH-Stationary heater		•	0		•	*
Up to 05/2005	E-Class	211	Drive	ETC-Electronic transmission control		•	•		•	
Up to 05/2005	E-Class	211	Drive	SEQ-Sequentronic automated manual transmission		•	•		•	
Up to 05/2005	E-Class	211	Drive	ETC-Electronic transmission control		•	•		•	
Up to 05/2005	E-Class	211	Drive	DTR-Distronic		•	•		•	*
Up to 05/2005	E-Class	211	Drive	DTR-Distronic		•	•		•	
Up to 05/2005	E-Class	211	Drive	ME-SFI-Motor electronics		•	•		•	
Up to 05/2005	E-Class	211	Drive	ME-SFI-Motor electronics		•	•		•	
Up to 05/2005	E-Class	211	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Drive	ESM-Electronic selector module		•	•		•	0
Up to 05/2005	E-Class	211	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•		•	•
Up to 05/2005	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•		•	•
Up to 05/2005	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Drive	CDID-Common Rail Diesel Injection	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Drive	TV-TV tuner	•	•	•		•	
Up to 05/2005	E-Class	211	Drive	CDI-V-Common Rail Diesel Injection	•	•	•		•	
Up to 05/2005	E-Class	211	Chassis	SBC-Sensotronic Brake Control	•	•	•		•	
Up to 05/2005	E-Class	211	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Chassis	ESP-Electronic stability program	•	•		•	•	
Up to 05/2005	E-Class	211	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Chassis	AIRmatic	•	•	•	•	•	0
Up to 05/2005	E-Class	211	Chassis	Suspension	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Chassis	TPC-Tire pressure monitor	•	•	•		•	
Up to 05/2005	E-Class	211	Chassis	ABR-Adaptive Brake						

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 05/2005	E-Class	211	Body	CGW-Central gateway	•		•		0	0
Up to 05/2005	E-Class	211	Body	EZS-Electronic ignition switch						0
Up to 05/2005	E-Class	211	Body	AB-Airbag			•		•	
Up to 05/2005	E-Class	211	Body	WSS-Weight sensing system			•		•	
Up to 05/2005	E-Class	211	Body	BCM-Battery control module			•		•	
Up to 05/2005	E-Class	211	Body	On board electrical system(voltage supply)			•		•	
Up to 05/2005	E-Class	211	Body	System diagnosis (CAN)						
Up to 05/2005	E-Class	211	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0
Up to 05/2005	E-Class	211	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0
Up to 05/2005	E-Class	211	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0
Up to 05/2005	E-Class	211	Body	AHE-Trailer recognition	•	•	•	•	•	0
Up to 05/2005	E-Class	211	Body	MSS-Special vehicle multifunction control module	•	•	•		•	0
Up to 05/2005	E-Class	211	Body	LCP-Lower control panel	•	•	•		•	0
Up to 05/2005	E-Class	211	Body	UCP-Upper control panel	•	•			•	0
Up to 05/2005	E-Class	211	Body	OCP-Overhead control panel	•		•		•	0
Up to 05/2005	E-Class	211	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
Up to 05/2005	E-Class	211	Body	On board electrical system(voltage supply)	•		•		•	
Up to 05/2005	E-Class	211	Body	XALWA-L-Xenon headlamp, left	•	•	•		•	•
Up to 05/2005	E-Class	211	Body	XALWA-R-Xenon headlamp, right	•	•	•		•	•
Up to 05/2005	E-Class	211	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
Up to 05/2005	E-Class	211	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
Up to 05/2005	E-Class	211	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 05/2005	E-Class	211	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	AUDIO	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
Up to 05/2005	E-Class	211	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
Up to 05/2005	E-Class	211	Information and communication	CDC-CD changer	•	•	0	•	•	•
Up to 05/2005	E-Class	211	Information and communication	VCS-Voice control system	•	•	0	•		•
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner	•	•	0	•	•	•
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
Up to 05/2005	E-Class	211	Information and communication	GPS box	•	•	0	•	•	•
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
Up to 05/2005	E-Class	211	Information and communication	PTS-Parktronic system	•	•	•	•	•	0
Up to 05/2005	E-Class	211	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	UCI-Media interface	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 05/2005	E-Class	211	Information and communication	DAB-Digital radio	•	•	•	•	•	0
Up to 05/2005	E-Class	211	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner	•	•	•	•	•	•
Up to 05/2005	E-Class	211	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
Up to 05/2005	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver			•			0
Up to 05/2005	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver (with	•	•			•	0
Up to 05/2005	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•			•	0
Up to 05/2005	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•			•	0
Up to 05/2005	E-Class	211	Seats and doors	DS-LF-Left front dynamic seat	•	•	•	•	•	•
Up to 05/2005	E-Class	211		DS-RF-Right front dynamic seat	•	•	•	•	•	•
Up to 05/2005	E-Class	211		DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•
Up to 05/2005	E-Class	211		HS-Seat heater	•	•		•	0	0
Up to 05/2005	E-Class	211		HS-Seat heater	•			•	•	0
Up to 05/2005	E-Class	211		DCM-FL-Door control module front left	•				•	0
Up to 05/2005	E-Class	211		DCM-FR-Door control module front right	•					0
Up to 05/2005	E-Class	211		DCM-RL-Door control module rear left						0
Up to 05/2005	E-Class	211		DCM-RR-Door control module rear right						0
Up to 05/2005	E-Class	211	Seats and doors	TLC-Trunk lid control	•	•	•		•	•
Up to 05/2005	E-Class	211	Seats and doors	LAE [LAA]-Loading floor automatically extendable	•	•	•		•	
Up to 05/2005	E-Class	211	Seats and doors	RWT-Rear-end door control module	•			•	•	0
Up to 05/2005	E-Class	211	Seats and doors	TLC-Trunk lid control						
Up to 05/2005	E-Class	211		AAC-Automatic air conditioning	•		•			
Up to 05/2005	E-Class	211		HSW-Heated steering wheel	•		•			
Up to 05/2005	E-Class	211		HSW-Heated steering wheel	•	•	•		•	0
Up to 05/2005	E-Class	211		STH-Stationary heater	•	•	•	•	•	•
From 06/2005 to										
05/2006	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
05/2006	E-Class	211	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Drive	DTR-Distronic	•	•	•	•	•	•
From 06/2005 to	E-Class	211	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•
From 06/2005 to	E-Class	211	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Drive	ESM-Electronic selector module	•	•	•	•	•	0
From 06/2005 to 05/2006	E-Class	211	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Drive	CDI5-Common Rail Diesel Injection(USA)	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 5-Common Rail Diesel Injection	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Chassis	AIRmatic	•	•	•	•	•	0
From 06/2005 to 05/2006	E-Class	211	Chassis	Suspension	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•
From 06/2005 to	E-Class	211	Body	CGW-Central gateway	•	•	•	•	0	0
From 06/2005 to	E-Class	211	Body	EZS-Electronic ignition switch	•	•	•	•	•	0
E 0C/2005 +-	E-Class	211	Body	AB-Airbag	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 06/2005 to 05/2006	E-Class	211	Body	WSS-Weight sensing system	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Body	BCM-Battery control module	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Body	On board electrical system(voltage supply)	•	•	•	•	•	•
From 06/200E to	E-Class	211	Body	System diagnosis(CAN)	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0
From 06/2005 to	E-Class	211	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0
E 06 /200E +	E-Class	211	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0
From 06/2005 to	E-Class	211	Body	AHE-Trailer recognition	•	•	•	•	•	0
From 06/2005 to	E-Class	211	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0
From 06/200E to	E-Class	211	Body	LCP-Lower control panel	•	•	•	•	•	0
From 06/2005 to	E-Class	211	Body	UCP-Upper control panel	•	•	•	•	•	0
From 06/2005 to	E-Class	211	Body	OCP-Overhead control panel	•	•	•	•	•	0
From 06/2005 to	E-Class	211	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
From 06/2005 to	E-Class	211	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
E 06 /200E +	E-Class	211	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
E 06/200E +	E-Class	211	Body	On board electrical system(voltage supply)	•	•	•	•	•	•
From 06/2005 to	E-Class	211	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
From 06/2005 to	E-Class	211	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
$F_{rom} = 06/2005$ to	E-Class	211	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
$F_{rom} = 06/2005$ to	E-Class	211	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
Enom 06/200E to	E-Class	211	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 06/2005 to 05/2006	E-Class	211	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Information and communication	AUDIO	•	•	•	•	•	•
Enom 06/2005 to	E-Class	211	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
Enom 06/2005 to	E-Class	211	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
Enam 06/200E + a	E-Class	211	Information and communication	CDC-CD changer	•	•	0	•	•	•
E 06/200E +	E-Class	211	Information and communication	VCS-Voice control system	•	•	0	•		•
E 06/200E +	E-Class	211	Information and communication	TV-TV tuner	•	•	0	•	•	•
Enam 06/200E + a	E-Class	211	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
E 06/200E +	E-Class	211	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
E 0C/200E +-	E-Class	211	Information and communication	GPS box	•	•	0	•	•	•
E 0C/200E +-	E-Class	211	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
Enom 06/2005 to	E-Class	211	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
E 0C /200E +-	E-Class	211	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
From 06/2005 to	E-Class	211	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
Enom 06/200E + a	E-Class	211	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
E 0C/200E +-	E-Class	211		ESA driver-Electric seat adjustment driver	•	•	•	•	•	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DS-LF-Left front dynamic seat	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Seats and doors	HS-Seat heater	•	•	•	•	0	0
From 06/2005 to 05/2006	E-Class	211	Seats and doors	HS-Seat heater	•	•	•	•	•	0
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-RR-Door control module rear right	•	•	•	•	•	0
From 06/2005 to 05/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Seats and doors	LAE [LAA]-Loading floor automatically extendable	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Seats and doors	RWT-Rear-end door control module	•	•	•	•	•	0
From 06/2005 to 05/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ARWT-Automatic rear-end door	•	•	•	•	•	0
E 0C /000E +-	E-Class	211	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•
Erram 06/200E +a	E-Class	211	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	•
Erram 06/200E +a	E-Class	211	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0
From 06/2005 to 05/2006	E-Class	211	Air conditioning	STH-Stationary heater	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 06/2006	E-Class	211	Drive	ETC-Electronic transmission control					•	
As of 06/2006	E-Class	211	Drive	ETC-Electronic transmission control					•	
As of 06/2006	E-Class	211	Drive	SEQ-Sequentronic automated manual transmission						
As of 06/2006	E-Class	211	Drive	ETC-Electronic transmission control						
As of 06/2006	E-Class	211	Drive	DTR-Distronic		•			•	
As of 06/2006	E-Class	211	Drive	ME-SFI-Motor electronics		•			•	
As of 06/2006	E-Class	211	Drive	ME-SFI-Motor electronics		•			•	
As of 06/2006	E-Class	211	Drive	ME-SFI-Motor electronics					•	
As of 06/2006	E-Class	211	Drive	ME-SFI-Motor electronics			•		•	
As of 06/2006	E-Class	211	Drive	ESM-Electronic selector module					•	0
As of 06/2006	E-Class	211	Drive	TV-TV tuner			•		•	
As of 06/2006	E-Class	211	Drive	ME 9.7-Motor electronics 9.7			•		•	
As of 06/2006	E-Class	211	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)		•	•		•	
As of 06/2006	E-Class	211	Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	•	
As of 06/2006	E-Class	211	Drive	FSCU Left-Control unit 'Left fuel pump'		•	•		•	
As of 06/2006	E-Class	211	Drive	CDID-Common Rail Diesel Injection	•	•	•	•	•	•
As of 06/2006	E-Class	211	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•
As of 06/2006	E-Class	211	Drive	CDI5-Common Rail Diesel Injection(USA)	•	•	•	•	•	•
As of 06/2006	E-Class	211	Drive	CDI 5-Common Rail Diesel Injection	•	•	•	•	•	•
As of 06/2006	E-Class	211	Chassis	ABR-Adaptive Brake	•	•	•	•	•	•
As of 06/2006	E-Class	211	Chassis	AIRmatic	•	•	•	•	•	0
As of 06/2006	E-Class	211	Chassis	Suspension	•		•	•	•	
As of 06/2006	E-Class	211	Chassis	TPC-Tire pressure monitor			•	•	•	
As of 06/2006	E-Class	211	Body	CGW-Central gateway			•	•	0	0
As of 06/2006	E-Class	211	Body	EZS-Electronic ignition switch			•	•	•	0
As of 06/2006	E-Class	211	Body	AB-Airbag			•	•	•	
As of 06/2006	E-Class	211	Body	WSS-Weight sensing system					•	
As of 06/2006	E-Class	211	Body	System diagnosis (CAN)		•			•	
As of 06/2006	E-Class	211	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0
As of 06/2006	E-Class	211	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0
As of 06/2006	E-Class	211	Body	REAR SAM-Rear signal acquisition and actuation module					•	0
As of 06/2006	E-Class	211	Body	AHE-Trailer recognition	•		•		•	0
As of 06/2006	E-Class	211	Body	MSS-Special vehicle multifunction control module			•		•	0
As of 06/2006	E-Class	211	Body	LCP-Lower control panel	•		•	•	•	0
As of 06/2006	E-Class	211	Body	UCP-Upper control panel	•	•	•	•	•	0
As of 06/2006	E-Class	211	Body	OCP-Overhead control panel	•	•	•	•	•	0
As of 06/2006	E-Class	211	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
As of 06/2006	E-Class	211	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 06/2006	E-Class	211	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•
As of 06/2006	E-Class	211	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	PTS-Parktronic system	•	•	•	•	•	0
As of 06/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
As of 06/2006	E-Class	211	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
As of 06/2006	E-Class	211	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	AUDIO	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
As of 06/2006	E-Class	211	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
As of 06/2006	E-Class	211	Information and communication	CDC-CD changer	•	•	0	•	•	•
As of 06/2006	E-Class	211	Information and communication	VCS-Voice control system	•	•	0	•		•
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner	•	•	0	•	•	•
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner (AGW)	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
As of 06/2006	E-Class	211	Information and communication	GPS box	•	•	0	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 06/2006	E-Class	211	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
As of 06/2006	E-Class	211	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	UCI-Media interface	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	DAB-Digital radio	•	•	•	•	•	0
As of 06/2006	E-Class	211	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner	•	•	•	•	•	•
As of 06/2006	E-Class	211	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
As of 06/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver					•	0
As of 06/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver (with		•			•	0
As of 06/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger		•	•	•	•	0
As of 06/2006	E-Class	211		ESA passenger-Electric seat adjustment passenger	•		•	•	•	0
As of 06/2006	E-Class	211	Seats and doors	DS-LF-Left front dynamic seat		•	•	•	•	
As of 06/2006	E-Class	211	Seats and doors	DS-RF-Right front dynamic seat	•		•	•	•	
As of 06/2006	E-Class	211		DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•
As of 06/2006	E-Class	211		HS-Seat heater		•		•	0	0
As of 06/2006	E-Class	211	Seats and doors	HS-Seat heater		•		•	•	0
As of 06/2006	E-Class	211	Seats and doors	DCM-FL-Door control module front left	•	•		•	•	0
As of 06/2006	E-Class	211		DCM-FR-Door control module front right	•	•	•	•	•	0
As of 06/2006	E-Class	211		DCM-RL-Door control module rear left	•	•		•	•	0
As of 06/2006	E-Class	211		DCM-RR-Door control module rear right	•	•	•	•	•	0
As of 06/2006	E-Class	211		TLC-Trunk lid control	•	•	•	•	•	•
As of 06/2006	E-Class	211		LAE [LAA]-Loading floor automatically extendable	•	•	•	•	•	•
As of 06/2006	E-Class	211		RWT-Rear-end door control module	•	•	•	•	•	0
As of 06/2006	E-Class	211		TLC-Trunk lid control	•	•	•	•	•	•
As of 06/2006	E-Class	211		ARWT-Automatic rear-end door	•	•	•	•	•	0

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 06/2006	E-Class	211	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	
As of 06/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	•	•			•	
As of 06/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	•	•			•	0
	E-Class	211	Air conditioning	STH-Stationary heater	•			•	•	
	E-Class	210	Drive	ETC-Electronic transmission control	•		0	•		*
	E-Class	210	Drive	ETC-Electronic transmission control	•		0	•	•	*
As of 03/97 DAS	E-Class	210	Drive	ETC-Electronic transmission control	•	•	•	•	•	
As of 03/97 DAS	E-Class	210	Drive	ESM-Electronic selector module	•	•	0	•	•	*
	E-Class	210	Drive	ME2-SFI-Motor electronics 2	•	•	0		•	*
As of 03/97 DAS	E-Class	210	Drive	ME-SFI-Motor electronics	•	•	•	•	•	
As of 03/97 DAS	E-Class	210	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	
As of 03/97 DAS	E-Class	210	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	
As of 03/97 DAS	E-Class	210	Drive	DFI-Electronic distributor injection system diesel	•	•	0	•		*
As of 03/97 DAS	E-Class	210	Drive	IFI-Electronic in-line injection system diesel	•	•	0	•		*
As of 03/97 DAS	E-Class	210	Drive	CDI-Common Rail Diesel Injection	•	•	0	•		*
As of 03/97 DAS	E-Class	210	Drive	CDI 2-Common Rail Diesel Injection	•				•	
	E-Class	210	Chassis	ABS-Antilock brake system	•	•	0	•	•	*
	E-Class	210	Chassis	ASR-Acceleration Slip Regulation	•	•	0	•	•	*
	E-Class	210	Chassis	ESP-Electronic stability program	•	•	0	•	•	*
	E-Class	210	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
	E-Class	210	Chassis	ASR-Acceleration Slip Regulation	•	•	0	•	•	*
	E-Class	210	Chassis	ESP-Electronic stability program	•	•	0	•	•	*
	E-Class	210	Chassis	ETS-Electronic traction system	•	•	0	•	•	*
	E-Class	210	Chassis	ESP-Electronic stability program	•	•	0	•	•	*
	E-Class	210	Chassis	ETS-Electronic traction system	•	•	0	•	•	*
	E-Class	210	Chassis	BAS-Brake assist	•	•	0	•	•	*
	E-Class	210	Chassis	BAS-Brake assist	•	•	0	•	•	•
	E-Class	210	Chassis	SPS-Speed-sensitive power steering	•	•	0	•	•	*
	E-Class	210	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	*
	E-Class	210	Chassis	VP-Vacuum pump brake booster	•	•	•	•	•	•
	E-Class	210	Body	AB-Airbag	•	•	0	•	•	*
	E-Class	210	Body	AB-Airbag	•	•	0	•		*
	E-Class	210	Body	EZS-Electronic ignition switch	•	•	0	•	•	*
As of 03/97 DAS		210	Body	OCP-Overhead control panel	•	•	0	•	•	*
As of 03/97 DAS	E-Class	210	Body	LCP-Lower control panel	•	•	0	•	•	*
As of 03/97 DAS		210	Body	PSE-Pneumatic system equipment	•	•	0	•	•	*
		210	Body	SAM-Signal acquisition and actuation module	•	•	0	•	•	*
	E-Class	210	Body	MSS-Special vehicle multifunction control module	•	•	0	•	•	*
	E-Class	210	Body	HRA-Headlamp range adjustment	•	•	0	•		*
	E-Class	210	Body	HRA-Headlamp range adjustment	•	•	0	•	•	0
	E-Class	210	Body	APS-Auto pilot system	•	•	0	•	•	*
	E-Class	210	Body	HB-Heater booster	•	•	0	•	-	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/97 DAS 3	E-Class	210	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*
As of 03/97 DAS 3	E-Class	210	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
As of 03/97 DAS 3	E-Class	210	Information and communication	COMAND	•	•	0	•	•	•
As of 03/97 DAS 3	E-Class	210	Information and communication	AUDIO	•	•	•	•	•	•
As of 03/97 DAS 3	E-Class	210	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
As of 03/97 DAS 3	E-Class	210	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
As of 03/97 DAS 3	E-Class	210	Information and communication	VCS-Voice control system	•	•	0	•		0
As of 03/97 DAS 3	E-Class	210	Information and communication	CDC-CD changer	•	•	•	•	0	0
As of 03/97 DAS 3	E-Class	210	Information and communication	ICS-Information and communication system	•	•	0	•		*
As of 03/97 DAS 3	E-Class	210	Information and communication	PTS-Parktronic system	•	•	•	•	•	*
As of 03/97 DAS 3	E-Class	210	Information and communication	TV-TV tuner	•	•	•	•		•
As of 03/97 DAS 3	E-Class	210	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•
As of 03/97 DAS 3	E-Class	210	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0
As of 03/97 DAS 3	E-Class	210	Information and communication	TELE AID-Emergency call system	•	•	•	•	•	•
As of 03/97 DAS 3	E-Class	210	Information and communication	TELE AID-Telematic system	•	•	0	•		•
As of 03/97 DAS 3	E-Class	210	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
As of 03/97 DAS 3	E-Class	210	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
As of 03/97 DAS 3	E-Class	210	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
As of 03/97 DAS 3	E-Class	210	Information and communication	DN-Dynamic navigation by means of CTEL	•	•	•	•	•	0
As of 03/97 DAS	E-Class	210		DCM1-Door control module front driver side	•	•	0			*
As of 03/97 DAS	E-Class	210	Seats and doors	DCM2-Door control module front passenger side	•	•	0		•	*
	E-Class	210	Seats and doors	DCM3-Door control module rear driver side	•	•	0		•	*
As of 03/97 DAS	E-Class	210	Seats and doors	DCM4-Door control module rear passenger side	•	•	0	•	•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/97 DAS	E-Class	210	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	0		•	*
As of 03/97 DAS	E-Class	210	Seats and doors	ESA-FR-Electric seat adjustment front right	•	•	0		•	*
As of 03/97 DAS	E-Class	210	Air conditioning	TAC-Automatic temperature control	•	•	0			*
As of 03/97 DAS	E-Class	210	Air conditioning	AAC-Automatic air conditioning	•	•	0			*
As of 03/97 DAS	E-Class	210	Air conditioning	STH-Stationary heater	•	•	0		•	*
Up to 05/2005	CLS	219	Drive	ETC-Electronic transmission control	•	•	•		•	
Up to 05/2005	CLS	219	Drive	SEQ-Sequentronic automated manual transmission	•	•	•		•	
Up to 05/2005	CLS	219	Drive	ETC-Electronic transmission control			•		•	
Up to 05/2005	CLS	219	Drive	ME 9.7-Motor electronics 9.7			•		•	
Up to 05/2005	CLS	219	Drive	DTR-Distronic	•	•	•	•	•	
Up to 05/2005	CLS	219	Drive	ESM-Electronic selector module	•	•	•	•	•	0
Up to 05/2005	CLS	219	Drive	MED 9.7-Motor electronics for direct injection 9.7	•	•	•	•	•	
Up to 05/2005	CLS	219	Drive	FSCU-Fuel pump	•	•	•	•	0	
Up to 05/2005	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	
Up to 05/2005	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	
Up to 05/2005	CLS	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)			•	•	•	
Up to 05/2005	CLS	219	Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	•	•
Up to 05/2005	CLS	219	Drive	FSCU Left-Control unit 'Left fuel pump'	•	•	•	•	•	•
Up to 05/2005	CLS	219	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•
Up to 05/2005	CLS	219	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•
Up to 05/2005	CLS	219	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
Up to 05/2005	CLS	219	Chassis	AIRmatic	•	•	•	•	•	0
Up to 05/2005	CLS	219	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•
Up to 05/2005	CLS	219	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•
Up to 05/2005	CLS	219	Body	CGW-Central gateway	•	•	•	•	0	0
Up to 05/2005	CLS	219	Body	EZS-Electronic ignition switch	•	•	•	•	•	0
Up to 05/2005	CLS	219	Body	AB-Airbag	•	•	•	•	•	•
Up to 05/2005	CLS	219	Body	WSS-Weight sensing system	•	•	•	•	•	•
Up to 05/2005	CLS	219	Body	BCM-Battery control module	•	•	•	•	•	•
Up to 05/2005	CLS	219	Body	System diagnosis(CAN)	•	•	•	•	•	•
Up to 05/2005	CLS	219	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0
Up to 05/2005	CLS	219	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0
Up to 05/2005	CLS	219	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•		•	0
Up to 05/2005	CLS	219	Body	LCP-Lower control panel	•	•	•		•	0
Up to 05/2005	CLS	219	Body	UCP-Upper control panel	•	•		•	•	0
Up to 05/2005	CLS	219	Body	OCP-Overhead control panel	•	•		•	•	0
Up to 05/2005	CLS	219	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
Up to 05/2005	CLS	219	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 05/2005	CLS	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
Up to 05/2005	CLS	219	Body	On board electrical system(voltage supply)			•	•	•	
Up to 05/2005	CLS	219	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
Up to 05/2005	CLS	219	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 05/2005	CLS	219	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
Up to 05/2005	CLS	219	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
Up to 05/2005	CLS	219	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	•	•	•	•
Up to 05/2005	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
Up to 05/2005	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
Up to 05/2005	CLS	219	Information and communication	AUDIO	•	•	•	•	•	•
Up to 05/2005	CLS	219	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
Up to 05/2005	CLS	219	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
Up to 05/2005	CLS	219	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
Up to 05/2005	CLS	219	Information and communication	CDC-CD changer	•	•	0	•	•	•
Up to 05/2005	CLS	219	Information and communication	VCS-Voice control system	•	•	0	•		•
Up to 05/2005	CLS	219	Information and communication	TV-TV tuner	•	•	0	•	•	•
Up to 05/2005	CLS	219	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
Up to 05/2005	CLS	219	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
Up to 05/2005	CLS	219	Information and communication	GPS box	•	•	0	•	•	•
Up to 05/2005	CLS	219	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	•	•	•	•		•
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
Up to 05/2005	CLS	219	Seats and doors	ESA driver-Electric seat adjustment driver (with	•	•	•		•	0
Up to 05/2005	CLS	219	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•		•	0
Up to 05/2005	CLS	219		DS-LF-Left front dynamic seat	•	•	•	•	•	•
Up to 05/2005	CLS	219	Seats and doors	DS-RF-Right front dynamic seat	•	•	•		•	
Up to 05/2005	CLS	219	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•
Up to 05/2005	CLS	219	Seats and doors	HS-Seat heater	•	•	•		•	0
Up to 05/2005	CLS	219		DCM-FL-Door control module front left	•	•	•	•	•	0
Up to 05/2005	CLS	219	Seats and doors	DCM-FR-Door control module front right	•	•	•		•	0
Up to 05/2005	CLS	219	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0
Up to 05/2005	CLS	219	Seats and doors	DCM-RR-Door control module rear right	•	•	•		•	0
Up to 05/2005	CLS	219	Seats and doors	TLC-Trunk lid control	•	•	•		•	
Up to 05/2005	CLS	219	Seats and doors	LAE [LAA]-Loading floor automatically extendable	•	•	•		•	
Up to 05/2005	CLS	219	Seats and doors	RWT-Rear-end door control module	•	•	•		•	0
Up to 05/2005	CLS	219	Air conditioning	AAC-Automatic air conditioning	•				•	
Up to 05/2005	CLS	219	Air conditioning	HSW-Heated steering wheel	•	•	•		•	0
Up to 05/2005	CLS	219	Air conditioning	STH-Stationary heater	•				•	
From 06/2005 to 05/2006	CLS	219	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
From 06/2005 to	CLS	219	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Drive	DTR-Distronic	•	•	•	•	•	•
From 06/2005 to	CLS	219	Drive	ESM-Electronic selector module	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Drive	MED 9.7-Motor electronics for direct injection 9.7	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Drive	FSCU-Fuel pump	•	•	•	•	0	•
From 06/2005 to 05/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
From 06/2005 to	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 06/2005 to 05/2006	CLS	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Drive	FSCU Left-Control unit 'Left fuel pump'	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Chassis	AIRmatic	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Body	CGW-Central gateway	•	•	•	•	0	0
From 06/2005 to 05/2006	CLS	219	Body	EZS-Electronic ignition switch	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Body	AB-Airbag	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Body	WSS-Weight sensing system	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Body	BCM-Battery control module	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Body	System diagnosis(CAN)	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Body	LCP-Lower control panel	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Body	UCP-Upper control panel	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Body	OCP-Overhead control panel	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 06/2005 to 05/2006	CLS	219	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Body	On board electrical system(voltage supply)	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
From 06/2005 to 05/2006	CLS	219	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	AUDIO	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	CDC-CD changer	•	•	0	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	VCS-Voice control system	•	•	0	•		•
From 06/2005 to 05/2006	CLS	219	Information and communication	TV-TV tuner	•	•	0	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
From 06/2005 to 05/2006	CLS	219	Information and communication	GPS box	•	•	0	•	•	•
From $06/2005$ to $05/2006$	CLS	219	Information and communication	TELE AID-Control unit	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
From 06/2005 to 05/2006	CLS	219	Information and	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
From 06/2005 to 05/2006	CLS	219	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219		ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Seats and doors	DS-LF-Left front dynamic seat	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Seats and doors	HS-Seat heater	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-RR-Door control module rear right	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Seats and doors	LAE [LAA]-Loading floor automatically extendable	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Seats and doors	RWT-Rear-end door control module	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•
From 06/2005 to 05/2006	CLS	219	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0
From 06/2005 to 05/2006	CLS	219	Air conditioning	STH-Stationary heater	•	•	•	•	•	•
As of 06/2006	CLS	219		ETC-Electronic transmission control	•	•	•	•	•	•
As of 06/2006	CLS	219	Drive	SEQ-Sequentronic automated manual transmission	•	•		•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 06/2006	CLS	219	Drive	ETC-Electronic transmission control	•	•	•		•	
As of 06/2006	CLS	219	Drive	ME 9.7-Motor electronics 9.7			•		•	
As of 06/2006	CLS	219	Drive	DTR-Distronic		•	•		•	
As of 06/2006	CLS	219	Drive	ESM-Electronic selector module			•		•	0
As of 06/2006	CLS	219	Drive	TV-TV tuner		•	•		•	
As of 06/2006	CLS	219	Drive	MED 9.7-Motor electronics for direct injection 9.7		•	•		•	
As of 06/2006	CLS	219	Drive	FSCU-Fuel pump			•		0	
As of 06/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8		•	•		•	
As of 06/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8		•	•		•	
As of $06/2006$	CLS	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)						
As of 06/2006	CLS	219	Drive	FSCU Right-Control unit 'Right fuel pump'			•		•	
As of 06/2006	CLS	219	Drive	FSCU Left-Control unit 'Left fuel pump'			•		•	
As of 06/2006	CLS	219	Drive	CDI 4-Common Rail Diesel Injection			•	•	•	
As of 06/2006	CLS	219	Chassis	ABR-Adaptive Brake			•	•	•	
As of 06/2006	CLS	219	Chassis	AIRmatic			•		•	0
As of 06/2006	CLS	219	Chassis	TPC-Tire pressure monitor		•	•	•	•	
As of 06/2006	CLS	219	Body	CGW-Central gateway			•	•	0	0
As of 06/2006	CLS	219	Body	EZS-Electronic ignition switch			•	•	•	0
As of 06/2006	CLS	219	Body	AB-Airbag			•	•	•	
As of 06/2006	CLS	219	Body	WSS-Weight sensing system			•	•	•	
As of 06/2006	CLS	219	Body	System diagnosis(CAN)	•	•	•	•	•	•
As of 06/2006	CLS	219	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0
As of 06/2006	CLS	219	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0
As of 06/2006	CLS	219	Body	REAR SAM-Rear signal acquisition and actuation module						0
As of 06/2006	CLS	219	Body	LCP-Lower control panel		•	•		•	0
As of 06/2006	CLS	219	Body	UCP-Upper control panel						0
As of 06/2006	CLS	219	Body	OCP-Overhead control panel			•		•	0
As of 06/2006	CLS	219	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
As of 06/2006	CLS	219	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
As of 06/2006	CLS	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
As of 06/2006	CLS	219	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
As of 06/2006	CLS	219	Information and communication	PTS-Parktronic system	•	•	•	•	•	0
As of 06/2006	CLS	219	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 06/2006	CLS	219	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
As of 06/2006	CLS	219	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
As of 06/2006	CLS	219	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	•	•	•	•
As of 06/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 06/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 06/2006	CLS	219	Information and communication	AUDIO	•	•	•	•	•	•
As of 06/2006	CLS	219	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
As of 06/2006	CLS	219	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of 06/2006	CLS	219	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
As of 06/2006	CLS	219	Information and communication	CDC-CD changer	•	•	0	•	•	•
As of 06/2006	CLS	219	Information and communication	VCS-Voice control system	•	•	0	•		•
As of 06/2006	CLS	219	Information and communication	TV-TV tuner	•	•	0	•	•	•
As of 06/2006	CLS	219	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
As of 06/2006	CLS	219	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
As of 06/2006	CLS	219	Information and communication	GPS box	•	•	0	•	•	•
As of 06/2006	CLS	219	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
As of 06/2006	CLS	219	Information and communication	COMAND or AUDIO	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 06/2006	CLS	219	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
As of 06/2006	CLS	219	Information and communication	UCI-Media interface	•	•	•	•	•	•
As of 06/2006	CLS	219	Information and communication	DAB-Digital radio	•	•	•	•	•	0
As of 06/2006	CLS	219	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
As of 06/2006	CLS	219	Information and communication	TV-TV tuner	•	•	•	•	•	•
As of 06/2006	CLS	219	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
As of 06/2006	CLS	219	Seats and doors	ESA driver-Electric seat adjustment driver (with		•			•	0
As of 06/2006	CLS	219	Seats and doors	ESA passenger-Electric seat adjustment passenger		•			•	0
As of 06/2006	CLS	219	Seats and doors	DS-LF-Left front dynamic seat	•		•			•
As of 06/2006	CLS	219	Seats and doors	DS-RF-Right front dynamic seat	•					•
As of 06/2006	CLS	219	Seats and doors	DSP-Pneumatic pump for dynamic seat	•					•
As of 06/2006	CLS	219	Seats and doors	HS-Seat heater	•					0
As of 06/2006	CLS	219	Seats and doors	DCM-FL-Door control module front left	•					0
As of 06/2006	CLS	219	Seats and doors	DCM-FR-Door control module front right	•					0
As of 06/2006	CLS	219	Seats and doors	DCM-RL-Door control module rear left	•					0
As of 06/2006	CLS	219	Seats and doors	DCM-RR-Door control module rear right	•	•	•		•	0
As of 06/2006	CLS	219	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•
As of 06/2006	CLS	219	Seats and doors	LAE [LAA]-Loading floor automatically extendable	•	•	•	•	•	•
As of 06/2006	CLS	219	Seats and doors	RWT-Rear-end door control module		•	•	•	•	0
As of 06/2006	CLS	219	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•
As of 06/2006	CLS	219	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0
As of 06/2006	CLS	219	Air conditioning	STH-Stationary heater	•	•	•	•	•	•
ALL	CLS	218	Drive	DTR-Distronic		•	•	•	•	•
ALL	CLS	218	Drive	ME 9.7-Motor electronics 9.7	•	•	•		•	•
ALL	CLS	218	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•
ALL	CLS	218	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•	
ALL	CLS	218	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•
ALL	CLS	218	Drive	MED 9.7-Motor electronics for direct injection 9.7	•	•	•	•	•	•
ALL	CLS	218	Drive	ISM-Shift module (A80)	<b>A</b>			<b>A</b>	<b>A</b>	<b>A</b>
ALL	CLS	218	Drive	FSCU-Fuel pump	•	•	•	•	•	•
ALL	CLS	218	Drive	FSCU-Fuel pump	•	•	•	•	•	•
ALL	CLS	218	Drive	mbrace-mbrace (N123/4)	•	•	0	•	0	•
ALL	CLS	218	Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•
ALL	CLS	218	Drive	ESM-Electronic selector module	•	•	•	•	•	•
ALL	CLS	218	Drive	FSCU-Fuel pump	•	•	•	•	0	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	CLS	218	Drive	ETC-Electronic transmission control	•					
ALL	CLS	218	Drive	CDI-Motor electronics 'CR42' for combustion engine 'OM607' (N3/9)	•	•	0	•	0	•
ALL	CLS	218	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9)	•	•	0	•	0	•
ALL	CLS	218	Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•	
ALL	CLS	218	Drive	CDI-Motor electronics 'CDI61' for combustion engine 'OM642' (N3/9)	•	•	0	•	0	•
ALL	CLS	218	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	
ALL	CLS	218	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	
ALL	CLS	218	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	
ALL	CLS	218	Chassis	ESP-Electronic stability program	•	•		•	•	
ALL	CLS	218	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	
ALL	CLS	218	Chassis	FWGW-Chassis gateway (N97/7)	•		0	•	0	
ALL	CLS	218	Chassis	TPM - Tire pressure monitor(N88)	•			•	•	
ALL	CLS	218	Body	CGW[ZGW]-Central gateway (CGW[ZGW])			0		0	
ALL	CLS	218	Body	CGW-Central gateway					•	
ALL	CLS	218	Body	CGW-Central gateway					<b>A</b>	
ALL	CLS	218	Body	EZS-Electronic ignition lock	•			•	•	
ALL	CLS	218	Body	EZS-Electronic ignition lock (N73)	•		0	•	0	
ALL	CLS	218	Body	XALWA-L-Left xenon headlamp(E1n1)	•	•	0	•	0	
ALL	CLS	218	Body	XALWA-R-Right xenon headlamp(E2n1)	•		0	•	0	
ALL	CLS	218	Body	SGR-Radar sensors control unit					<b>A</b>	
ALL	CLS	218	Body	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'		•	0		0	
ALL	CLS	218	Body	IRS-HRA-Outer right rear intelligent radar sensor		•	0		0	
ALL	CLS	218	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•
ALL	CLS	218	Body	KG-KEYLESS GO (N69/5)	•		0	•	0	
ALL	CLS	218	Body	KG-Keyless Go	•			•	•	
ALL	CLS	218	Body	WSS-Weight sensing system	•			•	•	
ALL	CLS	218	Body	SRS-Supplemental restraint system (N2/10)	•	•	•	•	<b>A</b>	•
ALL	CLS	218	Body	SRS-Supplemental restraint system	•	•		•	•	•
ALL	CLS	218	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	CLS	218	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	CLS	218	Body	RFK-Backup camera (B84/3)	•	•	0	•	0	•
ALL	CLS	218	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	CLS	218	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	CLS	218	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>	
ALL	CLS	218	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	
ALL	CLS	218	Body	Rear SAM-Rear signal acquisition and actuation module	•					
ALL	CLS	218	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0		0	
ALL	CLS	218	Body	SCM-Steering column module(N80)		•	0	•	0	
ALL	CLS	218	Body	Trailer recognition module		•	•	•	•	
ALL	CLS	218	Body	PSD-Control mudule 'Panoramic sliding roof' (A98)			•	•	•	
ALL	CLS	218	Body	SGR-Radar sensors control unit	•		•	•	0	•
ALL	CLS	218	Information and communication	ES-Electrical power steering	•	•	•	•	•	0
ALL	CLS	218	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	CLS	218	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	CLS	218	Information and communication	ICI-InCar Internet (N125/3)	•	•	0	•	0	•
ALL	CLS	218	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	CLS	218	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•
ALL	CLS	218	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•
ALL	CLS	218	Information and communication	DAB-Digital radio	•	•	•	•	•	•
ALL	CLS	218	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	CLS	218	Information and communication	Left rear screen	•	•	•	•	•	•
ALL	CLS	218	Information and communication	Right rear screen	•	•	•	•	•	•
ALL	CLS	218	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•
ALL	CLS	218	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•
ALL	CLS	218	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•
ALL	CLS	218	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
ALL	CLS	218	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	CLS	218	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
ALL	CLS	218	Information and communication	MFK-Multifunction camera	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>
ALL	CLS	218	Information and communication	NSA-Night View Assist	•	•	•	•	•	0
ALL	CLS	218	Information and communication	NSA-Night View Assist(N101)	•	•	0	•	0	•
ALL	CLS	218	Information and communication	PTS-Parktronic	•	•	0	•	0	•
ALL	CLS	218	Information and communication	PTS-PARKTRONIC (N62)	•	•	0	•	0	•
ALL	CLS	218	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•
ALL	CLS	218	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	CLS	218	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	CLS	218	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	CLS	218	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•
ALL	CLS	218	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•
ALL	CLS	218	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	•
ALL	CLS	218	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	CLS	218	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	CLS	218	Information and communication	NAVI20 - Navigation(N125/2)	•	•	0	•	0	•
ALL	CLS	218	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
ALL	CLS	218	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
ALL	CLS	218	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
ALL	CLS	218	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	•	•	•	•		•
ALL	CLS	218	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	CLS	218	Seats and doors	DCU-LF-Left front door	•	•				
ALL	CLS	218	Seats and doors	DCU-RF-Right front door					•	
ALL	CLS	218	Seats and doors	DCU-LR-Left rear door					•	
ALL	CLS	218	Seats and doors	DCU-RR-Right rear door	•	•	•	•	•	
ALL	CLS	218	Seats and doors	SIH-FOND-Rear passenger compartment seat heater	<b>A</b>			<b>A</b>	<b>A</b>	
ALL	CLS	218	Seats and doors	AMKS-LF-Active multicontour seat(N32/19)	•	•	•	•	•	
ALL	CLS	218	Seats and doors	AMKS-RF-Active multicontour seat(N32/22)	•	•	•	•	•	
ALL	CLS	218	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	
ALL	CLS	218		HKS-Tailgate control (N121/1)	•	•	•	•	•	
ALL	CLS	218	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1)	•	•	0	•	0	
ALL	CLS	218	Seats and doors	ESA driver	•	•	•	•	•	
ALL	CLS	218	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•
ALL	CLS	218	Seats and doors	ESA passenger			•	•	•	•
ALL	CLS	218		AAC-Air conditioning (N22/7)	•		•		•	
ALL	CLS	218		Stationary heater	•		•		•	
ALL	CLS	218	LIN Bus	AU-Analog clock (A70/1)	•		0		0	
ALL	CLS	218	LIN Bus	LCP-Lower control panel (S77)	•		0		0	
ALL	CLS	218	LIN Bus	AISP-Dimming inside rearview mirror (A67)			0	•	0	•
ALL	CLS	218	LIN Bus	GTO-Garage door opener (A67n2)	•		0	•	0	•
				AMLAB-L 2-Actuation module 2, LED exterior lighting,	•	<u> </u>				•
ALL	CLS	218	LIN Bus	left front (E1n8)	•	•	0	•	0	_
ALL	CLS	218	LIN Bus	AMLAB-R 2-Actuation module 2, LED exterior lighting, right front (E2n8)	•	•	0	•	0	•
ALL	CLS	218	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	•	•	0	•	0	•
ALL	CLS	218	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•
Up to 06/2009	S-Class	221	Drive	ISM-Intelligent servo module	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Drive	ISM-Shift module (A80)	<b>A</b>		<b>A</b>	<b>A</b>	<b>A</b>	
Up to 06/2009	S-Class	221	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Drive	ETC-Electronic transmission control	•	•	•	•	•	
Up to 06/2009	S-Class	221	Drive	ETC-Electronic transmission control	•	•	•	•		•
Up to 06/2009	S-Class	221	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•		•
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•	•	0	•
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Drive	DTR-Distronic	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Drive	SGR-Radar sensors control unit	•	•	•	•	•	0
Up to 06/2009	S-Class	221	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump AMG	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•	•	0	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 06/2009	S-Class	221	Drive	CDI 5-Common Rail Diesel Injection	•	•	•		•	
Up to 06/2009	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•		•	
Up to 06/2009	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•		•	
Up to 06/2009	S-Class	221	Chassis	ABR-Adaptive Brake	•	•	•		•	
Up to 06/2009	S-Class	221	Chassis	AIRmatic	•	•	•		•	
Up to 06/2009	S-Class	221	Chassis	ABC-ABC active body control	•	•	•		•	
Up to 06/2009	S-Class	221	Chassis	Electronic parking brake-Electric parking brake	•	•	•		•	
Up to 06/2009	S-Class	221	Chassis	TPC-Tire pressure monitor	•	•	•		•	
Up to 06/2009	S-Class	221	Body	CGW-Central gateway	•	•	•		0	
Up to 06/2009	S-Class	221	Body	EZS-Electronic ignition switch	•	•	•		•	
Up to 06/2009	S-Class	221	Body	EZS-Electronic ignition switch	•	•	•		•	
Up to 06/2009	S-Class	221	Body	KG-Keyless Go		•			•	
Up to 06/2009	S-Class	221	Body	KG-KEYLESS GO		•			•	
Up to 06/2009	S-Class	221	Body	MSS-Special vehicle multifunction control module					•	
Up to 06/2009	S-Class	221	Body	AB-Airbag		•	•		•	
Up to 06/2009	S-Class	221	Body	WSS-Weight sensing system				•	•	0
Up to 06/2009	S-Class	221	Body	WSS-Weight sensing system				•	•	
Up to 06/2009	S-Class	221	Body	OCP-Overhead control panel	•		•		•	
Up to 06/2009	S-Class	221	Body	UCP-Upper control panel	•		•		•	
Up to 06/2009	S-Class	221	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Body	REAR SAM-Rear signal acquisition and actuation module				•	•	
Up to 06/2009	S-Class	221	Body	BNS-Vehicle power supply control module	•		•		•	0
Up to 06/2009	S-Class	221	Body	AHE-Trailer recognition	•		•		•	
Up to 06/2009	S-Class	221	Body	PSD-Panoramic sliding roof(Interior CAN bus)	•	•	•		•	
Up to 06/2009	S-Class	221	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Body	XALWA-L-Xenon headlamp, left		•			•	
Up to 06/2009	S-Class	221	Body	XALWA-L-Xenon headlamp, left				•	•	
Up to 06/2009	S-Class	221	Body	XALWA-R-Xenon headlamp, right			•	•	•	
Up to 06/2009	S-Class	221	Body	XALWA-R-Xenon headlamp, right	•		•		•	
Up to 06/2009	S-Class	221	Body	System diagnosis(CAN)		•	•		•	0
Up to 06/2009	S-Class	221	Body	COU [ZBE]-Central operating unit			•		•	
Up to 06/2009	S-Class	221	Body	HBF (Rear control panel)-Rear control field		•	•	•	•	
Up to 06/2009	S-Class	221	Information and communication	NSA-Night View Assist	•	•	•	•	•	0
Up to 06/2009	S-Class	221	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	IC-Instrument cluster	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 06/2009	S-Class	221	Information and communication	ASSYST-Active Service System	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	ASSYST PLUS	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	PTS-Parktronic	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	COMAND	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	COMAND	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	Tuner-Standard tuner	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	Tuner-Tuner sound	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	Tuner-Tuner sound	•	•	•	•	0	0
Up to 06/2009	S-Class	221	Information and communication	VCS-Voice control	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and	DAB-Digital radio	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	ZAN-Central display	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	UCI-Media interface	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	Left rear screen	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	Right rear screen	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Control unit	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	•	•	•	•		•
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
Up to 06/2009	S-Class	221	Seats and doors	DS-LF-Left front dynamic seat	•	•		•	•	
Up to 06/2009	S-Class	221	Seats and doors	DS-RF-Right front dynamic seat	•	•			•	
Up to 06/2009	S-Class	221	Seats and doors	MKL-HL-Rear left multicontour backrest	•	•	•	•	•	
Up to 06/2009	S-Class	221	Seats and doors	MKL-HR-Rear right multicontour backrest	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	
Up to 06/2009	S-Class	221	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	
Up to 06/2009	S-Class	221	Seats and doors	DCM-FR-Door control module front right					•	
Up to 06/2009	S-Class	221	Seats and doors	DCM-RL-Door control module rear left		•	•		•	
Up to 06/2009	S-Class	221	Seats and doors	DCM-RR-Door control module rear right					•	
Up to 06/2009	S-Class	221	Seats and doors	ESA-FL-Electric seat adjustment front left					•	
Up to 06/2009	S-Class	221	Seats and doors	ESA-FR-Electric seat adjustment front right		•	•		•	
Up to 06/2009	S-Class	221	Seats and doors	ESA-R-Electric seat adjustment rear		•	•		•	
Up to 06/2009	S-Class	221	Seats and doors	TLC-Trunk lid control					•	
Up to 06/2009	S-Class	221	Seats and doors	TLC-Trunk lid control					•	
Up to 06/2009	S-Class	221	Seats and doors	TSG-ML-Left center door control unit (interior Can	•	•	•	•	•	
Up to 06/2009	S-Class	221	Seats and doors	TSG-MR-Right center door control unit (interior Can					•	
Up to 06/2009	S-Class	221		AAC-Automatic air conditioning	•	•	•	•	•	•
Up to 06/2009	S-Class	221	Air conditioning	STH-Stationary heater with remote control	•	•	•	•	•	
Up to 06/2009	S-Class	221	Air conditioning	KBE-H-Rear A/C operating unit	•	•	•	•	•	
As of 07/2009	S-Class	221	Drive	ISM-Shift module (A80)					<b>A</b>	
As of 07/2009	S-Class	221	Drive	ETC-Electronic transmission control	•	•	•		•	•
As of 07/2009	S-Class	221	Drive	ETC-Electronic transmission control	•	•	•		•	
As of 07/2009	S-Class	221	Drive	ME 9.7-Motor electronics 9.7	•	•	•		•	
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•	•	0	•
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•	•	<u> </u>	•
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•	•	•	•
As of 07/2009	S-Class	221	Drive	DTR-Distronic	•	•	•	•	•	•
As of 07/2009	S-Class	221	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•	
As of 07/2009	S-Class	221	Drive	ME-SF 17.7-Motor electronics 17.7	•	•	•	•	•	
As of 07/2009	S-Class	221	Drive	SG-EM - Electric motor control unit	•	•	•	•	•	•
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•	•	0	•
As of 07/2009	S-Class	221	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump AMG	•	•	•	•	•	•
As of 07/2009	S-Class	221	Drive	CDI 3-Common Rail Diesel Injection3					•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 07/2009	S-Class	221	Drive	CDI 5-Common Rail Diesel Injection	•	•	•	•	•	
As of 07/2009	S-Class	221	Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•	
As of 07/2009	S-Class	221	Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	
As of 07/2009	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	
As of 07/2009	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2		•	•		•	
As of 07/2009	S-Class	221	Chassis	ABR-Adaptive Brake		•	•		•	
As of 07/2009	S-Class	221	Chassis	ABR-Adaptive Brake		•	•		•	
As of 07/2009	S-Class	221	Chassis	AIRmatic			•		•	
As of 07/2009	S-Class	221	Chassis	ABC-ABC active body control			•		•	
As of 07/2009	S-Class	221	Chassis	Electronic parking brake-Electric parking brake			•		•	
As of 07/2009	S-Class	221	Chassis	TPM - Tire pressure monitor(N88)			•		•	
As of 07/2009	S-Class	221	Chassis	EHPS-Electrohydraulic Power Steering			•		•	
As of 07/2009	S-Class	221	Chassis	RBS-Brake system		$\blacktriangle$			<b>A</b>	
As of 07/2009	S-Class	221	Body	CGW-Central gateway	•	•	•	•	0	
As of 07/2009	S-Class	221	Body	EZS-Electronic ignition switch	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	KG-Keyless Go	•	•	•	•	•	•
As of 07/2009	S-Class	221	Body	KG-KEYLESS GO	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	•
As of 07/2009	S-Class	221	Body	AB-Airbag	•	•	•	•	•	•
As of 07/2009	S-Class	221	Body	SGR-Radar sensors control unit	<b>A</b>	<b>A</b>	<b>A</b>	lack	<b>A</b>	lack
As of 07/2009	S-Class	221	Body	SGR-Radar sensors control unit	•	•	•	•	0	•
As of 07/2009	S-Class	221	Body	WSS-Weight sensing system	•		•	•	•	•
As of 07/2009	S-Class	221	Body	OCP-Overhead control panel			•		•	
As of 07/2009	S-Class	221	Body	UCP-Upper control panel			•		•	
As of 07/2009	S-Class	221	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
As of 07/2009	S-Class	221	Body	REAR SAM-Rear signal acquisition and actuation module	•		•		•	
As of 07/2009	S-Class	221	Body	Trailer recognition module	•	•	•	•	•	•
As of 07/2009	S-Class	221	Body	PSD-Panoramic sliding roof(Interior CAN bus)	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
As of 07/2009	S-Class	221	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
As of 07/2009	S-Class	221	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	XALWA-R-Xenon headlamp, right	•	•	•		•	
As of 07/2009	S-Class	221	Body	System diagnosis (CAN)	•	•	•	•	•	0

Model	year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
	07/2009	S-Class	221	Body	COU [ZBE]-Central operating unit	•	•	•	•	•	•
	07/2009	S-Class	221	Body	HBF (Rear control panel)-Rear control field	•	•	•	•	•	•
	07/2009	S-Class	221	Body	SG-BMS - Battery management system control unit	•	•	•	•	•	•
	07/2009	S-Class	221	Body	SG-DDW - DC/DC converter control unit	•	•	•	•	•	
As of	07/2009	S-Class	221	Body	BNS-Vehicle power supply control module	•	•	•	•	•	0
As of	07/2009	S-Class	221	Information and communication	NSA-Night View Assist	•	•	•	•	•	0
As of	07/2009	S-Class	221	Information and communication	MFK-Multifunction camera	•	•	<b>A</b>	<b>A</b>	•	•
As of	07/2009	S-Class	221	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	IC-Instrument cluster	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	ASSYST-Active Service System	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	ASSYST PLUS	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	COMAND	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	COMAND	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	Tuner-Standard tuner	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	Tuner-Tuner sound	•	•	•	•	0	0
As of	07/2009	S-Class	221	Information and communication	Tuner-Tuner sound	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	VCS-Voice control	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of	07/2009	S-Class	221	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 07/2009	S-Class	221	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
As of 07/2009	S-Class	221	Information and communication	DAB-Digital radio	•	•	•	•	•	•
As of 07/2009	S-Class	221	Information and communication	ZAN-Central display	•	•	•	•	•	•
As of 07/2009	S-Class	221	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
As of 07/2009	S-Class	221	Information and communication	UCI-Media interface	•	•	•	•	•	•
As of 07/2009	S-Class	221	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
As of 07/2009	S-Class	221	Information and communication	Left rear screen	•	•	•	•	•	•
As of 07/2009	S-Class	221	Information and communication	Right rear screen	•	•	•	•	•	•
As of 07/2009	S-Class	221	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
As of 07/2009	S-Class	221	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
As of 07/2009	S-Class	221	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
As of 07/2009	S-Class	221	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
As of 07/2009	S-Class	221	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
As of 07/2009	S-Class	221	Information and communication	ICI-InCar Internet (N125/3)	•	•	0	•	0	•
As of 07/2009	S-Class	221		DS-LF-Left front dynamic seat	•	•	•			
As of 07/2009	S-Class	221		DS-RF-Right front dynamic seat		•				
As of 07/2009	S-Class	221		MKL-HL-Rear left multicontour backrest	•	•	•			
As of 07/2009	S-Class	221		MKL-HR-Rear right multicontour backrest	•	•	•	•	•	•
As of 07/2009	S-Class	221		DSP-Pneumatic pump for dynamic seat	•	•		•	•	•
	S-Class	221		DCM-FL-Door control module front left	•	•	•	•	•	•
As of 07/2009	S-Class	221		DCM-FR-Door control module front right	•	•	•	•	•	•
As of 07/2009	S-Class	221		DCM-RL-Door control module rear left	•	•	•	•	•	•
As of 07/2009	S-Class	221		DCM-RR-Door control module rear right	•	•	•	•	•	•
As of 07/2009	S-Class	221		ESA-FL-Electric seat adjustment front left	•	•	•	•	•	•
	S-Class	221		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	•
	S-Class	221		ESA-R-Electric seat adjustment rear	•	•	•	•	•	•
	S-Class	221		TLC-Trunk lid control	•	•	•	•	•	•
As of 07/2009	S-Class	221	Seats and doors	TSG-ML-Left center door control unit (interior Can						

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 07/2009	S-Class	221	Seats and doors	TSG-MR-Right center door control unit (interior Can	•	•	•	•	•	
As of 07/2009	S-Class	221	Air conditioning	AAC-Automatic air conditioning		•			•	
As of 07/2009	S-Class	221	Air conditioning	STH-Stationary heater with remote control		•				
As of 07/2009	S-Class	221	Air conditioning	KBE-H-Rear A/C operating unit	•	•			•	
Up to 08/2002	S-Class	220	Drive	ETC-Electronic transmission control	•	•	0		•	*
Up to 08/2002	S-Class	220	Drive	ETC-Electronic transmission control		•				
Up to 08/2002	S-Class	220	Drive	ESM-Electronic selector module	•	•	•		•	*
Up to 08/2002	S-Class	220	Drive	DTR-Distronic		•				*
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.0-Motor electronics 2.0		•				*
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8		•				
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.0-Motor electronics 2.0		•				*
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8		•				
Up to 08/2002	S-Class	220	Drive	ETC-Electronic transmission control	•	•	•	•	•	
Up to 08/2002	S-Class	220	Drive	DTR-Distronic		•			•	
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.7-Motor electronics 2.7		•	•		•	
Up to 08/2002	S-Class	220	Drive	CDI 2-Common Rail Diesel Injection		•	•	•	•	
Up to 08/2002	S-Class	220	Drive	CDI-V-Common Rail Diesel Injection		•	•	•	•	
Up to 08/2002	S-Class	220	Chassis	ESP-Electronic stability program		•	•	•	•	*
Up to 08/2002	S-Class	220	Chassis	AIRmatic		•	•	•	•	*
Up to 08/2002	S-Class	220	Chassis	ABC-ABC active body control		•	•	•	•	*
Up to 08/2002	S-Class	220	Chassis	TPM - Tire pressure monitor(N88)		•	•	•	•	*
Up to 08/2002	S-Class	220	Body	AB-Airbag		•	0	•	•	*
Up to 08/2002	S-Class	220	Body	EZS-Electronic ignition switch		•		•	•	*
Up to 08/2002	S-Class	220	Body	EZS-Electronic ignition switch		•		•	•	*
Up to 08/2002	S-Class	220	Body	SAM-FL-Front left signal acquisition and actuation module	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Body	SAM-FR-Front right signal acquisition and actuation module	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Body	REAR SAM-Rear signal acquisition and actuation module		•		•	•	*
Up to 08/2002	S-Class	220	Body	AHE-Trailer recognition	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Body	OCP-Overhead control panel	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Body	PSE-Pneumatic system equipment	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Body	UCP-Upper control panel	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Body	KG-Keyless Go	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Body	HRA-Headlamp range adjustment	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Body	EZS-Electronic ignition switch	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Body	HRA-Headlamp range adjustment	•	•	•	•	•	*
Up to 08/2002		220	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0
Up to 08/2002		220	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0
Up to $08/2002$		220	Body	CGW-Central gateway	•	•	•	•	0	0
Up to 08/2002		220	Body	AB-Airbag	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 08/2002	S-Class	220	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
Up to 08/2002	S-Class	220	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
Up to 08/2002	S-Class	220	Body	OCP-Overhead control panel	•	•	•		•	0
Up to 08/2002	S-Class	220	Body	UCP-Upper control panel	•				•	0
Up to 08/2002	S-Class	220	Body	System diagnosis (CAN)	•	•			•	
Up to 08/2002	S-Class	220	Information and communication	PTS-Parktronic system	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Information and communication	TSTH-Radio remote control of stationary heater	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
Up to 08/2002	S-Class	220	Information and communication	COMAND	•	•	0	•	•	•
Up to 08/2002	S-Class	220	Information and communication	AUDIO	•	•	•	•	•	•
Up to 08/2002	S-Class	220	Information and communication	CDC-CD changer	•	•	•	•	0	0
Up to 08/2002	S-Class	220	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0
Up to 08/2002	S-Class	220	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	•	0
Up to 08/2002	S-Class	220	Information and communication	SOUND- Sound system	•	•	0	•	•	•
Up to 08/2002	S-Class	220	Information and communication	VCS-Voice control system	•	•	0	•		0
Up to 08/2002	S-Class	220	Information and communication	TV-TV tuner	•	•	•	•		•
Up to 08/2002	S-Class	220	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•
Up to 08/2002	S-Class	220	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
Up to 08/2002	S-Class	220	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Emergency call system	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 08/2002	S-Class	220	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
Up to 08/2002	S-Class	220	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
Up to 08/2002	S-Class	220	Information and communication	DN-Dynamic navigation by means of CTEL	•	•	•	•	•	0
Up to 08/2002	S-Class	220	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•
Up to 08/2002	S-Class	220	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
Up to 08/2002	S-Class	220	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•
Up to 08/2002	S-Class	220	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	•	•	•	•	•	•
Up to 08/2002	S-Class	220	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
Up to 08/2002	S-Class	220	Information and communication	AUDIO	•	•	•	•	•	•
Up to 08/2002	S-Class	220	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
Up to 08/2002	S-Class	220	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
Up to 08/2002	S-Class	220	Information and communication	CDC-CD changer	•	•	0	•	•	•
Up to 08/2002	S-Class	220	Information and communication	VCS-Voice control system	•	•	0	•		•
Up to 08/2002	S-Class	220	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•
Up to 08/2002	S-Class	220	Information and communication	TV-TV tuner	•	•	0	•	•	•
Up to 08/2002	S-Class	220	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
Up to 08/2002	S-Class	220	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
Up to 08/2002	S-Class	220	Information and communication	GPS box	•	•	0	•	•	•
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Control unit	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
Up to 08/2002	S-Class	220	Seats and doors	DCM-FL-Door control module front left		•		•	•	*
Up to 08/2002	S-Class	220	Seats and doors	DCM-FR-Door control module front right		•	•		•	*
Up to 08/2002	S-Class	220	Seats and doors	DCM-RL-Door control module rear left			•		•	*
Up to 08/2002	S-Class	220	Seats and doors	DCM-RR-Door control module rear right	•	•	•	•	•	*
Up to 08/2002	S-Class	220	Seats and doors	ESA-R-Electric seat adjustment rear		•	•		•	*
Up to 08/2002	S-Class	220	Seats and doors	ESA-FL-Electric seat adjustment front left		•	•		•	*
Up to 08/2002	S-Class	220	Seats and doors	ESA-FR-Electric seat adjustment front right		•	•		•	*
Up to 08/2002	S-Class	220	Seats and doors	OSB-R-Multicontour backrest rear		•	•		•	*
Up to 08/2002	S-Class	220	Seats and doors	OSB-FL-Multicontour backrest front left		•	•		•	*
Up to 08/2002	S-Class	220	Seats and doors	OSB-FR-Multicontour backrest front right		•	•		•	*
Up to 08/2002	S-Class	220	Seats and doors	DS-LF-Left front dynamic seat		•	•		•	
Up to 08/2002	S-Class	220	Seats and doors	DS-RF-Right front dynamic seat		•	•		•	
Up to 08/2002	S-Class	220	Seats and doors	DSP-Pneumatic pump for dynamic seat		•	•		•	
Up to 08/2002	S-Class	220	Air conditioning	AAC-Automatic air conditioning	•	•	•		•	*
Up to 08/2002	S-Class	220	Air conditioning	REAR AC- Rear air conditioning	•	•	•		•	*
Up to 08/2002	S-Class	220		STH-Stationary heater		•	•		•	*
Up to 08/2002	S-Class	220	Air conditioning	HSW-Heated steering wheel		•	•		•	*
Up to 08/2002	S-Class	220	Air conditioning	STH-Stationary heater		•	•		•	*
Up to 08/2002	S-Class	220	Air conditioning	STH-Stationary heater		•	•		•	
As of 09/2002	S-Class	220	Drive	ETC-Electronic transmission control		•	•		•	
As of 09/2002	S-Class	220	Drive	ETC-Electronic transmission control	•	•	•	•	•	
As of 09/2002	S-Class	220	Drive	ESM-Electronic selector module	•	•	•	•	•	*
As of 09/2002	S-Class	220	Drive	DTR-Distronic	•	•	•	•	•	*
As of 09/2002	S-Class	220	Drive	DTR-Distronic	•	•	•	•	•	
As of 09/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•		•	
As of 09/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•		•	
As of 09/2002	S-Class	220	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	•	•	•		•	
As of 09/2002	S-Class	220	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	
As of 09/2002	S-Class	220	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•
As of 09/2002	S-Class	220	Drive	CDI-V-Common Rail Diesel Injection	•	•	•	•	•	•
As of 09/2002	S-Class	220	Chassis	ESP-Electronic stability program	•	•	•	•	•	*
As of 09/2002	S-Class	220	Chassis	AIRmatic	•	•	•	•	•	*
As of 09/2002	S-Class	220	Chassis	ABC-ABC active body control	•	•	•		•	*
As of 09/2002	S-Class	220	Chassis	TPM - Tire pressure monitor(N88)					•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 09/2002	S-Class	220	Body	EZS-Electronic ignition switch	•		•		•	*
As of 09/2002	S-Class	220	Body	SAM-FL-Front left signal acquisition and actuation module	•	•	•	•	•	*
As of 09/2002	S-Class	220	Body	SAM-FR-Front right signal acquisition and actuation module	•	•	•	•	•	*
As of 09/2002	S-Class	220	Body	REAR SAM-Rear signal acquisition and actuation module	•		•	•	•	*
As of 09/2002	S-Class	220	Body	AHE-Trailer recognition					•	*
As of 09/2002	S-Class	220	Body	PSE-Pneumatic system equipment					•	*
As of 09/2002	S-Class	220	Body	KG-Keyless Go					•	*
As of 09/2002	S-Class	220	Body	MSS-Special vehicle multifunction control module					•	*
As of 09/2002	S-Class	220	Body	HRA-Headlamp range adjustment					•	*
As of 09/2002	S-Class	220	Body	HRA-FR-Front right headlamp range control					•	0
As of 09/2002	S-Class	220	Body	HRA-FL-Front left headlamp range control					•	0
As of 09/2002	S-Class	220	Body	CGW-Central gateway	•	•	•	•	0	0
As of 09/2002	S-Class	220	Body	AB-Airbag	•	•	•	•	•	
As of 09/2002	S-Class	220	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
As of 09/2002	S-Class	220	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
As of 09/2002	S-Class	220	Body	OCP-Overhead control panel	•	•	•	•	•	0
As of 09/2002	S-Class	220	Body	UCP-Upper control panel	•		•	•	•	0
As of 09/2002	S-Class	220	Body	System diagnosis(CAN)	•		•	•	•	
As of 09/2002	S-Class	220	Information and communication	PTS-Parktronic system	•	•	•	•	•	*
As of 09/2002	S-Class	220	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*
As of 09/2002	S-Class	220	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
As of 09/2002	S-Class	220	Information and communication	COMAND	•	•	0	•	•	•
As of 09/2002	S-Class	220	Information and communication	AUDIO	•	•	•	•	•	•
As of 09/2002	S-Class	220	Information and communication	CDC-CD changer	•	•	•	•	0	0
As of 09/2002	S-Class	220	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0
As of 09/2002	S-Class	220	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	•	0
As of 09/2002	S-Class	220	Information and communication	SOUND- Sound system	•	•	0	•	•	•
As of 09/2002	S-Class	220	Information and communication	VCS-Voice control system	•	•	0	•		0

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 09/2002	S-Class	220	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•
As of 09/2002	S-Class	220	Information and communication	TV-TV tuner	•	•	•	•		•
As of 09/2002	S-Class	220	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
As of 09/2002	S-Class	220	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
As of 09/2002	S-Class	220	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
As of 09/2002	S-Class	220	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 09/2002	S-Class	220	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•
As of 09/2002	S-Class	220	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	•	•	•	•	•	•
As of 09/2002	S-Class	220	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of 09/2002	S-Class	220	Information and communication	AUDIO	•	•	•	•	•	•
As of 09/2002	S-Class	220	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
As of 09/2002	S-Class	220	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
As of 09/2002	S-Class	220	Information and communication	CDC-CD changer	•	•	0	•	•	•
As of 09/2002	S-Class	220	Information and communication	VCS-Voice control system	•	•	0	•		•
As of 09/2002	S-Class	220	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•
As of 09/2002	S-Class	220	Information and communication	TV-TV tuner	•	•	0	•	•	•
As of 09/2002	S-Class	220	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
As of 09/2002	S-Class	220	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
As of 09/2002	S-Class	220	Information and communication	GPS box	•	•	0	•	•	•
As of 09/2002	S-Class	220	Information and communication	TELE AID-Control unit	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
As of 09/2002	S-Class	220	Seats and doors	DCM-FL-Door control module front left		•	•		•	*
As of 09/2002	S-Class	220	Seats and doors	DCM-FR-Door control module front right		•	•		•	*
As of 09/2002	S-Class	220	Seats and doors	DCM-RL-Door control module rear left		•	•		•	*
As of 09/2002	S-Class	220	Seats and doors	DCM-RR-Door control module rear right		•	•		•	*
As of 09/2002	S-Class	220	Seats and doors	ESA-R-Electric seat adjustment rear	•	•	•	•	•	*
As of 09/2002	S-Class	220		ESA-FL-Electric seat adjustment front left	•	•	•	•	•	*
As of 09/2002	S-Class	220		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*
As of 09/2002	S-Class	220		OSB-R-Multicontour backrest rear	•	•	•	•	•	*
As of 09/2002	S-Class	220		OSB-FL-Multicontour backrest front left	•	•	•		•	*
As of 09/2002	S-Class	220		OSB-FR-Multicontour backrest front right						*
As of 09/2002	S-Class	220		DS-LF-Left front dynamic seat		•	•	•	•	•
As of 09/2002	S-Class	220		DS-RF-Right front dynamic seat		•	•	•	•	•
As of 09/2002	S-Class	220		DSP-Pneumatic pump for dynamic seat		•	•	•	•	•
As of 09/2002	S-Class	220		AAC-Automatic air conditioning		•	•	•	•	*
As of 09/2002	S-Class	220		REAR AC- Rear air conditioning		•	•	•	•	*
As of 09/2002	S-Class	220		HSW-Heated steering wheel	•	•	•	•	•	*
As of 09/2002	S-Class	220		STH-Stationary heater		•	•	•	•	•
ALL	S-Class	140	Drive	ME2-SFI-Motor electronics 2			0	•		*
ALL	S-Class	140	Drive	ME1RE-Motor electronics 1 RE			0		0	*
ALL	S-Class	140	Drive	EFP, TPM, ISC-Electronic accelerator pedal, Cruise control, Idle speed control	•	•	0	•	0	*
ALL	S-Class	140	Chassis	EGS, EAG-Electronic control for automatic transmission		•	0	•	0	*
ALL	S-Class	140	Chassis	ESP-Electronic stability program		•	0		•	*
ALL	S-Class	140	Chassis	BAS-Brake assist		•	0		•	*
ALL	S-Class	140	Chassis	SPS-Speed-sensitive power steering		•	0		•	*
ALL	S-Class	140	Body	RFL-Radio frequency locking/electric central locking		•	0		•	*
ALL	S-Class	140	Body	PTS-Parktronic system		•	0		0	*
ALL	S-Class	140	Body	PSE-Pneumatic system equipment			0	•	0	*
ALL	S-Class	140	Body	AirBag		•	0	•	0	*
ALL	S-Class	140	Body	KFB-Power windows, emergency opening, convenience closing, tilting/sliding roof	•	•	0	•	0	*
ALL	S-Class	140	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*
ALL	S-Class	140	Air conditioning	AAC-Automatic air conditioning	•	•	0			*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	CL	216	Drive	ISM-Intelligent servo module	•	•	•	•	•	•
ALL	CL	216	Drive	ISM-Shift module (A80)	<b>A</b>	<b>A</b>	lack	<b>A</b>	<b>A</b>	<b>A</b>
ALL	CL	216	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
ALL	CL	216	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
ALL	CL	216	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•
ALL	CL	216	Drive	DTR-Distronic	•	•	•	•	•	•
ALL	CL	216	Drive	DTR-Distronic	•	•	•	•	•	•
ALL	CL	216	Drive	FSCU-Fuel pump	•	•	•	•	0	•
ALL	CL	216	Drive	FSCU-Fuel pump	•	•	•	•	•	•
ALL	CL	216	Drive	FSCU-Fuel pump	•	•	•	•	•	•
ALL	CL	216	Drive	SGR-Radar sensors control unit		•		•	•	0
ALL	CL	216	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•
ALL	CL	216	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•
ALL	CL	216	Drive	FSCU-Fuel pump AMG	•	•	•	•	•	•
ALL	CL	216	Drive	FSCU-Fuel pump	•	•	•	•	0	•
ALL	CL	216	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•
ALL	CL	216	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•	
ALL	CL	216	Chassis	ABR-Adaptive Brake	•	•	•	•	•	•
ALL	CL	216	Chassis	ABR-Adaptive Brake	•	•	•	•	•	
ALL	CL	216	Chassis	AIRmatic	•	•	•	•	•	•
ALL	CL	216	Chassis	ABC-ABC active body control	•	•	•	•	•	•
ALL	CL	216	Chassis	Electronic parking brake-Electric parking brake		•	•	•	•	•
ALL	CL	216	Chassis	TPC-Tire pressure monitor		•	•	•	•	•
ALL	CL	216	Chassis	TPM - Tire pressure monitor(N88)		•	•	•	•	•
ALL	CL	216	Chassis	EHPS-Electrohydraulic Power Steering	•	•	•	•	•	
ALL	CL	216	Body	CGW-Central gateway	•	•	•	•	0	•
ALL	CL	216	Body	EZS-Electronic ignition switch	•	•	•	•	•	•
ALL	CL	216	Body	EZS-Electronic ignition switch	•	•	•	•	•	
ALL	CL	216	Body	SGR-Radar sensors control unit	•	•	•	•	0	•
ALL	CL	216	Body	KG-Keyless Go		•	•	•	•	•
ALL	CL	216	Body	KG-KEYLESS GO		•	•	•	•	
ALL	CL	216	Body	AB-Airbag		•	•	•	•	
ALL	CL	216	Body	WSS-Weight sensing system		•	•	•	•	•
ALL	CL	216	Body	OCP-Overhead control panel		•	•	•	•	
ALL	CL	216	Body	UCP-Upper control panel	•	•	•	•	•	•
ALL	CL	216	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	CL	216	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•
ALL	CL	216	Body	BNS-Vehicle power supply control module	•	•	•	•	•	0
ALL	CL	216	Body	AHE-Trailer recognition	•	•	•	•	•	•
ALL	CL	216	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•
ALL	CL	216	Body	XALWA-L-Xenon headlamp, left		•		•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	CL	216	Body	XALWA-L-Xenon headlamp, left	•			•	•	
ALL	CL	216	Body	XALWA-R-Xenon headlamp, right					•	
ALL	CL	216	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	
ALL	CL	216	Body	XALWA-R-Xenon headlamp, right				•	•	
ALL	CL	216	Body	System diagnosis(CAN)			•	•	•	0
ALL	CL	216	Body	COU [ZBE]-Central operating unit			•	•	•	•
ALL	CL	216	Information and communication	NSA-Night View Assist	•	•	•	•	•	0
ALL	CL	216	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
ALL	CL	216	Information and communication	IC-Instrument cluster	•	•	•	•	•	•
ALL	CL	216	Information and communication	ASSYST-Active Service System	•	•	•	•	•	•
ALL	CL	216	Information and communication	ASSYST PLUS	•	•	•	•	•	•
ALL	CL	216	Information and communication	PTS-Parktronic	•	•	•	•	•	•
ALL	CL	216	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•
ALL	CL	216	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•
ALL	CL	216	Information and communication	MFK-Multifunction camera	•	•	•	•	<b>A</b>	•
ALL	CL	216	Information and communication	COMAND	•	•	•	•	•	•
ALL	CL	216	Information and communication	COMAND	•	•	•	•	•	•
ALL	CL	216	Information and communication	Tuner-Standard tuner	•	•	•	•	•	•
ALL	CL	216	Information and communication	Tuner-Tuner sound	•	•	•	•	•	•
ALL	CL	216	Information and communication	Tuner-Tuner sound	•	•	•	•	0	0
ALL	CL	216	Information and communication	VCS-Voice control	•	•	•	•	•	•
ALL	CL	216	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
ALL	CL	216	Information and communication	TV-TV tuner (AGW)	•	•	•	•	•	•
ALL	CL	216	Information and communication	DAB-Digital radio	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	CL	216	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	CL	216	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	CL	216	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	CL	216	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
ALL	CL	216	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
ALL	CL	216		TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
ALL	CL	216	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
ALL	CL	216	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
ALL	CL	216	Information and communication	ICI-InCar Internet (N125/3)	•	•	0	•	0	•
ALL	CL	216	Seats and doors	DS-LF-Left front dynamic seat	•	•		•	•	
ALL	CL	216		DS-RF-Right front dynamic seat	•	•	•	•	•	
ALL	CL	216		DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	
ALL	CL	216		DCM-FL-Door control module front left	•	•	•	•	•	
ALL	CL	216		DCM-FR-Door control module front right	•	•	•	•	•	
ALL	CL	216		RCM-Rear control module	•	•			•	
ALL	CL	216		ESA-FL-Electric seat adjustment front left	•	•		•	•	
ALL	CL	216		ESA-FR-Electric seat adjustment front right	•	•		•	•	
ALL	CL	216		TLC-Trunk lid control	•	•	•	•	•	
ALL	CL	216		TLC-Trunk lid control	•	•	•	•	•	
ALL	CL	216		AAC-Automatic air conditioning	•	•	•	•	•	•
ALL	CL	216	Air conditioning	STH-Stationary heater with remote control	•	•	•	•	•	
Up to 08/2002	CL	215	Drive	ETC-Electronic transmission control			0	•	•	*
Up to 08/2002	CL	215	Drive	ETC-Electronic transmission control				•	•	
Up to 08/2002	CL	215	Drive	ESM-Electronic selector module	•	•	•	•	•	*
	CL	215	Drive	DTR-Distronic	•	•	•	•	•	*
Up to 08/2002	CL	215	Drive	ME-SFI 2.0-Motor electronics 2.0	•	•	•	•	•	*
Up to 08/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
Up to 08/2002	CL	215	Drive	ME-SFI 2.0-Motor electronics 2.0	•	•	•	•	•	*
Up to 08/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
Up to 08/2002	CL	215	Drive	ME-SFI 2.7-Motor electronics 2.7	•	•	•	•	•	•
Up to 08/2002	CL	215	Chassis	ESP-Electronic stability program	•	•	•	•	•	*
Up to 08/2002	CL	215	Chassis	ABC-ABC active body control	•	•	•	•	•	*
Up to 08/2002	CL	215	Chassis	TPM - Tire pressure monitor(N88)		•		•	•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 08/2002	CL	215	Body	AB-Airbag			0	•	•	*
Up to 08/2002	CL	215	Body	EZS-Electronic ignition switch	•	•	•		•	*
Up to 08/2002	CL	215	Body	EZS-Electronic ignition switch						*
Up to 08/2002	CL	215	Body	SAM-FL-Front left signal acquisition and actuation module	•	•	•	•	•	*
Up to 08/2002	CL	215	Body	SAM-FR-Front right signal acquisition and actuation module	•	•	•	•	•	*
Up to 08/2002	CL	215	Body	REAR SAM-Rear signal acquisition and actuation module		•	•	•	•	*
Up to 08/2002	CL	215	Body	AHE-Trailer recognition		•	•	•	•	*
Up to 08/2002	CL	215	Body	OCP-Overhead control panel		•	•	•	•	*
Up to 08/2002	CL	215	Body	PSE-Pneumatic system equipment		•	•	•	•	*
Up to 08/2002	CL	215	Body	UCP-Upper control panel		•	•	•	•	*
Up to 08/2002	CL	215	Body	KG-Keyless Go		•	•	•	•	*
Up to 08/2002	CL	215	Body	MSS-Special vehicle multifunction control module		•	•	•	•	*
Up to 08/2002	CL	215	Body	HRA-Headlamp range adjustment	•	•	•	•	•	*
Up to 08/2002	CL	215	Information and communication	PTS-Parktronic system	•	•	•	•	•	*
Up to 08/2002	CL	215	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*
Up to 08/2002	CL	215	Information and communication	TSTH-Radio remote control of stationary heater	•	•	•	•	•	*
Up to 08/2002	CL	215	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	*
Up to 08/2002	CL	215	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
Up to 08/2002	CL	215	Information and communication	COMAND	•	•	0	•	•	•
Up to 08/2002	CL	215	Information and communication	AUDIO	•	•	•	•	•	•
Up to 08/2002	CL	215	Information and communication	CDC-CD changer	•	•	•	•	0	0
Up to 08/2002	CL	215	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0
Up to 08/2002	CL	215	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
Up to 08/2002	CL	215	Information and communication	SOUND- Sound system	•	•	0	•	•	•
Up to 08/2002	CL	215	Information and communication	VCS-Voice control system	•	•	0	•		0
Up to 08/2002	CL	215	Information and communication	TV-TV tuner	•	•	•	•		•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 08/2002	CL	215	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•
Up to 08/2002	CL	215	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
Up to 08/2002	CL	215	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0
Up to 08/2002	CL	215	Information and communication	TELE AID-Emergency call system	•	•	•	•	•	•
Up to 08/2002	CL	215	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
Up to 08/2002	CL	215	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
Up to 08/2002	CL	215	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
Up to 08/2002	CL	215	Information and communication	DN-Dynamic navigation by means of CTEL	•	•	•	•	•	0
Up to 08/2002	CL	215	Seats and doors	DCM-FL-Door control module front left		•				*
Up to 08/2002	CL	215	Seats and doors	DCM-FR-Door control module front right	•	•		•	•	*
Up to 08/2002	CL	215	Seats and doors	RCM-Rear control module	•	•	•	•	•	*
Up to 08/2002	CL	215		ESA-FL-Electric seat adjustment front left	•	•	•	•	•	*
Up to 08/2002	CL	215		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*
Up to 08/2002	CL	215		OSB-FL-Multicontour backrest front left	•	•	•	•	•	*
Up to 08/2002	CL	215		OSB-FR-Multicontour backrest front right	•	•	•	•	•	*
Up to 08/2002	CL	215		AAC-Automatic air conditioning	•	•	•	•	•	*
Up to 08/2002	CL	215		STH-Stationary heater	•	•	•	•	•	*
Up to 08/2002	CL	215		HSW-Heated steering wheel	•	•	•	•	•	*
Up to 08/2002	CL	215		STH-Stationary heater	•	•	•	•	•	*
As of 09/2002	CL	215	Drive	ETC-Electronic transmission control	•	•		•	•	•
As of 09/2002	CL	215	Drive	ETC-Electronic transmission control	•	•	•	•	•	
As of 09/2002	CL	215	Drive	ESM-Electronic selector module	•	•	•	•	•	*
As of 09/2002	CL	215	Drive	DTR-Distronic	•	•	•	•	•	*
As of 09/2002	CL	215	Drive	DTR-Distronic	•	•	•	•	•	
As of 09/2002	CL	215	Drive	ME-SFI 2.0-Motor electronics 2.0	•	•	•	•	•	*
As of 09/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8				•	•	•
As of 09/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	
As of 09/2002	CL	215	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	•	•	•	•	•	
As of 09/2002	CL	215	Chassis	ESP-Electronic stability program			•	•	•	*
As of 09/2002	CL	215	Chassis	ABC-ABC active body control	•			•	•	*
As of 09/2002	CL	215	Chassis	TPM - Tire pressure monitor(N88)	•			•	•	*
As of 09/2002	CL	215	Body	EZS-Electronic ignition switch		•		•	•	*
As of 09/2002	CL	215	Body	PSE-Pneumatic system equipment	•	•	•	•	•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 09/2002	CL	215	Body	SAM-FL-Front left signal acquisition and actuation module	•	•	•	•	•	*
As of 09/2002	CL	215	Body	SAM-FR-Front right signal acquisition and actuation module	•	•	•	•	•	*
As of 09/2002	CL	215	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*
As of 09/2002	CL	215	Body	AHE-Trailer recognition	•	•	•	•	•	*
As of 09/2002	CL	215	Body	KG-Keyless Go	•	•	•	•	•	*
As of 09/2002	CL	215	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	*
As of 09/2002	CL	215	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0
As of 09/2002	CL	215	Body	HRA-FL-Front left headlamp range control		•	•	•	•	0
As of 09/2002	CL	215	Body	CGW-Central gateway		•	•	•	0	0
As of 09/2002	CL	215	Body	AB-Airbag					•	
As of 09/2002	CL	215	Body	OCP-Overhead control panel		•			•	0
As of 09/2002	CL	215	Body	UCP-Upper control panel					•	0
As of 09/2002	CL	215	Body	System diagnosis (CAN)				•	•	
As of 09/2002	CL	215	Information and communication	PTS-Parktronic system	•	•	•	•	•	*
As of 09/2002	CL	215	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*
As of 09/2002	CL	215	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
As of 09/2002	CL	215	Information and communication	COMAND	•	•	0	•	•	•
As of 09/2002	CL	215	Information and communication	AUDIO	•	•	•	•	•	•
As of 09/2002	CL	215	Information and communication	CDC-CD changer	•	•	•	•	0	0
As of 09/2002	CL	215	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0
As of 09/2002	CL	215	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
As of 09/2002	CL	215	Information and communication	SOUND- Sound system	•	•	0	•	•	•
As of 09/2002	CL	215	Information and communication	VCS-Voice control system	•	•	0	•		0
As of 09/2002	CL	215	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•
As of 09/2002	CL	215	Information and communication	TV-TV tuner	•	•	•	•		•
As of 09/2002	CL	215	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 09/2002	CL	215	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
As of 09/2002	CL	215	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
As of 09/2002	CL	215	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 09/2002	CL	215	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•
As of 09/2002	CL	215	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	•	•	•	•	•	•
As of 09/2002	CL	215	Information and communication	AUDIO	•	•	•	•	•	•
As of 09/2002	CL	215	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
As of 09/2002	CL	215	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of 09/2002	CL	215	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
As of 09/2002	CL	215	Information and communication	CDC-CD changer	•	•	0	•	•	•
As of 09/2002	CL	215	Information and communication	VCS-Voice control system	•	•	0	•		•
As of 09/2002	CL	215	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•
As of 09/2002	CL	215	Information and communication	TV-TV tuner	•	•	0	•	•	•
As of 09/2002	CL	215	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
As of 09/2002	CL	215	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
As of 09/2002	CL	215	Information and communication	GPS box	•	•	0	•	•	•
As of 09/2002	CL	215	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•

Model	year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
	09/2002	CL	215	communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
As of	09/2002	CL	215	Seats and doors	DCM-FL-Door control module front left	•	•	•		•	*
As of	09/2002	CL	215		DCM-FR-Door control module front right	•	•	•	•	<u> </u>	*
	09/2002	CL	215		RCM-Rear control module	•	•	•	•	<u> </u>	*
	09/2002	CL	215		ESA-FL-Electric seat adjustment front left	•	•	•		<u> </u>	*
As of	09/2002	CL	215		ESA-FR-Electric seat adjustment front right	•	•	•		<u> </u>	*
	09/2002	CL	215		OSB-FL-Multicontour backrest front left	•	•	•		<u> </u>	*
As of	09/2002	CL	215	Seats and doors	OSB-FR-Multicontour backrest front right	•	•	•		•	*
As of	09/2002	CL	215	Air conditioning	AAC-Automatic air conditioning	•	•	•		•	*
As of	09/2002	CL	215		REAR AC- Rear air conditioning	•	•	•		•	*
As of	09/2002	CL	215	Air conditioning	HSW-Heated steering wheel	•	•	•		•	*
As of	09/2002	CL	215	Air conditioning	STH-Stationary heater	•	•	•		•	
Up to	08/2006	MayBach	240	Drive	ETC-Electronic transmission control					•	
Up to	08/2006	MayBach	240	Drive	ETC-Electronic transmission control	•	•	•		•	•
Up to	08/2006	MayBach	240	Drive	ESM-Electronic selector module		•			•	*
Up to	08/2006	MayBach	240	Drive	SGR-Radar sensors control unit					•	
Up to	08/2006	MayBach	240	Drive	DTR-Distronic					•	*
Up to	08/2006	MayBach	240	Drive	DTR-Distronic		•	•		•	
Up to	08/2006	MayBach	240	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1		•	•		•	
Up to	08/2006	MayBach	240	Chassis	SBC-Sensotronic Brake Control		•	•		•	0
Up to	08/2006	MayBach	240	Chassis	SBC-Right Sensotronic Brake Control				•	•	0
Up to	08/2006	MayBach	240	Chassis	ESP-Electronic stability program				•	•	
Up to	08/2006	MayBach	240	Chassis	AIRmatic				•	•	0
Up to	08/2006	MayBach	240	Chassis	TPC-Tire pressure monitor	•			•	•	
Up to	08/2006	MayBach	240	Body	CGW-Central gateway				•	•	0
Up to	08/2006	MayBach	240	Body	EZS-Electronic ignition switch				•	•	
Up to	08/2006	MayBach	240	Body	AB-Airbag				•	•	
Up to	08/2006	MayBach	240	Body	WSS-Weight sensing system				•	•	0
Up to	08/2006	MayBach	240	Body	BNS-Vehicle power supply control module	•	•		•	•	0
Up to	08/2006	MayBach	240	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0
Up to	08/2006	MayBach	240	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0
Up to	08/2006	MayBach	240	Body	Rear SAM 1-Rear signal acquisition and actuation	•	•	•	•	•	0
	08/2006	MayBach	240	Body	Rear SAM 2-Rear signal acquisition and actuation	•	•	•	•	•	0
	08/2006	MayBach	240	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0
_	08/2006	MayBach	240	Body	VBF (Front control panel)-Front control panel	•	•	•	•	•	0
	08/2006	MayBach	240	Body	HBF (Rear control panel)-Rear control field	•	•	•	•	•	0
	08/2006	MayBach	240	Body	BCG-Remote control (Rear control field)	•	•	•	•	•	0
	08/2006	MayBach	240		OCP-Overhead control panel	•	•	•	•	•	0
		MayBach	240	<del> </del>	CRN-Center roof node	•	•	0	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 08/2006	MayBach	240	Body	PSE-Pneumatic system equipment	•	•	•	•	•	0
Up to 08/2006	MayBach	240	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
Up to 08/2006	MayBach	240	Body	System diagnosis(CAN)	•	•	•	•	•	
Up to 08/2006	MayBach	240	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
Up to 08/2006	MayBach	240	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 08/2006	MayBach	240	Information and communication	ICM-Instrument cluster	•	•	•	•	•	0
Up to 08/2006	MayBach	240	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
Up to 08/2006	MayBach	240	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•
Up to 08/2006	MayBach	240	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	•	•	•	•	•	•
Up to 08/2006	MayBach	240	Information and communication	AUDIO	•	•	•	•	•	•
Up to 08/2006	MayBach	240	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
Up to 08/2006	MayBach	240	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
Up to 08/2006	MayBach	240	Information and communication	VCS-Voice control system	•	•	0	•		•
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner	•	•	0	•	•	•
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
Up to 08/2006	MayBach	240	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•
Up to 08/2006	MayBach	240	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
Up to 08/2006	MayBach	240	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
Up to 08/2006	MayBach	240	Information and communication	AVC-Audio video controller	•	•	0	•	•	•
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner(REAR)	•	•	0	•	•	•
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner (rear)	•	•	•	•	•	•
Up to 08/2006	MayBach	240	Information and communication	CDC-CD changer(REAR)	•	•	0	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 08/2006	MayBach	240	Information and communication	KTL-Left headphone transmitter	•	•	0	•	•	0
Up to 08/2006	MayBach	240	Information and communication	KTR-Right headphone transmitter	•	•	0	•	•	0
Up to 08/2006	MayBach	240	Information and communication	GPS box	•	•	0	•	•	•
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
Up to 08/2006	MayBach	240	Seats and doors	ESA-FL-Electric seat adjustment front left		•		•	•	0
Up to 08/2006	MayBach	240	Seats and doors	ESA-FR-Electric seat adjustment front right		•		•	•	0
Up to 08/2006	MayBach	240	Seats and doors	ESA-LR-Left rear electrical seat adjustment	•	•	•	•	•	0
Up to 08/2006	MayBach	240	Seats and doors	ESA-RR-Right rear electrical seat adjustment			0	•	•	
Up to 08/2006	MayBach	240	Seats and doors	OSB-FL-Multicontour backrest front left		•			•	0
Up to 08/2006	MayBach	240	Seats and doors	OSB-FR-Multicontour backrest front right	•	•	0		•	0
Up to 08/2006	MayBach	240	Seats and doors	MKL-HL-Rear left multicontour backrest		•				0
Up to 08/2006	MayBach	240	Seats and doors	MKL-HR-Rear right multicontour backrest		•				0
Up to 08/2006	MayBach	240	Seats and doors	DCM-FL-Door control module front left	•	•			•	0
Up to 08/2006	MayBach	240	Seats and doors	DCM-FR-Door control module front right	•	•	•		•	0
Up to 08/2006	MayBach	240	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0
Up to 08/2006	MayBach	240	Seats and doors	DCM-RR-Door control module rear right	•	•	•	•	•	0
Up to 08/2006	MayBach	240		PWC-Partition wall control module	•	•	•	•	•	0
Up to 08/2006	MayBach	240		LDCA-Electric left door closing assist	•	•	•	•	•	
Up to 08/2006	MayBach	240		RDCA-Electric right door closing assist	•	•	•	•	•	•
Up to 08/2006	MayBach	240		TLC-Trunk lid control	•	•	•	•	•	•
Up to 08/2006	MayBach	240		AAC-Automatic air conditioning	•	•	•	•	•	0
Up to 08/2006	MayBach	240		REAR AC-Rear air conditioning	•	•		•	•	0
Up to 08/2006	MayBach	240		STH-Stationary heater	•	•	•	•	•	•
Up to 08/2006	MayBach	240		HSW-Heated steering wheel	•	•	•	•	•	•
As of 09/2006	MayBach	240	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
As of 09/2006	MayBach	240	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
As of 09/2006	MayBach	240	Drive	ESM-Electronic selector module	•	•	•	•	•	*
As of 09/2006	MayBach	240	Drive	SGR-Radar sensors control unit	•	•		•	•	•
As of 09/2006	MayBach	240	Drive	DTR-Distronic	•	•	•	•		
As of 09/2006	MayBach	240	Drive	ME 2.7.2-Motor electronics 2.7.2					•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 09/2006	MayBach	240	Drive	FSCU-Fuel pump	•	•	•		0	
As of 09/2006	MayBach	240	Drive	ME 2.7.2-Motor electronics 2.7.2			•		•	
As of 09/2006	MayBach	240	Chassis	SBC-Sensotronic Brake Control	•	•	•		•	0
As of 09/2006	MayBach	240	Chassis	SBC-Right Sensotronic Brake Control	•	•	•		•	0
As of 09/2006	MayBach	240	Chassis	ESP-Electronic stability program	•	•	•		•	
As of 09/2006	MayBach	240	Chassis	AIRmatic	•	•	•	•	•	0
As of 09/2006	MayBach	240	Chassis	TPC-Tire pressure monitor	•	•	•		•	
As of 09/2006	MayBach	240	Body	CGW-Central gateway	•	•	•		•	0
As of 09/2006	MayBach	240	Body	EZS-Electronic ignition switch	•	•	•		•	
As of 09/2006	MayBach	240	Body	AB-Airbag	•	•	•		•	
As of 09/2006	MayBach	240	Body	WSS-Weight sensing system	•	•	•		•	0
As of 09/2006	MayBach	240	Body	BNS-Vehicle power supply control module	•	•	•		•	0
As of 09/2006	MayBach	240	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0
As of 09/2006	MayBach	240	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0
As of 09/2006	MayBach	240	Body	Rear SAM 1-Rear signal acquisition and actuation			•	•	•	0
As of 09/2006	MayBach	240	Body	Rear SAM 2-Rear signal acquisition and actuation			•	•	•	0
As of 09/2006	MayBach	240	Body	MSS-Special vehicle multifunction control module		•	•		•	0
As of 09/2006	MayBach	240	Body	VBF (Front control panel)-Front control panel		•	•		•	0
As of 09/2006	MayBach	240	Body	HBF (Rear control panel)-Rear control field	•	•	•	•	•	0
As of 09/2006	MayBach	240	Body	BCG-Remote control (Rear control field)		•	•		•	0
As of 09/2006	MayBach	240	Body	OCP-Overhead control panel	•	•	•	•	•	0
As of 09/2006	MayBach	240	Body	CRN-Center roof node		•	0		•	
As of 09/2006	MayBach	240	Body	PSE-Pneumatic system equipment	•	•	•	•	•	0
As of 09/2006	MayBach	240	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
As of 09/2006	MayBach	240	Body	System diagnosis(CAN)		•	•		•	
As of 09/2006	MayBach	240	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
As of 09/2006	MayBach	240	Information and communication	SCM [MRM]—Steering column module	•	•	•	•	•	•
As of 09/2006	MayBach	240	Information and communication	ICM-Instrument cluster	•	•	•	•	•	0
As of 09/2006	MayBach	240	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 09/2006	MayBach	240	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•
As of 09/2006	MayBach	240	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	•	•	•	•	•	•
As of 09/2006	MayBach	240	Information and communication	AUDIO	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 09/2006	MayBach	240	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
As of 09/2006	MayBach	240	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
As of 09/2006	MayBach	240	Information and communication	VCS-Voice control system	•	•	0	•		•
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner	•	•	0	•	•	•
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner (AGW)	•	•	•	•	•	•
As of 09/2006	MayBach	240	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•
As of 09/2006	MayBach	240	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
As of 09/2006	MayBach	240	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of 09/2006	MayBach	240	Information and communication	AVC-Audio video controller	•	•	0	•	•	•
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner(REAR)	•	•	0	•	•	•
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner (rear)	•	•	•	•	•	•
As of 09/2006	MayBach	240	Information and communication	CDC-CD changer(REAR)	•	•	0	•	•	•
As of 09/2006	MayBach	240	Information and communication	KTL-Left headphone transmitter	•	•	0	•	•	0
As of 09/2006	MayBach	240	Information and communication	KTR-Right headphone transmitter	•	•	0	•	•	0
As of 09/2006	MayBach	240	Information and communication	GPS box	•	•	0	•	•	•
As of 09/2006	MayBach	240	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
As of 09/2006	MayBach	240	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	•	•	•	0
As of 09/2006	MayBach	240	Seats and doors	ESA-FR-Electric seat adjustment front right						0

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 09/2006	MayBach	240	Seats and doors	ESA-LR-Left rear electrical seat adjustment			•		•	0
As of 09/2006	MayBach	240	Seats and doors	ESA-RR-Right rear electrical seat adjustment		•	0		•	
As of 09/2006	MayBach	240	Seats and doors	OSB-FL-Multicontour backrest front left		•	•		•	0
As of 09/2006	MayBach	240	Seats and doors	OSB-FR-Multicontour backrest front right		•	0		•	0
As of 09/2006	MayBach	240	Seats and doors	MKL-HL-Rear left multicontour backrest			•		•	0
As of 09/2006	MayBach	240	Seats and doors	MKL-HR-Rear right multicontour backrest			•		•	0
As of 09/2006	MayBach	240	Seats and doors	DCM-FL-Door control module front left			•		•	0
As of 09/2006	MayBach	240	Seats and doors	DCM-FR-Door control module front right			•		•	0
As of 09/2006	MayBach	240	Seats and doors	DCM-RL-Door control module rear left			•		•	0
As of 09/2006	MayBach	240	Seats and doors	DCM-RR-Door control module rear right			•		•	0
As of 09/2006	MayBach	240	Seats and doors	PWC-Partition wall control module			•		•	0
As of 09/2006	MayBach	240	Seats and doors	LDCA-Electric left door closing assist			•		•	
As of 09/2006	MayBach	240	Seats and doors	RDCA-Electric right door closing assist			•		•	
As of 09/2006	MayBach	240	Seats and doors	TLC-Trunk lid control			•		•	
As of 09/2006	MayBach	240	Air conditioning	AAC-Automatic air conditioning	•	•	•		•	0
As of 09/2006	MayBach	240	Air conditioning	REAR AC-Rear air conditioning	•	•	•		•	0
As of 09/2006	MayBach	240	Air conditioning	STH-Stationary heater	•	•	•		•	
As of 09/2006	MayBach	240	Air conditioning	HSW-Heated steering wheel	•	•	•		•	
Up to 08/2003	SL	230	Drive	ETC-Electronic transmission control	•	•	•		•	
Up to 08/2003	SL	230	Drive	SEQ-Sequentronic automated manual transmission	•	•	•		•	
Up to 08/2003	SL	230	Drive	ETC-Electronic transmission control		•	•		•	
Up to 08/2003	SL	230	Drive	ESM-Electronic selector module		•	•		•	*
Up to 08/2003	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•		•	
Up to 08/2003	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8		•	•		•	
Up to 08/2003	SL	230	Drive	DTR-Distronic	•	•	•		•	*
Up to 08/2003	SL	230	Chassis	SBC-Sensotronic Brake Control	•	•	•		•	0
Up to 08/2003	SL	230	Chassis	ESP-Electronic stability program	•	•	•		•	
Up to 08/2003	SL	230	Chassis	ABC-ABC active body control		•	•		•	*
Up to 08/2003	SL	230	Chassis	TPM - Tire pressure monitor(N88)		•	•		•	*
Up to 08/2003	SL	230	Body	System diagnosis(CAN)		•	•		0	
Up to 08/2003	SL	230	Body	AB-Airbag		•	•		•	
Up to 08/2003	SL	230	Body	AB-Airbag		•	0		•	*
Up to 08/2003	SL	230	Body	EZS-Electronic ignition switch		•	•		•	*
Up to 08/2003	SL	230	Body	OCP-Overhead control panel	•	•	•	•	•	*
Up to 08/2003	SL	230	Body	LCP-Lower control panel	•	•	•	•	•	*
Up to 08/2003	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	*
Up to 08/2003	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	*
Up to 08/2003	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	•				•	*
Up to 08/2003	SL	230	Body	BNS-Vehicle power supply control module	•					*
Up to 08/2003	SL	230	Body	RVC-Rollover bar/vario roof control module	•	•				*

Model	year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to	08/2003	SL	230	Body	PSE-Pneumatic system equipment	•	•	•		•	*
Up to	08/2003	SL	230	Body	KG-Keyless Go	•		•	•	•	*
Up to	08/2003	SL	230	Body	HRA-FR-Front right headlamp range control	•		•	•	•	0
Up to	08/2003	SL	230	Body	HRA-FL-Front left headlamp range control	•		•	•	•	0
Up to	08/2003	SL	230	Information and communication	PTS-Parktronic system	•	•	•	•	•	*
Up to	08/2003	SL	230	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*
Up to	08/2003	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
Up to	08/2003	SL	230	Information and communication	TV-TV tuner	•	•	•	•		•
Up to	08/2003	SL	230	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
Up to	08/2003	SL	230	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
Up to	08/2003	SL	230	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
Up to	08/2003	SL	230	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
Up to	08/2003	SL	230	Information and communication	COMAND	•	•	0	•	•	•
Up to	08/2003	SL	230	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•
Up to	08/2003	SL	230	Information and communication	AUDIO	•	•	•	•	•	•
Up to	08/2003	SL	230	Information and communication	CDC-CD changer	•	•	•	•	0	0
Up to	08/2003	SL	230	Information and communication	VCS-Voice control system	•	•	0	•		0
Up to	08/2003	SL	230	Information and communication	SOUND- Sound system	•	•	0	•	•	•
Up to	08/2003	SL	230	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•
Up to	08/2003	SL	230		CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
Up to	08/2003	SL	230	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	•	0
Up to	08/2003	SL	230		DCM-L-Door control module left	•	•	•	•	•	*
	08/2003	SL	230		DCM-R-Door control module right	•	•	•	•	•	*
	08/2003	SL	230		ESA-FL-Electric seat adjustment front left	•	•	•	•	•	*
	08/2003	SL	230		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 08/2003	SL	230		OSB-FL-Multicontour backrest front left	•	•	•	•	•	*
Up to 08/2003	SL	230		OSB-FR-Multicontour backrest front right	•	•	•	•	•	*
Up to 08/2003	SL	230		AAC-Automatic air conditioning	•	•	•	•	•	*
Up to 08/2003	SL	230		STH-Stationary heater	•	•	•	•	•	*
Up to 08/2003	SL	230	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Drive	ESM-Electronic selector module	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Drive	DTR-Distronic	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Drive	DTR-Distronic	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Chassis	ABC-ABC active body control	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Chassis	ABC-ABC active body control	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2003 to 05/2006	SL	230	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Body	CGW-Central gateway	•	•	•	•	0	0
From 09/2003 to 05/2006	SL	230	Body	EZS-Electronic ignition switch	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Body	System diagnosis(CAN)	•	•	•	•	0	•
From 09/2003 to 05/2006	SL	230	Body	AB-Airbag	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Body	WSS-Weight sensing system	•	•	•	•	•	0
From 09/2003 to 05/2006	SL	230	Body	OCP-Overhead control panel	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Body	LCP-Lower control panel	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Body	BNS-Vehicle power supply control module	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Body	RVC-Rollover bar/vario roof control module	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Body	RVC-Rollover bar/vario roof control module	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Body	PSE-Pneumatic system equipment	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Body	KG-Keyless Go	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Body	KG-Keyless Go	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0
From 09/2003 to 05/2006	SL	230	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0
From 09/2003 to 05/2006	SL	230	Body	System diagnosis(CAN)	•	•	0	•	*	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2003 to 05/2006	SL	230	Information and communication	PTS-Parktronic system	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
From 09/2003 to 05/2006	SL	230	Information and communication	TV-TV tuner	•	•	•	•		•
From 09/2003 to 05/2006	SL	230	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
From 09/2003 to 05/2006	SL	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	AUDIO	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	CDC-CD changer	•	•	0	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	VCS-Voice control system	•	•	0	•		•
$F_{rom} 09/2003 + 0$	SL	230	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	TV-TV tuner	•	•	0	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Control unit	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
From 09/2003 to 05/2006	SL	230	Information and communication	COMAND	•	•	0	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	AUDIO	•	•	•	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	CDC-CD changer	•	•	•	•	0	0
From 09/2003 to 05/2006	SL	230	Information and communication	VCS-Voice control system	•	•	0	•		0
From 09/2003 to 05/2006	SL	230	Information and communication	SOUND- Sound system	•	•	0	•	•	•
From 09/2003 to 05/2006	SL	230	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
From 09/2003 to 05/2006	SL	230		UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
From 09/2003 to 05/2006	SL	230		ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
From 09/2003 to 05/2006	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
From 09/2003 to 05/2006	SL	230		DCM-L-Door control module left	•	•	•	•	•	*
$F_{rom} 09/2003 + 0$	SL	230	Seats and doors	DCM-R-Door control module right	•	•	•	•	•	*
$E_{\text{mom}} = 0.0 / 20.02 \pm 0.00$	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	•	•	•	*
$F_{rom} = 00/2003 + 0$	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*
$F_{rom} 09/2003 + 0$	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	•	•	•	•	•	*
$E_{rom} = 00/2003 + 0$	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	•	•	•	•	•	*

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2003 to 05/2006	SL	230	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Air conditioning	STH-Stationary heater	•	•	•	•	•	*
From 09/2003 to 05/2006	SL	230	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	*
From 06/2006 to	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
$F_{rom} 06/2006 to$	SL	230	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
$F_{rom} 06/2006 to$	SL	230	Drive	ESM-Electronic selector module	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Drive	DTR-Distronic	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
$F_{rom} 06/2006 to$	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Drive	DTR-Distronic	•	•	•	•	•	*
$F_{rom} 06/2006 + 0$	SL	230	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•
$F_{rom} 06/2006 + 0$	SL	230	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•
From 06/2006 to	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•
From 06/2006 to	SL	230	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Chassis	ABC-ABC active body control	•	•	•	•	•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 06/2006 to 02/2008	SL	230	Chassis	ABC-ABC active body control	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Body	CGW-Central gateway	•	•	•	•	0	0
From 06/2006 to 02/2008	SL	230	Body	EZS-Electronic ignition switch	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Body	System diagnosis(CAN)	•	•	•	•	0	•
From 06/2006 to 02/2008	SL	230	Body	AB-Airbag	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Body	WSS-Weight sensing system	•	•	•	•	•	0
From 06/2006 to 02/2008	SL	230	Body	OCP-Overhead control panel	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Body	LCP-Lower control panel	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Body	BNS-Vehicle power supply control module	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Body	RVC-Rollover bar/vario roof control module	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Body	RVC-Rollover bar/vario roof control module	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Body	PSE-Pneumatic system equipment	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Body	KG-Keyless Go	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Body	KG-Keyless Go	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0
From 06/2006 to 02/2008	SL	230	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 06/2006 to 02/2008	SL	230	Body	System diagnosis(CAN)	•	•	0	•	*	•
From 06/2006 to 02/2008	SL	230	Information and communication	PTS-Parktronic system	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
From 06/2006 to 02/2008	SL	230	Information and communication	TV-TV tuner	•	•	•	•		•
From 06/2006 to 02/2008	SL	230	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
From 06/2006 to 02/2008	SL	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	AUDIO	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	CDC-CD changer	•	•	0	•	•	•
From 06/2006 to	SL	230	Information and communication	VCS-Voice control system	•	•	0	•		•
From 06/2006 to 02/2008	SL	230	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	TV-TV tuner	•	•	0	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
From 06/2006 to 02/2008	SL	230	Information and communication	COMAND	•	•	0	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	AUDIO	•	•	•	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	CDC-CD changer	•	•	•	•	0	0
From 06/2006 to 02/2008	SL	230	Information and communication	VCS-Voice control system	•	•	0	•		0
From 06/2006 to 02/2008	SL	230	Information and communication	SOUND- Sound system	•	•	0	•	•	•
From 06/2006 to 02/2008	SL	230	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
From 06/2006 to 02/2008	SL	230	Information and	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
From 06/2006 to 02/2008	SL	230	Information and	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
From 06/2006 to 02/2008	SL	230	Information and	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
From 06/2006 to	SL	230		DCM-L-Door control module left	•	•	•	•	•	*
$E_{\text{mom}} = 06/2006 \pm 0$	SL	230	Seats and doors	DCM-R-Door control module right	•	•	•	•	•	*
$E_{\text{rom}} = 06/2006 + 0$	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	•	•	•	*
From 06/2006 to	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*
$E_{rom} = 06/2006 + 0$	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	•	•	•	•	•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 06/2006 to 02/2008	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Air conditioning	STH-Stationary heater	•	•	•	•	•	*
From 06/2006 to 02/2008	SL	230	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	*
As of 03/2008	SL	230	Drive	ETC-Electronic transmission control	•	•		•	•	
As of 03/2008	SL	230	Drive	ETC-Electronic transmission control	•				•	
As of 03/2008	SL	230	Drive	ETC-Electronic transmission control	•				•	
As of 03/2008	SL	230	Drive	ESM-Electronic selector module		•	•		•	*
As of 03/2008	SL	230	Drive	DTR-Distronic	•	•	•	•	•	
As of 03/2008	SL	230	Drive	ME 9.7-Motor electronics 9.7	•				•	
As of 03/2008	SL	230	Drive	TV-TV tuner	•				•	
As of 03/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•		•	•	
As of 03/2008	SL	230	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•		•	•	
As of 03/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2		•			•	
As of 03/2008	SL	230	Chassis	SBC-Sensotronic Brake Control		•			•	
As of 03/2008	SL	230	Chassis	ESP-Electronic stability program		•	•		•	
As of 03/2008	SL	230	Chassis	ABC-ABC active body control		•			•	
As of 03/2008	SL	230	Chassis	TPC-Tire pressure monitor	•	•		•	•	
As of 03/2008	SL	230	Body	CGW-Central gateway		•			0	0
As of 03/2008	SL	230	Body	EZS-Electronic ignition switch		•			•	*
As of 03/2008	SL	230	Body	System diagnosis(CAN)	•	•	•	•	0	
As of 03/2008	SL	230	Body	AB-Airbag		•			•	
As of 03/2008	SL	230	Body	WSS-Weight sensing system		•		•	•	0
As of 03/2008	SL	230	Body	OCP-Overhead control panel		•			•	*
As of 03/2008	SL	230	Body	LCP-Lower control panel	•	•		•	•	*
As of 03/2008	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	*
As of 03/2008	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	*
As of 03/2008	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*
	SL	230	Body	BNS-Vehicle power supply control module	•	•	•	•	•	*
As of 03/2008	SL	230	Body	RVC-Rollover bar/vario roof control module	•			•	•	•
	SL	230	Body	PSE-Pneumatic system equipment	•	•	•	•	•	*
As of 03/2008	SL	230	Body	KG-Keyless Go	•	•	•	•	•	•
	SL	230	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•
	SL	230	Body	XALWA-R-Xenon headlamp, right		•	•	•	•	•
	SL	230	Body	System diagnosis (CAN)		•	0	•	*	•
	SL	230	Body	AMG DRVU-AMG DRIVE UNIT (N145)		•	•	•	<u> </u>	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/2008	SL	230	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*
As of 03/2008	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
As of 03/2008	SL	230	Information and communication	TV-TV tuner	•	•	•	•		•
As of 03/2008	SL	230	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
As of 03/2008	SL	230	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
As of 03/2008	SL	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	AUDIO	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
As of 03/2008	SL	230	Information and communication	CDC-CD changer	•	•	0	•	•	•
As of 03/2008	SL	230	Information and communication	VCS-Voice control system	•	•	0	•		•
As of 03/2008	SL	230	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•
As of 03/2008	SL	230	Information and communication	TV-TV tuner	•	•	0	•	•	•
As of 03/2008	SL	230	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
As of 03/2008	SL	230	Information and communication	COMAND or AUDIO	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/2008	SL	230	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	UCI-Media interface	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	DAB-Digital radio	•	•	•	•	•	0
As of 03/2008	SL	230	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	TV-TV tuner	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
As of 03/2008	SL	230	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	•	•	•	•		•
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
As of 03/2008	SL	230	communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
As of 03/2008	SL	230	Seats and doors	DCM-L-Door control module left					•	*
As of 03/2008	SL	230	Seats and doors	DCM-R-Door control module right	•				•	*
As of 03/2008	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left					•	*
As of 03/2008	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right					•	*
As of 03/2008	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left					•	*
As of 03/2008	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	•	•	•	•	•	*
As of 03/2008	SL	230	Seats and doors	AIRSCARF					•	
As of 03/2008	SL	230	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	*
As of 03/2008	SL	230	Air conditioning	STH-Stationary heater	•	•	•	•	•	*
As of 03/2008	SL	230	Air conditioning	HSW-Heated steering wheel					•	*
As of 09/99	SL	129	Drive	ETC-Electronic transmission control			0			*
As of 09/99	SL	129	Drive	ME2-SFI-Motor electronics 2	•	•	0	•	•	*
As of 09/99	SL	129		ME1-SFI-Motor electronics	•		0	•		*
As of 09/99	SL	129	Chassis	ASR-Acceleration Slip Regulation	•		0	•	•	*
As of 09/99	SL	129		ESP-Electronic stability program	•	•	0	•	•	*
As of 09/99	SL	129		ASR-Acceleration Slip Regulation	•	•	0	•	•	*
As of 09/99	SL	129		ESP-Electronic stability program	•	•	0	•	•	*
As of 09/99	SL	129		ETS-Electronic traction system	•	•	0	•	•	*
As of 09/99	SL	129		ESP-Electronic stability program	•	•	0	•	•	*
As of 09/99	SL	129		BAS-Brake assist	•	•	0	•	•	*

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 09/99	SL	129	Body	AB-Airbag	•	•	0	•		*
As of 09/99	SL	129	Body	HRA-Headlamp range adjustment		•	0			*
As of 09/99	SL	129	Body	RFL-Radio frequency locking/electric central locking		•	0		•	*
As of 09/99	SL	129	Body	APS-Auto pilot system		•	0		•	*
As of 09/99	SL	129	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*
As of 09/99	SL	129	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
As of 09/99	SL	129	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•
As of 09/99	SL	129	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0
As of 09/99	SL	129	Information and communication	TELE AID-Emergency call system	•	•	•	•	•	•
As of 09/99	SL	129	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
As of 09/99	SL	129	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
As of 09/99	SL	129	Information and communication	DN-Dynamic navigation by means of CTEL	•	•	•	•	•	0
As of 09/99	SL	129	Information and communication	AUDIO	•	•	•	•	•	•
As of 09/99	SL	129	Information and communication	CDC-CD changer	•	•	•	•	0	0
As of 09/99	SL	129	Information and communication	VCS-Voice control system	•	•	0	•		0
As of 09/99	SL	129	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
As of 09/99	SL	129	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
As of 09/99	SL	129	Air conditioning	AAC-Automatic air conditioning	•		0	•		*
As of 09/99	SL	129		STH-Stationary heater	•		0	•	•	*
ALL	SLR	199	Drive	ETC-Electronic transmission control	•		•	•	•	•
ALL	SLR	199	Drive	ESM-Electronic selector module	•		•	•	•	*
ALL	SLR	199	Drive	ME-SFI 2.8-Motor electronics 2.8	•				•	
ALL	SLR	199	Chassis	SBC-Sensotronic Brake Control					•	0
ALL	SLR	199	Chassis	ESP-Electronic stability program	•		•	•	•	
ALL	SLR	199	Chassis	TPM - Tire pressure monitor(N88)	•			•	•	*
ALL	SLR	199	Chassis	TPC-Tire pressure monitor		•			•	•
ALL	SLR	199	Body	EZS-Electronic ignition switch	•	•		•	•	*
ALL	SLR	199	Body	OCP-Overhead control panel	•	•		•	•	*
ALL	SLR	199	Body	LCP-Lower control panel	•	•	•	•	•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SLR	199	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	*
ALL	SLR	199	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	*
ALL	SLR	199	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•		•	*
ALL	SLR	199	Body	BNS-Vehicle power supply control module	•	•	•		•	*
ALL	SLR	199	Body	HRA-FR-Front right headlamp range control			•		•	0
ALL	SLR	199	Body	HRA-FL-Front left headlamp range control			•		•	0
ALL	SLR	199	Body	RS-Roadster soft top			•		•	
ALL	SLR	199	Body	CGW-Central gateway			•		0	0
ALL	SLR	199	Body	AB-Airbag			•		•	
ALL	SLR	199	Body	WSS-Weight sensing system			•		•	0
ALL	SLR	199	Body	ACL [ZLB]-Air brake (spoiler) and central locking control unit	•	•	•	•	•	•
ALL	SLR	199	Body	BKGS-Brake cooling and gearshift	•	•	•	•	•	•
ALL	SLR	199	Body	System diagnosis(CAN)	•		•	•	•	
ALL	SLR	199	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*
ALL	SLR	199	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
ALL	SLR	199	Information and communication	AUDIO	•	•	•	•	•	•
ALL	SLR	199	Information and communication	CDC-CD changer	•	•	•	•	0	0
ALL	SLR	199	Information and communication	SOUND- Sound system	•	•	0	•	•	•
ALL	SLR	199	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0
ALL	SLR	199	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	•	0
ALL	SLR	199	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
ALL	SLR	199	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
ALL	SLR	199	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
ALL	SLR	199	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
ALL	SLR	199	Seats and doors	DCM-L-Door control module left	•	•	•	•	•	*
ALL	SLR	199	Seats and doors	DCM-R-Door control module right	•	•	•	•	•	*
ALL	SLR	199		AAC-Automatic air conditioning	•	•	•	•	•	*
Up to 05/2005	SLK	171	Drive	ETC-Electronic transmission control	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 05/2005	SLK	171	Drive	SEQ-Sequentronic automated manual transmission		•			•	
Up to 05/2005	SLK	171	Drive	ETC-Electronic transmission control		•			•	
Up to 05/2005	SLK	171	Drive	ESM-Electronic selector module					•	0
Up to 05/2005	SLK	171	Drive	ME-SFI-Motor electronics					•	
Up to 05/2005	SLK	171	Drive	ME-SFI-Motor electronics					•	
Up to 05/2005	SLK	171	Drive	TV-TV tuner		•			•	
Up to 05/2005	SLK	171	Drive	ME 9.7-Motor electronics 9.7		•			•	
Up to 05/2005	SLK	171	Drive	ME-SFI 2.8-Motor electronics 2.8					•	
Up to 05/2005	SLK	171	Chassis	ESP-Electronic stability program			•		•	
Up to 05/2005	SLK	171	Body	CGW-Central gateway				•	•	0
Up to 05/2005	SLK	171	Body	EZS-Electronic ignition switch				•	•	0
Up to 05/2005	SLK	171	Body	System diagnosis (CAN)				•	•	
Up to 05/2005	SLK	171	Body	AB-Airbag	•	•	•		•	
Up to 05/2005	SLK	171	Body	VR-Vario roof	•	•	•		•	0
Up to 05/2005	SLK	171	Body	UCP-Upper control panel	•	•	•		•	0
Up to 05/2005	SLK	171	Body	OCP-Overhead control panel	•	•	•	•	•	0
Up to 05/2005	SLK	171	Body	SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0
Up to 05/2005	SLK	171	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0
Up to 05/2005	SLK	171	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
Up to 05/2005	SLK	171	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
Up to 05/2005	SLK	171	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 05/2005	SLK	171	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
Up to 05/2005	SLK	171	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
Up to 05/2005	SLK	171	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•
Up to 05/2005	SLK	171		AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
Up to 05/2005	SLK	171		AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
Up to 05/2005	SLK	171	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
Up to 05/2005	SLK	171	Information and communication	AUDIO	•	•	•	•	•	•
Up to 05/2005	SLK	171	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
Up to 05/2005	SLK	171	Information and communication	NAVI-Navigation system	•	•	0	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 05/2005	SLK	171	Information and communication	CDC-CD changer	•	•	0	•	•	•
Up to 05/2005	SLK	171	Information and communication	VCS-Voice control system	•	•	0	•		•
Up to 05/2005	SLK	171	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
Up to 05/2005	SLK	171	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
Up to 05/2005	SLK	171	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
Up to 05/2005	SLK	171	Information and communication	UCI-Media interface	•	•	•	•	•	•
Up to 05/2005	SLK	171	Information and communication	DAB-Digital radio	•	•	•	•	•	0
Up to 05/2005	SLK	171	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
Up to 05/2005	SLK	171	Information and communication	TV-TV tuner	•	•	•	•	•	•
Up to 05/2005	SLK	171	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
Up to 05/2005	SLK	171	Information and communication	GPS box	•	•	0	•	•	•
Up to 05/2005	SLK	171	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
Up to 05/2005	SLK	171	Seats and doors	DCM-L-Door control module left	•	•		•	•	0
Up to 05/2005	SLK	171		DCM-R-Door control module right	•	•		•	•	0
Up to 05/2005	SLK	171	Seats and doors	ESA driver-Electric seat adjustment driver (with	•	•	•	•	•	0
Up to 05/2005	SLK	171		ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
Up to 05/2005	SLK	171		HS-Seat heater	•	•	•	•	•	0
Up to 05/2005	SLK	171	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC- Automatic air conditioning/HEAT-Automatic heater	•	•	•	•	•	0
As of 06/2005	SLK	171	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
As of 06/2005	SLK	171	Drive	ETC-Electronic transmission control	•			•	•	•
As of 06/2005	SLK	171	Drive	SEQ-Sequentronic automated manual transmission	•	•			•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 06/2005	SLK	171	Drive	ETC-Electronic transmission control	•	•	•	•	•	
As of 06/2005	SLK	171	Drive	ESM-Electronic selector module	•	•	•		•	0
As of 06/2005	SLK	171	Drive	ME-SFI-Motor electronics	•	•	•		•	
As of 06/2005	SLK	171	Drive	ME-SFI-Motor electronics	•	•	•		•	
As of 06/2005	SLK	171	Drive	TV-TV tuner		•	•		•	
As of 06/2005	SLK	171	Drive	ME 9.7-Motor electronics 9.7		•	•		•	
As of 06/2005	SLK	171	Drive	ME-SFI 2.8-Motor electronics 2.8		•	•		•	
As of 06/2005	SLK	171	Chassis	ESP-Electronic stability program		•	•		•	
As of $06/2005$	SLK	171	Chassis	TPC-Tire pressure monitor					•	
As of $06/2005$	SLK	171	Body	CGW-Central gateway					•	0
As of 06/2005	SLK	171	Body	EZS-Electronic ignition switch		•			•	0
As of 06/2005	SLK	171	Body	System diagnosis (CAN)					•	
As of 06/2005	SLK	171	Body	AB-Airbag	•	•	•	•	•	
As of 06/2005	SLK	171	Body	WSS-Weight sensing system	•	•	•	•	•	0
As of 06/2005	SLK	171	Body	VR-Vario roof	•	•	•	•	•	0
As of 06/2005	SLK	171	Body	UCP-Upper control panel	•	•	•	•	•	0
As of 06/2005	SLK	171	Body	OCP-Overhead control panel	•	•	•	•	•	0
As of 06/2005	SLK	171	Body	SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0
As of 06/2005	SLK	171	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0
As of 06/2005	SLK	171	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
As of 06/2005	SLK	171	Information and communication	PTS-Parktronic system	•	•	•	•	•	•
As of 06/2005	SLK	171	Information and communication	PTS-Parktronic system	•	•	•	•	•	0
As of 06/2005	SLK	171	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
As of 06/2005	SLK	171	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
As of 06/2005	SLK	171	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
As of 06/2005	SLK	171	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•
As of 06/2005	SLK	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 06/2005	SLK	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 06/2005	SLK	171	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of 06/2005	SLK	171	Information and communication	AUDIO	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 06/2005	SLK	171	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
As of 06/2005	SLK	171	Information and communication	NAVI-Navigation system	•	•	0	•	•	•
As of 06/2005	SLK	171	Information and communication	CDC-CD changer	•	•	0	•	•	•
As of 06/2005	SLK	171	Information and communication	VCS-Voice control system	•	•	0	•		•
As of 06/2005	SLK	171	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
As of 06/2005	SLK	171	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
As of 06/2005	SLK	171	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
As of 06/2005	SLK	171	Information and communication	UCI-Media interface	•	•	•	•	•	•
As of 06/2005	SLK	171	Information and communication	DAB-Digital radio	•	•	•	•	•	0
As of 06/2005	SLK	171	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
As of 06/2005	SLK	171	Information and communication	TV-TV tuner	•	•	•	•	•	•
As of 06/2005	SLK	171	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
As of 06/2005	SLK	171	Information and communication	GPS box	•	•	0	•	•	•
As of 06/2005	SLK	171	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
As of 06/2005	SLK	171	Seats and doors	DCM-L-Door control module left	•	•	•	•	•	0
As of 06/2005	SLK	171		DCM-R-Door control module right	•	•	•	•	•	0
As of 06/2005	SLK	171		ESA driver-Electric seat adjustment driver (with	•	•	•	•		0
As of 06/2005	SLK	171		ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
As of 06/2005	SLK	171	Seats and doors	HS-Seat heater					•	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 06/2005	SLK	171	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC- Automatic air conditioning/HEAT-Automatic heater	•	•	•	•	•	0
ALL	SLK	170(16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	0	•	•	*
ALL	SLK	170(16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
ALL	SLK	170(16- pin diagnos tic socket)	Drive	ESM-Electronic selector module	•	•	0	•	•	*
ALL	SLK	170(16- pin diagnos tic socket)	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•
ALL	SLK	170(16- pin diagnos tic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
ALL	SLK	170(16- pin diagnos tic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
ALL	SLK	tic socket)	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
ALL	SLK	170(16- pin diagnos tic socket)	Chassis	ESP-Electronic stability program	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SLK	170(16- pin diagnos tic socket)	Chassis	BAS-Brake assist	•	•	0	•	•	•
ALL	SLK	tic socket)	Chassis	VP-Vacuum pump brake booster	•	•	•	•	•	•
ALL	SLK	170(16- pin diagnos tic socket)	Body	AB-Airbag	•	•	0	•		*
ALL	SLK	170(16- pin diagnos tic socket)		RFL-Radio frequency locking/electric central locking	•	•	0	•	•	*
ALL	SLK	170(16- pin diagnos tic socket)		PSE-Pneumatic system equipment	•	•	0	•	•	*
ALL	SLK	170(16- pin diagnos tic socket)		CCM-Multifunction control module	•	•	0	•	•	*
ALL	SLK	170(16- pin diagnos tic socket)		VR-Vario roof	•	•	0	•	•	*
ALL	SLK	170(16- pin diagnos tic socket)	Body	HRA-Headlamp range adjustment	•	•	•	•	•	*

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SLK	170(16- pin diagnos tic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*
ALL	SLK	170(16- pin diagnos tic socket)	Information and communication	AUDIO	•	•	•	•	•	•
ALL	SLK	170(16- pin diagnos tic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
ALL	SLK	170(16- pin diagnos tic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
ALL	SLK	170(16- pin diagnos tic socket)	Information and communication	VCS-Voice control system	•	•	0	•		0
ALL	SLK	170(16- pin diagnos tic socket)	Information and communication	CDC-CD changer	•	•	•	•	0	0
ALL	SLK	170(16- pin diagnos tic socket)	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•
ALL	SLK	170(16- pin diagnos tic socket)	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SLK	170(16- pin diagnos tic socket)	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
ALL	SLK	170(16- pin diagnos tic socket)	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
ALL	SLK	170(16- pin diagnos tic socket)	Air conditioning	TAC-Automatic temperature control	•	•	0	•		*
ALL	SLK	170(16- pin diagnos tic socket)	Air conditioning	AAC-Automatic air conditioning	•	•	0	•		*
ALL	SLK	170(16- pin	Air conditioning	STH-Stationary heater	•	•	0	•	•	*
ALL	SLK	170(38- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	0	•		*
ALL	SLK	170(38- pin diagnos tic socket)	Drive	ME2-SFI-Motor electronics 2	•	•	0	•	•	*
ALL	SLK	170(38- pin	Chassis	ABS-Antilock brake system	•	•	0	•	•	*

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SLK	170(38- pin diagnos tic socket)	Chassis	ASR-Acceleration Slip Regulation	•	•	0	•	•	*
ALL	SLK	tic socket)	Chassis	ETS-Electronic traction system	•	•	0	•	•	*
ALL	SLK	tic socket)	Chassis	BAS-Brake assist	•	•	0	•	•	*
ALL	SLK	170(38- pin diagnos tic socket)	Body	AB-Airbag	•	•	0	•		*
ALL	SLK	170(38- pin diagnos tic socket)	Body	RFL-Radio frequency locking/electric central locking	•	•	0	•	•	*
ALL	SLK	170(38- pin diagnos tic socket)	Body	PSE-Pneumatic system equipment	•	•	0	•	•	*
ALL	SLK	170(38- pin diagnos tic socket)		CCM-Multifunction control module	•	•	0	•	•	*
ALL	SLK	170(38- pin diagnos tic socket)		VR-Vario roof	•	•	0	•	•	*

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SLK	170(38- pin diagnos tic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*
ALL	SLK	170(38- pin diagnos tic socket)	Information and communication	AUDIO	•	•	•	•	•	•
ALL	SLK	170(38- pin diagnos tic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
ALL	SLK	170(38- pin diagnos tic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
ALL	SLK	170(38- pin diagnos tic socket)	Information and communication	VCS-Voice control system	•	•	0	•		0
ALL	SLK	170(38- pin diagnos tic socket)	Information and communication	CDC-CD changer	•	•	•	•	0	0
ALL	SLK	170(38- pin diagnos tic socket)	Air conditioning	TAC-Automatic temperature control	•	•	0	•		*
ALL	SLK	170(38- pin		AAC-Automatic air conditioning	•	•	0	•		*
ALL	SLK	172	Drive	DTR-Distronic	•	•	•	•	•	
ALL	SLK	172	Drive	MED 17.7-Motor electronics for direct injection 17.7				•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SLK	172	Drive	ME-Motor electronics 'MED177AMG' for combustion engine 'M152' (N3/10)	•	•	0	•	0	•
ALL	SLK	172	Drive	FSCU-Fuel pump	•	•	•		•	
ALL	SLK	172	Drive	FSCU-Fuel pump	•	•			•	
ALL	SLK	172	Drive	mbrace-mbrace (N123/4)	•	•	0		0	
ALL	SLK	172	Drive	ESM-Electronic selector module	•	•			•	
ALL	SLK	172	Drive	FSCU-Fuel pump	•	•			0	
ALL	SLK	172	Drive	ETC-Electronic transmission control	•	•			•	
ALL	SLK	172	Drive	CDI 3-Common Rail Diesel Injection3	•	•			•	
ALL	SLK	172	Chassis	ESP-Electronic stability program (N30/4)	•	•	0		0	
ALL	SLK	172	Chassis	AIRSCARF-AIRSCARF system (N25/7)	•	•	•		•	
ALL	SLK	172	Chassis	EHPS-Electrohydraulic Power Steering	•	•	•		•	
ALL	SLK	172	Chassis	EFB-Electronic parking break (N128)	•	•	0		0	
ALL	SLK	172	Chassis	TPM-Tire pressure monitor	•	•	0		0	
ALL	SLK	172	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•	•	0	•	0	
ALL	SLK	172	Body	CGW-Central gateway	•	•	•	•	•	
ALL	SLK	172	Body	CGW-Central gateway	•	•	•		<b>A</b>	
ALL	SLK	172	Body	EZS-Electronic ignition lock	•	•	•		•	•
ALL	SLK	172	Body	VDS-Vario roof control (N52)	•	•	0	•	0	•
ALL	SLK	172	Body	SGR-Radar sensors control unit	<b>A</b>				<b>A</b>	
ALL	SLK	172	Body	SG-SW-Control unit 'Headlamp' (N71/1)	•	•	0		0	
ALL	SLK	172	Body	KG-Keyless Go	•	•	•		•	
ALL	SLK	172	Body	MSC-MAGIC SKY CONTROL (N53)	•	•	0		0	
ALL	SLK	172	Body	SRS-Supplemental restraint system (N2/10)	•	•	•		<b>A</b>	•
ALL	SLK	172	Body	RevETR-LF-Left front reversible emergency tensioning retractor (A76)	•	•	0	•	0	•
ALL	SLK	172	Body	RevETR-RF-Right front reversible emergency tensioning retractor(A76/1)	•	•	0	•	0	•
ALL	SLK	172	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	SLK	172	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	SLK	172	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>	
ALL	SLK	172	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	
ALL	SLK	172	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	•	•	<b>A</b>	
ALL	SLK	172	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0	•	0	•
ALL	SLK	172	Body	SCM-Steering column module(N80)	•	•	0		0	•
ALL	SLK	172	Body	SGR-Radar sensors control unit	•	•	•		0	•
ALL	SLK	172	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SLK	172	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	SLK	172	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	SLK	172	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	SLK	172	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•
ALL	SLK	172	Information and communication	DAB-Digital radio	•	•	•	•	•	•
ALL	SLK	172	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	SLK	172	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•
ALL	SLK	172	Information and communication	MFK-Multifunction camera	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>
ALL	SLK	172	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•
ALL	SLK	172	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•
ALL	SLK	172	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•
ALL	SLK	172	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	SLK	172	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	SLK	172	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	SLK	172	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	SLK	172	Information and communication	NAVI20 - Navigation(N125/2)	•	•	0	•	0	•
ALL	SLK	172	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
ALL	SLK	172	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
ALL	SLK	172	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
ALL	SLK	172	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	•	•	•	•		•
ALL	SLK	172	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SLK	172	Seats and doors	DCU-LF-Left front door	•	•	•		•	
ALL	SLK	172	Seats and doors	DCU-RF-Right front door	•	•	•		•	
ALL	SLK	172	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1)	•	•	0		0	
ALL	SLK	172	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•
ALL	SLK	172	Air conditioning	AAC-Air conditioning (N22/7)	•	•	0	•	0	•
ALL	SLK	172	LIN Bus	AU-Analog clock (A70/1)			0		0	
ALL	SLK	172	LIN Bus	GTO-Garage door opener (A67n2)			0		0	
ALL	SLK	172	LIN Bus	OCP-Overhead control panel(N70)			0		0	
ALL	GLK	X204	Drive	ETC-Electronic transmission control	•		•	•	•	
ALL	GLK	X204	Drive	ETC-Electronic transmission control	•		•	•	•	•
ALL	GLK	X204	Drive	ME 9.7-Motor electronics 9.7	•		•	•	•	
ALL	GLK	X204	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•
ALL	GLK	X204	Drive	MED 17.7-Motor electronics for direct injection 17.7	•		•	•	•	
ALL	GLK	X204	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•
ALL	GLK	X204	Drive	MED 9.7-Motor electronics for direct injection 9.7	•	•	•		•	
ALL	GLK	X204	Drive	FSCU-Fuel pump	•		•	•	0	
ALL	GLK	X204	Drive	FSCU-Fuel pump	•		•	•	•	
ALL	GLK	X204	Drive	FSCU-Fuel pump	•		•	•	•	
ALL	GLK	X204	Drive	FSCU Left-Control unit 'left fuel pump'	•		•	•	0	
ALL	GLK	X204	Drive	FSCU Right-Control unit 'Right fuel pump'	•		•	•	0	•
ALL	GLK	X204	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EV0' (N3/10)	•	•	•	•	•	•
ALL	GLK	X204	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•
ALL	GLK	X204	Drive	ESM-Electronic selector module	•	•	•	•	•	•
ALL	GLK	X204	Drive	DTR-Distronic	•	•	•	•	•	•
ALL	GLK	X204	Drive	PTCU-Common powertrain controller(N127)	•	•	0	•	0	•
ALL	GLK	X204	Drive	ISM-Shift module (A80)	<b>A</b>	<b>A</b>	<b>A</b>	lack	<b>A</b>	lack
ALL	GLK	X204	Drive	mbrace-mbrace (N123/4)	•	•	0	•	0	•
ALL	GLK	X204	Drive	SCR-Selective Catalytic Reduction			•		•	
ALL	GLK	X204	Drive	FSCU-Fuel pump			•		0	
ALL	GLK	X204	Drive	CDID-Common Rail Diesel Injection			•		0	
ALL	GLK	X204	Drive	CDI 3-Common Rail Diesel Injection3			•		•	
ALL	GLK	X204	Drive	ESM-Electronic selector module	•		•		•	
ALL	GLK	X204	Drive	CDI 6-Common Rail Diesel Injection			•		•	
ALL	GLK	X204	Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•	
ALL	GLK	X204	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	
ALL	GLK	X204	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	
ALL	GLK	X204	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•
ALL	GLK	X204	Chassis	ABR-Adaptive Brake	•	•	•	•	•	•
ALL	GLK	X204	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	GLK	X204	Chassis	TPM - Tire pressure monitor(N88)		•			•	
ALL	GLK	X204	Chassis	AIRMATIC-AIRMATIC					<b>A</b>	
ALL	GLK	X204	Chassis	EHPS-Electrohydraulic Power Steering		•			•	
ALL	GLK	X204	Chassis	ES-Electrical power steering (N68)		•	0		0	
ALL	GLK	X204	Chassis	ESP-Electronic stability program						
ALL	GLK	X204	Chassis	ESP-Regenerative braking system (N30/6)			0		0	
ALL	GLK	X204	Body	CGW-Central gateway						
ALL	GLK	X204	Body	CGW[ZGW]-Central gateway (CGW[ZGW])			0		0	
ALL	GLK	X204	Body	CGW-Central gateway		•			<b>A</b>	
ALL	GLK	X204	Body	EZS-Electronic ignition switch		•			•	
ALL	GLK	X204	Body	KG-Keyless Go		•			•	
ALL	GLK	X204	Body	KG-KEYLESS GO (N69/5)		•			•	
ALL	GLK	X204	Body	Trailer recognition module		•			•	
ALL	GLK	X204	Body	AB-Airbag		•			•	
ALL	GLK	X204	Body	SRS-Supplemental restraint system (N2/10)		•			<b></b>	
ALL	GLK	X204	Body	SRS-Supplemental restraint system		•	•		•	
ALL	GLK	X204	Body	WSS-Weight sensing system				•	•	
ALL	GLK	X204	Body	OCP-Overhead control panel				•	•	
ALL	GLK	X204	Body	PSD-Control mudule 'Panoramic sliding roof' (A98)				•	•	
ALL	GLK	X204	Body	PSD-Control mudule 'Panoramic sliding roof' (A98)		•			•	
ALL	GLK	X204	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	GLK	X204	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	GLK	X204	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>	
ALL	GLK	X204	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•
ALL	GLK	X204	Body	Rear SAM-Rear signal acquisition and actuation module					<u> </u>	
ALL	GLK	X204	Body	AHE-Trailer recognition		•		•	•	•
ALL	GLK	X204	Body	MSS-Special vehicle multifunction control module		•		•	•	
ALL	GLK	X204	Body	Multifunction control unit-Multifunction control unit (N26/14)	•	•	•	•	•	•
ALL	GLK	X204	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	GLK	X204	Body	RevETR-LF-Left front reversible emergency tensioning retractor(A76)	•	•	•	•	•	•
ALL	GLK	X204	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	GLK	X204	Body	RevETR-RF-Right front reversible emergency tensioning retractor (A76/1)	•	•	•	•	•	•
ALL	GLK	X204	Body	XALWA-L-Xenon headlamp, left	•					
ALL	GLK	X204 X204	Body	XALWA-L-Xenon headlamp, left						
MEL	OFW	A4U4	ινοαy	MILIT L ACTION HEAGTAMP, TELL			. •			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	GLK	X204	Body	XALWA-L-Xenon headlamp, left		•	•		•	
ALL	GLK	X204	Body	XALWA-R-Xenon headlamp, right	•	•	•		•	
ALL	GLK	X204	Body	XALWA-R-Xenon headlamp, right			•		•	
ALL	GLK	X204	Body	XALWA-R-Xenon headlamp, right			•		•	
ALL	GLK	X204	Body	EZS-Electronic ignition lock			•		•	
ALL	GLK	X204	Body	SG-SW-Control unit 'Headlamp' (N71/1)		•	0		0	
ALL	GLK	X204	Body	IRS-HRA-Outer right rear intelligent radar sensor			0	•	0	
ALL	GLK	X204	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•
ALL	GLK	X204	Body	SGR-Radar sensors control unit	<b>A</b>			<b>A</b>	_	
ALL	GLK	X204	Body	RFK-Backup camera (B84/3)	•	•	0	•	0	•
ALL	GLK	X204	Body	Rear SAM-Rear signal acquisition and actuation module	•		0	•	0	•
ALL	GLK	X204	Body	SCM-Steering column module(N80)	•		0	•	0	•
ALL	GLK	X204	Body	SGR-Radar sensors control unit	•	•	•	•	0	•
ALL	GLK	X204	Information and communication	ES-Electrical power steering	•	•	•	•	•	0
ALL	GLK	X204	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	GLK	X204	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	GLK	X204	Information and communication	ICI-InCar Internet (N125/3)	•	•	0	•	0	•
ALL	GLK	X204	Information and communication	PTS-Parktronic	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	PTS-PARKTRONIC (N62)	•	•	0	•	0	•
ALL	GLK	X204	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	COMAND or AUDIO	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	GLK	X204	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•
ALL	GLK	X204	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	ZBE-Audio/COMAND operating unit(A40/9)	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	TV-TV tuner	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	DAB-Digital radio	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•
ALL	GLK	X204	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	Left rear screen	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	Right rear screen	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
ALL	GLK	X204	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
ALL	GLK	X204	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
ALL	GLK	X204	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
ALL	GLK	X204	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
ALL	GLK	X204	Information and communication	AMG PM-AMG Performance Media(N125/2)	•	•	0	•	0	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	GLK	X204	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•
ALL	GLK	X204	Information and communication	Drive-side SAM-Front signal acquisition and actuation module (N10/1)	•	•	0	•	0	•
ALL	GLK	X204	Information and communication	MFK-Multifunction camera	•	•	•	<b>A</b>	<b>A</b>	•
ALL	GLK	X204	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•
ALL	GLK	X204	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•
ALL	GLK	X204	Information and communication	NAVI20 - Navigation(N125/2)	•	•	0	•	0	•
ALL	GLK	X204	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	•
ALL	GLK	X204	Seats and doors	DCU-LF-Left front door					•	
ALL	GLK	X204	Seats and doors	DCM-FR-Door control module front right					•	
ALL	GLK	X204	Seats and doors	DCU-RF-Right front door					•	
ALL	GLK	X204	Seats and doors	DCM-RL-Door control module rear left					•	
ALL	GLK	X204	Seats and doors	DCU-LR-Left rear door	•	•		•	•	
ALL	GLK	X204		DCM-RR-Door control module rear right	•	•	•	•	•	
ALL	GLK	X204	Seats and doors	DCU-RR-Right rear door	•				•	
ALL	GLK	X204		HKS-Tailgate control (N121/1)	•	•	•	•	•	
ALL	GLK	X204	Seats and doors	ESA driver	•	•	•	•	•	
ALL	GLK	X204	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1)	•	•	0	•	0	
ALL	GLK	X204	Seats and doors	ESA passenger	•			•	•	
ALL	GLK	X204		ESA-Electirc seat adjustment 'Front passenger' (N32/2)	•			•	•	
ALL	GLK	X204	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function (N32/2)	•	•	0	•	0	•
ALL	GLK	X204	Air conditioning	Stationary heater	•	•	•	•	•	•
ALL	GLK	X204		AAC-Air conditioning (N22/7)	•			•	•	
ALL	GLK	X204		AAC-Air conditioning (N22/7)	•	•	•	•	•	•
ALL	GLK	X204		EKMK-Electric refrigerant compressor (A9/5)	•	•	0	•	0	•
ALL	GLK	X204	LIN Bus	LCP-Lower control panel (S77)	•	•	0	•	0	•
ALL	GLK	X204	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•
ALL	GLK	X204	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•
ALL	GLK	X204	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•
ALL	M-Class	164	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
ALL	M-Class	164	Drive	VG-Transfer case	•	•	•	•	•	•
ALL	M-Class	164	Drive	HAQ-Interwheel differential lock at rear axle	•	•	•	•	•	•
ALL	M-Class	164	Drive	ISM-Intelligent servo module	•	•		•	•	•
ALL	M-Class	164	Drive	ISM-Shift module (A80)	<u> </u>	<u> </u>	<b>A</b>	<b>A</b>	À	Á

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	M-Class	164	Drive	ME 9.7-Motor electronics 9.7		•	•			
ALL	M-Class	164	Drive	FSCU-Fuel pump		•	•			
ALL	M-Class	164	Drive	DTR-Distronic						
ALL	M-Class	164	Drive	DTR-Distronic						
ALL	M-Class	164	Drive	IRS-HRA-Outer right rear intelligent radar sensor		•	•			
ALL	M-Class	164	Drive	IRS-HLA - Outer left rear intelligent radar sensor system	•	•	•	•	•	•
ALL	M-Class	164	Drive	TV-TV tuner	•	•	•	•	•	
ALL	M-Class	164	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
ALL	M-Class	164	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
ALL	M-Class	164	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•
ALL	M-Class	164	Drive	FSCU Left-Control unit 'Left fuel pump'	•	•	•	•	•	•
ALL	M-Class	164	Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	•	•
ALL	M-Class	164	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•
ALL	M-Class	164	Drive	CDI 6BIN5-Common Rail Diesel Injection	•	•	•	•	•	•
ALL	M-Class	164	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	
ALL	M-Class	164	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	
ALL	M-Class	164	Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•
ALL	M-Class	164	Drive	CDI 5-Common Rail Diesel Injection	•	•	•	•	•	•
ALL	M-Class	164	Drive	ETC-Electronic transmission control	•	•	•	•	•	
ALL	M-Class	164	Drive	ME-SF 17.7-Motor electronics 17.7	•	•	•	•	•	
ALL	M-Class	164	Drive	FSCU-Fuel pump		•			•	
ALL	M-Class	164	Drive	HSG-Hybrid control unit	•	•	•	•	•	•
ALL	M-Class	164	Chassis	ESP-Electronic stability program		•			•	•
ALL	M-Class	164	Chassis	Suspension		•			•	0
ALL	M-Class	164	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•
ALL	M-Class	164	Chassis	TPM - Tire pressure monitor(N88)		•			•	•
ALL	M-Class	164	Chassis	EHPS-Electrohydraulic Power Steering		•	•		•	
ALL	M-Class	164	Chassis	RBS-Brake system					<b>A</b>	
ALL	M-Class	164	Body	CGW-Central gateway	•	•	•		0	0
ALL	M-Class	164	Body	EZS-Electronic ignition switch		•	•		•	0
ALL	M-Class	164	Body	EZS-Electronic ignition switch		•	•		•	
ALL	M-Class	164	Body	KG-Keyless Go		•			•	
ALL	M-Class	164	Body	KG-KEYLESS GO	•	•	•		•	
ALL	M-Class	164	Body	AB-Airbag		•			•	
ALL	M-Class	164	Body	OCP-Overhead control panel		•			•	
ALL	M-Class	164	Body	WSS-Weight sensing system	•	•			•	
ALL	M-Class	164	Body	UCP-Upper control panel	•	•	•	•	•	0
ALL	M-Class	164	Body	HBF (Rear control panel)-Rear control field	•	•	•	•	•	0
ALL	M-Class	164	Body	SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	
ALL	M-Class	164	Body	REAR SAM-Rear signal acquisition and actuation module	•				•	0

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	M-Class	164	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	M-Class	164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	
ALL	M-Class	164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	M-Class	164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	
ALL	M-Class	164	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
ALL	M-Class	164	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	
ALL	M-Class	164	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•
ALL	M-Class	164	Body	XALWA-R-Xenon headlamp, right	•		•		•	
ALL	M-Class	164	Body	XALWA-R-Xenon headlamp, right	•		•		•	
ALL	M-Class	164	Body	System diagnosis (CAN)	•	•	0		•	•
ALL	M-Class	164	Body	SG-DDW - DC/DC converter control unit		•	•		•	
ALL	M-Class	164	Body	SG-BMS - Battery management system control unit			•		•	
ALL	M-Class	164	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	CM-Compass module	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
ALL	M-Class	164	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
ALL	M-Class	164	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•
ALL	M-Class	164	Information and communication	PTS-Parktronic system	•	•	•	•	•	0
ALL	M-Class	164	Information and communication	PTS-Parktronic system	•	•	•	•	•	0
ALL	M-Class	164	Information and communication	RFK-Backup camera	•	•	•	•	•	•
ALL	M-Class	164		AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	CDC-CD changer	•	•	0	•	•	•
ALL	M-Class	164	Information and communication	VCS-Voice control system	•	•	0	•		•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	M-Class	164	Information and communication	AUDIO	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
ALL	M-Class	164	Information and communication	TV-TV tuner	•	•	0	•	•	•
ALL	M-Class	164	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
ALL	M-Class	164	Information and communication	SOUND- Sound system	•	•	0	•	•	•
ALL	M-Class	164	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	NAVI-Navigation system	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	DAB-Digital radio	•	•	•	•	•	0
ALL	M-Class	164	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	TV-TV tuner	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
ALL	M-Class	164	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	Left rear screen	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	Right rear screen	•	•	•	•	•	•
ALL	M-Class	164	Information and communication	TELE AID-Control unit	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	M-Class	164	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
ALL	M-Class	164	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
ALL	M-Class	164	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
ALL	M-Class	164	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
ALL	M-Class	164	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0
ALL	M-Class	164	Seats and doors	DCM-FR-Door control module front right	•		•		•	0
ALL	M-Class	164	Seats and doors	ESA driver-Electric seat adjustment driver (with	•	•	•		•	
ALL	M-Class	164	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•		•	
ALL	M-Class	164	Seats and doors	DS-LF-Left front dynamic seat	•	•	•		•	
ALL	M-Class	164	Seats and doors	DS-RF-Right front dynamic seat	•		•		•	
ALL	M-Class	164	Seats and doors	DSP-Pneumatic pump for dynamic seat	•		•		•	
ALL	M-Class	164	Seats and doors	REDC-Rear-end door closing control module	•	•	•	•	•	0
ALL	M-Class	164	Seats and doors	REDC-Rear-end door closing control module	•	•	•	•	•	
ALL	M-Class	164	Seats and doors	HS-Seat heater	•		•		•	0
ALL	M-Class	164	Air conditioning	AAC-Automatic air conditioning	•		•		•	
ALL	M-Class	164	Air conditioning	HSW-Heated steering wheel	•		•		•	0
ALL	M-Class	164		STH-Stationary heater with remote control	•	•	•	•	•	•
ALL	M-Class	164	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)	•		•		•	
ALL	M-Class	163	Drive	ETC-Electronic transmission control	•	•	0			*
ALL	M-Class	163	Drive	ETC-Electronic transmission control	•		•		•	
ALL	M-Class	163	Drive	ESM-Electronic selector module	•		0		•	*
ALL	M-Class	163	Drive	ME2-SFI-Motor electronics 2	•	•	0	•	•	*
ALL	M-Class	163	Drive	VG-Transfer case	•		0		•	*
ALL	M-Class	163	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
ALL	M-Class	163	Drive	ME-SFI 2.8-Motor electronics 2.8	•		•		•	
ALL	M-Class	163	Drive	CDI 2-Common Rail Diesel Injection	•		•		•	
ALL	M-Class	163	Drive	CDI-V-Common Rail Diesel Injection	•		•		•	
ALL	M-Class	163	Chassis	ESP-Electronic stability program	•		•		•	•
ALL	M-Class	163	Chassis	ESP-Electronic stability program	•	•	0	•	•	*
ALL	M-Class	163	Chassis	ESP-Electronic stability program	•		0		•	*
ALL	M-Class	163	Chassis	ESP-Electronic stability program	•		0		•	*
ALL	M-Class	163	Chassis	ETS-Electronic traction system	•		0		•	*
ALL	M-Class	163	Chassis	ETS-Electronic traction system	•	•	0	•	•	*
ALL	M-Class	163	Chassis	BAS-Brake assist	•	•	0	•	•	*
ALL	M-Class	163	Chassis	VP-Vacuum pump brake booster	•	•	•	•	•	•
ALL	M-Class	163	Body	AB-Airbag	•	•	0	•		*
ALL	M-Class	163	Body	AB-Airbag	•	•	0		•	*
ALL	M-Class	163	Body	EAM-Extended activity module	•	•	0	•	•	*

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	M-Class	163	Body	AAM-All Activity Module	•		0	•	•	*
ALL	M-Class	163	Body	AAM-All Activity Module			0	•	•	*
ALL	M-Class	163	Body	DAS-Drive authorization system	•	•	•	•	•	*
ALL	M-Class	163	Body	HRA-Headlamp range adjustment			•	•	•	0
ALL	M-Class	163	Body	LCP-Lower operating panel with power window function	•	•	•	•	•	*
ALL	M-Class	163	Body	SEM-Security Module	•	•	0	•		*
ALL	M-Class	163	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*
ALL	M-Class	163	Information and communication	PTS-Parktronic system	•	•	•	•	•	*
ALL	M-Class	163	Information and communication	COMAND	•	•	0	•	•	•
ALL	M-Class	163	Information and communication	MCS-Modular control system	•	•	0	•	•	•
ALL	M-Class	163	Information and communication	AUDIO	•	•	•	•	•	•
ALL	M-Class	163	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0
ALL	M-Class	163	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
ALL	M-Class	163	Information and communication	CDC-CD changer	•	•	•	•	0	0
ALL	M-Class	163	Information and communication	VCS-Voice control system	•	•	0	•		0
ALL	M-Class	163	Information and communication	SOUND- Sound system	•	•	0	•	•	•
ALL	M-Class	163	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•
ALL	M-Class	163	Information and communication	MCS navigation-Navigation in MCS	•	•	0	•	•	•
ALL	M-Class	163	Information and	E-call [USA]-Telematic system	•	•	•	•	•	•
ALL	M-Class	163	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
ALL	M-Class	163		STH-Stationary heater	•	•	0	•	•	*
ALL	M-Class	163		AAC-Automatic air conditioning				•	•	
ALL	M-Class	166	Drive	DTR-Distronic				•	•	
ALL	M-Class	166	Drive	MED 17.7-Motor electronics for direct injection 17.7				•	•	
ALL	M-Class	166	Drive	ISM-Shift module (A80)					<b>A</b>	
ALL	M-Class	166	Drive	FSCU-Fuel pump	•	•	•	•	•	•
ALL	M-Class	166	Drive	FSCU-Fuel pump	•	•	•	•	•	•
ALL	M-Class	166	Drive	mbrace-mbrace (N123/4)	•	•	0	•	0	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	M-Class	166	Drive	SCR-Selective Catalytic Reduction	•					
ALL	M-Class	166	Drive	N15/7(Transfer case control module)	•		0		0	
ALL	M-Class	166	Drive	ETC-Electronic transmission control					•	
ALL	M-Class	166	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9)	•	•	0	•	0	•
ALL	M-Class	166	Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•	
ALL	M-Class	166	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	
ALL	M-Class	166	Chassis	Roll control-Roll control (N51/6)	•	•	0	•	0	
ALL	M-Class	166	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	
ALL	M-Class	166	Chassis	TPM-Tire pressure monitor	•	•	0	•	0	
ALL	M-Class	166	Chassis	EFB-Electronic parking break (N128)	•	•	0	•	0	
ALL	M-Class	166	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	
ALL	M-Class	166	Chassis	ESP-Regenerative braking system (N30/6)	•	•	0	•	0	
ALL	M-Class	166	Chassis	AIRMATIC - AIRMATIC(N51/3)	•	•	0	•	0	•
ALL	M-Class	166	Body	EZS-Electronic ignition switch	•	•	0	•	0	•
ALL	M-Class	166	Body	KG-KEYLESS GO	•	•	•	•	•	
ALL	M-Class	166	Body	KG-KEYLESS GO (N69/5)	•	•	0	•	0	•
ALL	M-Class	166	Body	BMS-Battery management system (N82/2)	•	•	0	•	0	•
ALL	M-Class	166	Body	IRS-HRA-Outer right rear intelligent radar sensor	•	•	0	•	0	
ALL	M-Class	166	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•
ALL	M-Class	166	Body	SAM-Signal acquisition and actuation module (N10)			0		0	•
ALL	M-Class	166	Body	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'			0		0	
ALL	M-Class	166	Body	SG-SW-Control unit 'Headlamp' (N71/1)			0		0	
ALL	M-Class	166	Body	SG-EM-Power electronics (N129/1)			0		0	
ALL	M-Class	166	Body	SRS-Supplemental restraint system (N2/10)			0		0	
ALL	M-Class	166	Body	HKS-Tailgate control (N121/1)			0		0	
ALL	M-Class	166	Body	Rear-Rear control unit (N10/8)			0		0	
ALL	M-Class	166	Body	RevETR-LF-Left front reversible emergency tensioning retractor (A76)	•	•	0	•	0	•
ALL	M-Class	166	Body	RevETR-RF-Right front reversible emergency tensioning retractor (A76/1)	•	•	0	•	0	•
ALL	M-Class	166	Body	SGR-Radar sensors control unit	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	lack
ALL	M-Class	166	Body	SCM-Steering column module(N80)	•	•	0	•	0	•
ALL	M-Class	166	Body	SD-Control module 'Sliding roof (A98/1)'	•		0		0	
ALL	M-Class	166	Body	Trailer recognition module-Trailer recognition (N28/1)	•		0	•	0	
ALL	M-Class	166	Body	PSD-Control module 'Panoramic sliding roof' (A98)	•	•	0	•	0	
ALL	M-Class	166	Body	SGR-Radar sensors control unit	•		•	•	0	
ALL	M-Class	166	Body	ATA-ATA[EDW]/tow-away protection/interior protection(N26/6)	•	•	0	•	0	•
ALL	M-Class	166	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	M-Class	166	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	M-Class	166	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	M-Class	166	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•
ALL	M-Class	166	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•
ALL	M-Class	166	Information and communication	DAB-Digital radio	•	•	•	•	•	•
ALL	M-Class	166	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	M-Class	166	Information and communication	Left rear screen	•	•	•	•	•	•
ALL	M-Class	166	Information and communication	Right rear screen	•	•	•	•	•	•
ALL	M-Class	166	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
ALL	M-Class	166	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•
ALL	M-Class	166	Information and communication	MFK-Multifunction camera	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>
ALL	M-Class	166	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•
ALL	M-Class	166	Information and communication	NSA-Night View Assist	•	•	•	•	•	0
ALL	M-Class	166	Toformation and	PTS-PARKTRONIC (N62)	•	•	0	•	0	•
ALL	M-Class	166	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	M-Class	166	Information and communication	SOUND - Sound system(N40/3)	•	•	0	•	0	•
ALL	M-Class	166	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	M-Class	166	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•
ALL	M-Class	166	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•
ALL	M-Class	166	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	M-Class	166	Information and communication	UCI-Media interface	•	•	•	•	•	•

M-Class M-Class M-Class M-Class	166 166 166 166 166 166 166 166	communication Information and communication Information and communication Seats and doors Seats and doors	TELE AID-Control unit  TELE AID-Telematic services Emergency call  TELE AID-Telematic services Remote door unlocking, Remote door locking  TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)  TELE AID-Telematic services Stolen vehicle tracking  DCU-LF-Left front door (N69/1)	•	•	•	•	•	•
M-Class M-Class M-Class M-Class M-Class M-Class M-Class M-Class M-Class	166 166 166 166 166 166	communication Information and communication Information and communication Information and communication Seats and doors Seats and doors	TELE AID-Telematic services Remote door unlocking, Remote door locking TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE) TELE AID-Telematic services Stolen vehicle tracking DCU-LF-Left front door (N69/1)	•	•	•	•		•
M-Class M-Class M-Class M-Class M-Class M-Class M-Class M-Class	166 166 166 166	communication Information and communication Information and communication Seats and doors Seats and doors	unlocking, Remote door locking TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE) TELE AID-Telematic services Stolen vehicle tracking DCU-LF-Left front door (N69/1)	•	•	•	•		•
M-Class M-Class M-Class M-Class M-Class M-Class M-Class	166 166 166 166	communication Information and communication Seats and doors Seats and doors	assistance(USA, Canada), Tele diagnosis(ECE)  TELE AID-Telematic services Stolen vehicle tracking  DCU-LF-Left front door (N69/1)	•	<del>                                     </del>				•
M-Class M-Class M-Class M-Class M-Class	166 166 166	Information and communication Seats and doors Seats and doors	TELE AID-Telematic services Stolen vehicle tracking DCU-LF-Left front door (N69/1)		•	•			
M-Class M-Class M-Class M-Class	166 166	Seats and doors Seats and doors		•					•
M-Class M-Class M-Class M-Class	166 166	Seats and doors				0	•	0	•
M-Class M-Class M-Class	166		DCU-RF-Right front door (N69/2)	•	•	0	•	0	•
M-Class M-Class		Seats and doors	DCU-LR-Left rear door (N69/3)	•	•	0	•	0	•
	100		DCU-RR-Right rear door (N69/4)	•	•	0	•	0	•
M. C1	166		MKS-FS-Multicontour seat 'Driver' (N32/29)	•	•	0	•	0	•
M-Class	166			•	•	0	•	0	•
M-Class	166		1	•	•	•	•	•	•
M-Class	166	Soats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function(N32/1)	•	•	0	•	0	•
M-Class	166	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•
M-Class	166	Air conditioning	AAC-Air conditioning (N22/7)	•		0	•	0	
M-Class				•		0	•	0	
M-Class	166	Air conditioning	STH-Stationary heater (A6n1)	•		0	•	0	
M-Class	166	LIN Bus	LCP-Lower control panel (N72)	•		0	•	0	
M-Class	166	LIN Bus	UCP-Upper control panel (N72/1)	•		0	•	0	
M-Class	166	LIN Bus	BSN-Battery sensor (B95)	•		0	•	0	
M-Class	166	LIN Bus	AISP-Dimming inside rearview mirror (A67)	•	•	0	•	0	•
M-Class	166	LIN Bus	GTO-Garage door opener (A67n2)	•		0		0	
M-Class	166	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•
M-Class	166	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting,	•	•	0	•	0	•
M-Class	166		RGLS-Rain/light sensor (B38/2)	•	•	0	•	0	•
			Robb Rain, 116nt Benber (Boo, 1)	•	•	0	•	Ö	•
				•	•	0	•	0	•
			AS-Alarm siren(H3/1)	•	•	0	•	0	•
	463(16- pin diagnos tic			•	•	•	•	•	•
	M-Class	M-Class 166	M—Class         166         Seats and doors           M—Class         166         Seats and doors           M—Class         166         Seats and doors           M—Class         166         Air conditioning           M—Class         166         Air conditioning           M—Class         166         Air conditioning           M—Class         166         LIN Bus           M—Class         166         D           M—Class         166         D           M—Class         166         D           M—Class         166         D           M—Class	M-Class 166 Seats and doors DSP-Pneumatic pump for dynamic seat M-Class 166 Seats and doors DSP-Pneumatic pump for dynamic seat M-Class 166 Seats and doors ESA' Priver' Electrical seat adjustment 'Driver' with memory function (N32/1) M-Class 166 Air conditioning AAC-Air conditioning (N22/7) M-Class 166 Air conditioning HBF-Rear control panel (N72/2) M-Class 166 Air conditioning STH-Stationary heater (A6n1) M-Class 166 LIN Bus LCP-Lower control panel (N72) M-Class 166 LIN Bus UCP-Upper control panel (N72/1) M-Class 166 LIN Bus BSN-Battery sensor (B95) M-Class 166 LIN Bus GTO-Garage door opener (A67n2) M-Class 166 LIN GTO-GARAGE M-Class 166 LIN GTO-GARAGE M-Class 166 LIN GTO-GARAGE M-Class 166 LIN GTO-GARAGE M-Cl	M-Class 166 Seats and doors MKS-BFS-Multicontour seat 'Front passenger' (N32/30) M-Class 166 Seats and doors DSP-Pneumatic pump for dynamic seat M-Class 166 Seats and doors ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function (N32/1) M-Class 166 Seats and doors ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function (N32/2) M-Class 166 Air conditioning AAC-Air conditioning (N22/7) M-Class 166 Air conditioning STH-Stationary heater (A6n1) M-Class 166 LIN Bus LCP-Lower control panel (N72/2) M-Class 166 LIN Bus UCP-Upper control panel (N72/1) M-Class 166 LIN Bus BSN-Battery sensor (B95) M-Class 166 LIN Bus AISP-Dimming inside rearview mirror (A67) M-Class 166 LIN Bus GTO-Garage door opener (A67n2) M-Class 166 LIN Bus AISP-Dimming inside rearview mirror (A67) M-Class 166 LIN Bus GTO-Garage door opener (A67n2) M-Class 166 LIN GTO-GARAGE AIR GTO-GARAGE AIR GTO-GARAGE AIR	M-Class 166 Seats and doors DSP-Pneumatic pump for dynamic seat   M-Class 166 Seats and doors DSP-Pneumatic pump for dynamic seat   M-Class 166 Seats and doors   M-Class 166 Seats and d	M-Class 166 Seats and doors MKS-BFS-Multicontour seat 'Front passenger' (N32/30)   M-Class 166 Seats and doors   M-Class 166 S	M-Class 166 Seats and doors MKS-BFS-Multicontour seat 'Front passenger' (N32/30)   M-Class 166 Seats and doors   M-Class 166 Air conditioning MAC-Air conditioning (N32/1)   M-Class 166 Air conditioning MBF-Rear control panel (N72/2)   M-Class 166 Air conditioning MBF-Rear control panel (N72/2)   M-Class 166 LIN Bus   M-Class 166 LIN Bus	M-Class 166 Seats and doors MKS-BFS-Multicontour seat 'Front passenger' (N32/30)

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Drive	ESM-Electronic selector module	•	•	0	•	•	*
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Drive	N15/7(Transfer case control module)	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Drive	CDI-V-Common Rail Diesel Injection	•	•	•	•	•	•
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Drive	CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•
Up to 03/2004	G-Class	463(16- pin	Chassis	ABS-Antilock brake system	•	•	•	•	•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Chassis	ESP-Electronic stability program	•	•	•	•	•	*
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Body	AB-Airbag	•	•	0	•	•	*
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Body	EZS-Electronic ignition switch	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Body	EZS-Electronic ignition switch	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Body	UCP-Upper control panel	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)		SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)		REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)		OCP-Overhead control panel	•	•	•	•	•	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)	Body	AHE-Trailer recognition	•	•	•	•	•	0
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)	Information and communication	AUDIO	•	•	•	•	•	•
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Information and communication	COMAND	•	•	0	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)	Information and communication	CDC-CD changer	•	•	•	•	0	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Information and communication	VCS-Voice control system	•	•	0	•		0
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)	Information and communication	TV-TV tuner	•	•	•	•		•
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Seats and doors	DCM-RR-Door control module rear right	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
Up to 03/2004	G-Class	tic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0
Up to 03/2004	G-Class	463(16- pin diagnos tic socket)	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•
Up to 03/2004	G-Class	463 (16- pin diagnos tic socket)	Air conditioning	STH-Stationary heater	•	•	•	•	•	•
Up to 03/2004	G-Class	tic socket)	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Drive	ESM-Electronic selector module	•	•	0	•	•	*
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Drive	N15/7(Transfer case control module)	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Drive	CDI-V-Common Rail Diesel Injection	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Drive	CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463(16- pin	Chassis	ABS-Antilock brake system	•	•	•	•	•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Chassis	ESP-Electronic stability program	•	•	•	•	•	*
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Body	EZS-Electronic ignition switch	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Body	AB-Airbag	•	•	0	•	•	*
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Body	UCP-Upper control panel	•	•	•	•	•	Ο
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Body	SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Body	OCP-Overhead control panel	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Body	AHE-Trailer recognition	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Information and communication	AUD10	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Information and communication	COMAND	•	•	0	•	•	•
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Information and communication	CDC-CD changer	•	•	•	•	0	Ο

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Information and communication	VCS-Voice control system	•	•	0	•		0
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Information and communication	TV-TV tuner	•	•	•	•		•
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Information and communication	TELE AID-Telematic system	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
From 04/2004 to 08/2006	G-Class	463(16- pin	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	Ο
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Seats and doors	DCM-RR-Door control module rear right	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	tic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463(16- pin	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463(16- pin diagnos tic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Air conditioning	STH-Stationary heater	•	•	•	•	•	•
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnos tic socket)	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Drive	ESM-Electronic selector module	•	•	0	•	•	*
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Drive	N15/7(Transfer case control module)	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Chassis	ABS-Antilock brake system	•	•	•	•	•	*
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Chassis	ESP-Electronic stability program	•	•	•	•	•	*

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Body	EZS-Electronic ignition switch	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Body	AB-Airbag	•	•	0	•	•	*
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Body	UCP-Upper control panel	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Body	SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Body	OCP-Overhead control panel	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Body	ALWR-Headlamp range adjustment	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Body	AHE-Trailer recognition	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	AUDIO	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and	COMAND	•	•	0	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	CDC-CD changer	•	•	•	•	0	0
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	VCS-Voice control system	•	•	0	•		0
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	TV-TV tuner	•	•	•	•		•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	TELE AID-Telematic system	•	•	•	•	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	AUDIO	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	CDC-CD changer	•	•	0	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	VCS-Voice control system	•	•	0	•		•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	SOUND- Sound system	•	•	0	•	•	•
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	NAVI-Navigation system	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)		TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	Ο
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Seats and doors	DCM-RR-Door control module rear right	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463(16- pin	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
From 09/2006 to 02/2007	G-Class	463(16- pin diagnos tic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463(16- pin	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnos tic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0
From 09/2006 to 02/2007	G-Class	463(16- pin	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin	Air conditioning	STH-Stationary heater	•	•	•	•	•	•
From 09/2006 to 02/2007	G-Class	463(16- pin	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Drive	ESM-Electronic selector module	•	•	0	•	•	*
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Drive	N15/7(Transfer case control module)	•	•	•	•	•	0
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)		TV-TV tuner	•	•	•	•	•	
As of 03/2007	G-Class	463(16- pin diagnos tic socket)		ME 9.7-Motor electronics 9.7	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•
As of 03/2007	G-Class	tic socket)	Chassis	ABS-Antilock brake system	•	•	•	•	•	*
As of 03/2007	G-Class	tic socket)	Chassis	ESP-Electronic stability program	•	•	•	•	•	*
As of 03/2007	G-Class	tic socket)	Chassis	ESP-Electronic stability program	•	•	•	•	•	•
As of 03/2007	G-Class	tic socket)	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Body	EZS-Electronic ignition switch	•	•	•	•	•	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Body	AB-Airbag	•	•	0	•	•	*
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Body	UCP-Upper control panel	•	•	•	•	•	0
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Body	SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Body	OCP-Overhead control panel	•	•	•	•	•	0
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Body	ALWR-Headlamp range adjustment	•	•	•	•	•	•
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Body	AHE-Trailer recognition	•	•	•	•	•	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Body	AHE-Trailer recognition	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	AUDIO	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	COMAND or AUDIO	•	•	0	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	CDC-CD changer	•	•	0	•	•	•
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	VCS-Voice control system	•	•	0	•		•
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	SOUND- Sound system	•	•	0	•	•	•
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	NAVI-Navigation system	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	COMAND or AUDIO	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	UCI-Media interface	•	•	•	•	•	•
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	DAB-Digital radio	•	•	•	•	•	0
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	TV-TV tuner	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin	Seats and doors	DCM-RR-Door control module rear right	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin diagnos tic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0
As of 03/2007	G-Class	463 (16- pin diagnos tic socket)	Seats and doors	HS-Seat heater	•	•	•	•	•	0
As of 03/2007	G-Class	463(16- pin	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•
As of 03/2007	G-Class	463(16- pin	Air conditioning	STH-Stationary heater	•	•	•	•	•	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
As of 03/2007	G-Class	tic socket)	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0
ALL	G-Class	463 (38- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	0	•		*
ALL	G-Class	463 (38- pin diagnos tic socket)	Drive	ESM-Electronic selector module	•	•	0	•	•	*
ALL	G-Class	463 (38- pin diagnos tic socket)	Drive	ME2-SFI-Motor electronics 2	•	•	0	•	•	*
ALL	G-Class	463 (38- pin diagnos tic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
ALL	G-Class	463 (38- pin diagnos tic socket)	Drive	HFM-SFI-Hot film engine management	•	•	0	•		*
ALL	G-Class	463 (38- pin diagnos tic socket)	Drive	IFI-Electronic in-line injection system diesel	•	•	0	•		*
ALL	G-Class	463(38- pin	Chassis	ABS-Antilock brake system	•	•	0	•	•	*

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	G-Class	463 (38- pin diagnos tic socket)		AB-Airbag	•	•	0	•		*
ALL	G-Class	463 (38- pin diagnos tic socket)	Body	APS-Auto pilot system	•	•	0	•	•	*
ALL	G-Class	463 (38- pin diagnos tic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*
ALL	G-Class	463 (38- pin diagnos tic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	G-Class	463 (38- pin diagnos tic socket)	Information and communication	AUDIO	•	•	•	•	•	•
ALL	G-Class	463(38- pin diagnos tic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0
ALL	G-Class	463 (38- pin diagnos tic socket)		VCS-Voice control system	•	•	0	•		0
ALL	G-Class	463 (38- pin diagnos tic socket)	Information and	CDC-CD changer	•	•	•	•	0	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	G-Class	463(38- pin diagnos tic socket)	Air conditioning	STH-Stationary heater	•	•	0	•	•	*
ALL	G-Class	461(16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
ALL	G-Class	461(16- pin diagnos tic socket)	Drive	ESM-Electronic selector module	•	•	0	•	•	*
ALL	G-Class	461(16- pin diagnos tic socket)	Drive	N15/7(Transfer case control module)	•	•	•	•	•	0
ALL	G-Class	461(16- pin diagnos tic socket)	Drive	CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•
ALL	G-Class	461(16- pin diagnos tic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
ALL	G-Class	461 (16- pin diagnos tic socket)	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	
ALL	G-Class	461(16- pin diagnos tic socket)	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	G-Class	tic socket)	Chassis	ABS-Antilock brake system	•	•	•	•	•	*
ALL	G-Class	tic socket)	Chassis	Traction systems ABS	•	•	•	•	•	
ALL	G-Class	461(16- pin diagnos tic socket)	Body	AB-Airbag	•	•	0	•	•	*
ALL	G-Class	461(16- pin diagnos tic socket)	Body	CGW-Central gateway	•	•	•	•	•	•
ALL	G-Class	461(16- pin diagnos tic socket)	Information and communication	WSP immobilizer	•	•	•	•	•	*
ALL	G-Class	461(16- pin diagnos tic socket)	Information and communication	IC-Instrument cluster	•	•	•	•	•	*
ALL	G-Class	461(16- pin	Information and communication	AUDIO	•	•	0	•	0	•
ALL	G-Class	461(16- pin		STH-Stationary heater	•	•	0	•	•	*
ALL	GL-Class	X 164	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
ALL	GL-Class	X 164	Drive	VG-Transfer case						

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL		X 164	Drive	HAQ-Interwheel differential lock at rear axle	•	•	•		•	
ALL		X 164	Drive	ISM-Intelligent servo module	•	•	•		•	
ALL		X 164	Drive	ISM-Shift module (A80)	lack					
ALL		X 164	Drive	ME 9.7-Motor electronics 9.7	•	•	•		•	
ALL	GL-Class	X 164	Drive	FSCU-Fuel pump		•			•	
ALL	GL-Class	X 164	Drive	DTR-Distronic					•	
ALL	GL-Class	X 164	Drive	DTR-Distronic						
ALL	GL-Class	X 164	Drive	IRS-HRA-Outer right rear intelligent radar sensor					•	
ALL	GL-Class	X 164	Drive	IRS-HLA - Outer left rear intelligent radar sensor system	•	•	•	•	•	•
ALL	GL-Class	X 164	Drive	TV-TV tuner	•	•	•	•	•	
ALL		X 164	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•
ALL		X 164	Drive	CDI 5-Common Rail Diesel Injection	•	•	•	•	•	•
ALL		X 164	Drive	CDI 6BIN5-Common Rail Diesel Injection	•	•		•	•	•
ALL		X 164	Drive	CDI 6-Common Rail Diesel Injection	•	•		•	•	
ALL		X 164	Drive	SCR-Selective Catalytic Reduction	•	•		•	•	•
ALL		X 164	Drive	CDI 60LS-Common Rail Diesel Injection				•	•	
ALL		X 164	Chassis	ESP-Electronic stability program				•	•	•
ALL		X 164	Chassis	EHPS-Electrohydraulic Power Steering	•	•	•	•	•	
ALL		X 164	Chassis	Suspension				•	•	0
ALL		X 164	Chassis	TPC-Tire pressure monitor				•	•	
ALL		X 164	Chassis	TPM - Tire pressure monitor(N88)	•	•		•	•	•
ALL		X 164	Body	CGW-Central gateway					0	0
ALL		X 164	Body	EZS-Electronic ignition switch		•	•	•	•	0
ALL		X 164	Body	EZS-Electronic ignition switch			•	•	•	•
ALL		X 164	Body	KG-Keyless Go				•	•	
ALL		X 164	Body	KG-KEYLESS GO				•	•	
ALL		X 164	Body	AB-Airbag			•	•	•	•
ALL		X 164	Body	OCP-Overhead control panel				•	•	•
ALL		X 164	Body	WSS-Weight sensing system				•	•	•
ALL		X 164	Body	UCP-Upper control panel				•	•	0
ALL		X 164	Body	HBF (Rear control panel)—Rear control field				•		0
ALL		X 164	Body	SAM-F-Signal acquisition and actuation module front	•	•				
ALL	GL-Class	-	Body	REAR SAM-Rear signal acquisition and actuation module						0
ALL		X 164	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	GL-Class	X 164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	
ALL	GL-Class	X 164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	GL-Class	X 164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	GL-Class	X 164	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
ALL	GL-Class	X 164	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	
ALL	GL-Class	X 164	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•
ALL	GL-Class	X 164	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	
ALL	GL-Class	X 164	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	•
ALL	GL-Class	X 164	Body	System diagnosis(CAN)	•	•	0	•	•	•
ALL	GL-Class	X 164	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	CM-Compass module	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
ALL	GL-Class	X 164	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
ALL	GL-Class	X 164	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•
ALL	GL-Class	X 164	Information and communication	PTS-Parktronic system	•	•	•	•	•	0
ALL	GL-Class	X 164	Information and communication	PTS-Parktronic system	•	•	•	•	•	0
ALL	GL-Class	X 164	Information and communication	RFK-Backup camera	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	CDC-CD changer	•	•	0	•	•	•
ALL	GL-Class	X 164	Information and communication	VCS-Voice control system	•	•	0	•		•
ALL	GL-Class	X 164	Information and communication	AUDIO	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
ALL	GL-Class	X 164	Information and communication	TV-TV tuner	•	•	0	•	•	•
ALL	GL-Class	X 164	Information and communication	TV-TV tuner (AGW)	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	GL-Class	X 164	Information and communication	SOUND- Sound system	•	•	0	•	•	•
ALL	GL-Class	X 164	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	NAVI-Navigation system	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	DAB-Digital radio	•	•	•	•	•	0
ALL	GL-Class	X 164	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	TV-TV tuner	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
ALL	GL-Class	X 164	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	Left rear screen	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	Right rear screen	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
ALL	GL-Class	X 164	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
ALL	GL-Class	X 164	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	•	•	•	•		•
ALL	GL-Class	X 164	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
ALL	GL-Class	X 164	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
ALL	GL-Class	X 164	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0
ALL	GL-Class	X 164	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	GL-Class	X 164	Seats and doors	ESA driver-Electric seat adjustment driver (with		•	•			
ALL	GL-Class	X 164	Seats and doors	ESA passenger-Electric seat adjustment passenger			•			
ALL	GL-Class	X 164	Seats and doors	DS-LF-Left front dynamic seat			•			
ALL	GL-Class	X 164	Seats and doors	DS-RF-Right front dynamic seat			•			
ALL	GL-Class	X 164	Seats and doors	DSP-Pneumatic pump for dynamic seat			•			
ALL	GL-Class	X 164	Seats and doors	ERA-Electric fold-down backrest system (3rd seat row)		•	•		•	
ALL	GL-Class	X 164	Seats and doors	REDC-Rear-end door closing control module		•	•		•	0
ALL	GL-Class	X 164	Seats and doors	REDC-Rear-end door closing control module		•	•		•	
ALL	GL-Class	X 164	Seats and doors	HS-Seat heater			•		•	0
ALL	GL-Class	X 164	Air conditioning	AAC-Automatic air conditioning			•	•	•	
ALL	GL-Class	X 164	Air conditioning	HSW-Heated steering wheel			•	•	•	0
ALL	GL-Class	X 164		STH-Stationary heater with remote control			•	•	•	
ALL	R-Class	251	Drive	ISM-Intelligent servo module	•	•	•	•	•	
ALL	R-Class	251	Drive	ISM-Shift module (A80)	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>
ALL	R-Class	251	Drive	ETC-Electronic transmission control	•	•	•	•	•	•
ALL	R-Class	251	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•
ALL	R-Class	251	Drive	FSCU-Fuel pump	•	•	•	•	•	
ALL	R-Class	251	Drive	DTR-Distronic	•	•	•	•	•	
ALL	R-Class	251	Drive	DTR-Distronic		•	•	•	•	
ALL	R-Class	251	Drive	IRS-HRA-Outer right rear intelligent radar sensor	•	•	•	•	•	
ALL	R-Class	251	Drive	IRS-HLA - Outer left rear intelligent radar sensor system	•	•	•	•	•	•
ALL	R-Class	251	Drive	TV-TV tuner	•	•	•	•	•	
ALL	R-Class	251	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•
ALL	R-Class	251	Drive	ME-SFI 2.8-Motor electronics 2.8			•	•	•	
ALL	R-Class	251	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)				•		
ALL	R-Class	251	Drive	FSCU Left-Control unit 'Left fuel pump'		•				
ALL	R-Class	251	Drive	FSCU Right-Control unit 'Right fuel pump'				•		
ALL	R-Class	251	Drive	CDI 4-Common Rail Diesel Injection						
ALL	R-Class	251	Drive	CDI 6BIN5-Common Rail Diesel Injection	•	•	•	•	•	
ALL	R-Class	251	Drive	CDI 6-Common Rail Diesel Injection				•		
ALL	R-Class	251	Drive	SCR-Selective Catalytic Reduction				•		
ALL	R-Class	251	Drive	CDI 60LS-Common Rail Diesel Injection						
ALL		251	Chassis	ESP-Electronic stability program						
ALL		251	Chassis	Suspension	•					0
ALL	R-Class	251	Chassis	Suspension	•				•	
ALL	R-Class	251	Chassis	TPC-Tire pressure monitor	•	•		•	•	•
ALL	R-Class	251	Chassis	TPM - Tire pressure monitor(N88)	•	•		•	•	
ALL	R-Class	251	Chassis	EHPS-Electrohydraulic Power Steering	•	•		•		
ALL	R-Class	251	Body	CGW-Central gateway	•	•			0	0
ALL	R-Class	251	Body	EZS-Electronic ignition switch	•	•				0
ALL	R-Class	251	Воду	EZS-Electronic ignition switch						

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	R-Class	251	Body	KG-Keyless Go						
ALL	R-Class	251	Body	KG-KEYLESS GO					•	
ALL	R-Class	251	Body	AB-Airbag		•			•	
ALL	R-Class	251	Body	OCP-Overhead control panel		•			•	
ALL	R-Class	251	Body	WSS-Weight sensing system		•		•	•	
ALL	R-Class	251	Body	UCP-Upper control panel					•	0
ALL	R-Class	251	Body	HBF (Rear control panel)-Rear control field					•	0
ALL	R-Class	251	Body	SAM-F-Signal acquisition and actuation module front					•	
ALL	R-Class	251	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•		•	0
ALL	R-Class	251	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	R-Class	251	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	
ALL	R-Class	251	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	R-Class	251	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	
ALL	R-Class	251	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0
ALL	R-Class	251	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	
ALL	R-Class	251	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	
ALL	R-Class	251	Body	System diagnosis(CAN)		•	0	•	•	
ALL	R-Class	251	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	CM-Compass module	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	IC-Instrument cluster	•	•	•	•	•	0
ALL	R-Class	251	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0
ALL	R-Class	251	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•
ALL	R-Class	251	Information and communication	PTS-Parktronic system	•	•	•	•	•	0
ALL	R-Class	251	Information and communication	PTS-Parktronic system	•	•	•	•	•	0
ALL	R-Class	251	Information and communication	RFK-Backup camera	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	R-Class	251	Information and communication	CDC-CD changer	•	•	0	•	•	•
ALL	R-Class	251	Information and communication	VCS-Voice control system	•	•	0	•		•
ALL	R-Class	251	Information and communication	AUDIO	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	COMAND or AUDIO	•	•	0	•	•	•
ALL	R-Class	251	Information and communication	TV-TV tuner	•	•	0	•	•	•
ALL	R-Class	251	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•
ALL	R-Class	251	Information and communication	SOUND- Sound system	•	•	0	•	•	•
ALL	R-Class	251	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	NAVI-Navigation system	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	DAB-Digital radio	•	•	•	•	•	0
ALL	R-Class	251	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	TV-TV tuner	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0
ALL	R-Class	251	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	Left rear screen	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	R-Class	251	Information and communication	Right rear screen	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
ALL	R-Class	251	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
ALL	R-Class	251	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
ALL	R-Class	251	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
ALL	R-Class	251	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
ALL	R-Class	251		DCM-FL-Door control module front left	•	•	•	•	•	0
ALL	R-Class	251		DCM-FR-Door control module front right	•	•	•	•	•	0
ALL	R-Class	251	Seats and doors	ESA driver-Electric seat adjustment driver (with	•	•		•	•	
ALL	R-Class	251	Seats and doors	ESA passenger-Electric seat adjustment passenger		•		•	•	
ALL	R-Class	251		DS-LF-Left front dynamic seat	•	•		•	•	
ALL	R-Class	251	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	
ALL	R-Class	251	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	
ALL	R-Class	251	Seats and doors	REDC-Rear-end door closing control module	•	•		•	•	0
ALL	R-Class	251	Seats and doors	REDC-Rear-end door closing control module		•		•	•	
ALL	R-Class	251	Seats and doors	HS-Seat heater	•	•		•	•	0
ALL	R-Class	251	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	
ALL	R-Class	251	Air conditioning	STH-Stationary heater with remote control				•	•	
ALL	R-Class	251	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0
ALL	E-Class	212	Drive	ETC-Electronic transmission control	•	•			•	
ALL	E-Class	212	Drive	ETC-Electronic transmission control		•				
ALL	E-Class	212	Drive	ME 9.7-Motor electronics 9.7		•			•	
ALL	E-Class	212	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	
ALL	E-Class	212	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•		•	
ALL	E-Class	212	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•
ALL	E-Class	212	Drive	MED 9.7-Motor electronics for direct injection 9.7	•	•	•	•	•	
ALL	E-Class	212	Drive	ME-Motor electronics 'MED40CNG' for combustion engine 'M274' (N3/10)	•	•	0	•	0	•
ALL	E-Class	212	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO' (N3/10)	•	•	•	•	•	•
ALL	E-Class	212	Drive	FSCU-Fuel pump	•	•	•	•	•	•
ALL	E-Class	212	Drive	FSCU-Fuel pump	•	•	•	•	•	
ALL	E-Class	212	Drive	DTR-Distronic	•	•	•	•	•	
ALL	E-Class	212	Drive	ESM-Electronic selector module	•	•	•	•	•	
ALL	E-Class	212	Drive	ISM-Shift module (A80)	A	Ā	Ā	<u> </u>	lack	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	E-Class	212	Drive	mbrace-mbrace (N123/4)	•	•	0		0	
ALL	E-Class	212	Drive	SCR-Selective Catalytic Reduction	•	•			•	
ALL	E-Class	212	Drive	FSCU-Fuel pump					0	
ALL	E-Class	212	Drive	CDI 6-Common Rail Diesel Injection	•					
ALL	E-Class	212	Drive	CDI 60LS-Common Rail Diesel Injection				•	•	
ALL	E-Class	212	Drive	CDI 6-Common Rail Diesel Injection					•	
ALL	E-Class	212	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	
ALL	E-Class	212	Drive	CDID-Common Rail Diesel Injection	•	•	•	•	0	
ALL	E-Class	212	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	
ALL	E-Class	212	Drive	CDI-Motor electronics 'CR42' for combustion engine 'OM607' (N3/9)	•	•	0	•	0	•
ALL	E-Class	212	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9)	•	•	0	•	0	•
ALL	E-Class	212	Drive	CDI-Motor electronics 'CDI61' for combustion engine 'OM642' (N3/9)	•	•	0	•	0	•
ALL	E-Class	212	Chassis	ES-Electrical power steering (N68)			0		0	
ALL	E-Class	212	Chassis	ESP-Electronic stability program (N30/4)			0		0	
ALL	E-Class	212	Chassis	ESP-Regenerative braking system (N30/6)	•		0		0	
ALL	E-Class	212	Chassis	ESP-Electronic stability program	•	•	•	•	•	
ALL	E-Class	212	Chassis	TPC-Tire pressure monitor	•			•	•	
ALL	E-Class	212	Chassis	TPM - Tire pressure monitor(N88)	•			•	•	
ALL	E-Class	212	Chassis	AIRMATIC-AIRMATIC	<b>A</b>			<b>A</b>	<b>A</b>	
ALL	E-Class	212	Chassis	FWGW-Chassis gateway (N97/7)	•	•	0	•	0	
ALL	E-Class	212	Body	CGW-Central gateway	•	•	•	•	•	
ALL	E-Class	212	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•		0	•	0	•
ALL	E-Class	212	Body	CGW-Central gateway	•		•	•	<b>A</b>	•
ALL	E-Class	212	Body	EZS-Electronic ignition lock	•		•	•	•	•
ALL	E-Class	212	Body	EZS-Electronic ignition lock (N73)	•		0	•	0	•
ALL	E-Class	212	Body	KG-Keyless Go	•		•	•	•	•
ALL	E-Class	212	Body	KG-KEYLESS GO(N69/5)	•	•	•	•	•	•
ALL	E-Class	212	Body	IRS-HRA-Outer right rear intelligent radar sensor	•	•	0	•	0	•
ALL	E-Class	212	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•
ALL	E-Class	212	Body	SRS-Supplemental restraint system (N2/10)	•	•	•	•	<b>A</b>	
ALL	E-Class	212	Body	SRS-Supplemental restraint system	•	•	•	•	•	•
ALL	E-Class	212	Body	WSS-Weight sensing system	•	•	•	•	•	•
ALL	E-Class	212	Body	OCP-Overhead control panel (N70)	•	•	•	•	•	•
ALL	E-Class	212	Body	PSD-Control mudule 'Panoramic sliding roof' (A98)	•	•	•	•	•	•
ALL	E-Class	212	Body	SGR-Radar sensors control unit	<b>A</b>	<b>A</b>	<u> </u>	<u> </u>	<u> </u>	<b>A</b>
ALL	E-Class	212	Body	SGR-Radar sensors control unit	•	•	•	•	0	•
ALL	E-Class	212	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	E-Class	212	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	E-Class	212	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>	
ALL	E-Class	212	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•
ALL	E-Class	212	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	•		<b>A</b>	
ALL	E-Class	212	Body	BMS-Battery management system (N82/2)	•	•	0	•	0	
ALL	E-Class	212	Body	Trailer recognition module	•	•	•	•	•	•
ALL	E-Class	212	Body	Multifunction control unit-Multifunction control unit (N26/14)	•	•	•	•	•	•
ALL	E-Class	212	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	E-Class	212	Body	RevETR-LF-Left front reversible emergency tensioning retractor(A76)	•	•	•	•	•	•
ALL	E-Class	212	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	E-Class	212	Body	RevETR-RF-Right front reversible emergency tensioning retractor(A76/1)	•	•	•	•	•	•
ALL	E-Class	212	Body	XALWA-L-Left xenon headlamp(E1n1)	•	•	•	•	•	•
ALL	E-Class	212	Body	XALWA-R-Right xenon headlamp(E2n1)	•		•	•	•	•
ALL	E-Class	212	Body	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	•	•	0	•	0	•
ALL	E-Class	212	Body	KG-KEYLESS GO (N69/5)	•		0	•	0	
ALL	E-Class	212	Body	SG-EM-Power electronics (N129/1)	•		0	•	0	
ALL	E-Class	212	Body	RFK-Backup camera (B84/3)	•	•	0	•	0	
ALL	E-Class	212	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0	•	0	
ALL	E-Class	212	Body	SCM-Steering column module(N80)	•	•	0		0	
ALL	E-Class	212	Information and communication	ES-Electrical power steering	•	•	•	•	•	0
ALL	E-Class	212	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•
ALL	E-Class	212	Information and communication	NSA-Night View Assist	•	•	•	•	•	0
ALL	E-Class	212	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	E-Class	212	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	E-Class	212	Information and communication	ICI-InCar Internet (N125/3)	•	•	0	•	0	•
ALL	E-Class	212	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	E-Class	212	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	ZBE-Audio/COMAND operating unit(A40/9)	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	DAB-Digital radio	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•
ALL	E-Class	212	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	Left rear screen	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	Right rear screen	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
ALL	E-Class	212	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
ALL	E-Class	212	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	E-Class	212	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
ALL	E-Class	212	Information and communication	MFK-Multifunction camera	<b>A</b>	•	•	•	•	•
ALL	E-Class	212	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•
ALL	E-Class	212	Information and communication	Drive-side SAM-Front signal acquisition and actuation module (N10/1)	•	•	0	•	0	•
ALL	E-Class	212	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•
ALL	E-Class	212	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•
ALL	E-Class	212	Information and communication	NSA-Night View Assist(N101)	•	•	0	•	0	•
ALL	E-Class	212	Information and communication	PTS-Parktronic	•	•	0	•	0	•
ALL	E-Class	212	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•
ALL	E-Class	212	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•
ALL	E-Class	212	Information and communication	NAVI20 - Navigation(N125/2)	•	•	0	•	0	•
ALL	E-Class	212	Seats and doors	DSP-Pneumatic pump for dynamic seat	•			•	•	
ALL	E-Class	212		DCU-LF-Left front door	•			•	•	
ALL	E-Class	212		DCU-RF-Right front door	•	•	•	•	•	
ALL	E-Class	212		DCU-LR-Left rear door	•	•	•	•	•	•
ALL	E-Class	212		DCU-RR-Right rear door						
ALL	E-Class	212		AMKS-LF-Active multicontour seat(N32/19)	•	•	•	•	•	
ALL	E-Class	212		AMKS-RF-Active multicontour seat (N32/22)	•	•	•	•	•	
ALL	E-Class	212		TLC-Trunk lid control	•	•	•	•	•	
ALL	E-Class	212		ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1)	•	•	0	•	0	
ALL	E-Class	212	Seats and doors		•	•	•	•	•	•
ALL	E-Class	212	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•
ALL	E-Class	212	Seats and doors	ESA passenger	•	•	•	•	•	•
ALL	E-Class	212		ESA-Electirc seat adjustment 'Front passenger' (N32/2)	•	•	•	•	•	
ALL	E-Class	212		SIH-FOND-Rear passenger compartment seat heater	<b>A</b>		Ā	<u> </u>	Ā	Ā
ALL	E-Class	212		Stationary heater	•	-	-	•	-	•
ALL	E-Class	212		AAC-Air conditioning	•	•	•	•	•	•
ALL	E-Class	212		LRH-Steering wheel heater	•				0	<b>A</b>

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	E-Class	212	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)	•	•	0		0	
ALL	E-Class	212	LIN Bus	LCP-Lower control panel (S77)			0		0	
ALL	E-Class	212	LIN Bus	AU-Analog clock (A70/1)			0		0	
ALL	E-Class	212	LIN Bus	GTO-Garage door opener (A67n2)			0		0	
ALL	E-Class	207	Drive	ETC-Electronic transmission control			•	•	•	
ALL	E-Class	207	Drive	ETC-Electronic transmission control					•	
ALL	E-Class	207	Drive	ME 9.7-Motor electronics 9.7		•	•		•	
ALL	E-Class	207	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	
ALL	E-Class	207	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•		•	
ALL	E-Class	207	Drive	MED 9.7-Motor electronics for direct injection 9.7	•		•	•	•	
ALL	E-Class	207	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•
ALL	E-Class	207	Drive	ME-Motor electronics 'MED40CNG' for combustion engine 'M274' (N3/10)	•	•	0	•	0	•
ALL	E-Class	207	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO' (N3/10)	•	•	•	•	•	•
ALL	E-Class	207	Drive	FSCU-Fuel pump			•		•	
ALL	E-Class	207	Drive	FSCU-Fuel pump			•	•	•	
ALL	E-Class	207	Drive	DTR-Distronic			•	•	•	
ALL	E-Class	207	Drive	ESM-Electronic selector module	•		•	•	•	
ALL	E-Class	207	Drive	ISM-Shift module (A80)					<b>A</b>	
ALL	E-Class	207	Drive	mbrace-mbrace (N123/4)			0		0	
ALL	E-Class	207	Drive	SCR-Selective Catalytic Reduction			•		•	
ALL	E-Class	207	Drive	CDI 6-Common Rail Diesel Injection			•		•	
ALL	E-Class	207	Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•	
ALL	E-Class	207	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	
ALL	E-Class	207	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	
ALL	E-Class	207	Drive	CDID-Common Rail Diesel Injection	•	•	•	•	0	•
ALL	E-Class	207	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	
ALL	E-Class	207	Drive	CDI-Motor electronics 'CR42' for combustion engine 'OM607' (N3/9)	•	•	0	•	0	•
ALL	E-Class	207	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9)	•	•	0	•	0	•
ALL	E-Class	207	Drive	CDI-Motor electronics 'CDI61' for combustion engine 'OM642' (N3/9)	•	•	0	•	0	•
ALL	E-Class	207	Chassis	ESP-Electronic stability program	•	•	•	•	•	
ALL	E-Class	207	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	
ALL	E-Class	207	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	
ALL	E-Class	207	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	
ALL	E-Class	207	Chassis	AIRMATIC-AIRMATIC	<b>A</b>		lack	<b>A</b>	<b>A</b>	
ALL	E-Class	207	Chassis	AIRSCARF-AIRSCARF system (N25/7)	•	•	•	•	•	•
ALL	E-Class	207	Chassis	FWGW-Chassis gateway (N97/7)	•	•	0	•	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	E-Class	207	Body	CGW-Central gateway	•	•	•		•	
ALL	E-Class	207	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•	•	0		0	
ALL	E-Class	207	Body	CGW-Central gateway	•	•				
ALL	E-Class	207	Body	EZS-Electronic ignition switch	•	•	•		•	
ALL	E-Class	207	Body	EZS-Electronic ignition lock (N73)	•	•	0		0	
ALL	E-Class	207	Body	KG-Keyless Go						
ALL	E-Class	207	Body	KG-KEYLESS GO(N69/5)	•	•				
ALL	E-Class	207	Body	IRS-HRA-Outer right rear intelligent radar sensor			0		0	
ALL	E-Class	207	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•
ALL	E-Class	207	Body	SRS-Supplemental restraint system	•	•	•	•	•	•
ALL	E-Class	207	Body	SRS-Supplemental restraint system (N2/10)	•	•	•	•	<b>A</b>	•
ALL	E-Class	207	Body	WSS-Weight sensing system	•	•	•	•	•	•
ALL	E-Class	207	Body	OCP-Overhead control panel	•	•	•	•	•	•
ALL	E-Class	207	Body	PSD-Control mudule 'Panoramic sliding roof' (A98)	•	•	•	•	•	•
ALL	E-Class	207	Body	SGR-Radar sensors control unit	<b>A</b>		<b>A</b>	<b>A</b>	<b>A</b>	lack
ALL	E-Class	207	Body	SGR-Radar sensors control unit	•	•	•	•	0	•
ALL	E-Class	207	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	E-Class	207	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	E-Class	207	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>	
ALL	E-Class	207	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	
ALL	E-Class	207	Body	Rear SAM-Rear signal acquisition and actuation module				•		
ALL	E-Class	207	Body	Rear SAM-Rear signal acquisition and actuation module			0	•	0	
ALL	E-Class	207	Body	Trailer recognition module	•	•	•	•	•	•
ALL	E-Class	207	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	E-Class	207	Body	RevETR-LF-Left front reversible emergency tensioning retractor(A76)	•	•	•	•	•	•
ALL	E-Class	207	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	E-Class	207	Body	RevETR-RF-Right front reversible emergency tensioning retractor (A76/1)	•	•	•	•	•	•
ALL	E-Class	207	Body	XALWA-L-Left xenon headlamp(Eln1)	•	•	•	•	•	•
ALL	E-Class	207	Body	XALWA-R-Right xenon headlamp(E2n1)	•	•	•	•	•	
ALL	E-Class	207	Body	BMS-Battery management system (N82/2)	•	•	0	•	0	
ALL	E-Class	207	Body	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	•	•	0	•	0	•
ALL	E-Class	207	Body	KG-KEYLESS GO (N69/5)	•	•	0	•	0	
ALL	E-Class	207	Body	SG-EM-Power electronics (N129/1)	•	•	0	•	0	•
ALL	E-Class	207	Body	RFK-Backup camera (B84/3)	•		0	•	0	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	E-Class	207	Body	SCM-Steering column module(N80)	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	ES-Electrical power steering	•	•	•	•	•	0
ALL	E-Class	207	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	ICI-InCar Internet (N125/3)	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	ZBE-Audio/COMAND operating unit(A40/9)	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	DAB-Digital radio	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	E-Class	207	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
ALL	E-Class	207	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
ALL	E-Class	207	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
ALL	E-Class	207	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
ALL	E-Class	207	Information and communication	SG-FOND-Rear control unit (N22/6)	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	MFK-Multifunction camera	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>
ALL	E-Class	207	Information and communication	Left rear screen	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	Right rear screen	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	Drive-side SAM-Front signal acquisition and actuation module (N10/1)	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	NSA-Night View Assist(N101)	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	PTS-Parktronic	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•
ALL	E-Class	207	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	E-Class	207	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•
ALL	E-Class	207	Information and communication	NAVI20 - Navigation(N125/2)	•	•	0	•	0	•
ALL	E-Class	207	Seats and doors	DCU-LF-Left front door		•			•	
ALL	E-Class	207	Seats and doors	DCU-RF-Right front door		•			•	
ALL	E-Class	207	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1)		•	0		0	
ALL	E-Class	207	Seats and doors	ESA driver		•				
ALL	E-Class	207	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function (N32/2)	•	•	0	•	0	•
ALL	E-Class	207	Seats and doors	ESA passenger					•	
ALL	E-Class	207	Seats and doors	ESA-Electirc seat adjustment 'Front passenger' (N32/2)					•	
ALL	E-Class	207	Seats and doors	SIH-FOND-Rear passenger compartment seat heater					•	
ALL	E-Class	207		DSP-Pneumatic pump for dynamic seat		•	•		•	
ALL	E-Class	207		HKS-Tailgate control (N121/1)		•	•		•	
ALL	E-Class	207	Air conditioning	Stationary heater		•	•		•	
ALL	E-Class	207	Air conditioning	AAC-Air conditioining	•	•	•	•	•	
ALL	E-Class	207	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)	•	•	0	•	0	
ALL	E-Class	207	LIN Bus	LCP-Lower control panel (S77)	•	•	0	•	0	
ALL	E-Class	207	LIN Bus	AU-Analog clock (A70/1)	•	•	0	•	0	•
ALL	E-Class	207	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•
ALL	SLS	197	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•
ALL	SLS	197	Drive	ISM-Shift module (A80)	<b>A</b>		<b>A</b>	<b>A</b>	<b>A</b>	lack
ALL	SLS	197	Drive	FSCU-Fuel pump	•	•	•	•	0	•
ALL	SLS	197	Chassis	AIRSCARF-AIRSCARF system (N25/7)	•	•	•	•	•	•
ALL	SLS	197	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•
ALL	SLS	197	Chassis	ESP-Electronic stability program (N30/4)	•		0		0	•
ALL	SLS	197	Chassis	Electronic parking brake-Electric parking brake			•		•	•
ALL	SLS	197	Chassis	EHPS-Electrohydraulic Power Steering			•	•	•	
ALL	SLS	197	Chassis	EFB-Electronic parking break (N128)			0		0	•
ALL	SLS	197	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	•
ALL	SLS	197	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•		0		0	•
ALL	SLS	197	Body	CGW-Central gateway	•		•		•	•
ALL	SLS	197	Body	CGW-Central gateway	•	•	•	•	<b>A</b>	
ALL	SLS	197	Body	EZS-Electronic ignition lock	•	•	•	•	•	•
ALL	SLS	197	Body	BMS-Battery management system	•		0	•	0	
ALL	SLS	197	Body	BMS-Battery management system	•		0	•	0	•
ALL	SLS	197	Body	BMS-Battery management system	•		0	•	0	•
ALL	SLS	197	Body	VDS-Soft top control (N52)	•		0	•	0	•
ALL	SLS	197	Body	SRS-Supplemental restraint system			•	•	•	•
ALL	SLS	197	Body	DDW-DC/DC converter (N83/1)			0	•	0	•
ALL	SLS	197	Body	IRS-HRA-Outer right rear intelligent radar sensor		•	0		0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SLS	197	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•
ALL	SLS	197	Body	KG-Keyless Go	•			•	•	
ALL	SLS	197	Body	WSS-Weight sensing system						
ALL	SLS	197	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	SLS	197	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	SLS	197	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>	
ALL	SLS	197	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•
ALL	SLS	197	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	•	•	<u> </u>	<u> </u>
ALL	SLS	197	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0	•	0	•
ALL	SLS	197	Information and communication	AMG PM-AMG Performance Media(N125/2)	•	•	0	•	0	•
ALL	SLS	197	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•
ALL	SLS	197	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	SLS	197	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	SLS	197	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	SLS	197	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•
ALL	SLS	197	Information and communication	DAB-Digital radio	•	•	•	•	•	•
ALL	SLS	197	Information and communication	DKG-Electronic transmission control for double-plate clutch transmission (N15/13)	•	•	0	•	0	•
ALL	SLS	197	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	SLS	197	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•
ALL	SLS	197	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•
ALL	SLS	197	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•
ALL	SLS	197	Information and communication	COMAND or AUDIO	•	•	•	•	•	•
ALL	SLS	197	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SLS	197	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•
ALL	SLS	197	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•
ALL	SLS	197	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	SLS	197	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	SLS	197	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	SLS	197	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•
ALL	SLS	197	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	SLS	197	Information and communication	TELE AID-Control unit	•	•	•	•	•	•
ALL	SLS	197	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•
ALL	SLS	197	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•
ALL	SLS	197	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•
ALL	SLS	197	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•
ALL	SLS	197	1	DCU-LF-Left front door	•	•	•	•	•	
ALL	SLS	197		DCU-RF-Right front door				•	•	<b>A</b>
ALL	SLS	197		ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1)	•		0	•	0	•
ALL	SLS	197		ESA driver				•	•	
ALL	SLS	197	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•
ALL	SLS	197	Seats and doors	ESA passenger	•	•	•	•	•	
ALL	SLS	197		EKMK-Electric refrigerant compressor (A9/5)				•	•	
ALL	SLS	197		AAC-Air conditioning (N22/7)			0	•	0	
ALL	SLS	197		GTO-Garage door opener (A67n2)	•	•	0	•	0	•
ALL	SLS	197	LIN Bus	BSN-Battery sensor (B95)	•	•	0	•	0	•
ALL	CLA	117	Drive	PTCU-Common powertrain controller(N127)	•	•	0	•	0	•
ALL	CLA	117	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•
ALL	CLA	117	Drive	ME-Motor electronics 'MED40AMG' for combustion engine 'M133' (N3/10)	•	•	0	•	0	•
ALL	CLA	117	Drive	FSCU-Fuel pump	•	•	•	•	•	•
ALL	CLA	117	Drive	FSCU-Fuel pump	•	•	•	•	•	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	CLA	117	Drive	mbrace-mbrace (N123/4)	•	•	0		0	
ALL	CLA	117	Drive	SCR-Selective Catalytic Reduction	•	•	•		•	
ALL	CLA	117	Drive	PTCU-Common powertrain controller(N127)	•	•	0		0	
ALL	CLA	117	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•		•	
ALL	CLA	117	Drive	CDI-Motor electronics 'CRR1' for combustion engine 'OM607' (N3/9)	•	•	0	•	0	•
ALL	CLA	117	Chassis	ES-Electrical power steering (N68)			0		0	
ALL	CLA	117	Chassis	ESP-Electronic stability program (N30/4)			0		0	•
ALL	CLA	117	Chassis	TPM-Tire pressure monitor	•	•	0		0	
ALL	CLA	117	Chassis	EFB-Electronic parking break (N128)			0		0	
ALL	CLA	117	Chassis	DTR-DISTRONIC (A89)			0		0	
ALL	CLA	117	Chassis	DTR-DISTRONIC (A89)			0		0	
ALL	CLA	117	Body	EZS-Electronic ignition switch	•	•	0	•	0	•
ALL	CLA	117	Body	SAM-Signal acquisition and actuation module (N10)	•	•	0	•	0	•
ALL	CLA	117	Body	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	•	•	0	•	0	•
ALL	CLA	117	Body	SG-SW-Control unit 'Headlamp' (N71/1)	•	•	0	•	0	•
ALL	CLA	117	Body	IRS-HRA-Outer right rear intelligent radar sensor	•	•	0	•	0	•
ALL	CLA	117	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•
ALL	CLA	117	Body	SRS-Supplemental restraint system (N2/10)	•	•	0	•	0	•
ALL	CLA	117	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	CLA	117	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	CLA	117	Body	SCM-Steering column module (N80)	•	•	0	•	0	•
ALL	CLA	117	Body	Trailer recognition module-Trailer recognition (N28/1)	•		0	•	0	•
ALL	CLA	117	Body	PSD-Control module 'Panoramic sliding roof (A98)'			0		0	
ALL	CLA	117	Body	ATA-ATA[EDW]/tow-away protection/interior protection (N26/6)	•	•	0	•	0	•
ALL	CLA	117	Information and communication	KAB-Control unit 'Camera cover' (N42)	•	•	0	•	0	•
ALL	CLA	117	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•
ALL	CLA	117	Communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	CLA	117	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	CLA	117	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	CLA	117	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	CLA	117	Information and communication	DAB-Digital radio	•	•	•	•	•	•
ALL	CLA	117	Information and communication	DKG-Electronic transmission control for double-plate clutch transmission (N15/13)	•	•	0	•	0	•
ALL	CLA	117	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	CLA	117	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•
ALL	CLA	117	Information and communication	MFK-Multifunction camera	•	•	•	•	<b>A</b>	•
ALL	CLA	117	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•
ALL	CLA	117	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•
ALL	CLA	117	Information and communication	PTS-Parktronic	•	•	0	•	0	•
ALL	CLA	117	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	CLA	117	Information and communication	SOUND - Sound system(N40/3)	•	•	0	•	0	•
ALL	CLA	117	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	CLA	117	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	CLA	117	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	CLA	117	Information and communication	Audio-Audio 5 USB(A2)	•	•	0	•	0	•
ALL	CLA	117	Seats and doors	DCU-LF-Left front door (N69/1)	•	•	0	•	0	
ALL	CLA	117	Seats and doors	DCU-RF-Right front door (N69/2)	•	•	0	•	0	•
ALL	CLA	117	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function(N32/1)	•	•	0	•	0	•
ALL	CLA	117	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•
ALL	CLA	117	Air conditioning	AAC-Air conditioning (N22/7)	•	•	0	•	0	•
ALL	CLA	117		STH-Stationary heater (A6n1)	•	•	0	•	0	•
ALL	CLA	117	LIN Bus	AISP-Dimming inside rearview mirror (A67)	•	•	0	•	0	•
ALL	CLA	117	LIN Bus	UCP-Upper control panel (N72/1)	•	•	0	•	0	•
ALL	CLA	117	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•
ALL	CLA	117	LIN Bus	BSN-Battery sensor (B95)	•	•	0	•	0	•
ALL	CLA	117	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	CLA	117	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•
ALL	CLA	117	LIN Bus	RGLS-Rain/light sensor (B38/2)	•	•	0	•	0	
ALL	CLA	117	LIN Bus	OCP-Control unit 'Overhead control panel' (N70)	•	•	0	•	0	
ALL	CLA	117	LIN Bus	AS-Alarm siren(H3/1)	•	•	0	•	0	
ALL	A-Class	176	Drive	PTCU-Common powertrain controller(N127)			0		0	
ALL	A-Class	176	Drive	PTCU-Common powertrain controller(N127)		•	0		0	
ALL	A-Class	176	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•
ALL	A-Class	176	Drive	ME-Motor electronics 'MED40AMG' for combustion engine 'M133' (N3/10)	•	•	0	•	0	•
ALL	A-Class	176	Drive	FSCU-Fuel pump	•	•	•	•	•	•
ALL	A-Class	176	Drive	FSCU-Fuel pump			•	•	•	
ALL	A-Class	176	Drive	mbrace-mbrace (N123/4)			0		0	
ALL	A-Class	176	Drive	SCR-Selective Catalytic Reduction			•			
ALL	A-Class	176	Drive	CDI 3-Common Rail Diesel Injection3			•			
ALL	A-Class	176	Drive	CDI-Motor electronics 'CRR1' for combustion engine 'OM607' (N3/9)	•	•	0	•	0	•
ALL	A-Class	176	Chassis	ES-Electrical power steering (N68)	•		0	•	0	
ALL	A-Class	176	Chassis	ESP-Electronic stability program (N30/4)			0	•	0	
ALL	A-Class	176	Chassis	EFB-Electronic parking break (N128)			0	•	0	
ALL	A-Class	176	Chassis	DTR-DISTRONIC (A89)			0	•	0	
ALL	A-Class	176	Chassis	DTR-DISTRONIC (A89)	•		0	•	0	•
ALL	A-Class	176	Chassis	TPM-Tire pressure monitor	•		0	•	0	
ALL	A-Class	176	Body	EZS-Electronic ignition switch			0	•	0	
ALL	A-Class	176	Body	SAM-Signal acquisition and actuation module (N10)			0	•	0	
ALL	A-Class	176	Body	IRS-HRA-Outer right rear intelligent radar sensor	•		0	•	0	•
ALL	A-Class	176	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•
ALL	A-Class	176	Body	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	•		0	•	0	
ALL	A-Class	176	Body	SG-SW-Control unit 'Headlamp' (N71/1)			0	•	0	
ALL	A-Class	176	Body	SRS-Supplemental restraint system (N2/10)			0	•	0	
ALL	A-Class	176	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	A-Class	176	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•
ALL	A-Class	176	Body	SCM-Steering column module(N80)	•	•	0	•	0	•
ALL	A-Class	176	Body	Trailer recognition module-Trailer recognition(N28/1)	•	•	0	•	0	
ALL	A-Class	176	Body	PSD-Control module 'Panoramic sliding roof (A98)'	•	•	0	•	0	•
ALL	A-Class	176	Body	ATA-ATA[EDW]/tow-away protection/interior protection(N26/6)	•	•	0	•	0	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	A-Class	176	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	A-Class	176	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	A-Class	176	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	A-Class	176	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•
ALL	A-Class	176	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•
ALL	A-Class	176	Information and communication	DAB-Digital radio	•	•	•	•	•	•
ALL	A-Class	176	Information and communication	DKG-Electronic transmission control for double-plate clutch transmission (N15/13)	•	•	0	•	0	•
ALL	A-Class	176	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	A-Class	176	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•
ALL	A-Class	176	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•
ALL	A-Class	176	Information and communication	MFK-Multifunction camera	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>
ALL	A-Class	176	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•
ALL	A-Class	176	Information and communication	PTS-PARKTRONIC (N62)	•	•	0	•	0	•
ALL	A-Class	176	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	A-Class	176	Information and communication	SOUND - Sound system(N40/3)	•	•	0	•	0	•
ALL	A-Class	176	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	A-Class	176	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	A-Class	176	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	A-Class	176	Information and communication	Audio-Audio 5 USB(A2)	•	•	0	•	0	•
ALL	A-Class	176	Seats and doors	DCU-LF-Left front door (N69/1)	•	•	0	•	0	•
ALL	A-Class	176	Seats and doors	DCU-RF-Right front door (N69/2)	•	•	0	•	0	•
ALL	A-Class	176	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function(N32/1)	•	•	0	•	0	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	A-Class	176	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•
ALL	A-Class	176	Air conditioning	AAC-Air conditioning (N22/7)		•	0		0	
ALL	A-Class	176	Air conditioning	STH-Stationary heater (A6n1)			0	•	0	
ALL	A-Class	176	LIN Bus	UCP-Upper control panel (N72/1)		•	0	•	0	
ALL	A-Class	176	LIN Bus	BSN-Battery sensor (B95)		•	0		0	
ALL	A-Class	176	LIN Bus	AISP-Dimming inside rearview mirror (A67)		•	0		0	
ALL	A-Class	176	LIN Bus	GTO-Garage door opener (A67n2)			0		0	
ALL	A-Class	176	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	•	•	0	•	0	•
ALL	A-Class	176	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•
ALL	A-Class	176	LIN Bus	RGLS-Rain/light sensor (B38/2)	•	•	0	•	0	•
ALL	A-Class	176	LIN Bus	OCP-Control unit 'Overhead control panel' (N70)		•	0	•	0	
ALL	A-Class	176	LIN Bus	AS-Alarm siren(H3/1)		•	0	•	0	•
ALL	SL	231	Drive	ME-Motor electronics 'ME1778' for combustion engine 'M277' (N3/10)	•	•	0	•	0	•
ALL	SL	231	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•	
ALL	SL	231	Drive	DTR-Distronic		•	•	•	•	•
ALL	SL	231	Drive	ISM-Shift module (A80)			<b>A</b>	<b>A</b>	<u> </u>	<b>A</b>
ALL	SL	231	Drive	FSCU-Fuel pump	•	•	•	•	•	•
ALL	SL	231	Drive	mbrace-mbrace (N123/4)	•	•	0	•	0	•
ALL	SL	231	Chassis	ABC-ABC (N51/2)		•	0	•	0	•
ALL	SL	231	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•
ALL	SL	231	Chassis	AIRSCARF-AIRSCARF system (N25/7)	•	•	•	•	•	•
ALL	SL	231	Chassis	EFB-Electronic parking break (N128)	•	•	0	•	0	•
ALL	SL	231	Chassis	TPM-Tire pressure monitor	•	•	0	•	0	•
ALL	SL	231	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•	•	0	•	0	•
ALL	SL	231	Body	CGW-Central gateway	•	•	•	•	•	•
ALL	SL	231	Body	CGW-Central gateway	•	•	•	•	<b>A</b>	•
ALL	SL	231	Body	EZS-Electronic ignition lock (N73)	•	•	0	•	0	•
ALL	SL	231	Body	SRS-Supplemental restraint system (N2/10)	•	•	•	•	<b>A</b>	•
ALL	SL	231	Body	SGR-Radar sensors control unit	lack	<b>A</b>	<b>A</b>		<b>A</b>	lack
ALL	SL	231	Body	VDS-Vario roof control (N52)	•	•	0	•	0	•
ALL	SL	231	Body	SG-SW-Control unit 'Headlamp' (N71/1)	•	•	0	•	0	•
ALL	SL	231	Body	KG-KEYLESS GO	•	•	•	•	•	
ALL	SL	231	Body	KG-KEYLESS GO (N69/5)	•	•	0	•	0	•
ALL	SL	231	Body	MSC-MAGIC SKY CONTROL (N53)	•	•	0	•	0	•
ALL	SL	231	Body	RevETR-LF-Left front reversible emergency tensioning retractor (A76)	•	•	0	•	0	•
ALL	SL	231	Body	RevETR-RF-Right front reversible emergency tensioning retractor (A76/1)	•	•	0	•	0	•

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SL	231	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	SL	231	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•
ALL	SL	231	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>	
ALL	SL	231	Body	REAR SAM-Rear signal acquisition and actuation module	•	•			•	
ALL	SL	231	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	•			
ALL	SL	231	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0		0	
ALL	SL	231	Body	SCM-Steering column module(N80)	•	•	0		0	
ALL	SL	231	Body	SGR-Radar sensors control unit	•	•	•		0	
ALL	SL	231	Information and communication	AMG PM-AMG Performance Media(N125/2)	•	•	0	•	0	•
ALL	SL	231	Information and communication	ES-Electrical power steering	•	•	•	•	•	0
ALL	SL	231	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	SL	231	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•
ALL	SL	231	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•
ALL	SL	231	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•
ALL	SL	231	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•
ALL	SL	231	Information and communication	DAB-Digital radio	•	•	•	•	•	•
ALL	SL	231	Information and communication	ZAN-Central display	•	•	•	•	•	•
ALL	SL	231	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•
ALL	SL	231	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•
ALL	SL	231	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•
ALL	SL	231	Information and communication	MFK-Multifunction camera	•	•	•	•	<b>A</b>	•
ALL	SL	231	Information and communication	NSA-Night View Assist(N101)	•	•	0	•	0	•
ALL	SL	231	Information and communication	PTS-PARKTRONIC (N62)	•	•	0	•	0	•

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame
ALL	SL	231	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•
ALL	SL	231	Information and communication	SOUND - Sound system(N40/3)	•	•	0	•	0	•
ALL	SL	231	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•
ALL	SL	231	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•
ALL	SL	231	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•
ALL	SL	231	Information and communication	UCI-Media interface	•	•	•	•	•	•
ALL	SL	231	Seats and doors	DCU-LF-Left front door (N69/1)		•	0		0	
ALL	SL	231	Seats and doors	DCU-RF-Right front door (N69/2)	•	•	0		0	
ALL	SL	231	Seats and doors	DS-LF-Left front dynamic seat	•	•	•		•	
ALL	SL	231	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	
ALL	SL	231	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	
ALL	SL	231	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function(N32/1)	•	•	0	•	0	•
ALL	SL	231	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•
ALL	SL	231	Air conditioning	AAC-Air conditioning (N22/7)			0		0	
ALL	SL	231	LIN Bus	AU-Analog clock (A70/1)		•	0		0	
ALL	SL	231	LIN Bus	BFS LSE-Lumbar support 'Front passenger seat' (N32/24)		•	0		0	
ALL	SL	231	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0		0	•
ALL	SL	231	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7)	•	•	0	•	0	•
ALL	SL	231	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•
ALL	SL	231	LIN Bus	OCP-Overhead control panel(N70)	•	•	0	•	0	•