

MaxiDiag_Jaguar_V2.10 Function List (Note:For reference only)

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- ▲ This function is the new feature in this version.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XK8	2000			ABS	●	●	●
XK8	2000			ECM	●	●	●
XK8	2000			IPK	●	●	●
XK8	2000			TCM	●	●	●
XK8	2000			ACC	●	●	●
XK8	2000			SBC	●	●	●
XK8	2000			DSM	●	●	●
XK8	2000			PSM	●	●	●
XK8	2000			SLM	●	●	●
XK8	2000			PDM	●	●	●
XK8	2000			DDM	●	●	●
XK8	2000			BPM	●	●	●
XK8	2000			CCM	●	●	●
XK8	2000			ADS	●	●	●
XK8	2000			ACM	●	●	●
XK8	2000			KTM	●	●	●
XK8	2001			ABS	●	●	●
XK8	2001			ECM	●	●	●
XK8	2001			IPK	●	●	●
XK8	2001			TCM	●	●	●
XK8	2001			ACC	●	●	●
XK8	2001			SBC	●	●	●
XK8	2001			DSM	●	●	●
XK8	2001			PSM	●	●	●
XK8	2001			SLM	●	●	●
XK8	2001			PDM	●	●	●
XK8	2001			DDM	●	●	●
XK8	2001			BPM	●	●	●
XK8	2001			DHM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XK8	2001			PHM	●	●	●
XK8	2001			CCM	●	●	●
XK8	2001			ARM	●	●	●
XK8	2001			KTM	●	●	●
XK8	2001			ADS	●	●	●
XK8	1997			ABS	●	●	●
XK8	1997			ECM	●	●	●
XK8	1997			IPK	●	●	●
XK8	1997			TCM	●	●	●
XK8	1997			DSM	●	●	●
XK8	1997			PSM	●	●	●
XK8	1997			SLM	●	●	●
XK8	1997			PDM	●	●	●
XK8	1997			DDM	●	●	●
XK8	1997			BPM	●	●	●
XK8	1997			ACM	●	●	●
XK8	1997			CCM	●	●	●
XK8	1997			ADS	●	●	●
XK8	1997			KTM	●	●	●
XK8	1997_25			ABS	●	●	●
XK8	1997_25			ECM	●	●	●
XK8	1997_25			IPK	●	●	●
XK8	1997_25			TCM	●	●	●
XK8	1997_25			DSM	●	●	●
XK8	1997_25			PSM	●	●	●
XK8	1997_25			SLM	●	●	●
XK8	1997_25			PDM	●	●	●
XK8	1997_25			DDM	●	●	●
XK8	1997_25			BPM	●	●	●
XK8	1997_25			ACM	●	●	●
XK8	1997_25			CCM	●	●	●
XK8	1997_25			ADS	●	●	●
XK8	1997_25			KTM	●	●	●
XK8	1998			ABS	●	●	●
XK8	1998			ECM	●	●	●
XK8	1998			IPK	●	●	●
XK8	1998			TCM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XK8	1998			DSM	●	●	●
XK8	1998			PSM	●	●	●
XK8	1998			SLM	●	●	●
XK8	1998			PDM	●	●	●
XK8	1998			DDM	●	●	●
XK8	1998			BPM	●	●	●
XK8	1998			ACM	●	●	●
XK8	1998			CCM	●	●	●
XK8	1998			ADS	●	●	●
XK8	1998			KTM	●	●	●
XK8	1998_75			ABS	●	●	●
XK8	1998_75			ECM	●	●	●
XK8	1998_75			IPK	●	●	●
XK8	1998_75			TCM	●	●	●
XK8	1998_75			DSM	●	●	●
XK8	1998_75			PSM	●	●	●
XK8	1998_75			SLM	●	●	●
XK8	1998_75			PDM	●	●	●
XK8	1998_75			DDM	●	●	●
XK8	1998_75			BPM	●	●	●
XK8	1998_75			ACM	●	●	●
XK8	1998_75			CCM	●	●	●
XK8	1998_75			ADS	●	●	●
XK8	1998_75			KTM	●	●	●
XK8	1999			ABS	●	●	●
XK8	1999			ECM	●	●	●
XK8	1999			IPK	●	●	●
XK8	1999			TCM	●	●	●
XK8	1999			DSM	●	●	●
XK8	1999			PSM	●	●	●
XK8	1999			SLM	●	●	●
XK8	1999			PDM	●	●	●
XK8	1999			DDM	●	●	●
XK8	1999			BPM	●	●	●
XK8	1999			ACM	●	●	●
XK8	1999			CCM	●	●	●
XK8	1999			ADS	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XK8	1999			KTM	●	●	●
XK8	2000			ABS	●	●	●
XK8	2000			ECM	●	●	●
XK8	2000			IPK	●	●	●
XK8	2000			TCM	●	●	●
XK8	2000			ACC	●	●	●
XK8	2000			SBC	●	●	●
XK8	2000			DSM	●	●	●
XK8	2000			PSM	●	●	●
XK8	2000			SLM	●	●	●
XK8	2000			PDM	●	●	●
XK8	2000			DDM	●	●	●
XK8	2000			BPM	●	●	●
XK8	2000			CCM	●	●	●
XK8	2000			ADS	●	●	●
XK8	2000			ACM	●	●	●
XK8	2000			ATM	●	●	●
XK8	2001			ABS	●	●	●
XK8	2001			ECM	●	●	●
XK8	2001			IPK	●	●	●
XK8	2001			TCM	●	●	●
XK8	2001			ACC	●	●	●
XK8	2001			SBC	●	●	●
XK8	2001			DSM	●	●	●
XK8	2001			PSM	●	●	●
XK8	2001			SLM	●	●	●
XK8	2001			PDM	●	●	●
XK8	2001			DDM	●	●	●
XK8	2001			BPM	●	●	●
XK8	2001			DHM	●	●	●
XK8	2001			PHM	●	●	●
XK8	2001			CCM	●	●	●
XK8	2001			ADS	●	●	●
XK8	2001			ARM	●	●	●
XK8	2001			KTM	●	●	●
XK8	2003			ATM	●	●	●
XK8	2003			PAM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XK8	2003			PDM	●	●	●
XK8	2003			PHM	●	●	●
XK8	2003			PSM	●	●	●
XK8	2003			SLM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		ABS	●	●	●
New XK	2006.5-2009	Normal aspirated V8		CCM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		ADCM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		HCM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		PCM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		VIM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		PBM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		IPC	●	●	●
New XK	2006.5-2009	Normal aspirated V8		ICS	●	●	●
New XK	2006.5-2009	Normal aspirated V8		RCM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		TCM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		DDM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		DSM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		FLR	●	●	●
New XK	2006.5-2009	Normal aspirated V8		FSJB	●	●	●
New XK	2006.5-2009	Normal aspirated V8		FTCM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		ICM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		ICP	●	●	●
New XK	2006.5-2009	Normal aspirated V8		KVM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		PAM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		PDM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		PSM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		HVAC	●	●	●
New XK	2006.5-2009	Normal aspirated V8		RSJB	●	●	●
New XK	2006.5-2009	Normal aspirated V8		TPM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		FCDIM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		ACM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		AAM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		NCM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		SRM	●	●	●
New XK	2006.5-2009	Normal aspirated V8		BPM	●	●	●
New XK	2006.5-2009	Supercharged V8		ABS	●	●	●
New XK	2006.5-2009	Supercharged V8		CCM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
New XK	2006. 5-2009	Supercharged V8		ADCM	●	●	●
New XK	2006. 5-2009	Supercharged V8		HCM	●	●	●
New XK	2006. 5-2009	Supercharged V8		PCM	●	●	●
New XK	2006. 5-2009	Supercharged V8		VIM	●	●	●
New XK	2006. 5-2009	Supercharged V8		PBM	●	●	●
New XK	2006. 5-2009	Supercharged V8		IPC	●	●	●
New XK	2006. 5-2009	Supercharged V8		ICS	●	●	●
New XK	2006. 5-2009	Supercharged V8		RCM	●	●	●
New XK	2006. 5-2009	Supercharged V8		TCM	●	●	●
New XK	2006. 5-2009	Supercharged V8		DDM	●	●	●
New XK	2006. 5-2009	Supercharged V8		DSM	●	●	●
New XK	2006. 5-2009	Supercharged V8		FSJB	●	●	●
New XK	2006. 5-2009	Supercharged V8		FTCM	●	●	●
New XK	2006. 5-2009	Supercharged V8		ICM	●	●	●
New XK	2006. 5-2009	Supercharged V8		ICP	●	●	●
New XK	2006. 5-2009	Supercharged V8		KVM	●	●	●
New XK	2006. 5-2009	Supercharged V8		PAM	●	●	●
New XK	2006. 5-2009	Supercharged V8		PDM	●	●	●
New XK	2006. 5-2009	Supercharged V8		PSM	●	●	●
New XK	2006. 5-2009	Supercharged V8		HVAC	●	●	●
New XK	2006. 5-2009	Supercharged V8		RSJB	●	●	●
New XK	2006. 5-2009	Supercharged V8		TPM	●	●	●
New XK	2006. 5-2009	Supercharged V8		FCDIM	●	●	●
New XK	2006. 5-2009	Supercharged V8		ACM	●	●	●
New XK	2006. 5-2009	Supercharged V8		AAM	●	●	●
New XK	2006. 5-2009	Supercharged V8		NCM	●	●	●
New XK	2006. 5-2009	Supercharged V8		SRM	●	●	●
New XK	2006. 5-2009	Supercharged V8		BPM	●	●	●
New XK	2006. 5-2009	Supercharged V8		FLR	●	●	●
New XK	2010	Normal aspirated V8		AAM	●	●	●
New XK	2010	Normal aspirated V8		ABS	●	●	●
New XK	2010	Normal aspirated V8		ACM	●	●	●
New XK	2010	Normal aspirated V8		ADCM	●	●	●
New XK	2010	Normal aspirated V8		APIM	●	●	●
New XK	2010	Normal aspirated V8		BCM	●	●	●
New XK	2010	Normal aspirated V8		CCM	●	●	●
New XK	2010	Normal aspirated V8		DABM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
New XK	2010	Normal aspirated V8		DACMC	●	●	●
New XK	2010	Normal aspirated V8		DCSM	●	●	●
New XK	2010	Normal aspirated V8		DDM	●	●	●
New XK	2010	Normal aspirated V8		DSM	●	●	●
New XK	2010	Normal aspirated V8		FCDIM	●	●	●
New XK	2010	Normal aspirated V8		FLR	●	●	●
New XK	2010	Normal aspirated V8		FSJB	●	●	●
New XK	2010	Normal aspirated V8		FTCM	●	●	●
New XK	2010	Normal aspirated V8		GSM	●	●	●
New XK	2010	Normal aspirated V8		HCM	●	●	●
New XK	2010	Normal aspirated V8		HVAC	●	●	●
New XK	2010	Normal aspirated V8		ICM	●	●	●
New XK	2010	Normal aspirated V8		ICP	●	●	●
New XK	2010	Normal aspirated V8		ICS	●	●	●
New XK	2010	Normal aspirated V8		IPC	●	●	●
New XK	2010	Normal aspirated V8		KVM	●	●	●
New XK	2010	Normal aspirated V8		NCM	●	●	●
New XK	2010	Normal aspirated V8		OCS	●	●	●
New XK	2010	Normal aspirated V8		PAM	●	●	●
New XK	2010	Normal aspirated V8		PBM	●	●	●
New XK	2010	Normal aspirated V8		PCM	●	●	●
New XK	2010	Normal aspirated V8		PDM	●	●	●
New XK	2010	Normal aspirated V8		PSM	●	●	●
New XK	2010	Normal aspirated V8		RCM	●	●	●
New XK	2010	Normal aspirated V8		RDCM	●	●	●
New XK	2010	Normal aspirated V8		RSJB	●	●	●
New XK	2010	Normal aspirated V8		SRM	●	●	●
New XK	2010	Normal aspirated V8		TCM	●	●	●
New XK	2010	Normal aspirated V8		TEL	●	●	●
New XK	2010	Normal aspirated V8		TPM	●	●	●
New XK	2010	Normal aspirated V8		VIM	●	●	●
New XK	2010	Supercharged V8		AAM	●	●	●
New XK	2010	Supercharged V8		ABS	●	●	●
New XK	2010	Supercharged V8		ACM	●	●	●
New XK	2010	Supercharged V8		ADCM	●	●	●
New XK	2010	Supercharged V8		APIM	●	●	●
New XK	2010	Supercharged V8		BCM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
New XK	2010	Supercharged V8		CCM	●	●	●
New XK	2010	Supercharged V8		DABM	●	●	●
New XK	2010	Supercharged V8		DACMC	●	●	●
New XK	2010	Supercharged V8		DCSM	●	●	●
New XK	2010	Supercharged V8		DDM	●	●	●
New XK	2010	Supercharged V8		DSM	●	●	●
New XK	2010	Supercharged V8		FCDIM	●	●	●
New XK	2010	Supercharged V8		FLR	●	●	●
New XK	2010	Supercharged V8		FSJB	●	●	●
New XK	2010	Supercharged V8		FTCM	●	●	●
New XK	2010	Supercharged V8		GSM	●	●	●
New XK	2010	Supercharged V8		HCM	●	●	●
New XK	2010	Supercharged V8		HVAC	●	●	●
New XK	2010	Supercharged V8		ICM	●	●	●
New XK	2010	Supercharged V8		ICP	●	●	●
New XK	2010	Supercharged V8		ICS	●	●	●
New XK	2010	Supercharged V8		IPC	●	●	●
New XK	2010	Supercharged V8		KVM	●	●	●
New XK	2010	Supercharged V8		NCM	●	●	●
New XK	2010	Supercharged V8		OCS	●	●	●
New XK	2010	Supercharged V8		PAM	●	●	●
New XK	2010	Supercharged V8		PBM	●	●	●
New XK	2010	Supercharged V8		PCM	●	●	●
New XK	2010	Supercharged V8		PDM	●	●	●
New XK	2010	Supercharged V8		PSM	●	●	●
New XK	2010	Supercharged V8		RCM	●	●	●
New XK	2010	Supercharged V8		RDCM	●	●	●
New XK	2010	Supercharged V8		RSJB	●	●	●
New XK	2010	Supercharged V8		SRM	●	●	●
New XK	2010	Supercharged V8		TCM	●	●	●
New XK	2010	Supercharged V8		TEL	●	●	●
New XK	2010	Supercharged V8		TPM	●	●	●
New XK	2010	Supercharged V8		VIM	●	●	●
S-Type	1999_25			PAM	●	●	●
S-Type	1999_25			RCM	●	●	●
S-Type	1999_25			ABS	●	●	●
S-Type	1999_25			ADS	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
S-Type	1999_25			CCM	●	●	●
S-Type	1999_25			CPM	●	●	●
S-Type	1999_25			DDM	●	●	●
S-Type	1999_25			DSM	●	●	●
S-Type	1999_25			GEM	●	●	●
S-Type	1999_25			ICE	●	●	●
S-Type	1999_25			IPK	●	●	●
S-Type	1999_25			MCC	●	●	●
S-Type	1999_25			NAV	●	●	●
S-Type	1999_25			PCM	●	●	●
S-Type	1999_25			REM	●	●	●
S-Type	1999_25			RES	●	●	●
S-Type	1999_25			SCL	●	●	●
S-Type	1999_25			TCU	●	●	●
S-Type	1999_25			VAM	●	●	●
S-Type	2000			PAM	●	●	●
S-Type	2000			RCM	●	●	●
S-Type	2000			ABS	●	●	●
S-Type	2000			ADS	●	●	●
S-Type	2000			CCM	●	●	●
S-Type	2000			CPM	●	●	●
S-Type	2000			DDM	●	●	●
S-Type	2000			DSM	●	●	●
S-Type	2000			GEM	●	●	●
S-Type	2000			ICE	●	●	●
S-Type	2000			IPK	●	●	●
S-Type	2000			MCC	●	●	●
S-Type	2000			NAV	●	●	●
S-Type	2000			PCM	●	●	●
S-Type	2000			REM	●	●	●
S-Type	2000			RES	●	●	●
S-Type	2000			SCL	●	●	●
S-Type	2000			TCU	●	●	●
S-Type	2000			VAM	●	●	●
S-Type	2001			PAM	●	●	●
S-Type	2001			RCM	●	●	●
S-Type	2001			ABS	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
S-Type	2001			ADS	●	●	●
S-Type	2001			CCM	●	●	●
S-Type	2001			CPM	●	●	●
S-Type	2001			DDM	●	●	●
S-Type	2001			DSM	●	●	●
S-Type	2001			GEM	●	●	●
S-Type	2001			ICE	●	●	●
S-Type	2001			IPK	●	●	●
S-Type	2001			MCC	●	●	●
S-Type	2001			NAV	●	●	●
S-Type	2001			PCM	●	●	●
S-Type	2001			REM	●	●	●
S-Type	2001			RES	●	●	●
S-Type	2001			SCL	●	●	●
S-Type	2001			TCU	●	●	●
S-Type	2001			VAM	●	●	●
S-Type	2002. 5			ABS	●	●	●
S-Type	2002. 5			ACC	●	●	●
S-Type	2002. 5			ADHLS	●	●	●
S-Type	2002. 5			ADRC	●	●	●
S-Type	2002. 5			AMP	●	●	●
S-Type	2002. 5			ARM	●	●	●
S-Type	2002. 5			ATC	●	●	●
S-Type	2002. 5			CPM	●	●	●
S-Type	2002. 5			DDM	●	●	●
S-Type	2002. 5			DSM	●	●	●
S-Type	2002. 5			ECM	●	●	●
S-Type	2002. 5			EPB	●	●	●
S-Type	2002. 5			FETM	●	●	●
S-Type	2002. 5			GEM	●	●	●
S-Type	2002. 5			IP	●	●	●
S-Type	2002. 5			ISM	●	●	●
S-Type	2002. 5			NAV	●	●	●
S-Type	2002. 5			PAM	●	●	●
S-Type	2002. 5			REM	●	●	●
S-Type	2002. 5			SCLM	●	●	●
S-Type	2002. 5			TCM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
S-Type	2002. 5			VACM	●	●	●
S-Type	2004	AJ61		ABS	●	●	●
S-Type	2004	AJ61		ACC	●	●	●
S-Type	2004	AJ61		ADHLS	●	●	●
S-Type	2004	AJ61		ADRC	●	●	●
S-Type	2004	AJ61		AMP	●	●	●
S-Type	2004	AJ61		ARM	●	●	●
S-Type	2004	AJ61		ATC	●	●	●
S-Type	2004	AJ61		CPM	●	●	●
S-Type	2004	AJ61		DDM	●	●	●
S-Type	2004	AJ61		DSM	●	●	●
S-Type	2004	AJ61		ECM	●	●	●
S-Type	2004	AJ61		FETM	●	●	●
S-Type	2004	AJ61		GEM	●	●	●
S-Type	2004	AJ61		IP	●	●	●
S-Type	2004	AJ61		ISM	●	●	●
S-Type	2004	AJ61		NAV	●	●	●
S-Type	2004	AJ61		PAM	●	●	●
S-Type	2004	AJ61		PBM	●	●	●
S-Type	2004	AJ61		REM	●	●	●
S-Type	2004	AJ61		SCLM	●	●	●
S-Type	2004	AJ61		TCM	●	●	●
S-Type	2004	AJ61		VACM	●	●	●
S-Type	2004	V6DIESEL		ABS	●	●	●
S-Type	2004	V6DIESEL		ACC	●	●	●
S-Type	2004	V6DIESEL		ADHLS	●	●	●
S-Type	2004	V6DIESEL		ADRC	●	●	●
S-Type	2004	V6DIESEL		AMP	●	●	●
S-Type	2004	V6DIESEL		ARM	●	●	●
S-Type	2004	V6DIESEL		ATC	●	●	●
S-Type	2004	V6DIESEL		CPM	●	●	●
S-Type	2004	V6DIESEL		DDM	●	●	●
S-Type	2004	V6DIESEL		DSM	●	●	●
S-Type	2004	V6DIESEL		FETM	●	●	●
S-Type	2004	V6DIESEL		GEM	●	●	●
S-Type	2004	V6DIESEL		IP	●	●	●
S-Type	2004	V6DIESEL		ISM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
S-Type	2004	V6DIESEL		NAV	●	●	●
S-Type	2004	V6DIESEL		PAM	●	●	●
S-Type	2004	V6DIESEL		PBM	●	●	●
S-Type	2004	V6DIESEL		REM	●	●	●
S-Type	2004	V6DIESEL		SCLM	●	●	●
S-Type	2004	V6DIESEL		TCM	●	●	●
S-Type	2004	V6DIESEL		VACM	●	●	●
S-Type	2004	V6DIESEL		AHCM	●	●	●
S-Type	2004	V6DIESEL		PCM	●	●	●
S-Type	2006	V6DIESEL		AHCM	●	●	●
S-Type	2006	V6DIESEL		ABS	●	●	●
S-Type	2006	V6DIESEL		ACC	●	●	●
S-Type	2006	V6DIESEL		ADHLS	●	●	●
S-Type	2006	V6DIESEL		ADRC	●	●	●
S-Type	2006	V6DIESEL		AMP	●	●	●
S-Type	2006	V6DIESEL		ARM	●	●	●
S-Type	2006	V6DIESEL		ATC	●	●	●
S-Type	2006	V6DIESEL		CPM	●	●	●
S-Type	2006	V6DIESEL		DDM	●	●	●
S-Type	2006	V6DIESEL		DSM	●	●	●
S-Type	2006	V6DIESEL		FETM	●	●	●
S-Type	2006	V6DIESEL		GEM	●	●	●
S-Type	2006	V6DIESEL		IP	●	●	●
S-Type	2006	V6DIESEL		ISM	●	●	●
S-Type	2006	V6DIESEL		NAV	●	●	●
S-Type	2006	V6DIESEL		PAM	●	●	●
S-Type	2006	V6DIESEL		PBM	●	●	●
S-Type	2006	V6DIESEL		PCM	●	●	●
S-Type	2006	V6DIESEL		REM	●	●	●
S-Type	2006	V6DIESEL		SCLM	●	●	●
S-Type	2006	V6DIESEL		TCM	●	●	●
S-Type	2006	V6DIESEL		TPM	●	●	●
S-Type	2006	V6DIESEL		VACM	●	●	●
S-Type	2006	V6NA		ABS	●	●	●
S-Type	2006	V6NA		ACC	●	●	●
S-Type	2006	V6NA		ADHLS	●	●	●
S-Type	2006	V6NA		ADRC	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
S-Type	2006	V6NA		AMP	●	●	●
S-Type	2006	V6NA		ARM	●	●	●
S-Type	2006	V6NA		ATC	●	●	●
S-Type	2006	V6NA		CPM	●	●	●
S-Type	2006	V6NA		DDM	●	●	●
S-Type	2006	V6NA		DSM	●	●	●
S-Type	2006	V6NA		FETM	●	●	●
S-Type	2006	V6NA		GEM	●	●	●
S-Type	2006	V6NA		IP	●	●	●
S-Type	2006	V6NA		ISM	●	●	●
S-Type	2006	V6NA		NAV	●	●	●
S-Type	2006	V6NA		PAM	●	●	●
S-Type	2006	V6NA		PBM	●	●	●
S-Type	2006	V6NA		PCM	●	●	●
S-Type	2006	V6NA		REM	●	●	●
S-Type	2006	V6NA		SCLM	●	●	●
S-Type	2006	V6NA		TCM	●	●	●
S-Type	2006	V6NA		TPM	●	●	●
S-Type	2006	V6NA		VACM	●	●	●
S-Type	2006	V8SC		ABS	●	●	●
S-Type	2006	V8SC		ACC	●	●	●
S-Type	2006	V8SC		ADHLS	●	●	●
S-Type	2006	V8SC		ADRC	●	●	●
S-Type	2006	V8SC		AMP	●	●	●
S-Type	2006	V8SC		ARM	●	●	●
S-Type	2006	V8SC		ATC	●	●	●
S-Type	2006	V8SC		CPM	●	●	●
S-Type	2006	V8SC		DDM	●	●	●
S-Type	2006	V8SC		DSM	●	●	●
S-Type	2006	V8SC		FETM	●	●	●
S-Type	2006	V8SC		GEM	●	●	●
S-Type	2006	V8SC		IP	●	●	●
S-Type	2006	V8SC		ISM	●	●	●
S-Type	2006	V8SC		NAV	●	●	●
S-Type	2006	V8SC		PAM	●	●	●
S-Type	2006	V8SC		PBM	●	●	●
S-Type	2006	V8SC		PCM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
S-Type	2006	V8SC		REM	●	●	●
S-Type	2006	V8SC		SCLM	●	●	●
S-Type	2006	V8SC		TCM	●	●	●
S-Type	2006	V8SC		TPM	●	●	●
S-Type	2006	V8SC		VACM	●	●	●
S-Type	2006	V8NA		ABS	●	●	●
S-Type	2006	V8NA		ACC	●	●	●
S-Type	2006	V8NA		ADHLS	●	●	●
S-Type	2006	V8NA		ADRC	●	●	●
S-Type	2006	V8NA		AMP	●	●	●
S-Type	2006	V8NA		ARM	●	●	●
S-Type	2006	V8NA		ATC	●	●	●
S-Type	2006	V8NA		CPM	●	●	●
S-Type	2006	V8NA		DDM	●	●	●
S-Type	2006	V8NA		DSM	●	●	●
S-Type	2006	V8NA		FETM	●	●	●
S-Type	2006	V8NA		GEM	●	●	●
S-Type	2006	V8NA		IP	●	●	●
S-Type	2006	V8NA		ISM	●	●	●
S-Type	2006	V8NA		NAV	●	●	●
S-Type	2006	V8NA		PAM	●	●	●
S-Type	2006	V8NA		PBM	●	●	●
S-Type	2006	V8NA		PCM	●	●	●
S-Type	2006	V8NA		REM	●	●	●
S-Type	2006	V8NA		SCLM	●	●	●
S-Type	2006	V8NA		TCM	●	●	●
S-Type	2006	V8NA		TPM	●	●	●
S-Type	2006	V8NA		VACM	●	●	●
Jaguar XF	2010	V6DIESEL		AAM	●	●	●
Jaguar XF	2010	V6DIESEL		ABS	●	●	●
Jaguar XF	2010	V6DIESEL		ACM	●	●	●
Jaguar XF	2010	V6DIESEL		ADCM	●	●	●
Jaguar XF	2010	V6DIESEL		APIM	●	●	●
Jaguar XF	2010	V6DIESEL		CCM	●	●	●
Jaguar XF	2010	V6DIESEL		DABM	●	●	●
Jaguar XF	2010	V6DIESEL		DACMC	●	●	●
Jaguar XF	2010	V6DIESEL		DCSM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2010	V6DIESEL		DDM	●	●	●
Jaguar XF	2010	V6DIESEL		DSM	●	●	●
Jaguar XF	2010	V6DIESEL		FCDIM	●	●	●
Jaguar XF	2010	V6DIESEL		FLR	●	●	●
Jaguar XF	2010	V6DIESEL		FSJB	●	●	●
Jaguar XF	2010	V6DIESEL		GSM	●	●	●
Jaguar XF	2010	V6DIESEL		HCM	●	●	●
Jaguar XF	2010	V6DIESEL		HVAC	●	●	●
Jaguar XF	2010	V6DIESEL		ICM	●	●	●
Jaguar XF	2010	V6DIESEL		ICP	●	●	●
Jaguar XF	2010	V6DIESEL		ICS	●	●	●
Jaguar XF	2010	V6DIESEL		IPC	●	●	●
Jaguar XF	2010	V6DIESEL		KVM	●	●	●
Jaguar XF	2010	V6DIESEL		NCM	●	●	●
Jaguar XF	2010	V6DIESEL		OCS	●	●	●
Jaguar XF	2010	V6DIESEL		PAM	●	●	●
Jaguar XF	2010	V6DIESEL		PBM	●	●	●
Jaguar XF	2010	V6DIESEL		PCM	●	●	●
Jaguar XF	2010	V6DIESEL		PDM	●	●	●
Jaguar XF	2010	V6DIESEL		RCM	●	●	●
Jaguar XF	2010	V6DIESEL		RDCM	●	●	●
Jaguar XF	2010	V6DIESEL		RSJB	●	●	●
Jaguar XF	2010	V6DIESEL		SODL	●	●	●
Jaguar XF	2010	V6DIESEL		SODR	●	●	●
Jaguar XF	2010	V6DIESEL		SRM	●	●	●
Jaguar XF	2010	V6DIESEL		TCM	●	●	●
Jaguar XF	2010	V6DIESEL		TEL	●	●	●
Jaguar XF	2010	V6DIESEL		TPM	●	●	●
Jaguar XF	2010	V6DIESEL		TVM	●	●	●
Jaguar XF	2010	V6DIESEL		VIM	●	●	●
Jaguar XF	2010	Normal aspirated V6		AAM	●	●	●
Jaguar XF	2010	Normal aspirated V6		ABS	●	●	●
Jaguar XF	2010	Normal aspirated V6		ACM	●	●	●
Jaguar XF	2010	Normal aspirated V6		ADCM	●	●	●
Jaguar XF	2010	Normal aspirated V6		APIM	●	●	●
Jaguar XF	2010	Normal aspirated V6		CCM	●	●	●
Jaguar XF	2010	Normal aspirated V6		DABM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2010	Normal aspirated V6		DACMC	●	●	●
Jaguar XF	2010	Normal aspirated V6		DCSM	●	●	●
Jaguar XF	2010	Normal aspirated V6		DDM	●	●	●
Jaguar XF	2010	Normal aspirated V6		DSM	●	●	●
Jaguar XF	2010	Normal aspirated V6		FCDIM	●	●	●
Jaguar XF	2010	Normal aspirated V6		FLR	●	●	●
Jaguar XF	2010	Normal aspirated V6		FSJB	●	●	●
Jaguar XF	2010	Normal aspirated V6		GSM	●	●	●
Jaguar XF	2010	Normal aspirated V6		HCM	●	●	●
Jaguar XF	2010	Normal aspirated V6		HVAC	●	●	●
Jaguar XF	2010	Normal aspirated V6		ICM	●	●	●
Jaguar XF	2010	Normal aspirated V6		ICP	●	●	●
Jaguar XF	2010	Normal aspirated V6		ICS	●	●	●
Jaguar XF	2010	Normal aspirated V6		IPC	●	●	●
Jaguar XF	2010	Normal aspirated V6		KVM	●	●	●
Jaguar XF	2010	Normal aspirated V6		NCM	●	●	●
Jaguar XF	2010	Normal aspirated V6		OCS	●	●	●
Jaguar XF	2010	Normal aspirated V6		PAM	●	●	●
Jaguar XF	2010	Normal aspirated V6		PBM	●	●	●
Jaguar XF	2010	Normal aspirated V6		PCM	●	●	●
Jaguar XF	2010	Normal aspirated V6		PDM	●	●	●
Jaguar XF	2010	Normal aspirated V6		RCM	●	●	●
Jaguar XF	2010	Normal aspirated V6		RDCM	●	●	●
Jaguar XF	2010	Normal aspirated V6		RSJB	●	●	●
Jaguar XF	2010	Normal aspirated V6		SODL	●	●	●
Jaguar XF	2010	Normal aspirated V6		SODR	●	●	●
Jaguar XF	2010	Normal aspirated V6		SRM	●	●	●
Jaguar XF	2010	Normal aspirated V6		TCM	●	●	●
Jaguar XF	2010	Normal aspirated V6		TEL	●	●	●
Jaguar XF	2010	Normal aspirated V6		TPM	●	●	●
Jaguar XF	2010	Normal aspirated V6		TVM	●	●	●
Jaguar XF	2010	Normal aspirated V6		VIM	●	●	●
Jaguar XF	2010	Supercharged V8		AAM	●	●	●
Jaguar XF	2010	Supercharged V8		ABS	●	●	●
Jaguar XF	2010	Supercharged V8		ACM	●	●	●
Jaguar XF	2010	Supercharged V8		ADCM	●	●	●
Jaguar XF	2010	Supercharged V8		APIM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2010	Supercharged V8		CCM	●	●	●
Jaguar XF	2010	Supercharged V8		DABM	●	●	●
Jaguar XF	2010	Supercharged V8		DACMC	●	●	●
Jaguar XF	2010	Supercharged V8		DCSM	●	●	●
Jaguar XF	2010	Supercharged V8		DDM	●	●	●
Jaguar XF	2010	Supercharged V8		DSM	●	●	●
Jaguar XF	2010	Supercharged V8		FCDIM	●	●	●
Jaguar XF	2010	Supercharged V8		FLR	●	●	●
Jaguar XF	2010	Supercharged V8		FSJB	●	●	●
Jaguar XF	2010	Supercharged V8		GSM	●	●	●
Jaguar XF	2010	Supercharged V8		HCM	●	●	●
Jaguar XF	2010	Supercharged V8		HVAC	●	●	●
Jaguar XF	2010	Supercharged V8		ICM	●	●	●
Jaguar XF	2010	Supercharged V8		ICP	●	●	●
Jaguar XF	2010	Supercharged V8		ICS	●	●	●
Jaguar XF	2010	Supercharged V8		IPC	●	●	●
Jaguar XF	2010	Supercharged V8		KVM	●	●	●
Jaguar XF	2010	Supercharged V8		NCM	●	●	●
Jaguar XF	2010	Supercharged V8		OCS	●	●	●
Jaguar XF	2010	Supercharged V8		PAM	●	●	●
Jaguar XF	2010	Supercharged V8		PBM	●	●	●
Jaguar XF	2010	Supercharged V8		PCM	●	●	●
Jaguar XF	2010	Supercharged V8		PDM	●	●	●
Jaguar XF	2010	Supercharged V8		RCM	●	●	●
Jaguar XF	2010	Supercharged V8		RDCM	●	●	●
Jaguar XF	2010	Supercharged V8		RSJB	●	●	●
Jaguar XF	2010	Supercharged V8		SODL	●	●	●
Jaguar XF	2010	Supercharged V8		SODR	●	●	●
Jaguar XF	2010	Supercharged V8		SRM	●	●	●
Jaguar XF	2010	Supercharged V8		TCM	●	●	●
Jaguar XF	2010	Supercharged V8		TEL	●	●	●
Jaguar XF	2010	Supercharged V8		TPM	●	●	●
Jaguar XF	2010	Supercharged V8		TVM	●	●	●
Jaguar XF	2010	Supercharged V8		VIM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4.2L	AAM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4.2L	ABS	●	●	●
Jaguar XF	2010	Normal aspirated V8	4.2L	ACM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2010	Normal aspirated V8	4. 2L	ADCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	APIM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	CCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	DABM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	DACMC	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	DCSM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	DDM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	DSM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	FCDIM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	FLR	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	FSJB	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	GSM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	HCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	HVAC	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	ICM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	ICP	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	ICS	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	IPC	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	KVM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	NCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	OCS	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	PAM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	PBM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	PCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	PDM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	RCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	RDCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	RSJB	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	SODL	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	SODR	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	SRM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	TCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	TEL	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	TPM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	TVM	●	●	●
Jaguar XF	2010	Normal aspirated V8	4. 2L	VIM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	AAM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2010	Normal aspirated V8	5L	ABS	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	ACM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	ADCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	APIM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	CCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	DABM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	DACMC	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	DCSM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	DDM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	DSM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	FCDIM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	FLR	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	FSJB	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	GSM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	HCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	HVAC	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	ICM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	ICP	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	ICS	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	IPC	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	KVM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	NCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	OCS	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	PAM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	PBM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	PCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	PDM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	RCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	RDCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	RSJB	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	SODL	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	SODR	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	SRM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	TCM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	TEL	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	TPM	●	●	●
Jaguar XF	2010	Normal aspirated V8	5L	TVM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2010	Normal aspirated V8	5L	VIM	●	●	●
Jaguar XF	2012	V8NA		ABS	●	●	●
Jaguar XF	2012	V8NA		CCM	●	●	●
Jaguar XF	2012	V8NA		GSM	●	●	●
Jaguar XF	2012	V8NA		GWM	●	●	●
Jaguar XF	2012	V8NA		HCM	●	●	●
Jaguar XF	2012	V8NA		IPC	●	●	●
Jaguar XF	2012	V8NA		OCS	●	●	●
Jaguar XF	2012	V8NA		PBM	●	●	●
Jaguar XF	2012	V8NA		PCM	●	●	●
Jaguar XF	2012	V8NA		RCM	●	●	●
Jaguar XF	2012	V8NA		RDCM	●	●	●
Jaguar XF	2012	V8NA		SPMA	●	●	●
Jaguar XF	2012	V8NA		SPMB	●	●	●
Jaguar XF	2012	V8NA		SUMB	●	●	●
Jaguar XF	2012	V8NA		TCM	●	●	●
Jaguar XF	2012	V8NA		VIM	●	●	●
Jaguar XF	2012	V8NA		FSJB	●	●	●
Jaguar XF	2012	V8NA		RSJB	●	●	●
Jaguar XF	2012	V8NA		DDM	●	●	●
Jaguar XF	2012	V8NA		DSM	●	●	●
Jaguar XF	2012	V8NA		FCDIM	●	●	●
Jaguar XF	2012	V8NA		FCIMB	●	●	●
Jaguar XF	2012	V8NA		HVMB	●	●	●
Jaguar XF	2012	V8NA		HVAC	●	●	●
Jaguar XF	2012	V8NA		PAM	●	●	●
Jaguar XF	2012	V8NA		PDM	●	●	●
Jaguar XF	2012	V8NA		PSM	●	●	●
Jaguar XF	2012	V8NA		SCME	●	●	●
Jaguar XF	2012	V8NA		SODL	●	●	●
Jaguar XF	2012	V8NA		SODR	●	●	●
Jaguar XF	2012	V8NA		TPM	●	●	●
Jaguar XF	2012	V8NA		AAM	●	●	●
Jaguar XF	2012	V8NA		DABM	●	●	●
Jaguar XF	2012	V8NA		SRM	●	●	●
Jaguar XF	2012	V8NA		TVM	●	●	●
Jaguar XF	2012	V8NA		TEL	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2012	V8NA		TPM	●	●	●
Jaguar XF	2012	V8NA		TVM	●	●	●
Jaguar XF	2012	V8SC		ABS	●	●	●
Jaguar XF	2012	V8SC		CCM	●	●	●
Jaguar XF	2012	V8SC		GSM	●	●	●
Jaguar XF	2012	V8SC		GWM	●	●	●
Jaguar XF	2012	V8SC		HCM	●	●	●
Jaguar XF	2012	V8SC		IPC	●	●	●
Jaguar XF	2012	V8SC		OCS	●	●	●
Jaguar XF	2012	V8SC		PBM	●	●	●
Jaguar XF	2012	V8SC		PCM	●	●	●
Jaguar XF	2012	V8SC		RCM	●	●	●
Jaguar XF	2012	V8SC		RDCM	●	●	●
Jaguar XF	2012	V8SC		SPMA	●	●	●
Jaguar XF	2012	V8SC		SPMB	●	●	●
Jaguar XF	2012	V8SC		SUMB	●	●	●
Jaguar XF	2012	V8SC		TCM	●	●	●
Jaguar XF	2012	V8SC		VIM	●	●	●
Jaguar XF	2012	V8SC		FSJB	●	●	●
Jaguar XF	2012	V8SC		RSJB	●	●	●
Jaguar XF	2012	V8SC		DDM	●	●	●
Jaguar XF	2012	V8SC		DSM	●	●	●
Jaguar XF	2012	V8SC		FCDIM	●	●	●
Jaguar XF	2012	V8SC		FCIMB	●	●	●
Jaguar XF	2012	V8SC		HVMB	●	●	●
Jaguar XF	2012	V8SC		HVAC	●	●	●
Jaguar XF	2012	V8SC		PAM	●	●	●
Jaguar XF	2012	V8SC		PDM	●	●	●
Jaguar XF	2012	V8SC		PSM	●	●	●
Jaguar XF	2012	V8SC		SCME	●	●	●
Jaguar XF	2012	V8SC		SODL	●	●	●
Jaguar XF	2012	V8SC		SODR	●	●	●
Jaguar XF	2012	V8SC		TPM	●	●	●
Jaguar XF	2012	V8SC		AAM	●	●	●
Jaguar XF	2012	V8SC		DABM	●	●	●
Jaguar XF	2012	V8SC		SRM	●	●	●
Jaguar XF	2012	V8SC		TVM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2012	V8SC		TEL	●	●	●
Jaguar XF	2012	V8SC		TPM	●	●	●
Jaguar XF	2012	V8SC		TVM	●	●	●
Jaguar XF	2012	V6NA		ABS	●	●	●
Jaguar XF	2012	V6NA		CCM	●	●	●
Jaguar XF	2012	V6NA		GSM	●	●	●
Jaguar XF	2012	V6NA		GWM	●	●	●
Jaguar XF	2012	V6NA		HCM	●	●	●
Jaguar XF	2012	V6NA		IPC	●	●	●
Jaguar XF	2012	V6NA		OCS	●	●	●
Jaguar XF	2012	V6NA		PBM	●	●	●
Jaguar XF	2012	V6NA		PCM	●	●	●
Jaguar XF	2012	V6NA		RCM	●	●	●
Jaguar XF	2012	V6NA		RDCM	●	●	●
Jaguar XF	2012	V6NA		SPMA	●	●	●
Jaguar XF	2012	V6NA		SPMB	●	●	●
Jaguar XF	2012	V6NA		SUMB	●	●	●
Jaguar XF	2012	V6NA		TCM	●	●	●
Jaguar XF	2012	V6NA		VIM	●	●	●
Jaguar XF	2012	V6NA		FSJB	●	●	●
Jaguar XF	2012	V6NA		RSJB	●	●	●
Jaguar XF	2012	V6NA		DDM	●	●	●
Jaguar XF	2012	V6NA		DSM	●	●	●
Jaguar XF	2012	V6NA		FCDIM	●	●	●
Jaguar XF	2012	V6NA		FCIMB	●	●	●
Jaguar XF	2012	V6NA		HVMB	●	●	●
Jaguar XF	2012	V6NA		HVAC	●	●	●
Jaguar XF	2012	V6NA		PAM	●	●	●
Jaguar XF	2012	V6NA		PDM	●	●	●
Jaguar XF	2012	V6NA		PSM	●	●	●
Jaguar XF	2012	V6NA		SCME	●	●	●
Jaguar XF	2012	V6NA		SODL	●	●	●
Jaguar XF	2012	V6NA		SODR	●	●	●
Jaguar XF	2012	V6NA		TPM	●	●	●
Jaguar XF	2012	V6NA		AAM	●	●	●
Jaguar XF	2012	V6NA		DABM	●	●	●
Jaguar XF	2012	V6NA		SRM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2012	V6NA		TVM	●	●	●
Jaguar XF	2012	V6NA		TEL	●	●	●
Jaguar XF	2012	V6NA		TPM	●	●	●
Jaguar XF	2012	V6NA		TVM	●	●	●
Jaguar XF	2012	V6DIESEL		ABS	●	●	●
Jaguar XF	2012	V6DIESEL		CCM	●	●	●
Jaguar XF	2012	V6DIESEL		GSM	●	●	●
Jaguar XF	2012	V6DIESEL		GWM	●	●	●
Jaguar XF	2012	V6DIESEL		HCM	●	●	●
Jaguar XF	2012	V6DIESEL		IPC	●	●	●
Jaguar XF	2012	V6DIESEL		OCS	●	●	●
Jaguar XF	2012	V6DIESEL		PBM	●	●	●
Jaguar XF	2012	V6DIESEL		PCM	●	●	●
Jaguar XF	2012	V6DIESEL		RCM	●	●	●
Jaguar XF	2012	V6DIESEL		RDCM	●	●	●
Jaguar XF	2012	V6DIESEL		SPMA	●	●	●
Jaguar XF	2012	V6DIESEL		SPMB	●	●	●
Jaguar XF	2012	V6DIESEL		SUMB	●	●	●
Jaguar XF	2012	V6DIESEL		TCM	●	●	●
Jaguar XF	2012	V6DIESEL		VIM	●	●	●
Jaguar XF	2012	V6DIESEL		FSJB	●	●	●
Jaguar XF	2012	V6DIESEL		RSJB	●	●	●
Jaguar XF	2012	V6DIESEL		DDM	●	●	●
Jaguar XF	2012	V6DIESEL		DSM	●	●	●
Jaguar XF	2012	V6DIESEL		FCDIM	●	●	●
Jaguar XF	2012	V6DIESEL		FCIMB	●	●	●
Jaguar XF	2012	V6DIESEL		HVMB	●	●	●
Jaguar XF	2012	V6DIESEL		HVAC	●	●	●
Jaguar XF	2012	V6DIESEL		PAM	●	●	●
Jaguar XF	2012	V6DIESEL		PDM	●	●	●
Jaguar XF	2012	V6DIESEL		PSM	●	●	●
Jaguar XF	2012	V6DIESEL		SCME	●	●	●
Jaguar XF	2012	V6DIESEL		SODL	●	●	●
Jaguar XF	2012	V6DIESEL		SODR	●	●	●
Jaguar XF	2012	V6DIESEL		TPM	●	●	●
Jaguar XF	2012	V6DIESEL		AAM	●	●	●
Jaguar XF	2012	V6DIESEL		DABM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2012	V6DIESEL		SRM	●	●	●
Jaguar XF	2012	V6DIESEL		TVM	●	●	●
Jaguar XF	2012	V6DIESEL		TEL	●	●	●
Jaguar XF	2012	V6DIESEL		TPM	●	●	●
Jaguar XF	2012	V6DIESEL		TVM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	ABS	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	CCM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	GSM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	GWM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	HCM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	IPC	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	OCS	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	PBM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	PCM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	RCM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	RDCM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	SPMA	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	SPMB	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	SUMB	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	TCM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	VIM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	FSJB	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	RSJB	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	DDM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	DSM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	FCDIM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	FCIMB	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	HVMB	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	HVAC	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	PAM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	PDM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	PSM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	SCME	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	SODL	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	SODR	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	TPM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	AAM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2012	I4DIESEL	2. 2L	DABM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	SRM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	TVM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	TEL	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	TPM	●	●	●
Jaguar XF	2012	I4DIESEL	2. 2L	TVM	●	●	●
Jaguar XF	2013	V8SC		ABS	●	●	●
Jaguar XF	2013	V8SC		CCM	●	●	●
Jaguar XF	2013	V8SC		CHCM	●	●	●
Jaguar XF	2013	V8SC		GSM	●	●	●
Jaguar XF	2013	V8SC		GWM	●	●	●
Jaguar XF	2013	V8SC		HCM	●	●	●
Jaguar XF	2013	V8SC		IPC	●	●	●
Jaguar XF	2013	V8SC		OCS	●	●	●
Jaguar XF	2013	V8SC		PBM	●	●	●
Jaguar XF	2013	V8SC		RCM	●	●	●
Jaguar XF	2013	V8SC		RDCM	●	●	●
Jaguar XF	2013	V8SC		SPMA	●	●	●
Jaguar XF	2013	V8SC		SPMB	●	●	●
Jaguar XF	2013	V8SC		SUMB	●	●	●
Jaguar XF	2013	V8SC		TCM	●	●	●
Jaguar XF	2013	V8SC		VIM	●	●	●
Jaguar XF	2013	V8SC		FSJB	●	●	●
Jaguar XF	2013	V8SC		RSJB	●	●	●
Jaguar XF	2013	V8SC		CAV	●	●	●
Jaguar XF	2013	V8SC		DDM	●	●	●
Jaguar XF	2013	V8SC		DSM	●	●	●
Jaguar XF	2013	V8SC		FCDIM	●	●	●
Jaguar XF	2013	V8SC		FCIMB	●	●	●
Jaguar XF	2013	V8SC		HCMB	●	●	●
Jaguar XF	2013	V8SC		HVAC	●	●	●
Jaguar XF	2013	V8SC		PAM	●	●	●
Jaguar XF	2013	V8SC		PDM	●	●	●
Jaguar XF	2013	V8SC		PSM	●	●	●
Jaguar XF	2013	V8SC		RFA	●	●	●
Jaguar XF	2013	V8SC		RGTM	●	●	●
Jaguar XF	2013	V8SC		SCME	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2013	V8SC		SODL	●	●	●
Jaguar XF	2013	V8SC		SODR	●	●	●
Jaguar XF	2013	V8SC		TPM	●	●	●
Jaguar XF	2013	V8SC		AAM	●	●	●
Jaguar XF	2013	V8SC		ACM	●	●	●
Jaguar XF	2013	V8SC		DABM	●	●	●
Jaguar XF	2013	V8SC		NCM	●	●	●
Jaguar XF	2013	V8SC		SRM	●	●	●
Jaguar XF	2013	V8SC		TVM	●	●	●
Jaguar XF	2013	V6SC		ABS	●	●	●
Jaguar XF	2013	V6SC		CCM	●	●	●
Jaguar XF	2013	V6SC		CHCM	●	●	●
Jaguar XF	2013	V6SC		GSM	●	●	●
Jaguar XF	2013	V6SC		GWM	●	●	●
Jaguar XF	2013	V6SC		HCM	●	●	●
Jaguar XF	2013	V6SC		IPC	●	●	●
Jaguar XF	2013	V6SC		OCS	●	●	●
Jaguar XF	2013	V6SC		PBM	●	●	●
Jaguar XF	2013	V6SC		RCM	●	●	●
Jaguar XF	2013	V6SC		RDCM	●	●	●
Jaguar XF	2013	V6SC		SPMA	●	●	●
Jaguar XF	2013	V6SC		SPMB	●	●	●
Jaguar XF	2013	V6SC		SUMB	●	●	●
Jaguar XF	2013	V6SC		TCM	●	●	●
Jaguar XF	2013	V6SC		VIM	●	●	●
Jaguar XF	2013	V6SC		FSJB	●	●	●
Jaguar XF	2013	V6SC		RSJB	●	●	●
Jaguar XF	2013	V6SC		CAV	●	●	●
Jaguar XF	2013	V6SC		DDM	●	●	●
Jaguar XF	2013	V6SC		DSM	●	●	●
Jaguar XF	2013	V6SC		FCDIM	●	●	●
Jaguar XF	2013	V6SC		FCIMB	●	●	●
Jaguar XF	2013	V6SC		HCMB	●	●	●
Jaguar XF	2013	V6SC		HVAC	●	●	●
Jaguar XF	2013	V6SC		PAM	●	●	●
Jaguar XF	2013	V6SC		PDM	●	●	●
Jaguar XF	2013	V6SC		PSM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2013	V6SC		RFA	●	●	●
Jaguar XF	2013	V6SC		RGTM	●	●	●
Jaguar XF	2013	V6SC		SCME	●	●	●
Jaguar XF	2013	V6SC		SODL	●	●	●
Jaguar XF	2013	V6SC		SODR	●	●	●
Jaguar XF	2013	V6SC		TPM	●	●	●
Jaguar XF	2013	V6SC		AAM	●	●	●
Jaguar XF	2013	V6SC		ACM	●	●	●
Jaguar XF	2013	V6SC		DABM	●	●	●
Jaguar XF	2013	V6SC		NCM	●	●	●
Jaguar XF	2013	V6SC		SRM	●	●	●
Jaguar XF	2013	V6SC		TVM	●	●	●
Jaguar XF	2013	V6DIESEL		ABS	●	●	●
Jaguar XF	2013	V6DIESEL		CCM	●	●	●
Jaguar XF	2013	V6DIESEL		CHCM	●	●	●
Jaguar XF	2013	V6DIESEL		GSM	●	●	●
Jaguar XF	2013	V6DIESEL		GWM	●	●	●
Jaguar XF	2013	V6DIESEL		HCM	●	●	●
Jaguar XF	2013	V6DIESEL		IPC	●	●	●
Jaguar XF	2013	V6DIESEL		OCS	●	●	●
Jaguar XF	2013	V6DIESEL		PBM	●	●	●
Jaguar XF	2013	V6DIESEL		RCM	●	●	●
Jaguar XF	2013	V6DIESEL		RDCM	●	●	●
Jaguar XF	2013	V6DIESEL		SPMA	●	●	●
Jaguar XF	2013	V6DIESEL		SPMB	●	●	●
Jaguar XF	2013	V6DIESEL		SUMB	●	●	●
Jaguar XF	2013	V6DIESEL		TCM	●	●	●
Jaguar XF	2013	V6DIESEL		VIM	●	●	●
Jaguar XF	2013	V6DIESEL		FSJB	●	●	●
Jaguar XF	2013	V6DIESEL		RSJB	●	●	●
Jaguar XF	2013	V6DIESEL		CAV	●	●	●
Jaguar XF	2013	V6DIESEL		DDM	●	●	●
Jaguar XF	2013	V6DIESEL		DSM	●	●	●
Jaguar XF	2013	V6DIESEL		FCDIM	●	●	●
Jaguar XF	2013	V6DIESEL		FCIMB	●	●	●
Jaguar XF	2013	V6DIESEL		HCMB	●	●	●
Jaguar XF	2013	V6DIESEL		HVAC	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2013	V6DIESEL		PAM	●	●	●
Jaguar XF	2013	V6DIESEL		PDM	●	●	●
Jaguar XF	2013	V6DIESEL		PSM	●	●	●
Jaguar XF	2013	V6DIESEL		RFA	●	●	●
Jaguar XF	2013	V6DIESEL		RGTM	●	●	●
Jaguar XF	2013	V6DIESEL		SCME	●	●	●
Jaguar XF	2013	V6DIESEL		SODL	●	●	●
Jaguar XF	2013	V6DIESEL		SODR	●	●	●
Jaguar XF	2013	V6DIESEL		TPM	●	●	●
Jaguar XF	2013	V6DIESEL		AAM	●	●	●
Jaguar XF	2013	V6DIESEL		ACM	●	●	●
Jaguar XF	2013	V6DIESEL		DABM	●	●	●
Jaguar XF	2013	V6DIESEL		NCM	●	●	●
Jaguar XF	2013	V6DIESEL		SRM	●	●	●
Jaguar XF	2013	V6DIESEL		TVM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	ABS	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	CCM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	CHCM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	GSM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	GWM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	HCM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	IPC	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	OCS	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	PBM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	RCM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	RDCM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	SPMA	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	SPMB	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	SUMB	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	TCM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	VIM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	FSJB	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	RSJB	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	CAV	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	DDM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	DSM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	FCDIM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2013	I4DIESEL	2. 2L	FCIMB	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	HCMB	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	HVAC	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	PAM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	PDM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	PSM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	RFA	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	RGTM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	SCME	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	SODL	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	SODR	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	TPM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	AAM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	ACM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	DABM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	NCM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	SRM	●	●	●
Jaguar XF	2013	I4DIESEL	2. 2L	TVM	●	●	●
Jaguar XF	2013	GTDI	2. 0L	ABS	●	●	●
Jaguar XF	2013	GTDI	2. 0L	CCM	●	●	●
Jaguar XF	2013	GTDI	2. 0L	CHCM	●	●	●
Jaguar XF	2013	GTDI	2. 0L	GSM	●	●	●
Jaguar XF	2013	GTDI	2. 0L	GWM	●	●	●
Jaguar XF	2013	GTDI	2. 0L	HCM	●	●	●
Jaguar XF	2013	GTDI	2. 0L	IPC	●	●	●
Jaguar XF	2013	GTDI	2. 0L	OCS	●	●	●
Jaguar XF	2013	GTDI	2. 0L	PBM	●	●	●
Jaguar XF	2013	GTDI	2. 0L	RCM	●	●	●
Jaguar XF	2013	GTDI	2. 0L	RDCM	●	●	●
Jaguar XF	2013	GTDI	2. 0L	SPMA	●	●	●
Jaguar XF	2013	GTDI	2. 0L	SPMB	●	●	●
Jaguar XF	2013	GTDI	2. 0L	SUMB	●	●	●
Jaguar XF	2013	GTDI	2. 0L	TCM	●	●	●
Jaguar XF	2013	GTDI	2. 0L	VIM	●	●	●
Jaguar XF	2013	GTDI	2. 0L	FSJB	●	●	●
Jaguar XF	2013	GTDI	2. 0L	RSJB	●	●	●
Jaguar XF	2013	GTDI	2. 0L	CAV	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
Jaguar XF	2013	GTDI	2.0L	DDM	●	●	●
Jaguar XF	2013	GTDI	2.0L	DSM	●	●	●
Jaguar XF	2013	GTDI	2.0L	FCDIM	●	●	●
Jaguar XF	2013	GTDI	2.0L	FCIMB	●	●	●
Jaguar XF	2013	GTDI	2.0L	HCMB	●	●	●
Jaguar XF	2013	GTDI	2.0L	HVAC	●	●	●
Jaguar XF	2013	GTDI	2.0L	PAM	●	●	●
Jaguar XF	2013	GTDI	2.0L	PDM	●	●	●
Jaguar XF	2013	GTDI	2.0L	PSM	●	●	●
Jaguar XF	2013	GTDI	2.0L	RFA	●	●	●
Jaguar XF	2013	GTDI	2.0L	RGTM	●	●	●
Jaguar XF	2013	GTDI	2.0L	SCME	●	●	●
Jaguar XF	2013	GTDI	2.0L	SODL	●	●	●
Jaguar XF	2013	GTDI	2.0L	SODR	●	●	●
Jaguar XF	2013	GTDI	2.0L	TPM	●	●	●
Jaguar XF	2013	GTDI	2.0L	AAM	●	●	●
Jaguar XF	2013	GTDI	2.0L	ACM	●	●	●
Jaguar XF	2013	GTDI	2.0L	DABM	●	●	●
Jaguar XF	2013	GTDI	2.0L	NCM	●	●	●
Jaguar XF	2013	GTDI	2.0L	SRM	●	●	●
Jaguar XF	2013	GTDI	2.0L	TVM	●	●	●
XJ8	1998			ABS	●	●	●
XJ8	1998			ECM	●	●	●
XJ8	1998			IPK	●	●	●
XJ8	1998			TCM	●	●	●
XJ8	1998			DSM	●	●	●
XJ8	1998			PSM	●	●	●
XJ8	1998			SLM	●	●	●
XJ8	1998			PRDM	●	●	●
XJ8	1998			PDM	●	●	●
XJ8	1998			DRDM	●	●	●
XJ8	1998			DDM	●	●	●
XJ8	1998			BPM	●	●	●
XJ8	1998			ACM	●	●	●
XJ8	1998			CCM	●	●	●
XJ8	1998			ADS	●	●	●
XJ8	1998			KTM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJ8	1998_25			ABS	●	●	●
XJ8	1998_25			ECM	●	●	●
XJ8	1998_25			IPK	●	●	●
XJ8	1998_25			TCM	●	●	●
XJ8	1998_25			DSM	●	●	●
XJ8	1998_25			PSM	●	●	●
XJ8	1998_25			SLM	●	●	●
XJ8	1998_25			PRDM	●	●	●
XJ8	1998_25			PDM	●	●	●
XJ8	1998_25			DRDM	●	●	●
XJ8	1998_25			DDM	●	●	●
XJ8	1998_25			BPM	●	●	●
XJ8	1998_25			ACM	●	●	●
XJ8	1998_25			CCM	●	●	●
XJ8	1998_25			ADS	●	●	●
XJ8	1998_25			KTM	●	●	●
XJ8	2001			ABS	●	●	●
XJ8	2001			ECM	●	●	●
XJ8	2001			IPK	●	●	●
XJ8	2001			TCM	●	●	●
XJ8	2001			DSM	●	●	●
XJ8	2001			PSM	●	●	●
XJ8	2001			SLM	●	●	●
XJ8	2001			PRDM	●	●	●
XJ8	2001			PDM	●	●	●
XJ8	2001			DRDM	●	●	●
XJ8	2001			DDM	●	●	●
XJ8	2001			BPM	●	●	●
XJ8	2001			ACM	●	●	●
XJ8	2001			CCM	●	●	●
XJ8	2001			ADS	●	●	●
XJ8	2001			KTM	●	●	●
XJ8	1996			BPM	●	●	●
XJ8	1996			IPK	●	●	●
XJ8	1996			SEC	●	●	●
XJ8	1996			CCM	●	●	●
XJ8	1996			DSM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJ8	1996			CMM	●	●	●
XJ8	1996			TCM	●	●	●
XJ8	1996			ECM	●	●	●
XJ8	1996			PSM	●	●	●
XJ8	1996			ABS	●	●	●
XJ range	2002.5			ABS	●	●	●
XJ range	2002.5			ACC	●	●	●
XJ range	2002.5			ADHLS_L	●	●	●
XJ range	2002.5			ADHLS_R	●	●	●
XJ range	2002.5			AMP	●	●	●
XJ range	2002.5			ARM	●	●	●
XJ range	2002.5			ASU	●	●	●
XJ range	2002.5			ATC	●	●	●
XJ range	2002.5			CPM	●	●	●
XJ range	2002.5			DDM	●	●	●
XJ range	2002.5			DSM	●	●	●
XJ range	2002.5			ECM	●	●	●
XJ range	2002.5			EPB	●	●	●
XJ range	2002.5			FETM	●	●	●
XJ range	2002.5			GEM	●	●	●
XJ range	2002.5			IP	●	●	●
XJ range	2002.5			ISM	●	●	●
XJ range	2002.5			NAV	●	●	●
XJ range	2002.5			PAM	●	●	●
XJ range	2002.5			RATC	●	●	●
XJ range	2002.5			REM	●	●	●
XJ range	2002.5			RETM	●	●	●
XJ range	2002.5			RSM	●	●	●
XJ range	2002.5			SCLM	●	●	●
XJ range	2002.5			TCM	●	●	●
XJ range	2002.5			VACM	●	●	●
XJ range	2010	V6DIESEL		AAM	●	●	●
XJ range	2010	V6DIESEL		ABS	●	●	●
XJ range	2010	V6DIESEL		ACM	●	●	●
XJ range	2010	V6DIESEL		ADCM	●	●	●
XJ range	2010	V6DIESEL		BCM	●	●	●
XJ range	2010	V6DIESEL		CCM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJ range	2010	V6DIESEL		CHCM	●	●	●
XJ range	2010	V6DIESEL		DABM	●	●	●
XJ range	2010	V6DIESEL		DCSM	●	●	●
XJ range	2010	V6DIESEL		DDM	●	●	●
XJ range	2010	V6DIESEL		DSM	●	●	●
XJ range	2010	V6DIESEL		FCDIM	●	●	●
XJ range	2010	V6DIESEL		FCIMB	●	●	●
XJ range	2010	V6DIESEL		GSM	●	●	●
XJ range	2010	V6DIESEL		HCMB	●	●	●
XJ range	2010	V6DIESEL		HCM	●	●	●
XJ range	2010	V6DIESEL		HVAC	●	●	●
XJ range	2010	V6DIESEL		IPC	●	●	●
XJ range	2010	V6DIESEL		KVM	●	●	●
XJ range	2010	V6DIESEL		OCS	●	●	●
XJ range	2010	V6DIESEL		PAM	●	●	●
XJ range	2010	V6DIESEL		PBM	●	●	●
XJ range	2010	V6DIESEL		PCM	●	●	●
XJ range	2010	V6DIESEL		PDM	●	●	●
XJ range	2010	V6DIESEL		PSM	●	●	●
XJ range	2010	V6DIESEL		RCM	●	●	●
XJ range	2010	V6DIESEL		RDCM	●	●	●
XJ range	2010	V6DIESEL		RDCSM	●	●	●
XJ range	2010	V6DIESEL		REM	●	●	●
XJ range	2010	V6DIESEL		RGTM	●	●	●
XJ range	2010	V6DIESEL		RHVAC	●	●	●
XJ range	2010	V6DIESEL		RLM	●	●	●
XJ range	2010	V6DIESEL		SODL	●	●	●
XJ range	2010	V6DIESEL		SODR	●	●	●
XJ range	2010	V6DIESEL		SPMA	●	●	●
XJ range	2010	V6DIESEL		SPMB	●	●	●
XJ range	2010	V6DIESEL		SRM	●	●	●
XJ range	2010	V6DIESEL		TCM	●	●	●
XJ range	2010	V6DIESEL		TVM	●	●	●
XJ range	2010	V6DIESEL		VIM	●	●	●
XJ range	2010	V8NA		AAM	●	●	●
XJ range	2010	V8NA		ABS	●	●	●
XJ range	2010	V8NA		ACM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJ range	2010	V8NA		ADCM	●	●	●
XJ range	2010	V8NA		BCM	●	●	●
XJ range	2010	V8NA		CCM	●	●	●
XJ range	2010	V8NA		CHCM	●	●	●
XJ range	2010	V8NA		DABM	●	●	●
XJ range	2010	V8NA		DCSM	●	●	●
XJ range	2010	V8NA		DDM	●	●	●
XJ range	2010	V8NA		DSM	●	●	●
XJ range	2010	V8NA		FCDIM	●	●	●
XJ range	2010	V8NA		FCIMB	●	●	●
XJ range	2010	V8NA		GSM	●	●	●
XJ range	2010	V8NA		HCMB	●	●	●
XJ range	2010	V8NA		HCM	●	●	●
XJ range	2010	V8NA		HVAC	●	●	●
XJ range	2010	V8NA		IPC	●	●	●
XJ range	2010	V8NA		KVM	●	●	●
XJ range	2010	V8NA		OCS	●	●	●
XJ range	2010	V8NA		PAM	●	●	●
XJ range	2010	V8NA		PBM	●	●	●
XJ range	2010	V8NA		PCM	●	●	●
XJ range	2010	V8NA		PDM	●	●	●
XJ range	2010	V8NA		PSM	●	●	●
XJ range	2010	V8NA		RCM	●	●	●
XJ range	2010	V8NA		RDCM	●	●	●
XJ range	2010	V8NA		RDCSM	●	●	●
XJ range	2010	V8NA		REM	●	●	●
XJ range	2010	V8NA		RGTM	●	●	●
XJ range	2010	V8NA		RHVAC	●	●	●
XJ range	2010	V8NA		RLM	●	●	●
XJ range	2010	V8NA		SODL	●	●	●
XJ range	2010	V8NA		SODR	●	●	●
XJ range	2010	V8NA		SPMA	●	●	●
XJ range	2010	V8NA		SPMB	●	●	●
XJ range	2010	V8NA		SRM	●	●	●
XJ range	2010	V8NA		TCM	●	●	●
XJ range	2010	V8NA		TVM	●	●	●
XJ range	2010	V8NA		VIM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJ range	2010	V8SC		AAM	●	●	●
XJ range	2010	V8SC		ABS	●	●	●
XJ range	2010	V8SC		ACM	●	●	●
XJ range	2010	V8SC		ADCM	●	●	●
XJ range	2010	V8SC		BCM	●	●	●
XJ range	2010	V8SC		CCM	●	●	●
XJ range	2010	V8SC		CHCM	●	●	●
XJ range	2010	V8SC		DABM	●	●	●
XJ range	2010	V8SC		DCSM	●	●	●
XJ range	2010	V8SC		DDM	●	●	●
XJ range	2010	V8SC		DSM	●	●	●
XJ range	2010	V8SC		FCDIM	●	●	●
XJ range	2010	V8SC		FCIMB	●	●	●
XJ range	2010	V8SC		GSM	●	●	●
XJ range	2010	V8SC		HCMB	●	●	●
XJ range	2010	V8SC		HCM	●	●	●
XJ range	2010	V8SC		HVAC	●	●	●
XJ range	2010	V8SC		IPC	●	●	●
XJ range	2010	V8SC		KVM	●	●	●
XJ range	2010	V8SC		OCS	●	●	●
XJ range	2010	V8SC		PAM	●	●	●
XJ range	2010	V8SC		PBM	●	●	●
XJ range	2010	V8SC		PCM	●	●	●
XJ range	2010	V8SC		PDM	●	●	●
XJ range	2010	V8SC		PSM	●	●	●
XJ range	2010	V8SC		RCM	●	●	●
XJ range	2010	V8SC		RDCM	●	●	●
XJ range	2010	V8SC		RDCSM	●	●	●
XJ range	2010	V8SC		REM	●	●	●
XJ range	2010	V8SC		RGTM	●	●	●
XJ range	2010	V8SC		RHVAC	●	●	●
XJ range	2010	V8SC		RLM	●	●	●
XJ range	2010	V8SC		SODL	●	●	●
XJ range	2010	V8SC		SODR	●	●	●
XJ range	2010	V8SC		SPMA	●	●	●
XJ range	2010	V8SC		SPMB	●	●	●
XJ range	2010	V8SC		SRM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJ range	2010	V8SC		TCM	●	●	●
XJ range	2010	V8SC		TVM	●	●	●
XJ range	2010	V8SC		VIM	●	●	●
XJ range	2006	V6DIESEL		AHCM	●	●	●
XJ range	2006	V6DIESEL		ABS	●	●	●
XJ range	2006	V6DIESEL		ACC	●	●	●
XJ range	2006	V6DIESEL		AMP	●	●	●
XJ range	2006	V6DIESEL		ARM	●	●	●
XJ range	2006	V6DIESEL		ASU	●	●	●
XJ range	2006	V6DIESEL		ATC	●	●	●
XJ range	2006	V6DIESEL		CPM	●	●	●
XJ range	2006	V6DIESEL		DDM	●	●	●
XJ range	2006	V6DIESEL		DSM	●	●	●
XJ range	2006	V6DIESEL		FETM	●	●	●
XJ range	2006	V6DIESEL		GEM	●	●	●
XJ range	2006	V6DIESEL		IP	●	●	●
XJ range	2006	V6DIESEL		ISM	●	●	●
XJ range	2006	V6DIESEL		NAV	●	●	●
XJ range	2006	V6DIESEL		PAM	●	●	●
XJ range	2006	V6DIESEL		PBM	●	●	●
XJ range	2006	V6DIESEL		PCM	●	●	●
XJ range	2006	V6DIESEL		RATC	●	●	●
XJ range	2006	V6DIESEL		REM	●	●	●
XJ range	2006	V6DIESEL		RETM	●	●	●
XJ range	2006	V6DIESEL		RSM	●	●	●
XJ range	2006	V6DIESEL		SCLM	●	●	●
XJ range	2006	V6DIESEL		TCM	●	●	●
XJ range	2006	V6DIESEL		TPM	●	●	●
XJ range	2006	V6DIESEL		VACM	●	●	●
XJ range	2006	V6NA		ABS	●	●	●
XJ range	2006	V6NA		ACC	●	●	●
XJ range	2006	V6NA		AMP	●	●	●
XJ range	2006	V6NA		ARM	●	●	●
XJ range	2006	V6NA		ASU	●	●	●
XJ range	2006	V6NA		ATC	●	●	●
XJ range	2006	V6NA		CPM	●	●	●
XJ range	2006	V6NA		DDM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJ range	2006	V6NA		DSM	●	●	●
XJ range	2006	V6NA		FETM	●	●	●
XJ range	2006	V6NA		GEM	●	●	●
XJ range	2006	V6NA		IP	●	●	●
XJ range	2006	V6NA		ISM	●	●	●
XJ range	2006	V6NA		NAV	●	●	●
XJ range	2006	V6NA		PAM	●	●	●
XJ range	2006	V6NA		PBM	●	●	●
XJ range	2006	V6NA		PCM	●	●	●
XJ range	2006	V6NA		RATC	●	●	●
XJ range	2006	V6NA		REM	●	●	●
XJ range	2006	V6NA		RETM	●	●	●
XJ range	2006	V6NA		RSM	●	●	●
XJ range	2006	V6NA		SCLM	●	●	●
XJ range	2006	V6NA		TCM	●	●	●
XJ range	2006	V6NA		TPM	●	●	●
XJ range	2006	V6NA		VACM	●	●	●
XJ range	2006	V8NA		ABS	●	●	●
XJ range	2006	V8NA		ACC	●	●	●
XJ range	2006	V8NA		AMP	●	●	●
XJ range	2006	V8NA		ARM	●	●	●
XJ range	2006	V8NA		ASU	●	●	●
XJ range	2006	V8NA		ATC	●	●	●
XJ range	2006	V8NA		CPM	●	●	●
XJ range	2006	V8NA		DDM	●	●	●
XJ range	2006	V8NA		DSM	●	●	●
XJ range	2006	V8NA		FETM	●	●	●
XJ range	2006	V8NA		GEM	●	●	●
XJ range	2006	V8NA		IP	●	●	●
XJ range	2006	V8NA		ISM	●	●	●
XJ range	2006	V8NA		NAV	●	●	●
XJ range	2006	V8NA		PAM	●	●	●
XJ range	2006	V8NA		PBM	●	●	●
XJ range	2006	V8NA		PCM	●	●	●
XJ range	2006	V8NA		RATC	●	●	●
XJ range	2006	V8NA		REM	●	●	●
XJ range	2006	V8NA		RETM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJ range	2006	V8NA		RSM	●	●	●
XJ range	2006	V8NA		SCLM	●	●	●
XJ range	2006	V8NA		TCM	●	●	●
XJ range	2006	V8NA		TPM	●	●	●
XJ range	2006	V8NA		VACM	●	●	●
XJ range	2006	V8SC		ABS	●	●	●
XJ range	2006	V8SC		ACC	●	●	●
XJ range	2006	V8SC		AMP	●	●	●
XJ range	2006	V8SC		ARM	●	●	●
XJ range	2006	V8SC		ASU	●	●	●
XJ range	2006	V8SC		ATC	●	●	●
XJ range	2006	V8SC		CPM	●	●	●
XJ range	2006	V8SC		DDM	●	●	●
XJ range	2006	V8SC		DSM	●	●	●
XJ range	2006	V8SC		FETM	●	●	●
XJ range	2006	V8SC		GEM	●	●	●
XJ range	2006	V8SC		IP	●	●	●
XJ range	2006	V8SC		ISM	●	●	●
XJ range	2006	V8SC		NAV	●	●	●
XJ range	2006	V8SC		PAM	●	●	●
XJ range	2006	V8SC		PBM	●	●	●
XJ range	2006	V8SC		PCM	●	●	●
XJ range	2006	V8SC		RATC	●	●	●
XJ range	2006	V8SC		REM	●	●	●
XJ range	2006	V8SC		RETM	●	●	●
XJ range	2006	V8SC		RSM	●	●	●
XJ range	2006	V8SC		SCLM	●	●	●
XJ range	2006	V8SC		TCM	●	●	●
XJ range	2006	V8SC		TPM	●	●	●
XJ range	2006	V8SC		VACM	●	●	●
XJ range	2008	V6DIESEL		AHCM	●	●	●
XJ range	2008	V6DIESEL		ABS	●	●	●
XJ range	2008	V6DIESEL		ACC	●	●	●
XJ range	2008	V6DIESEL		AMP	●	●	●
XJ range	2008	V6DIESEL		ARM	●	●	●
XJ range	2008	V6DIESEL		ASU	●	●	●
XJ range	2008	V6DIESEL		ATC	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJ range	2008	V6DIESEL		CPM	●	●	●
XJ range	2008	V6DIESEL		DABM	●	●	●
XJ range	2008	V6DIESEL		DACMC	●	●	●
XJ range	2008	V6DIESEL		DCSM	●	●	●
XJ range	2008	V6DIESEL		DDM	●	●	●
XJ range	2008	V6DIESEL		DSM	●	●	●
XJ range	2008	V6DIESEL		FETM	●	●	●
XJ range	2008	V6DIESEL		GEM	●	●	●
XJ range	2008	V6DIESEL		GWM	●	●	●
XJ range	2008	V6DIESEL		IP	●	●	●
XJ range	2008	V6DIESEL		ISM	●	●	●
XJ range	2008	V6DIESEL		NAV	●	●	●
XJ range	2008	V6DIESEL		PAM	●	●	●
XJ range	2008	V6DIESEL		PBM	●	●	●
XJ range	2008	V6DIESEL		PCM	●	●	●
XJ range	2008	V6DIESEL		RATC	●	●	●
XJ range	2008	V6DIESEL		REM	●	●	●
XJ range	2008	V6DIESEL		RETM	●	●	●
XJ range	2008	V6DIESEL		RSM	●	●	●
XJ range	2008	V6DIESEL		SCLM	●	●	●
XJ range	2008	V6DIESEL		SRM	●	●	●
XJ range	2008	V6DIESEL		TCM	●	●	●
XJ range	2008	V6DIESEL		TPM	●	●	●
XJ range	2008	V6DIESEL		VACM	●	●	●
XJ range	2008	V6NA		ABS	●	●	●
XJ range	2008	V6NA		ACC	●	●	●
XJ range	2008	V6NA		AMP	●	●	●
XJ range	2008	V6NA		ARM	●	●	●
XJ range	2008	V6NA		ASU	●	●	●
XJ range	2008	V6NA		ATC	●	●	●
XJ range	2008	V6NA		CPM	●	●	●
XJ range	2008	V6NA		DABM	●	●	●
XJ range	2008	V6NA		DACMC	●	●	●
XJ range	2008	V6NA		DCSM	●	●	●
XJ range	2008	V6NA		DDM	●	●	●
XJ range	2008	V6NA		DSM	●	●	●
XJ range	2008	V6NA		FETM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJ range	2008	V6NA		GEM	●	●	●
XJ range	2008	V6NA		GWM	●	●	●
XJ range	2008	V6NA		IP	●	●	●
XJ range	2008	V6NA		ISM	●	●	●
XJ range	2008	V6NA		NAV	●	●	●
XJ range	2008	V6NA		PAM	●	●	●
XJ range	2008	V6NA		PBM	●	●	●
XJ range	2008	V6NA		PCM	●	●	●
XJ range	2008	V6NA		RATC	●	●	●
XJ range	2008	V6NA		REM	●	●	●
XJ range	2008	V6NA		RETM	●	●	●
XJ range	2008	V6NA		RSM	●	●	●
XJ range	2008	V6NA		SCLM	●	●	●
XJ range	2008	V6NA		SRM	●	●	●
XJ range	2008	V6NA		TCM	●	●	●
XJ range	2008	V6NA		TPM	●	●	●
XJ range	2008	V6NA		VACM	●	●	●
XJ range	2008	V8NA		ABS	●	●	●
XJ range	2008	V8NA		ACC	●	●	●
XJ range	2008	V8NA		AMP	●	●	●
XJ range	2008	V8NA		ARM	●	●	●
XJ range	2008	V8NA		ASU	●	●	●
XJ range	2008	V8NA		ATC	●	●	●
XJ range	2008	V8NA		CPM	●	●	●
XJ range	2008	V8NA		DABM	●	●	●
XJ range	2008	V8NA		DACMC	●	●	●
XJ range	2008	V8NA		DCSM	●	●	●
XJ range	2008	V8NA		DDM	●	●	●
XJ range	2008	V8NA		DSM	●	●	●
XJ range	2008	V8NA		FETM	●	●	●
XJ range	2008	V8NA		GEM	●	●	●
XJ range	2008	V8NA		GWM	●	●	●
XJ range	2008	V8NA		IP	●	●	●
XJ range	2008	V8NA		ISM	●	●	●
XJ range	2008	V8NA		NAV	●	●	●
XJ range	2008	V8NA		PAM	●	●	●
XJ range	2008	V8NA		PBM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJ range	2008	V8NA		PCM	●	●	●
XJ range	2008	V8NA		RATC	●	●	●
XJ range	2008	V8NA		REM	●	●	●
XJ range	2008	V8NA		RETM	●	●	●
XJ range	2008	V8NA		RSM	●	●	●
XJ range	2008	V8NA		SCLM	●	●	●
XJ range	2008	V8NA		SRM	●	●	●
XJ range	2008	V8NA		TCM	●	●	●
XJ range	2008	V8NA		TPM	●	●	●
XJ range	2008	V8NA		VACM	●	●	●
XJ range	2008	V8SC		ABS	●	●	●
XJ range	2008	V8SC		ACC	●	●	●
XJ range	2008	V8SC		AMP	●	●	●
XJ range	2008	V8SC		ARM	●	●	●
XJ range	2008	V8SC		ASU	●	●	●
XJ range	2008	V8SC		ATC	●	●	●
XJ range	2008	V8SC		CPM	●	●	●
XJ range	2008	V8SC		DABM	●	●	●
XJ range	2008	V8SC		DACMC	●	●	●
XJ range	2008	V8SC		DCSM	●	●	●
XJ range	2008	V8SC		DDM	●	●	●
XJ range	2008	V8SC		DSM	●	●	●
XJ range	2008	V8SC		FETM	●	●	●
XJ range	2008	V8SC		GEM	●	●	●
XJ range	2008	V8SC		GWM	●	●	●
XJ range	2008	V8SC		IP	●	●	●
XJ range	2008	V8SC		ISM	●	●	●
XJ range	2008	V8SC		NAV	●	●	●
XJ range	2008	V8SC		PAM	●	●	●
XJ range	2008	V8SC		PBM	●	●	●
XJ range	2008	V8SC		PCM	●	●	●
XJ range	2008	V8SC		RATC	●	●	●
XJ range	2008	V8SC		REM	●	●	●
XJ range	2008	V8SC		RETM	●	●	●
XJ range	2008	V8SC		RSM	●	●	●
XJ range	2008	V8SC		SCLM	●	●	●
XJ range	2008	V8SC		SRM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJ range	2008	V8SC		TCM	●	●	●
XJ range	2008	V8SC		TPM	●	●	●
XJ range	2008	V8SC		VACM	●	●	●
X-Type	2001_50			ABS	●	●	●
X-Type	2001_50			ECM	●	●	●
X-Type	2001_50			IP	●	●	●
X-Type	2001_50			TCM	●	●	●
X-Type	2001_50			ATC	●	●	●
X-Type	2001_50			PAM	●	●	●
X-Type	2001_50			ISM	●	●	●
X-Type	2001_50			ARM	●	●	●
X-Type	2001_50			ADHLS	●	●	●
X-Type	2001_50			FETM	●	●	●
X-Type	2001_50			GEM	●	●	●
X-Type	2001_50			NAV	●	●	●
X-Type	2001_50			CPM	●	●	●
X-Type	2001_50			VACM	●	●	●
X-Type	2004	AJ61		ABS	●	●	●
X-Type	2004	AJ61		ADHLS	●	●	●
X-Type	2004	AJ61		AMP	●	●	●
X-Type	2004	AJ61		ARM	●	●	●
X-Type	2004	AJ61		ATC	●	●	●
X-Type	2004	AJ61		CPM	●	●	●
X-Type	2004	AJ61		DSM	●	●	●
X-Type	2004	AJ61		ECM	●	●	●
X-Type	2004	AJ61		FETM	●	●	●
X-Type	2004	AJ61		GEM	●	●	●
X-Type	2004	AJ61		IP	●	●	●
X-Type	2004	AJ61		ISM	●	●	●
X-Type	2004	AJ61		NAV	●	●	●
X-Type	2004	AJ61		PAM	●	●	●
X-Type	2004	AJ61		TCM	●	●	●
X-Type	2004	AJ61		TPM	●	●	●
X-Type	2004	AJ61		VACM	●	●	●
X-Type	2004	TDCi	2. 2L	ABS	●	●	●
X-Type	2004	TDCi	2. 2L	ADHLS	●	●	●
X-Type	2004	TDCi	2. 2L	AMP	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
X-Type	2004	TDCi	2. 2L	ARM	●	●	●
X-Type	2004	TDCi	2. 2L	ATC	●	●	●
X-Type	2004	TDCi	2. 2L	CPM	●	●	●
X-Type	2004	TDCi	2. 2L	DSM	●	●	●
X-Type	2004	TDCi	2. 2L	FETM	●	●	●
X-Type	2004	TDCi	2. 2L	GEM	●	●	●
X-Type	2004	TDCi	2. 2L	IP	●	●	●
X-Type	2004	TDCi	2. 2L	ISM	●	●	●
X-Type	2004	TDCi	2. 2L	NAV	●	●	●
X-Type	2004	TDCi	2. 2L	PAM	●	●	●
X-Type	2004	TDCi	2. 2L	TPM	●	●	●
X-Type	2004	TDCi	2. 2L	VACM	●	●	●
X-Type	2004	TDCi	2. 2L	ECM	●	●	●
X-Type	2004	TDCi	2. 2L	FFH	●	●	●
X-Type	2004	TDCi	2. 2L	GWM	●	●	●
X-Type	2004	TDCi	2. 2L	TCM	●	●	●
X-Type	2004	TDCi	2L	ABS	●	●	●
X-Type	2004	TDCi	2L	ADHLS	●	●	●
X-Type	2004	TDCi	2L	AMP	●	●	●
X-Type	2004	TDCi	2L	ARM	●	●	●
X-Type	2004	TDCi	2L	ATC	●	●	●
X-Type	2004	TDCi	2L	CPM	●	●	●
X-Type	2004	TDCi	2L	DSM	●	●	●
X-Type	2004	TDCi	2L	FETM	●	●	●
X-Type	2004	TDCi	2L	GEM	●	●	●
X-Type	2004	TDCi	2L	IP	●	●	●
X-Type	2004	TDCi	2L	ISM	●	●	●
X-Type	2004	TDCi	2L	NAV	●	●	●
X-Type	2004	TDCi	2L	PAM	●	●	●
X-Type	2004	TDCi	2L	TPM	●	●	●
X-Type	2004	TDCi	2L	VACM	●	●	●
X-Type	2004	TDCi	2L	ECM	●	●	●
X-Type	2004	TDCi	2L	FFH	●	●	●
XJS	1996			CCM	●	●	●
XJS	1996			SEC	●	●	●
XJS	1996			DSM	●	●	●
XJS	1996			TCM	●	●	●

VehicleType	ModelYear	Engine Type	Capacity	System Name	Read Codes	Erase Codes	Live Data
XJS	1996			ECM	●	●	●
XJS	1996			ABS	●	●	●
XJS	1994_75			CCM	●	●	●
XJS	1994_75			SEC	●	●	●
XJS	1994_75			DSM	●	●	●
XJS	1994_75			TCM	●	●	●
XJS	1994_75			ECM	●	●	●
XJS	1994_75			ABS	●	●	●
XJS	1995_25			CCM	●	●	●
XJS	1995_25			SEC	●	●	●
XJS	1995_25			DSM	●	●	●
XJS	1995_25			TCM	●	●	●
XJS	1995_25			ECM	●	●	●
XJS	1995_25			ABS	●	●	●