

# MaxiDiag\_Peugeot\_V2.11 Function List (Note:For reference only)

## NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- ▲ This function is the new feature in this version.

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
107	Driving assistance/Comfort		Power steering	●	●	●	●
107	Engine/Gearbox	Gearbox ECU	Controlled Manual Gearbox(MMT)	○	●	●	●
107	Engine/Gearbox	Petrol	CFA BOSCH ME7.9.5	○	●	●	●
107	Engine/Gearbox	Diesel	8HT SIEMENS SID805	●	●	●	●
107	Vehicle protection/Management of		Coded engine immobiliser	○	●	●	●
107	Active and passive safety		ABS BOSCH 8.0 C1	○	●	●	○
107	Active and passive safety		ESP BOSCH 8.0 C1	○	●	●	○
107	Active and passive safety		Airbag ECU	●	●	●	●
208		Buit-in syrtem interface	BSI2010	●	●	●	●
208		Engine ECU	EDC17C10 BR2	●	●	●	●
208		Engine ECU	HDI SID807 BR2	●	●	●	●
208		Diesel additive	POMPE MUX TI	●	●	●	●
208		ABS or ESP ECU	ABSMK100	●	●	●	●
208		ABS or ESP ECU	ESPMK100	●	●	●	●
208		Engine ECU	MEV 17 4 2	●	●	●	●
208		Engine ECU	V46	●	●	●	●
208		Electric power steering	DAE	●	●	●	●
208		Battery change status unit	BECB GEN2	●	●	●	●
208		Rain sensor	PLUIE LUMINOSITE UDS	●	●	●	●
208		Radio	AUTORADIO	●	●	●	●
208		Air bag	RGB UDS	●	●	●	●
208		Multiplexed control panel	FMUX	●	●	●	●
208		Steering wheel with integral controls(VCI)	VCI	●	●	●	●
208		Independent telematic	BTA	●	●	●	●
208		Instrument panel	COMBINE UDS	●	●	●	●
208		Audio amplifier	AMPLI AUDIO	●	●	●	○
208		Parking aid	AAS UDS	●	●	●	●
208		Air conditioning	TDC CH MUX	●	●	●	●
208		Air conditioning	TDC RF MUX	●	●	●	●
208		Air conditioning	TDC RFTA MUX	●	●	●	●
208		gearbox	BVMP	●	●	●	●
208		Voltage retaining device	DMTC	●	○	○	○
208		Trailer relay unit	BSG 2010 RQ	●	●	●	●
208		CD player	CDE	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
208		Telematics	SMEG	●	●	●	●
208		Matrix screen integral to the instrument panel	MATT_C_2010	●	●	●	○
208		Matrix screen integral to the instrument panel	MATT_M_2010	●	●	●	○
208		Siren	SIR	●	●	●	●
208		Anti-theft alarm	MUS	●	●	●	●
208		Driving school module	MAE	●	●	●	○
208		Lighting relay unit	BSG E	●	●	●	●
208		Switch module under the steering wheel (top of column)	COM2008P	●	●	●	●
308	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
308	Active and passive safety	ABS or ESP ECU	ABS 8.1	●	●	●	●
308	Engine /Gearbox	Engine ECU→Petrol	5FT MED17.4	●	●	●	●
308	Engine /Gearbox	Engine ECU→Petrol	5FW MEV17.4	●	●	●	●
308	Engine /Gearbox	Engine ECU→Petrol	5FX MED17.4	●	●	●	●
308	Engine /Gearbox	Engine ECU→Petrol	5FY MED17.4	●	●	●	●
308	Engine /Gearbox	Engine ECU→Petrol	8FS MEV17.4	●	●	●	●
308	Engine /Gearbox	gearbox	AL4 gearbox	●	●	●	●
308	Active and passive safety	air-bag	air-bag	●	●	●	●
308	Engine /Gearbox	gearbox	AM6 Euro5 automatic gearbox	●	●	●	●
308	Engine /Gearbox	Engine ECU→Petrol	N6A ME745	●	●	●	●
308	Engine /Gearbox	Engine ECU→Petrol	N6B ME745	●	●	●	●
308	Engine /Gearbox	Engine ECU→Petrol	NFU ME745	●	●	●	●
308	Driving assistance/Comfort		Under inflation detection	●	●	●	●
308	Built-in systems interface(BSI)		Built-in systems interface(BSI)	●	●	●	●
308	Engine /Gearbox	Engine ECU→Diesel	DCM3.5	●	●	●	●
308	Engine /Gearbox	Engine ECU→Diesel	RHF DCM3.4	●	●	●	●
308	Engine /Gearbox	Engine ECU→Diesel	RHL DCM3.4	●	●	●	●
308	Engine /Gearbox	Engine ECU→Diesel	RHR DCM3.4	●	●	●	●
308	Engine /Gearbox	Engine ECU→Diesel	EDC17C10 BR2	●	●	●	●
308	Engine /Gearbox	Engine ECU→Diesel	HDI SID807 BR2	●	●	●	●
308	Engine /Gearbox	Engine ECU→Diesel	HDI SID807	●	●	●	●
308	Engine /Gearbox	Engine ECU→Diesel	9HV BOSCH EDC16C3	●	●	●	●
308	Engine /Gearbox	Engine ECU→Diesel	9HX BOSCH EDC16C3	●	●	●	●
308	Engine /Gearbox	Engine ECU→Diesel	9HY BOSCH EDC16C3	●	●	●	●
308	Engine /Gearbox	Engine ECU→Diesel	9HZ BOSCH EDC16C3	●	●	●	●
308	Engine /Gearbox	Multiplexed additive adding	POMPE MUX TI	●	●	●	●
308	Active and passive safety	ABS or ESP ECU	ESP 8.1	●	●	●	●
308	Engine /Gearbox	gearbox	CFC300P gearbox	●	●	●	●
308	Engine /Gearbox	Engine ECU→Petrol	NFU ME749 Bio Flex	●	●	●	●
308	Engine /Gearbox	Engine ECU→Petrol	RFJ MM6KP Bio Flex(EW10AFF)	●	●	●	●
308	Engine /Gearbox	Engine ECU→Petrol	RFJ MM6LPB	●	●	●	●
308	Engine /Gearbox	gearbox	AM6C gearbox	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
308	Engine /Gearbox	gearbox	AT6 Euro5 automatic gearbox	●	●	●	●
308	Inform the driver/Audio/Communication	Telematics	Data communication ECU	●	●	●	●
308	Inform the driver/Audio/Communication	Telematics	RNEG radio navigation	●	●	●	●
308	Driving assistance/Comfort		air conditioning	●	●	●	●
308	Vehicle protection/Management of		Alarm	●	●	●	●
308	Inform the driver/Audio/Communication		Audio amplifier	●	●	●	○
308	Inform the driver/Audio/Communication		Battery charge status unit.	●	●	●	●
308	Inform the driver/Audio/Communication		CD player	●	●	●	○
308	Inform the driver/Audio/Communication		Control panel dot matrix display	●	●	●	●
308	Visibility/Lighting/Signalling		discharge bulbs vertical and horizontal adjustment	●	●	●	●
308	Driving assistance/Comfort		driver seat memory unit	●	●	●	●
308	Vehicle protection/Management of		Driver's door control panel	●	●	●	●
308	Visibility/Lighting/Signalling		Driving school moduel	●	●	○	○
308	Driving assistance/Comfort		Electropump assembly	●	●	●	●
308	Inform the driver/Audio/Communication		Hands Free Kit	●	●	●	●
308	Driving assistance/Comfort		Lane departure warning	●	●	●	●
308	Inform the driver/Audio/Communication		multifunction screen	●	●	●	●
308	Engine /Gearbox		multiplexed additive adding pump	●	●	●	●
308	Inform the driver/Audio/Communication		not fastened warning light(TNB)	●	○	○	○
308	Driving assistance/Comfort		Parking assistance	●	●	●	●
308	Inform the driver/Audio/Communication		radio	●	●	●	●
308	Visibility/Lighting/Signalling		rain sensor	●	●	●	○
308	Inform the driver/Audio/Communication		Service module	●	●	●	●
308	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
407	Driving assistance/Comfort		Under inflation detection	●	●	●	●
407			Built-in systems interface(BSI)	●	●	●	●
407	Engine/Gearbox	Diesel	RHL SIEMENS SID 803	●	●	●	●
407	Engine/Gearbox	Diesel	RHL SIEMENS SID 803	●	●	●	●
407	Engine/Gearbox		Diesel fuel additive control unit	●	●	●	●
407	Engine/Gearbox	Diesel	UHZ SIEMENS SID 201	●	●	●	●
407	Engine/Gearbox	Diesel	RHL DCM3.4	●	●	●	●
407	Engine/Gearbox	Diesel	RHR DCM3.4	●	●	●	●
407	Engine/Gearbox	Diesel	RHF DCM3.4	●	●	●	●
407	Engine/Gearbox	Diesel	RHF DCM3.5	●	●	●	●
407	Engine/Gearbox	Diesel	4HP BOSCH EDC16CP39	●	●	●	●
407	Engine/Gearbox	Diesel	4HR BOSCH EDC16CP39	●	●	●	●
407	Engine/Gearbox	Diesel	4HS BOSCH EDC16CP39	●	●	●	●
407	Engine/Gearbox	Diesel	4HT BOSCH EDC16CP39	●	●	●	●
407	Engine/Gearbox	Diesel	9HY BOSCH EDC16C3 EURO3	●	●	●	●
407	Engine/Gearbox	Diesel	9HZ BOSCH EDC16C3	●	●	●	●
407	Engine/Gearbox	Diesel	9HT BOSCH EDC16C3	●	●	●	●
407	Engine/Gearbox	Diesel	EDC17CP11	●	●	●	●
407	Active and passive safety	ABS or ESP ECU	ESP EBC 440 K	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
407	Active and passive safety	ABS or ESP ECU	ESP8.1	●	●	●	●
407	Active and passive safety	ABS or ESP ECU	ESP EBC 440 CAN	●	●	●	●
407	Engine/Gearbox	Petrol	RFJ MM6LPB	●	●	●	●
407	Engine/Gearbox	Petrol	3FY MM6LPB	●	●	●	●
407	Engine/Gearbox	Petrol	6FY MM6LPB	●	●	●	●
407	Engine/Gearbox	Petrol	6FZ S2000PM2		●	●	
407	Engine/Gearbox	Petrol	RFJ MM6KP Bio Flex(EW10AFF)	●	●	●	●
407	Driving assistance/Comfort		Parking assistance	●	●	●	●
407	Driving assistance/Comfort		Drivers seat memory unit	●	●	●	●
407	Driving assistance/Comfort		Passenger seat memorisation module	●	●	●	●
407	Driving assistance/Comfort		Air conditioning	●	●	●	●
407	Driving assistance/Comfort		Additional heating	●	●	●	●
407	Driving assistance/Comfort		Power steering	●	●	●	●
407	Driving assistance/Comfort		Controlled suspension	●	●	●	●
407	Driving assistance/Comfort		battery charge statue unit	●	●	●	●
407	Inform the driver/Audio/Communication		Multi-function display	●	●	●	●
407	Inform the driver/Audio/Communication		Radio	●	●	●	●
407	Inform the driver/Audio/Communication		CD player	●	●	●	○
407	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
407	Inform the driver/Audio/Communication		Hands Free Kit	●	●	●	●
407	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
407	Inform the driver/Audio/Communication	Telematics	Data communication ECU	●	●	●	●
407	Inform the driver/Audio/Communication	Telematics	RNEG radio navigation	●	●	●	●
407	Engine/Gearbox		AM6 automatic gearbox	●	●	●	●
407	Engine/Gearbox		AL4 automatic gearbox	●		●	●
407	Engine/Gearbox		4HP20 automatic gearbox	●		●	●
407	Engine/Gearbox		AM6 Euro5 automatic gearbox	●	●	●	●
407	Engine/Gearbox	Petrol	XFV ME7.4.7	●	●	●	●
407	Engine/Gearbox	Petrol	3FZ MM6LP	●	●	●	●
407	Engine/Gearbox	Petrol	RFN MM6LP	●	●	●	●
407	Vehicle protection/Management of		Alarm	●	●	●	●
407	Vehicle protection/Management of		Drivers's door module	●	●	●	●
407	Vehicle protection/Management of		Passenger door module	●	●	●	●
407	Vehicle protection/Management of		Sun roof	●	●	●	●
407	Active and passive safety		Airbag ECU	●	●	●	●
407	Visibility/Lighting/Signalling		Control unit Windscreen wipers	●	●	●	●
407	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
407	Visibility/Lighting/Signalling		Master discharge bulb	●	●	●	●
407	Visibility/Lighting/Signalling		Slave discharge bulb	●	●	●	●
407	Visibility/Lighting/Signalling		Steering wheel switching module.	●	●	●	●
408	Engine /Gearbox	Engine ECU→Diesel	DCM3.5	●	●	●	●
408	Engine /Gearbox	Engine ECU→Diesel	EDC17C10 BR2	●	●	●	●
408	Engine /Gearbox	Engine ECU→Diesel	HDI SID807 BR2	●	●	●	●
408	Engine /Gearbox	Engine ECU→Diesel	HDI SID807	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
408	Engine /Gearbox	Multiplexed additive adding	POMPE MUX TI	●	●	●	●
806	Engines/automatic gearbox	Petrol	RFV BOSCH MP7.3	○	●	●	○
806	Engines/automatic gearbox	Petrol	RFN MM4.8P	●	●	●	●
806	Engines/automatic gearbox	Petrol	R6F MM4.8P	●	●	●	●
806	Engines/automatic gearbox		AL4 autoadaptive automatic gearbox	●	○	●	●
806	Active safety		BOSCH ABS5.3	●	●	●	●
806	Engines/automatic gearbox	Diesel	RHW BOSCH EDC15C2	●	●	●	●
806	Engines/automatic gearbox	Diesel	RHZ BOSCH EDC15C2	●	●	●	●
3008	Driving assistance/Comfort		Electric parking brake	●	●	●	●
3008	Driving assistance/Comfort		Under inflation detection	●	●	●	●
3008	Engine/Gearbox	Diesel	9HZ BOSCH EDC16C3	●	●	●	●
3008	Engine/Gearbox	Diesel	DCM3.5	●	●	●	●
3008	Engine/Gearbox	Diesel	HDI SID807	●	●	●	●
3008	Active and passive safety	ABS or ESP ECU	ESP 8.1	●	●	●	●
3008	Engine/Gearbox	Diesel	5FX MED 17.4	●	●	●	●
3008	Driving assistance/Comfort		High head Vision.	●	●	●	●
3008	Driving assistance/Comfort		Assistance in complying with the inter-vehicle(ARTIV)	●	●	●	●
3008	Driving assistance/Comfort		Lane departure warning	●	●	●	●
3008	Driving assistance/Comfort		Air conditioning ECU	●	●	●	●
3008	Driving assistance/Comfort		Parking assistance	●	●	●	●
3008	Driving assistance/Comfort		Electropump assembly	●	●	●	●
3008			Built-in systems interface(BSI)	●	●	●	●
3008	Inform the driver/Audio/Communication		Audio amplifier	●	●	●	●
3008	Inform the driver/Audio/Communication	Multi-function display(EMF)	EMF A	●	●	●	●
3008	Inform the driver/Audio/Communication	Multi-function display(EMF)	EMF C	●	●	●	●
3008	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
3008	Inform the driver/Audio/Communication		Portable unit.	●	●	●	●
3008	Inform the driver/Audio/Communication		Radio.	●	●	●	●
3008	Inform the driver/Audio/Communication	Telematics	RNEG radio navigation	●	●	●	●
3008	Inform the driver/Audio/Communication		Service module	●	●	●	●
3008	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
3008	Inform the driver/Audio/Communication		Control panel dot matrix display	●	●	●	●
3008	Inform the driver/Audio/Communication		Battery charge status unit.	●	●	●	●
3008	Inform the driver/Audio/Communication		CD player	●	●	●	●
3008	Engine/Gearbox		CFC300P gearbox	●	●	●	●
3008	Engine/Gearbox		AM6 Euro5 automatic gearbox	●	●	●	●
3008	Engine/Gearbox		AT6 Euro5 automatic gearbox	●	●	●	●
3008	Engine/Gearbox		Multiplexed additive adding pump	●	●	●	●
3008	Vehicle protection/Management of		Driver's door control panel	●	●	●	●
3008	Vehicle protection/Management of		Alarm	●	●	●	●
3008	Active and passive safety		Airbag ECU	●	●	●	●
3008	Active and passive safety		8.1 ESP	●	●	●	●
3008	Active and passive safety		Anti-lock brakes BENDIX	●	●	○	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
3008	Active and passive safety		Network isolation unit	●	○	○	●
3008	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
3008	Visibility/Lighting/Signalling		Windscreen wiper	●	●	●	●
3008	Visibility/Lighting/Signalling		Headlamp height corrector	●	●	●	●
3008	Engine/Gearbox		MED174	●	●	●	●
3008	Engine/Gearbox		MEV17.4	●	●	●	●
3008	Engine/Gearbox		MEV174	●	●	●	●
3008	Engine/Gearbox		HDI SID807	●	●	●	●
3008	Engine/Gearbox		MED17 4 2	●	●	●	●
3008			Service module	●	●	●	●
3008			Multiplexed additive adding pump	●	●	●	●
3008			Not Fastened warning light (TNB)	●	●	●	●
4007	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
4007	Engine/Automatic Gearbox/Transmission	Engine ECU/Diesel	4HN EDC16CP39	●	●	●	●
4007	Engine/Automatic Gearbox/Transmission	Engine ECU/Diesel	EDC16CP39 EUR05	●	●	●	●
4007	Active and passive safety	ABS or ESP ECU	ESP	●	●	●	●
4007	Active and passive safety	ABS or ESP ECU	ABS	●	●	●	●
4007	Driving assistance/Comfort		Air conditioning	●	●	●	●
4007			Built-in system interface(BSI)	●	●	●	●
4007	Inform the driver/Audio/Communication		Radio	●	●	●	●
4007	Inform the driver/Audio/Communication		Navigation	●	●	●	○
4007	Inform the driver/Audio/Communication		Hands Free Kit	●	●	●	●
4007	Engine/Automatic Gearbox/Transmission	Engine ECU/Petrol	SFZ MIVEC	●	●	●	●
4007	Engine/Automatic Gearbox/Transmission	Gearbox	CVT gearbox	●	●	●	●
4007	Engine/Automatic Gearbox/Transmission	Gearbox	DCT controlled gearbox	●	●	●	●
4007	Engine/Automatic Gearbox/Transmission		4x4 transmission	●	●	●	●
4007	Vehicle protection/Management of		Coded immobiliser	●	●	●	●
4007	Vehicle protection/Management of		Driver's door control panel	●	●	●	●
4007	Vehicle protection/Management of		Passenger's door control panel	●	●	●	●
4007	Vehicle protection/Management of		Rear left door control pad	●	●	●	●
4007	Vehicle protection/Management of		Rear right door control pad	●	●	●	●
4007	Vehicle protection/Management of		Sun roof	●	●	●	●
4007	Active and passive safety		Air bag	●	●	●	●
4007	Active and passive safety		steering wheel angle sensor	●	●	●	○
4008		Parking aid	AAS MMC	●	●	●	●
4008		ABS/traction control	ABS 4x4	●	●	●	●
4008		ABS/traction control	ESP 4x4	●	●	●	●
4008		Driver and passenger airbags	SAC TRW	●	●	●	●
4008		Driver's door module	PDPC	●	●	●	●
4008		Rain and brightness sensor	CDPL	●	●	●	●
4008		Anti-theft alarm	ALARME MMC	●	●	●	●
4008		Power steering	EPS	●	●	●	●
4008		Instrument panel	COMBINE	●	●	●	●
4008		Starting authorisation ECU	OSS	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
4008		Radio or radiotelephone(radio part)	AUTORADIO_3	●	●	●	●
4008		Injection/ignition	MIVEC	●	●	●	●
4008		Injection/ignition	CMM 4A92	●	●	●	●
4008		Injection/ignition	HDI 4N13	●	●	●	●
4008		Rear final drive piloted	TRANSMISSION	●	●	●	●
4008		Directional headlamps	CORPRO	●	●	●	●
4008		Locking and immobiliser control module	WCM	●	●	●	●
4008		Locking and immobiliser control module	KOS	●	●	●	●
4008		Calculateur stop and start	STT MMC	●	●	●	●
4008		Streeing wheel angle sensor	CAV	●	●	●	○
4008		heating/ventilation	CLIM REGULEE	●	●	●	●
4008		gearbox	BV CVT	●	●	●	●
4008		built-in Systems Interface	BSI	●	●	●	●
4008		Navigation	NAVIGATION	●	●	●	○
4008		Injection/ignition	HDI SID807 J3J4	●	●	●	●
5008	Driving assistance/Comfort		Electric parking brake	●	●	●	●
5008	Driving assistance/Comfort		Under inflation detection	●	●	●	●
5008	Engine/Gearbox	Diesel	9HZ BOSCH EDC16C3	●	●	●	●
5008	Engine/Gearbox	Diesel	DCM3.5	●	●	●	●
5008	Engine/Gearbox	Diesel	HDI SID807	●	●	●	●
5008	Active and passive safety	ABS or ESP ECU	ESP 8.1	●	●	●	●
5008	Engine/Gearbox	Diesel	5FX MED 17.4	●	●	●	●
5008	Driving assistance/Comfort		High head Vision.	●	●	●	●
5008	Driving assistance/Comfort		Assistance in complying with the inter-vehicle(ARTIV)	●	●	●	●
5008	Driving assistance/Comfort		Lane departure warning	●	●	●	●
5008	Driving assistance/Comfort		Air conditioning ECU	●	●	●	●
5008	Driving assistance/Comfort		Parking assistance	●	●	●	●
5008	Driving assistance/Comfort		Electropump assembly	●	●	●	●
5008			Built-in systems interface(BSI)	●	●	●	●
5008	Inform the driver/Audio/Communication		Audio amplifier	●	●	●	●
5008	Inform the driver/Audio/Communication	Multi-function display(EMF)	EMF A	●	●	●	●
5008	Inform the driver/Audio/Communication	Multi-function display(EMF)	EMF C	●	●	●	●
5008	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
5008	Inform the driver/Audio/Communication		Portable unit.	●	●	●	●
5008	Inform the driver/Audio/Communication		Radio.	●	●	●	●
5008	Inform the driver/Audio/Communication	Telematics	RNEG radio navigation	●	●	●	●
5008	Inform the driver/Audio/Communication		Service module	●	●	●	●
5008	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
5008	Inform the driver/Audio/Communication		Control panel dot matrix display	●	●	●	●
5008	Inform the driver/Audio/Communication		Battery charge status unit.	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
5008	Inform the driver/Audio/Communication		CD player	●	●	●	●
5008	Engine/Gearbox		CFC300P gearbox	●	●	●	●
5008	Engine/Gearbox		AM6 Euro5 automatic gearbox	●	●	●	●
5008	Engine/Gearbox		AT6 Euro5 automatic gearbox	●	●	●	●
5008	Engine/Gearbox		Multiplexed additive adding pump	●	●	●	●
5008	Vehicle protection/Management of		Driver's door control panel	●	●	●	●
5008	Vehicle protection/Management of		Alarm	●	●	●	●
5008	Active and passive safety		Airbag ECU	●	●	●	●
5008	Active and passive safety		8.1 ESP	●	●	●	●
5008	Active and passive safety		Anti-lock brakes BENDIX	●	●	○	●
5008	Active and passive safety		Network isolation unit	●	○	○	●
5008	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
5008	Visibility/Lighting/Signalling		Windscreen wiper	●	●	●	●
5008	Visibility/Lighting/Signalling		Headlamp height corrector	●	●	●	●
5008	Engine/Gearbox		MED174	●	●	●	●
5008	Engine/Gearbox		MEV17.4	●	●	●	●
5008	Engine/Gearbox		MEV174	●	●	●	●
5008	Engine/Gearbox		HDI SID807	●	●	●	●
5008	Engine/Gearbox		MED17 4 2	●	●	●	●
5008			Service module	●	●	●	●
5008			Multiplexed additive adding pump	●	●	●	●
5008			Not Fastened warning light (TNB)	●	●	●	●
1007 CAN	Driving assistance/Comfort		Under inflation detection	●	●	●	●
1007 CAN			Built-in systems interface(BSI)	●	●	●	●
1007 CAN	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
1007 CAN	Engine/Gearbox	Diesel	9HZ BOSCH EDC16C3	●	●	●	●
1007 CAN	Engine/Gearbox	Diesel	9HT BOSCH EDC16C3	●	●	●	●
1007 CAN	Active and passive safety		ESP MK60-0	●	●	●	●
1007 CAN	Engine/Gearbox		Controlled manual gearbox(BVMP)	●	●	●	●
1007 CAN	Engine/Gearbox	Petrol	KFU MM6LPC	●	●	●	●
1007 CAN	Engine/Gearbox	Petrol	KFV J34P	●	●	●	●
1007 CAN	Engine/Gearbox	Petrol	KFW J34P	●	●	●	●
1007 CAN	Active and passive safety		ABS MK70.1	●	●	●	●
1007 CAN	Active and passive safety		ESP MK60	●	●	●	●
1007 CAN	Active and passive safety		Airbag ECU	●	●	●	●
1007 CAN	Driving assistance/Comfort		Parking assistance	●	●	●	●
1007 CAN	Driving assistance/Comfort		Air conditioning	●	●	●	●
1007 CAN	Driving assistance/Comfort		Power steering	●	●	●	●
1007 CAN	Engine/Gearbox	Petrol	NFU BOSCH ME7.4.5	●	●	●	●
1007 CAN	Engine/Gearbox	Diesel	8HX SID 806 DV4	●	●	●	●
1007 CAN	Engine/Gearbox		Multiplexed additive adding pump	●	●	●	●
1007 CAN	Inform the driver/Audio/Communication		Multi-function display	●	●	●	●
1007 CAN	Inform the driver/Audio/Communication		Radio	●	●	●	●
1007 CAN	Inform the driver/Audio/Communication		CD player	●	●	●	○



Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
1007 CAN	Inform the driver/Audio/Communication		Hands Free Kit	●	●	●	●
1007 CAN	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
1007 CAN	Inform the driver/Audio/Communication		Telematics	●	●	●	●
1007 CAN	Inform the driver/Audio/Communication		High frequency receiver	●	●	●	●
1007 CAN	Vehicle protection/Management of		Alarm	●	●	●	●
1007 CAN	Engine/Gearbox	Diesel	8HZ SID 806 DV4	●	●	●	●
1007 CAN	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
1007 CAN	Vehicle protection/Management of		Motorised sliding side doors	●	●	●	●
1007 VAN			Built-in systems interface(BSI)	●	●	●	●
1007 VAN	Driving assistance/Comfort		Air conditioning	●	●	●	●
1007 VAN	Driving assistance/Comfort	Power steering	Power steering DAE	●	●	●	●
1007 VAN	Inform the driver/Audio/Communication	Display/Telematics	EMF	●	●	●	●
1007 VAN	Inform the driver/Audio/Communication	Display/Telematics	RT3	●	●	●	●
1007 VAN	Inform the driver/Audio/Communication		Radio	●	●	●	●
1007 VAN	Inform the driver/Audio/Communication		CD player	●	●	●	●
1007 VAN	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
1007 VAN	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
1007 VAN	Engine/Gearbox		Controlled manual gearbox(BVMP)	●	●	●	●
1007 VAN	Engine/Gearbox	Petrol	NFU ME744	●	●	●	●
1007 VAN	Engine/Gearbox	Petrol	N6A BOSCH ME7.4.5	●	●	●	●
1007 VAN	Engine/Gearbox	Petrol	N6B BOSCH ME7.4.5	●	●	●	●
1007 VAN	Engine/Gearbox	Petrol	NFU BOSCH ME7.4.5	●	●	●	●
1007 VAN	Engine/Gearbox	Petrol	KFU S2000MP2	●	●	●	●
1007 VAN	Engine/Gearbox	Petrol	KFU MM6LP	●	●	●	●
1007 VAN	Engine/Gearbox	Petrol	KFV J34P	●	●	●	●
1007 VAN	Engine/Gearbox	Diesel	8HX SIEEMENS SID 804	●	●	●	●
1007 VAN	Vehicle protection/Management of		Alarm	●	●	●	●
1007 VAN	Engine/Gearbox	Diesel	8HZ SIEEMENS SID 804	●	●	●	●
1007 VAN	Active and passive safety		ABS MK70	●	●	●	●
1007 VAN	Active and passive safety		ESP MK60	●	●	●	●
1007 VAN	Active and passive safety		Airbag ECU	●	●	●	●
1007 VAN	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
1007 VAN	Visibility/Lighting/Signalling		Steering wheel switching module.	●	●	●	●
1007 VAN	Vehicle protection/Management of		Sliding side doors module	●	●	●	●
206/206MUX	Active safety		ABS MK70	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	N6A BOSCH ME7.4.4	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	NFU BOSCH ME7.4.4	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	KFW BOSCH ME7.4.4	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL	●	●	●	●
206/206MUX			Air bags	●	●	●	○
206/206MUX	Engines/automatic gearbox	Petrol	NFU BOSCH ME7.4.5	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	KFW BOSCH ME7.4.5	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
206/206MUX			Built-in systems interface(BSI)	●	●	●	●
206/206MUX	Engines/automatic gearbox		Diesel fuel additive control unit	●	●	●	●
206/206MUX	Engines/automatic gearbox	Diesel	RHY BOSCH EDC15C2	●	●	●	●
206/206MUX	Active safety		ESP MK60	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	KFW SAGEM S2000	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	K6D SAGEM S2000	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	RFN MM4. 8P	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	HFX MM4. 8P	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	KFW J34P	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	K6D J34P	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	NFU J35	●	●	●	●
206/206MUX	Engines/automatic gearbox		AL4 automatic gearbox	●		●	●
206/206MUX	Engines/automatic gearbox	Petrol	7LZ MM5NP	●	●	●	●
206/206MUX			Alarm	●	●	●	●
206/206MUX	Driver information/Communication		Display/Telematics (AMF)	●	●	●	●
206/206MUX	Driver information/Communication		Display/Telematics (RT3)	●	●	●	●
206/206MUX	Driver information/Communication		Radio	●	●	●	●
206/206MUX	Driver information/Communication		CD player	●	●	●	●
206/206MUX	Driver information/Communication		Instrument panel	●	●	●	●
206/206MUX	Driver information/Communication		Switch unit under steering wheel(COM 2000)	●	●	●	●
206/206MUX	Driver information/Communication		On-board navigation system	●	●	●	●
206/206MUX	Visibility/Lighting		Driving school	●	○	○	●
206/206MUX	Visibility/Lighting		Rain/brightness sensor	●	●	●	○
206/206MUX	Control the openings		Electric retractable roof	●	●	●	●
206/206MUX			Air conditioning	●	●	●	●
206/206MUX	Active safety		Anti-lock brakes TEVES	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	KFU MM6LP	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	RFK MM6LP	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	RFN MM6LP	●	●	●	●
206/206MUX			Electric pump unit(power steering)	●	●	●	●
206/206MUX	Engines/automatic gearbox	Petrol	NFU Or N6A or N6B ME749 B10 FLEX	●	●	●	●
206/206MUX	Engines/automatic gearbox	Diesel	8HX/8HZ BOSCH EDC16C3 EUR3	●	●	●	●
206/206MUX	Engines/automatic gearbox	Diesel	8HZ BOSCH EDC16C3 EUR04	●	●	●	●
206/206MUX	Engines/automatic gearbox	Diesel	9HY BOSCH EDC16C3 EURO4	●	●	●	●
206/206MUX	Engines/automatic gearbox	Diesel	9HY BOSCH EDC16C3	●	●	●	●
206/206MUX	Engines/automatic gearbox	Diesel	9HZ BOSCH EDC16C3	●	●	●	●
206/206MUX	Engines/automatic gearbox	Diesel	WJY LUCAS DCN2	●	●	●	●
206/206MUX	Engines/automatic gearbox	Diesel	9HT BOSCH EDC16C3	●	●	●	●
206+	Active and passive safety	ABS or ESP ECU	ABS MK70	●	●	●	●
206+	Engine/Gearbox	Engine ECU→Diesel	WJY DCN2	●	●	●	●
206+	Engine/Gearbox	Engine ECU→Diesel	RHY EDC15C2	●	●	●	●
206+	Active and passive safety	air-bag	air-bag	●	●	●	○
206+	Active and passive safety	ABS or ESP ECU	ESP MK60	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
206+	Engine/Gearbox	Engine ECU→Petrol	NFU Or N6A ME749	●	●	●	●
206+	Engine/Gearbox	Engine ECU→Petrol	KFW ME749	●	●	●	●
206+	Engine/Gearbox	Engine ECU→Petrol	KFW ME749 BIO ELEX	●	●	●	●
206+	Engine/Gearbox	Engine ECU→Petrol	TU5JP4ME745	●	●	●	●
206+	Engine/Gearbox	Engine ECU→Diesel	8HZ BOSCH EDC16C3 EURO4	●	●	●	●
206+	Engine/Gearbox	Engine ECU→Diesel	9HY BOSCH EDC16C3 EURO4	●	●	●	●
206+			Built-in systems interface(BSI)	●	●	●	●
206+	Engine/Gearbox	Engine ECU→Petrol	EDC17C10 BR2	●	●	●	●
206+	Engine/Gearbox	Engine ECU→Petrol	N6A ME749 BIO FLEX	●	●	●	●
206+	Engine/Gearbox	Engine ECU→Petrol	KFW J34P	●	●	●	●
206+	Engine/Gearbox	Engine ECU→Petrol	HFX J34P	●	●	●	●
206+	Engine/Gearbox	Gearbox ECU	AL4 automatic gearbox	●	●	●	●
206+	Inform the driver/Audio/Communication	Display/Telematics	RT3	●	●	●	●
206+	Inform the driver/Audio/Communication	Display/Telematics	display	●	●	●	●
206+	Driver information/Communication		Air conditioning	●	●	●	●
206+	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
206+	Inform the driver/Audio/Communication		Radio	●	●	●	●
206+	Inform the driver/Audio/Communication		CD player	●	●	●	●
206+	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
206+	Vehicle protection/Management of		Alarm	●	●	●	○
206+	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
207CAN	Active and passive safety	ABS or ESP ECU	ABS MK70.1	●	●	●	●
207CAN	Active and passive safety		Airbag ECU	●	●	●	●
207CAN	Engine/Gearbox	Diesel	8HZ BOSCH EDC16C3 EURO4	●	●	●	●
207CAN	Engine/Gearbox	Diesel	9HY BOSCH EDC16C3 EURO4	●	●	●	●
207CAN	Engine/Gearbox	Petrol	KFV J34P	●	●	●	●
207CAN	Engine/Gearbox	Diesel	9HX BOSCH EDC16C3	●	●	●	●
207CAN	Engine/Gearbox	Diesel	9HZ BOSCH EDC16C3	●	●	●	●
207CAN	Engine/Gearbox	Diesel	9HV BOSCH EDC16C3	●	●	●	●
207CAN	Engine/Gearbox	Diesel	9HY BOSCH EDC16C3	●	●	●	●
207CAN	Engine/Gearbox	Diesel	9HT BOSCH EDC16C3	●	●	●	●
207CAN	Engine/Gearbox	Petrol	N6A BOSCH ME7.4.5	●	●	●	●
207CAN	Engine/Gearbox	Petrol	N6B BOSCH ME7.4.5	●	●	●	●
207CAN	Engine/Gearbox	Petrol	NFU BOSCH ME7.4.5	●	●	●	●
207CAN	Engine/Gearbox	Petrol	KFU MM6LPC	●	●	●	●
207CAN	Driving assistance/Comfort		Under inflation detection	●	●	●	●
207CAN			Built-in systems interface(BSI)	●	●	●	●
207CAN	Engine/Gearbox	Diesel	EDC17C10 BR2	●	●	●	●
207CAN	Engine/Gearbox	Diesel	EDC17C10	●	●	●	●
207CAN	Engine/Gearbox	Diesel	HDI SID807	●	●	●	●
207CAN	Active and passive safety	ABS or ESP ECU	ESP MK60-0	●	●	●	●
207CAN	Engine/Gearbox		AL4 automatic gearbox	●	●	●	●
207CAN	Engine/Gearbox	Petrol	5FX MED17.4	●	●	●	●
207CAN	Engine/Gearbox	Petrol	5FY MED17.4	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
207CAN	Engine/Gearbox	Petrol	5FW MEV17.4	●	●	●	●
207CAN	Engine/Gearbox	Petrol	8FS MEV17.4	●	●	●	●
207CAN	Engine/Gearbox	Petrol	MEV17.4EVO	●	●	●	●
207CAN	Engine/Gearbox		Controlled manual gearbox (BVMP)	●	●	●	●
207CAN	Driving assistance/Comfort		Parking assistance	●	●	●	●
207CAN	Driving assistance/Comfort		Air conditioning	●	●	●	●
207CAN	Driving assistance/Comfort		Power steering	●	●	●	●
207CAN	Inform the driver/Audio/Communication		Multi-function display	●	●	●	●
207CAN	Inform the driver/Audio/Communication		Radio	●	●	●	●
207CAN	Inform the driver/Audio/Communication		CD player	●	●	●	○
207CAN	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
207CAN	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
207CAN	Inform the driver/Audio/Communication		Hands Free Kit	●	●	●	●
207CAN	Inform the driver/Audio/Communication	Telematics	Data communication ECU	●	●	●	●
207CAN	Inform the driver/Audio/Communication	Telematics	RNEG radio navigation	●	●	●	●
207CAN	Inform the driver/Audio/Communication		Warning light showing seat belt not fastened	●	○	○	○
207CAN	Inform the driver/Audio/Communication		High frequency receiver	●	●	●	●
207CAN	Inform the driver/Audio/Communication		Battery charge status unit	●	●	●	●
207CAN	Engine/Gearbox		Multiplexed additive adding pump	●	●	●	●
207CAN	Vehicle protection/Management of		Alarm	●	●	●	●
207CAN	Vehicle protection/Management of		Retractable roof	●	●	●	●
207CAN	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
207CAN	Visibility/Lighting/Signalling		Static AFS	●	●	●	●
207CAN	Visibility/Lighting/Signalling		Driving school moduel	●	●	○	○
207CAN	Visibility/Lighting/Signalling		Steering wheel switching module.	●	●	●	●
207VAN/207i	Active and passive safety	ABS or ESP ECU	ABS MK70	●	●	●	●
207VAN/207i	Engine/Gearbox	Engine ECU→Diesel	WJY DCN2	●	●	●	●
207VAN/207i	Engine/Gearbox	Engine ECU→Diesel	RHY EDC15C2	●	●	●	●
207VAN/207i	Active and passive safety	air-bag	air-bag	●	●	●	○
207VAN/207i	Active and passive safety	ABS or ESP ECU	ESP MK60	●	●	●	●
207VAN/207i	Engine/Gearbox	Engine ECU→Petrol	N6A ME749 BIO FLEX	●	●	●	●
207VAN/207i	Engine/Gearbox	Engine ECU→Petrol	KFW ME749	●	●	●	●
207VAN/207i	Engine/Gearbox	Engine ECU→Petrol	KFW ME749 BIO ELEX	●	●	●	●
207VAN/207i	Engine/Gearbox	Engine ECU→Petrol	TU5JP4ME745	●	●	●	●
207VAN/207i	Engine/Gearbox	Engine ECU→Diesel	8HZ BOSCH EDC16C3 EURO4	●	●	●	●
207VAN/207i	Engine/Gearbox	Engine ECU→Diesel	9HY BOSCH EDC16C3 EURO4	●	●	●	●
207VAN/207i			Built-in systems interface(BSI)	●	●	●	●
207VAN/207i	Engine/Gearbox	Engine ECU→Petrol	EDC17C10 BR2	●	●	●	●
207VAN/207i	Engine/Gearbox	Engine ECU→Petrol	NFU Or N6A ME749	●	●	●	●
207VAN/207i	Engine/Gearbox	Engine ECU→Petrol	KFW J34P	●	●	●	●
207VAN/207i	Engine/Gearbox	Engine ECU→Petrol	HFX J34P	●	●	●	●
207VAN/207i	Engine/Gearbox	Gearbox ECU	AL4 automatic gearbox	●	●	●	●
207VAN/207i	Inform the driver/Audio/Communication	Display/Telematics	RT3	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
207VAN/207i	Inform the driver/Audio/Communication	Display/Telematics	display	●	●	●	●
207VAN/207i	Driver information/Communication		Air conditioning	●	●	●	●
207VAN/207i	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
207VAN/207i	Inform the driver/Audio/Communication		Radio	●	●	●	●
207VAN/207i	Inform the driver/Audio/Communication		CD player	●	●	●	●
207VAN/207i	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
207VAN/207i	Vehicle protection/Management of		Alarm	●	●	●	○
207VAN/207i	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
3008 HYbrid4		Parking aid	ASS	●	●	●	●
3008 HYbrid4		ABS or ESP ECU	ESP81	●	●	●	●
3008 HYbrid4		Multifunction display	EMF A	●	●	●	●
3008 HYbrid4		Multifunction display	EMF C	●	●	●	●
3008 HYbrid4		Airbag	SAC AUTOLIV	●	●	●	●
3008 HYbrid4		Anti-theft alarm	ALARME	●	●	●	○
3008 HYbrid4		Radio amplifier	AMPLI AUDIO	●	●	●	●
3008 HYbrid4		Radio	AUTORADIO	●	●	●	●
3008 HYbrid4		Radio	RD45	●	●	●	●
3008 HYbrid4		Battery charge status unit	BECB GEN2	●	●	●	●
3008 HYbrid4		Built-in System Interface	BSI	●	●	●	●
3008 HYbrid4		MCP piloted manual gearbox(hybrid)	CFC300P_HY	●	●	●	●
3008 HYbrid4		Engine relay unit	BSM	●	●	●	●
3008 HYbrid4		Trailer relay unit	BSR	●	●	●	●
3008 HYbrid4		CD player	CHANGEUR CD	●	●	●	○
3008 HYbrid4		Air conditioning ECU	CLIM REGULEE	●	●	●	●
3008 HYbrid4		Instrument panel	COMBINE	●	●	●	●
3008 HYbrid4		Rain sensor	PLUIE LUMINOSITE	●	●	●	○
3008 HYbrid4		Power steering electric pump unit	GEP	●	●	●	●
3008 HYbrid4		Windscreen wiper	MOTEV	●	●	●	●
3008 HYbrid4		Electric sencondary brake	FSE	●	●	●	●
3008 HYbrid4		Switch module under the steering wheel (top of column)	HDC	●	●	●	●
3008 HYbrid4		Engine ECU	DCM35 HY	●	●	●	●
3008 HYbrid4		Hands-free kit (Telephone)	BOITIER NOMADE	●	●	●	●
3008 HYbrid4		Matrix screen integral to the instrument panel	MATT	●	●	●	●
3008 HYbrid4		Services module	MD SERV	●	●	●	●
3008 HYbrid4		Services module	BTA	●	●	●	●
3008 HYbrid4		Services module	BLVV	●	●	●	●
3008 HYbrid4		Multiplexed additive adding	PADDGO E5	●	●	●	●
3008 HYbrid4		Driver's door module	PDPC	●	●	●	●
3008 HYbrid4		Telematics	RADIONAV NG4	●	●	●	●
3008 HYbrid4		High Head Vision	VTH	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
3008 HYbrid4		Hybird mode selector	MCM	●	●	●	●
3008 HYbrid4		Traction battery ECU	TBMU	●	●	●	●
3008 HYbrid4		Hybrid control ECU 2	HCU2	●	●	●	●
3008 HYbrid4		Hybrid control ECU 1	HCU1	●	●	●	●
306R	Engine/automatic gearbox	Petrol	KFX BOSCH MP7.3		●	●	
306R	Engine/automatic gearbox	Petrol	LFY BOSCH MP7.3		●	●	
306R	Engine/automatic gearbox	Petrol	NFZ BOSCH MP7.2		●	●	
306R	Engine/automatic gearbox	Petrol	KFW SAGEM S2000	●		●	●
306R	Engine/automatic gearbox	Petrol	K6D SAGEM S2000	●		●	●
306R	Engine/automatic gearbox	AL4 automatic gearbox	AL4 automatic gearbox	●	●	●	●
306R	Engine/automatic gearbox	Petrol	NFT BOSCH M7.4.4	●	●	●	●
306R	Engine/automatic gearbox	Petrol	NFV BOSCH M7.4.4	●	●	●	●
306R	Engine/automatic gearbox	Diesel	RHY BOSCH EDC15C2	●	●	●	●
306R	Engine/automatic gearbox	Diesel	WJY LUCAS DCN2	●	●	●	●
306R	Engine/automatic gearbox	Diesel	WJZ LUCAS DCN2	●	●	●	●
306R	Active safety		ABS BOSCH 5.3	●	●	●	●
307CAN	Active and passive safety		Airbag ECU	●	●	●	●
307CAN	Active and passive safety	ABS or ESP ECU	ESP BOSCH8	●	●	●	●
307CAN	Engine/Gearbox	Petrol	NFU Or N6A Or N6B ME7.4.9	●	●	●	●
307CAN	Engine/Gearbox	Petrol	NFU Or N6A Or N6B ME7.4.9 BIO FLEX	●	●	●	●
307CAN	Engine/Gearbox	Petrol	RFK MM6LP	●	●	●	●
307CAN	Engine/Gearbox	Petrol	RFN MM6LP	●	●	●	●
307CAN	Engine/Gearbox	Petrol	RFJ MM6LPB	●	●	●	●
307CAN	Engine/Gearbox	Petrol	NFU BOSCH ME7.4.5	●	●	●	●
307CAN	Engine/Gearbox	Diesel	9HV BOSCH EDC16C3	●	●	●	●
307CAN	Driving assistance/Comfort		Under inflation detection	●	●	●	●
307CAN			Built-in systems interface(BSI)	●	●	●	●
307CAN	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
307CAN	Engine/Gearbox		Diesel fuel additive control unit	●	●	●	●
307CAN	Engine/Gearbox	Diesel	RHL DCM3.4	●	●	●	●
307CAN	Engine/Gearbox	Diesel	RHR DCM3.4	●	●	●	●
307CAN	Engine/Gearbox	Diesel	RHR SIEMENS SID 803	●	●	●	●
307CAN	Engine/Gearbox	Diesel	RHL SIEMENS SID 803	●	●	●	●
307CAN	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
307CAN	Visibility/Lighting/Signalling		Steering wheel switching module.	●	●	●	●
307CAN	Active and passive safety	ABS or ESP ECU	ABS8.1	●	●	●	●
307CAN	Active and passive safety	ABS or ESP ECU	ESP8.1	●	●	●	●
307CAN	Driving assistance/Comfort		Parking assistance	●	●	●	●
307CAN	Inform the driver/Audio/Communication		Telematics	●	●	●	●
307CAN	Engine/Gearbox	Petrol	RFJ MM6KP Bio Flex(EW10AFF)	●	●	●	●
307CAN	Engine/Gearbox		AM6 automatic gearbox	●	●	●	●
307CAN	Engine/Gearbox	Diesel	9HX BOSCH EDC16C3	●	●	●	●
307CAN	Engine/Gearbox	Diesel	9HZ BOSCH EDC16C3	●	●	●	●
307CAN	Engine/Gearbox	Diesel	9HT BOSCH EDC16C3	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
307CAN	Active and passive safety	ABS or ESP ECU	ABS8 BOSCH	●	●	●	●
307CAN	Engine/Gearbox	Petrol	KFU MM6LP	●	●	●	●
307CAN	Engine/Gearbox		AL4 automatic gearbox	●	●	●	●
307CAN	Engine/Gearbox	Petrol	N6A BOSCH ME7.4.5	●	●	●	●
307CAN	Engine/Gearbox	Petrol	N6B BOSCH ME7.4.5	●	●	●	●
307CAN	Driving assistance/Comfort		Air conditioning	●	●	●	●
307CAN	Driving assistance/Comfort		Power steering	●	●	●	●
307CAN	Inform the driver/Audio/Communication		Multi-function display	●	●	●	●
307CAN	Inform the driver/Audio/Communication		Radio	●	●	●	●
307CAN	Inform the driver/Audio/Communication		CD player	●	●	●	○
307CAN	Inform the driver/Audio/Communication		Hands Free Kit	●	●	●	●
307CAN	Engine/Gearbox	Petrol	RFU MM6LPC	●	●	●	●
307CAN	Engine/Gearbox	Diesel	RHY BOSCH EDC15C2	●	●	●	●
307CAN	Engine/Gearbox	Diesel	RHZ BOSCH EDC15C2	●	●	●	●
307CAN	Engine/Gearbox	Diesel	9HY BOSCH EDC15C3 EURO3	●	●	●	●
307CAN	Engine/Gearbox	Diesel	9HY BOSCH EDC15C3 EURO4	●	●	●	●
307CAN	Engine/Gearbox		Multiplexed additive adding pump	●	●	●	●
307CAN	Vehicle protection/Management of		Alarm	●	●	●	●
307CAN	Vehicle protection/Management of		Driver's door module	●	●	●	●
307CAN	Vehicle protection/Management of		Passenger door module	●	●	●	●
307CAN	Vehicle protection/Management of		Retractable roof	●	●	●	●
307CAN	Vehicle protection/Management of		Sun roof	●	●	●	●
307CAN	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
307CAN	Visibility/Lighting/Signalling		Right headlamp beam corrector	●	●	●	●
307CAN	Visibility/Lighting/Signalling		Left headlamp beam corrector	●	●	●	●
307CAN	Visibility/Lighting/Signalling		Driving school moduel	●	●	●	○
307VAN	Active safety		ABS BOSCH 5.3		●	●	
307VAN	Active safety		ABS BOSCH 8	●	●	●	●
307VAN	Engine/automatic gearbox	Petrol	N6A BOSCH ME7.4.4	●	●	●	●
307VAN	Engine/automatic gearbox	Petrol	NFU BOSCH ME7.4.4	●	●	●	●
307VAN	Engine/automatic gearbox	Petrol	KFW SAGEM S2000	●		●	●
307VAN	Engine/automatic gearbox	Petrol	K6D SAGEM S2000	●		●	●
307VAN	Engine/automatic gearbox	Petrol	KFU MM6LP	●	●	●	●
307VAN	Engine/automatic gearbox	Petrol	RFK MM6LP	●	●	●	●
307VAN	Engine/automatic gearbox	Petrol	RFN MM6LP	●	●	●	●
307VAN	Engine/automatic gearbox	Petrol	KFU MM6LP	●	●	●	●
307VAN	Engine/automatic gearbox	Petrol	RFK MM6LP	●	●	●	●
307VAN	Engine/automatic gearbox	Petrol	RFN MM6LP	●	●	●	●
307VAN	Driver information/Communication	Display/Telematics	RT3	●	●	●	●
307VAN	Engine/automatic gearbox	Petrol	N6A BOSCH ME7.4.5	●	●	●	●
307VAN	Engine/automatic gearbox	Petrol	NFU BOSCH ME7.4.5	●	●	●	●
307VAN	Engine/automatic gearbox		AL4 gearbox	●		●	●
307VAN			Built-in systems interface(BSI)	●	●	●	●
307VAN	Engine/automatic gearbox	Diesel	RHR SIEMENS SID 803	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
307VAN	Engine/automatic gearbox	Diesel	RHL SIEMENS SID 803	●	●	●	●
307VAN	Engine/automatic gearbox		Diesel fuel additive control unit	●	●	●	●
307VAN	Active safety		ESP BOSCH 5.7	●	●	●	●
307VAN	Active safety		ESP BOSCH 8	●	●	●	●
307VAN	Engine/automatic gearbox	Petrol	RFN MM48P (Mechanical throttle housing)	●	●	●	●
307VAN	Engine/automatic gearbox	Petrol	RFN MM4MP2 (Motorised butterfly)	●	●	●	●
307VAN			Alarm	●	●	●	●
307VAN	Driver information/Communication	Display/Telematics	AMF	●	●	●	●
307VAN	Driver information/Communication		Parking assistance	●	●	●	●
307VAN	Driver information/Communication		Radio	●	●	●	●
307VAN	Driver information/Communication		CD player	●	●	●	●
307VAN	Driver information/Communication		Instrument panel	●	●	●	●
307VAN	Driver information/Communication		Switch unit under steering wheel (COM 2000)	●	●	●	●
307VAN	Visibility/Lighting		Driving school	●	○	○	●
307VAN	Visibility/Lighting		Switch unit under steering wheel (COM 2000)	●	●	●	●
307VAN			Air bags	●	●	●	○
307VAN			Roll-over ECU	●	●	●	●
307VAN	Control the openings		Driver's door module	●	●	●	●
307VAN	Control the openings		Passenger door module	●	●	●	●
307VAN	Control the openings		Retractable roof	●	●	●	●
307VAN	Control the openings		Sun roof	●	●	●	●
307VAN			Air conditioning	●	●	●	●
307VAN	Engine/automatic gearbox	Diesel	8HZ BOSCH EDC16C3	●	●	●	●
307VAN	Engine/automatic gearbox	Diesel	9HX BOSCH EDC16C3	●	●	●	●
307VAN	Engine/automatic gearbox	Diesel	9HY BOSCH EDC16C3 EURO4	●	●	●	●
307VAN	Engine/automatic gearbox	Diesel	9HZ BOSCH EDC16C3	●	●	●	●
307VAN	Engine/automatic gearbox	Diesel	RHS BOSCH EDC15C2	●	●	●	●
307VAN	Engine/automatic gearbox	Diesel	RHY BOSCH EDC15C2	●	●	●	●
307VAN	Engine/automatic gearbox	Diesel	RHZ BOSCH EDC15C2	●	●	●	●
307VAN	Engine/automatic gearbox	Diesel	RHY SIEMENS SID 801	●	●	●	●
307VAN	Engine/automatic gearbox	Diesel	9HT BOSCH EDC16C3	●	●	●	●
307VAN			Electric pump unit (power steering)	●	●	●	●
308 4 portes		Multifunction display	EMF A	●	●	●	●
308 4 portes		Multifunction display	EMF C	●	●	●	●
308 4 portes		Anti-theft alarm		●	●	●	●
308 4 portes		Engine relay unit	BSM	●	●	●	●
308 4 portes		Rain and brightness sensor	PLUIE LUMINOSITE	●	●	●	○
308 4 portes		Injection/ignition	DCM3.5 BR2	●	●	●	●
308 4 portes		Injection/ignition	MED17 4 EURO4	●	●	●	●
308 4 portes		Injection/ignition	MEV17 4 EURO4	●	●	●	●
308 4 portes		Injection/ignition	ME749 EC5	●	●	●	●



Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
308 4 portes		Injection/ignition	MEV17 4 EURO5	●	●	●	●
308 4 portes		Injection/ignition	MED17 4 EURO5	●	●	●	●
308 4 portes		Injection/ignition	MED17 4 2	●	●	●	●
308 4 portes		Servces module	BLVV	●	●	●	●
308 4 portes		Telematics	RADIONAV RNEG ECO	●	●	●	●
308 4 portes		Telematics	RNEG2010	●	●	●	●
308 4 portes		Battery charge status unit	BECB GEN2	●	●	●	●
308 4 portes		Voltage retaining device	DMTC	●	○	○	○
406	Engines/automatic gearbox	Automatic gearbox	AL4 autoadaptive automatic gearbox	●	●	●	●
406	Air bags		Air bag and seat belt		●	●	
406	Air bags		Side airbag. (right side)		●	●	
406	Active safety		Electronically managed suspension		●	●	
406	Active safety		ABS BOSCH		●	●	
406	Active safety		ABS BOSCH 5.3	●	●	●	●
406	Engines/automatic gearbox	Petrol	LFX MM1AP		●	●	
406	Engines/automatic gearbox	Petrol	LFY BOSCH MP7.3		●	●	
406	Engines/automatic gearbox	Petrol	LFY SAGEM SL 96		●	●	
406	Engines/automatic gearbox	Petrol	XFZ BOSCH MP7.0		●	●	
406	Engines/automatic gearbox	Diesel	RHZ BOSCH EDC15C2	●	●	●	●
406	Engines/automatic gearbox	Diesel	RHZ BOSCH EDC15C2		●	●	●
406	Air bags		Side airbag. (left side)		●	●	
406 COUPE	Air bags		Air bag and seat belt		●	●	○
406 COUPE	Air bags		Side airbag. (right side)		●	●	○
406 COUPE	Active safety		BOSCH ABS5		●	●	
406 COUPE	Active safety		BOSCH ABS5.3		●	●	
406 COUPE	Engines/automatic gearbox	Automatic gearbox	AL4 autoadaptive automatic gearbox	●	●	●	●
406 COUPE	Air bags		Side airbag. (left side)		●	●	○
406R/406R COUPE	Engine/automatic gearbox	Diesel	4HX BOSCH EDC15C2		●	●	
406R/406R COUPE	Engine/automatic gearbox	Diesel	RHY BOSCH EDC15C2		●	●	
406R/406R COUPE	Engine/automatic gearbox	Diesel	RHZ BOSCH EDC15C2		●	●	
406R/406R COUPE	Engine/automatic gearbox	Diesel	RHS BOSCH EDC15C2	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox		Diesel fuel additive control unit	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Petrol	R6F MM4.8P	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Petrol	RFN MM4.8P	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Automatic gearbox	AL4 autoadaptive automatic gearbox	●		●	●
406R/406R COUPE	Engine/automatic gearbox	Petrol	6FZ SAGEM S2000	●		●	●
406R/406R COUPE	Engine/automatic gearbox	Petrol	6FZ SAGEM S2000	●		●	●
406R/406R COUPE	Engine/automatic gearbox	Petrol	XFX BOSCH ME7.4.6	●		●	●
406R/406R COUPE	Engine/automatic gearbox	Petrol	3FZ MM4MP2	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Petrol	6FZ SAGEM S2000	●			●
406R/406R COUPE	Engine/automatic gearbox	Petrol	RLZ SIEMENS SIRIUS 81	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Petrol	LFY BOSCH MP7.3		●	●	
406R/406R COUPE	Engine/automatic gearbox	Petrol	R6F MM4.8P	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Petrol	RFR MM4.8P	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
406R/406R COUPE	Engine/automatic gearbox	Petrol	RFN MM4. 8P	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Petrol	XFZ BOSCH ME7. 4. 6	●		●	●
406R/406R COUPE			Built-in systems interface(BSI)		●	●	●
406R/406R COUPE	Driver information/Communication		Multi-function display	●	●	●	●
406R/406R COUPE	Driver information/Communication		Radio	●	●	●	●
406R/406R COUPE	Driver information/Communication		CD player	●	●	●	●
406R/406R COUPE	Driver information/Communication		Instrument panel		●	●	
406R/406R COUPE	Driver information/Communication		On-board navigation system	●	●	●	●
406R/406R COUPE	Air bags		Air bag and seat belt		●	●	○
406R/406R COUPE	Air bags		Side airbag. (right side)		●	●	○
406R/406R COUPE			Air conditioning		●	●	
406R/406R COUPE	Engine/automatic gearbox	Automatic gearbox	4HP20 automatic gearbox	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Petrol	3FZ MM4MP2	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Petrol	RLZ IDE SIRIUS 81	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Diesel	4HX BOSCH EDC15C2	●	●	●	●
406R/406R COUPE			Built-in systems interface(BSI)	●	●	●	●
406R/406R COUPE			Alarm	●	●	●	●
406R/406R COUPE	Driver information/Communication		Multi-function display	●	●	●	●
406R/406R COUPE	Driver information/Communication		Instrument panel	●	●	●	●
406R/406R COUPE	Driver information/Communication		Radio	●	●	●	●
406R/406R COUPE	Driver information/Communication		CD player	●	●	●	●
406R/406R COUPE	Driver information/Communication		On-board navigation system	●	●	●	●
406R/406R COUPE	Driver information/Communication		Switch unit under steering wheel(COM 2000)	●	●	●	●
406R/406R COUPE	Visibility /lighting		Rain/brightness sensor	●	●	●	○
406R/406R COUPE			Air bags	●	●	●	○
406R/406R COUPE			Air conditioning	●	●	●	●
406R/406R COUPE	Air bags		Side airbag. (left side)		●	●	○
406R/406R COUPE	Engine/automatic gearbox		Diesel fuel additive control unit	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Automatic gearbox	4HP20 automatic gearbox	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Automatic gearbox	AL4 autoadaptive automatic gearbox	●		●	●
406R/406R COUPE	Active safety		ABS BOSCH 5.3	●	●	●	●
406R/406R COUPE	Active safety		ABS BOSCH 5.3	●	●	●	●
406R/406R COUPE	Engine/automatic gearbox	Diesel	RHY SIEMENS SID 801	●	●	●	●
508/508HY/508RXH		Airbag	RBG UDS	●	●	●	●
508/508HY/508RXH		gearbox	BVA AM6 AT6 EURO5	●	●	●	●
508/508HY/508RXH		ABS/traction control	ABS81	●	●	●	●
508/508HY/508RXH		Engine ECU	DCM35 BR2	●	●	●	●
508/508HY/508RXH		gearbox	CFC300P HY	●	●	●	●
508/508HY/508RXH		gearbox	CFC300P	●	●	●	●
508/508HY/508RXH		Engine ECU	MED17 4 2	●	●	●	●
508/508HY/508RXH		Engine ECU	MEV17 4 2	●	●	●	●
508/508HY/508RXH		Engine ECU	MM6KP	●	●	●	●
508/508HY/508RXH		Engine ECU	DCM35 HY	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
508/508HY/508RXH		Engine ECU	DCM34 P	●	●	●	●
508/508HY/508RXH		Engine ECU	HDI SID807 BR2	●	●	●	●
508/508HY/508RXH		Engine ECU	EDC17CP42	●	●	●	●
508/508HY/508RXH		ABS/traction control	81 ESP	●	●	●	●
508/508HY/508RXH		Electric sencondary brake	FSE	●	●	●	●
508/508HY/508RXH		Under inflation detection	DSG	●	●	●	●
508/508HY/508RXH		Built-in System Interface(BSI)	BSI2010	●	●	●	●
508/508HY/508RXH		Switch module under the steering wheel (top of column)	COM2008P	●	●	●	●
508/508HY/508RXH		Electric steering lock	AVE	●	●	●	●
508/508HY/508RXH		Additional heating	CHAUFF ADD	●	●	●	●
508/508HY/508RXH		Active damper electronic unit	BEBA	●	●	●	●
508/508HY/508RXH		Air conditioning	CLIM REGULEE UDS	●	●	●	●
508/508HY/508RXH		Anti-thdft alarm	ALARME	●	●	●	●
508/508HY/508RXH		Battery charge status unit	BECB GEN2	●	●	●	●
508/508HY/508RXH		Data communication ECU (RT6)	RT6	●	●	●	●
508/508HY/508RXH		Discharger bulbs vertical and horizontal adjustment	LADCT	●	●	●	●
508/508HY/508RXH		Driver's seat memorizing unit	BDMC	●	●	●	●
508/508HY/508RXH		Electronic key reader	LCE	●	●	●	●
508/508HY/508RXH		Engine relay unit	BSM 2010	●	●	●	●
508/508HY/508RXH		Hands-free control unit	BML	●	●	●	●
508/508HY/508RXH		High Head Vision	VTH UDS	●	●	●	●
508/508HY/508RXH		Hybird mode selector	MCM	●	●	●	●
508/508HY/508RXH		Hybrid control ECU 1	HCU1	●	●	●	●
508/508HY/508RXH		Hybrid control ECU 2	HCU2	●	●	●	●
508/508HY/508RXH		Independent telematic unit	BTA	●	●	●	●
508/508HY/508RXH		Instrument panel	COMBINE UDS	●	●	●	●
508/508HY/508RXH		Main beams assistant ECU	RETRO INT	●	●	●	●
508/508HY/508RXH		Matrix screen integral to the instrument panel	MATT_C_2010	●	●	●	○
508/508HY/508RXH		Matrix screen integral to the instrument panel	MATT_M_2010	●	●	●	○
508/508HY/508RXH		Motorised Boot ECU	COFFRE MOTORISE	●	●	●	●
508/508HY/508RXH		Multifunction screen	EMF A UDS	●	●	●	○
508/508HY/508RXH		Multifunction screen	EMF C UDS	●	●	●	○
508/508HY/508RXH		Multiplexed control panel	FMUX	●	●	●	●
508/508HY/508RXH		Parking assistance	AAS UDS	●	●	●	●
508/508HY/508RXH		PLATINE DE PORTE	PDPF	●	●	●	●
508/508HY/508RXH		Power steering electric pump unit	GEP	●	●	●	●
508/508HY/508RXH		Radio amplifier	AMPLI AUDIO	●	●	●	○
508/508HY/508RXH		Rain and brightness	PLUIE LUMINOSITE UDS	●	●	●	●
508/508HY/508RXH		RD5 radio	RD5	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
508/508HY/508RXH		Rear air conditioning	CLIM AR	●	○	○	●
508/508HY/508RXH		Seat belts not fastened LED unit (TNB)	TNB_2010	●	○	○	○
508/508HY/508RXH		Steering wheel with integral controls (VCI)	VCI	●	●	●	●
508/508HY/508RXH		Supply protection and management unit	BPGA2010	●	●	●	●
508/508HY/508RXH		Telematic navigator	CRT UDS	●	○	○	●
508/508HY/508RXH		Traction battery ECU	TBMU	●	●	●	●
508/508HY/508RXH		Trailer relay unit	BSG 2010 RQ	●	●	●	●
508/508HY/508RXH		Voltage retaining device	DMTC	●	○	○	○
508/508HY/508RXH		Widscreen wiper(left-hand	MOTEV UDS	●	●	●	●
508/508HY/508RXH		Windscreen wiper(right-hand side)	MOTED_UDS	●	●	●	●
607	Engine/automatic gearbox	Petrol	3FZ MM4MP2	●	●	●	●
607	Engine/automatic gearbox	Petrol	RFN MM4MP2 (Motoresed butterfly)	●	●	●	●
607	Engine/automatic gearbox	Petrol	RFN MM48P (Mechanical throttle housing)	●	●	●	●
607	Engine/automatic gearbox	Petrol	R6F mm4.8P	●	●	●	●
607	Engine/automatic gearbox	Petrol	XFX BOSCH ME7.4.6	●		●	●
607			Built-in systems interface (BSI)	●	●	●	●
607	Driver information/Communication		Multi-function display		●	●	
607	Driver information/Communication		Parking assistance	●	●	●	●
607	Driver information/Communication		Radio	●	●	●	●
607	Driver information/Communication		CD player	●	●	●	●
607	Driver information/Communication		Instrument panel	●	●	●	●
607	Driver information/Communication		Radio telephone	●	●	●	●
607	Driver information/Communication		Hands Free Kit		●	●	
607	Driver information/Communication		On-board navigation system	●	●	●	●
607	Visibility/Lighting		Headlamp height corrector		●	●	
607			Air bags	●	●	●	○
607	Control the openings		Motorised Boot ECU	●	●	●	●
607	Control the openings		Driver's door control panel		●	●	
607	Control the openings		Passenger's door control panel		●	●	
607			Air conditioning		●	●	
607	Engine/automatic gearbox	Diesel	4HX BOSCH EDC15C2	●	●	●	●
607	Engine/automatic gearbox	Diesel	RHS BOSCH EDC15C2	●	●	●	●
607	Engine/automatic gearbox	Diesel	RHZ BOSCH EDC15C2	●	●	●	●
607	Engine/automatic gearbox		Diesel fuel additive control unit	●	●	●	●
607	Engine/automatic gearbox		4HP20 gearbox	●	●	●	●
607			Storing of the driving position	●	●	●	●
607	Active safety		ABS BOSCH 5.3	●	●	●	●
607R	Driving assistance/Comfort		Under inflation detection	●	●	●	●
607R			Built-in systems interface (BSI)	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
607R	Engine/Gearbox		Diesel fuel additive control unit	●	●	●	●
607R	Engine/Gearbox	Diesel	UHZ SIEMENS SID 803	●	●	●	●
607R	Engine/Gearbox	Diesel	RHL SIEMENS SID 803	●	●	●	●
607R	Engine/Gearbox	Diesel	4HP BOSCH EDC16CP39	●	●	●	●
607R	Engine/Gearbox	Diesel	4HR BOSCH EDC16CP39	●	●	●	●
607R	Engine/Gearbox	Diesel	4HS BOSCH EDC16CP39	●	●	●	●
607R	Engine/Gearbox	Diesel	4HT BOSCH EDC16CP39	●	●	●	●
607R	Engine/Gearbox	Diesel	UHZ SIEMENS SID 201	●	●	●	●
607R	Active and passive safety		ESP BOSCH8	●	●	●	●
607R	Engine/Gearbox	Petrol	3FZ MM6LP	●	●	●	●
607R	Driving assistance/Comfort		Parking assistance	●	●	●	●
607R	Driving assistance/Comfort		Drivers seat memory unit	●	●	●	●
607R	Driving assistance/Comfort		Air conditioning	●	●	●	●
607R	Driving assistance/Comfort		Power steering	●	●	●	●
607R	Driving assistance/Comfort		Controlled suspension	●	●	●	●
607R	Inform the driver/Audio/Communication		Multi-function display	●	●	●	●
607R	Inform the driver/Audio/Communication		Radio	●	●	●	●
607R	Inform the driver/Audio/Communication		CD player	●	●	●	○
607R	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
607R	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
607R	Inform the driver/Audio/Communication		Hands Free Kit	●	●	●	●
607R	Inform the driver/Audio/Communication		Telematics	●	●	●	●
607R	Engine/Gearbox		AM6 automatic gearbox	●	●	●	●
607R	Engine/Gearbox		4HP20 automatic gearbox	●	●	●	●
607R	Engine/Gearbox	Petrol	XFV ME747	●	●	●	●
607R	Engine/Gearbox	Petrol	3FY MM6LPB	●	●	●	●
607R	Engine/Gearbox	Diesel	4HX BOSCH EDC15C2	●	●	●	●
607R	Engine/Gearbox	Diesel	RHS BOSCH EDC15C2	●	●	●	●
607R	Vehicle protection/Management of		Alarm	●	●	●	●
607R	Vehicle protection/Management of		Motorised Boot ECU	●	●	●	●
607R	Vehicle protection/Management of		Driver's door module	●	●	●	●
607R	Vehicle protection/Management of		Passenger door module	●	●	●	●
607R	Active and passive safety		Airbag ECU	●	●	●	●
607R	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
607R	Visibility/Lighting/Signalling		Automatic headlamps corrector	●	●	●	●
607R	Visibility/Lighting/Signalling		Steering wheel switching module.	●	●	●	●
807CAN	Driving assistance/Comfort		Under inflation detection	●	●	●	●
807CAN			Built-in systems interface(BSI)	●	●	●	●
807CAN	Engine/Gearbox	Diesel	RHR SIEMENS SID 803	●	●	●	●
807CAN	Engine/Gearbox	Diesel	RHL SIEMENS SID 803	●	●	●	●
807CAN	Engine/Gearbox	Diesel	RHK SIEMENS SID 803	●	●	●	●
807CAN	Engine/Gearbox		Diesel fuel additive control unit	●	●	●	●
807CAN	Engine/Gearbox	Diesel	DCM3.5	●	●	●	●
807CAN	Engine/Gearbox	Diesel	4HP EDC16CP39	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
807CAN	Engine/Gearbox	Diesel	4HR EDC16CP39	●	●	●	●
807CAN	Engine/Gearbox	Diesel	4HS EDC16CP39	●	●	●	●
807CAN	Engine/Gearbox	Diesel	4HT EDC16CP39	●	●	●	●
807CAN	Active and passive safety	ABS or ESP ECU	ESP 8.1	●	●	●	●
807CAN	Active and passive safety	ABS or ESP ECU	ESP BOSCH8	●	●	●	●
807CAN	Engine/Gearbox	Petrol	RFJMM6LPB	●	●	●	●
807CAN	Engine/Gearbox	BVA AL4	AL4 Automatic gearbox	●	●	●	●
807CAN	Engine/Gearbox	BVA AM6C	AM6C Automatic gearbox	●	●	●	●
807CAN	Engine/Gearbox	Diesel	4HW BOSCH EDC15C2	●	●	●	●
807CAN	Engine/Gearbox	Diesel	RHM BOSCH EDC15C2	●	●	●	●
807CAN	Engine/Gearbox	Diesel	RHT BOSCH EDC15C2	●	●	●	●
807CAN	Engine/Gearbox	Diesel	RHW BOSCH EDC15C2	●	●	●	●
807CAN	Driving assistance/Comfort		Parking assistance	●	●	●	●
807CAN	Driving assistance/Comfort		Additional heating	●	●	●	●
807CAN	Driving assistance/Comfort		Drivers seat memory unit	●	●	●	●
807CAN	Driving assistance/Comfort		Air conditioning	●	●	●	●
807CAN	Driving assistance/Comfort		Power steering	●	●	●	●
807CAN	Inform the driver/Audio/Communication		Multi-function display	●	●	●	●
807CAN	Inform the driver/Audio/Communication		Radio	●	●	●	●
807CAN	Inform the driver/Audio/Communication		Warning lights/odometer unit	●	●	●	●
807CAN	Inform the driver/Audio/Communication		CD player	●	●	●	○
807CAN	Inform the driver/Audio/Communication		Telematic receiver control	●	○	○	●
807CAN	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
807CAN	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
807CAN	Inform the driver/Audio/Communication		Hands Free Kit	●	●	●	●
807CAN	Inform the driver/Audio/Communication	Telematics	Data communication ECU	●	●	●	●
807CAN	Inform the driver/Audio/Communication	Telematics	RNEG radio navigation	●	●	●	●
807CAN	Vehicle protection/Management of		Alarm	●	●	●	●
807CAN	Vehicle protection/Management of		Driver's door module	●	●	●	●
807CAN	Vehicle protection/Management of		Passenger door module	●	●	●	●
807CAN	Vehicle protection/Management of		Front sunroof	●	●	●	●
807CAN	Vehicle protection/Management of		Rear sunroof	●	●	●	●
807CAN	Vehicle protection/Management of		Middle sunroof	●	●	●	●
807CAN	Active and passive safety		Airbag ECU	●	●	●	●
807CAN	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
807CAN	Visibility/Lighting/Signalling		Right headlamp beam corrector	●	●	●	●
807CAN	Visibility/Lighting/Signalling		Left headlamp beam corrector	●	●	●	●
807CAN	Visibility/Lighting/Signalling		Steering wheel switching module.	●	●	●	●
807CAN	Vehicle protection/Management of		Sliding side door module	●	●	●	●
807VAN			Built-in systems interface(BSI)	●	●	●	●
807VAN			Alarm	●	●	●	●
807VAN	Driver information/Communication	Display/Telematics	AMF	●	●	●	●
807VAN	Driver information/Communication	Display/Telematics	RT3	●	●	●	●
807VAN	Driver information/Communication		Radio/telematic receiver control	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
807VAN	Driver information/Communication		Parking assistance	●	●	●	●
807VAN	Driver information/Communication		Warning lights and odometer ECU	●	●	●	●
807VAN	Driver information/Communication		Instrument panel	●	●	●	●
807VAN	Driver information/Communication		CD player	●	●	●	●
807VAN	Driver information/Communication		Switch unit under steering wheel(COM 2000)	●	●	●	●
807VAN	Visibility/Lighting		Switch unit under steering wheel(COM 2000)	●	●	●	●
807VAN	Visibility/Lighting		Right headlamp beam corrector	●	●	●	●
807VAN	Visibility/Lighting		Left headlamp beam corrector	●	●	●	●
807VAN			Air bags	●	●	●	●
807VAN	Control the openings		Driver's door module	●	●	●	●
807VAN	Control the openings		Passenger door module	●	●	●	●
807VAN	Control the openings		Sliding door module	●	●	●	●
807VAN	Control the openings		Front sunroof	●	●	●	●
807VAN	Control the openings		Rear sunroof	●	●	●	●
807VAN	Control the openings		Middle sunroof	●	●	●	●
807VAN	Air conditioning		Climate control	●	●	●	●
807VAN			Storing of the driving position	●	●	●	●
807VAN			Additional heating	●	●	●	●
807VAN	Engines/automatic gearbox	Petrol	RFN MM48P (Mechanical throttle housing)	●	●	●	●
807VAN	Engines/automatic gearbox	Petrol	R6F MM4. 8P	●	●	●	●
807VAN	Engines/automatic gearbox	Petrol	3FZ MM4MP2	●	●	●	●
807VAN	Engines/automatic gearbox	Petrol	RFN MM4MP2 (Motorised butterfly)	●	●	●	●
807VAN	Engines/automatic gearbox	Petrol	3FZ MM6LP	●	●	●	●
807VAN	Engines/automatic gearbox	Petrol	RFN MM6LP	●	●	●	●
807VAN	Engines/automatic gearbox	Petrol	XFW BOSCH ME746	●		●	●
807VAN	Engines/automatic gearbox	Diesel	RHW BOSCH EDC15C2	●	●	●	●
807VAN	Engines/automatic gearbox	Diesel	RHM BOSCH EDC15C2	●	●	●	●
807VAN	Engines/automatic gearbox	Diesel	RHT BOSCH EDC15C2	●	●	●	●
807VAN	Engines/automatic gearbox	Diesel	4HW BOSCH EDC15C2	●	●	●	●
807VAN	Engines/automatic gearbox		Diesel fuel additive control unit:ADDITIF FAP	●	●	●	●
807VAN	Engines/automatic gearbox		Diesel fuel additive control unit:ADDGO2	●	●	●	●
807VAN	Engines/automatic gearbox	Automatic gearbox	4HP20 automatic gearbox	●	●	●	●
807VAN	Engines/automatic gearbox	Automatic gearbox	AL4 automatic gearbox	●		●	●
807VAN	Active safety		ABR BOSCH 5.7	●	●	●	●
807VAN	Active safety		ESP BOSCH 5.7	●	●	●	●
BIPPER	Engine / Gearbox	Engine ECU/Diesel	HDI 8DF2	●	●	●	●
BIPPER	Driving assistance/Comfort		Parking assistance	●	●	●	●
BIPPER			Built-in system interface(BSI)	●	●	●	●
BIPPER	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
BIPPER	Engine / Gearbox	Engine ECU/Petrol	KFV V34P	●	●	●	●
BIPPER	Engine / Gearbox	Engine ECU/Diesel	8HS EDC16C34	●	●	●	●
BIPPER	Engine / Gearbox	Gearbox	BVMP	●	●	●	●
BIPPER	Active and passive safety		Control unit ABS	●	●	●	●
BIPPER	Active and passive safety		Air-bag	●	●	●	●
BOXER 3	Engine/Gearbox		EDC17CP52	●	●	●	●
BOXER 3	Engine/Gearbox		EDC17CP52	●	●	●	●
BOXER 3	Active and passive safety	ABS or ESP ECU	ESP8.0	●	●	●	●
BOXER 3	Engine/Gearbox		4HU PUMA DCU102	●	●	●	●
BOXER 3	Engine/Gearbox		4HV PUMA DCU102	●	●	●	●
BOXER 3	Driving assistance/Comfort		Additional heating	●	●	●	●
BOXER 3	Driving assistance/Comfort		Power steering	●	●	●	●
BOXER 3	Inform the driver/Audio/Communication		Chronotachograph	●	●	●	●
BOXER 3			Built-in systems interface(BSI)	●	●	●	●
BOXER 3	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
BOXER 3	Inform the driver/Audio/Communication		Telematic	●	●	●	●
BOXER 3	Active and passive safety		Airbag ECU	●	●	●	●
BOXER 3	Driving assistance / comfort		Parking assistance	●	●	●	●
BOXER 3	Driving assistance / comfort		Pneumatic suspension	●	●	●	●
BOXER 3 Minibus	Active and passive safety	ABS or ESP ECU	ESP8.0	●	●	●	●
BOXER 3 Minibus	Engine/Gearbox		4HU PUMA DCU102	●	●	●	●
BOXER 3 Minibus	Engine/Gearbox		4HV PUMA DCU102	●	●	●	●
BOXER 3 Minibus	Driving assistance/Comfort		Additional heating	●	●	●	●
BOXER 3 Minibus	Driving assistance/Comfort		Power steering	●	●	●	●
BOXER 3 Minibus	Inform the driver/Audio/Communication		Chronotachograph	●	●	●	●
BOXER 3 Minibus			Built-in systems interface(BSI)	●	●	●	●
BOXER 3 Minibus	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
BOXER 3 Minibus	Inform the driver/Audio/Communication		Telematic	●	●	●	●
BOXER 3 Minibus	Active and passive safety		Airbag ECU	●	●	●	●
BOXER 3 Minibus	Driving assistance / comfort		Parking assistance	●	●	●	●
BOXER 3 Minibus	Driving assistance / comfort		Pneumatic suspension	●	●	●	●
BOXER U5	Air conditioning		WEBASTO additional teating	●			●
BOXER U5	Engines/automatic gearbox	Petrol	MM4.8P 2L Unleaded petrol	●	●	●	●
BOXER U5	Engines/automatic gearbox	Petrol	MM48P 2L essence plombee	●	●	●	●
BOXER U5	Engines/automatic gearbox	Petrol	MM48P 2L dual fuel(LPG)	●	●	●	●
BOXER U5	Engines/automatic gearbox	Diesel	2.0L Bosch EDC15C7	●	●	●	●
BOXER U5	Engines/automatic gearbox	Diesel	2.2L Bosch EDC15C7	●	●	●	●
BOXER U5	Engines/automatic gearbox	Diesel	2.8L Bosch EDC15C7	●	●	●	●
BOXER U5	Engines/automatic gearbox		4HP20 automatic gearbox	●			●
EXPERT	Engine/automatic gearbox		AL4 autoadaptive automatic gearbox	●		●	●
EXPERT	Air bags		Air bag and seat belt	●		●	
EXPERT	Engine/automatic gearbox	Petrol	R6F MM4.8P	●	●	●	●
EXPERT	Engine/automatic gearbox	Petrol	RFN MM4.8P	●	●	●	●
EXPERT	Engine/automatic gearbox	Diesel	RHW BOSCH EDC15C2	●	●	●	●



Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
EXPERT	Engine/automatic gearbox	Diesel	RHX BOSCH EDC15C2	●	●	●	●
EXPERT	Engine/automatic gearbox	Diesel	RHZ BOSCH EDC15C2	●	●	●	●
EXPERT	Engine/automatic gearbox	Diesel	WJY LUCAS DCN2	●	●	●	●
EXPERT	Active safety		BOSCH ABS5.3	●	●	●	●
EXPERT			Additional heating	●	●	●	●
EXPERT 2			Built-in systems interface(BSI)	●	●	●	●
EXPERT 2	Engine/Gearbox	Diesel	RHR SIEMENS SID 803	●	●	●	●
EXPERT 2	Engine/Gearbox	Diesel	RHL SIEMENS SID 803	●	●	●	●
EXPERT 2	Engine/Gearbox	Diesel	RHK SIEMENS SID 803	●	●	●	●
EXPERT 2	Engine/Gearbox	Diesel	RHG SIEMENS SID 803	●	●	●	●
EXPERT 2	Engine/Gearbox	Diesel	DCM3.5	●	●	●	●
EXPERT 2	Active and passive safety	ABS or ESP ECU	ABS8 BOSCH	●	●	●	●
EXPERT 2	Active and passive safety	ABS or ESP ECU	ESP BOSCH8	●	●	●	●
EXPERT 2	Engine/Gearbox	Petrol	RFH MM6KP	●	●	●	●
EXPERT 2	Driving assistance/Comfort		Parking assistance	●	●	●	●
EXPERT 2	Driving assistance/Comfort		Additional heating	●	●	●	●
EXPERT 2	Driving assistance/Comfort	Air conditioning	Air conditioning / Front air conditioning	●	●	●	●
EXPERT 2	Driving assistance/Comfort	Air conditioning	Rear air conditioning	●	●	●	●
EXPERT 2	Driving assistance/Comfort		Power steering	●	●	●	●
EXPERT 2	Driving assistance/Comfort		Pneumatic suspension	●	●	●	●
EXPERT 2	Inform the driver/Audio/Communication		Multi-function display	●	●	●	●
EXPERT 2	Inform the driver/Audio/Communication		Radio	●	●	●	●
EXPERT 2	Inform the driver/Audio/Communication		CD player	●	●	●	○
EXPERT 2	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
EXPERT 2	Inform the driver/Audio/Communication		Hands Free Kit	●	●	●	●
EXPERT 2	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
EXPERT 2	Inform the driver/Audio/Communication	Telematics	Data communication ECU	●	●	●	●
EXPERT 2	Inform the driver/Audio/Communication	Telematics	RNEG radio navigation	●	●	●	●
EXPERT 2	Engine/Gearbox	Diesel	9HU BOSCH EDC16C3-EDC16C34	●	●	●	●
EXPERT 2	Engine/Gearbox	Diesel	9HT BOSCH EDC16C3	●	●	●	●
EXPERT 2	Vehicle protection/Management of		Alarm	●	●	●	●
EXPERT 2	Active and passive safety		Airbag ECU	●	●	●	●
EXPERT 2	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
EXPERT 2	Visibility/Lighting/Signalling		Steering wheel switching module.	●	●	●	●
EXPERT 2	Active and passive safety	ABS or ESP ECU	ABS8.1	●	●	●	●
EXPERT 2	Active and passive safety	ABS or ESP ECU	ESP8.1	●	●	●	●
EXPERT 3		Multifunction display	EMF A	●	●	●	●
EXPERT 3		Multifunction display	EMF C	●	●	●	●
EXPERT 3		Driver and passenger airbags	SAC AUTOLIV	●	●	●	●
EXPERT 3		Anti-thdft alarm	ALARME	●	●	●	●
EXPERT 3		Radio	AUTORADIO	●	●	●	●
EXPERT 3		Engine relay unit	BSM	●	●	●	●
EXPERT 3		Trailer relay unit	BSR	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
EXPERT 3		Engine ECU	DCM3.5 BR2	●	●	●	●
EXPERT 3		Engine ECU	EDC17C10 BR2	●	●	●	●
EXPERT 3		Hands-free kit (Telephone)	KML	●	●	●	●
EXPERT 3		Bodywork conversion unit	BTC	●	●	●	●
EXPERT 3		Type Under-Inflation Detection	DSG	●	●	●	●
EXPERT 3		gearbox	BVA AM6 AT6 EURO5	●	●	●	●
EXPERT 3		High frequency receiver	RHF	●	●	●	●
EXPERT 3		Anti-slip mode selector	ASR	●	●	●	●
ION		Instrument panel	METER	●	●	●	●
ION		Built-in System Interface	ETACS	●	●	●	●
ION		Electric motor ECU	MCU	●	●	●	●
ION		Traction battery ECU	BMU	●	●	●	●
ION		Onboard charger of the tratction barrery		●	●	●	●
ION		Electric vehicle management	EV ECU	●	●	●	●
ION		Traction battery cell electronics 01	CMU_01	●	○	○	●
ION		Traction battery cell electronics 02	CMU_02	●	○	○	●
ION		Traction battery cell electronics 03	CMU_03	●	○	○	●
ION		Traction battery cell electronics 04	CMU_04	●	○	○	●
ION		Traction battery cell electronics 05	CMU_05	●	○	○	●
ION		Traction battery cell electronics 06	CMU_06	●	○	○	●
ION		Traction battery cell electronics 07	CMU_07	●	○	○	●
ION		Traction battery cell electronics 08	CMU_08	●	○	○	●
ION		Traction battery cell electronics 09	CMU_09	●	○	○	●
ION		Traction battery cell electronics 10	CMU_10	●	○	○	●
ION		Traction battery cell electronics 11	CMU_11	●	○	○	●
ION		Traction battery cell electronics 12	CMU_12	●	○	○	●
ION		ESP	ASC	●	●	●	●
ION		Power steering	EPS	●	●	●	●
ION		Steering wheel angle sensor	SAS	●	●	●	●
ION		Airbag	SRS	●	●	●	●
ION		Gateway wiring housing	BSP	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
ION		Independent telematic unit	BTA	●	●	●	●
ION		Radio	RDE	●	●	●	●
ION		Air conditioning	HVAC	●	●	●	●
ION		Air conditioning compressor and passeger compartment heating control module	COMP_HTR	●	●	●	●
PARTNER	engines/automatic gearbox	Diesel	9HW BOSCH EDC16C3	●	●	●	●
PARTNER	engines/automatic gearbox	Diesel	9HX BOSCH EDC16C3	●	●	●	●
PARTNER	engines/automatic gearbox	Diesel	9HT BOSCH EDC16C3	●	●	●	●
PARTNER	Active safety		ESP 8.1	●	●	●	●
PARTNER	Active safety		ESP BOSCH 5.7	●	●	●	●
PARTNER	Active safety		ESP BOSCH 8	●	●	●	●
PARTNER	Engines/automatic gearbox	Petrol	HFX BOSCH M7.4.4	●	●	●	●
PARTNER	Engines/automatic gearbox	Petrol	KFW SAGEM S2000	●		●	●
PARTNER			Built-in systems interface(BSI)		●	●	
PARTNER	Driver information/Communication		Radio PHILIPS		●	●	
PARTNER	Driver information/Communication		Radio CLARION		●	●	
PARTNER	Driver information/Communication		CD player	●	●	●	●
PARTNER	Driver information/Communication		Instrument panel	●	●	●	●
PARTNER	Air bags		Air bag and seat belt		●	●	○
PARTNER	Engines/automatic gearbox	Petrol	HDY BOSCH MA3.1	●	●	●	●
PARTNER			Additional heating	●	●	●	●
PARTNER	driving assistance / Comfort		Parking assistance	●	●	●	●
PARTNER	driving assistance / Comfort		Additional heating	●	●	●	●
PARTNER			Built-in systems interface(BSI)	●	●	●	●
PARTNER			Alarm	●	●	●	●
PARTNER	Driver information/Communication	Display/Telematics	AMF	●	●	●	●
PARTNER	Driver information/Communication	Display/Telematics	RT3	●	●	●	●
PARTNER	Driver information/Communication		radio	●	●	●	●
PARTNER	Driver information/Communication		CD player	●	●	●	●
PARTNER	Driver information/Communication		Instrument panel	●	●	●	●
PARTNER	Driver information/Communication		steering wheel switching module.	●	●	●	●
PARTNER			air bags	●	●	●	○
PARTNER	Visibility/Lighting/Signalling		Steering wheel switching module.	●	●	●	●
PARTNER	Visibility/Lighting/Signalling		Rain/brightness sensor	●	●	●	○
PARTNER	Engines/automatic gearbox	Petrol	K6D SAGEM S2000	●		●	●
PARTNER	Engines/automatic gearbox	Petrol	KFX BOSCH MP7.3		●	●	
PARTNER	Engines/automatic gearbox	Petrol	N6A BOSCH ME7.4.4	●	●	●	●
PARTNER	Engines/automatic gearbox	Petrol	NFU BOSCH ME7.4.4	●	●	●	●
PARTNER	Engines/automatic gearbox	Petrol	N6A BOSCH ME7.4.5	●	●	●	●
PARTNER	Engines/automatic gearbox	Petrol	N6B BOSCH ME7.4.5	●	●	●	●
PARTNER	Engines/automatic gearbox	Petrol	NFU BOSCH ME7.4.5	●	●	●	●
PARTNER	Engines/automatic gearbox	Diesel	RHY BOSCH EDC15C2	●	●	●	●
PARTNER	Engines/automatic gearbox	Diesel	WJY LUCAS DCN2	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
PARTNER	Engines/automatic gearbox	Diesel	WJZ LUCAS DCN2	●	●	●	●
PARTNER	engines/automatic gearbox	Petrol	HFX MM4. 8P	●	●	●	●
PARTNER	engines/automatic gearbox	Petrol	KFW SAGEM S2000PM1	●	●	●	●
PARTNER	engines/automatic gearbox	Petrol	KFW SAGEM S2000PM2	●	●	●	●
PARTNER	engines/automatic gearbox	Petrol	N6A BOSCH ME7. 4. 4	●	●	●	●
PARTNER	Active safety		BOSCH ABS5. 3	●	●	●	●
PARTNER	Active safety		ABS BOSCH 8	●	●	●	●
PARTNER	engines/automatic gearbox	Petrol	NFU BOSCH ME7. 4. 4	●	●	●	●
PARTNER	engines/automatic gearbox	Petrol	N6A BOSCH ME7. 4. 5	●	●	●	●
PARTNER	engines/automatic gearbox	Petrol	N6B BOSCH ME7. 4. 5	●	●	●	●
PARTNER	engines/automatic gearbox	Petrol	NFU BOSCH ME7. 4. 5	●	●	●	●
PARTNER	engines/automatic gearbox	Petrol	KFW J34P	●	●	●	●
PARTNER	Engines/automatic gearbox	Diesel	RHY SIEMENS SID801	●	●	●	●
PARTNER	engines/automatic gearbox	Diesel	WJY LUCAS DCN2	●	●	●	●
PARTNER	engines/automatic gearbox	Diesel	RHY SIEMENS SID801	●	●	●	●
PARTNER	engines/automatic gearbox	LPG /GNV	SAGEM SAX500	●	●	●	●
PARTNER	Active safety		ABS 8. 1	●	●	●	●
PARTNER B9	Driver information/Communication		Under inflation detection	●	●	●	●
PARTNER B9	engines/automatic gearbox	Diesel	EDC17C10 BR2	●	●	●	●
PARTNER B9	engines/automatic gearbox	Diesel	HDI SID807	●	●	●	●
PARTNER B9	Engine/Gearbox	Diesel	9HT EDC16C3	●	●	●	●
PARTNER B9	Engine/Gearbox	Diesel	9HX EDC16C3	●	●	●	●
PARTNER B9	Engine/Gearbox	Diesel	9HZ EDC16C3	●	●	●	●
PARTNER B9	Engine/Gearbox	Diesel	9HS EDC16C3	●	●	●	●
PARTNER B9	Engine/Gearbox	Diesel	9HV EDC16C3	●	●	●	●
PARTNER B9	Engine/Gearbox	Diesel	9HW EDC16C3	●	●	●	●
PARTNER B9	Active and passive safety	ABS or ESP ECU	ESP 8. 1	●	●	●	●
PARTNER B9	Engine/Gearbox	Petrol	N6A ME745	●	●	●	●
PARTNER B9	Engine/Gearbox	Petrol	N6B ME745	●	●	●	●
PARTNER B9	Engine/Gearbox	Petrol	NFU ME745	●	●	●	●
PARTNER B9	Engine/Gearbox	Petrol	NFR ME745	●	●	●	●
PARTNER B9	Engine/Gearbox		Multiplexed additive adding	●	●	●	●
PARTNER B9	Driver information/Communication		Air conditioning	●	●	●	●
PARTNER B9	Driver information/Communication		Power steering	●	●	●	●
PARTNER B9			Built-in systems interface(BSI)	●	●	●	●
PARTNER B9	Inform the driver/Audio/Communication	Multitifunction display(EMF)	EMF A	●	●	●	●
PARTNER B9	Inform the driver/Audio/Communication	Multitifunction display(EMF)	EMF C	●	●	●	●
PARTNER B9	Inform the driver/Audio/Communication		Radio	●	●	●	●
PARTNER B9	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
PARTNER B9	Inform the driver/Audio/Communication		CD player	●	●	●	○
PARTNER B9	Inform the driver/Audio/Communication	Hands Free Kit	Portable unit	●	●	●	●
PARTNER B9	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●
PARTNER B9	Inform the driver/Audio/Communication	Telematics	RNEG radio navigation	●	●	●	●
PARTNER B9	Vehicle protection/Management of		Alarm	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
PARTNER B9	Active and passive safety		Air bag	●	●	●	●
PARTNER B9	Visibility/Lighting/Signalling		Rain Sensor	●	●	●	○
PARTNER B9	Active and passive safety	ABS or ESP ECU	ABS 8.1	●	●	●	●
RCZ	Inform the driver/Audio/Communication		Instrument panel	●	●	●	●
RCZ	Active and passive safety	ABS or ESP ECU	ABS 8.1	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Petrol	5FT MED17.4	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Petrol	5FW MEV17.4	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Petrol	5FX MED17.4	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Petrol	5FY MED17.4	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Petrol	8FS MEV17.4	●	●	●	●
RCZ	Engine /Gearbox	gearbox	AL4 gearbox	●	●	●	●
RCZ	Active and passive safety	air-bag	air-bag	●	●	●	●
RCZ	Engine /Gearbox	gearbox	AM6 Euro5 automatic gearbox	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Petrol	N6A ME745	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Petrol	N6B ME745	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Petrol	NFU ME745	●	●	●	●
RCZ	Driving assistance/Comfort		Under inflation detection	●	●	●	●
RCZ	Built-in systems interface(BSI)		Built-in systems interface(BSI)	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Diesel	DCM3.5	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Diesel	RHF DCM3.4	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Diesel	RHL DCM3.4	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Diesel	RHR DCM3.4	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Diesel	EDC17C10 BR2	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Diesel	HDI SID807 BR2	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Diesel	HDI SID807	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Diesel	9HV BOSCH EDC16C3	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Diesel	9HX BOSCH EDC16C3	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Diesel	9HY BOSCH EDC16C3	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Diesel	9HZ BOSCH EDC16C3	●	●	●	●
RCZ	Engine /Gearbox	Multiplexed additive adding	POMPE MUX TI	●	●	●	●
RCZ	Active and passive safety	ABS or ESP ECU	ESP 8.1	●	●	●	●
RCZ	Engine /Gearbox	gearbox	CFC300P gearbox	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Petrol	NFU ME749 Bio Flex	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Petrol	RFJ MM6KP Bio Flex(EW10AFF)	●	●	●	●
RCZ	Engine /Gearbox	Engine ECU→Petrol	RFJ MM6LPB	●	●	●	●
RCZ	Engine /Gearbox	gearbox	AM6C gearbox	●	●	●	●
RCZ	Engine /Gearbox	gearbox	AT6 Euro5 automatic gearbox	●	●	●	●
RCZ	Inform the driver/Audio/Communication	Telematics	Data communication ECU	●	●	●	●
RCZ	Inform the driver/Audio/Communication	Telematics	RNEG radio navigation	●	●	●	●
RCZ	Driving assistance/Comfort		air conditioning	●	●	●	●
RCZ	Vehicle protection/Management of		Alarm	●	●	●	●
RCZ	Inform the driver/Audio/Communication		Audio amplifier	●	●	●	○
RCZ	Inform the driver/Audio/Communication		Battery charge status unit.	●	●	●	●
RCZ	Inform the driver/Audio/Communication		CD player	●	●	●	○

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Read Value
RCZ	Inform the driver/Audio/Communication		Control panel dot matrix display	●	●	●	●
RCZ	Visibility/Lighting/Signalling		discharge bulbs vertical and horizontal adjustment	●	●	●	●
RCZ	Driving assistance/Comfort		driver seat memory unit	●	●	●	●
RCZ	Vehicle protection/Management of		Driver's door control panel	●	●	●	●
RCZ	Visibility/Lighting/Signalling		Driving school moduel	●	●	○	○
RCZ	Driving assistance/Comfort		Electropump assembly	●	●	●	●
RCZ	Inform the driver/Audio/Communication		Hands Free Kit	●	●	●	●
RCZ	Driving assistance/Comfort		Lane departure warning	●	●	●	●
RCZ	Inform the driver/Audio/Communication		multifunction screen	●	●	●	●
RCZ	Engine /Gearbox		multiplexed additive adding pump	●	●	●	●
RCZ	Inform the driver/Audio/Communication		not fastened warning light(TNB)	●	○	○	○
RCZ	Driving assistance/Comfort		Parking assistance	●	●	●	●
RCZ	Inform the driver/Audio/Communication		radio	●	●	●	●
RCZ	Visibility/Lighting/Signalling		rain sensor	●	●	●	○
RCZ	Inform the driver/Audio/Communication		Service module	●	●	●	●
RCZ	Inform the driver/Audio/Communication		Steering wheel switching module.	●	●	●	●