

MaxiDas_BYD_V5. 20 Function List (Note:For reference only)

Notes:

• indicates the function is supported * indicates the function may be supported according to actual vehicle conditions O indicates the function is not available

Refer to Special Function List for special functions

Velet of	o special runction List	for special functions							
Mode1	System	ECU	Retrieve ECU Info.	Read DTCs	Clear DTCs	Read Live Data	Read Freeze Frame	Active Test	Special Function
F0	Engine System	UAES M7.8 Engine System	•	•	•	•	0	•	
F0	Engine System	UAES M7 Engine System	•	•	•	•	0	•	
F0	Engine System	Delphi MT22 Engine System	•	•	•	•	0	•	
F0	Engine System	BYD BU100 Engine System	•	•	•	•	0	•	0x10
F0	Engine System	UAES ME17.88	4	•	•	•	0	•	
F0	ABS	Delphi ABS	•	•	•	•	0	•	
F0	ABS	BWI ABS	•	•	•	•	0	•	0x18
F0	ABS	BOSCH Anti-Lock Braking System (ABS9)	•	•	•	•	0	•	0x33, 0x30, 0x0b, 0x25
F0	Automatic Transmission	Marelli TCU	•	•	•	•	0	•	0x35
F0	SRS	SRS	•	•	•	•	0	0	0x09
F0	Body Control	Steering Shaft Lock System	0			0	0	0	
F0	Body Control	Instrument System	•			0	0	0	
F0	Body Control	Body Control System	•			0	0	0	0x13, 0x2F
F0	Body Control	Smart Key	•	•		•	0	0	
F3	Engine System	UAES M79 Engine System	•	•		•	0	•	
F3	Engine System	Delphi MT20U2 Engine System	•			•	0	•	0x13
F3	Engine System	Delphi MT20U Engine System	•	•		•	0	•	0x13
F3	Engine System	Delphi MT22 Engine System	•	•		•	0	•	
F3	Engine System	BYD 473QE+DCT Engine System	•	•		•	0	•	
F3	Engine System	UAES M79 473QE Engine System	•	•		•	0	•	
F3	Automatic Transmission	BYD DCT Transmission Control System	•	•	•	•	0	•	0x34
F3	ABS	SABS MK70 System	•	•	•	•	0	•	
F3	ABS	Delphi ABS	•	•	•	•	0	•	0x18
F3	ABS	BOSCH Anti-Lock Braking System (ABS8)	•	•	•	•	0	•	0x33, 0x30, 0x0b, 0x25
F3	ABS	BOSCH Anti-Lock Braking System (ABS9)	•	•	•	•	0	•	0x33, 0x30, 0x0b, 0x25
F3	ABS	BWI ABS	•	•	•	•	0	•	0x18
F3	SRS	SRS	•	•	•	•	0	0	0x09
F3	Power Steering System	BYD EPS	•	•	•	0	0	•	
F3DM	ABS	BOSCH Anti-Lock Braking System (ABS8)	•	•	•	•	0	•	0x33, 0x30, 0x0b, 0x25

Model	System	ECU	Retrieve ECU Info.	Read DTCs	Clear DTCs	Read Live Data	Read Freeze Frame	Active Test	Special Function
F3DM	SRS	SRS	•	•	•	•	0	0	0x09
F3CK	Engine System	UAES M79 Engine System	•	•		•	0		
F3CK	ABS	Delphi ABS	•			•	0		0x18
F3CK	SRS	SRS	•			•	0	0	0x09
F3CK	Body Control	Communication System	0	0	0	0	0		
F3CK	Body Control	Keyless System	•			•	0	0	
F3CK	Body Control	Body Control System	•			0	0	0	
F3CK	Body Control	Steering Shaft Lock System	•			•	0	0	
F3CK	Body Control	A/C System	•			•	0	0	
F3CK	Body Control	Instrument System	•			0	0	0	
F3CK	Body Control	Multi-Function Display System	•	•	•	0	0	0	
F3CK	Body Control	Parking Assist System	•	•	•	0	0	0	
F3R	Engine System	UAES M79 Engine System	•	•	•	•	0	•	
F3R	Engine System	Delphi MT20U2 Engine System	•	•	•	•	0	•	0x13
F3R	Engine System	Delphi MT20U Engine System	•	•	•	•	0	•	0x13
F3R	ABS	Delphi ABS	•	•		•	0	•	0x18
F3R	ABS	BOSCH Anti-Lock Braking System (ABS8)	•	•	•	•	0	•	0x33, 0x30, 0x0b, 0x25
F3R	ABS	BWI ABS	•	•	•	•	0	•	0x18
F3R	SRS	SRS	•		•	•	0	0	0x09
F6	Engine System	UAES M79 Engine System	•			•	0	•	
F6	ABS	BOSCH Anti-Lock Braking System (ABS8)	•	•	•	•	0	•	0x33, 0x30, 0x0b, 0x25
F6	ABS	BOSCH Anti-Lock Braking System (ABS9)	•	•	•	•	0	•	0x33, 0x30, 0x0b, 0x25
F6	ABS	BWI ABS	•	•	•	•	0	•	0x18
F6	Body Control	Body Control System	•	•	•	0	0	0	
F6	Body Control	Door Multiple Control Template	•		•	0	0	0	
F6	Body Control System	Front Cabin Distribution Box Relay Circuit Template	•	•	•	0	0	0	
F6	Body Control	Combination Switch	•	•	•	0	0	0	
F6	Body Control	A/C	•			•	0	0	
F6	Body Control	Instrument System	•			0	0	0	
F6	Body Control	Gateway	•	•		•	0	0	
F6	Body Control	Parking Assist System	•			0	0	0	
F6	SRS	Airbag	•	•	•	0	0	0	0x09
F6	Automatic Transmission	VT2TCU	•	•	•	•	0		0x09
G3	Engine System	UAES M787CAN Engine System	•	•	•	•	0	•	
G3	Engine System Engine System	Delphi MT22 Engine System	•	•	•	•	0	•	
G3	Engine System	BYD 473QE+DCT Engine System	•	•	•	•	0	•	
G3	Engine System Engine System	UAES M78 473QE Engine System	•	•	•		0	•	
G3	Automatic	BYD DCT Transmission Control	•	•	•	•	0		0x34
	Transmission	System		l				<u> </u>	

G3		0x09 0x33, 0x30, 0x0b, 0x25 0x33, 0x30, 0x0b, 0x25 0x33, 0x30, 0x0b, 0x25 0x18
G3	•	0x33, 0x30, 0x0b, 0x25 0x33, 0x30, 0x0b, 0x25
ABS	• • • • • • • • • • • • • • • • • • •	0x33, 0x30, 0x0b, 0x25
G3	0 0	
G3	0 0 0	0v18
G3	0	OYIO
G3	0	
G3	0	
G3		
G3		
G3	\circ	0x2F
G3	•	
G3 SRS Airbag ● ● ○ ○ G3 Body Control Gateway ● ● ○ ○ G6 Engine System UAES M79 Engine System (CVT) ● ● ○ ○ G6 Engine System BYD TI Engine Management System ● ● ○ ○ G6 Automatic Transmission System ● ● ● ○ ○ G6 Automatic Transmission VT2TCU ● ● ● ● ○ ○ G6 ABS BOSCH Anti-Lock Braking System (ABS8) ●	0	
G3	0	0x09
G6 Engine System UAES M79 Engine System (MT) ● ● ● ○ G6 Engine System UAES M79 Engine System (CVT) ● ● ● ○ G6 Engine System BYD TI Engine Management System ● ● ● ○ G6 Automatic Transmission System ●	0	
G6	•	
G6 Engine System BYD TI Engine Management System ● </td <td>•</td> <td></td>	•	
G6 Automatic Transmission BYD DCT Transmission Control System • • • • • • • • • • • • • • • • • • •	•	0x31
Transmission System		
G6 Automatic Transmission VT2TCU ● ● ● ● ○	0	0x34
G6 ABS BOSCH Anti-Lock Braking System (ABS8) • • • • • • • • • • • • • • • • • • •	0	0x09
G6 ABS BOSCH Anti-Lock Braking System (ABS9) ● ● ● ○ G6 Bosch Esp9 System Bosch Esp9 System ● ● ● ● ○ G6 Body Control Instrument System ● ● ● ○ ○ G6 Body Control Steering Shaft Lock System ● ● ○ ○	•	0x33, 0x30, 0x0b, 0x25
G6 Bosch Esp9 System ● ● ● ○ G6 Body Control Instrument System ● ● ● ○ ○ G6 Body Control Steering Shaft Lock System ● ● ○ ○	•	0x33, 0x30, 0x0b, 0x25
G6 Body Control Instrument System ● ● ○ ○ G6 Body Control Steering Shaft Lock System ● ● ○ ○	•	0x0B, 0x18
G6 Body Control Steering Shaft Lock System • • O O	0	
	0	
TOO TOOKY CONTITUE IN CANTAINS TO SOLON TO TO THE TOO TO TOOK TO THE TOOK TO T	0	
G6 Body Control Keyless System • • • • •	0	
G6 Body Control Door Multiple Control Template	0	
G6 Body Control Combination Switch	0	
G6 Body Control Front Cabin Distribution Box System Relay Circuit Template	0	
G6 Body Control A/C • • • O	0	
G6 Body Control Multi-Function Display • • O	0	
G6 Body Control Gateway • • • •	0	
G6 Body Control Tire Pressure Monitoring Systems (TPMS)	0	0x2E
G6 Body Control Headlight Adjustment Unit • • • •	•	
G6 Body Control Body Control System • • • • • • • • • • • • • • • • • • •		0x2F, 0x13
G6 SRS Airbag • • • • •	0	0x2F, $0x130x09$

Mode1	System	ECU	Retrieve ECU Info.	Read DTCs	Clear DTCs	Read Live Data	Read Freeze Frame	Active Test	Special Function
L3	Engine System	UAES M787CAN Engine System	•	•	•	•	0	•	
L3	Engine System	Delphi MT22 Engine System	•	•	•	•	0		
L3	Engine System	BYD 473QE+DCT Engine System	•	•			0		
L3	Engine System	UAES M78 473QE Engine System	•	•	•	•	0		
L3	ABS	Delphi ABS	•	•	•	•	0		0x18
L3	ABS	BOSCH Anti-Lock Braking System (ABS8)	•	•	•	•	0	•	0x33, 0x30, 0x0b, 0x25
L3	ABS	BOSCH Anti-Lock Braking System (ABS9)	•	•	•	•	0	•	0x33, 0x30, 0x0b, 0x25
L3	ABS	BWI ABS	•		•	•	0	•	0x18
L3	SRS	Airbag			•	0	0	0	0x09
L3	Body Control	Communication System	0	0	0	0	0	•	
L3	Body Control	Instrument System	•	•	•	0	0	0	
L3	Body Control	Steering Shaft Lock System	•	•	•	0	0	0	
L3	Body Control	Body Control System	•	•	•	0	0	0	
L3	Body Control	Parking Assist System	•	•	•	0	0	0	
L3	Body Control	Keyless System	•	•	•	•	0	0	
L3	Body Control	Gateway	•	•	•	•	0	0	
L3	Body Control	Personalized Setting	0	0	0	0	0	0	0x2F
L3	Automatic Transmission	VT2TCU	•	•	•	•	0	0	0x09
L3	Automatic Transmission	BYD DCT Transmission Control System	•	•	•	•	0	•	0x34
M6	Engine System	UAES M787CAN Engine System	•	•	•	•	0	•	
M6	Engine System	UAES M7971 Engine System	•	•	•	•	0	•	
M6	Engine System	UAES ME17.88 Engine System	•		•	•	0		
M6	ABS	BOSCH ABSV3 System	•		•	•	0	0	0x18
M6	ABS	BOSCH ABS System	•		•	•	0	0	0x18
M6	Bosch Esp9 System	Bosch Esp9 System	•		•	•	0	•	0x0B, 0x18
M6	Automatic Transmission	BYD DCT Transmission Control System	•	•	•	•	0	•	0x34
M6	SRS	Airbag	•	•	•	0	0	0	0x09
M6	Body Control	Communication System	0	0	0	0	0	•	
M6	Body Control	Instrument System	•	•	•	0	0	0	
M6	Body Control	Body Control System	•	•	•	0	0	0	
M6	Body Control	Keyless System	•	•	•	•	0	0	
M6	Body Control	Steering Shaft Lock System	•	•	•	0	0	0	
M6	Body Control	Door Multiple Control Template	•	•	•	0	0	0	
M6	Body Control	Parking Assist System	•	•	•	0	0	0	
M6	Body Control	Combination Switch	•	•	•	0	0	0	
M6	Body Control System	Front Cabin Distribution Box Relay Circuit Template	•	•	•	0	0	0	
M6	Body Control	A/C	•	•	•	•	0	0	
M6	Body Control	Multi-Function Display		•	•	0	0	0	
M6	Body Control	Gateway		•	•	•	0	0	

Mode1	System	ECU	Retrieve ECU Info.	Read DTCs	Clear DTCs	Read Live Data	Read Freeze Frame	Active Test	Special Function
M6	Body Control	Left Autokinesis Door	•	•	•	•	0	0	
M6	Body Control	Right Autokinesis Door	•	•	•	•	0	0	
M6	Body Control	QuanJing ECU	•	•	•	0	0	0	
S6	Engine System	UAES M787CAN Engine System	•	•	•	•	0	•	
S6	Engine System	UAES M7971 Engine System	•	•	•	•	0	•	
S6	ABS	BOSCH ABSV3 System	•	•	•	•	0	0	0x18
S6	ABS	BOSCH ABS System	•	•	•	•	0	0	0x18
S6	Bosch Esp9 System	Bosch Esp9 System	•	•	•	•	0	•	0x0B, 0x18
S6	Automatic	BYD DCT Transmission Control		•		•	0	0	0x34
	Transmission	System							
S6	SRS	Airbag	•	•	•	•	0	0	0x09
S6	Body Control	Communication System	0	0	0	0	0	•	
S6	Body Control	Hard-top	•	•	•	0	0	0	
S6	Body Control	Sunroof	•	•	•	•	0	•	0x09
S6	Body Control	Instrument System	•	•	•	0	0	0	
S6	Body Control	Body Control System	•	•	•	0	0	0	0x13, 0x2F
S6	Body Control	Keyless System	•	•	•	•	0	0	
S6	Body Control	Steering Shaft Lock System	•	•	•	0	0	0	
S6	Body Control	Door Multiple Control Template	•	•	•	0	0	0	
S6	Body Control	Parking Assist System	•	•	•	0	0	0	
S6	Body Control	Combination Switch	•	•	•	0	0	0	
S6	Body Control	Front Cabin Distribution Box	•	•	•	0	0	0	
	System	Relay Circuit Template							
S6	Body Control	A/C	•	•	•	•	0	0	
S6	Body Control	Multi-Function Display	•	•	•	0	0	0	
S6	Body Control	Gateway	•	•	•	•	0	0	
S8	Engine System	UAES M79 Engine System	•	•	•	•	0	•	
S8	Automatic Transmission	VT2TCU	•	•	•	•	0	0	0x09
S8	ABS	BWI ABS	•	•		•	0		0x18
S8	Body Control	Steering Shaft Lock	•	•		•	0	0	0.110
S8	Body Control	Keyless System	•	•	•	•	0	0	
S8	Body Control	Airbag		•	•	0	0	0	
S8	Body Control	Hard-top		•	•	0	0	0	
S8		Front Cabin Distribution Box		•		0	0	0	
	System	Relay Template			_				
S8	Body Control	Body Control System	•	•	•	0	0	0	
E6B	Engine System	P Gear Motor Controller	•	•	•	•	0	0	
E6B	Engine System	MG2 Motor Controller	•	•	•		0	0	
E6B	Engine System	On-Board Charger	•	•	•		0	0	
E6B	Engine System	Gear Controller	•	•	•	•	0	0	
E6B	Engine System	Power Battery Management	•	•	•	•	0	0	
E6B	Engine System	A/C Driver	•	•	•	•	0	0	
E6B	Engine System	Master Controller	•	•	•	•	0	0	
E6B	Engine System	Combination Instrument				0	0	0	

Model	System	ECU	Retrieve ECU Info.	Read DTCs	Clear DTCs	Read Live Data	Read Freeze Frame	Active Test	Special Function
E6B	Engine System	A/C Controller	•	•	•	•	0	0	
E6B	Engine System	Power Steering System (EHPS)	•	•	•	•	0	0	
E6B	Body Control	SRS	•	•	•	•	0	0	0x09
E6B	Body Control	Body Control System	•	•	•	0	0	0	
E6B	Body Control	Smart Key	•	•	•	•	0	0	
E6B	Body Control	Steering Shaft Lock System	•	•	•	0	0	0	
E6B	Body Control	Door Multiple Control Template	•	•	•	0	0	0	
E6B	Body Control	Park Pilot	•	•	•	0	0	0	
E6B	Body Control	Combination Switch	•	•	•	0	0	0	
E6B	Body Control	Relay Control	•	•	•	0	0	0	
E6B	Body Control	Gateway	•	•	•	0	0	0	
E6B	Body Control	TPMS	•	•	•	•	0	0	0x2E
E6B	ABS	BOSCH ABS	•	•	•	•	0	0	0x18
Surui	Engine System	UAES ME17.88 Engine System	•	•	•	•	0	•	
Surui	Engine System	BYD TI Engine Management System	•	•	•	•	0		0x31
Surui	Engine System	P Gear Motor Controller	•	•	•	•	0	0	01101
Surui	ABS	BOSCH Anti-Lock Braking System (ABS9)	•	•	•	•	0		0x33, 0x30, 0x0b, 0x25
Surui	Power Steering System	BYD EPS	•	•	•	•	0	0	
Surui	SRS	SRS	•	•	•	•	0	0	0x09
Surui	Body Control	Communication System	0	0	0	0	0		
Surui	Body Control	Instrument System	•	•	•	•	0	0	0x2E
Surui	Body Control	Body Control System	•		•	•	0		0x2F, 0x13
Surui	Body Control	Keyless System	•			•	0	0	, , , , , , , , , , , , , , , , , , , ,
Surui	Body Control	Steering Shaft Lock System	•	•	•	0	0	0	
Surui	Body Control	Door Multiple Control Template	•		•	0	0	0	
Surui	Body Control	Parking Assist System	•	•	•	0	0	0	
Surui	Body Control	Combination Switch	•		•	0	0	0	
Surui	Body Control	Relay Control	•	•		0	0	0	
Surui	Body Control	A/C	•	•	•	•	0	0	0x2E
Surui	Body Control	Multi-Function Display	•	•	•	0	0	0	
Surui	Body Control	Gateway	•	•	•	•	0	0	
Surui	Body Control	TPMS	•	•	•	•	0	0	0x2E
FLYER QCJ7081BD	Engine System	FLYER 7081BD UAES	0	•	•	•	0	0	
FLYER QCJ7081BD	Engine System	FLYER 7081BD UAES	0	•	•	•	0	0	
FLYER QCJ7081BD	ABS	BYD ABS	•	•	•	•	0		0x18
FLYER QCJ7081BD	SRS	BYD SRS	•	•	•	•	0	•	
FLYER QCJ7081DD	Engine System	Matiz Engine	•	•	•	•	0	0	
FLYER QCJ7081DD	ABS	BYD ABS	•	•	•	•	0		0x18
FLYER QCJ7081DD	SRS	BYD SRS	•	•	•	•	0	•	
FLYER QCJ7110	Engine System	Delphi (4G24) Engine System	•	•	•	0	0	0	
FLYER QCJ7110	ABS	BYD ABS	•	•	•	•	0		0x18
FLYER QCJ7110	SRS	BYD SRS	•	•	•	•	0	•	
BOSCH M154 Engine		BOSCH M154 Engine	•	•	•	•	0		

Model	System	ECU	Retrieve ECU Info.	Read DTCs	Clear DTCs	Read Live Data	Read Freeze Frame	Active Test	Special Function
E6A	Engine System	MG2 Motor Controller	•	•	•	•	0	0	
E6A	Engine System	P Gear Motor Controller	•	•	•	•	0	0	
E6A	Engine System	Gear Controller	•	•	•	•	0	0	
E6A	Engine System	Power Battery Management	•	•	•	•	0	0	
E6A	Engine System	A/C Driver	•	•	•	•	0	0	
E6A	Engine System	Master Controller	•	•	•	•	0	0	
E6A	Engine System	Combination Icm	•	•	•	0	0	0	
E6A	Engine System	A/C Controller	•	•	•	•	0	0	
E6A	Engine System	EHPS	•	•	•	•	0	0	
E6A	ABS	Bosch ABS9	•	•	•	•	0	0	0x18
E6A	ABS	Bosch ABSV30	•	•	•	•	0	0	0x18
E6A	Bosch Esp9 System	Bosch Esp9 System	•	•	•	•	0	•	0x0B, 0x18
E6A	SRS	SRS	•	•	•	•	0		0x09
E6A	Body Control	Steering Shaft Lock System	•	•	•	0	0	0	
E6A	Body Control	Backup Radar	•	•	•	0	0	0	
E6A	Body Control	Body Control System	•	•	•	0	0	0	
E6A	Body Control	Smart Key	•	•	•	0	0	0	
E6A	Body Control	Door Multiple Control Template	•	•	•	0	0	0	
E6A	Body Control	Combination Switch	•	•	•	0	0	0	
E6A	Body Control	Relay Control	•		•	0	0	0	
E6A	Body Control	Gateway	•		•	0	0	0	
E6Y	Engine System	Power Battery Management	•			•	0	0	
E6Y	Engine System	VTOG Control System	•			•	0	0	
E6Y	Engine System	Gear Controller	•	•		•	0	0	
E6Y	Engine System	12V DC 1	•			•	0	0	
E6Y	Engine System	12V DC 2	•			•	0	0	
E6Y	Engine System	Master Controller	•			•	0	0	
E6Y	Engine System	A/C Driver	•	•		•	0	0	
E6Y	Engine System	Master Controller	•			•	0	0	
E6Y	Engine System	PTC Module				•	0	0	
E6Y	Engine System	P Gear Motor Controller	•			•	0	0	
E6Y	Engine System	Combination Icm	•	•		0	0	0	
E6Y	Engine System	Power Steering System (EHPS)	•			•	0	0	
E6Y	ABS	Bosch ABS	•	•		•	0		0x18
E6Y	Bosch Esp9 System				•	•	0		0x0B, 0x18
E6Y	EPB Electronic	EPB Electronic Parking Brake	•	•	•	•	0	•	ONOD, UNIO
E6Y	Parking Brake SRS	SRS	•		•		0	0	
E6Y		Smart Key		•					
E6Y	Body Control			•	•	_	0	0	
	Body Control	Body Control System	•	•	•	0	0	0	
E6Y	Body Control	Steering Shaft Lock System	•	•	•	0	0	0	
E6Y	Body Control	Backup Radar	•	•	•	0	0	0	
E6Y	Body Control	Door Multiple Control Template	•	•	•	0	0	0	0.00
E6Y	Body Control	Back Hit ECU	•	•	•	•	0		0x09
E6Y	Body Control	Combination Switch				0	0	0	

Model	System	ECU	Retrieve	Read	Clear	Read Live	Read Freeze	Active	Special Function
DOM	P 1 C + 1	D 1 0 1	ECU Info.	DTCs	DTCs	Data	Frame	Test	
E6Y	Body Control	Relay Control	•	•	•	0	0	0	0.00
E6Y	Body Control	TPMS	•	•	•	0	0	0	0x2E
E6Y	Body Control	Gateway	•	•	•	0	0	0	
sirui	Engine System	UAES ME17.88 Engine System	•	•	•	•	0	•	
sirui	Engine System	BYD TI Engine Management System	•	•	•	•	0	•	0x31
sirui	Engine System	P Gear Motor Controller	•	•	•	•	0	0	
sirui	Automatic	BYD DCT Transmission Control	•	•	•	•	0	•	0x34
- ::	Transmission	System Bosch Esp9 System							0-0D 0-10
sirui		Bosch Esp9 System	•	•	•	•	0	•	0x0B, 0x18
sirui	Power Steering System	BYD EPS	•	•	•	0	0	•	
sirui	EPB Electronic Parking Brake	EPB Electronic Parking Brake	•	•	•	•	0	•	
sirui	SRS	SRS	•	•	•	•	0	0	0x09
sirui	Body Control	Steering Shaft Lock System	•	•		0	C	0	
sirui	Body Control	Combination Icm	•	•		0	0		
sirui	Body Control	Parking Auxiliary System	•	•	•	0	0	0	
sirui	Body Control	Body Control System	•	•	•	•	0	•	0x2F, 0x13
sirui	Body Control	Smart Kev	•	•	•	•	0	0	
sirui	Body Control	Door Multiple Control Template	•	•	•	0	0	0	
sirui	Body Control	Combination Switch	•	•	•	•	0	•	
sirui	Body Control	Relay Control	•	•	•	0	0	•	
sirui	Body Control	A/C Controller	•	•	•	•	0	•	
sirui	Body Control	Gateway	•	•	•	0	0	0	
sirui	Body Control	TPMS	•	•	•	•	0	0	0x2E
sirui	Body Control	AFS System	•		•	•	0	•	0x36
sirui	Body Control	Night Vision System	•		•	0	0	0	
sirui	Body Control	Up Screen System	•	•	•	0	0	0	
sirui	Body Control	Back Row Seat	•	•	•	•	0	•	
sirui	Body Control	Overall View Wheel switch	•	•	•	•	0	•	
sirui	Body Control	Overall View Image	•	•	•	0	0	0	
sirui	Body Control	Tubular Column ECU	•	•	•	•	0	•	0x36
sirui	Body Control	Front Right DoorECU	•	•	•	•	0	•	
sirui	Body Control	Front Left Door ECU	•	•	•	•	0	•	
sirui	Body Control	Seat ECU	•	•	•	•	0	•	0x36



Specil_Function

Index	Specil Function Name	Index	Specil Function Name
0x01	Version Information	0x1C	Vehicle Service
0x02	Read DTCs	0x1D	Coding
0x03	Freeze Frame	0x1E	Activate Alarm Horn
0x04	Clear DTCs	0x1F	CAN Configuration Selection
0x05	Live Data	0x20	CAN Configuration Input
0x06	Active Test	0x21	Initialize Tire Location
0x07	Parameter Adjustment	0x22	ISU Reset
0x08	Programming	0x23	Fast Dormancy
0x09	Special Function	0x24	Shipping Mode
0x0A	02 Sensor Monitoring	0x25	Air Bleeding Function
0x0B	End-of-Line Test	0x26	02 Sensor Test
0x0C	Remote Control Matching	0x27	Engine Test
0x0D	Service Lamp Reset	0x28	Fuel Injector Matching
0x0E	Input Code	0x29	Read Fuel Injector Code
0x0F	Immobilizer Matching	0x2A	2-Airbag Automatch
0x10	ECU Reset	0x2B	6-Airbag Automatch
0x11	Warning Light Configuration	0x2C	Key Identification
0x12	Steering Angle Sensor Calibration	0x2D	Remote Control Receiving and Sending Function
0x13	Restore Default	0x2E	Tire Pressure Monitoring Module Register
0x14	Automatic Bleeding	0x2F	Personalized Setting
0x15	Hydraulic Control Unit Test	0x30	Write Hydraulic Module Filling Status
0x16	Bleeding and Filling	0x31	Self-Learning Clearing
0x17	EOBD Module	0x32	Filling and Bleeding
0x18	Bleeding Mode	0x33	seting/cancel Diagnose CommunicationRate-limiting
0x19	Write Data	0x34	Self-Adaption
0x1A	Matching Function	0x35	End-of-Line Test/learn After Service
0x1B	Reset Adaptive Value	0x36	Instant Initalization