

How to read this list:	
Mark	Description
X	Function is supported.
*	Function is added or developed newly

Function List													
Automaker:				ACURA									
Software Version:				V6.2									
Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions
ACURA	All	1996-2011	All	All	All	PGM FI		X	X	X	X	X	TP sensor reset Replace ECM/PCM
ACURA	All	1996-2011	All	All	All	AT		X	X	X	X		
ACURA	All	1996-2011	All	All	All	ABS TCS VSA		X	X	X	X	X	All sensor calibration
ACURA	All	1996-2011	All	All	All	SRS		X	X	X	X	X	OPDS init
ACURA	All	1996-2011	All	All	All	EPS		X	X	X	X		
ACURA	All	1996-2011	All	All	All	BODY(Gauges)		X	X	X	X	X	Gauge Control Module Replacement
ACURA	All	1996-2011	All	All	All	BODY(Lighting)		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	BODY(Door Locks)		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	BODY(Keyless)		X	X	X	X	X	Keyless Check
ACURA	All	1996-2011	All	All	All	BODY(Power Windows)		X	X	X	X	X	1.Power Window Reset for Driver side 2.Power Window Reset for Passenger side 3.Power Window Reset for Left side 4.Power Window Reset for Right side
ACURA	All	1996-2011	All	All	All	BODY(Wiper)		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	BODY(Security)		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	BODY(HVAC/Climate control)		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	BODY(Power Sliding Door)		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	BODY(Power Tailgate)		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	BODY(Auto Light Leveling)		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	BODY(Power Seat/Power Mirror)		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	BODY(Adaptive Front Lighting)		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	BODY(YOP Security)		X	X	X	X		

ACURA	All	1996-2011	All	All	All	BODY(YOP ECU)		X	X	X	X		
ACURA	All	1996-2011	All	All	All	BODY(Front Panel)		X	X	X	X		Front Panel Check
ACURA	All	1996-2011	All	All	All	BODY(HF LINK/TEL)		X	X	X			Passcode clear
ACURA	All	1996-2011	All	All	All	BODY(OnStar)		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	BODY(Power Trunk Lid)		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	BODY(YOP R/C ENG Starter)		X	X	X	X		
ACURA	All	1996-2011	All	All	All	BODY(Parking Sensor)		X	X	X	X		
ACURA	All	1996-2011	All	All	All	BODY(Auto AC Sub display)		X	X	X			
ACURA	All	1996-2011	All	All	All	IMMOBI							1.Add one key 2.Rewrite keys 3.All keys lost 4.Add Keys 5.Delete Keys 6.Replace ECM/PCM
ACURA	All	1996-2011	All	All	All	IMA		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	TPMS		X	X	X	X		
ACURA	All	1996-2011	All	All	All	SH-AWD		X	X	X	X		
ACURA	All	1996-2011	All	All	All	SMART KEY		X	X	X	X		
ACURA	All	2009-2011	All	All	All	ONE-PUSH START		X	X	X	X	X	
ACURA	All	1996-2011	All	All	All	ATTS		X	X	X	X		
ACURA	All	1996-2011	All	All	All	VTM 4		X	X	X	X		
ACURA	All	1996-2011	All	All	All	DRIVING SUPPORT		X	X	X	X		
ACURA	All	1996-2011	All	All	All	BRAKE SYSTEM		X	X	X	X		
ACURA	All	1996-2011	All	All	All	Active Damper System		X	X	X	X		