

How to read this list:	
Mark	Description
X	Function is supported.
*	Function is added or developed newly

Function List													
Automaker:				INFINITI									
Software Version:				V7.0									
Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuation s	Special Functions
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		ABS		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		AIRBAG		X	X	X			
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		BCM		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		METER/M&A		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		ICC		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		HVAC		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		MULTI AV		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		EPS		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		e-4WD		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		DIU		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		ASCD			X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		HCM			X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		LDW			X	X	X		
INFINITI	ALL	2009	INFINITI EX25/EX35	J50		ACCELE PEDAL ACT		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	2009	INFINITI EX35	J50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		ABS		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		AIRBAG		X	X	X			
INFINITI	ALL	2009	INFINITI EX35	J50		BCM		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		METER/M&A		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		ICC		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		HVAC		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		MULTI AV		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		EPS		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		e-4WD		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		DIU		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	2009	INFINITI EX35	J50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	2009	INFINITI EX35	J50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		ASCD			X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		HCM			X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		LDW			X	X	X		
INFINITI	ALL	2009	INFINITI EX35	J50		ACCELE PEDAL ACT		X	X	X	X	X	

INFINITI	ALL	01/2008	INFINITI EX35	J50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	01/2008	INFINITI EX35	J50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI EX35	J50		ABS		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI EX35	J50		AIRBAG		X	X	X			
INFINITI	ALL	01/2008	INFINITI EX35	J50		BCM		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI EX35	J50		METER/M&A		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI EX35	J50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI EX35	J50		ICC		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI EX35	J50		HVAC		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI EX35	J50		MULTI AV		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI EX35	J50		EPS		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI EX35	J50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI EX35	J50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI EX35	J50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI EX35	J50		e-4WD		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI EX35	J50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI EX35	J50		DIU		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI EX35	J50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI EX35	J50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI EX35	J50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI EX35	J50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI EX35	J50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI EX35	J50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI EX35	J50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	01/2008	INFINITI EX35	J50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI EX35	J50		ASCD			X	X	X		
INFINITI	ALL	01/2008	INFINITI EX35	J50		HCM			X	X	X		
INFINITI	ALL	01/2008	INFINITI EX35	J50		LDW			X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	06/2008	INFINITI EX37	J50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		ABS		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI EX37	J50		AIRBAG		X	X	X			
INFINITI	ALL	06/2008	INFINITI EX37	J50		BCM		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI EX37	J50		METER/M&A		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI EX37	J50		ICC		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		HVAC		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		MULTI AV		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		EPS		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI EX37	J50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI EX37	J50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI EX37	J50		e-4WD		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI EX37	J50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI EX37	J50		DIU		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI EX37	J50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI EX37	J50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI EX37	J50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI EX37	J50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	06/2008	INFINITI EX37	J50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		ASCD			X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		HCM			X	X	X		
INFINITI	ALL	06/2008	INFINITI EX37	J50		LDW			X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		ABS		X	X	X	X	X	
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		AIRBAG		X	X	X			
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		BCM		X	X	X	X	X	
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		METER/M&A		X	X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		ICC		X	X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		HVAC		X	X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		MULTI AV		X	X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		EPS		X	X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		IPDM E/R		X	X	X	X	X	

INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		e-4WD		X	X	X	X	X	
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		DIU		X	X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		ASCD			X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		HCM			X	X	X		
INFINITI	ALL	06/2007	INFINITI FX35/FX45	S50		LDW			X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		ABS		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		AIRBAG		X	X	X			
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		BCM		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		METER/M&A		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		ICC		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		HVAC		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		MULTI AV		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		EPS		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		e-4WD		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		DIU		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		ASCD			X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		HCM			X	X	X		
INFINITI	ALL	07/2006	INFINITI FX35/FX45	S50		LDW			X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		TRANSMISSION		X	X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		ABS		X	X	X	X	X	
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		AIRBAG		X	X	X			
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		BCM		X	X	X	X	X	
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		METER/M&A		X	X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		ICC		X	X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		HVAC		X	X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		MULTI AV		X	X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		EPS		X	X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		e-4WD		X	X	X	X	X	
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		DIU		X	X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		SMART ENTRANCE		X	X	X			
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		ASCD			X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		HCM			X	X	X		
INFINITI	ALL	2009~	INFINITI FX35/FX50	S51		LDW			X	X	X		

INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		TRANSMISSION		X	X	X	X		
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		ABS		X	X	X	X	X	
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		AIRBAG		X	X	X			
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		BCM		X	X	X	X	X	
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		METER/M&A		X	X	X	X		
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		ICC		X	X	X	X		
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		HVAC		X	X	X	X		
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		MULTI AV		X	X	X	X		
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		EPS		X	X	X	X		
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		e-4WD		X	X	X	X	X	
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		DIU		X	X	X	X		
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		SMART ENTRANCE		X	X	X			
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		ASCD			X	X	X		
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		HCM			X	X	X		
INFINITI	ALL	05/2008	INFINITI FX35/FX50	S51		LDW			X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		TRANSMISSION		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		ABS		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		AIRBAG		X	X	X			
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		BCM		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		METER/M&A		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		ICC		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		HVAC		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		MULTI AV		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		EPS		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		e-4WD		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		DIU		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		SMART ENTRANCE		X	X	X			
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		ASCD			X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		HCM			X	X	X		
INFINITI	ALL	07/2006	INFINITI G35 Coupe	CV35		LDW			X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		TRANSMISSION		X	X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		ABS		X	X	X	X	X	
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		AIRBAG		X	X	X			
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		BCM		X	X	X	X	X	
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		METER/M&A		X	X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		ICC		X	X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		HVAC		X	X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		MULTI AV		X	X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		EPS		X	X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		IPDM E/R		X	X	X	X	X	

INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		e-4WD		X	X	X	X	X	
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		DIU		X	X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		SMART ENTRANCE		X	X	X			
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		ASCD			X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		HCM			X	X	X		
INFINITI	ALL	08/2005	INFINITI G35 Coupe	CV35		LDW			X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		TRANSMISSION		X	X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		ABS		X	X	X	X	X	
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		AIRBAG		X	X	X			
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		BCM		X	X	X	X	X	
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		METER/M&A		X	X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		ICC		X	X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		HVAC		X	X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		MULTI AV		X	X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		EPS		X	X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		e-4WD		X	X	X	X	X	
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		DIU		X	X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		SMART ENTRANCE		X	X	X			
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		ASCD			X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		HCM			X	X	X		
INFINITI	ALL	01/2005	INFINITI G35 Coupe	CV35		LDW			X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		TRANSMISSION		X	X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		ABS		X	X	X	X	X	
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		AIRBAG		X	X	X			
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		BCM		X	X	X	X	X	
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		METER/M&A		X	X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		ICC		X	X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		HVAC		X	X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		MULTI AV		X	X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		EPS		X	X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		e-4WD		X	X	X	X	X	
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		DIU		X	X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		SMART ENTRANCE		X	X	X			
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		ASCD			X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		HCM			X	X	X		
INFINITI	ALL	12/2007	INFINITI G35 Sedan	V36		LDW			X	X	X		

INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		TRANSMISSION		X	X	X	X		
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		ABS		X	X	X	X	X	
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		AIRBAG		X	X	X			
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		BCM		X	X	X	X	X	
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		METER/M&A		X	X	X	X		
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		ICC		X	X	X	X		
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		HVAC		X	X	X	X		
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		MULTI AV		X	X	X	X		
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		EPS		X	X	X	X		
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		e-4WD		X	X	X	X	X	
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		DIU		X	X	X	X		
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		SMART ENTRANCE		X	X	X			
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		ASCD			X	X	X		
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		HCM			X	X	X		
INFINITI	ALL	12/2006	INFINITI G35 Sedan	V36		LDW			X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		TRANSMISSION		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		ABS		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		AIRBAG		X	X	X			
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		BCM		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		METER/M&A		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		ICC		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		HVAC		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		MULTI AV		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		EPS		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		e-4WD		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		DIU		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		SMART ENTRANCE		X	X	X			
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		ASCD			X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		HCM			X	X	X		
INFINITI	ALL	06/2008	INFINITI G37 Coupe	CV36		LDW			X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		TRANSMISSION		X	X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		ABS		X	X	X	X	X	
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		AIRBAG		X	X	X			
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		BCM		X	X	X	X	X	
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		METER/M&A		X	X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		ICC		X	X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		HVAC		X	X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		MULTI AV		X	X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		EPS		X	X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		IPDM E/R		X	X	X	X	X	

INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		e-4WD		X	X	X	X	X	
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		DIU		X	X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		SMART ENTRANCE		X	X	X			
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		ASCD			X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		HCM			X	X	X		
INFINITI	ALL	11/2007	INFINITI G37 Coupe	CV36		LDW			X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		TRANSMISSION		X	X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		ABS		X	X	X	X	X	
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		AIRBAG		X	X	X			
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		BCM		X	X	X	X	X	
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		METER/M&A		X	X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		ICC		X	X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		HVAC		X	X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		MULTI AV		X	X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		EPS		X	X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		e-4WD		X	X	X	X	X	
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		DIU		X	X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		SMART ENTRANCE		X	X	X			
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		ASCD			X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		HCM			X	X	X		
INFINITI	ALL	07/2008	INFINITI G37 Sedan	V36		LDW			X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	2010	INFINITI M25/M37	Y50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		ABS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M25/M37	Y50		AIRBAG		X	X	X			
INFINITI	ALL	2010	INFINITI M25/M37	Y50		BCM		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M25/M37	Y50		METER/M&A		X	X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M25/M37	Y50		ICC		X	X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		HVAC		X	X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		MULTI AV		X	X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		EPS		X	X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M25/M37	Y50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M25/M37	Y50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M25/M37	Y50		e-4WD		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M25/M37	Y50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M25/M37	Y50		DIU		X	X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M25/M37	Y50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M25/M37	Y50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M25/M37	Y50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M25/M37	Y50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	2010	INFINITI M25/M37	Y50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		ASCD			X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		HCM			X	X	X		
INFINITI	ALL	2010	INFINITI M25/M37	Y50		LDW			X	X	X		

INFINITI	ALL	2010	INFINITI M25/M37	Y50		ACCELE PEDAL ACT		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		TRANSMISSION		X	X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		ABS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		AIRBAG		X	X	X			
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		BCM		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		METER/M&A		X	X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		ICC		X	X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		HVAC		X	X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		MULTI AV		X	X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		EPS		X	X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		e-4WD		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		DIU		X	X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		SMART ENTRANCE		X	X	X			
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		ASCD			X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		HCM			X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		LDW			X	X	X		
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		ACCELE PEDAL ACT		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI M37/M56/M30d	Y51		LASER		X	X	X	X	X	
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		ABS		X	X	X	X	X	
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		AIRBAG		X	X	X			
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		BCM		X	X	X	X	X	
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		METER/M&A		X	X	X	X		
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		ICC		X	X	X	X		
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		HVAC		X	X	X	X		
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		MULTI AV		X	X	X	X		
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		EPS		X	X	X	X		
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		e-4WD		X	X	X	X	X	
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		DIU		X	X	X	X		
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		ADAPTIVE LIGHT		X	X	X	X	X	

INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		ASCD			X	X	X		
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		HCM			X	X	X		
INFINITI	ALL	08/2008	INFINITI M35/M45	Y50		LDW			X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		ABS		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		AIRBAG		X	X	X			
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		BCM		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		METER/M&A		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		ICC		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		HVAC		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		MULTI AV		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		EPS		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		e-4WD		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		DIU		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		ASCD			X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		HCM			X	X	X		
INFINITI	ALL	01/2008	INFINITI M35/M45	Y50		LDW			X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		ABS		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		AIRBAG		X	X	X			
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		BCM		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		METER/M&A		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		ICC		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		HVAC		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		MULTI AV		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		EPS		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		e-4WD		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		DIU		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		ASCD			X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		HCM			X	X	X		
INFINITI	ALL	07/2006	INFINITI M35/M45	Y50		LDW			X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	ALL	INFINITI M45	2005		TRANSMISSION		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		ABS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2005		AIRBAG		X	X	X			
INFINITI	ALL	ALL	INFINITI M45	2005		BCM		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2005		METER/M&A		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		METER ACAMP		X	X	X	X	X	

INFINITI	ALL	ALL	INFINITI M45	2005		ICC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		HVAC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		MULTI AV		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		EPS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2005		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2005		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2005		e-4WD		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2005		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2005		DIU		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2005		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2005		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2005		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2005		SMART ENTRANCE		X	X	X			
INFINITI	ALL	ALL	INFINITI M45	2005		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		ASCD			X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		HCM			X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2005		LDW			X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	ALL	INFINITI M45	2004		TRANSMISSION		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		ABS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2004		AIRBAG		X	X	X			
INFINITI	ALL	ALL	INFINITI M45	2004		BCM		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2004		METER/M&A		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2004		ICC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		HVAC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		MULTI AV		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		EPS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2004		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2004		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2004		e-4WD		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2004		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2004		DIU		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2004		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2004		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2004		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2004		SMART ENTRANCE		X	X	X			
INFINITI	ALL	ALL	INFINITI M45	2004		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		ASCD			X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		HCM			X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2004		LDW			X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	ALL	INFINITI M45	2003		TRANSMISSION		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		ABS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2003		AIRBAG		X	X	X			
INFINITI	ALL	ALL	INFINITI M45	2003		BCM		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2003		METER/M&A		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2003		ICC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		HVAC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		MULTI AV		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		EPS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2003		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2003		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2003		e-4WD		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2003		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2003		DIU		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2003		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2003		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI M45	2003		ADAPTIVE LIGHT		X	X	X	X	X	

INFINITI	ALL	ALL	INFINITI M45	2003		SMART ENTRANCE		X	X	X			
INFINITI	ALL	ALL	INFINITI M45	2003		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		ASCD			X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		HCM			X	X	X		
INFINITI	ALL	ALL	INFINITI M45	2003		LDW			X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	11/2005	INFINITI Q45	F50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		ABS		X	X	X	X	X	
INFINITI	ALL	11/2005	INFINITI Q45	F50		AIRBAG		X	X	X			
INFINITI	ALL	11/2005	INFINITI Q45	F50		BCM		X	X	X	X	X	
INFINITI	ALL	11/2005	INFINITI Q45	F50		METER/M&A		X	X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	11/2005	INFINITI Q45	F50		ICC		X	X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		HVAC		X	X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		MULTI AV		X	X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		EPS		X	X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	11/2005	INFINITI Q45	F50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	11/2005	INFINITI Q45	F50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	11/2005	INFINITI Q45	F50		e-4WD		X	X	X	X	X	
INFINITI	ALL	11/2005	INFINITI Q45	F50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	11/2005	INFINITI Q45	F50		DIU		X	X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	11/2005	INFINITI Q45	F50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	11/2005	INFINITI Q45	F50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	11/2005	INFINITI Q45	F50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	11/2005	INFINITI Q45	F50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	11/2005	INFINITI Q45	F50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		ASCD			X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		HCM			X	X	X		
INFINITI	ALL	11/2005	INFINITI Q45	F50		LDW			X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	08/2004	INFINITI Q45	F50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		ABS		X	X	X	X	X	
INFINITI	ALL	08/2004	INFINITI Q45	F50		AIRBAG		X	X	X			
INFINITI	ALL	08/2004	INFINITI Q45	F50		BCM		X	X	X	X	X	
INFINITI	ALL	08/2004	INFINITI Q45	F50		METER/M&A		X	X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	08/2004	INFINITI Q45	F50		ICC		X	X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		HVAC		X	X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		MULTI AV		X	X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		EPS		X	X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	08/2004	INFINITI Q45	F50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	08/2004	INFINITI Q45	F50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	08/2004	INFINITI Q45	F50		e-4WD		X	X	X	X	X	
INFINITI	ALL	08/2004	INFINITI Q45	F50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	08/2004	INFINITI Q45	F50		DIU		X	X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	08/2004	INFINITI Q45	F50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	08/2004	INFINITI Q45	F50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	08/2004	INFINITI Q45	F50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	08/2004	INFINITI Q45	F50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	08/2004	INFINITI Q45	F50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		ASCD			X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		HCM			X	X	X		
INFINITI	ALL	08/2004	INFINITI Q45	F50		LDW			X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	08/2003	INFINITI Q45	F50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		ABS		X	X	X	X	X	
INFINITI	ALL	08/2003	INFINITI Q45	F50		AIRBAG		X	X	X			
INFINITI	ALL	08/2003	INFINITI Q45	F50		BCM		X	X	X	X	X	
INFINITI	ALL	08/2003	INFINITI Q45	F50		METER/M&A		X	X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		METER ACAMP		X	X	X	X	X	

INFINITI	ALL	08/2003	INFINITI Q45	F50		ICC		X	X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		HVAC		X	X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		MULTI AV		X	X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		EPS		X	X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	08/2003	INFINITI Q45	F50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	08/2003	INFINITI Q45	F50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	08/2003	INFINITI Q45	F50		e-4WD		X	X	X	X	X	
INFINITI	ALL	08/2003	INFINITI Q45	F50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	08/2003	INFINITI Q45	F50		DIU		X	X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	08/2003	INFINITI Q45	F50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	08/2003	INFINITI Q45	F50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	08/2003	INFINITI Q45	F50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	08/2003	INFINITI Q45	F50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	08/2003	INFINITI Q45	F50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		ASCD			X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		HCM			X	X	X		
INFINITI	ALL	08/2003	INFINITI Q45	F50		LDW			X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	09/2002	INFINITI Q45	F50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		ABS		X	X	X	X	X	
INFINITI	ALL	09/2002	INFINITI Q45	F50		AIRBAG		X	X	X			
INFINITI	ALL	09/2002	INFINITI Q45	F50		BCM		X	X	X	X	X	
INFINITI	ALL	09/2002	INFINITI Q45	F50		METER/M&A		X	X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	09/2002	INFINITI Q45	F50		ICC		X	X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		HVAC		X	X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		MULTI AV		X	X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		EPS		X	X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	09/2002	INFINITI Q45	F50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	09/2002	INFINITI Q45	F50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	09/2002	INFINITI Q45	F50		e-4WD		X	X	X	X	X	
INFINITI	ALL	09/2002	INFINITI Q45	F50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	09/2002	INFINITI Q45	F50		DIU		X	X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	09/2002	INFINITI Q45	F50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	09/2002	INFINITI Q45	F50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	09/2002	INFINITI Q45	F50		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	09/2002	INFINITI Q45	F50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	09/2002	INFINITI Q45	F50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		ASCD			X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		HCM			X	X	X		
INFINITI	ALL	09/2002	INFINITI Q45	F50		LDW			X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	08/2001	INFINITI Q45	F50		TRANSMISSION		X	X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		ABS		X	X	X	X	X	
INFINITI	ALL	08/2001	INFINITI Q45	F50		AIRBAG		X	X	X			
INFINITI	ALL	08/2001	INFINITI Q45	F50		BCM		X	X	X	X	X	
INFINITI	ALL	08/2001	INFINITI Q45	F50		METER/M&A		X	X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	08/2001	INFINITI Q45	F50		ICC		X	X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		HVAC		X	X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		MULTI AV		X	X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		EPS		X	X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	08/2001	INFINITI Q45	F50		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	08/2001	INFINITI Q45	F50		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	08/2001	INFINITI Q45	F50		e-4WD		X	X	X	X	X	
INFINITI	ALL	08/2001	INFINITI Q45	F50		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	08/2001	INFINITI Q45	F50		DIU		X	X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	08/2001	INFINITI Q45	F50		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	08/2001	INFINITI Q45	F50		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	08/2001	INFINITI Q45	F50		ADAPTIVE LIGHT		X	X	X	X	X	

INFINITI	ALL	08/2001	INFINITI Q45	F50		SMART ENTRANCE		X	X	X			
INFINITI	ALL	08/2001	INFINITI Q45	F50		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		ASCD			X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		HCM			X	X	X		
INFINITI	ALL	08/2001	INFINITI Q45	F50		LDW			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	ALL	INFINITI QX4	2003		TRANSMISSION		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		ABS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2003		AIRBAG		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	2003		BCM		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2003		METER/M&A		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2003		ICC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		HVAC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		MULTI AV		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		EPS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2003		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2003		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2003		e-4WD		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2003		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2003		DIU		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2003		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2003		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2003		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2003		SMART ENTRANCE		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	2003		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		ASCD			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		HCM			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2003		LDW			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	ALL	INFINITI QX4	2002		TRANSMISSION		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		ABS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2002		AIRBAG		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	2002		BCM		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2002		METER/M&A		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2002		ICC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		HVAC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		MULTI AV		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		EPS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2002		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2002		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2002		e-4WD		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2002		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2002		DIU		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2002		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2002		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2002		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2002		SMART ENTRANCE		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	2002		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		ASCD			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		HCM			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2002		LDW			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	ALL	INFINITI QX4	2001		TRANSMISSION		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		ABS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2001		AIRBAG		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	2001		BCM		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2001		METER/M&A		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		METER ACAMP		X	X	X	X	X	

INFINITI	ALL	ALL	INFINITI QX4	2001		ICC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		HVAC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		MULTI AV		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		EPS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2001		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2001		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2001		e-4WD		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2001		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2001		DIU		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2001		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2001		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2001		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2001		SMART ENTRANCE		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	2001		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		ASCD			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		HCM			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2001		LDW			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	ALL	INFINITI QX4	2000		TRANSMISSION		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		ABS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2000		AIRBAG		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	2000		BCM		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2000		METER/M&A		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2000		ICC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		HVAC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		MULTI AV		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		EPS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2000		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2000		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2000		e-4WD		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2000		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2000		DIU		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2000		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2000		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2000		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	2000		SMART ENTRANCE		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	2000		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		ASCD			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		HCM			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	2000		LDW			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	ALL	INFINITI QX4	1999		TRANSMISSION		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		ABS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1999		AIRBAG		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	1999		BCM		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1999		METER/M&A		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1999		ICC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		HVAC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		MULTI AV		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		EPS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1999		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1999		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1999		e-4WD		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1999		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1999		DIU		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1999		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1999		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1999		ADAPTIVE LIGHT		X	X	X	X	X	

INFINITI	ALL	ALL	INFINITI QX4	1999		SMART ENTRANCE		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	1999		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		ASCD			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		HCM			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1999		LDW			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	ALL	INFINITI QX4	1998		TRANSMISSION		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		ABS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1998		AIRBAG		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	1998		BCM		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1998		METER/M&A		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1998		ICC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		HVAC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		MULTI AV		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		EPS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1998		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1998		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1998		e-4WD		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1998		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1998		DIU		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1998		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1998		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1998		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1998		SMART ENTRANCE		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	1998		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		ASCD			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		HCM			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1998		LDW			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	ALL	INFINITI QX4	1997		TRANSMISSION		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		ABS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1997		AIRBAG		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	1997		BCM		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1997		METER/M&A		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1997		ICC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		HVAC		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		MULTI AV		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		EPS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1997		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1997		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1997		e-4WD		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1997		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1997		DIU		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1997		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1997		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1997		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	ALL	INFINITI QX4	1997		SMART ENTRANCE		X	X	X			
INFINITI	ALL	ALL	INFINITI QX4	1997		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		ASCD			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		HCM			X	X	X		
INFINITI	ALL	ALL	INFINITI QX4	1997		LDW			X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	2010	INFINITI QX56	Z62		TRANSMISSION		X	X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		ABS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		AIRBAG		X	X	X			
INFINITI	ALL	2010	INFINITI QX56	Z62		BCM		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		METER/M&A		X	X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		METER ACAMP		X	X	X	X	X	

INFINITI	ALL	2010	INFINITI QX56	Z62		ICC		X	X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		HVAC		X	X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		MULTI AV		X	X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		EPS		X	X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		e-4WD		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		DIU		X	X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		SMART ENTRANCE		X	X	X			
INFINITI	ALL	2010	INFINITI QX56	Z62		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		ASCD			X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		HCM			X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		LDW			X	X	X		
INFINITI	ALL	2010	INFINITI QX56	Z62		ACCELE PEDAL ACT		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		E-SUS		X	X	X	X	X	
INFINITI	ALL	2010	INFINITI QX56	Z62		LASER		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	04/2008	INFINITI QX56	JA60		TRANSMISSION		X	X	X	X		
INFINITI	ALL	04/2008	INFINITI QX56	JA60		ABS		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		AIRBAG		X	X	X			
INFINITI	ALL	04/2008	INFINITI QX56	JA60		BCM		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		METER/M&A		X	X	X	X		
INFINITI	ALL	04/2008	INFINITI QX56	JA60		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		ICC		X	X	X	X		
INFINITI	ALL	04/2008	INFINITI QX56	JA60		HVAC		X	X	X	X		
INFINITI	ALL	04/2008	INFINITI QX56	JA60		MULTI AV		X	X	X	X		
INFINITI	ALL	04/2008	INFINITI QX56	JA60		EPS		X	X	X	X		
INFINITI	ALL	04/2008	INFINITI QX56	JA60		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		e-4WD		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		DIU		X	X	X	X		
INFINITI	ALL	04/2008	INFINITI QX56	JA60		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		PRECRASH SEATBELT		X	X	X	X		
INFINITI	ALL	04/2008	INFINITI QX56	JA60		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	04/2008	INFINITI QX56	JA60		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	04/2008	INFINITI QX56	JA60		SMART ENTRANCE		X	X	X			
INFINITI	ALL	04/2008	INFINITI QX56	JA60		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	04/2008	INFINITI QX56	JA60		ASCD			X	X	X		
INFINITI	ALL	04/2008	INFINITI QX56	JA60		HCM			X	X	X		
INFINITI	ALL	04/2008	INFINITI QX56	JA60		LDW			X	X	X		
INFINITI	ALL	08/2007	INFINITI QX56	JA60		ENGINE		X	X	X	X	X	1.TP/SW SEN IDLE POSI ADJ 2.IGNITION TIMING ADJ 3.FUEL PRESSURE RELEASE 4.IDLE AIR VOL LEARN 5.TARGET IGN TIM ADJ 6.TARGET IDLE PRM ADJ
INFINITI	ALL	08/2007	INFINITI QX56	JA60		TRANSMISSION		X	X	X	X		
INFINITI	ALL	08/2007	INFINITI QX56	JA60		ABS		X	X	X	X	X	
INFINITI	ALL	08/2007	INFINITI QX56	JA60		AIRBAG		X	X	X			
INFINITI	ALL	08/2007	INFINITI QX56	JA60		BCM		X	X	X	X	X	
INFINITI	ALL	08/2007	INFINITI QX56	JA60		METER/M&A		X	X	X	X		
INFINITI	ALL	08/2007	INFINITI QX56	JA60		METER ACAMP		X	X	X	X	X	
INFINITI	ALL	08/2007	INFINITI QX56	JA60		ICC		X	X	X	X		
INFINITI	ALL	08/2007	INFINITI QX56	JA60		HVAC		X	X	X	X		
INFINITI	ALL	08/2007	INFINITI QX56	JA60		MULTI AV		X	X	X	X		
INFINITI	ALL	08/2007	INFINITI QX56	JA60		EPS		X	X	X	X		
INFINITI	ALL	08/2007	INFINITI QX56	JA60		IPDM E/R		X	X	X	X	X	
INFINITI	ALL	08/2007	INFINITI QX56	JA60		AIR PRESSURE MONITOR		X	X	X	X	X	
INFINITI	ALL	08/2007	INFINITI QX56	JA60		HEAD LAMP LEVELIZER		X	X	X	X	X	
INFINITI	ALL	08/2007	INFINITI QX56	JA60		e-4WD		X	X	X	X	X	
INFINITI	ALL	08/2007	INFINITI QX56	JA60		INTELLIGENT KEY		X	X	X	X	X	
INFINITI	ALL	08/2007	INFINITI QX56	JA60		DIU		X	X	X	X		
INFINITI	ALL	08/2007	INFINITI QX56	JA60		AUTO DRIVE POS		X	X	X	X	X	
INFINITI	ALL	08/2007	INFINITI QX56	JA60		AUTO SLIDE POS		X	X	X	X	X	
INFINITI	ALL	08/2007	INFINITI QX56	JA60		PRECRASH SEATBELT		X	X	X	X		

INFINITI	ALL	08/2007	INFINITI QX56	JA60		ALL MODE AWD/4WD		X	X	X	X		
INFINITI	ALL	08/2007	INFINITI QX56	JA60		4WAS(MAIN)/RAS/HICAS		X	X	X	X	X	
INFINITI	ALL	08/2007	INFINITI QX56	JA60		ADAPTIVE LIGHT		X	X	X	X	X	
INFINITI	ALL	08/2007	INFINITI QX56	JA60		SMART ENTRANCE		X	X	X			
INFINITI	ALL	08/2007	INFINITI QX56	JA60		ACTIVE SUS		X	X	X	X		
INFINITI	ALL	08/2007	INFINITI QX56	JA60		ASCD			X	X	X		
INFINITI	ALL	08/2007	INFINITI QX56	JA60		HCM			X	X	X		
INFINITI	ALL	08/2007	INFINITI QX56	JA60		LDW			X	X	X		