

| ·FCAR 爱夫卡 FCAR F3 Diagnostic list (Note: for reference only) | | | | | | | Automaker: | CAT | | |
|---|----------------------------|---------------|-----------------------|----------------------|-----------------|------------------|------------------|----------------|-------------------|---|
| | | | | | | | Version: | V6.30 | | |
| Model | System | System | System | Function | | | | | | |
| | | | | Read ECU Information | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Read Freeze Frame | Remarks (Other functions) |
| CAT | CAT construction machinery | 320D/323D | Engine control module | √ | – | – | √ | – | – | configuration, advanced function |
| | | | Hydraulic system | √ | √ | – | √ | √ | – | – |
| | | 312 | Engine control module | √ | – | – | √ | – | – | Injector data, configuration, advanced function |
| | | | Hydraulic system | √ | √ | – | √ | √ | – | – |
| | | 320C/323C | | √ | √ | – | √ | √ | – | configuration |
| | | 385C/385D | Engine control module | √ | – | – | √ | – | – | Injector data, configuration, advanced function |
| | | | Hydraulic system | √ | √ | – | √ | √ | – | – |
| | | 330C/330D | Engine control module | √ | √ | – | √ | – | – | Injector data |
| | | | Hydraulic system | √ | √ | – | √ | √ | – | – |
| | | | Monitor system | √ | – | – | – | – | – | – |
| | | CAT 325D/329D | Engine control module | √ | √ | – | √ | – | – | Injector data |
| | | | Hydraulic system | √ | √ | – | √ | √ | – | – |
| | | | Monitor system | √ | – | – | – | – | – | – |
| CAT bus | | | | √ | √ | – | √ | √ | – | – |

| | | | | | | | | | |
|----------------|--|-----------------------|---|---|---|---|---|---|---|
| CAT heavy duty | | Engine control module | ✓ | - | - | ✓ | - | - | - |
| CAT detection | | Hydraulic system | ✓ | ✓ | - | ✓ | ✓ | - | - |

Remark: ✓ means the system supports the function, -mean not