

Honda Acura

GIT Vehicle Coverage Table

As of July. 1st. 2013

[illegible]

Honda Acura

GIT Vehicle Coverage Table

As of July. 1st. 2013

16PIN CONNECTOR										Connector Type	
System 1	ABS	Type 2	V	V	V	V		V		Sub System DTC Analysis Freeze frame Data Analysis Actuator ECU Information Display ECU Reset SCS Short Mode ALL SENSORS VSA SENSOR NEUTRAL POSITION MEMORIZATION Torque Sensor Learn REWRITE KEYS ALL KEYS LOST REWRITE KEYS ALL KEYS LOST System Check Number of Key Key Type Keyless Transmitter Registration IQA Data Status IQA Data Write DPF Regeneration DPF Differential Pressure Sensor Initial Learn Reset Calculated PM Value CRANK (CKP) PATTERN CLEAR CRANK (CKP) PATTERN LEARNING CRANK (CKP) PATTERN CLEAR CRANK (CKP) PATTERN LEARNING TP Position Check (TP learning Value Reset) FUEL PUMP ON TEST ONE INJECTOR ALL INJECTORS A/C CLUTCH TEST OPDS Initialization Power Window Reset for Driver side Power Window Reset for Passenger side Power Window Reset for Left Rear Power Window Reset for Right Rear EGR test Cruise Control Cancel History ETCS (TAC) TEST FUEL PUMP OFF TEST Shift Solenoid A Test Shift Solenoid B Test Shift Solenoid C Test Shift Solenoid D Test	
		Type 3	V	V		V					
		Type 4	V	V	V						
		VSA Tyoe 1	V	V	V	V		V			
		VSA Tyoe 2	V	V	V	V		V	V		
		VSA Tyoe 3	V	V	V	V		V			
	SRS Airbag	VSA Tyoe 4	V	V							
		Type 1	V	V							
	EPS	Type 2	V	V	V						
		Type 1	V	V	V						
SH-AWD	Type 2	V		V							
	Type 2	V		V							
	Type 3	V	V	V			V				
	Type 1	V	V	V							
	Type 2	V	V	V							
	Type 3	V	V	V							
	Type 4	V	V	V							
	Type 5	V	V	V							
VTM 4 POP-UP HOOD TPMS EVPS	Type 6	V	V	V							
	Type 7	V	V	V							
		V			V						
		V	V		V						

Honda Acura

GIT Vehicle Coverage Table

As of July. 1st. 2013

[illegible]

16PIN CONNECTOR	Connector Type																					
	System 1	Sub System	Shift Solenoid E Test	Pressure Test Assistance Mode	Shift Lock Solenoid Test	Clutch Pressure Control Solenoid Valve Control	Clutch Pressure Control (Linear) Solenoid Valve A Test	Clutch Pressure Control (Linear) Solenoid Valve B Test	Clutch Pressure Control (Linear) Solenoid Valve C Test	Clutch Pressure Control (Linear) Solenoid Valve D Test	Shift Solenoid Test	Acceleration Device Test	Clutch Coil Test	Differential Torque Calibration	YAW Rate/Lateral Acceleration Sensor Calibration	Steering Angle Sensor Calibration	SH-AWD Initialization	All Sensor Calibration	Seat Output Check	SWS Initialization	Inhibitor Solenoid	Shift Lock Solenoid Test
16PIN CONNECTOR	Engine	Type 1																				
		Type 2																				
		Type 3																				
		Type 4																				
		Type 5																				
	Diesel	Type 1																				
		Type 2																				
	AT	Type 1	V	V	V	V	V	V	V	V												
		Type 2	V		V																	
		Type 3																				
	IMA																					
	ACM																					
	CVT	Type 1																				
		Type 2																				
		Type 3																				
	Immobilizer/One Push Start																					
		Backup Unit																				
		SLOT Control Unit																				
		Control Unit																				
	ABS	Type 1																				
			Start Clutch Status Data Clear																			
			Start Clutch Status Feedback Learn																			
			ACM Reset																			
			VTC Test																			
			EGR Test																			
			Injector Test																			
			Fuel Heater ON/OFF																			
			ACG ON/OFF																			
			Glow ON/OFF																			
			MAF Sensor Learning Clear																			
			A/F Sensor Learning Clear																			
			ISV Forced Learning																			
			Keyless Check																			
			History Data																			
			History Data Clear																			
			Initialization																			
			Service Reminder (USA)																			
			PAX Warning Reset (USA)																			
			ODS Initialization																			
			Add A KEYLESS ACCESS Remote																			
			Rewrite KEYLESS ACCESS Remotes																			
			All KEYLESS ACCESS Remotes Lost																			
			Self Check																			
			System Check																			
			Number of KEYLESS ACCESS Remotes																			

Honda Acura

GIT Vehicle Coverage Table

As of July. 1st. 2013

[illegible]

Honda Acura

GIT Vehicle Coverage Table

As of July. 1st. 2013

[illegible]

[illegible]

[illegible]

[illegible]