

Area	Vehicle	System	DTC Analysis	Data Analysis	Actuator	ECU Information	Read IQA Code	Write IQA Code	Adjust Idle	ECU replacement	ECU reset	Write VIN	Write IQA Values	Bolero_Write C3I Values	Bolero_Write Parameter	Air Bleeding	Read configuration	Enter injector codes	Injector adaptives	Fuel supply prevention	Stop fuel supply prevention	Rail pressure sensor adaptives	Pressure regulation adaptives	EGR valve programming	Air path programming	Particle filter relative pressure sensor	Fuel flow regulator	Exhaust injector circuit	Air damper valve programming	Engine adaptives	Camshaft sensor programming	Flywheel target programming	Cruise control/speed limiter programming	Cabin filter regeneration	Write date of after sales operation	Flashing buzzer	Lock computer	Unlock computer				
Mahindra	XUV500	ITM	V							V																																
		IS	V							V																																
	ABS	All	V	V		V										V																										
	Immo	All	V																																							
	MBFM(Remote)	All	V			V																																				
Renault	LOGAN	Gasoline	V	V	V	V											V	V		V	V																					
		Diesel	V	V	V	V												V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V								
		GAS	V	V	V	V												V																								
		ABS	V	V	V	V												V																								
		Variable P.A.S	V	V	V	V												V																								
		UCH	V	V	V	V												V																								
		Airbag / Pretensioners	V	V	V	V												V																								