

Seat V24.66 Diagnostics List (Note: For reference only)

MODEL	SYSTEM	TYPE	Functions					
			System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special functions
	03 Brake Electronics	(..-03)	✓	✓	✓	✓	✓	✓
	03 Brake Electronics	(01-..)	✓	✓	✓	✓	✓	✓
	15 Airbags	(..-03)	✓	✓	✓	✓	✓	✓
	25 Immobilizer	(..-00)	✓	✓	✓	✓	✓	✓
	49 Auto. Lighting switch	(..-00)	✓	✓	✓	✓	✓	✓
	02 Transmission ElectronicsI	(..-00)	✓	✓	✓	✓	✓	✓
	7D Auxiliary Heater	(..-00)	✓	✓	✓	✓	✓	✓
	71 Battery charger	(..-00)	✓	✓	✓	✓	✓	✓
	61 Battery control	(..-00)	✓	✓	✓	✓	✓	✓
	43 BRAKER BOOST.ASSI.	(..-00)	✓	✓	✓	✓	✓	✓
	46 Central Control Module	(..-00)	✓	✓	✓	✓	✓	✓
	CLIMA	(..-03)	✓	✓	✓	✓	✓	✓
	CLUTCH ELECTRONI	(..-00)	✓	✓	✓	✓	✓	✓
	COMFORT SYSTEM	(..-03)	✓	✓	✓	✓	✓	✓
	CONV. TOP/SUNROO	(..-00)	✓	✓	✓	✓	✓	✓
	CRUISE CONTROL	(..-00)	✓	✓	✓	✓	✓	✓
	DASHBOARD	(..-00)	✓	✓	✓	✓	✓	✓
	DRIVER FOOT BOAR	(..-00)	✓	✓	✓	✓	✓	✓
	DRIVER SEAT CONTR	(..-00)	✓	✓	✓	✓	✓	✓
	DRIVER SIDE DOOR	(..-00)	✓	✓	✓	✓	✓	✓
	ELECTRIC ACTUATIO	(..-00)	✓	✓	✓	✓	✓	✓
	ELECTRIC STEERING	(..-03)	✓	✓	✓	✓	✓	✓
	EMERGENCY CALL	(..-00)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓

Seat **V24.66** Diagnostics List

(Note: For reference only)

MODEL	SYSTEM	TYPE	Functions					
			System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special functions
Alhambra	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.8 20V T 110kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 TDI S 66kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 TDI S 85kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 2.0 85kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 2.8 V6 150kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-00)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-00)	✓	✓	✓	✓	✓	✓
	FRONT CONTR.INDIC	(..-00)	✓	✓	✓	✓	✓	✓
	HEADLIGHT LEVEL	(..-03)	✓	✓	✓	✓	✓	✓
	IMMOBILIZER	(..-00)	✓	✓	✓	✓	✓	✓
	LEFT REAR DOOR	(..-00)	✓	✓	✓	✓	✓	✓
	LH RIGHT MODULATI	(..-00)	✓	✓	✓	✓	✓	✓
	NAVIGATION	(..-00)	✓	✓	✓	✓	✓	✓
	PARK.BRAKE	(..-00)	✓	✓	✓	✓	✓	✓
	PARKING HELP	(..-00)	✓	✓	✓	✓	✓	✓
	PASS. SIDE DOOR	(..-00)	✓	✓	✓	✓	✓	✓
	PASS.FOOT BOARD	(..-00)	✓	✓	✓	✓	✓	✓
	PASSIVE ENTRY	(..-00)	✓	✓	✓	✓	✓	✓
	POWER BRAKE	(..-00)	✓	✓	✓	✓	✓	✓
	RADIO / CD	(..-03)	✓	✓	✓	✓	✓	✓
	REAR CONTROL INDI	(..-00)	✓	✓	✓	✓	✓	✓
	RH LIGHT MODULATI	(..-00)	✓	✓	✓	✓	✓	✓
	RIGHT REAR DOOR	(..-00)	✓	✓	✓	✓	✓	✓
	SEAT/MIRROR POS.	(..-00)	✓	✓	✓	✓	✓	✓

Seat **V24.66** Diagnostics List

(Note: For reference only)

MODEL	SYSTEM	TYPE	Functions					
			System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special functions
	SERVICE LIGHT RES	(..-6/98)	✓	✓	✓	✓	✓	✓
	SERVICE LIGHT RES	(99-..)	✓	✓	✓	✓	✓	✓
	SOUND SYSTEM	(..-00)	✓	✓	✓	✓	✓	✓
	STEERING WHEEL	(..-00)	✓	✓	✓	✓	✓	✓
	SUSPENSION CONTR	(..-00)	✓	✓	✓	✓	✓	✓
	SWITCH PANEL	(..-00)	✓	✓	✓	✓	✓	✓
	TRACTION CONTROL	(..-00)	✓	✓	✓	✓	✓	✓
	VOICE CONTROL	(..-00)	✓	✓	✓	✓	✓	✓
Altea	03 Brake Electronics	(04-..)	✓	✓	✓	✓	✓	✓
	15 Airbags	(04-..)	✓	✓	✓	✓	✓	✓
	7D Auxiliary Heater	(04-..)	✓	✓	✓	✓	✓	✓
	CENTRAL ELECTRIC	(04-..)	✓	✓	✓	✓	✓	✓
	CLIMA	(04-..)	✓	✓	✓	✓	✓	✓
	COMFORT SYSTEM	(04-..)	✓	✓	✓	✓	✓	✓
	CONV. TOP/SUNROO	(04-..)	✓	✓	✓	✓	✓	✓
	DASHBOARD	(04-..)	✓	✓	✓	✓	✓	✓
	DRIVER SIDE DOOR	(04-..)	✓	✓	✓	✓	✓	✓
	ELECTRIC STEERING	(04-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 TDI BKC	(04-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 2.0 TDI BKD	(04-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(04-..)	✓	✓	✓	✓	✓	✓
	IMMOBILIZER	(04-..)	✓	✓	✓	✓	✓	✓
	LEFT REAR DOOR	(04-..)	✓	✓	✓	✓	✓	✓
	PASS. SIDE DOOR	(04-..)	✓	✓	✓	✓	✓	✓
	RADIO / CD	(04-..)	✓	✓	✓	✓	✓	✓

Seat V24.66 Diagnostics List (Note: For reference only)

MODEL	SYSTEM	TYPE	Functions					
			System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special functions
	RIGHT REAR DOOR	(04-..)	✓	✓	✓	✓	✓	✓
	SERVICE LIGHT RES	(04-..)	✓	✓	✓	✓	✓	✓
	STEERING WHEEL	(04-..)	✓	✓	✓	✓	✓	✓
	03 Brake Electronics	(..-03)	✓	✓	✓	✓	✓	✓
	03 Brake Electronics	(01-..)	✓	✓	✓	✓	✓	✓
	15 Airbags	(..-03)	✓	✓	✓	✓	✓	✓
	25 Immobilizer	(..-00)	✓	✓	✓	✓	✓	✓
	02 Transmission Electronics	(..-00)	✓	✓	✓	✓	✓	✓
	7D Auxiliary Heater	(..-00)	✓	✓	✓	✓	✓	✓
	71 Battery charger	(..-00)	✓	✓	✓	✓	✓	✓
	61 Battery control	(..-00)	✓	✓	✓	✓	✓	✓
	43 BRAKER BOOST.ASSI.	(..-00)	✓	✓	✓	✓	✓	✓
	46 Central Control Module	(..-00)	✓	✓	✓	✓	✓	✓
	CHASSIS NETWORK	(..-03)	✓	✓	✓	✓	✓	✓
	CLIMA	(..-03)	✓	✓	✓	✓	✓	✓
	CLUTCH ELECTRONI	(..-00)	✓	✓	✓	✓	✓	✓
	COMFORT SYSTEM	(..-03)	✓	✓	✓	✓	✓	✓
	CONV. TOP/SUNROO	(..-00)	✓	✓	✓	✓	✓	✓
	CRUISE CONTROL	(..-00)	✓	✓	✓	✓	✓	✓
	DASHBOARD	(..-00)	✓	✓	✓	✓	✓	✓
	DISTANCE REGULATI	(..-00)	✓	✓	✓	✓	✓	✓
	DRIVER FOOT BOAR	(..-00)	✓	✓	✓	✓	✓	✓
	DRIVER SEAT CONTR	(..-00)	✓	✓	✓	✓	✓	✓
	DRIVER SIDE DOOR	(..-00)	✓	✓	✓	✓	✓	✓
	ELECTRIC ACTUATIO	(..-00)	✓	✓	✓	✓	✓	✓

Seat **V24.66** Diagnostics List

(Note:For reference only)

MODEL	SYSTEM	TYPE	Functions					
			System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Specail functions
Arosa	ELECTRIC STEERING	(..-03)	✓	✓	✓	✓	✓	✓
	EMERGENCY CALL	(..-00)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.0 37kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.4 16v 74kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.4 44kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.4 SDI 44kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.4 TDI 55kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-00)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-00)	✓	✓	✓	✓	✓	✓
	FRONT CONTR.INDIC	(..-00)	✓	✓	✓	✓	✓	✓
	HEADLIGHT LEVEL	(..-03)	✓	✓	✓	✓	✓	✓
	IMMOBILIZER	(..-00)	✓	✓	✓	✓	✓	✓
	LH RIGHT MODULATI	(..-00)	✓	✓	✓	✓	✓	✓
	NAVIGATION	(..-00)	✓	✓	✓	✓	✓	✓
	PARK.BRAKE	(..-00)	✓	✓	✓	✓	✓	✓
	PARKING HELP	(..-00)	✓	✓	✓	✓	✓	✓
	PASS. SIDE DOOR	(..-00)	✓	✓	✓	✓	✓	✓
	PASS.FOOT BOARD	(..-00)	✓	✓	✓	✓	✓	✓
	PASSIVE ENTRY	(..-00)	✓	✓	✓	✓	✓	✓
	POWER BRAKE	(..-00)	✓	✓	✓	✓	✓	✓
	RADIO / CD	(..-03)	✓	✓	✓	✓	✓	✓
	REAR CONTROL INDI	(..-00)	✓	✓	✓	✓	✓	✓

Seat V24.66 Diagnostics List (Note: For reference only)

MODEL	SYSTEM	TYPE	Functions					
			System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special functions
	RH LIGHT MODULATI	(..-00)	✓	✓	✓	✓	✓	✓
	SEAT/MIRROR POS.	(..-00)	✓	✓	✓	✓	✓	✓
	SERVICE LIGHT RES	(99-..)	✓	✓	✓	✓	✓	✓
	SOUND SYSTEM	(..-00)	✓	✓	✓	✓	✓	✓
	STEERING WHEEL	(..-00)	✓	✓	✓	✓	✓	✓
	SUSPENSION CONTR	(..-00)	✓	✓	✓	✓	✓	✓
	TRACTION CONTROL	(..-00)	✓	✓	✓	✓	✓	✓
	TV SYSTEM	(..-00)	✓	✓	✓	✓	✓	✓
	VOICE CONTROL	(..-00)	✓	✓	✓	✓	✓	✓
Cordoba	03 Brake Electronics	(..-03)	✓	✓	✓	✓	✓	✓
	03 Brake Electronics	(01-..)	✓	✓	✓	✓	✓	✓
	15 Airbags	(..-03)	✓	✓	✓	✓	✓	✓
	02 Transmission Electronics	(..-00)	✓	✓	✓	✓	✓	✓
	46 Central Control Module	(..-00)	✓	✓	✓	✓	✓	✓
	CHASSIS NETWORK	(..-03)	✓	✓	✓	✓	✓	✓
	CLIMA	(..-03)	✓	✓	✓	✓	✓	✓
	DASHBOARD	(..-00)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.4 16v 55kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.4 44kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.6 74kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.8 20v Turbo 115kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 SDI 50kW	(01-..)	✓	✓	✓	✓	✓	✓

Seat **V24.66** Diagnostics List (Note: For reference only)

MODEL	SYSTEM	TYPE	Functions					
			System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special functions
	ENGINE MANAGEME 1.9 TDI 66kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 TDI 81kW	(01-..)	✓	✓	✓	✓	✓	✓
	IMMOBILIZER	(..-00)	✓	✓	✓	✓	✓	✓
	SERVICE LIGHT RES	(93-95)	✓	✓	✓	✓	✓	✓
	SERVICE LIGHT RES	(99-..)	✓	✓	✓	✓	✓	✓
Ibiza	03 Brake Electronics	(..-03)	✓	✓	✓	✓	✓	✓
	03 Brake Electronics	(01-..)	✓	✓	✓	✓	✓	✓
	15 Airbags	(..-03)	✓	✓	✓	✓	✓	✓
	25 Immobilizer	(..-00)	✓	✓	✓	✓	✓	✓
	02 Transmission Electronics	(..-00)	✓	✓	✓	✓	✓	✓
	7D Auxiliary Heater	(..-00)	✓	✓	✓	✓	✓	✓
	46 Central Control Module	(..-00)	✓	✓	✓	✓	✓	✓
	CHASSIS NETWORK	(..-03)	✓	✓	✓	✓	✓	✓
	CLIMA	(..-03)	✓	✓	✓	✓	✓	✓
	CLUTCH ELECTRONI	(..-00)	✓	✓	✓	✓	✓	✓
	COMFORT SYSTEM	(..-03)	✓	✓	✓	✓	✓	✓
	CONV. TOP/SUNROO	(..-00)	✓	✓	✓	✓	✓	✓
	CRUISE CONTROL	(..-00)	✓	✓	✓	✓	✓	✓
	DASHBOARD	(..-00)	✓	✓	✓	✓	✓	✓
	DRIVER SEAT CONTR	(..-00)	✓	✓	✓	✓	✓	✓
	ELECTRIC STEERING	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.4 16v 55kW	(01-..)	✓	✓	✓	✓	✓	✓

Seat **V24.66** Diagnostics List

(Note: For reference only)

MODEL	SYSTEM	TYPE	Functions					
			System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special functions
	ENGINE MANAGEME 1.4 44kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.6 74kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.8 20V Turbo 115kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 TDI 44kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 TDI 66kW	(01-..)	✓	✓	✓	✓	✓	✓
	HEADLIGHT LEVEL	(..-03)	✓	✓	✓	✓	✓	✓
	IMMOBILIZER	(..-00)	✓	✓	✓	✓	✓	✓
	PARKING HELP	(..-00)	✓	✓	✓	✓	✓	✓
	RADIO / CD	(..-03)	✓	✓	✓	✓	✓	✓
	SEAT/MIRROR POS.	(..-00)	✓	✓	✓	✓	✓	✓
	SERVICE LIGHT RES	(02-..)	✓	✓	✓	✓	✓	✓
	SERVICE LIGHT RES	(93-95)	✓	✓	✓	✓	✓	✓
	SERVICE LIGHT RES	(99-01)	✓	✓	✓	✓	✓	✓
	STEERING WHEEL	(..-00)	✓	✓	✓	✓	✓	✓
	SUSPENSION CONTR	(..-00)	✓	✓	✓	✓	✓	✓
	TRACTION CONTROL	(..-00)	✓	✓	✓	✓	✓	✓
Inca	03 Brake Electronics	(..-03)	✓	✓	✓	✓	✓	✓
	15 Airbags	(..-03)	✓	✓	✓	✓	✓	✓
	CLIMA	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.4 16v 55kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.4 44kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 SDI 47kW	(01-..)	✓	✓	✓	✓	✓	✓

Seat **V24.66** Diagnostics List

(Note: For reference only)

MODEL	SYSTEM	TYPE	Functions					
			System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special functions
	IMMOBILIZER	(..-00)	✓	✓	✓	✓	✓	✓
	SERVICE LIGHT RES	(93-95)	✓	✓	✓	✓	✓	✓
Leon	03 Brake Electronics	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.4 16v 55kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.6 16v 77kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.8 20v 92kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.8 20v T 132kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 SDI 50kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 TDI 66kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 TDI 81kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 2.8 V6 150kW	(01-..)	✓	✓	✓	✓	✓	✓
	SERVICE LIGHT RES	(99-..)	✓	✓	✓	✓	✓	✓
New Toledo	03 Brake Electronics	(04-..)	✓	✓	✓	✓	✓	✓
	15 Airbags	(04-..)	✓	✓	✓	✓	✓	✓
	7D Auxiliary Heater	(04-..)	✓	✓	✓	✓	✓	✓
	CENTRAL ELECTRIC	(04-..)	✓	✓	✓	✓	✓	✓
	CLIMA	(04-..)	✓	✓	✓	✓	✓	✓
	COMFORT SYSTEM	(04-..)	✓	✓	✓	✓	✓	✓
	CONV. TOP/SUNROO	(04-..)	✓	✓	✓	✓	✓	✓
	DASHBOARD	(04-..)	✓	✓	✓	✓	✓	✓
	DRIVER SIDE DOOR	(04-..)	✓	✓	✓	✓	✓	✓
	ELECTRIC STEERING	(04-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(04-..)	✓	✓	✓	✓	✓	✓

Seat V24.66 Diagnostics List (Note: For reference only)

MODEL	SYSTEM	TYPE	Functions					
			System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special functions
	IMMOBILIZER	(04-..)	✓	✓	✓	✓	✓	✓
	LEFT REAR DOOR	(04-..)	✓	✓	✓	✓	✓	✓
	PASS. SIDE DOOR	(04-..)	✓	✓	✓	✓	✓	✓
	RADIO / CD	(04-..)	✓	✓	✓	✓	✓	✓
	RIGHT REAR DOOR	(04-..)	✓	✓	✓	✓	✓	✓
	SERVICE LIGHT RES	(04-..)	✓	✓	✓	✓	✓	✓
	STEERING WHEEL	(04-..)	✓	✓	✓	✓	✓	✓
Toledo	03 Brake Electronics	(..-03)	✓	✓	✓	✓	✓	✓
	03 Brake Electronics	(01-..)	✓	✓	✓	✓	✓	✓
	15 Airbags	(..-03)	✓	✓	✓	✓	✓	✓
	02 Transmission ElectronicsI	(..-00)	✓	✓	✓	✓	✓	✓
	46 Central Control Module	(..-00)	✓	✓	✓	✓	✓	✓
	CHASSIS NETWORK	(..-03)	✓	✓	✓	✓	✓	✓
	CLIMA	(..-03)	✓	✓	✓	✓	✓	✓
	CONV. TOP/SUNROO	(..-00)	✓	✓	✓	✓	✓	✓
	DASHBOARD	(..-00)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME	(..-03)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.6 16v 77kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.8 20v 92kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 TDI 66kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 1.9 TDI 81kW	(01-..)	✓	✓	✓	✓	✓	✓
	ENGINE MANAGEME 2.3 20v V5 125kW	(01-..)	✓	✓	✓	✓	✓	✓
	IMMOBILIZER	(..-00)	✓	✓	✓	✓	✓	✓

Seat V24.66 Diagnostics List(Note:For reference only)								
MODEL	SYSTEM	TYPE	Functions					
			System Info.	Read Dtc	Clear Dtc	Data stream	Actuatio n	Specail function s
	SERVICE LIGHT RES	(93-95)	√	√	√	√	√	√
	SERVICE LIGHT RES	(99-..)	√	√	√	√	√	√

(*) :Tested;

(?) :Manual on website(www.x431.com)

NOTE:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD

CONNECTOR	X431/TOOL	DIAGUN
OBD 16C	Seat Model of non-CAN BUS protocol	N/A
CANBUS II	All Seat Models with 16PIN DLC	N/A
SUPER 16	All Seat Models with 16PIN DLC	N/A
diagun connector	N/A	All Seat Models with 16PIN DLC