

LANCIA V16.31 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
Ypsilon(2011)		BCM(Body Controller)	VC DFA
		CMM(Collision Mitigation Module)	VC DF
		TCM(Transmission Control Module)	VC DFA
		CTM(Convergence Telematic Module)	VC DA
		AHM(Additional Heater Module)	VC DA
		ECM(Engine Control Module)	VC DFA
		ORC(Occupant Restraint)	VC D
		PAM(Parking Aid Module)	VC D
		IPC(Instrument Panel Cluster)	VC DA
		EPS(Electric Power Steering)	VC DF
		ABS(Anti Lock Brakes)	VC DFA
		HVAC(Heat, Ventilation and A/C)	VC DFA
Flavia(2012)		TIPMCGW(Central Gateway)	VC DFA
		PDM(Passenger Door Module)	VC DA
		AMP(Amplifier)	VC DF
		PCM(Powertrain Control Module)	VC DFA
		HVAC(Heat, Ventilation and A/C)	VC DFA
		ABS(Anti Lock Brakes)	VC DFA
		ORC(Occupant Restraint)	VC DF
		CCN(Instrument Cluster/Cabin Compartment Node)	VC DFA
		HFM(Hands Free Module(cell phone))	VC DA
		SAS(Steering Angle Sensor)	VC D
		DDM(Driver Door Module)	VC DA
		RADIO(RADIO)	VC DF
WCM(Wireless Control)	VC DF		

LANCIA V16.31 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
Flavia(2013)		PTCM(Power Top Control Module)	VCDF
		TIPMCGW(Central Gateway)	VCDF
		PDM(Passenger Door Module)	VCDA
		AMP(Amplifier)	VCDF
		PCM(Powertrain Control Module)	VCDF
		HVAC(Heat, Ventilation and A/C)	VCDF
		ABS(Anti Lock Brakes)	VCDF
		ORC(Occupant Restraint)	VCDF
		CCN(Instrument Cluster/Cabin Compartment Node)	VCDF
		HFM(Hands Free Module(cell phone))	VCDA
		SAS(Steering Angle Sensor)	VCD
		DDM(Driver Door Module)	VCDA
		RADIO(RADIO)	VCDF
		WCM(Wireless Control)	VCDF
		PTCM(Power Top Control Module)	VCDF
		ESM(Electronic Shifter)	VCDF
		TCM(Transmission Control Module)	VCDA
		BCM(Body Controller)	VCDF
		ORC(Occupant Restraint)	VCDF
		TGW(Telematic Gateway Radio)	VCD
		HVAC(Heat, Ventilation and A/C)	VCDF
		ICS(Integrated Center Stack)	VCDF
		TCM(Transmission Control Module)	VCDF
		ESM(Electronic Shifter)	VCDA
		AFLS(Adaptive Front Lighting System)	VCDA

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
Thema (2012)		PDM(Passenger Door Module)	VCDFA
		PCM(Powertrain Control Module)	VCDFA
		DDM(Driver Door Module)	VCDFA
		AMP(Amplifier)	VCD
		PTS(Parktronics)	VCDFA
		ABS(Anti Lock Brakes)	VCDFA
		IPC(Instrument Panel Cluster)	VCDFA
		SCCM(Steering Column Control Module)	VCD
		ITM(Intrusion)	VCDFA
		HSM(Heated Seat Module)	VCDFA
		EPS(Electric Power Steering)	VCDF
		RFH(Radio Frequency Hub)	VCDFA
		MSM(Memory Seat Module)	VCDFA
		DTCM(Drive Train Control Module)	VCDFA
		ACC(Adaptive Cruise Control)	VCDF
		HFM(Hands Free Module(cell phone))	VCD
		BSM(Blind Spot Module)	VCD
		ADCM(Active Damping Control Module)	VCD
		TPM(Tire Pressure Monitor)	VCDF
ORC(Occupant Restraint)	VCDF		
TGW(Telematic Gateway Radio)	VCD		
HVAC(Heat, Ventilation and A/C)	VCDFA		
ICS(Integrated Center Stack)	VCDFA		
TCM(Transmission Control Module)	VCDF		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
Thema (2013)		ESM(Electronic Shifter)	VCDA
		AFLS(Adaptive Front Lighting System)	VCDA
		PDM(Passenger Door Module)	VCDFA
		PCM(Powertrain Control Module)	VCDFA
		DDM(Driver Door Module)	VCDFA
		AMP(Amplifier)	VCD
		PTS(Parktronics)	VCDFA
		ABS(Anti Lock Brakes)	VCDFA
		IPC(Instrument Panel Cluster)	VCDFA
		SCCM(Steering Column Control Module)	VCD
		ITM(Intrusion)	VCDFA
		HSM(Heated Seat Module)	VCDFA
		EPS(Electric Power Steering)	VCDF
		RFH(Radio Frequency Hub)	VCDFA
		MSM(Memory Seat Module)	VCDFA
		DTCM(Drive Train Control Module)	VCDFA
		ACC(Adaptive Cruise Control)	VCDF
		HFM(Hands Free Module(cell phone))	VCD
		BSM(Blind Spot Module)	VCD
		ADCM(Active Damping Control Module)	VCD
		RBSS(Right blind spot sensor)	VCD
		LBSS(Left blind spot sensor)	VCD
		BCM(Body Controller)	VCDFA
		ORC(Occupant Restraint)	VCDF
		TGW(Telematic Gateway Radio)	VCD

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
Thema (2014)		HVAC(Heat, Ventilation and A/C)	VCDFA
		ICS(Integrated Center Stack)	VCDFA
		TCM(Transmission Control Module)	VCDF
		ESM(Electronic Shifter)	VCDFA
		AFLS(Adaptive Front Lighting System)	VCDFA
		PDM(Passenger Door Module)	VCDFA
		PCM(Powertrain Control Module)	VCDFA
		DDM(Driver Door Module)	VCDFA
		AMP(Amplifier)	VCD
		PTS(Parktronics)	VCDFA
		ABS(Anti Lock Brakes)	VCDFA
		IPC(Instrument Panel Cluster)	VCDFA
		SCCM(Steering Column Control Module)	VCD
		ITM(Intrusion)	VCDFA
		HSM(Heated Seat Module)	VCDFA
		EPS(Electric Power Steering)	VCDF
		RFH(Radio Frequency Hub)	VCDFA
		MSM(Memory Seat Module)	VCDFA
		DTCM(Drive Train Control Module)	VCDFA
		ACC(Adaptive Cruise Control)	VCDF
		HFM(Hands Free Module(cell phone))	VCD
		BSM(Blind Spot Module)	VCD
ADCM(Active Damping Control Module)	VCD		
RBSS(Right blind spot sensor)	VCD		
LBSS(Left blind spot sensor)	VCD		

LANCIA V16.31 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
Voyager(2012)		TIPMCGW(Central Gateway)	VCDFA
		DVD(DVD Changer)	VCD
		HVAC(Heat, Ventilation and A/C)	VCDFA
		PLGM(Power Liftgate)	VCDFA
		SAS(Steering Angle Sensor)	VCD
		DMFL(Door Module Front Left)	VCDFA
		CCN(Instrument Cluster/Cabin Compartment Node)	VCDFA
		SUNR(Sunroof)	VCDA
		PCM(Powertrain Control Module)	VCDFA
		RADIO(RADIO)	VCDF
		DMRL(Door Module Rear Left)	VCDFA
		TPM(Tire Pressure Monitor)	VCDF
		TCM(Transmission Control Module)	VCDFA
		PEM(Passive Entry Module)	VCDF
		VES3(Last Row Screen)	VCDFA
		ORC(Occupant Restraint)	VCDF
		EPPM(Electronic Pedestrian Protection Module)	VCDF
		PSDML(Power Sliding Doors (Left))	VCD
		FSM(Fold Stow Module)	VCDA
		HFM(Hands Free Module(cell phone))	VCDA
		ABS(Anti Lock Brakes)	VCDFA
		PTS(Parktronics)	VCDFA
		PSDMR(Power Sliding Doors (Right))	VCD
WCM(Wireless Control)	VCDFA		
ITM(Intrusion)	VCDFA		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
		HSM(Heated Seat Module)	VCDFA
		DMRR(Door Module Rear Right)	VCDFA
		DMFR(Door Module Front Right)	VCDFA
		HIDT(High Intensity Discharge Translator)	VCDA
		VES2(Second Row Screen)	VCDFA
		AHBM(Automatic High Beam)	VCD
		MSMD(Memory Seat)	VCDFA
		AMP(Amplifier)	VCDF
		BSM(Blind Spot Module)	VCD
		TIPMCGW(Central Gateway)	VCDFA
		DVD(DVD Changer)	VCD
		HVAC(Heat, Ventilation and A/C)	VCDFA
		PLGM(Power Liftgate)	VCDFA
		SAS(Steering Angle Sensor)	VCD
		DMFL(Door Module Front Left)	VCDFA
		CCN(Instrument Cluster/Cabin Compartment Node)	VCDFA
		SUNR(Sunroof)	VCDA
		PCM(Powertrain Control Module)	VCDFA
		RADIO(RADIO)	VCDF
		DMRL(Door Module Rear Left)	VCDFA
		TPM(Tire Pressure Monitor)	VCDF
		TCM(Transmission Control Module)	VCDFA
		PEM(Passive Entry Module)	VCDF
		VES3(Last Row Screen)	VCDFA
		ORC(Occupant Restraint)	VCDF

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
Voyager (2013)		EPPM(Electronic Pedestrian Protection Module)	VCDF
		PSDML(Power Sliding Doors (Left))	VCD
		FSM(Fold Stow Module)	VCDA
		HFM(Hands Free Module(cell phone))	VCDA
		ABS(Anti Lock Brakes)	VCDF
		PTS(Parktronics)	VCDF
		PSDMR(Power Sliding Doors (Right))	VCD
		WCM(Wireless Control)	VCDF
		ITM(Intrusion)	VCDF
		HSM(Heated Seat Module)	VCDF
		DMRR(Door Module Rear Right)	VCDF
		DMFR(Door Module Front Right)	VCDF
		HIDT(High Intensity Discharge Translator)	VCDA
		VES2(Second Row Screen)	VCDF
		AHBM(Automatic High Beam)	VCD
		MSMD(Memory Seat)	VCDF
		AMP(Amplifier)	VCDF
		LBSS(Left blind spot sensor)	VCD
		RBSS(Right blind spot sensor)	VCD
DVD(DVD Changer)	VCD		
HVAC(Heat, Ventilation and A/C)	VCDF		
PLGM(Power Liftgate)	VCDF		
SAS(Steering Angle Sensor)	VCD		
DMFL(Door Module Front Left)	VCDF		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
Voyager (2014)		CCN(Instrument Cluster/Cabin Compartment Node)	VCDFA
		SUNR(Sunroof)	VCDA
		PCM(Powertrain Control Module)	VCDFA
		RADIO(RADIO)	VCDF
		DMRL(Door Module Rear Left)	VCDFA
		TPM(Tire Pressure Monitor)	VCDF
		TCM(Transmission Control Module)	VCDFA
		PEM(Passive Entry Module)	VCDF
		VES3(Last Row Screen)	VCDFA
		ORC(Occupant Restraint)	VCDF
		EPPM(Electronic Pedestrian Protection Module)	VCDF
		PSDML(Power Sliding Doors (Left))	VCD
		FSM(Fold Stow Module)	VCDA
		HFM(Hands Free Module(cell phone))	VCDA
		ABS(Anti Lock Brakes)	VCDFA
		PTS(Parktronics)	VCDFA
		PSDMR(Power Sliding Doors (Right))	VCD
		WCM(Wireless Control)	VCDFA
		ITM(Intrusion)	VCDFA
		HSM(Heated Seat Module)	VCDFA
		DMRR(Door Module Rear Right)	VCDFA
		DMFR(Door Module Front Right)	VCDFA
		HIDT(High Intensity Discharge Translator)	VCDA
		VES2(Second Row Screen)	VCDFA
AHBM(Automatic High Beam)	VCD		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
		MSMD(Memory Seat)	VCDFA
		AMP(Amplifier)	VCDF
		LBSS(Left blind spot sensor)	VCD
		RBSS(Right blind spot sensor)	VCD
DEDRA	'96 1.8 16V 115 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
	'96 1.8 16V 115 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
	'96 1.8 16V 130 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
'98 1.6 16V	Bosch 5.3 ABS	VCD	
	Magneti Marelli IAW 49F injection (1.6 eng.)	VCDAS049	
DELTA (111)	'96 1.6 16V	Bosch 5.3 ABS	VCD
	'96 1.6 16V	Bosch 5.3 ABS	VCD
	'96 1.8 16V 115 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
	'96 1.8 16V 130 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
	'96 2.0 TURBO 16V	Bosch 5.3 ABS	VCD
	'96 TD	Bosch 5.3 ABS	VCD
	'98 1.6 16V	Bosch 5.3 ABS	VCD
		Magneti Marelli IAW 49F injection (1.6 eng.)	VCDAS049
'98 1.8 16V	Bosch 5.3 ABS	VCD	
	Hitachi MPI injection (eng. 1.8 16v '98)	VCDAS001	
		Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	VCDAS002

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
		Engine-Gearbox		
	1.4 TURBO 16V	Engine-Gearbox	Injection Landi Renzo LC02 Gas	VCDA
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli Radio Navigator	VCDA
			Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
			TRW Lane Control Control Unit (HALF)	VCDA
		Comfort	Denso 3 climate control (Two-zone)	VCDAS007
			Driver's seat Lear 3	VCDA
			Passenger's seat Lear 3	VCDA
			TRW 3 Electric Steering	VCDS008
		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
	1.6 MJET 16V	Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
			Marelli SELESPEED CFC300 Automatic Gearbox	VCDAS010
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli Radio Navigator	VCDA
Marelli/Microsoft C3 Convergence			VCDAS004	
Marelli/Microsoft Convergence			VCDAS004	
Safety		Marelli Body Computer 8	VCDAS005	
		SIEMENS Airbag 1 (Proxi)	VCDA	
		TRW ABS ESP	VCDAS006	

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
DELTA (181)	1.8 JTS TB 16V	Comfort	TRW Lane Control Control Unit (HALF)	VCDA
			Denso 3 climate control (Two-zone)	VCDAS007
			Driver's seat Lear 3	VCDA
			Passenger's seat Lear 3	VCDA
			TRW 3 Electric Steering	VCDS008
		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
		Engine-Gearbox	Automatic Gearbox AISIN AF40-6	VCDAS011
			Bosch Injection Motronic MeD17.3.1 CF5/EOBD (eng. 1.8)	VCDAS012
	Instrumentation		Marelli instrument panel 3	VCDAS003
			Marelli Radio Navigator	VCDA
			Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
	Safety		Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
			TRW Lane Control Control Unit (HALF)	VCDA
	Comfort		Denso 3 climate control (Two-zone)	VCDAS007
			Driver's seat Lear 3	VCDA
			Passenger's seat Lear 3	VCDA
			TRW 3 Electric Steering	VCDS008
	Other systems		Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	1.9 MJET 16V TWINTB	Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli Radio Navigator	VCDA
			Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
			TRW Lane Control Control Unit (HALF)	VCDA
		Comfort	Denso 3 climate control (Two-zone)	VCDAS007
			Driver's seat Lear 3	VCDA
			Passenger's seat Lear 3	VCDA
			TRW 3 Electric Steering	VCDS008
		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
	2.0 MJET 16V	Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli Radio Navigator	VCDA
			Marelli/Microsoft C3 Convergence	VCDAS004
Marelli/Microsoft Convergence			VCDAS004	
Safety		Marelli Body Computer 8	VCDAS005	
		SIEMENS Airbag 1 (Proxi)	VCDA	
		TRW ABS ESP	VCDAS006	
	TRW Lane Control Control Unit (HALF)	VCDA		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
		Comfort	Denso 3 climate control (Two-zone)	
			Driver's seat Lear 3	VCDA
			Passenger's seat Lear 3	VCDA
			TRW 3 Electric Steering	VCDS008
		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
		Engine-Gearbox	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	VCDAS050
	'98 2.4 JTD	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
		Engine-Gearbox	Bosch Motronic ME3.1 injection (eng. 2.0 20V)	VCDAS001
	'99 2.0	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
			TRW MY 97 Air Bag (2F-2P-2L)	VCD
		Engine-Gearbox	Bosch Motronic ME3.1 injection (eng. 2.0 20v)	VCDAS001
	'99 2.4	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
			TRW MY 97 Air Bag (2F-2P-2L)	VCD
			Bosch 5.3 ABS	VCD

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
K	99 3.0	Safety	TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
			TRW MY 97 Air Bag (2F-2P-2L)	VCD
	2.0	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	2.0 TURBO	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	2.4	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	2.4 TD	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
3.0	Safety	Bosch 5.3 ABS	VCD	
		TRW MY 97 Air Bag (2F-2P)	VCD	
		TRW MY 97 Air Bag (2F-2P-2L-S)	VCD	
		TRW MY 97 Air Bag (2F-2P-S)	VCD	
		Allied Airbag MY 97 (2F-2P-2L-2T-I)		VCD

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
	1.6	Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD
		Allied MY 97 AirBag (2F-2P-I)	VCD
		Allied MY 97 AirBag (2F-2P-I-S)	VCD
		Bosch 5.3 ABS	VCD
		Bosch discharge headlamp (left)	VCDA
		Bosch discharge headlamp (right)	VCDA
		ESP TRW Lucas ABS	VCDAS013
		Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	VCDAS014
		Magneti Marelli IAW 49F injection (1.6 eng.)	VCDAS049
		Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA
		TRW Lucas ABS	VCDAS015
		VAS 97/3 Door Lock RF alarm/receiver	VCD
		Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD
		Allied MY 97 AirBag (2F-2P-I)	VCD
	Allied MY 97 AirBag (2F-2P-I-S)	VCD	
	Bosch 5.3 ABS	VCD	
	Bosch discharge headlamp (left)	VCDA	
	Bosch discharge headlamp (right)	VCDA	
	ESP TRW Lucas ABS	VCDAS013	
	Hitachi EOBD injection	VCDAS001	

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
LYBRA		Hitachi MPI injection (eng. 1.8 16v '98)	VCDAS001
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA
		TRW Lucas ABS	VCDAS015
		VAS 97/3 Door Lock RF alarm/receiver	VCD
		Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD
	1.9 JTD	Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD
		Allied MY 97 AirBag (2F-2P-I)	VCD
		Allied MY 97 AirBag (2F-2P-I-S)	VCD
		Bosch 5.3 ABS	VCD
		Bosch Diesel EDC15 injection (1.9 TD d.i. engine)	VCDAS050
		Bosch discharge headlamp (left)	VCDA
		Bosch discharge headlamp (right)	VCDA
		Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	VCDAS016
		ESP TRW Lucas ABS	VCDAS013
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA
		TRW Lucas ABS	VCDAS015
		VAS 97/3 Door Lock RF alarm/receiver	VCD
		Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I)	VCD
		Allied MY 97 Air Bag (2F-2P-I)	VCD
		Allied MY 97 Air Bag (2F-2P-I-S)	VCD

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
	2.0	Bosch 5.3 ABS	VCD
		Bosch discharge headlamp (left)	VCDA
		Bosch discharge headlamp (right)	VCDA
		Bosch Motronic Me3.1 EOBD injection (eng. 2.0/2.4 20v)	VCDAS001
		ESP TRW Lucas ABS	VCDAS013
		Injection-Bosch Motronic Me3.1 (eng. 2.0/2.4 20v Outside EEC)	VCDAS001
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA
		TRW Lucas ABS	VCDAS015
		VAS 97/3 Door Lock RF alarm/receiver	VCD
	2.4 JTD	Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD
		Allied MY 97 AirBag (2F-2P-I)	VCD
		Allied MY 97 AirBag (2F-2P-I-S)	VCD
		Bosch 5.3 ABS	VCD
		Bosch discharge headlamp (left)	VCDA
		Bosch discharge headlamp (right)	VCDA
		Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	VCDAS016
		Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	VCDAS050
		ESP TRW Lucas ABS	VCDAS013
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA
		TRW Lucas ABS	VCDAS015
		VAS 97/3 Door Lock RF alarm/receiver	VCD

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	1.3 JTD	Engine-Gearbox	Automatic Gearbox Marelli SELESPEED CFC 308F	VCDAS017
			Marelli 6JF EOBD Diesel injection (eng. 1.3 JTD)	VCDAS018
			Marelli Automatic Gearbox SELESPEED CFC208F (1)	VCDAS055
			Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	VCDAS051
			Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	VCDAS019
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Marelli instrument panel (Comfort)	VCDAS020
			Marelli instrument panel (Modal)	VCDAS021
		Safety	Bosch 8 ABS	VCD
			Bosch 8 VDC ABS	VCDAS045
			Marelli 7 Body Computer	VCDAS047
			Marelli Body Computer 1	VCDAS046
			TRW MY 03 Airbag (2F-2P-2L-2T-I)	VCDA
			TRW MY 03 Airbag (2F-2P-2T-I)	VCDA
			TRW MY 03 Airbag (2F-2P-I)	VCDA
		Comfort	Denso Climate Control 1 (Two-zone)	VCDAS022
			Marelli/Microsoft Convergence	VCDAS004
			TRW 1 Power Steering	VCDAS061
			TRW 3 Electric Steering	VCDS008
		Other systems	G.E.PROCOND boot	VCDA
			G.E.PROCOND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single BITRON Driver's Door	VCDA
			Single Driver's Door G.E. PROCOND	VCDA
Valeo Parking control unit	VCDS023			

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	1.4 16V	Engine-Gearbox	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	VCDAS002
			Bosch Motronic ME7.3 H4M EOBD Injection	VCDAS001
			Marelli SELESPEED CFC228F Automatic Gearbox	VCDAS043
			Marelli SELESPEED CFC328 Automatic Gearbox	VCDAS024
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Marelli instrument panel (Comfort)	VCDAS020
			Marelli instrument panel (Modal)	VCDAS021
		Safety	Bosch 8 ABS	VCD
			Bosch 8 VDC ABS	VCDAS045
			Marelli 7 Body Computer	VCDAS047
			Marelli Body Computer 1	VCDAS046
			TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-I)	VCDA
		Comfort	Denso Climate Control 1 (Two-zone)	VCDAS022
			Marelli/Microsoft Convergence	VCDAS004
			TRW 1 Power Steering	VCDAS061
			TRW 3 Electric Steering	VCDS008
		Other systems	G.E.PROCOND boot	VCDA
			G.E.PROCOND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single BITRON Driver's Door	VCDA
			Single Driver's Door G.E. PROCOND	VCDA
Valeo Parking control unit	VCDS023			
Engine-Gearbox		Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	VCDAS025	

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
MUSA	1.4 8V	Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Marelli instrument panel (Comfort)	VCDAS020
			Marelli instrument panel (Modal)	VCDAS021
		Safety	Bosch 8 ABS	VCD
			Bosch 8 VDC ABS	VCDAS045
			Marelli 7 Body Computer	VCDAS047
			Marelli Body Computer 1	VCDAS046
			TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-I)	VCDA
		Comfort	Denso Climate Control 1 (Two-zone)	VCDAS022
			Marelli/Microsoft Convergence	VCDAS004
			TRW 1 Power Steering	VCDAS061
			TRW 3 Electric Steering	VCDS008
		Other systems	G.E.PROCOND boot	VCDA
			G.E.PROCOND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single Driver's Door G.E. PROCOND	VCDA
			Valeo Parking control unit	VCDS023
		Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Marelli instrument panel (Comfort)	VCDAS020
Marelli instrument panel (Modal)	VCDAS021			
	Bosch 8 ABS	VCD		
	Bosch 8 VDC ABS	VCDAS045		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions	
	1.6 MJET 16V	Safety	Marelli Body Computer	VCD	
			TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA	
			TRW MY 03 AirBag (2F-2P-2T-I)	VCDA	
			TRW MY 03 AirBag (2F-2P-I)	VCDA	
		Comfort	Denso Climate Control 1 (Two-zone)	VCDAS022	
			Marelli/Microsoft Convergence	VCDAS004	
			TRW 1 Power Steering	VCDAS061	
			TRW 3 Electric Steering	VCDS008	
		Other systems	G.E.PROCOND boot	VCDA	
			G.E.PROCOND Driver's Door	VCDA	
			G.E.PROCOND Passenger Door	VCDA	
			Single Driver's Door G.E. PROCOND	VCDA	
			Valeo Parking control unit	VCDS023	
		1.9 JTD	Engine-Gearbox	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.)	VCDAS026
				Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.)	VCDAS027
	Instrumentation		Marelli 3 Connect (multi-model)	VCDA	
			Marelli instrument panel (Comfort)	VCDAS020	
			Marelli instrument panel (Modal)	VCDAS021	
	Safety		Bosch 8 ABS	VCD	
			Bosch 8 VDC ABS	VCDAS045	
Marelli 7 Body Computer			VCDAS047		
Marelli Body Computer 1			VCDAS046		
TRW MY 03 AirBag (2F-2P-2L-2T-I)			VCDA		
TRW MY 03 AirBag (2F-2P-2T-I)			VCDA		
TRW MY 03 AirBag (2F-2P-I)			VCDA		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
		Comfort	Denso Climate Control 1 (Two-zone)	
		Marelli/Microsoft Convergence		VCDAS004
		TRW 3 Electric Steering		VCDS008
		Other systems	G.E.PROCOND boot	VCDA
			G.E.PROCOND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single BITRON Driver's Door	VCDA
			Single Driver's Door G.E. PROCOND	VCDA
			Valeo Parking control unit	VCDS023
		Engine-Gearbox	Magneti Marelli MM4MP2 PSA Injection	VCDA
			Magneti Marelli MM6LP PSA Injection	VCDAS053
			Siemens AL4 TA2000 V PSA Automatic Gearbox	VCDAS054
		Instrumentation	Marelli DAV PSA Connect control	VCD
			Marelli odometer w. lamps (BTO)	VCDA
			Marelli PSA Connect	VCDAS028
			Marelli PSA instrument panel	VCDA
			Sagem multi-function screen	VCDA
		Safety	Bosch 5.7 ESP PSA ABS	VCDAS052
			Sagem Body Computer	VCDAS029
			Temic airbag	VCDS030
			Texton alarm 2	VCDA
	2.0 16V	Comfort	Bitron PSA driver's seat	VCDA
			Clarion CD Changer	VCDA
			Clarion/Philips sound system	VCDAS031

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
			Marelli PSA climate control	VCDA
		Other systems	Eaton multi-switch stalk unit (COM2000)	VCD
			Inalfa central sunroof	VCDAS084
			Inalfa front sunroof	VCDAS084
			Inalfa rear sunroof	VCDAS084
			Marelli PSA Driver's Door	VCDA
			Marelli PSA Passenger's Door	VCDS032
			Texton sliding doors	VCDA
			Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Valeo PSA Parking Control unit	VCDA
	2.0 JTD 16V		Engine-Gearbox	Bosch EDC 15 PSA diesel injection (eng. 16v)
		Siemens AL4 TA2000 V PSA Automatic Gearbox		VCDAS054
		Instrumentation	Marelli DAV PSA Connect control	VCD
			Marelli odometer w. lamps (BTO)	VCDA
			Marelli PSA Connect	VCDAS028
			Marelli PSA instrument panel	VCDA
			Sagem multi-function screen	VCDA
		Safety	Bosch 5.7 ESP PSA ABS	VCDAS052
			Sagem Body Computer	VCDAS029
			Temic airbag	VCDS030
			Texton alarm 2	VCDA
		Comfort	Bitron PSA driver's seat	VCDA
			Clarion CD Changer	VCDA
			Clarion/Philips sound system	VCDAS031

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
PHEDRA			Marelli PSA climate control	VCDA
			WEBASTO Heater (PSA)	VCDA
		Other systems	Eaton multi-switch stalk unit (COM2000)	VCD
			Inalfa central sunroof	VCDAS084
			Inalfa front sunroof	VCDAS084
			Inalfa rear sunroof	VCDAS084
			Marelli diesel additive check	VCDAS034
			Marelli PSA Driver's Door	VCDA
			Marelli PSA Passenger's Door	VCDS032
			Texton sliding doors	VCDA
			Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
	Valeo PSA Parking Control unit	VCDA		
	Engine-Gearbox	Bosch EDC 15 PSA diesel injection (eng. 16v)	VCDAS033	
		Instrumentation	Marelli DAV PSA Connect control	VCD
			Marelli odometer w. lamps (BTO)	VCDA
			Marelli PSA Connect	VCDAS028
			Marelli PSA instrument panel	VCDA
			Sagem multi-function screen	VCDA
		Safety	Bosch 5.7 ESP PSA ABS	VCDAS052
Sagem Body Computer			VCDAS029	
Temic airbag	VCDS030			
Texton alarm 2	VCDA			
	Bitron PSA driver's seat	VCDA		
	Clarion CD Changer	VCDA		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	2.2 JTD 16V	Comfort	Clarion/Philips sound system	VCDAS031
			Marelli PSA climate control	VCDA
			WEBASTO Heater (PSA)	VCDA
		Other systems	Eaton multi-switch stalk unit (COM2000)	VCD
			Inalfa central sunroof	VCDAS084
			Inalfa front sunroof	VCDAS084
			Inalfa rear sunroof	VCDAS084
			Marelli diesel additive check	VCDAS034
			Marelli PSA Driver's Door	VCDA
			Marelli PSA Passenger's Door	VCDS032
			Texton sliding doors	VCDA
			Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Valeo PSA Parking Control unit	VCDA
	Engine-Gearbox	Bosch Motronic Me7.4.6 PSA Injection	VCDAS035	
		ZF 4HP20 PSA Automatic Gearbox	VCD	
	Instrumentation	Marelli DAV PSA Connect control	VCD	
		Marelli odometer w. lamps (BTO)	VCDA	
		Marelli PSA Connect	VCDAS028	
		Marelli PSA instrument panel	VCDA	
Sagem multi-function screen		VCDA		
Safety	Bosch 5.7 ESP PSA ABS	VCDAS052		
	Sagem Body Computer	VCDAS029		
	Temic airbag	VCDS030		
	Texton alarm 2	VCDA		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	3.0 V6 24V	Comfort	Bitron PSA driver's seat	VCDA
			Clarion CD Changer	VCDA
			Clarion/Philips sound system	VCDAS031
			Marelli PSA climate control	VCDA
		Other systems	Eaton multi-switch stalk unit (COM2000)	VCD
			Inalfa central sunroof	VCDAS084
			Inalfa front sunroof	VCDAS084
			Inalfa rear sunroof	VCDAS084
			Marelli PSA Driver's Door	VCDA
			Marelli PSA Passenger's Door	VCDS032
			Texton sliding doors	VCDA
			Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Valeo PSA Parking Control unit	VCDA
		Engine-Gearbox	Bosch EDC 15 PSA diesel injection (eng. 16v)	VCDAS033
			Siemens AL4 TA2000 V PSA Automatic Gearbox	VCDAS054
			Siemens Diesel Injection SID803 CF4/EOBD (eng. 16v)	VCDAS036
		Instrumentation	Johnson/Borg multi-function screen	VCDAS073
			Marelli odometer warning lamps (BTO CAN)	VCDA
PSA DAV Connect Command (CAN)	VCD			
PSA Marelli Connect (CAN)	VCDAS085			
Marelli Connect PSA RT5 (CAN)	VCDAS082			
PSA Marelli cluster (CAN)	VCDA			
	Bosch ABS 8.1 ESP PSA (CAN)	VCDAS070		
	Johnson EV Body Computer (BSI CAN) 2	VCDAS088		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
PHEDRA (180)	2.0 JTD 16V	Safety	BOSCH/TEMIC Airbag (CAN)	VCDAS071
			PSA Bosch ABS 8 ESP (CAN)	VCDAS083
			Delphi Alarm	VCDAS072
		Comfort	Blaupunkt radio	VCDA
			PSA Denso Climate Control (CAN)	VCDA
			WEBASTO Heater (PSA)	CDA
		Other systems	Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Delphi multi-function switch (COM2005)	VCDA
			Brose Driver's Door	VCDA
			Brose passenger door	VCDA
			Delphi multi-SWITCH (COM2003)	VCDA
			Inalfa centre sunroof (CAN)	VCDA
			Inalfa front sunroof (CAN)	VCDA
	Inalfa rear sunroof (CAN)		VCDA	
	Marelli Diesel additive control (CAN)		VCDAS087	
	Siemens Tyre Pressure Control	VCDAS086		
	Texton sliding doors (CAN)	VCDA		
	PSA Valeo Parking Control Unit (CAN)	VCDA		
	Engine-Gearbox	AISIN AM6 Automatic Gearbox	VCDAS037	
Bosch Diesel Injection EDC16CP39 CF4/EOBD (2.2 eng.)		VCDAS038		
Bosch EDC 15 PSA diesel injection (eng. 16v)		VCDAS033		
	Johnson/Borg multi-function screen	VCDAS073		
	Marelli odometer warning lamps (BTO CAN)	VCDA		
	Marelli Connect PSA RT5 (CAN)	VCDAS082		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	2.2 JTD 16V	Instrumentation	PSA DAV Connect Command (CAN)	VCD
			PSA Marelli Connect (CAN)	VCDAS085
			PSA Marelli cluster (CAN)	VCDA
		Safety	Bosch ABS 8.1 ESP PSA (CAN)	VCDAS070
			Johnson EV Body Computer (BSI CAN) 2	VCDAS088
			BOSCH/TEMIC Airbag (CAN)	VCDAS071
			PSA Bosch ABS 8 ESP (CAN)	VCDAS083
			Delphi Alarm	VCDAS072
		Comfort	Blaupunkt radio	VCDA
			PSA Denso Climate Control (CAN)	VCDA
			WEBASTO Heater (PSA)	CDA
		Other systems	Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Brose Driver's Door	VCDA
			Brose passenger door	VCDA
			Delphi multi-SWITCH (COM2003)	VCDA
			Inalfa centre sunroof (CAN)	VCDA
			Inalfa front sunroof (CAN)	VCDA
			Inalfa rear sunroof (CAN)	VCDA
			Marelli Diesel additive control (CAN)	VCDAS087
Siemens Tyre Pressure Control	VCDAS086			
Texton sliding doors (CAN)	VCDA			
PSA Valeo Parking Control Unit (CAN)	VCDA			
Engine-Gearbox	Bosch Motronic Me7.3.1 EOBD injection (2 lambda sensors)	VCDAS001		
	ESP TRW Lucas ABS	VCDAS013		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	2.0 20V TB	Safety	Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
		Comfort	Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			Borletti/Hella climate control	VCDS089
			SAGEM SpeedPro power steering	VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
	2.4 20V	Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
			Bosch Motronic Me3.1 EOBD injection (eng. 2.0/2.4 20v)	VCDAS001
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
		Comfort	Bitron driving seat	VCDA
Bitron passenger seat			VCDA	
Borletti/Hella climate control			VCDS089	
SAGEM SpeedPro power steering			VCD	
			Marelli Boot	VCDA
		Marelli Driver's Door	VCDA	

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
THESES	2.4 JTD 10V	Other systems	Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
		Engine-Gearbox	Bosch EDC15 CF3/EOBD Diesel injection (eng. 1.9/2.4)	VCDAS016
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
		Comfort	Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
	Borletti/Hella climate control		VCDS089	
	SAGEM SpeedPro power steering		VCD	
	Other systems	Marelli Boot	VCDA	
		Marelli Driver's Door	VCDA	
		Marelli Passenger Door	VCDA	
		Valeo Parking control unit	VCDS023	
	2.4 JTD 20V	Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
			Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	VCDAS039
			Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	VCDAS040
		Instrumentation	Nippon Seiki instrument panel (Thesis)	VCDAS060
Safety		ESP TRW Lucas ABS	VCDAS013	
		Marelli Easy-go Body computer	VCDAS046	
		Marelli Full Body computer	VCDAS046	
		TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD	
TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD			

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
		Comfort	Bitron driving seat	
		Bitron passenger seat		VCDA
		Borletti/Hella climate control		VCDS089
		SAGEM SpeedPro power steering		VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
	3.0 V6 24V	Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
			Bosch Motronic EOBD ME3.1 Injection (eng. V6)	VCDAS001
		Instrumentation	Nippon Seiki instrument panel (Thesis)	VCDAS060
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
			TRW MY 99 Airbag (2F-4P-I-S-C)	VCD
		Comfort	Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			Borletti/Hella climate control	VCDS089
			SAGEM SpeedPro power steering	VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
	Valeo Parking control unit		VCDS023	

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	3.2 V6 24V	Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
			Bosch Motronic ME7.3.1 EOBD Injection	VCDAS001
			Injection-Bosch Motronic Me7.3.1 Outside EEC	VCDAS001
		Instrumentation	Nippon Seiki instrument panel (Thesis)	VCDAS060
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
		Comfort	Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			Borletti/Hella climate control	VCDS089
			SAGEM SpeedPro power steering	VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
	1.1	Allied MY 97 Air Bag (2F-2P-2L-S)	VCD	
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD	
		Allied MY 97 Airbag (2F-2P-I)	VCD	
		Bosch 5.3 ABS	VCD	
		Magneti Marelli IAW 16F Injection	VCD	
		Allied MY 97 Air Bag (2F-2P-2L-S)	VCD	
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD	
		Allied MY 97 Airbag (2F-2P-I)	VCD	

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
Y	1.2	Bosch 5.3 ABS	VCD
		Fuji MX665 Automatic Transmission (EEC2 engine)	VCD
		Magneti Marelli IAW 16F Injection	VCD
	1.2 16V	Allied MY 97 Air Bag (2F-2P-2L-S)	VCD
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD
		Allied MY 97 Airbag (2F-2P-I)	VCD
		Bosch 5.3 ABS	VCD
	1.2 16V CF3	Allied MY 97 Air Bag (2F-2P-2L-S)	VCD
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD
		Allied MY 97 Airbag (2F-2P-I)	VCD
		Bosch 5.3 ABS	VCD
		Bosch Motronic ME7.3H4 EOBD injection	VCDAS001
	1.2 CF3	Allied MY 97 Air Bag (2F-2P-2L-S)	VCD
		Allied MY 97 Air Bag (2F-2P-S)	VCD
		Allied MY 97 Airbag (2F-2P)	VCD
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD
		Allied MY 97 Airbag (2F-2P-I)	VCD
		Bosch 5.3 ABS	VCD
		Fuji MX665 Automatic Transmission (EEC2 engine)	VCD
		Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014
1.4	Allied MY 97 Airbag (2F-2P)	VCD	
	Allied MY 97 Airbag (2F-2P-2L-I)	VCD	
	Allied MY 97 Airbag (2F-2P-I)	VCD	
	Bosch 5.3 ABS	VCD	
		Engine-Gearbox Bosch Motronic ME7.3H4M EOBD Injection	VCDAS001

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	1.2 16V	Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	Autoliv AirBag 99 (A) (2F-2P-2L-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	VCDA
			Autoliv MY 99 Airbag (2F-2P-I)	VCDA
			ESP TRW Lucas ABS	VCDAS013
			Marelli/Finmek Body Computer	VCDAS041
		Comfort	TRW Lucas ABS	VCDAS015
			DELPHI Electric Steering	VCDS044
		Other systems	Denso Climate Control (Two-zone)	VCDAS007
			Bitron Driver's door	VCDA
			BITRON passenger door	VCDA
			Bosch Parking Control Unit	VCDAS042
			G.E.PROCKND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single BITRON Driver's Door	VCDA
			Single Driver's Door G.E.PROCOND	VCDA
		Engine-Gearbox	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014
			Instrumentation	Marelli 3 Connect (multi-model)
		Siemens instrument panel		VCDAS058
		Autoliv AirBag 99 (A) (2F-2P-2L-I)	VCDA	
		Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	VCDA	

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	1.2 8V	Safety	Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	VCDA
			Autoliv MY 99 Airbag (2F-2P-I)	VCDA
			ESP TRW Lucas ABS	VCDAS013
			Marelli/Finmek Body Computer	VCDAS041
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
		Other systems	BITRON Driver's door	VCDA
			BITRON passenger door	VCDA
			Bosch Parking Control Unit	VCDAS042
			G.E.PROCKND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
	Single BITRON Driver's Door		VCDA	
	Single Driver's Door G.E.PROCOND		VCDA	
	Engine-Gearbox	Marelli 6JF EOBD Diesel injection (eng. 1.3 JTD)	VCDAS018	
		Marelli Automatic Gearbox SELESPEED CFC208F (1)	VCDAS055	
		Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	VCDAS051	
	Instrumentation	Marelli 3 Connect (multi-model)	VCDA	
		Siemens instrument panel	VCDAS058	
		Autoliv AirBag 99 (A) (2F-2P-2L-I)	VCDA	
		Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	VCDA	
		Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	VCDA	
		Autoliv Airbag MY 99 (2F-2P-2T-I)	VCDA	

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
YPSILON	1.3 JTD	Safety	Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	VCDA
			Autoliv MY 99 Airbag (2F-2P-I)	VCDA
			ESP TRW Lucas ABS	VCDAS013
			Marelli/Finmek Body Computer	VCDAS041
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
		Other systems	BITRON Driver's door	VCDA
			BITRON passenger door	VCDA
			Bosch Parking Control Unit	VCDAS042
			G.E.PROCKND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single BITRON Driver's Door	VCDA
		Single Driver's Door G.E.PROCOND	VCDA	
	Engine-Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	VCDAS001	
		Marelli SELESPEED CFC228F Automatic Gearbox	VCDAS043	
	Instrumentation	Marelli 3 Connect (multi-model)	VCDA	
		Siemens instrument panel	VCDAS058	
	Safety	Autoliv AirBag 99 (A) (2F-2P-2L-I)	VCDA	
		Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	VCDA	
		Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	VCDA	
Autoliv Airbag MY 99 (2F-2P-2T-I)		VCDA		
Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)		VCDA		
Autoliv MY 99 Airbag (2F-2P-I)		VCDA		
ESP TRW Lucas ABS		VCDAS013		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	1.4 16V		Marelli/Finmek Body Computer	VCDAS041
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
		Other systems	BITRON Driver's door	VCDA
			BITRON passenger door	VCDA
			Bosch Parking Control Unit	VCDAS042
			G.E.PROCOND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single BITRON Driver's Door	VCDA
	Single Driver's Door G.E.PROCOND	VCDA		
	'06 1.2 8V	Engine-Gearbox	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	VCDAS014
			Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli 7 Body Computer	VCDAS047
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
Marelli/Microsoft Convergence			VCDAS004	
Other systems	Bosch Parking Control Unit	VCDAS042		
	Engine-Gearbox	Marelli Automatic Gearbox SELESPEED CFC208F (1)	VCDAS055	
		Marelli Diesel injection 6F3 EOBD (eng. 1.3 JTD)	VCDAS051	
		Marelli 3 Connect (multi-model)	VCDA	

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	'06 1.3 JTD	Instrumentation	Siemens instrument panel	VCDAS058
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli 7 Body Computer	VCDAS047
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
			Marelli/Microsoft Convergence	VCDAS004
	Other systems	Bosch Parking Control Unit	VCDAS042	
	'06 1.4 16V	Engine-Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	VCDAS001
			Marelli SELESPEED CFC228F Automatic Gearbox	VCDAS043
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli 7 Body Computer	VCDAS047
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
			Marelli/Microsoft Convergence	VCDAS004
		Other systems	Bosch Parking Control Unit	VCDAS042
'06 1.4 8V		Engine-Gearbox	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	VCDAS025
	Instrumentation	Marelli 3 Connect (multi-model)	VCDA	
		Siemens instrument panel	VCDAS058	
	Safety	ESP TRW Lucas ABS	VCDAS013	
		Marelli 7 Body Computer	VCDAS047	
		TRW Lucas ABS	VCDAS015	

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
	0.9 TURBO TWIN AIR	Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
			Marelli/Microsoft Convergence	VCDAS004
		Other systems	Bosch Parking Control Unit	VCDAS042
		Engine-Gearbox	Automatic Gearbox Marelli SELESPEED CFC328 2	VCDAS066
			Magneti Marelli IAW 8GSF CF5/EOBD Injection (EP 0.9 engine)	VCDAS064
		Instrumentation	Continental instrument panel (EP)	VCDAS077
			Lauberhorn Convergence (EP)	VCDAS081
		Safety	Bosch ABS 9 (EP)	VCDAS067
			Bosch ABS 9 ESP (EP)	VCDAS068
			Delphi (EP) 6 Body Computer	VCDAS076
			Bosch Air bag (EP)	VCDA
		Comfort	Denso Heater (EP)	VCDA
			DELPHI Electric Steering (EP) 4	VCDS078
Marelli Single-Zone Automatic Climate Control (EP)	VCDAS079			
Other systems	VALEO Parking Control unit (EP) 2	VCDAS069		
	Litronic discharge headlamp (left)	VCDA		
	Litronic discharge headlamp (right)	VCD		
	Valeo Semi-Automatic Parking Control Unit (EP)	VCDAS080		
Engine-Gearbox	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8V)	VCDAS065		
	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	VCDAS074		
Instrumentation	Continental instrument panel (EP)	VCDAS077		
	Lauberhorn Convergence (EP)	VCDAS081		
	Bosch ABS 9 (EP)	VCDAS067		
	Bosch ABS 9 ESP (EP)	VCDAS068		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
YPSILON(402)	1.2 8V	Safety	Delphi (EP) 6 Body Computer	VCDAS076
			Bosch Air bag (EP)	VCDA
		Comfort	Denso Heater (EP)	VCDA
			DELPHI Electric Steering (EP) 4	VCDS078
			Marelli Single-Zone Automatic Climate Control (EP)	VCDAS079
		Other systems	VALEO Parking Control unit (EP) 2	VCDAS069
			Litronic discharge headlamp (left)	VCDA
			Litronic discharge headlamp (right)	VCD
			Valeo Semi-Automatic Parking Control Unit (EP)	VCDAS080
		1.3 MJET 16V	Engine-Gearbox	Marelli Diesel Injection 8F3 CF5/EOBD (EP 1.3 JTD engine)
	Instrumentation		Continental instrument panel (EP)	VCDAS077
			Lauberhorn Convergence (EP)	VCDAS081
	Safety		Bosch ABS 9 (EP)	VCDAS067
			Bosch ABS 9 ESP (EP)	VCDAS068
			Delphi (EP) 6 Body Computer	VCDAS076
			Bosch Air bag (EP)	VCDA
	Comfort		Denso Heater (EP)	VCDA
			DELPHI Electric Steering (EP) 4	VCDS078
			Marelli Single-Zone Automatic Climate Control (EP)	VCDAS079
	Other systems	VALEO Parking Control unit (EP) 2	VCDAS069	
Valeo Semi-Automatic Parking Control Unit (EP)		VCDAS080		
Z	'00 2.0 16v	Magneti Marelli MM4.8P PSA injection	VCDA	
	'00 2.0 JTD	Bosch EDC 15 PSA Diesel Injection (2.0 8v v60 eng.)	VCDA	
Bosch EDC 15 PSA Diesel Injection (eng. 16v)		VCDAS033		
Bosch EDC 15 PSA Diesel Injection (eng. 2.0 8v)		VCDA		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
		WEBASTO Heater (PSA)	VCDA

(*) : Tested;
 (?) : Manual on website (www.x431.com)
 NOTE: The final interpretation of the products belongs to LAUNCH TECH CO., LTD

N. B. :

V: Control Unit Info

C: Fault Codes

D: Datastream

A: Active Test

S: Additional Functions

- S001 Startup with Code Card
- S002 Startup with Code Card
- S002 Performance limiting
- S002 Neutral signal learn
- S002 Knock counter reset
- S002 Overboost counter reset
- S002 Self-learnt functions reset
- S002 Zeroing of self-adaption parameters
- S003 Headlamp pos. correct.
- S003 Inputs status
- S003 Servicing information delete
- S003 Reset odometer
- S003 Seat belts alarm exclusion
- S003 Seat belts alarm enable

LANCIA V16.31 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S003	Oil change servicing information delete		
S003	Instrument panel replacement		
S004	Audio System Test		
S004	Convergence system Restart		
S005	Siren Serial line check		
S005	Ultrasound sensor check		
S005	Tilt sensor check(if present)		
S005	Dusk and rain sensors check		
S005	Indicators command enable/disable		
S005	Inertia switch rearm(FIS)		
S005	Key programming		
S006	Yaw sensor calibration		
S006	Lateral accel. Sensor calibration		
S006	Pressure sensor calibration		
S006	Accept configuration		
S006	Longit. Acc. Sensor calibration		
S006	Accelerat. And yaw sensors calibration		
S006	Recognition of speed sensor type		
S007	Conditioner compressor		
S007	Flap actuators learning test		
S007	Pollution sensor test		
S007	Autotest		
S008	Steering angle calibration		
S008	Mounting check		
S009	Startup with Code Card		

LANCIA V16.31 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S009	Injector codes read		
S009	Neutral signal learn		
S009	Replacement of injector cyl.1		
S009	Replacement of injector cyl.2		
S009	Replacement of injector cyl.3		
S009	Replacement of injector cyl.4		
S009	Injector replacement(per bank)		
S009	Oil change(only for version with DPF)		
S009	EGR valve replacement		
S009	Variable geometry turbo replacement		
S009	Rail pressure sensor replacement		
S009	Replacement Lambda sensor		
S009	Air flow meter sensor replacement		
S009	Differential pressure sensor replacement(only for version with DPF)		
S009	Pre-catalyser replacement(only for version with DPF)		
S009	Particulate filter replacement (only for version with DPF)		
S009	Replacement of particulate filter with built-in pre-catalyzer(only for versions with DPF)		
S009	Particulate filter regeneration(only for version with DPF)		
S009	Resetting distance travelled with Water Temp.w.lamp ON		
S009	Resetting distance travelled with Water in diesel w.lamp ON		
S010	Accumulator depressurisation		
S010	Clutch bleed		
S010	End of line / service self-calibration		
S010	Clutch self-calibration enable		
S010	New actuators		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S010	Satistical data deletion		
S010	Clutch replacement		
S010	KIT/Gearbox replacement		
S010	Gearbox replacement		
S010	Tunnel lever replacement		
S010	Steering wheel levers replacement		
S010	Electropump replacement		
S010	Pump relay replacement		
S010	AUTO switch replacement		
S010	ECO/SPORT switch replacement		
S010	Gearbox oil accumulator replacement		
S010	Longitudinal acceleration signal learn		
S011	Gearbox lever position learn		
S011	Self-adaptation parameter erasure		
S012	Startup with Code Card		
S012	Oil change		
S012	Knock counter reset		
S012	Overboost counter reset		
S012	Self-learnt functions reset		
S012	Zeroing of self-adaptation parameters		
S013	Steering angle calibration		
S013	Yaw sensor calibration		
S013	Lateral accel. Sensor calibration		
S013	Pressure sensor calibration		
S013	Accept configuration		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S013	Longit. Acc. Sensor calibration		
S014	Startup with Code Card		
S014	Lambda sensor check		
S015	Accept configuration		
S016	Startup with Code Card		
S016	Injector classification		
S017	Accumulator depressurisation		
S017	Clutch bleed		
S017	End of line / service self-calibration		
S017	Clutch self-calibration enable		
S017	Calculation of clutch degradation index		
S017	Gearbox replacement		
S017	Hydraulic Kit replacement		
S017	Gearbox and hydraulic KIT replacement		
S017	Clutch replacement		
S017	Tunnel lever replacement		
S017	Electropump replacement		
S017	Pump relay replacement		
S017	ECO switch replacement		
S017	Gearbox oil accumulator replacement		
S017	Selection and/or engagement clutch electrovalve replacement		
S017	Longitudinal acceleration signal learn		
S018	Startup with Code Card		
S018	Self-learnt functions reset		
S018	Injector codes read		

LANCIA V16.31 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S018	Cyl.1 injector classification		
S018	Cyl.2 injector classification		
S018	Cyl.3 injector classification		
S018	Cyl.4 injector classification		
S018	Injector classification (4 cyl.blank)		
S019	Startup with Code Card		
S019	Injector codes read		
S019	Neutral signal learn		
S019	Replacement of injector cyl.1		
S019	Replacement of injector cyl.2		
S019	Replacement of injector cyl.3		
S019	Replacement of injector cyl.4		
S019	Injector replacement(per bank)		
S019	Oil change		
S019	Rail pressure sensor replacement		
S019	Replacement Lambda sensor		
S019	Air flow meter sensor replacement		
S019	Phonic wheel replacement		
S019	Differential pressure sensor replacement		
S019	Particulate filter with integrated pre-cat replacement		
S019	Particulate filter regeneration		
S019	Mechanical waste-gate valve replacement		
S019	Replacement of variable geometry turbo and/or turbo posit. Sensor		
S019	Resetting distance travelled with Water Temp. w. lamp ON		
S019	Resetting distance travelled with Water in diesel w. lamp ON		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S020	Headlamp pos. correct.		
S020	Inputs status		
S020	Servicing information delete		
S020	Reset odometer		
S020	Seat belts alarm exclusion		
S020	Seat belts alarm Enable		
S020	Instrument panel replacement		
S021	Headlamp pos. correct		
S021	Inputs status		
S021	Reset odometer		
S021	Seat belts alarm exclusion		
S021	Seat belts alarm enable		
S021	Instrument panel replacement		
S022	Flap actuators learning test		
S022	Pollution sensor test		
S023	Tow hook presence disable		
S023	Tow hook presence enable		
S024	Accumulator depressurisation		
S024	Clutch bleed		
S024	End of line / service self-calibration		
S024	Clutch self-calibration enable		
S024	New actuators		
S024	Calculation of clutch degradation index		
S024	Statistical data deletion		
S024	Clutch replacement		

LANCIA V16.31 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S024	KIT/Gearbox replacement		
S024	Gearbox replacement		
S024	Tunnel lever replacement		
S024	Electropump replacement		
S024	Pump relay replacement		
S024	ECO switch replacement		
S024	Gearbox oil accumulator replacement		
S024	Longitudinal acceleration signal learn		
S025	Startup with Code Card		
S025	Phonic wheel learn reset		
S025	Zeroing of self-adaption parameters		
S025	Throttle learn storage		
S025	Vehicle configuration deletion		
S025	Cruise Control Learn		
S025	Air conditioner Learn		
S025	Phase sensor learn zeroing		
S026	Startup with Code Card		
S026	Injector codes read		
S026	Cyl.1 injector classification		
S026	Cyl.2 injector classification		
S026	Cyl.3 injector classification		
S026	Cyl.4 injector classification		
S026	Injector classification (4 cyl.blank)		
S027	Startup with Code Card		
S027	Injector codes read		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S027	Replacement of injector cyl. 1		
S027	Replacement of injector cyl. 2		
S027	Replacement of injector cyl. 3		
S027	Replacement of injector cyl. 4		
S027	Replacement injectors (4 cyl. Bank)		
S027	Control unit replacement		
S027	Replacement of control unit and injector/s		
S027	Air flow sensor replacement		
S027	Replacement Lambda sensor		
S027	Rail pressure sensor replacement		
S027	Rail pressure sensor and injector/s replacement		
S028	Voice synthesis test		
S028	Cooling fans test		
S028	Automatic emergency call activation		
S028	Manual emergency call activation		
S028	Assistance call activation		
S028	Optical fibre test		
S028	Backup battery replacement		
S028	Personal data deletion		
S028	VIN Code Configuration		
S028	Call buttons Configuration		
S028	Manual System Configuration		
S028	Automatic Configuration Read		
S028	Activation/Deactivation 'Auxiliary video input' procedure		
S029	Dist. To Next Service Zeroing (Coupon)		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S029	Tyre Pressure check	Wheel transmitters learning Looks for faulty wheel transmitter Looks for flat battery on wheel transmitter	
S029	New vehicle preparation	Maintenance Services config. Customer mode Reset distance till next servicing	
S029	Control Unit Replacement	Customer options Key programming Closure / Safety Engine / Gearbox	
S029	Manual System Configuration	Lights / Visibility Various Driver warnings Select the type of vehicle	
S030	System Configuration Read		
S031	Chassis number		
S032	Stored status deletion		
S033	Part. Filter regeneration		
S034	FAP Replacement		
S034	Additive type configuration		
S034	FAP Temperature Probe presence configuration		
S035	Zeroing of self-adaption parameters		
S036	Additional diesel circuit filling		
S036	Replacement of the additive, or the pump, or the tubes.		
S036	Particulate filter replacement (only for version with DPF)		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S036	EGR valve learn		
S036	Part. Filter regeneration		
S036	Replacement injector/s		
S037	Automatic gearbox replacement		
S037	Automatic gearbox and Control unit replacement		
S037	Automatic gearbox oil replacement		
S038	Part. Filter regeneration		
S039	Startup with Code Card		
S039	Injector codes read		
S039	Replacement of injector cyl. 1		
S039	Replacement of injector cyl. 2		
S039	Replacement of injector cyl. 3		
S039	Replacement of injector cyl. 4		
S039	Replacement injector cyl. 5		
S039	Injector replacement (per bank)		
S039	Oil change (only for version with DPF)		
S039	Rail pressure sensor replacement		
S039	Lambda sensor replacement (only for version with lambda sensor)		
S039	Air flow meter replacement (only for version with lambda sensor)		
S039	Differential pressure sensor replacement (only for version with DPF)		
S039	Pre-catalyser replacement (only for version with DPF)		
S039	Particulate filter replacement (only for version with DPF)		
S039	Particulate filter regeneration (only for version with DPF)		
S040	Startup with Code Card		
S040	Injector codes read		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S040	Cyl. 1 injector classification		
S040	Cyl. 2 injector classification		
S040	Cyl. 3 injector classification		
S040	Cyl. 4 injector classification		
S040	Cyl.5 injector classification		
S040	Injector classification (4 cyl. blank)		
S040	Injector classification (5 cyl. blank)		
S041	Siren serial line check		
S041	Ultrasound sensor check		
S041	Tilt sensor check (if present)		
S041	Dusk and rain sensors check		
S041	Window wash system check		
S041	Country Standards Change		
S042	Sensor vibration time too long		
S043	Accumulator depressurisation		
S043	Clutch bleed		
S043	End of line / service self-calibration		
S043	Clutch self-calibration enable		
S043	New actuators		
S043	Calculation of clutch degradation index		
S043	Satistical data deletion		
S043	Data deletion and return to initial values for clutch replacement		
S043	Data deletion for KIT/Gearbox replacement		
S043	Data deletion for tunnel lever replacement		
S043	Data deletion for pump replacement		

LANCIA V16.31 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S043	Data deletion for KIT/Pump replacement		
S043	Data deletion for pump relay replacement		
S043	Deletion of statistical data relating to errors		
S044	Servo Mechanism Group Replacement		
S044	Engine - Control Unit Group Replacement		
S045	Steering angle calibration		
S045	Longit.acc.sensor calibration		
S046	Siren serial line check		
S046	Ultrasound sensor check		
S046	Tilt sensor check(if present)		
S046	Dusk and rain sensors check		
S046	Window wash system check		
S047	Dusk and rain sensors check		
S047	Window wash system check		
S048	next service km's reset		
S048	Light setting corr.		
S048	trip counter reset		
S049	Startup with Code Card		
S049	Zeroing of self-adaption parameters		
S050	Electronic Key release		
S050	EGR		
S051	Startup with Code Card		
S051	Replacement of injector cyl. 1		
S051	Replacement of injector cyl. 2		
S051	Replacement of injector cyl. 3		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S051	Replacement of injector cyl. 4		
S051	Oil change (only for version with DPF)		
S051	Phonic wheel replacement		
S051	Rail pressure sensor replacement		
S051	Lambda sensor replacement (only for version with lambda sensor)		
S051	Air flow meter replacement (only for version with lambda sensor)		
S051	Differential pressure sensor replacement (only for version with DPF)		
S051	Pre-catalyser replacement (only for version with DPF)		
S051	Particulate filter replacement (only for version with DPF)		
S052	Steering angle calibration		
S052	Test limit speed disable		
S052	Test limit speed restore		
S052	Brake bleed		
S053	Reset self-adapt. param. and idle act		
S054	Oil Counter Write		
S054	Self-adaptive parameters		
S054	Sequence EV. 1		
S054	Sequence EV. 2		
S054	Sequence EV. 3		
S054	Sequence EV. 4		
S054	Sequence EV. 5		
S054	Sequence EV. 6		
S054	Heat exchang. Flow EV.		
S055	Accumulator depressurisation		
S055	Clutch bleed		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S055	End of line / service self-calibration		
S055	Clutch self-calibration enable		
S055	New actuators		
S055	Calculation of clutch degradation index		
S055	Engagement lever pin securing screw diagnosis		
S055	Selection lever return diagnosis		
S055	Satistical data deletion		
S055	Deletion of statistical data relating to errors		
S055	Data deletion and return to initial values for clutch replacement		
S055	Data deletion for KIT/Gearbox replacement		
S055	Data deletion for tunnel lever replacement		
S055	Data deletion for pump replacement		
S055	Data deletion for KIT/Pump replacement		
S055	Data deletion for pump relay replacement		
S055	Deletion of CITY switch replacement data		
S055	Deletion of SPORT switch replacement data		
S055	Data deletion for steering wheel levers replacement		
S056	Tow hook presence disable		
S056	Tow hook presence enable		
S056	Parking manoeuvre status		
S057	Antenna replacement		
S057	Control unit replacement		
S057	Alarm deletion		
S057	Wheel transmitters learning		
S057	Control unit activation		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S057	Control unit deactivation		
S057	Alarm state check		
S058	Headlamp pos.correct.		
S058	Servicing information delete		
S058	Reset odometer		
S058	Seat belts alarm exclusion		
S058	Seat belts alarm Enable		
S058	Instrument panel replacement		
S059	Tow hook presence disable		
S059	Tow hook presence enable		
S060	Reset odometer		
S060	Servicing information delete		
S060	Odometer write		
S060	Intrument panel replacement		
S061	Steering angle calibration		
S061	Vehicle type learn reset		
S062	Headlight actuators - high		
S062	Headlight actuators - intermediate		
S062	Headlight actuators - low		
S062	System calibration		
S063	Headlight actuators - high		
S063	Headlight actuators - intermediate		
S063	Headlight actuators - low		
S063	System calibration		
S064	Startup with Code Card		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S064			Self - learnt functions reset
S064			Zeroing of self - adaption parameters
S064			Neutral signal learn
S064			Performance limiting deactivation
S064			Oil change
S064			Motorised throttle replacement
S064			MultiAir Rolling finger replacement
S064			Timing sensor and/or cam replacement
S064			Rpm sensor and/or timing chain replacement
S064			Oil temperature sensor replacement
S064			Phonic wheel replacement
S064			UniAir module replacement
S064			Intelligent alternator (IAM) replacement
S064			Supercharging system components replacement
S064			Downstream lambda sensor and/or catalyzer and/or Injectors replacement
S065			Startup with Code Card
S065			Throttle learn storage
S065			Vehicle configuration deletion
S065			Phonic wheel learn reset
S065			Zeroing of self-adaption parameters
S065			Cam edges zeroing(VVT)
S065			Neutral signal learn
S066			Self-learnt functions reset
S066			Pump relay replacement
S066			Tunnel lever replacement

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S066	Steering wheel levers replacement		
S066	AUTO switch replacement		
S066	ECO/SPORT switch replacement		
S066	Clutch self-calibration enable		
S066	Accumulator depressurisation		
S066	New actuators		
S066	Clutch bleed		
S066	End of line/service self-calibration		
S066	Longitudinal acceleration signal learn		
S067	Static test		
S068	Static test		
S068	Lateral and longitud.acceleration sensor calibration		
S068	Steering angle calibration		
S068	Longitudinal/lateral Accel.sens.Calibration reset		
S069	Tow hook presence disable		
S069	Tow hook presence enable		
S070	Brake bleed		
S070	Steering angle calibration		
S070	Steering angle reset		
S070	Longit. acc. sensor calibration		
S071	System Configuration Read		
S071	control Unit Unlock		
S072	Manual System Configuration		
S072	Automatic Configuration Read		
S072	Automatic Configuration Write		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S072	United Kingdom(Thatcham std)		
S072	Volumetric sensors automatic diagnosis		
S073	Manual System Configuration		
S073	Deletion stored buttons		
S073	Automatic Configuration Read		
S073	Automatic Configuration Write		
S074	Startup with Code Card		
S074	Throttle learn storage		
S074	Vehicle configuration deletion		
S074	Phonic wheel learn reset		
S074	Zeroing of self-adaption parameters		
S074	Cam edges zeroing(VVT)		
S075	Startup with Code Card		
S075	Injector codes read		
S075	Speed limit setting		
S075	Neutral signal learn		
S075	Replacement of injector cyl. 1		
S075	Replacement of injector cyl. 2		
S075	Replacement of injector cyl. 3		
S075	Replacement of injector cyl. 4		
S075	Injector replacement(per bank)		
S075	Oil change		
S075	Phonic wheel replacement		
S075	Rail pressure sensor replacement		
S075	Replacement lambda sensor		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S075	Air flow meter sensor replacement		
S075	Differential pressure sensor replacement		
S075	Particulate filter with intergrated pre-cat replacement		
S075	Particulate filter regeneration		
S075	Intelligent alternator (IAM) replacement		
S075	Mechanical waste-gate valve replacement		
S075	Replacement of variable geometry turbo and/or turbo posit. Sensor		
S075	Resetting distance travelled with Water Temp. w. lamp ON		
S075	Resetting distance travelled with Water in diesel w. lamp ON		
S075	EGR valve test		
S075	Throttle test		
S075	Glow plug preheating circuit test		
S075	Self-learnt functions reset		
S076	Windowscreen wiper relay speed 1		
S076	Windowscreen wiper relay speed 2		
S076	Driver's side wind. Lift. Motion		
S076	Pass. Side wind. Lift. Motion		
S076	Inertia switch rearm (FIS)		
S076	Indicators command enable/disable		
S076	Country Standards Change		
S076	Power Mode Gearbox		
S077	Headlamp pos. correct		
S077	Servicing information delete		
S077	Reset odometer		
S077	Seat belts alarm exclusion		

LANCIA V16.31 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S077	Seat belts alarm Enable		
S077	Instrument panel replacement		
S078	Position sensor calibration		
S079	Flap actuators learning test		
S080	Tow hook presence disable		
S080	Tow hook presence enable		
S080	Parking manoeuvre status		
S081	Audio System Test		
S081	Convergence System Restart		
S082	Cooling fans test		
S082	Automatic emergency call activation		
S082	Manual emergency call activation		
S082	Assistance call activation		
S082	Backup battery replacement		
S082	Personal data deletion		
S082	JukeBox data deletion		
S082	VIN Code Configuration		
S082	Call buttons Configuration		
S082	Manual System Configuration		
S082	Automatic Configuration Read		
S082	Automatic Configuration Write		
S083	Brake bleed		
S083	Steering angle calibration		
S083	Steering angle reset		
S084	System configuration		

LANCIA V16.31 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S085	Voice synthesis test		
S085	Cooling fans test		
S085	Automatic emergency call activation		
S085	Manual emergency call activation		
S085	Assistance call activation		
S085	Optical fibre test		
S085	Backup battery replacement		
S085	Personal data deletion		
S085	VIN Code Configuration		
S085	Call buttons configuration		
S086	Looks for faunty wheel transmitter		
S086	Wheel transmitters learning		
S086	Wheel identification check		
S086	Control unit deactivation		
S086	Control unit activation		
S087	FAP Replacement		
S087	Control unit replacement		
S087	Engine type configuration		
S088	Dist. To Next Service Zeroing(Coupon)		
S089	Flap actuators learning test		
S089	Pollution sensor test		