



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	AVELLA(FV)	2000	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
			G 1.5 SOHC	ENGINE	Engine Control		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
		1999	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
			G 1.5 SOHC	ENGINE	Engine Control		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
		1998	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
			G 1.5 SOHC	ENGINE	Engine Control		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
		1997	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
			G 1.5 SOHC	ENGINE	Engine Control		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
		1996	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
			G 1.5 SOHC	ENGINE	Engine Control		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
		1995	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
		1994	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
2003	D 2.5 TCI	ENGINE	Engine Control			√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
	BESTA(TP)	2002	D 2.5 TCI	ENGINE	Engine Control		√	√	√	√		
		2001	D 2.5 TCI	ENGINE	Engine Control		√	√	√	√		
		2000	D 2.5 TCI	ENGINE	Engine Control		√	√	√	√		
		1999	D 2.5 TCI	ENGINE	Engine Control		√	√	√	√		
		1998	D 2.5 TCI	ENGINE	Engine Control		√	√	√	√		
		1997	D 2.5 TCI	ENGINE	Engine Control		√	√	√	√		
					ENGINE	Unleaded All	√	√	√	√	√	PCM lock(MEC)set PCM automatically detect reset Read VIN
					ENGINE	Leaded All	√	√	√	√	√	PCM lock(MEC)set PCM automatically detect reset Read VIN
					AT	Automatic Transaxle	√	√	√	√	√	Resetting adaptive values
					ESP	Electronic Stability Program	√	√	√	√		
					EPB	Electric Parking Brake	√	√	√	√	√	
					AIRBAG	Airbag(Event #1)	√	√	√	√		
					AIRBAG	Airbag(Event #2)	√	√	√	√		
					AIRCON	Air Conditioner	√	√	√	√	√	
					EPS	Power Steering	√	√	√	√		
			G 3.5 DOHC	BCM	All Systems	√	√	√	√	√		
					Instrument Panel Module	√	√	√	√	√		
					Driver Door Module	√	√	√	√	√		
					Assist Door Module	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
					Cluster Module	√	√	√	√	√	
					Power Seat Module	√	√	√	√	√	
					Steering Coulmn Module	√	√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				AHLS	Auto Headlamp Leveling	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Unleaded All	√	√	√	√	√	
					Leaded All	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√		
				EPB	EPB	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		
					Airbag(Event #2)	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√	√		
					All Systems	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2012	G 2.4 DOHC	BCM	Instrument Panel Module	√	√	√	√	√		
						Driver Door Module	√	√	√	√	√	
						Assist Door Module	√	√	√	√	√	
						Cluster Module	√	√	√	√	√	
						Power Seat Module	√	√	√	√	√	
						Steering Coulmn Module	√	√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PIC	All Systems	√	√	√	√	√	
						Smart Key Unit	√	√	√	√	√	
						Power Distribution Module	√	√	√	√	√	
						Smart Key Code Saving				√		
					AHLS	Auto Headlamp Leveling	√	√	√	√	√	
					CODE	Transmitter Code Saving				√		
					ENGINE	Unleaded All	√	√	√	√	√	self-learning clear
						Leaded All	√	√	√	√	√	self-learning clear
					AT	Automatic Transaxle	√	√	√	√	√	
					ESP	Electronic Stability Program	√	√	√	√		
					EPB	Electric Parking Brake	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√			
					Airbag(Event #2)	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function								
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions			
	CADENZA(VG)		G 3.0 DOHC	AIRCON	Air Conditioner	√	√	√	√	√				
				EPS	Motor Driven Power Steering	√	√	√	√	√				
				BCM	All Systems		√	√	√	√	√	√		
					Instrument Panel Module		√	√	√	√	√	√		
					Driver Door Module		√	√	√	√	√	√		
					Assist Door Module		√	√	√	√	√	√		
					Cluster Module		√	√	√	√	√	√		
					Power Seat Module		√	√	√	√	√	√		
					Steering Coulmn Module		√	√	√	√	√	√		
					IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems		√	√	√	√	√	√		
					Smart Key Unit		√	√	√	√	√	√		
					Power Distribution Module		√	√	√	√	√	√		
					Smart Key Code Saving						√			
				AHLS	Auto Headlamp Leveling		√	√	√	√	√	√		
				CODE	Transmitter Code Saving						√			
							ENGINE	Unleaded All	√	√	√	√	√	PCM lock(MEC)set PCM automatically detect reset Read VIN



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				ENGINE	Leaded All	√	√	√	√	√	PCM lock(MEC)set PCM automatically detect reset Read VIN
				AT	Automatic Transaxle	√	√	√	√	√	Resetting adaptive values
				ESP	Electronic Stability Program	√	√	√	√		
				AIRBAG	Airbag(Event #1)	√	√	√	√		
				AIRBAG	Airbag(Event #2)	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				BCM	All Systems	√	√	√	√	√	
					Instrument Panel Module	√	√	√	√	√	
					Driver Door Module	√	√	√	√	√	
					Assist Door Module	√	√	√	√	√	
					Cluster Module	√	√	√	√	√	
					Power Seat Module	√	√	√	√	√	
				IMMO	Steering Coulmn Module	√	√	√	√	√	
					Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
					Smart Key Code Saving				√			
				AHLS	Auto Headlamp Leveling	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
		2010	G 3.5 DOHC	ENGINE	Engine(Unleaded)	√	√	√	√	√	PCM lock(MEC)set PCM automatically detect reset Read VIN	
						Engine(Leaded)	√	√	√	√	√	√
					AT	Automatic Transaxle	√	√	√	√	√	Resetting adaptive values
					ESP	Electronic Stability Program	√	√	√	√		
					AIRBAG	Airbag(Event #1)	√	√	√	√		
						Airbag(Event #2)	√	√	√	√		
					AIRCON	Air Conditioner	√	√	√	√	√	
					BCM	All Systems	√	√	√	√	√	
						Instrument Panel Module	√	√	√	√	√	
						Driver Door Module	√	√	√	√	√	
						Assist Door Module	√	√	√	√	√	
						Cluster Module	√	√	√	√	√	
						Power Seat Module	√	√	√	√	√	
				Steering Coulmn Module	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
					Smart Key Code Saving				√			
				AHLS	Auto Headlamp Leveling	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
			G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√	Reset adaptive values	
					AT	Automatic Transaxle	√	√	√	√	√	
					ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
					AIRBAG	Airbag Control	√	√	√	√		
			G 1.6 DOHC	ENGINE	Unleaded IMMO(+)		√	√	√			
					ENGINE	Unleaded IMMO(-)		√	√	√		
					AT	Automatic Transaxle	√	√	√	√	√	
					ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
					AIRBAG	Airbag Control	√	√	√	√		
				IMMO	Immobilizer				√		Password learning/modify Key match Neutral mode Limp mode	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2006	G 1.8 DOHC	ENGINE	Unleaded EURO-4		√	√	√		
					Leaded All		√	√	√		
					Unleaded IMMO(+)		√	√	√		
					Unleaded IMMO(-)		√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√		
				IMMO	Immobilizer				√		Password learning/modify Key match Neutral mode Limp mode
			D 2.0 TCI	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√		
			G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√	Reset adaptive values
				AT	Automatic Transaxle	√	√	√	√	√	
		ABS		Anti-Lock Brake	√	√	√	√	√	Deflated mode	
		AIRBAG		Airbag Control	√	√	√	√			
		G 1.6 DOHC	ENGINE	Unleaded IMMO(+)		√	√	√			
				Unleaded IMMO(-)		√	√	√			
			AT	Automatic Transaxle	√	√	√	√	√		
			ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
AIRBAG	Airbag Control	√	√	√	√						



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function								
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions			
	CARENS(FJ)	2005	G 1.8 DOHC	IMMO	Immobilizer				√		Password learning/modify Key match Neutral mode Limp mode			
				ENGINE	Unleaded EURO-4		√	√	√					
					Leaded All		√	√	√					
					Unleaded IMMO(+)		√	√	√					
					Unleaded IMMO(-)		√	√	√					
				AT	Automatic Transaxle	√	√	√	√	√	√			
				ABS	Anti-Lock Brake	√	√	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√	√	√	√			
				IMMO	Immobilizer							√		Password learning/modify Key match Neutral mode Limp mode
				D 2.0 TCI	ENGINE	Engine Control	√	√	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	√	√	
					ABS	Anti-Lock Brake	√	√	√	√	√	√	√	Deflated mode
					AIRBAG	Airbag Control	√	√	√	√	√	√	√	
					IMMO	Immobilizer							√	
							ENGINE	Unleaded IMMO(+)		√	√	√		
							ENGINE	Unleaded IMMO(-)		√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2004	G 1.6 DOHC	AT	Automatic Transaxle		√	√	√				
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√	√	√			
				IMMO	Immobilizer						√	Password learning/modify Key match Neutral mode Limp mode	
			G 1.8 DOHC	ENGINE	Unleaded EURO-4			√	√	√			
					Leaded All				√	√	√		
					Unleaded IMMO(+)				√	√	√		
					Unleaded IMMO(-)				√	√	√		
				AT	Automatic Transaxle				√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√	√	√		
				IMMO	Immobilizer						√		Password learning/modify Key match Neutral mode Limp mode
			ENGINE	Engine Control	√	√	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	√		
		ABS		Anti-Lock Brake	√	√	√	√	√	√	√	Deflated mode	
		AIRBAG		Airbag Control	√	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.0 TCI	IMMO	Immobilizer				√		Password learning/modify Key match Neutral mode Limp mode	
		2003	G 1.8 DOHC	ENGINE	Unleaded EURO-4		√	√	√			
					Leaded All		√	√	√			
					Unleaded IMMO(+)		√	√	√			
					Unleaded IMMO(-)		√	√	√			
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√	√			
			IMMO	Immobilizer					√		Password learning/modify Key match Neutral mode Limp mode	
			D 2.0 TCI	ENGINE	Engine Control			√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√	√			
				IMMO	Immobilizer					√		Password learning/modify Key match Neutral mode Limp mode
			ENGINE	Engine Control-MT			√	√	√			
			AT	Automatic Transaxle			√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2002	G 1.8 DOHC	ABS	Anti-Lock Brake		√	√	√	√			
				AIRBAG	Airbag Control		√	√					
		2001	G 1.8 DOHC	ENGINE	Engine Control-MT		√	√	√				
				AT	Automatic Transaxle		√	√	√				
				ABS	Anti-Lock Brake		√	√	√	√			
				AIRBAG	Airbag Control		√	√					
		2000	G 1.8 DOHC	ENGINE	Engine Control		√	√	√				
				AT	Automatic Transaxle		√	√	√				
				ABS	Anti-Lock Brake		√	√	√	√	√		
						ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
							Unleaded GEN	√	√	√	√	√	Adaptive value reset
							Leaded All	√	√	√	√	√	Adaptive value reset
						AT	Automatic Transaxle	√	√	√	√	√	Resetting adaptive values
						ESP	Electronic Stability Program	√	√	√	√	√	
						AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
AIRCON	Air Conditioner					√	√	√	√	√			
BCM	Body Control Module					√			√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				CODE	Transmitter Code Saving				√			
			G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√		
					Unleaded GEN	√	√	√	√	√	√	
					Leaded All	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag	
				AIRCON	Air Conditioner	√	√	√	√	√		
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				CODE	Transmitter Code Saving				√			
		2011		ENGINE	Engine Control	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 2.0 TCI-D	AT	Automatic Transaxle	√	√	√	√	√	Resetting adaptive values
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√	
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
			AIRCON	Air Conditioner	√	√	√	√	√		
			BCM	Body Control Module	√			√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 1.6 TCI-U2	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				CODE	Transmitter Code Saving				√			
			G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
					Unleaded GEN	√	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	Resetting adaptive values	
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag	
				AIRCON	Air Conditioner	√	√	√	√	√		
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				CODE	Transmitter Code Saving				√			
					Unleaded EOBD	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2010	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√		
				ENGINE	Leaded All	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√				Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√	√	
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving						√	
				ENGINE	Engine Control	√	√	√	√	√	√	
			AT	Automatic Transaxle	√	√	√	√	√	√	Resetting adaptive values	
			ESP	Electronic Stability Program	√	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√				Collision Information Real-time information of passenger airbag	
			AIRCON	Air Conditioner	√	√	√	√	√	√		
		BCM	Body Control Module	√			√	√				
			D 2.0 TCI-D									



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				CODE	Transmitter Code Saving				√			
			G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
					Unleaded GEN	√	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	Resetting adaptive values	
				ESP	Electronic Stability Program	√	√	√	√			
				AIRBAG	Airbag Control	√	√	√				Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√		
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving					√		
					Unleaded EOBD	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	CARENS(UN)	2009	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	
					Leaded All	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√	
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving					√	
			D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	Resetting adaptive values
				ESP	Electronic Stability Program	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√	
				BCM	Body Control Module	√			√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				CODE	Transmitter Code Saving				√			
			G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
					Unleaded GEN	√	√	√	√	√	√	Adaptive value reset
					Leaded	√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	Resetting adaptive values	
				ABSESP	ABS/ESP(MGH-40)	√	√	√	√			
					ABS/ESP(MGH-25)	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√		
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			CODE	Transmitter Code Saving					√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2008	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset		
					Unleaded GEN	√	√	√	√	√	√	Adaptive value reset	
					Leaded All	√	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√	√	Resetting adaptive values	
				ABS	Anti-Lock Brake	√	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√					Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√	√	√	
				BCM	Body Control Module	√			√	√	√	√	
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving						√		
				ENGINE	Engine Control	√	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√	√	Resetting adaptive values
				ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	√	√	
					ABS/ESP(MGH-25)	√	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√					Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.0 TCI-D	BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				CODE	Transmitter Code Saving				√			
			G 2.0 DOHC		Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
				ENGINE		Unleaded GEN	√	√	√	√	√	Adaptive value reset
						Leaded All	√	√	√	√	√	Adaptive value reset
					AT	Automatic Transaxle	√	√	√	√	√	Resetting adaptive values
					ABS	Anti-Lock Brake	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
					AIRCON	Air Conditioner	√	√	√	√	√	
					BCM	Body Control Module	√			√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2007	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
					Unleaded GEN	√	√	√	√	√	Adaptive value reset	
					Leaded All	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√	Resetting adaptive values	
				ABS	Anti-Lock Brake	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag	
				AIRCON	Air Conditioner	√	√	√	√	√		
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				CODE	Transmitter Code Saving				√			
			D 2.0 TCI-D		ENGINE	Engine Control	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	Resetting adaptive values
					ABS	Anti-Lock Brake	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
		AIRCON			Air Conditioner	√	√	√	√	√		
		BCM			Body Control Module	√			√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				CODE	Transmitter Code Saving				√			
				ENGINE	Gasoline KV6		√	√	√	√		
					EURO-3		√	√	√	√		
					General KV6		√	√	√	√		
					AT	Automatic Transaxle		√	√	√	√	
					ABS	Anti-Lock Brake		√	√	√	√	Deflated mode
						ABS(EURO-3)		√	√	√	√	Deflated mode
					AIRBAG	Airbag Control	√	√	√	√		
				IMMO	Bosch Smartra				√		Password learning/modify Key match Neutral mode Limp mode	
		2006	G 2.5 DOHC	ENGINE	Engine(M/East)		√	√	√	√		
					AT	Automatic Transaxle		√	√	√	√	
					ABS	Anti-Lock Brake		√	√	√	√	Deflated mode
					AIRBAG	Airbag Control	√	√	√	√		
					AT	Automatic Transaxle		√	√	√	√	
				G 3.5 DOHC	ABS	ABS(C/Rail)		√	√	√	√	Deflated mode
					ABS	ABS(EURO-3)		√	√	√	√	Deflated mode



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			D 2.9 TCI-J3	AIRBAG	Airbag Control	√	√	√	√				
				IMMO	IMMO(C/Rail)				√		Password learning/modify Key match Neutral mode Limp mode		
		2005	G 2.5 DOHC	ENGINE	Gasoline		√	√	√	√			
					General		√	√	√	√	√		
					EURO-3		√	√	√	√	√		
				AT	Automatic Transaxle		√	√	√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	√	Deflated mode	
					ABS(EURO-3)		√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control		√	√	√	√			
				IMMO	Bosch Smatra					√		Password learning/modify Key match Neutral mode Limp mode	
				G 3.5 DOHC	ENGINE	Engine(M/East)		√	√	√	√	√	
					AT	Automatic Transaxle		√	√	√	√	√	
					ABS	Anti-Lock Brake		√	√	√	√	√	Deflated mode
					AIRBAG	Airbag Control		√	√	√	√	√	
					AT	Automatic Transaxle		√	√	√	√	√	
					ABS	ABS(C/Rail)		√	√	√	√	√	Deflated mode
		ABS(EURO-3)				√	√	√	√	√	Deflated mode		
		AIRBAG	Airbag Control			√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function									
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions				
			D 2.9 TCI-J3	IMMO	IMMO(C/Rail)				√		Password learning/modify Key match Neutral mode Limp mode				
		2004	G 2.5 DOHC	ENGINE	Gasoline		√	√	√	√					
					General		√	√	√	√					
					EURO-3		√	√	√	√					
				AT	Automatic Transaxle		√	√	√	√					
				ABS	Anti-Lock Brake		√	√	√	√	Deflated mode				
					ABS(EURO-3)		√	√	√	√	Deflated mode				
				AIRBAG	Airbag Control		√	√	√	√					
				IMMO	Bosch Smartra					√	Password learning/modify Key match Neutral mode Limp mode				
				G 3.5 DOHC	ENGINE	Engine Control			√	√	√	√			
						AT	Automatic Transaxle				√	√	√	√	
							Anti-Lock Brake					√	√	√	Deflated mode
						AIRBAG	Airbag Control		√		√	√	√		
					AT	Automatic Transaxle			√	√	√	√			
						ABS	ABS(C/Rail)				√	√	√	√	Deflated mode
		ABS(EURO-3)								√	√	√	Deflated mode		
			AIRBAG	Airbag Control		√	√	√	√						



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function								
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions			
			D 2.9 TCI-J3	IMMO	IMMO(C/Rail)				√		Password learning/modify Key match Neutral mode Limp mode			
		2003	G 2.4 DOHC	ENGINE	Engine Control		√	√	√	√				
				AT	Automatic Transaxle			√	√	√	√			
				ABS	Anti-Lock Brake			√	√	√	√	Deflated mode		
					ABS(EURO-3)				√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control		√	√	√	√				
				IMMO	Bosch Smartra					√		Password learning/modify Key match Neutral mode Limp mode		
				G 2.5 DOHC	ENGINE	Gasoline			√	√	√	√		
						General				√	√	√	√	
						EURO-3				√	√	√	√	
					AT	Automatic Transaxle			√	√	√	√		
					ABS	Anti-Lock Brake			√	√	√	√	Deflated mode	
						ABS(EURO-3)				√	√	√	√	Deflated mode
				AIRBAG	Airbag Control		√	√	√	√				
				IMMO	Bosch Smartra					√		Password learning/modify Key match Neutral mode Limp mode		
			ENGINE	Engine Control			√	√	√	√				

CARNIVAL /



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function									
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions				
	SEDONA(GQ)		G 3.5 DOHC	AT	Automatic Transaxle		√	√	√	√					
				ABS	Anti-Lock Brake		√	√	√	√	√	Deflated mode			
				AIRBAG	Airbag Control	√	√	√	√	√					
			D 2.9 TCI-J3	AT	Automatic Transaxle		√	√	√	√	√				
				ABS	ABS(C/Rail)		√	√	√	√	√	Deflated mode			
					ABS(EURO-3)		√	√	√	√	√	Deflated mode			
				AIRBAG	Airbag Control	√	√	√	√	√					
			IMMO	IMMO(C/Rail)						√		Password learning/modify Key match Neutral mode Limp mode			
			G 2.4 DOHC	ENGINE	Engine Control					√	√	√	√		
				AT	Automatic Transaxle					√	√	√	√		
				ABS	Anti-Lock Brake						√	√	√	√	Deflated mode
					ABS(C/Rail)						√	√	√	√	Deflated mode
					ABS(EURO-3)						√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√				√	√	√	√		
				IMMO	IMMO(Bosch)								√	Password learning/modify Key match Neutral mode Limp mode	
			ENGINE	Europe						√	√	√	√		
				General						√	√	√	√		
				EURO-3						√	√	√	√		
				AT	Automatic Transaxle					√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2002	G 2.5 DOHC	ABS	Anti-Lock Brake		√	√	√	√	Deflated mode
					ABS(C/Rail)		√	√	√	√	Deflated mode
					ABS(EURO-3)		√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√		
			IMMO	IMMO(Bosch)				√		Password learning/modify Key match Neutral mode Limp mode	
			D 2.9 TCI-J3	AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake		√	√	√	√	Deflated mode
					ABS(C/Rail)		√	√	√	√	Deflated mode
					ABS(EURO-3)		√	√	√	√	Deflated mode
		AIRBAG		Airbag Control	√	√	√	√			
		IMMO	IMMO(C/Rail)				√		Password learning/modify Key match Neutral mode Limp mode		
		2001	G 2.5 DOHC	ENGINE	Engine(Europe)		√	√	√	√	
					Engine(General)		√	√	√	√	
				AT	A/T(Europe)		√	√	√	√	
					A/T(General)		√	√	√	√	
				AIRBAG	Airbag(Europe)		√	√	√		
					Airbag(General)		√	√	√		
		AT	A/T(Europe)		√	√	√				
A/T(General)			√	√	√						



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.9 TCI-J3	AIRBAG	Airbag(Europe)		√	√				
					Airbag(General)		√	√	√			
		2000	G 2.5 DOHC	ENGINE	Engine(Europe)		√	√	√	√		
					Engine(General)		√	√	√	√		
				AT	A/T(Europe)		√	√	√	√		
					A/T(General)		√	√	√	√		
			AIRBAG		Airbag(Europe)		√	√				
					Airbag(General)		√	√	√			
			D 2.9 TCI-J3	AT	A/T(Europe)		√	√	√			
					A/T(General)		√	√	√			
				AIRBAG		Airbag(Europe)		√	√			
						Airbag(General)		√	√	√		
		1999	G 2.5 DOHC	ENGINE	Engine(Europe)		√	√	√	√		
					Engine(General)		√	√	√	√		
				AT	A/T(Europe)		√	√	√	√		
					A/T(General)		√	√	√	√		
				ABS		ABS(Europe)		√	√	√	√	Deflated mode
						ABS(General)		√	√	√	√	Deflated mode
			AIRBAG		Airbag(Europe)		√	√	√			
					Airbag(General)		√	√				
			D 2.9 TCI-J3	AT	A/T(Europe)		√	√	√			
					A/T(General)		√	√	√			
				ABS		ABS(Europe)		√	√	√	√	Deflated mode
						ABS(General)		√	√	√	√	Deflated mode
			AIRBAG	Airbag(Europe)		√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				AIRBAG	Airbag(General)		√	√				
			G 2.5 DOHC	ENGINE	Engine(Europe)		√	√	√	√		
					Engine(General)		√	√	√	√	√	
				AT	A/T(Europe)		√	√	√	√		
					A/T(General)		√	√	√	√		
				ABS	ABS(Europe)		√	√	√	√	Deflated mode	
					ABS(General)		√	√	√	√	Deflated mode	
				AIRBAG	Airbag(Europe)		√	√	√			
					Airbag(General)		√	√				
			D 2.9 TCI-J3	AT	A/T(Europe)		√	√	√			
					A/T(General)		√	√	√			
				ABS	ABS(Europe)		√	√	√	√	Deflated mode	
					ABS(General)		√	√	√	√	Deflated mode	
				AIRBAG	Airbag(Europe)		√	√	√			
					Airbag(General)		√	√				
				ENGINE	Unleaded GEN	√	√	√	√	√		
					Leaded All		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	√	
				ABSESP	ABS(MEB-2)		√	√	√	√	√	
					ESP(MEB-2)		√	√	√	√	√	
				AIRBAG	Airbag Control		√	√	√	√		
				AIRCON	Air Conditioner		√	√	√	√	√	
					All Systems			√	√	√	√	
					Instrument Panel Module			√	√	√	√	
					Front Area Module			√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 3.5 DOHC	BCM	Rear Area Module		√	√	√	√		
					Driver Door Module		√	√	√	√	√	
					Assist Door Module		√	√	√	√	√	
					Integrated Memory System		√	√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PSD	All Systems	√	√	√	√		
						Power Sliding Door-LH	√	√	√	√		
						Power Sliding Door-RH	√	√	√	√		
					PTG	Power Tail Gate	√	√	√	√		
					CODE	Transmitter Code Saving				√		
					ENGINE	Unleaded EOBD		√	√	√	√	
						Unleaded GEN		√	√	√	√	
						Leaded All		√	√	√	√	
					AT	Automatic Transaxle		√	√	√	√	
				ABSESP	ABS(MEB-2)	√	√	√	√	√		
					ESP(MEB-2)	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
					All Systems		√	√	√	√		
					Instrument Panel Module		√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.7 DOHC	BCM	Front Area Module		√	√	√	√		
					Rear Area Module		√	√	√	√	√	
					Driver Door Module		√	√	√	√	√	
					Assist Door Module		√	√	√	√	√	
					Integrated Memory System		√	√	√	√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PSD	All Systems	√	√	√	√			
					Power Sliding Door-LH	√	√	√	√			
					Power Sliding Door-RH	√	√	√	√			
				PTG	Power Tail Gate	√	√	√	√			
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control			√	√	√	√	ECU initialization
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ABSESP	ABS(MEB-2)	√	√	√	√	√	√	
					ESP(MEB-2)	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	√	
					All Systems			√	√	√	√	
				Instrument Panel Module			√	√	√	√		
				Front Area Module			√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2012	D 2.9 WGT	BCM	Rear Area Module		√	√	√	√			
					Driver Door Module			√	√	√	√		
					Assist Door Module			√	√	√	√		
					Integrated Memory System			√	√	√	√		
					IMMO	Immobilizer				√		Password learning/modify Key match Neutral mode Limp mode	
					PSD	All Systems	√	√	√	√			
						Power Sliding Door-LH	√	√	√	√			
						Power Sliding Door-RH	√	√	√	√			
					PTG	Power Tail Gate	√	√	√	√			
					BHEATER	Fuel Fired Heater	√	√	√	√	√		
					CODE	Transmitter Code Saving				√			
					ENGINE	Engine Control	√	√	√	√	√		
					AT	Automatic Transaxle	√	√	√	√	√		
					ABSESP	ABS(MEB-2)	√	√	√	√	√		
						ESP(MEB-2)	√	√	√	√	√		
					AIRBAG	Airbag Control	√	√	√	√			
					AIRCON	Air Conditioner	√	√	√	√	√		
					BCM	All Systems		√	√	√	√		
						Instrument Panel Module			√	√	√	√	
						Front Area Module			√	√	√	√	
				Rear Area Module				√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.9 VGT		Driver Door Module		√	√	√	√		
						Assist Door Module		√	√	√	√	
						Integrated Memory System		√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PSD	All Systems	√	√	√	√		
						Power Sliding Door-LH	√	√	√	√		
						Power Sliding Door-RH	√	√	√	√		
					PTG	Power Tail Gate	√	√	√	√		
					BHEATER	Fuel Fired Heater	√	√	√	√	√	
					CODE	Transmitter Code Saving				√		
					ENGINE	Engine Control(CPF-)	√	√	√	√	√	
						Engine Control(CPF+)	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	
					ABSESP	ABS(MEB-2)	√	√	√	√	√	
						ESP(MEB-2)	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
					All Systems		√	√	√	√		
					Instrument Panel Module		√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.2 TCI-R	BCM	Front Area Module		√	√	√	√		
					Rear Area Module		√	√	√	√	√	
					Driver Door Module		√	√	√	√	√	
					Assist Door Module		√	√	√	√	√	
					Integrated Memory System		√	√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PSD	All Systems	√	√	√	√		
						Power Sliding Door-LH	√	√	√	√		
						Power Sliding Door-RH	√	√	√	√		
					PTG	Power Tail Gate	√	√	√	√		
					CODE	Transmitter Code Saving				√		
					ENGINE	Unleaded GEN	√	√	√	√	√	
						Leaded All	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	
					ABSESP	ABS(MEB-2)	√	√	√	√	√	
				ESP(MEB-2)		√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
					All Systems		√	√	√	√		
					Instrument Panel Module		√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 3.5 DOHC	BCM	Front Area Module		√	√	√	√		
					Rear Area Module		√	√	√	√	√	
					Driver Door Module		√	√	√	√	√	
					Assist Door Module		√	√	√	√	√	
					Integrated Memory System		√	√	√	√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PSD	All Systems	√	√	√	√			
					Power Sliding Door-LH	√	√	√	√			
					Power Sliding Door-RH	√	√	√	√			
				PTG	Power Tail Gate	√	√	√	√			
				CODE	Transmitter Code Saving				√			
				ENGINE	Unleaded EOBD		√	√	√	√	√	
					Unleaded GEN		√	√	√	√	√	
					Leaded All		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	√	
				ABSESP	ABS(MEB-2)	√	√	√	√	√	√	
					ESP(MEB-2)	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√			
			AIRCON	Air Conditioner	√	√	√	√	√	√		
				All Systems		√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.7 DOHC	BCM	Instrument Panel Module		√	√	√	√		
					Front Area Module		√	√	√	√	√	
					Rear Area Module		√	√	√	√	√	
					Driver Door Module		√	√	√	√	√	
					Assist Door Module		√	√	√	√	√	
					Integrated Memory System		√	√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PSD	All Systems	√	√	√	√		
				Power Sliding Door-LH		√	√	√	√			
				Power Sliding Door-RH		√	√	√	√			
					PTG	Power Tail Gate	√	√	√	√		
					CODE	Transmitter Code Saving				√		
					ENGINE	Engine Control		√	√	√	√	ECU initialization
					AT	Automatic Transaxle	√	√	√	√	√	
					ABSESP	ABS(MEB-2)	√	√	√	√	√	
				ESP(MEB-2)		√	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√	√		
					AIRCON	Air Conditioner	√	√	√	√	√	
						All Systems		√	√	√	√	
						Instrument Panel Module		√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2011	D 2.9 WGT	BCM	Front Area Module		√	√	√	√	
					Rear Area Module		√	√	√	√	
					Driver Door Module		√	√	√	√	
					Assist Door Module		√	√	√	√	
					Integrated Memory System		√	√	√	√	
				IMMO	Immobilizer				√		Password learning/modify Key match Neutral mode Limp mode
				PSD	All Systems	√	√	√	√		
					Power Sliding Door-LH	√	√	√	√		
					Power Sliding Door-RH	√	√	√	√		
				PTG	Power Tail Gate	√	√	√	√		
				BHEATER	Fuel Fired Heater	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABSESP	ABS(MEB-2)	√	√	√	√	√	
					ESP(MEB-2)	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
					All Systems		√	√	√	√	
					Instrument Panel Module		√	√	√	√	
					Front Area Module		√	√	√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.9 VGT	BCM	Rear Area Module		√	√	√	√		
					Driver Door Module		√	√	√	√	√	
					Assist Door Module		√	√	√	√	√	
					Integrated Memory System		√	√	√	√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PSD	All Systems	√	√	√	√			
					Power Sliding Door-LH	√	√	√	√			
					Power Sliding Door-RH	√	√	√	√			
				PTG	Power Tail Gate	√	√	√	√			
				BHEATER	Fuel Fired Heater	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
					Engine Control(CPF+)	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ABSESP	ABS(MEB-2)	√	√	√	√	√	√	
					ESP(MEB-2)	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	√	
				All Systems		√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.2 TCI-R	BCM	Instrument Panel Module		√	√	√	√		
					Front Area Module		√	√	√	√	√	
					Rear Area Module		√	√	√	√	√	
					Driver Door Module		√	√	√	√	√	
					Assist Door Module		√	√	√	√	√	
					Integrated Memory System		√	√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PSD	All Systems	√	√	√	√		
				Power Sliding Door-LH		√	√	√	√			
				Power Sliding Door-RH		√	√	√	√			
					PTG	Power Tail Gate	√	√	√	√		
					CODE	Transmitter Code Saving				√		
					ENGINE	Unleaded EOBD		√	√	√	√	
				Unleaded GEN			√	√	√	√	√	
				Leaded All			√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√		
				ABSESP	ABS(MEB-2)	√	√	√	√	√		
			ESP(MEB-2)		√	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 3.8 DOHC	BCM	All Systems		√	√	√	√		
					Instrument Panel Module		√	√	√	√	√	
					Front Area Module		√	√	√	√	√	
					Rear Area Module		√	√	√	√	√	
					Driver Door Module		√	√	√	√	√	
					Assist Door Module		√	√	√	√	√	
					Integrated Memory System		√	√	√	√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PSD	All Systems	√	√	√	√			
					Power Sliding Door-LH	√	√	√	√			
					Power Sliding Door-RH	√	√	√	√			
				PTG	Power Tail Gate	√	√	√	√			
				CODE	Transmitter Code Saving				√			
				ENGINE	Unleaded EOBD		√	√	√	√	√	
					Unleaded GEN		√	√	√	√	√	
					Leaded All		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	√	
				ABSESP	ABS(MEB-2)	√	√	√	√	√	√	
					ESP(MEB-2)	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 2.7 DOHC	AIRCON	Air Conditioner	√	√	√	√	√			
				BCM	All Systems			√	√	√	√		
					Instrument Panel Module				√	√	√	√	
					Front Area Module				√	√	√	√	
					Rear Area Module				√	√	√	√	
					Driver Door Module				√	√	√	√	
					Assist Door Module				√	√	√	√	
					Integrated Memory System				√	√	√	√	
					IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PSD	All Systems		√	√	√	√			
					Power Sliding Door-LH			√	√	√	√		
					Power Sliding Door-RH			√	√	√	√		
				PTG	Power Tail Gate		√	√	√	√			
				CODE	Transmitter Code Saving					√			
				ENGINE	Engine Control			√	√	√	√	ECU initialization	
				AT	Automatic Transaxle		√	√	√	√	√		
				ABSESP	ABS(MEB-2)		√	√	√	√	√		
					ESP(MEB-2)			√	√	√	√	√	
				AIRBAG	Airbag Control		√	√	√	√			
				AIRCON	Air Conditioner		√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2010	D 2.9 WGT	BCM	All Systems		√	√	√	√			
					Instrument Panel Module		√	√	√	√	√		
					Front Area Module		√	√	√	√	√		
					Rear Area Module		√	√	√	√	√		
					Driver Door Module		√	√	√	√	√		
					Assist Door Module		√	√	√	√	√		
					Integrated Memory System		√	√	√	√	√		
						IMMO	Immobilizer				√		Password learning/modify Key match Neutral mode Limp mode
						PSD	All Systems	√	√	√	√		
							Power Sliding Door-LH	√	√	√	√		
							Power Sliding Door-RH	√	√	√	√		
						PTG	Power Tail Gate	√	√	√	√		
						BHEATER	Fuel Fired Heater	√	√	√	√	√	
						CODE	Transmitter Code Saving				√		
						ENGINE	Engine Control	√	√	√	√	√	
						AT	Automatic Transaxle	√	√	√	√	√	
						ABSESP	ABS(MEB-2)	√	√	√	√	√	
							ESP(MEB-2)	√	√	√	√	√	
						AIRBAG	Airbag Control	√	√	√	√		
						AIRCON	Air Conditioner	√	√	√	√	√	
					All Systems		√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.9 VGT	BCM	Instrument Panel Module		√	√	√	√		
					Front Area Module		√	√	√	√	√	
					Rear Area Module		√	√	√	√	√	
					Driver Door Module		√	√	√	√	√	
					Assist Door Module		√	√	√	√	√	
					Integrated Memory System		√	√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PSD	All Systems	√	√	√	√		
				Power Sliding Door-LH		√	√	√	√			
				Power Sliding Door-RH		√	√	√	√			
					PTG	Power Tail Gate	√	√	√	√		
					BHEATER	Fuel Fired Heater	√	√	√	√	√	
					CODE	Transmitter Code Saving				√		
					ENGINE	Engine Control(CPF-)	√	√	√	√	√	
				Engine Control(CPF+)		√	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	
					ABSESP	ABS(MEB-2)	√	√	√	√	√	
			ESP(MEB-2)	√		√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			D 2.2 TCI-R	AIRCON	Air Conditioner	√	√	√	√	√			
				BCM		All Systems		√	√	√	√		
							Instrument Panel Module		√	√	√	√	
							Front Area Module		√	√	√	√	
							Rear Area Module		√	√	√	√	
							Driver Door Module		√	√	√	√	
							Assist Door Module		√	√	√	√	
							Integrated Memory System		√	√	√	√	
						IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PSD	All Systems	√	√	√	√			
							Power Sliding Door-LH	√	√	√	√		
							Power Sliding Door-RH	√	√	√	√		
					PTG	Power Tail Gate	√	√	√	√			
					CODE	Transmitter Code Saving				√			
	CARNIVAL/ SEDONA(V Q)				ENGINE	Unleaded EOBD		√	√	√	√		
						Unleaded GEN		√	√	√	√		
						Leaded All		√	√	√	√		
					AT	Automatic Transaxle		√	√	√	√		
					ABSESP	ABS/ESP	√	√	√	√	√		
					AIRBAG	Airbag Control	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 2.7 DOHC	AIRCON	Air Conditioner	√	√	√	√	√			
				BCM	All Systems			√	√	√	√		
					Instrument Panel Module				√	√	√	√	
					Front Area Module				√	√	√	√	
					Rear Area Module				√	√	√	√	
					Driver Door Module				√	√	√	√	
					Assist Door Module				√	√	√	√	
					Integrated Memory System				√	√	√	√	
					IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PSD	All Systems		√	√	√	√			
					Power Sliding Door-LH			√	√	√	√		
					Power Sliding Door-RH			√	√	√	√		
				PTG	Power Tail Gate		√	√	√	√			
				CODE	Transmitter Code Saving					√			
				ENGINE	Unleaded EOBD			√	√	√	√		
					Unleaded GEN				√	√	√	√	
					Leaded All				√	√	√	√	
				AT	Automatic Transaxle			√	√	√	√		
				ABSESP	ABS/ESP		√	√	√	√	√		
				AIRBAG	Airbag Control		√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2009	G 3.8 DOHC	AIRCON	Air Conditioner	√	√	√	√	√			
						BCM	All Systems		√	√	√	√	
							Instrument Panel Module		√	√	√	√	
							Front Area Module		√	√	√	√	
							Rear Area Module		√	√	√	√	
							Driver Door Module		√	√	√	√	
							Assist Door Module		√	√	√	√	
							Integrated Memory System		√	√	√	√	
							IMMO	Immobilizer					
						PSD	All Systems	√	√	√	√		
							Power Sliding Door-LH	√	√	√	√		
							Power Sliding Door-RH	√	√	√	√		
						PTG	Power Tail Gate	√	√	√	√		
						CODE	Transmitter Code Saving				√		
						ENGINE	Engine Control		√	√	√	√	ECU initialization
						AT	Automatic Transaxle	√	√	√	√	√	
						ABSESP	ABS/ESP	√	√	√	√	√	
						AIRBAG	Airbag Control	√	√	√	√		
						AIRCON	Air Conditioner	√	√	√	√	√	
					All Systems		√	√	√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.9 WGT	BCM	Instrument Panel Module		√	√	√	√		
					Front Area Module		√	√	√	√	√	
					Rear Area Module		√	√	√	√	√	
					Driver Door Module		√	√	√	√	√	
					Assist Door Module		√	√	√	√	√	
					Integrated Memory System		√	√	√	√	√	
					IMMO	Immobilizer				√		Password learning/modify Key match Neutral mode Limp mode
					PSD	All Systems	√	√	√	√		
						Power Sliding Door-LH	√	√	√	√		
						Power Sliding Door-RH	√	√	√	√		
					PTG	Power Tail Gate	√	√	√	√		
					BHEATER	Fuel Fired Heater	√	√	√	√	√	
					CODE	Transmitter Code Saving				√		
					ENGINE	Engine Control	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	
					ABSESP	ABS/ESP	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√	√		
					AIRCON	Air Conditioner	√	√	√	√	√	
						All Systems		√	√	√	√	
						Instrument Panel Module		√	√	√	√	
					Front Area Module		√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			D 2.9 VGT	BCM	Rear Area Module		√	√	√	√			
					Driver Door Module		√	√	√	√	√		
					Assist Door Module		√	√	√	√	√		
					Integrated Memory System		√	√	√	√	√		
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
					PSD	All Systems	√	√	√	√			
						Power Sliding Door-LH	√	√	√	√			
						Power Sliding Door-RH	√	√	√	√			
					PTG	Power Tail Gate	√	√	√	√			
					BHEATER	Fuel Fired Heater	√	√	√	√	√		
					CODE	Transmitter Code Saving				√			
					ENGINE	Unleaded EOBD		√	√	√	√		
						Unleaded GEN		√	√	√	√	√	
						Leaded All		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√			
				ABSESP	ABS/ESP	√	√	√	√	√			
				AIRBAG	Airbag Control	√	√	√	√				
				AIRCON	Air Conditioner	√	√	√	√	√			
					All Systems		√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 3.8 DOHC	BCM	Instrument Panel Module		√	√	√	√		
					Front Area Module		√	√	√	√	√	
					Rear Area Module		√	√	√	√	√	
					Driver Door Module		√	√	√	√	√	
					Assist Door Module		√	√	√	√	√	
					Integrated Memory System		√	√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PSD	All Systems	√	√	√	√		
				Power Sliding Door-LH		√	√	√	√			
				Power Sliding Door-RH		√	√	√	√			
					PTG	Power Tail Gate	√	√	√	√		
					CODE	Transmitter Code Saving				√		
					ENGINE	Unleaded EOBD		√	√	√	√	
				Unleaded GEN			√	√	√	√	√	
				Leaded All			√	√	√	√	√	
					AT	Automatic Transaxle		√	√	√	√	
					ABSESP	ABS/ESP	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√	√		
					AIRCON	Air Conditioner	√	√	√	√	√	
						All Systems		√	√	√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2008	G 2.7 DOHC	BCM	Instrument Panel Module		√	√	√	√			
					Front Area Module		√	√	√	√	√		
					Rear Area Module		√	√	√	√	√		
					Driver Door Module		√	√	√	√	√		
					Assist Door Module		√	√	√	√	√		
					Integrated Memory System		√	√	√	√	√		
						IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
						PSD	All Systems	√	√	√	√		
							Power Sliding Door-LH	√	√	√	√		
							Power Sliding Door-RH	√	√	√	√		
						PTG	Power Tail Gate	√	√	√	√		
						CODE	Transmitter Code Saving				√		
						ENGINE	Engine Control		√	√	√	√	ECU initialization
						AT	Automatic Transaxle	√	√	√	√	√	
						ABSESP	ABS/ESP	√	√	√	√	√	
						AIRBAG	Airbag Control	√	√	√	√		
						AIRCON	Air Conditioner	√	√	√	√	√	
							All Systems		√	√	√	√	
							Instrument Panel Module		√	√	√	√	
							Front Area Module		√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.9 WGT	BCM	Rear Area Module		√	√	√	√		
					Driver Door Module		√	√	√	√	√	
					Assist Door Module		√	√	√	√	√	
					Integrated Memory System		√	√	√	√	√	
				IMMO	Immobilizer					√		Password learning/modify Key match Neutral mode Limp mode
				PSD	All Systems	√	√	√	√	√		
					Power Sliding Door-LH	√	√	√	√	√		
					Power Sliding Door-RH	√	√	√	√	√		
				PTG	Power Tail Gate	√	√	√	√	√		
				BHEATER	Fuel Fired Heater	√	√	√	√	√	√	
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ABSESP	ABS/ESP	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√	√		
			AIRCON	Air Conditioner	√	√	√	√	√	√		
			BCM	All Systems		√	√	√	√	√		
				Instrument Panel Module		√	√	√	√	√		
				Front Area Module		√	√	√	√	√		
				Rear Area Module		√	√	√	√	√		
				Driver Door Module		√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.9 VGT		Assist Door Module		√	√	√	√		
						Integrated Memory System		√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PSD	All Systems	√	√	√	√		
						Power Sliding Door-LH	√	√	√	√		
						Power Sliding Door-RH	√	√	√	√		
					PTG	Power Tail Gate	√	√	√	√		
					BHEATER	Fuel Fired Heater	√	√	√	√	√	
					CODE	Transmitter Code Saving				√		
					ENGINE	Unleaded EOBD		√	√	√	√	
						Unleaded GEN		√	√	√	√	
						Leaded All		√	√	√	√	
					AT	Automatic Transaxle		√	√	√	√	
					ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
					All Systems		√	√	√	√		
					Instrument Panel Module		√	√	√	√		
					Front Area Module		√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 3.8 DOHC	BCM	Rear Area Module		√	√	√	√		
						Driver Door Module		√	√	√	√	
						Assist Door Module		√	√	√	√	
						Integrated Memory System		√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PSD	All Systems	√	√	√	√		
						Power Sliding Door-LH	√	√	√	√		
						Power Sliding Door-RH	√	√	√	√		
					PTG	Power Tail Gate	√	√	√	√		
					CODE	Transmitter Code Saving				√		
					ENGINE	Unleaded EOBD		√	√	√	√	
						Unleaded GEN		√	√	√	√	
						Leaded All		√	√	√	√	
					AT	Automatic Transaxle		√	√	√	√	
				ABSESP	ABS/ESP	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
					All Systems		√	√	√	√		
					Instrument Panel Module		√	√	√	√		
					Front Area Module		√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2007	G 2.7 DOHC	BCM	Rear Area Module		√	√	√	√			
					Driver Door Module		√	√	√	√			
					Assist Door Module		√	√	√	√			
					Integrated Memory System		√	√	√	√			
						IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
						PSD	All Systems	√	√	√	√		
							Power Sliding Door-LH	√	√	√	√		
							Power Sliding Door-RH	√	√	√	√		
						PTG	Power Tail Gate	√	√	√	√		
						CODE	Transmitter Code Saving				√		
						ENGINE	Engine Control		√	√	√	√	ECU initialization
						AT	Automatic Transaxle	√	√	√	√	√	
						ABSESP	ABS/ESP	√	√	√	√	√	
						AIRBAG	Airbag Control	√	√	√	√		
						AIRCON	Air Conditioner	√	√	√	√	√	
						BCM	All Systems		√	√	√	√	
							Instrument Panel Module		√	√	√	√	
							Front Area Module		√	√	√	√	
				Rear Area Module			√	√	√	√			
				Driver Door Module			√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.9 WGT		Assist Door Module		√	√	√	√		
						Integrated Memory System		√	√	√	√	
					IMMO	Immobilizer				√		Password learning/modify Key match Neutral mode Limp mode
					PSD	All Systems	√	√	√	√		
						Power Sliding Door-LH	√	√	√	√		
						Power Sliding Door-RH	√	√	√	√		
					PTG	Power Tail Gate	√	√	√	√		
					BHEATER	Fuel Fired Heater	√	√	√	√	√	
					CODE	Transmitter Code Saving				√		
					ENGINE	Engine Control	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	
					ABSESP	ABS/ESP	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√	√		
					AIRCON	Air Conditioner	√	√	√	√	√	
				BCM	All Systems		√	√	√	√		
					Instrument Panel Module		√	√	√	√		
					Front Area Module		√	√	√	√		
					Rear Area Module		√	√	√	√		
					Driver Door Module		√	√	√	√		
					Assist Door Module		√	√	√	√		
					Integrated Memory System		√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.9 VGT	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PSD	All Systems		√	√	√	√		
					Power Sliding Door-LH		√	√	√	√		
					Power Sliding Door-RH		√	√	√	√		
				PTG	Power Tail Gate		√	√	√	√		
				BHEATER	Fuel Fired Heater		√	√	√	√	√	
				CODE	Transmitter Code Saving					√		
				AT	Automatic Transaxle			√	√			
				ABSESP	ABS/ESP		√	√	√	√	√	
				AIRBAG	Airbag Control		√	√	√	√		
			AIRCON	Air Conditioner		√	√	√	√	√		
			BCM	Instrument Panel Module			√	√	√	√		
				Front Area Module			√	√	√	√		
				Rear Area Module			√	√	√	√		
				Driver Door Module			√	√	√	√		
				Assist Door Module			√	√	√	√		
				Integrated Memory System			√	√	√	√		
				All systems			√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 2.7 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
				PSD		All Systems	√	√	√	√			
							Power Sliding Door-LH	√	√	√	√		
							Power Sliding Door-RH	√	√	√	√		
							Power Tail Gate	√	√	√	√		
					CODE	Transmitter Code Saving				√			
					AT	Automatic Transaxle		√	√				
					ABSESP	ABS/ESP	√	√	√	√	√		
					AIRBAG	Airbag Control	√	√	√	√			
					AIRCON	Air Conditioner	√	√	√	√	√		
					BCM	All Systems		√	√	√	√		
							Instrument Panel Module		√	√	√	√	
							Front Area Module		√	√	√	√	
							Rear Area Module		√	√	√	√	
							Driver Door Module		√	√	√	√	
					Assist Door Module		√	√	√	√			
					Integrated Memory System		√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2006	G 3.8 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
				PSD	All Systems		√	√	√	√			
					Power Sliding Door-LH		√	√	√	√			
					Power Sliding Door-RH		√	√	√	√			
				PTG	Power Tail Gate		√	√	√	√			
			CODE	Transmitter Code Saving					√				
			D 2.9 WGT	ENGINE	Engine Control			√	√	√	√	ECU initialization	
				AT	Automatic Transaxle		√	√	√	√	√		
				ABSESP	ABS/ESP		√	√	√	√	√		
				AIRBAG	Airbag Control		√	√	√	√			
				AIRCON	Air Conditioner		√	√	√	√	√		
				BCM	All Systems			√	√	√	√	√	
					Instrument Panel Module				√	√	√	√	
					Front Area Module				√	√	√	√	
			Rear Area Module					√	√	√	√		
			Driver Door Module			√	√	√	√				
			Assist Door Module			√	√	√	√				
			Integrated Memory System			√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer				√		Password learning/modify Key match Neutral mode Limp mode
				PSD	All Systems	√	√	√	√		
					Power Sliding Door-LH	√	√	√	√		
					Power Sliding Door-RH	√	√	√	√		
				PTG	Power Tail Gate	√	√	√	√		
				BHEATER	Fuel Fired Heater	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				BCM	All Systems		√	√	√	√	
					Instrument Panel Module		√	√	√	√	
					Front Area Module		√	√	√	√	
					Rear Area Module		√	√	√	√	
					Driver Door Module		√	√	√	√	
					Assist Door Module		√	√	√	√	
					Integrated Memory System		√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 2.9 VGT	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PSD	All Systems	√	√	√	√		
					Power Sliding Door-LH	√	√	√	√		
					Power Sliding Door-RH	√	√	√	√		
				PTG	Power Tail Gate	√	√	√	√		
				BHEATER	Fuel Fired Heater	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information
				AIRCON	Air Conditioner(Dual)	√	√	√	√	√	
					Air Conditioner(Single)	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.0 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
				G 1.4 DOHC	ENGINE	Engine Control	√			√	√	Reading trouble code Clear fault code self-learning clear
			AT		Automatic Transaxle	√	√	√	√	√		
			ESP		Electronic Stability Program	√	√	√	√	√		
			AIRBAG		Airbag Control	√	√	√			Collision Information	
			AIRCON		Air Conditioner(Dual)	√	√	√	√	√		
					Air Conditioner(Single)	√	√	√	√	√		
			EPS		Electronic Power Steering	√	√	√	√			
			BCM		Body Control Module	√			√	√		
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					TPMS	Tire Pressure Monitoring	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				CODE	Transmitter Code Saving				√		
			2012 G 1.6 DOHC	ENGINE	Engine Control	√	√	√	√	√	self-learning clear
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information
				AIRCON	Air Conditioner(Dual)	√	√	√	√	√	
					Air Conditioner(Single)	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	ISG(-)/CPF(-)	√	√	√	√	√	
					ISG(-)/CPF(+)	√	√	√	√	√	
					ISG(+)/CPF(-)	√	√	√	√	√	
			ISG(+)/CPF(+)		√	√	√	√	√		
			AT	Automatic Transaxle	√	√	√	√	√		
			ESP	Electronic Stability Program	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√			Collision Information	
			AIRCON	Air Conditioner(Dual)	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 1.6 TCI-U2	AIRCON	Air Conditioner(Single)	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
			D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information
				AIRCON	Air Conditioner(Dual)	√	√	√	√	√	
				AIRCON	Air Conditioner(Single)	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
			IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
			G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information
				AIRCON	Air Conditioner(Dual)	√	√	√	√	√	
				AIRCON	Air Conditioner(Single)	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	self-learning clear
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
			AIRBAG	Airbag Control	√	√	√			Collision Information	
			AIRCON	Air Conditioner(Dual)	√	√	√	√	√		
			AIRCON	Air Conditioner(Single)	√	√	√	√	√		
			EPS	Electronic Power Steering	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 1.4 DOHC	BCM	Body Control Module	√			√	√			
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√			
				CODE	Transmitter Code Saving					√			
				G 1.6 DOHC	ENGINE	Engine Control	√	√	√	√	√	self-learning clear	
			AT		Automatic Transaxle	√	√	√	√	√			
			ESP		Electronic Stability Program	√	√	√	√	√			
			AIRBAG		Airbag Control	√	√	√			Collision Information		
			AIRCON		Air Conditioner(Dual)	√	√	√	√	√			
					Air Conditioner(Single)	√	√	√	√	√			
			EPS		Electronic Power Steering	√	√	√	√				
			BCM		Body Control Module	√			√	√			
			2011		IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
							TPMS	Tire Pressure Monitoring	√	√	√	√	√
				CODE			Transmitter Code Saving				√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu					Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 1.6 TCI-U2	ENGINE	ISG(-)/CPF(-)	√	√	√	√	√		
					ISG(-)/CPF(+)	√	√	√	√	√	√	
					ISG(+)/CPF(-)	√	√	√	√	√	√	
					ISG(+)/CPF(+)	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√				Collision Information
				AIRCON	Air Conditioner(Dual)	√	√	√	√	√	√	
					Air Conditioner(Single)	√	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√	√		
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	√	
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√				Collision Information
				AIRCON	Air Conditioner(Dual)	√	√	√	√	√	√	
			Air Conditioner(Single)		√	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 2.0 TCI-D	EPS	Electronic Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√
			AT		Automatic Transaxle	√	√	√	√	√	
			ESP		Electronic Stability Program	√	√	√	√	√	
			AIRBAG		Airbag Control	√	√	√			Collision Information
			AIRCON		Air Conditioner(Dual)	√	√	√	√	√	
					Air Conditioner(Single)	√	√	√	√	√	
			EPS		Electronic Power Steering	√	√	√	√		
			BCM		Body Control Module	√			√	√	
			IMMO		Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			TPMS		Tire Pressure Monitoring	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				CODE	Transmitter Code Saving				√			
			G 1.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	self-learning clear	
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				AIRCON	Air Conditioner(Dual)	√	√	√	√	√		
					Air Conditioner(Single)	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
				BCM	Body Control Module	√			√	√		
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control	√	√	√	√	√	self-learning clear	
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				AIRCON	Air Conditioner(Dual)	√	√	√	√	√		
					Air Conditioner(Single)	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
			BCM	Body Control Module	√			√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2010	G 1.6 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
			D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				AIRCON	Air Conditioner(Dual)	√	√	√	√	√		
					Air Conditioner(Single)	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
				BCM	Body Control Module	√			√	√		
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√			
					ISG(-)/CPF(-)	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 1.6 TCI-U2	ENGINE	ISG(-)/CPF(+)	√	√	√	√	√		
					ISG(+)/CPF(-)	√	√	√	√	√	√	
					ISG(+)/CPF(+)	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√				Collision Information
				AIRCON	Air Conditioner(Dual)	√	√	√	√	√	√	
					Air Conditioner(Single)	√	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√	√	√	
				BCM	Body Control Module	√			√	√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	√	
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control	√	√	√	√	√	√	Reset adaptive values
			AT	Automatic Transaxle	√	√	√	√	√	√		
			ESP	Electronic Stability Program	√	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√				Collision Information	
			AIRCON	Air Conditioner	√	√	√	√	√	√		
			EPS	Electronic Power Steering	√	√	√	√	√	√		
			BCM	Body Control Module	√			√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
Cee' d(ED)			G 2.0 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
						TPMS	Tire Pressure Monitoring	√	√	√	√	√	
						CODE	Transmitter Code Saving				√		
						AT	Automatic Transaxle	√	√	√	√	√	
			G 1.4 DOHC	IMMO	Immobilizer	ESP	Electronic Stability Program	√	√	√	√	√	
						AIRBAG	Airbag Control	√	√	√			Collision Information
						AIRCON	Air Conditioner	√	√	√	√	√	
						EPS	Electronic Power Steering	√	√	√	√		
						BCM	Body Control Module	√			√	√	
						TPMS	Tire Pressure Monitoring	√	√	√	√	√	
						CODE	Transmitter Code Saving				√		
						AT	Automatic Transaxle	√	√	√	√	√	
						ESP	Electronic Stability Program	√	√	√	√	√	
						AIRBAG	Airbag Control	√	√	√			Collision Information



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2009	G 1.6 DOHC	AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
			D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√		
					Engine Control(CPF+)	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√	√		
				BCM	Body Control Module	√			√	√		
			IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
			D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
					TPMS	Tire Pressure Monitoring	√	√	√	√	√	
					CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control(CPF-)	√	√	√	√	√		
				ENGINE	Engine Control(CPF+)	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
				BCM	Body Control Module	√			√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 1.6 TCI-U2	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
			G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
			ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values	
			AT	Automatic Transaxle	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 1.4 DOHC	ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values
				AT	Automatic Transaxle	√	√	√	√	√	
			ESP	Electronic Stability Program	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√			Collision Information	
			AIRCON	Air Conditioner	√	√	√	√	√		
			EPS	Electronic Power Steering	√	√	√	√			
			BCM	Body Control Module	√			√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2008	G 1.6 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
			D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√		
					ENGINE	Engine Control(CPF+)	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	
					ESP	Electronic Stability Program	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√			Collision Information
					AIRCON	Air Conditioner	√	√	√	√	√	
					EPS	Electronic Power Steering	√	√	√	√		
					BCM	Body Control Module	√			√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 2.0 TCI-D	AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values
			AT	Automatic Transaxle	√	√	√	√	√		
			ESP	Electronic Stability Program	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√			Collision Information	
			AIRCON	Air Conditioner	√	√	√	√	√		
			EPS	MDPS	√	√	√	√			
			BCM	Body Control Module	√			√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 2.0 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	TPMS	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values
			G 1.4 DOHC	AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	MDPS	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	TPMS	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values
			AT	Automatic Transaxle	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2007	G 1.6 DOHC	ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	MDPS	√	√	√	√			
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	TPMS	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control(CPF-)	√	√	√	√	√		
					Engine Control(CPF+)	√	√	√	√	√		
			AT		Automatic Transaxle	√	√	√	√	√		
			ESP		Electronic Stability Program	√	√	√	√	√		
			AIRBAG		Airbag Control	√	√	√				Collision Information
			AIRCON		Air Conditioner	√	√	√	√	√		
			EPS		MDPS	√	√	√	√			
		BCM	Body Control Module		√			√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 1.6 TCI-U	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	TPMS	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√
			AT		Automatic Transaxle	√	√	√	√	√	
			ESP		Electronic Stability Program	√	√	√	√	√	
			AIRBAG		Airbag Control	√	√	√			Collision Information
			AIRCON		Air Conditioner	√	√	√	√	√	
			EPS		MDPS	√	√	√	√		
			BCM		Body Control Module	√			√	√	
			IMMO		Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			TPMS		TPMS	√	√	√	√	√	
			CODE	Transmitter Code Saving				√			
			ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values	
			AT	Automatic Transaxle	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.0 DOHC	ESP	ESP	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	MDPS	√	√	√	√			
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√			
			G 1.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values	
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	ESP	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	MDPS	√	√	√	√			
				BCM	Body Control Module	√			√	√		
			IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
				CODE	Transmitter Code Saving				√				
			2006	G 1.6 DOHC	ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values	
					AT	Automatic Transaxle	√	√	√	√	√		
					ESP	ESP	√	√	√	√	√		
					AIRBAG	Airbag Control	√	√	√				Collision Information
					AIRCON	Air Conditioner	√	√	√	√	√		
					EPS	MDPS	√	√	√	√			
					BCM	Body Control Module	√			√	√		
						IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√				
			2006	D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√		
					ENGINE	Engine Control(CPF+)	√	√	√	√	√		
					AT	Automatic Transaxle	√	√	√	√	√		
					ESP	ESP	√	√	√	√	√		
					AIRBAG	Airbag Control	√	√	√				Collision Information
					AIRCON	Air Conditioner	√	√	√	√	√		
					EPS	MDPS	√	√	√	√			
					BCM	Body Control Module	√			√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
			D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	ESP	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	MDPS	√	√	√	√		
				BCM	Body Control Module	√			√	√	
					IMMO	Immobilizer					
				CODE	Transmitter Code Saving				√		
				ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	Adaptive value reset



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2009	G 2.0 DOHC	AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value		
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control			√	√	√			
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
			G 1.6 DOHC	ENGINE	Unleaded EOBD		√	√	√	√	√	Adaptive value reset	
					Unleaded GEN		√	√	√	√	√	√	Adaptive value reset
					Leaded All		√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle			√	√	√	√	√	Reset automatically drive shaft value
				ABS	Anti-Lock Brake			√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control				√	√	√		
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			ENGINE	Engine Control			√	√	√	√	√	Compression testing Write injector code	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 1.6 TCI-U	AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control		√	√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control		√	√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			ENGINE	Unleaded EOBD	√	√	√	√	√	√	Adaptive value reset
				Unleaded GEN	√	√	√	√	√	√	Adaptive value reset



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2008	G 1.6 DOHC		Leaded All	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√	√	Reset automatically drive shaft value
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control			√	√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			D 1.6 TCI-U	ENGINE	Engine Control	√	√	√	√	√	√	Compression testing Write injector code
				AT	Automatic Transaxle	√	√	√	√	√	√	Reset automatically drive shaft value
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control			√	√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
					ENGINE	Unleaded GEN	√	√	√	√	√	Adaptive value reset



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.0 DOHC		Leaded All	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control		√	√	√			
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
		2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
						Unleaded GEN	√	√	√	√	√	Adaptive value reset
						Leaded All	√	√	√	√	√	Adaptive value reset
					AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value
					ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
					AIRBAG	Airbag Control		√	√	√		
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 1.6 TCI-U	ENGINE	Engine Control	√	√	√	√	√	Compression testing Write injector code
				AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control		√	√	√		
				IMMO	Immobilizer						
			G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	
				ENGINE	Unleaded GEN	√	√	√	√	√	
					Leaded All	√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information
				IMMO	Immobilizer						
					Leaded All(+CVVT)	√	√	√	√	√	Reset adaptive values



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	CERATO(LD)	2006	G 2.0 DOHC	ENGINE	Leaded All(-CVVT)	√	√	√	√	√	Reset adaptive values
					Unleaded EOBD(+CVVT)	√	√	√	√	√	Reset adaptive values
					Unleaded EOBD(-CVVT)	√	√	√	√	√	Reset adaptive values
					Unleaded GEN(+CVVT)	√	√	√	√	√	Reset adaptive values
					Unleaded GEN(-CVVT)	√	√	√	√	√	Reset adaptive values
				AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				ENGINE	Engine Control	√	√	√	√	√	Compression testing Read injector data Write injector data
			AT	Automatic Transaxle		√	√	√	√		
			ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
			AIRBAG	Airbag Control	√	√	√			Collision Information	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 1.6 TCI-U	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 1.5 TCI-U	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
			G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√		
					Unleaded GEN	√	√	√	√	√		
					Leaded All	√	√	√	√	√		
				AT	Automatic Transaxle		√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				ENGINE	Leaded All(+CVVT)	√	√	√	√	√	√	Reset adaptive values
					Leaded All(-CVVT)	√	√	√	√	√	√	Reset adaptive values
					Unleaded EOBD(+CVVT)	√	√	√	√	√	√	Reset adaptive values
			Unleaded EOBD(-CVVT)		√	√	√	√	√	√	Reset adaptive values	
			Unleaded GEN(+CVVT)		√	√	√	√	√	√	Reset adaptive values	
			Unleaded GEN(-CVVT)		√	√	√	√	√	√	Reset adaptive values	
			AT	Automatic Transaxle		√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2005	G 2.0 DOHC	ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 1.5 TCI-U	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
			G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√		
					Unleaded GEN	√	√	√	√	√		
					Leaded All	√	√	√	√	√		
				AT	Automatic Transaxle		√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				ENGINE	Leaded All(+CVVT)	√	√	√	√	√	Reset adaptive values	
					Leaded All(-CVVT)	√	√	√	√	√	Reset adaptive values	
					Unleaded EOBD(+CVVT)	√	√	√	√	√	Reset adaptive values	
			Unleaded EOBD(-CVVT)		√	√	√	√	√	Reset adaptive values		
			Unleaded GEN(+CVVT)		√	√	√	√	√	Reset adaptive values		
			Unleaded GEN(-CVVT)		√	√	√	√	√	Reset adaptive values		
		2004	AT	Automatic Transaxle		√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 2.0 DOHC	ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
			D 2.0 TCI-D	AIRBAG	Airbag Control	√	√	√			Collision Information
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				ENGINE	Unleaded EOBD	√	√	√	√	√	
					Unleaded GEN	√	√	√	√	√	
					Leaded All	√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
			ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
			AIRBAG	Airbag Control	√	√	√			Collision Information	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2003	G 1.6 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				ENGINE	Unleaded EOBD	√	√	√	√	√	self-learning clear
				ENGINE	Unleaded GEN	√	√	√	√	√	self-learning clear
				ENGINE	Leaded All	√	√	√	√	√	self-learning clear
				AT	Automatic Transaxle(6-Speed)	√	√	√	√	√	
				AT	Automatic Transaxle(4-Speed)	√	√	√	√	√	Clear automatic transmission fitness
				ESP	Electronic Stability Program	√	√	√	√	√	Deflation
				AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
				AIRBAG	Airbag(Event #2)	√	√	√	√		Real-time information
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√			EPS type recognition ASP calibration
				EPS	Power Steering(KOUP)	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				BCM	Body Control Module(KOUP)	√			√	√	
				BCM	Body Control Module(5DR)	√			√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 1.6 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
				PIC	All Systems	√	√	√				Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information	
					Smart Key Unit	√	√	√					Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Power Distribution Module	√	√	√	√	√	√	√	ESCL open stae inspection



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2012			Smart Key Code Saving						Match key
				ENGINE	Unleaded EOBD	√	√	√	√	√	
					Unleaded GEN	√	√	√	√	√	
					Leaded All	√	√	√	√	√	
				AT	Automatic Transaxle(6-Speed)	√	√	√	√	√	
					Automatic Transaxle(4-Speed)	√	√	√	√	√	Clear automatic transmission fitness
				ESP	Electronic Stability Program	√	√	√	√	√	Deflation
				AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
					Airbag(Event #2)	√	√	√	√		Real-time information
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√			EPS type recognition ASP calibration
					Power Steering(KOUP)	√	√	√	√		
				BCM	Body Control Module	√			√	√	
					Body Control Module(KOUP)	√			√	√	
					Body Control Module(5DR)	√			√	√	
			G 2.0 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				PIC	All Systems	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Smart Key Unit	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Power Distribution Module	√	√	√	√	√	ESCL open stae inspection
					Smart Key Code Saving						Match key
					ENGINE	Unleaded EOBD	√	√	√	√	√
				Unleaded GEN		√	√	√	√	√	self-learning clear
				Leaded All		√	√	√	√	√	self-learning clear
				AT	Automatic Transaxle(6-Speed)	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu					Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 1.6 DOHC		Automatic Transaxle(4-Speed)	√	√	√	√	√	Clear automatic transmission fitness
				ESP	Electronic Stability Program	√	√	√	√	√	Deflation
				AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
					Airbag(Event #2)	√	√	√	√		Real-time information
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√			EPS type recognition ASP calibration
					Power Steering(KOUP)	√	√	√	√		
				BCM	Body Control Module	√			√	√	
					Body Control Module(KOUP)	√			√	√	
					Body Control Module(5DR)	√			√	√	
			IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2011		PIC	All Systems	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information	
					Smart Key Unit	√	√	√				Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Power Distribution Module	√	√	√	√	√	√	ESCL open stae inspection
						Smart Key Code Saving						Match key
					ENGINE	Unleaded EOBD	√	√	√	√	√	
						Unleaded GEN	√	√	√	√	√	
						Leaded All	√	√	√	√	√	
					AT	Automatic Transaxle(6-Speed)	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu					Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 2.0 DOHC		Automatic Transaxle(4-Speed)	√	√	√	√	√	Clear automatic transmission fitness
				ESP	Electronic Stability Program	√	√	√	√	√	Deflation
				AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
					Airbag(Event #2)	√	√	√	√		Real-time information
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√			EPS type recognition ASP calibration
					Power Steering(KOUP)	√	√	√	√		
				BCM	Body Control Module	√			√	√	
					Body Control Module(KOUP)	√			√	√	
					Body Control Module(5DR)	√			√	√	
			IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	CERATO/ ORTE(TD)			PIC	All Systems	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Smart Key Unit	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Power Distribution Module	√	√	√	√	√	ESCL open stae inspection
					Smart Key Code Saving						Match key
				ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	Clear automatic transmission fitness



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 1.6 DOHC	ESP	Electronic Stability Program	√	√	√	√	√	Deflation
				AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
					Airbag(Event #2)	√	√	√	√		Real-time information
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√			EPS type recognition ASP calibration
					Power Steering(KOUP)	√	√	√	√		
				BCM	Body Control Module	√			√	√	User select
					Body Control Module(KOUP)	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					All Systems		√	√	√		Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2010		PIC	Smart Key Unit	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information	
						Power Distribution Module	√	√	√	√	√	ESCL open stae inspection
						Smart Key Code Saving						Match key
					ENGINE	Unleaded EOBD	√	√	√	√	√	
						Unleaded GEN	√	√	√	√	√	
						Leaded All	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	Clear automatic transmission fitness
					ESP	Electronic Stability Program	√	√	√	√	√	Deflation
					AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
						Airbag(Event #2)	√	√	√	√		Real-time information
					AIRCON	Air Conditioner	√	√	√	√	√	
					EPS	Power Steering	√	√	√			EPS type recognition ASP calibration
						Power Steering(KOUP)	√	√	√	√		
					BCM	Body Control Module	√			√	√	User select
						Body Control Module(KOUP)	√			√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 2.0 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
				PIC	All Systems	√	√	√				Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information	
					Smart Key Unit	√	√	√					Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Power Distribution Module	√	√	√	√	√	√	√	ESCL open stae inspection



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu					Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
					Smart Key Code Saving						Match key
				ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	Adaptive value reset
					AT	Automatic Transaxle	√	√	√	√	√
				ESP	Electronic Stability Program	√	√	√	√	√	Deflation
				AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
					Airbag(Event #2)	√	√	√	√		Real-time information
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√			EPS type recognition ASP calibration
				BCM	Body Control Module	√			√	√	User select
				IMMO	IMMO(Bosch)						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2009	G 1.6 DOHC	PIC	All Systems	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Smart Key Unit	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Power Distribution Module	√	√	√	√	√	ESCL open stae inspection
					Smart Key Code Saving						Match key
				ENGINE	Unleaded EOBD	√	√	√	√	√	
					Unleaded GEN	√	√	√	√	√	
					Leaded All	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	Clear automatic transmission fitness



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.0 DOHC	ESP	Electronic Stability Program	√	√	√	√	√	Deflation	
				AIRBAG	Airbag(Event #1)	√	√	√	√			Real-time information
					Airbag(Event #2)	√	√	√	√			Real-time information
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Power Steering	√	√	√				EPS type recognition ASP calibration
				BCM	Body Control Module	√			√	√		User select
				IMMO	IMMO(Bosch)							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					All Systems	√	√	√				Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				PIC	Smart Key Unit	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information	
					Power Distribution Module	√	√	√	√	√	ESCL open stae inspection	
					Smart Key Code Saving						Match key	
		2000	G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√		
				AIRBAG	Airbag Control		√	√				
			G 1.8 DOHC	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√		
				AIRBAG	Airbag Control		√	√				
		1999	G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√		
			G 1.8 DOHC	AIRBAG	Airbag Control		√	√				
				ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
	CLARUS(FE)		G 1.8 DOHC	ABS	Anti-Lock Brake		√	√	√	√			
				AIRBAG	Airbag Control		√	√					
			G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√			
				AT	Automatic Transaxle		√	√	√				
				ABS	Anti-Lock Brake		√	√	√	√			
				AIRBAG	Airbag Control		√	√					
				G 1.8 DOHC	ENGINE	Engine Control		√	√	√	√		
					AT	Automatic Transaxle		√	√	√			
			ABS		Anti-Lock Brake		√	√	√	√			
			AIRBAG	Airbag Control		√	√						
				G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√		
					AT	Automatic Transaxle		√	√	√			
			AIRBAG		Airbag Control		√	√					
			G 1.8 DOHC	ENGINE	Engine Control		√	√	√	√			
				AT	Automatic Transaxle		√	√	√				
				AIRBAG	Airbag Control		√	√					
				G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√		
					AT	Automatic Transaxle		√	√	√			
					AIRBAG	Airbag Control		√	√				
			G 1.8 DOHC	ENGINE	Engine Control		√	√	√	√			
				AT	Automatic Transaxle		√	√	√				
				AIRBAG	Airbag Control		√	√					
				G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√		
					AT	Automatic Transaxle		√	√	√			
AIRBAG	Airbag Control				√	√							
G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√						
	AT	Automatic Transaxle		√	√	√							
	AIRBAG	Airbag Control		√	√								



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	ENTERPRISE(DB)	2002	G 3.0 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
				AIRBAG	Airbag Control		√	√			
		2001	G 3.0 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
				AIRBAG	Airbag Control		√	√			
		2000	G 2.5 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
				AIRBAG	Airbag Control		√	√			
			G 3.0 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
				AIRBAG	Airbag Control		√	√			
		G 3.6 DOHC	ENGINE	Engine Control		√	√	√			
			AT	Automatic Transaxle		√	√	√			
			ABS	Anti-Lock Brake		√	√	√			
			AIRBAG	Airbag Control		√	√				
G 2.5 DOHC	ENGINE	Engine Control		√	√	√					
	AT	Automatic Transaxle		√	√	√					
	ABS	Anti-Lock Brake		√	√	√					
	AIRBAG	Airbag Control		√	√						
			ENGINE	Engine Control		√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		1999	G 3.0 DOHC	AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
				AIRBAG	Airbag Control		√	√			
			G 3.6 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
		1998	G 3.6 DOHC	AIRBAG	Airbag Control		√	√			
				ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
		1997	G 3.0 DOHC	ABS	Anti-Lock Brake		√	√	√		
				AIRBAG	Airbag Control		√	√			
				ENGINE	Engine Control		√	√	√		
			G 3.6 DOHC	AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√		
				AIRBAG	Airbag Control		√	√			
		2002	G 2.0 DOHC	ENGINE	Unleaded EURO-3		√	√	√	√	
				ABS	Anti-Lock Brake		√	√	√	√	ABS deflation mode
				AIRBAG	Airbag Control		√	√	√		
		2001	G 2.0 DOHC	ENGINE	Unleaded EURO-3		√	√	√	√	
				ABS	Anti-Lock Brake		√	√	√	√	ABS deflation mode
				AIRBAG	Airbag Control		√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
	JOICE(NO)	2000	G 2.0 DOHC	ENGINE	Unleaded EURO-3		√	√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	ABS deflation mode	
				AIRBAG	Airbag Control		√	√	√			
		1999	G 2.0 DOHC	ENGINE	Unleaded EURO-3		√	√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	ABS deflation mode	
				AIRBAG	Airbag Control		√	√	√			
	K2(QBR)	2012		G 1.4 DOHC	ENGINE	Engine Control	√			√	√	Reading trouble code Clear fault code self-learning clear
					AT	Automatic Transaxle	√	√	√		√	
					ABSESP	ABS/ESP	√	√	√	√	√	
					AIRBAG	Airbag(Event #1)	√	√	√	√		
						Airbag(Event #2)	√	√	√	√		
					BCM	Body Control Module	√	√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					CODE	Transmitter Code Saving					√	
					ENGINE	Engine Control	√				√	√
AT	Automatic Transaxle	√	√	√			√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 1.6 DOHC	ABSESP	ABS/ESP	√	√	√	√	√			
				AIRBAG	Airbag(Event #1)	√	√	√	√				
					Airbag(Event #2)	√	√	√	√				
				BCM	Body Control Module	√	√	√	√	√			
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				CODE	Transmitter Code Saving					√			
			2012	D 2.7 J2	ENGINE	Engine Control		√	√	√	√		
					AT	Automatic Transaxle	√	√	√	√	√		
					ABS	Anti-Lock Brake	√	√	√	√			
					IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				D 2.9 CRDI	ENGINE	Engine Control	√	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√		
					ABS	Anti-Lock Brake	√	√	√	√			
					ENGINE	Engine Control		√	√	√	√	√	
D 3.0 JT	AT	Automatic Transaxle	√	√	√	√	√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 2.5 TCI	ABS	Anti-Lock Brake	√	√	√	√		
				ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
		2011	D 2.7 J2	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			D 2.9 CRDI	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√		
			D 3.0 JT	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 2.5 TCI	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			D 2.5 TCI	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
		2010		ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2010	D 2.7 J2	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			D 2.9 CRDI	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√		
			D 3.0 JT	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√		
			D 2.5 TCI	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
	K2500/K2700/K3000/K3000S(PU)	2009	D 2.7 J2	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
			D 2.9 CRDI	ENGINE	Engine Control	√	√	√	√	√			
				AT	Automatic Transaxle	√	√	√	√	√			
				ABS	Anti-Lock Brake	√	√	√	√				
			D 3.0 JT	ENGINE	Engine Control		√	√	√	√			
				AT	Automatic Transaxle	√	√	√	√	√			
				ABS	Anti-Lock Brake	√	√	√	√				
			D 2.5 TCI	ENGINE	Engine Control		√	√	√	√			
				AT	Automatic Transaxle	√	√	√	√	√			
				ABS	Anti-Lock Brake	√	√	√	√				
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
						ENGINE	Engine Control		√	√	√	√	
						AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function								
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions			
		2008	D 2.7 J2	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode			
			D 2.9 CRDI	ENGINE	Engine Control	√	√	√	√	√				
				AT	Automatic Transaxle	√	√	√	√	√				
				ABS	Anti-Lock Brake	√	√	√	√	√				
			D 3.0 JT	ENGINE	Engine Control		√	√	√	√				
				AT	Automatic Transaxle	√	√	√	√	√				
				ABS	Anti-Lock Brake	√	√	√	√	√				
			D 3.0 JT	ENGINE	Engine Control		√	√	√	√				
				AT	Automatic Transaxle	√	√	√	√	√				
				ABS	Anti-Lock Brake	√	√	√	√	√				
			2007	D 2.5 TCI	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
				ENGINE	Engine Control		√	√	√	√				
				AT	Automatic Transaxle	√	√	√	√	√				
				ABS	Anti-Lock Brake	√	√	√	√	√				
			AT	Automatic Transaxle	√	√	√	√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.7 J2	ABS	Anti-Lock Brake	√	√	√	√			
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
		2006	D 3.0 JT	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√			
			D 2.5 TCI	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√			
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				AT	Automatic Transaxle	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.7 J2	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
		2005	D 3.0 JT	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√			
			D 2.5 TCI	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√			
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					AT	Automatic Transaxle	√	√	√	√	√	
					ABS	Anti-Lock Brake	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.7 J2	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
		2004	D 3.0 JT	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√			
			D 2.5 TCI	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√			
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					AT	Automatic Transaxle	√	√	√	√	√	
					ABS	Anti-Lock Brake	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.7 J2	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
			G 4.6 DOHC	ENGINE	Engine Control	√	√	√	√		Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√			√	√		Read fault code Clear the fault code
				EPS	Electronic Power Steering	√	√	√	√			
				ECS	NON-ECS	√	√	√	√	√		
				4WD	4WD(EST)	√	√	√	√			
					4WD(TOD)	√	√	√	√			
				BCM	All Systems	√	√	√	√	√	√	
					Instrument Panel Module	√	√	√	√	√	√	
					Front Area Module	√	√	√	√	√	√	
					Rear Area Module	√	√	√	√	√	√	
			Driver Door Module		√	√	√	√	√	√		
				Assist Door Module	√	√	√	√	√	√		
				Integrated Memory System		√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
					User Option				√			
					Steering Coulmn Module		√	√	√	√		
				PIC	All Systems	√		√	√	√	Reading trouble code	
					Smart Key Unit	√		√	√	√	Reading trouble code	
					Power Distribution Module	√	√	√	√	√		
					Smart Key Code Saving				√			
		2012	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set	
						Unleaded GEN	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
						Leaded All	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					AT	Automatic Transaxle	√	√	√	√	√	
					ESP	Electronic Stability Program	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
					AIRCON	Air Conditioner	√			√	√	Read fault code Clear the fault code
					EPS	Electronic Power Steering	√	√	√	√		
					ECS	ECS(Mando)	√	√	√	√	√	
					4WD	4WD(EST)	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				4WD	4WD(TOD)	√	√	√	√		
				BCM	All Systems	√	√	√	√	√	
					Instrument Panel Module(Unleaded)	√	√	√	√	√	
					Front Area Module	√	√	√	√	√	
					Rear Area Module	√	√	√	√	√	
					Driver Door Module	√	√	√	√	√	
					Assist Door Module	√	√	√	√	√	
					Integrated Memory System		√	√	√	√	
					User Option				√		
					Steering Coulmn Module		√	√	√	√	
					PIC	All Systems	√		√	√	√
				Smart Key Unit		√		√	√	√	Reading trouble code
				Power Distribution Module		√	√	√	√	√	
				Smart Key Code Saving					√		
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√			√	√	Read fault code Clear the fault code
				EPS	Electronic Power Steering	√	√	√	√		
				ECS	NON-ECS	√	√	√	√	√	
				4WD	4WD(EST)	√	√	√	√		
					4WD(TOD)	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			D 3.0 TCI-S2	BCM	All Systems	√	√	√	√	√			
							Instrument Panel Module	√	√	√	√	√	
							Front Area Module	√	√	√	√	√	
							Rear Area Module	√	√	√	√	√	
							Driver Door Module	√	√	√	√	√	
							Assist Door Module	√	√	√	√	√	
							Integrated Memory System		√	√	√	√	
							User Option				√		
							Steering Coulmn Module		√	√	√	√	
					PIC	All Systems	√		√	√	√	Reading trouble code	
							Smart Key Unit	√		√	√	√	Reading trouble code
							Power Distribution Module	√	√	√	√	√	
							Smart Key Code Saving				√		
					ENGINE	Engine Control	√	√	√	√		Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√			
				ESP	Electronic Stability Program	√	√	√	√	√			
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag		
				AIRCON	Air Conditioner	√			√	√	Read fault code Clear the fault code		
				EPS	Electronic Power Steering	√	√	√	√				
				ECS	NON-ECS	√	√	√	√	√			
				4WD	4WD(EST)	√	√	√	√				
						4WD(TOD)	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 4.6 DOHC	BCM	All Systems	√	√	√	√	√			
							Instrument Panel Module	√	√	√	√	√	
							Front Area Module	√	√	√	√	√	
							Rear Area Module	√	√	√	√	√	
							Driver Door Module	√	√	√	√	√	
							Assist Door Module	√	√	√	√	√	
							Integrated Memory System		√	√	√	√	
							User Option				√		
							Steering Coulmn Module		√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
					PIC	All Systems	√		√	√	√	Reading trouble code	
							Smart Key Unit	√		√	√	√	Reading trouble code
							Power Distribution Module	√	√	√	√	√	
							Smart Key Code Saving				√		
					ENGINE	Unleaded EOBD	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set	
							Unleaded GEN	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
					Leaded All	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√			√	√	Read fault code Clear the fault code
				EPS	Electronic Power Steering	√	√	√	√		
				ECS	ECS(Mando)	√	√	√	√	√	
				4WD	4WD(EST)	√	√	√	√		
					4WD(TOD)	√	√	√	√		
				BCM	All Systems	√	√	√	√	√	
					Instrument Panel Module(Unleaded)	√	√	√	√	√	
					Front Area Module	√	√	√	√	√	
					Rear Area Module	√	√	√	√	√	
					Driver Door Module	√	√	√	√	√	
					Assist Door Module	√	√	√	√	√	
					Integrated Memory System		√	√	√	√	
					User Option				√		
					Steering Coulmn Module		√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√		√	√	√	Reading trouble code
					Smart Key Unit	√		√	√	√	Reading trouble code
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				ECS	ECS(Mando)	√	√	√	√	√	
				4WD	4WD(EST)	√	√	√	√		
					4WD(TOD)	√	√	√	√		
					All Systems	√	√	√	√	√	
					Instrument Panel Module	√	√	√	√	√	
					Front Area Module	√	√	√	√	√	
					Rear Area Module	√	√	√	√	√	

D 3 0 T C L S



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function								
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions			
	MOHAVE/BORREGO(HM)		D 3.0 TFS	BCM	Driver Door Module	√	√	√	√	√				
					Assist Door Module	√	√	√	√	√				
					Integrated Memory System		√	√	√	√				
					User Option				√					
					Steering Coulmn Module		√	√	√	√				
				IMMO	Immobilizer									Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√				
					Smart Key Unit	√	√	√	√	√				
					Power Distribution Module	√	√	√	√	√				
					Smart Key Code Saving					√				
				ENGINE	Unleaded EOBD	√	√	√	√	√			PCM automatically detect reset PCM lock(MEC)is set	
					Unleaded GEN	√	√	√	√	√			PCM automatically detect reset PCM lock(MEC)is set	
					Leaded All	√	√	√	√	√			PCM automatically detect reset PCM lock(MEC)is set	
				AT	Automatic Transaxle	√	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 3.8 DOHC	ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
				ECS	ECS(Mando)	√	√	√	√	√		
				4WD	4WD(EST)	√	√	√	√			
					4WD(TOD)	√	√	√	√			
				BCM	All Systems	√	√	√	√	√		
					Instrument Panel Module(Unleaded)	√	√	√	√	√		
					Front Area Module	√	√	√	√	√		
					Rear Area Module	√	√	√	√	√		
					Driver Door Module	√	√	√	√	√		
					Assist Door Module	√	√	√	√	√		
					Integrated Memory System		√	√	√	√		
					User Option				√			
					Steering Coulmn Module		√	√	√	√		
			IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
					Smart Key Code Saving				√			
		2010	G 4.6 DOHC	ENGINE	Engine Control	√	√	√	√		Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
				ECS	NON-ECS	√	√	√	√	√		
				4WD	4WD(EST)	√	√	√	√			
					4WD(TOD)	√	√	√	√			
				BCM	All Systems	√	√	√	√	√	√	
					Instrument Panel Module	√	√	√	√	√	√	
					Front Area Module	√	√	√	√	√	√	
					Rear Area Module	√	√	√	√	√	√	
					Driver Door Module	√	√	√	√	√	√	
		Assist Door Module	√		√	√	√	√	√			
		Integrated Memory System			√	√	√	√	√			
		User Option					√					
		Steering Coulmn Module		√	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				ECS	ECS(Mando)	√	√	√	√	√	
				4WD	4WD(EST)	√	√	√	√		
					4WD(TOD)	√	√	√	√		
					All Systems	√	√	√	√	√	
					Instrument Panel Module	√	√	√	√	√	
					Front Area Module	√	√	√	√	√	
					Rear Area Module	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			D 3.0 TCI-S	BCM	Driver Door Module	√	√	√	√	√			
					Assist Door Module	√	√	√	√	√			
					Integrated Memory System		√	√	√	√			
					User Option				√				
					Steering Coulmn Module		√	√	√	√			
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√			
					Smart Key Unit	√	√	√	√	√			
					Power Distribution Module	√	√	√	√	√			
					Smart Key Code Saving				√				
				ENGINE	Unleaded EOBD	√	√	√	√	√		PCM automatically detect reset PCM lock(MEC)is set	
					Unleaded GEN	√	√	√	√	√		PCM automatically detect reset PCM lock(MEC)is set	
					Leaded All	√	√	√	√	√		PCM automatically detect reset PCM lock(MEC)is set	
				AT	Automatic Transaxle	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 3.8 DOHC	ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
				ECS	ECS(Mando)	√	√	√	√	√		
				4WD	4WD(EST)	√	√	√	√			
					4WD(TOD)	√	√	√	√			
				BCM	All Systems	√	√	√	√	√		
					Instrument Panel Module(Unleaded)	√	√	√	√	√		
					Front Area Module	√	√	√	√	√		
					Rear Area Module	√	√	√	√	√		
					Driver Door Module	√	√	√	√	√		
					Assist Door Module	√	√	√	√	√		
					Integrated Memory System		√	√	√	√		
					User Option				√			
					Steering Coulmn Module		√	√	√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				PIC	All Systems	√		√	√	√	Reading trouble code	
					Smart Key Unit	√		√	√	√	Reading trouble code	
					Power Distribution Module	√	√	√	√	√		
					Smart Key Code Saving				√			
		2009	G 4.6 DOHC	ENGINE	Engine Control	√	√	√	√		Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√	√		
				ECS	NON-ECS	√	√	√	√	√	√	
				4WD	4WD(EST)	√	√	√	√	√		
					4WD(TOD)	√	√	√	√	√		
				BCM	All Systems	√	√	√	√	√	√	
					Instrument Panel Module	√	√	√	√	√	√	
					Front Area Module	√	√	√	√	√	√	
					Rear Area Module	√	√	√	√	√	√	
					Driver Door Module	√	√	√	√	√	√	
		Assist Door Module	√		√	√	√	√	√			
		Integrated Memory System			√	√	√	√	√			
		User Option					√					
		Steering Coulmn Module		√	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√		√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				ECS	ECS(Mando)	√	√	√	√	√	
				4WD	4WD(EST)	√	√	√	√		
					4WD(TOD)	√	√	√	√		
					All Systems	√	√	√	√	√	
					Instrument Panel Module	√	√	√	√	√	
					Front Area Module	√	√	√	√	√	
					Rear Area Module	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			D 3.0 TCI-S	BCM	Driver Door Module	√	√	√	√	√			
					Assist Door Module	√	√	√	√	√			
					Integrated Memory System		√	√	√	√			
					User Option				√				
					Steering Coulmn Module		√	√	√	√			
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√			
					Smart Key Unit	√	√	√	√	√			
					Power Distribution Module	√	√	√	√	√			
					Smart Key Code Saving					√			
				ENGINE	Unleaded EOBD	√	√	√	√	√			PCM automatically detect reset PCM lock(MEC)is set
					Unleaded GEN	√	√	√	√	√			PCM automatically detect reset PCM lock(MEC)is set
					Leaded All	√	√	√	√	√			PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 3.8 DOHC	ESP	Electronic Stability Program		√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				ECS	Electronic Control Suspension		√	√			
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Power Window Main		√	√	√	√	
					Power Window Assist		√	√	√	√	
					Power Seat Module		√	√	√	√	
					Tilt & Telescope		√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Smart Key Code Saving		√	√	√	√	
				AHLS	Auto Headlamp Leveling	√	√	√	√		
			CODE	Transmitter Code Saving				√			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2010	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set	
					Unleaded GEN	√	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					Leaded All	√	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program		√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
				ECS	Electronic Control Suspension		√	√				
				BCM	All Systems	√	√	√	√	√		
					Body Control Module	√	√	√	√	√		
					Power Window Main		√	√	√	√		
					Power Window Assist		√	√	√	√		
					Power Seat Module		√	√	√	√		
					Tilt & Telescope		√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Smart Key Code Saving		√	√	√	√	
				AHLS	Auto Headlamp Leveling	√	√	√	√		
				CODE	Transmitter Code Saving				√		
				ENGINE	Unleaded EOBD	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					Unleaded GEN	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					Leaded All	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program		√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 3.8 DOHC	ECS	Electronic Control Suspension		√	√				
				BCM	All Systems		√	√	√	√	√	
					Body Control Module		√	√	√	√	√	
					Power Window Main			√	√	√	√	
					Power Window Assist			√	√	√	√	
					Power Seat Module			√	√	√	√	
					Tilt & Telescope			√	√	√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems		√	√	√	√	√	
					Smart Key Unit		√	√	√	√	√	
					Smart Key Code Saving			√	√	√	√	
				AHLS	Auto Headlamp Leveling		√	√	√	√		
				CODE	Transmitter Code Saving					√		
		2009			ENGINE	Unleaded EOBD	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
			Unleaded GEN				√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 2.7 DOHC		Leaded All	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program		√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				ECS	Electronic Control Suspension		√	√			
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Power Window Main		√	√	√	√	
					Power Window Assist		√	√	√	√	
					Power Seat Module		√	√	√	√	
					Tilt & Telescope		√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Smart Key Code Saving		√	√	√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				AHLS	Auto Headlamp Leveling	√	√	√	√		
				CODE	Transmitter Code Saving				√		
			G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					Unleaded GEN	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					Leaded All	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program		√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				ECS	Electronic Control Suspension		√	√			
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Power Window Main		√	√	√	√	
					Power Window Assist		√	√	√	√	
					Power Seat Module		√	√	√	√	
				Tilt & Telescope		√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2008		IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems	√			√	√		
					Interface Unit	√			√	√		
					Smart Key Code Saving				√			
				AHLS	Auto Headlamp Leveling	√	√	√	√			
				CODE	Transmitter Code Saving				√			
				ENGINE	Unleaded EOBD	√	√	√	√	√		PCM automatically detect reset PCM lock(MEC)is set
					Unleaded GEN	√	√	√	√	√		PCM automatically detect reset PCM lock(MEC)is set
					Leaded All	√	√	√	√	√		PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program		√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
			EPS	Electronic Power Steering	√	√	√	√				



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
	OPIRUS(GH)		G 2.7 DOHC	ECS	Electronic Control Suspension		√	√					
				BCM	All Systems	√	√	√	√	√			
					Body Control Module	√	√	√	√	√			
					Power Window Main		√	√	√	√			
					Power Window Assist		√	√	√	√			
					Power Seat Module		√	√	√	√			
					Tilt & Telescope		√	√	√	√			
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√			√	√			
					Interface Unit	√			√	√			
					Smart Key Code Saving				√				
				AHLS	Auto Headlamp Leveling	√	√	√	√				
				CODE	Transmitter Code Saving				√				
				ENGINE	Unleaded EOBD	√	√	√	√	√			PCM automatically detect reset PCM lock(MEC)is set
					Unleaded GEN	√	√	√	√	√			PCM automatically detect reset PCM lock(MEC)is set



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 3.8 DOHC		Leaded	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program		√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				ECS	Electronic Control Suspension		√	√			
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Power Window Main		√	√	√	√	
					Power Window Assist		√	√	√	√	
					Power Seat Module		√	√	√	√	
					Tilt & Telescope		√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√			√	√	
					Interface Unit	√			√	√	
					Smart Key Code Saving				√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2007		AHLS	Auto Headlamp Leveling	√	√	√	√		
				CODE	Transmitter Code Saving				√		
			G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					Unleaded GEN	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					Leaded All	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program		√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				ECS	Electronic Control Suspension		√	√			
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Power Window Main		√	√	√	√	
					Power Window Assist		√	√	√	√	
					Power Seat Module		√	√	√	√	
				Tilt & Telescope		√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√			√	√	
					Interface Unit	√			√	√	
					Smart Key Code Saving				√		
				AHLS	Auto Headlamp Leveling	√	√	√	√		
				CODE	Transmitter Code Saving				√		
			G 3.0 DOHC	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
				ESP	Electronic Stability Program		√	√	√	√	
				AIRBAG	Airbag Control		√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering		√	√			
				ECS	Electronic Control Suspension		√	√			
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Power Window Main		√	√	√	√	
			Power Window Assist			√	√	√	√		
			Power Seat Module			√	√	√	√		
				Tilt & Telescope		√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2006	G 3.5 DOHC	IMMO	Immobilizer				√		Password learning/modify Limp mode	
				PIC	All Systems		√	√	√	√		
					Smart Key Unit		√	√	√	√		
					Smart Key Code Saving					√		
				AHLS	Auto Headlamp Leveling	√	√	√	√			
				CODE	Transmitter Code Saving					√		
				ENGINE	Engine Control			√	√	√	√	
				AT	Automatic Transaxle			√	√	√	√	
				ESP	Electronic Stability Program			√	√	√	√	
				AIRBAG	Airbag Control			√	√	√		
				AIRCON	Air Conditioner	√		√	√	√	√	
				EPS	Electronic Power Steering			√	√			
				ECS	Electronic Control Suspension			√	√			
				BCM	All Systems	√	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	√	
					Power Window Main		√	√	√	√	√	
					Power Window Assist		√	√	√	√	√	
					Power Seat Module		√	√	√	√	√	
					Tilt & Telescope		√	√	√	√	√	
				IMMO	Immobilizer					√		Password learning/modify Limp mode
		PIC	All Systems		√	√	√	√	√			
			Smart Key Unit		√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
					Smart Key Code Saving				√		
				AHLS	Auto Headlamp Leveling	√	√	√	√		
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
				ESP	Electronic Stability Program		√	√	√	√	
				AIRBAG	Airbag Control		√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering		√	√			
				ECS	Electronic Control Suspension		√	√			
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Power Window Main		√	√	√	√	
					Power Window Assist		√	√	√	√	
					Power Seat Module		√	√	√	√	
					Tilt & Telescope		√	√	√	√	
				IMMO	Immobilizer				√		Password learning/modify Limp mode
				PIC	All Systems		√	√	√	√	
					Smart Key Unit		√	√	√	√	
					Smart Key Code Saving				√		
				AHLS	Auto Headlamp Leveling	√	√	√	√		
				CODE	Transmitter Code Saving				√		
		2005		ENGINE	Engine Control		√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 3.5 DOHC	AT	Automatic Transaxle		√	√	√	√			
				ESP	Electronic Stability Program			√	√	√	√		
				AIRBAG	Airbag Control			√	√	√			
				AIRCON	Air Conditioner	√		√	√	√	√		
				EPS	Electronic Power Steering			√	√				
				ECS	Electronic Control Suspension			√	√				
				BCM	All Systems		√	√	√	√	√		
					Body Control Module		√	√	√	√	√	√	
					Power Window Main			√	√	√	√	√	
					Power Window Assist			√	√	√	√	√	
					Power Seat Module			√	√	√	√	√	
				Tilt & Telescope				√	√	√	√		
				IMMO	Immobilizer					√		Password learning/modify Limp mode	
				PIC	All Systems			√	√	√	√		
					Smart Key Unit			√	√	√	√	√	
					Smart Key Code Saving						√		
				AHLS	Auto Headlamp Leveling	√		√	√	√			
				CODE	Transmitter Code Saving					√			
			ENGINE	Engine Control			√	√	√	√			
			AT	Automatic Transaxle			√	√	√	√			
			ESP	Electronic Stability Program			√	√	√	√			
			AIRBAG	Airbag Control			√	√	√				
			AIRCON	Air Conditioner	√		√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 3.0 DOHC	EPS	Electronic Power Steering		√	√					
				ECS	Electronic Control Suspension			√	√				
				BCM	All Systems		√	√	√	√	√		
					Body Control Module		√	√	√	√	√		
					Power Window Main			√	√	√	√		
					Power Window Assist			√	√	√	√		
					Power Seat Module			√	√	√	√		
					Tilt & Telescope			√	√	√	√		
				IMMO	Immobilizer					√		Password learning/modify Limp mode	
				PIC	All Systems			√	√	√	√		
					Smart Key Unit			√	√	√	√		
					Smart Key Code Saving					√			
				AHLS	Auto Headlamp Leveling		√	√	√	√			
				CODE	Transmitter Code Saving					√			
		2004			ENGINE	Engine Control		√	√	√	√		
					AT	Automatic Transaxle			√	√	√	√	
					ESP	Electronic Stability Program			√	√	√	√	
					AIRBAG	Airbag Control			√	√	√		
			AIRCON		Air Conditioner		√	√	√	√	√		
			EPS		Electronic Power Steering			√	√				
			ECS		Electronic Control Suspension			√	√				
					All Systems		√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 3.5 DOHC	BCM	Body Control Module	√	√	√	√	√			
						Power Window Main		√	√	√	√		
						Power Window Assist		√	√	√	√		
						Power Seat Module		√	√	√	√		
						Tilt & Telescope		√	√	√	√		
					IMMO	Immobilizer				√		Password learning/modify Limp mode	
					PIC	All Systems		√	√	√	√		
						Smart Key Unit		√	√	√	√		
						Smart Key Code Saving				√			
					AHLS	Auto Headlamp Leveling	√	√	√	√			
					CODE	Transmitter Code Saving				√			
					ENGINE	Unleaded EOBD	√	√	√	√	√		
							Unleaded GEN	√	√	√	√	√	
							Leaded All	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√		
					ESP	Electronic Stability Program	√	√	√	√	√		
					AIRBAG	Airbag(Event #1)	√	√	√				
						Airbag(Event #2)	√	√	√	√			
					AIRCON	Air Conditioner	√	√	√	√	√		
					EPS	Motor Driven Power Steering	√	√	√	√	√		
					BCM	All Systems	√	√	√	√	√		
						Body Control Module	√	√	√	√	√		
						Cluster Module	√	√	√	√	√		
						Power Seat Module	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.0 DOHC		Smart Junction Box	√	√	√	√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√		
				AHLS	Auto Headlamp Leveling(GEN)	√	√	√	√	√		
					Auto Headlamp Leveling(EURO)	√	√	√	√	√		
				SPAS	Smart Parking Assist System	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
				ENGINE	Unleaded EOBD	√	√	√	√	√		
					Unleaded GEN	√	√	√	√	√		
					Leaded All	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag(Event #1)	√	√	√				
					Airbag(Event #2)	√	√	√	√			
			AIRCON	Air Conditioner	√	√	√	√	√			
			EPS	Motor Driven Power Steering	√	√	√	√	√			
				All Systems	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2012	G 2.4 DOHC	BCM	Body Control Module	√	√	√	√	√		
					Cluster Module	√	√	√	√	√	√	
					Power Seat Module	√	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√	√	
				AHLS	Auto Headlamp Leveling(GEN)	√	√	√	√	√	√	
					Auto Headlamp Leveling(EURO)	√	√	√	√	√	√	
				SPAS	Smart Parking Assist System	√	√	√	√	√	√	
				CODE	Transmitter Code Saving					√		
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√				
					Airbag(Event #2)	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	√	
		EPS	Motor Driven Power Steering	√	√	√	√	√	√			
			All Systems	√	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
OPTIMA(TF)			G 2.4 GDI	BCM	Body Control Module	√	√	√	√	√			
					Cluster Module	√	√	√	√	√			
					Power Seat Module	√	√	√	√	√			
					Smart Junction Box	√	√	√	√	√			
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√			
				AHLS	Auto Headlamp Leveling(GEN)	√	√	√	√	√			
					Auto Headlamp Leveling(EURO)	√	√	√	√	√			
				SPAS	Smart Parking Assist System	√	√	√	√	√			
				CODE	Transmitter Code Saving					√			
				ENGINE	Unleaded EOBD	√	√	√	√	√			
					Unleaded GEN	√	√	√	√	√			
					Leaded All	√	√	√	√	√			
				AT	Automatic Transaxle	√	√	√	√	√			
				ESP	Electronic Stability Program	√	√	√	√	√			
				AIRBAG	Airbag(Event #1)	√	√	√	√	√			
Airbag(Event #2)	√	√	√		√	√							



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.0 DOHC	AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Motor Driven Power Steering	√	√	√	√	√		
				BCM	All Systems	√	√	√	√	√		
					Body Control Module	√	√	√	√	√		
					Cluster Module	√	√	√	√	√		
					Power Seat Module	√	√	√	√	√		
					Smart Junction Box	√	√	√	√	√		
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PIC	Smart Key Unit	√	√	√	√	√	
					AHLS	Auto Headlamp Leveling(GEN)	√	√	√	√	√	
						Auto Headlamp Leveling(EURO)	√	√	√	√	√	
					SPAS	Smart Parking Assist System	√	√	√	√	√	
					CODE	Transmitter Code Saving				√		
					ENGINE	Unleaded EOBD	√	√	√	√	√	
						Unleaded GEN	√	√	√	√	√	
				Leaded All		√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√			
					Airbag(Event #2)	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Motor Driven Power Steering	√	√	√	√	√	
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Cluster Module	√	√	√	√	√	
					Power Seat Module	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√	
				AHLS	Auto Headlamp Leveling(GEN)	√	√	√	√	√	
					Auto Headlamp Leveling(EURO)	√	√	√	√	√	
				SPAS	Smart Parking Assist System	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				AT	Automatic Transaxle	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.4 GDI	ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag(Event #1)	√	√	√				
					Airbag(Event #2)	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Motor Driven Power Steering	√	√	√	√	√		
				BCM	All Systems	√	√	√	√	√		
					Body Control Module	√	√	√	√	√		
					Cluster Module	√	√	√	√	√		
					Power Seat Module	√	√	√	√	√		
					Smart Junction Box	√	√	√	√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√		
				AHLS	Auto Headlamp Leveling(GEN)	√	√	√	√	√		
					Auto Headlamp Leveling(EURO)	√	√	√	√	√		
				SPAS	Smart Parking Assist System	√	√	√	√	√		
			CODE	Transmitter Code Saving				√				
				Unleaded EOBD	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√		
						Leaded All	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	
					ESP	Electronic Stability Program	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√			
					AIRCON	Air Conditioner	√	√	√	√	√	
					ECS	Electronic Control Suspension		√	√	√	√	
					BCM	Body Control Module	√			√	√	
					PIC	All Systems	√	√	√	√	√	
						Smart Key Unit	√	√	√	√	√	
						Power Distribution Module	√	√	√	√	√	
						Smart Key Code Saving				√		
					CODE	Transmitter Code Saving				√		
			G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√		
						Unleaded GEN	√	√	√	√	√	
						Leaded All	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	
					ESP	Electronic Stability Program	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√			
					AIRCON	Air Conditioner	√	√	√	√	√	
					ECS	Electronic Control Suspension		√	√	√	√	
					BCM	Body Control Module	√			√	√	
						All Systems	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2010		PIC	Smart Key Unit	√	√	√	√	√			
					Power Distribution Module	√	√	√	√	√	√		
					Smart Key Code Saving					√			
				CODE	Transmitter Code Saving					√			
				G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
						Unleaded GEN	√	√	√	√	√	√	√
			Leaded All			√	√	√	√	√	√	√	
			AT		Automatic Transaxle	√	√	√	√	√	√	√	
			ESP		Electronic Stability Program	√	√	√	√	√	√	√	
			AIRBAG		Airbag Control	√	√	√					
			AIRCON		Air Conditioner	√	√	√	√	√	√	√	
			ECS		Electronic Control Suspension			√	√	√	√	√	
			BCM		Body Control Module	√				√	√	√	
			PIC		All Systems	√	√	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	√	√	
				Smart Key Code Saving					√				
			CODE	Transmitter Code Saving					√				
				ENGINE	Engine Control	√	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√					
				AIRCON	Air Conditioner	√	√	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.0 TCI-D	ECS	Electronic Control Suspension		√	√	√	√		
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
					Smart Key Code Saving				√			
				CODE	Transmitter Code Saving				√			
				G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	
						Unleaded GEN	√	√	√	√	√	
			Leaded All			√	√	√	√	√		
			AT		Automatic Transaxle	√	√	√	√	√		
			ESP		Electronic Stability Program	√	√	√	√	√		
			AIRBAG		Airbag Control	√	√	√				
			AIRCON		Air Conditioner	√	√	√	√	√		
			ECS		Electronic Control Suspension		√	√	√	√		
			BCM		Body Control Module	√			√	√		
					All Systems	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
				PIC	Smart Key Unit	√	√	√	√	√			
					Power Distribution Module	√	√	√	√	√			
					Smart Key Code Saving				√				
				CODE	Transmitter Code Saving				√				
			G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√			
						Unleaded GEN	√	√	√	√	√		
						Leaded All	√	√	√	√	√		
					AT	Automatic Transaxle	√	√	√	√	√		
					ESP	Electronic Stability Program	√	√	√	√	√		
					AIRBAG	Airbag Control	√	√	√				
					AIRCON	Air Conditioner	√	√	√	√	√		
					ECS	Electronic Control Suspension		√	√	√	√		
					BCM	Body Control Module	√			√	√		
					PIC	All Systems	√	√	√	√	√		
							Smart Key Unit	√	√	√	√	√	
							Power Distribution Module	√	√	√	√	√	
						Smart Key Code Saving				√			
					CODE	Transmitter Code Saving				√			
		2009		ENGINE	Unleaded EOBD	√	√	√	√	√			
							Unleaded GEN	√	√	√	√	√	
							Leaded All	√	√	√	√	√	
						AT	Automatic Transaxle	√	√	√	√	√	
						ESP	Electronic Stability Program	√	√	√	√	√	
						AIRBAG	Airbag Control	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 2.4 DOHC	AIRCON	Air Conditioner	√	√	√	√	√	
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving					√	
			CODE	Transmitter Code Saving				√			
			D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				ECU	Power Distribution Module	√	√	√	√	√		
					Smart Key Code Saving				√			
				CODE	Transmitter Code Saving				√			
			G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
					Unleaded GEN	√	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	√	Adaptive value reset
					AT	Automatic Transaxle	√	√	√	√	√	
					ABS	Anti-Lock Brake	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√			
					AIRCON	Air Conditioner	√	√	√	√	√	
					ECS	Electronic Control Suspension		√	√	√	√	
					BCM	Body Control Module	√			√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					CODE	Transmitter Code Saving				√		
					ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				
				AIRCON	Air Conditioner	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
Optima/Magentis(MG)		2008	G 2.4 DOHC	ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
			G 2.7 DOHC	ENGINE	Unleaded EOBD		√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					Unleaded GEN		√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					Leaded All		√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	
				ECS	Electronic Control Suspension		√	√	√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
			D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
					ENGINE	Unleaded EOBD	√	√	√	√	√
				ENGINE	Unleaded GEN	√	√	√	√	√	Adaptive value reset



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 2.0 DOHC		Leaded All	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
			G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
		2007		ENGINE	Unleaded EOBD		√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
			Unleaded GEN			√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set	
			Leaded All			√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set	
			G 2.7 DOHC	AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
			D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	
					IMMO	Immobilizer					
				CODE	Transmitter Code Saving				√		
				ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	Adaptive value reset



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 2.0 DOHC	AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
			G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
		2006		ENGINE	Unleaded EOBD		√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
			Unleaded GEN			√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set	
			Leaded All			√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set	
			G 2.7 DOHC	AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
			D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
			ENGINE	A/T(Unleaded)		√	√	√	√	√	
				A/T(Leaded)			√	√	√	√	
				M/T(Unleaded)		√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2006	G 2.0 DOHC		M/T(Leaded)		√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√	
					Anti-Lock Brake(Mando)	√	√	√	√	√	√	
			AIRBAG	Airbag Control	√	√	√	√	√			
			G 2.5 DOHC	ENGINE	Unleaded EOBD(TiO2)	√	√	√	√	√	√	Reset all adaptive value
					Unleaded EOBD(ZrO2)	√	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle		√	√	√	√		
			ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√		
				Anti-Lock Brake(Mando)	√	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√	√	√			
			G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle		√	√	√	√	√	
				ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√	
					Anti-Lock Brake(Mando)	√	√	√	√	√	√	
			AIRBAG	Airbag Control	√	√	√	√	√			
			G 2.0 DOHC	ENGINE	A/T(Unleaded)	√	√	√	√	√	√	
					A/T(Leaded)		√	√	√	√	√	√
		M/T(Unleaded)			√	√	√	√	√	√	√	
		M/T(Leaded)				√	√	√	√	√	√	
		AT		Automatic Transaxle	√	√	√	√	√	√		
		ABS		Anti-Lock Brake(Bosch)	√	√	√	√	√	√	√	
			Anti-Lock Brake(Mando)	√	√	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2005	G 2.5 DOHC	AIRBAG	Airbag Control	√	√	√	√			
				ENGINE	Unleaded EOBD(TiO2)	√	√	√	√	√	√	Reset all adaptive value
					Unleaded EOBD(ZrO2)	√	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle		√	√	√	√	√	
				ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√	
					Anti-Lock Brake(Mando)	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√	√		
				G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	
			AT		Automatic Transaxle	√	√	√	√	√		
			ABS		Anti-Lock Brake(Bosch)	√	√	√	√	√	√	
					Anti-Lock Brake(Mando)	√	√	√	√	√	√	
			AIRBAG	Airbag Control	√	√	√	√	√			
			G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√		Adaptive value reset
				AT	Automatic Transaxle		√	√	√	√	√	
				ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√	
					Anti-Lock Brake(Mando)	√	√	√	√	√	√	
			AIRBAG	Airbag Control	√	√	√	√	√			
			G 2.0 DOHC	ENGINE	A/T(Unleaded)	√	√	√	√	√	√	
		A/T(Leaded)				√	√	√	√	√		
		M/T		Unleaded	√	√	√	√	√	√		
				Leaded		√	√	√	√	√		
		AT		Automatic Transaxle	√	√	√	√	√	√		
		ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function								
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions			
Optima/Magentis(MS)		2004	G 2.5 DOHC	ABS	Anti-Lock Brake(Mando)	√	√	√	√	√				
				AIRBAG	Airbag Control	√	√	√	√					
			ENGINE	Unleaded EOBD(TiO2)	√	√	√	√	√	√	√	Reset all adaptive value		
				Unleaded EOBD(ZrO2)	√	√	√	√	√	√	√	Adaptive value reset		
				Unleaded GEN	√	√	√	√	√	√	√	Adaptive value reset		
				Leaded All	√	√	√	√	√	√	√	Adaptive value reset		
			AT	Automatic Transaxle		√	√	√	√	√				
			ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√	√			
				Anti-Lock Brake(Mando)	√	√	√	√	√	√	√			
			AIRBAG	Airbag Control	√	√	√	√	√	√				
			G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	√			
				AT	Automatic Transaxle	√	√	√	√	√	√			
				ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√	√		
					Anti-Lock Brake(Mando)	√	√	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√	√	√	√				
			G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle		√	√	√	√	√			
				ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√	√		
					Anti-Lock Brake(Mando)	√	√	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√	√	√	√				
			G 2.0 DOHC	ENGINE	A/T(Unleaded)	√	√	√	√	√	√	√		
					A/T(Leaded)		√	√	√	√	√	√		
				M/T(Unleaded)	√	√	√	√	√	√	√			
					M/T(Leaded)		√	√	√	√	√	√		
AT	Automatic Transaxle	√		√	√	√	√	√	√					



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2003		ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√			
						Anti-Lock Brake(Mando)	√	√	√	√	√		
					AIRBAG	Airbag Control	√	√	√	√			
			G 2.5 DOHC	ENGINE	Unleaded EOBD(TiO2)	√	√	√	√	√		Reset all adaptive value	
						Unleaded EOBD(ZrO2)	√	√	√	√	√		Adaptive value reset
						Unleaded GEN	√	√	√	√	√		Adaptive value reset
						Leaded All	√	√	√	√	√		Adaptive value reset
					AT	Automatic Transaxle		√	√	√	√		
					ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√		
						Anti-Lock Brake(Mando)	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√				
			G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√			
					AT	Automatic Transaxle	√	√	√	√	√		
					ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√		
						Anti-Lock Brake(Mando)	√	√	√	√	√		
					AIRBAG	Airbag Control	√	√	√	√			
			G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√		Adaptive value reset	
					AT	Automatic Transaxle		√	√	√	√		
					ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√		
						Anti-Lock Brake(Mando)	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√				
			ENGINE	A/T(Unleaded)	√	√	√	√	√				
					A/T(Leaded)		√	√	√	√			
					M/T(Unlesded)	√	√	√	√	√			
					M/T(Leaded)		√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function									
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions				
		2002	G 2.0 DOHC	AT	Automatic Transaxle	√	√	√	√	√					
				ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√				
					Anti-Lock Brake(Mando)	√	√	√	√	√	√				
				AIRBAG	Airbag Control	√	√	√	√						
			G 2.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	Reset all adaptive value			
					Unleaded GEN	√	√	√	√	√	√	Adaptive value reset			
					Leaded All	√	√	√	√	√	√	Adaptive value reset			
			G 2.5 DOHC	AT	Automatic Transaxle		√	√	√	√	√				
					ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√			
						Anti-Lock Brake(Mando)	√	√	√	√	√	√			
					AIRBAG	Airbag Control	√	√	√	√					
			G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	√				
					AT	Automatic Transaxle	√	√	√	√	√	√			
						ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√		
					Anti-Lock Brake(Mando)		√	√	√	√	√	√			
			G 2.4 DOHC	AIRBAG	Airbag Control	√	√	√	√						
					G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Adaptive value reset	
							AT	Automatic Transaxle		√	√	√	√	√	
								ABS	Anti-Lock Brake(Bosch)	√	√	√	√	√	√
			Anti-Lock Brake(Mando)	√			√		√	√	√	√			
		G 2.7 DOHC	AIRBAG	Airbag Control	√	√	√	√							
				G 2.0 DOHC	ENGINE	A/T(Unleaded)	√	√	√	√	√				
						A/T(Leaded)		√	√	√	√	√			
						M/T(Unleaded)	√	√	√	√	√	√			
		M/T(Leaded)				√	√	√	√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2001		AT	Automatic Transaxle	√	√	√	√	√			
				ABS	Anti-Lock Brake	√	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√	√	√		
			G 2.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	Reset all adaptive value	
					Unleaded GEN	√	√	√	√	√	√	Adaptive value reset	
					Leaded All	√	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle		√	√	√	√	√		
			G 2.4 DOHC	ABS	Anti-Lock Brake	√	√	√	√	√	√		
					AIRBAG	Airbag Control	√	√	√	√	√	√	
					ENGINE	Engine Control	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√	√	√	√	
			G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√		
					Unleaded GEN	√	√	√	√	√	√	√	
		Leaded All			√	√	√	√	√	√	√		
		AT		Automatic Transaxle	√	√	√	√	√	√	Adaptive value reset		
		ABSESP		ABS/ESP(MGH-40)	√	√	√	√	√	√	√	Deflated mode	
				ABS/ESP(MGH-60)	√	√	√	√	√	√	√		
		AIRBAG		Airbag Control	√	√	√	√	√	√	√	Collision Information	
		EPS	MDPS	√	√	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
		2011	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√			
							Unleaded GEN	√	√	√	√	√	
							Laeded All	√	√	√	√	√	
						AT	Automatic Transaxle	√	√	√	√	√	Adaptive value reset
						ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	Deflated mode
							ABS/ESP(MGH-60)	√	√	√	√	√	
						AIRBAG	Airbag Control	√	√	√			Collision Information
						EPS	Electronic Power Steering	√	√	√	√		
						IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
						ENGINE	Engine Control	√	√	√	√	√	Engine testing capabilities Read injector data Write injector code
				ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	Deflated mode		
					ABS/ESP(MGH-60)	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 1.1 TCI-U	AIRBAG	Airbag Control	√	√	√			Collision Information
				EPS	MDPS	√	√	√	√		
				IMMO	IMMO(Bosch)						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	
					Unleaded GEN	√	√	√	√	√	
					Leaded All	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	Adaptive value reset
				ABSESP	ABS/ESP(~2009.12.6)	√	√	√	√	√	Deflated mode
					ABS/ESP(2009.12.7~)	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information
				EPS	MDPS	√	√	√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				ENGINE	Unleaded EOBD	√	√	√	√	√	
			Unleaded GEN		√	√	√	√	√		
			Laeded All		√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2010	G 1.1 SOHC	AT	Automatic Transaxle	√	√	√	√	√	Adaptive value reset	
				ABSESP	ABS/ESP(~2009.12.6)	√	√	√	√	√	√	Deflated mode
					ABS/ESP(2009.12.7~)	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√				Collision Information
				EPS	Electronic Power Steering	√	√	√	√			
			IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
			D 1.1 TCI-U	ENGINE	Engine Control	√	√	√	√	√	√	Engine testing capabilities Read injector data Write injector code
				ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	√	Deflated mode
					ABS/ESP(MGH-60)(2009.12.7~)	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√				Collision Information
		EPS		MDPS	√	√	√	√				
		IMMO	IMMO(Bosch)							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√		
					Leaded All	√	√	√	√	√		
					Unleaded GEN	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	Adaptive value reset	
				ABSESP	ABS/ESP	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				EPS	Electronic Power Steering	√	√	√	√			
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	
						Unleaded GEN	√	√	√	√	√	
			Leaded All			√	√	√	√	√		
			AT		Automatic Transaxle	√	√	√	√	√	Adaptive value reset	
			ABSESP		ABS/ESP	√	√	√	√	√	Deflated mode	
			AIRBAG		Airbag Control	√	√	√			Collision Information	
		2009		EPS	MDPS	√	√	√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
			D 1.1 TCI-U	ENGINE	Engine Control	√	√	√	√	√	Engine testing capabilities Read injector data Write injector code	
				ABSESP	ABS/ESP	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				EPS	MDPS	√	√	√	√			
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					ENGINE	Unleaded EOBD	√	√	√	√	√	
					Unleaded GEN	√	√	√	√	√		
					Leaded All	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	Adaptive value reset	
				ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	Deflated mode	
					ABS/ESP(MGH-25)	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√			Collision Information	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
PICANTO(S A)		2008	G 1.0 SOHC	EPS	Electronic Power Steering	√	√	√	√			
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√		
					Unleaded GEN	√	√	√	√	√		
					Leaded All	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	Adaptive value reset	
				ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	Deflated mode	
					ABS/ESP(MGH-25)	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				EPS	Electronic Power Steering	√	√	√	√			
			G 1.1 SOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				ENGINE	Engine Control	√	√	√	√	√	Engine testing capabilities Read injector data Write injector code	
			AT	Automatic Transaxle	√	√	√	√	√	Adaptive value reset		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 1.1 TCI-U	ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	Deflated mode	
					ABS/ESP(MGH-25)	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				EPS	Electronic Power Steering	√	√	√	√			
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	
						Unleaded GEN	√	√	√	√	√	
						Leaded All	√	√	√	√	√	
					AT	Automatic Transaxle		√	√	√	√	
			ABS		Anti-Lock Brake	√	√	√	√	√	Deflated mode	
			AIRBAG		Airbag Control	√	√	√			Collision Information	
			EPS		Motor driven Power Steering		√	√				
			IMMO		Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
			ENGINE	Unleaded EOBD	√	√	√	√	√	√		
				Unleaded GEN	√	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2007	G 1.1 SOHC		Leaded All	√	√	√	√	√			
				AT	Automatic Transaxle				√	√	√	√	
				ABS	Anti-Lock Brake	√		√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√		√	√				Collision Information
				EPS	Electronic Power Steering				√	√			
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			D 1.1 TCI-U	ENGINE	Engine Control	√	√	√	√	√	√	Engine testing capabilities Write injector code	
				AT	Automatic Transaxle	√		√	√	√	√	√	Adaptive value reset
				ABS	Anti-Lock Brake	√		√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√		√	√				Collision Information
				EPS	Electronic Power Steering				√	√			
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				ENGINE	Unleaded EOBD		√	√	√	√	√		
				ENGINE	Unleaded GEN		√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			2006	G 1.0 SOHC		Leaded All	√	√	√	√			
						AT	Automatic Transaxle		√	√	√	√	
						ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
						AIRBAG	Airbag Control	√	√	√			Collision Information
						EPS	Electronic Power Steering		√	√			
						IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	
							Unleaded GEN	√	√	√	√	√	
							Leaded All	√	√	√	√	√	
						AT	Automatic Transaxle		√	√	√	√	
						ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG		Airbag Control	√	√	√			Collision Information	
				EPS		Electronic Power Steering		√	√				
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 1.1 TCI-U	ENGINE	Engine Control	√	√	√	√	√	Engine testing capabilities Write injector code	
				AT	Automatic Transaxle	√	√	√	√	√	Adaptive value reset	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				EPS	Electronic Power Steering		√	√				
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
		2005	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√		
				ENGINE	Unleaded GEN	√	√	√	√	√	√	
					Leaded All	√	√	√	√	√	√	
					AT	Automatic Transaxle		√	√	√	√	
					ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
					AIRBAG	Airbag Control	√	√	√			Collision Information
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					Unleaded EOBD	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2004	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√		
					Leaded All	√	√	√	√	√		
				AT	Automatic Transaxle		√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√		Deflated mode
				AIRBAG	Airbag Control	√	√	√				Collision Information
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				ENGINE	Unleaded EOBD	√	√	√	√	√		
			G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√		
					Leaded All	√	√	√	√	√		
				AT	Automatic Transaxle		√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√		Deflated mode
				AIRBAG	Airbag Control	√	√	√				Collision Information
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				ENGINE	Unleaded EOBD	√	√	√	√	√		
ENGINE	Unleaded GEN	√	√	√	√	√						



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 1.1 SOHC		Leaded All	√	√	√	√	√		
				AT	Automatic Transaxle		√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
		2003	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√		
					Unleaded GEN	√	√	√	√	√	√	
					Leaded All	√	√	√	√	√	√	
					AT	Automatic Transaxle		√	√	√	√	
					ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
					AIRBAG	Airbag Control	√	√	√			Collision Information
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			ENGINE	Unleaded All	√	√	√	√	√	√	self-learning clear	
				Leaded All	√	√	√	√	√	√	self-learning clear	
				AT	Automatic Transaxle	√	√	√		√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 1.2 DOHC	ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		
					Airbag(Event #2)	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Motor Driven Power Steering(EURO)	√	√	√	√		
					Motor Driven Power Steering(GEN)	√	√	√	√		
				BCM	Body Control Module(EURO)	√	√	√	√	√	
					Body Control Module(GEN)	√	√	√	√	√	
				PIC	Smart Key Unit	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
			G 1.0 DOHC	ENGINE	Unleaded All	√	√	√	√	√	self-learning clear
					Leaded All	√	√	√	√	√	self-learning clear
				AT	Automatic Transaxle	√	√	√		√	
				ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		
					Airbag(Event #2)	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Motor Driven Power Steering(EURO)	√	√	√	√		
					Motor Driven Power Steering(GEN)	√	√	√	√		
				BCM	Body Control Module(EURO)	√	√	√	√	√	
			Body Control Module(GEN)		√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
	PICANTO(TA)	2012		PIC	Smart Key Unit	√	√	√	√	√			
				CODE	Transmitter Code Saving				√				
			B 1.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	self-learning clear	
				AT	Automatic Transaxle	√	√	√			√		
				ABSESP	ABS/ESP	√	√	√	√	√			
				AIRBAG	Airbag(Event #1)	√	√	√	√				
					Airbag(Event #2)	√	√	√	√				
				AIRCON	Air Conditioner	√	√	√	√	√	√		
				EPS	Motor Driven Power Steering(EURO)	√	√	√	√				
					Motor Driven Power Steering(GEN)	√	√	√	√				
				BCM	Body Control Module(EURO)	√	√	√	√	√	√		
					Body Control Module(GEN)	√	√	√	√	√	√		
				PIC	Smart Key Unit	√	√	√	√	√	√		
				CODE	Transmitter Code Saving						√		
			F 1.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	self-learning clear	
				AT	Automatic Transaxle	√	√	√			√		
				ABSESP	ABS/ESP	√	√	√	√	√	√		
				AIRBAG	Airbag(Event #1)	√	√	√	√				
					Airbag(Event #2)	√	√	√	√				
				AIRCON	Air Conditioner	√	√	√	√	√	√		
				EPS	Motor Driven Power Steering(EURO)	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				EPS	Motor Driven Power Steering(GEN)	√	√	√	√		
				BCM	Body Control Module(FUPO)	√	√	√	√	√	
				PIC	Body Control Module(GEN)	√	√	√	√	√	
				PIC	Smart Key Unit	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
	PREGIO(FP)	2004	D 2.7 J2	ENGINE	Engine Control		√	√	√	√	Clear fault code
			D 2.5 TCI	ENGINE	Engine Control		√	√	√	√	√
		2003	D 2.7 J2	ENGINE	Engine Control		√	√	√	√	Clear fault code
			D 2.5 TCI	ENGINE	Engine Control		√	√	√	√	√
		2002	D 2.7 J2	ENGINE	Engine Control		√	√	√	√	Clear fault code
			D 2.5 TCI	ENGINE	Engine Control		√	√	√	√	√
		2001	D 2.7 J2	ENGINE	Engine Control		√	√	√	√	Clear fault code
		2000	D 2.7 J2	ENGINE	Engine Control		√	√	√	√	Clear fault code
		1999	D 2.7 J2	ENGINE	Engine Control		√	√	√	√	Clear fault code
		1998	D 2.7 J2	ENGINE	Engine Control		√	√	√	√	Clear fault code
	1997	D 2.7 J2	ENGINE	Engine Control		√	√	√	√	Clear fault code	
	G 1.3 SOHC	2004	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
		2003	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
		2002	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
		2001	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
		2000	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		1999	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
		1998	G 1.3 SOHC	ENGINE	Engine Control		√	√	√		
		1997	G 1.3 SOHC(MFI)	ENGINE	Engine(MFI)		√	√	√		
			G 1.3 SOHC(FBC)	ENGINE	Engine(AFM1) Engine(FBC)		√	√	√		
		1996	G 1.3 SOHC(MFI)	ENGINE	Engine(MFI)		√	√	√		
			G 1.3 SOHC(FBC)	ENGINE	Engine(AFM1) Engine(FBC)		√	√	√		
		1995	G 1.3 SOHC(MFI)	ENGINE	Engine Control(MFI)		√	√	√		
			G 1.3 SOHC(FBC)	ENGINE	Engine(AFM1) Engine(FBC)		√	√	√		
		1994	G 1.3 SOHC(CARB)	ENGINE	Engine Control		√	√	√		
			G 1.3 SOHC(MFI)	ENGINE	Engine Control		√	√	√		
			G 1.3 SOHC(FBC)	ENGINE	Engine(AFM1) Engine(FBC)		√	√	√		
		1993	G 1.3 SOHC(CARB)	ENGINE	Engine Control(CARB)		√	√	√		
			G 1.3 SOHC(MFI)	ENGINE	Engine Control		√	√	√		
			G 1.3	ENGINE	Engine(AFM1)		√	√	√		

PRIDE(PRD)



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			SOHC(FBC)	ENGINE	Engine(FBC)		√	√	√		
		1992	SOHC(CARB)	ENGINE	Engine Control(CARB)		√	√	√		
			G 1.3 SOHC(MFI)	ENGINE	Engine Control(MFI)		√	√	√		
			G 1.3 SOHC(FBC)	ENGINE	Engine(AFM1) Engine(FBC)		√ √	√ √	√ √		
			G 1.3 SOHC(CARB)	ENGINE	Engine Control(CARB)		√	√	√		
		1991	G 1.3 SOHC(MFI)	ENGINE	Engine Control(MFI)		√	√	√		
			G 1.3 SOHC(FBC)	ENGINE	Engine(AFM1) Engine(FBC)		√ √	√ √	√ √		
			G 1.3 SOHC(CARB)	ENGINE	Engine Control(CARB)		√	√	√		
		1990	G 1.3 SOHC(MFI)	ENGINE	Engine Control(MFI)		√	√	√		
			G 1.3 SOHC(FBC)	ENGINE	Engine(AFM1) Engine(FBC)		√ √	√ √	√ √		
			G 1.3 SOHC(CARB)	ENGINE	Engine Control(CARB)		√	√	√		
		2001	G 2.0 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
			D 2.0 TCI	ABS	Anti-Lock Brake		√	√	√	√	
				ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle		√	√	√		
			ABS	Anti-Lock Brake		√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
	RETONA(JL)	2000	G 2.0 DOHC	ENGINE	Engine Control		√	√	√			
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√		
			D 2.0 TCI	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√		
		1999	G 2.0 DOHC	ENGINE	Engine Control		√	√	√			
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√		
			D 2.0 TCI	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√		
	1998	D 2.0 TCI	ENGINE	Engine Control		√	√	√	√			
			AT	Automatic Transaxle		√	√	√				
			ABS	Anti-Lock Brake		√	√	√	√			
				G 1.3 SOHC	ENGINE	Unleaded-W/IMMO		√	√	√		
						Leaded All		√	√	√		
						Unleaded(RHD)-MAF		√	√	√		
						Unleaded(RHD)-MAP		√	√	√		
						Unleaded-MAF		√	√	√		
						Unleaded-MAP		√	√	√		
AT					Automatic Transaxle(LHD)		√	√	√			
					Automatic Transaxle(RHD)		√	√	√			
ABS					Anti-Lock Brake	√	√	√	√	√	Deflated mode	
AIRBAG					Airbag Control(LHD)		√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2006		AIRBAG	Airbag Control(RHD)		√	√	√				
			G 1.5 DOHC	ENGINE	Unleaded-W/IMMO		√	√	√				
					Leaded All		√	√	√				
					Unleaded(RHD)-MAF		√	√	√				
					Unleaded(RHD)-MAP		√	√	√				
					Unleaded-MAF		√	√	√				
					Unleaded-MAP		√	√	√				
				AT	Automatic Transaxle(LHD)		√	√	√				
					Automatic Transaxle(RHD)		√	√	√				
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control(LHD)		√	√	√				
			Airbag Control(RHD)			√	√	√					
		2005	G 1.3 SOHC	ENGINE	Unleaded-W/IMMO		√	√	√				
						Leaded All		√	√	√			
						Unleaded(RHD)-MAF		√	√	√			
						Unleaded(RHD)-MAP		√	√	√			
						Unleaded-MAF		√	√	√			
						Unleaded-MAP		√	√	√			
					AT	Automatic Transaxle(LHD)		√	√	√			
						Automatic Transaxle(RHD)		√	√	√			
					ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode
					AIRBAG	Airbag Control(LHD)		√	√	√			
			Airbag Control(RHD)			√	√	√					
					Unleaded-W/IMMO		√	√	√				
					Leaded All		√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2009	G 1.5 DOHC	ENGINE	Unleaded(RHD)-MAF		√	√	√		
					Unleaded(RHD)-MAP		√	√	√		
					Unleaded-MAF		√	√	√		
					Unleaded-MAP		√	√	√		
				AT	Automatic Transaxle(LHD)		√	√	√		
					Automatic Transaxle(RHD)		√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control(LHD)		√	√	√		
			Airbag Control(RHD)			√	√	√			
			G 1.6 DOHC	ENGINE	Engine Control		√	√	√		
					AT	Automatic Transaxle		√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control		√	√	√		
			G 1.3 SOHC	ENGINE	Unleaded-W/IMMO		√	√	√		
					Leaded All		√	√	√		
					Unleaded(RHD)-MAF		√	√	√		
		Unleaded(RHD)-MAP				√	√	√			
		Unleaded-MAF				√	√	√			
		Unleaded-MAP			√	√	√				
		AT		Automatic Transaxle(LHD)		√	√	√			
				Automatic Transaxle(RHD)		√	√	√			
		ABS		Anti-Lock Brake	√	√	√	√	√	Deflated mode	
		AIRBAG		Airbag Control(LHD)		√	√	√			
			Airbag Control(RHD)		√	√	√				
					Unleaded-W/IMMO		√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2004	G 1.5 DOHC	ENGINE	Leaded All		√	√	√		
					Unleaded(RHD)-MAF		√	√	√		
					Unleaded(RHD)-MAP		√	√	√		
					Unleaded-MAF		√	√	√		
					Unleaded-MAP		√	√	√		
				AT	Automatic Transaxle(LHD)		√	√	√		
					Automatic Transaxle(RHD)		√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control(LHD)		√	√	√		
			Airbag Control(RHD)			√	√	√			
			G 1.6 DOHC	ENGINE	Engine Control		√	√	√		
					AT	Automatic Transaxle		√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control		√	√	√		
			G 1.3 SOHC	ENGINE	Unleaded-W/IMMO		√	√	√		
					Leaded All		√	√	√		
					Unleaded(RHD)-MAF		√	√	√		
					Unleaded(RHD)-MAP		√	√	√		
		Unleaded-MAF				√	√	√			
		Unleaded-MAP			√	√	√				
		AT		Automatic Transaxle(LHD)		√	√	√			
				Automatic Transaxle(RHD)		√	√	√			
		ABS		Anti-Lock Brake	√	√	√	√	√	Deflated mode	
		AIRBAG	Airbag Control(LHD)		√	√	√				
			Airbag Control(RHD)		√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	RIO(BC)	2003	G 1.5 DOHC	ENGINE	Unleaded-W/IMMO		√	√	√		
					Leaded All		√	√	√		
					Unleaded(RHD)-MAF		√	√	√		
					Unleaded(RHD)-MAP		√	√	√		
					Unleaded-MAF		√	√	√		
					Unleaded-MAP		√	√	√		
				AT	Automatic Transaxle(LHD)		√	√	√		
					Automatic Transaxle(RHD)		√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control(LHD)		√	√	√		
			Airbag Control(RHD)			√	√	√			
			G 1.6 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
		AIRBAG		Airbag Control		√	√	√			
		G 1.3 SOHC	ENGINE	Unleaded-W/IMMO		√	√	√			
				Leaded All		√	√	√			
				Unleaded(RHD)-MAF		√	√	√			
				Unleaded(RHD)-MAP		√	√	√			
				Unleaded-MAF		√	√	√			
				Unleaded-MAP		√	√	√			
AT	Automatic Transaxle(LHD)			√	√	√					
	Automatic Transaxle(RHD)			√	√	√					
ABS	Anti-Lock Brake(LHD)		√	√	√	√					
	Anti-Lock Brake(RHD)		√	√	√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function								
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions			
		2002		AIRBAG	Airbag Control(LHD)		√	√	√					
				AIRBAG	Airbag Control(RHD)		√	√	√					
				G 1.5 DOHC	ENGINE		Unleaded-W/IMMO		√	√	√			
							Leaded All		√	√	√			
							Unleaded(RHD)-MAF		√	√	√			
							Unleaded(RHD)-MAP		√	√	√			
							Unleaded-MAF		√	√	√			
							Unleaded-MAP		√	√	√			
						AT		Automatic Transaxle(LHD)		√	√	√		
							Automatic Transaxle(RHD)		√	√	√			
						ABS		Anti-Lock Brake(LHD)		√	√	√	√	
							Anti-Lock Brake(RHD)		√	√	√	√		
					AIRBAG		Airbag Control(LHD)		√	√	√			
						Airbag Control(RHD)		√	√	√				
				G 1.3 SOHC	ENGINE		Unleaded-W/IMMO		√	√	√			
							Leaded All		√	√	√			
							Unleaded(RHD)-MAF		√	√	√			
							Unleaded(RHD)-MAP		√	√	√			
			Unleaded-MAF				√	√	√					
			Unleaded-MAP				√	√	√					
			AT			Automatic Transaxle(LHD)		√	√	√				
					Automatic Transaxle(RHD)		√	√	√					
			ABS			Anti-Lock Brake(LHD)		√	√	√	√			
					Anti-Lock Brake(RHD)		√	√	√	√				
			AIRBAG		Airbag Control(LHD)		√	√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2001		AIRBAG	Airbag Control(RHD)		√	√	√			
			G 1.5 DOHC	ENGINE	Unleaded-W/IMMO		√	√	√			
					Leaded All		√	√	√			
					Unleaded(RHD)-MAF		√	√	√			
					Unleaded(RHD)-MAP		√	√	√			
					Unleaded-MAF		√	√	√			
					Unleaded-MAP		√	√	√			
				AT	Automatic Transaxle(LHD)		√	√	√			
					Automatic Transaxle(RHD)		√	√	√			
				ABS	Anti-Lock Brake(LHD)		√	√	√	√		
					Anti-Lock Brake(RHD)		√	√	√	√		
				AIRBAG	Airbag Control(LHD)		√	√	√			
					Airbag Control(RHD)		√	√	√			
				G 1.3 SOHC	ENGINE	Unleaded-W/IMMO		√	√	√		
						Leaded All		√	√	√		
			Unleaded(RHD)-MAF				√	√	√			
			Unleaded(RHD)-MAP				√	√	√			
			Unleaded-MAF				√	√	√			
			Unleaded-MAP				√	√	√			
			AT		Automatic Transaxle(LHD)		√	√	√			
					Automatic Transaxle(RHD)		√	√	√			
			ABS		Anti-Lock Brake(LHD)		√	√	√	√		
					Anti-Lock Brake(RHD)		√	√	√	√		
			AIRBAG	Airbag Control(LHD)		√	√					
				Airbag Control(RHD)		√	√					



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2000	G 1.5 DOHC	ENGINE	Unleaded-W/IMMO		√	√	√		
					Leaded All		√	√	√		
					Unleaded(RHD)-MAF		√	√	√		
					Unleaded(RHD)-MAP		√	√	√		
					Unleaded-MAF		√	√	√		
					Unleaded-MAP		√	√	√		
				AT	Automatic Transaxle(LHD)		√	√	√		
					Automatic Transaxle(RHD)		√	√	√		
				ABS	ABS(LHD)		√	√	√	√	
					ABS(RHD)		√	√	√	√	
				AIRBAG	Airbag Control(LHD)		√	√			
					Airbag Control(RHD)		√	√			
		G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
				Unleaded GEN	√	√	√	√	√	Adaptive value reset	
				Leaded All	√	√	√	√	√	Adaptive value reset	
			AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset	
			ABSESP	ABS/ESP	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√				
			EPS	Power Steering	√	√	√	√			
			IMMO	Immobilizer				√			
			G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset
ABSESP	ABS/ESP	√		√	√	√	√				



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2011		AIRBAG	Airbag Control	√	√	√				
				EPS	Power Steering	√	√	√	√			
				IMMO	Immobilizer				√			
			D 1.5 TCI-U		ENGINE	Engine Control	√	√	√	√	√	Compression testing Read injector data Write injector code
					AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset
					ABSESP	ABS/ESP	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√			
					EPS	Power Steering	√	√	√	√		
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					G 1.4 DOHC		ENGINE	Unleaded EOBD	√	√	√	√
			Unleaded GEN	√				√	√	√	√	Adaptive value reset
			Leaded All	√				√	√	√	√	Adaptive value reset
			AT	Automatic Transaxle			√	√	√	√	√	Adaptive reset
			ABSESP	ABS/ESP			√	√	√	√	√	
			AIRBAG	Airbag Control			√	√	√			
		EPS	Power Steering	√			√	√	√			
		IMMO	Immobilizer						√			
					Unleaded EOBD	√	√	√	√	√	Adaptive value reset	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2010	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	Adaptive value reset	
					Leaded All	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset	
				ABSESP	ABS/ESP	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				
				EPS	Power Steering	√	√	√	√			
				IMMO					√			
			D 1.5 TCI-U	ENGINE	Engine Control	√	√	√	√	√	√	Compression testing Read injector data Write injector code
				AT	Automatic Transaxle	√	√	√	√	√	√	Adaptive reset
				ABSESP	ABS/ESP	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√				
				EPS	Power Steering	√	√	√	√			
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
		G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	Adaptive value reset	
				Unleaded GEN	√	√	√	√	√	Adaptive value reset		
				Leaded All	√	√	√	√	√	Adaptive value reset		
			AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset		
			ABS	ABS(MGH-40)	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2009		ABS	ABS(MGH-25)	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√				
				IMMO	Immobilizer				√			
			G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	√	√
				AT	Automatic Transaxle	√	√	√	√	√	√	Adaptive reset
				ABS	ABS(MGH-40)	√	√	√	√	√	√	
					ABS(MGH-25)	√	√	√	√	√	√	√
				AIRBAG	Airbag Control	√	√	√				
				IMMO	Immobilizer				√			
			D 1.5 TCI-U	ENGINE	Engine Control	√	√	√	√	√	√	Compression testing Read injector data Write injector code
				AT	Automatic Transaxle	√	√	√	√	√	√	Adaptive reset
				ABS	ABS(MGH-40)	√	√	√	√	√	√	
					ABS(MGH-25)	√	√	√	√	√	√	√
				AIRBAG	Airbag Control	√	√	√				
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				ENGINE	Unleaded EOBD	√	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	√	Adaptive value reset



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	RIO(JB)	2008	G 1.6 DOHC		Leaded All	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset
				ABS	ABS(MGH-40)	√	√	√	√		
					ABS(MGH-25)	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			
			IMMO	Immobilizer				√			
			G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset
				ABS	ABS(MGH-40)	√	√	√	√	√	
					ABS(MGH-25)	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			
			IMMO	Immobilizer				√			
			D 1.5 TCI-U	ENGINE	Engine Control	√	√	√	√	√	Compression testing Read injector data Write injector code
				AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset
				ABS	ABS(MGH-40)	√	√	√	√	√	
					ABS(MGH-25)	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
		2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset		
					Unleaded GEN	√	√	√	√	√	√	Adaptive value reset	
					Leaded All	√	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√	√	Adaptive reset	
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√					
				IMMO	Immobilizer				√				
			G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	Adaptive value reset	
					Unleaded GEN	√	√	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	√	Adaptive reset	
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√					
				IMMO	Immobilizer				√				
				ENGINE	Engine Control	√	√	√	√	√	√	Compression testing Read injector data Write injector code	
					AT	Automatic Transaxle	√	√	√	√	√	√	Adaptive reset
					ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√				
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
		2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
						Unleaded GEN	√	√	√	√	√	Adaptive value reset
						Leaded All	√	√	√	√	√	Adaptive value reset
					AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset
					ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
					AIRBAG	Airbag Control	√	√	√			
					IMMO	Immobilizer				√		
				G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
						Unleaded GEN	√	√	√	√	√	Adaptive value reset
						Leaded All	√	√	√	√	√	Adaptive value reset
					AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset
					ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
					AIRBAG	Airbag Control	√	√	√			
					IMMO	Immobilizer				√		
			D 1.5 TCI-U	ENGINE	Engine Control	√	√	√	√	√	Compression testing Read injector data Write injector code	
				AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode		
				AIRBAG	Airbag Control	√	√	√					
				IMMO	Immobilizer				√				
		2005	G 1.6 DOHC	AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset		
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√					
				IMMO	Immobilizer				√				
			G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	Adaptive value reset	
					Unleaded GEN	√	√	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	√	Adaptive reset	
			D 1.5 TCI-U	ENGINE	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode	
					AIRBAG	Airbag Control	√	√	√				
					IMMO	Immobilizer				√			
					ENGINE	Engine Control	√	√	√	√	√	√	Compression testing Read injector data Write injector code
			AT		Automatic Transaxle	√	√	√	√	√	√	Adaptive reset	
				ENGINE	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode	
					AIRBAG	Airbag Control	√	√	√				
		IMMO			Immobilizer				√				
		Unleaded All			√	√	√	√	√	√	√	self-learning clear	
			ENGINE	Leaded All	√	√	√	√	√	√	self-learning clear		
			ABSESP	ABS/ESP	√	√	√	√	√	√			
			AIRBAG	Airbag(Event #1)	√	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
RIO(UB)		2012	G 1.2 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√		
				EPS	Motor driven Power Steering	√	√	√	√	√	
				BCM	Body Control Module(FUPO)	√	√	√	√	√	
					Body Control Module(GEN)	√	√	√	√	√	
			CODE	Transmitter Code Saving				√			
			G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	self-learning clear
					Leaded All	√	√	√	√	√	self-learning clear
				ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		
					Airbag(Event #2)	√	√	√	√		
				EPS	Motor driven Power Steering	√	√	√	√	√	
				BCM	Body Control Module(FUPO)	√	√	√	√	√	
			Body Control Module(GEN)		√	√	√	√	√		
			CODE	Transmitter Code Saving				√			
			D 1.4 TCI-U2	ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		
					Airbag(Event #2)	√	√	√	√		
				EPS	Motor driven Power Steering	√	√	√	√	√	
				BCM	Body Control Module(FUPO)	√	√	√	√	√	
			Body Control Module(GEN)		√	√	√	√	√		
			CODE	Transmitter Code Saving				√			
			D 1.1 TCI-U2	ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		
					Airbag(Event #2)	√	√	√	√		
EPS	Motor driven Power Steering	√	√	√	√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function								
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions			
			G 1.4 DOHC	BCM	Body Control Module(FUPO)	√	√	√	√	√				
					Body Control Module(GEN)	√	√	√	√	√				
				CODE	Transmitter Code Saving				√					
				ENGINE	Unleaded All	√	√	√	√	√	self-learning clear			
					Leaded All	√	√	√	√	√	self-learning clear			
				AT	Automatic Transaxle	√	√	√		√				
				ABSESP	ABS/ESP	√	√	√	√	√				
				AIRBAG	Airbag(Event #1)	√	√	√	√					
					Airbag(Event #2)	√	√	√	√					
				EPS	Motor driven Power Steering	√	√	√	√	√				
			BCM	Body Control Module(FUPO)	√	√	√	√	√					
				Body Control Module(GEN)	√	√	√	√	√					
			CODE	Transmitter Code Saving				√						
			2000	G 1.5 DOHC	ENGINE	Engine Control			√	√	√			
					AT	Automatic Transaxle			√	√	√			
					ABS	Anti-Lock Brake			√	√	√	√		
					AIRBAG	Airbag Control			√	√				
				G 1.8 DOHC	ENGINE	Engine Control								
					AT	Automatic Transaxle			√	√	√			
					ABS	Anti-Lock Brake			√	√	√	√		
G 1.5 DOHC	AIRBAG	Airbag Control			√	√								
	ENGINE	Engine Control			√	√	√							
	AT	Automatic Transaxle			√	√	√							
	ABS	Anti-Lock Brake			√	√	√	√						
AIRBAG	Airbag Control			√	√									



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
	SEPHIA II(FB22)	1999	G 1.8 DOHC	ENGINE	Engine Control		√	√	√			
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√		
				AIRBAG	Airbag Control		√	√				
		1998	G 1.5 DOHC	ENGINE	Engine Control		√	√	√			
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√		
				AIRBAG	Airbag Control		√	√				
			G 1.8 DOHC	ENGINE	Engine Control							
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√		
				AIRBAG	Airbag Control		√	√				
	1998	G 1.6 DOHC	ENGINE	Engine Control-MAP		√	√	√				
			AT	Automatic Transaxle			√	√				
			AIRBAG	Airbag Control		√	√					
		G 1.5 DOHC	ENGINE	Engine Control-MAP		√	√	√				
			AT	Automatic Transaxle			√	√				
			AIRBAG	Airbag Control		√	√					
		G 1.5 SOHC	ENGINE	Engine Control-MAP		√	√	√				
			AT	Automatic Transaxle			√	√				
			AIRBAG	Airbag Control		√	√					
		G 1.6 SOHC	ENGINE	Engine Control-MAP		√	√	√				
			AT	Automatic Transaxle			√	√				
			AIRBAG	Airbag Control		√	√					
G 1.8 DOHC	AT	Automatic Transaxle			√	√						



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 1.8 DOHC	AIRBAG	Airbag Control		√	√			
			G 1.6 DOHC	ENGINE	Engine Control-MAP		√	√	√		
				AT	Automatic Transaxle			√	√		
				AIRBAG	Airbag Control		√	√			
			G 1.5 DOHC	ENGINE	Engine Control-MAP		√	√	√		
				AT	Automatic Transaxle			√	√		
				AIRBAG	Airbag Control		√	√			
			G 1.5 SOHC	ENGINE	Engine Control-MAP		√	√	√		
				AT	Automatic Transaxle			√	√		
				AIRBAG	Airbag Control		√	√			
			G 1.6 SOHC	ENGINE	Engine Control-MAP		√	√	√		
				AT	Automatic Transaxle			√	√		
				AIRBAG	Airbag Control		√	√			
			G 1.8 DOHC	AT	Automatic Transaxle			√	√		
				AIRBAG	Airbag Control		√	√			
			G 1.5 DOHC	ENGINE	Engine Control-MAP		√	√	√		
				AT	Automatic Transaxle			√	√		
				AIRBAG	Airbag Control		√	√			
			G 1.5 SOHC	ENGINE	Engine Control-MAP		√	√	√		
				AT	Automatic Transaxle			√	√		
				AIRBAG	Airbag Control		√	√			
			G 1.6 SOHC	ENGINE	Engine Control-MAP		√	√	√		
				AT	Automatic Transaxle			√	√		
				AIRBAG	Airbag Control		√	√			
				ENGINE	Engine Control-MAP		√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		1995	G 1.5 DOHC	AT	Automatic Transaxle			√	√		
				AIRBAG	Airbag Control		√	√			
			G 1.5 SOHC	ENGINE	Engine Control-MAP		√	√	√		
				AT	Automatic Transaxle			√	√		
			G 1.6 SOHC	ENGINE	Engine Control-MAP		√	√	√		
				AT	Automatic Transaxle			√	√		
		2004	G 1.8 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	
				AIRBAG	Airbag Control(TRW)		√	√			
				ENGINE	Unleaded(IMMO-)		√	√	√		
					Unleaded(IMMO+)		√	√	√		
	G 1.6 DOHC	Leaded All		√	√	√					
		AT	Automatic Transaxle		√	√	√				
		ABS	Anti-Lock Brake		√	√	√	√			
		AIRBAG	Airbag Control(TRW)		√	√					
		IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
		ENGINE	Engine Control		√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	SHUMA/SP ECTRA(SD)	2003	G 1.8 DOHC	AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	
				AIRBAG	Airbag Control		√	√			
			G 1.6 DOHC	ENGINE	Unleaded(IMMO-)		√	√	√		
					Unleaded(IMMO+)		√	√	√		
					Leaded All		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	
				AIRBAG	Airbag Control		√	√			
		IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
		2002	G 1.8 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	
				AIRBAG	Airbag Control		√	√			
			G 1.6 DOHC	ENGINE	Unleaded(IMMO-)		√	√	√		
					Unleaded(IMMO+)		√	√	√		
					Leaded All		√	√	√		
				AT	Automatic Transaxle		√	√	√		
ABS	Anti-Lock Brake				√	√	√	√			
AIRBAG	Airbag Control		√	√							



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 1.6 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
		2001	G 1.8 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	
				AIRBAG	Airbag Control		√	√			
			G 1.6 DOHC	ENGINE	Unleaded(IMMO-)		√	√	√		
					Unleaded(IMMO+)		√	√	√		
					Leaded All		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	
				AIRBAG	Airbag Control		√	√			
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			G 1.5 DOHC	AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	HCU(hydraulic control unit)exhaust mode



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set	
						Unleaded GEN		√	√	√	√	Special Features
						Leaded All		√	√	√	√	Special Features
					AT	Automatic Transaxle	√	√	√	√	√	
					ABSESP	ABS/ESP	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√	√		
					EPS	Electronic Power Steering	√	√	√	√		
					4WD	4WD Control	√	√	√			
					BCM	Body Control Module	√			√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					CODE	Transmitter Code Saving				√		
					ENGINE	Unleaded EOBD	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
							Unleaded GEN		√	√	√	√
						Leaded All		√	√	√	√	Special Features
					AT	Automatic Transaxle	√	√	√	√	√	
					ABSESP	ABS/ESP	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2009	G 3.3 DOHC	AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD Control	√	√	√			
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
			D 2.5 WGT	ENGINE	Engine Control		√	√			
				AT	Automatic Transaxle	√	√	√	√		
				ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD Control	√	√	√			
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.5 VGT	BHEATER	Fuel Fired Heater		√	√				
				CODE	Transmitter Code Saving					√		
				ENGINE	Engine Control			√	√			
				AT	Automatic Transaxle	√	√	√	√			
				ABSESP	ABS/ESP	√	√	√	√		√	
				AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control	√	√	√				
				BCM	Body Control Module	√			√		√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				BHEATER	Fuel Fired Heater			√	√			
				CODE	Transmitter Code Saving					√		
				ENGINE	Unleaded EOBD	√	√	√	√		√	PCM automatically detect reset PCM lock(MEC)is set
					Unleaded GEN			√	√	√	√	Special Features
			Leaded All				√	√	√	√	Special Features	
			AT		Automatic Transaxle	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 3.8 DOHC	ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD Control	√	√	√			
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
			G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					Unleaded GEN		√	√	√	√	Special Features
					Leaded All		√	√	√	√	Special Features
				AT	Automatic Transaxle	√	√	√	√	√	
				ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD Control	√	√	√			
			BCM	Body Control Module	√			√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2008		IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
			D 2.5 WGT	ENGINE	Engine Control		√	√			
				AT	Automatic Transaxle	√	√	√	√		
				ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD Control	√	√	√			
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				BHEATER	Fuel Fired Heater		√	√			
				CODE	Transmitter Code Saving				√		
			ENGINE	Engine Control			√	√			
			AT	Automatic Transaxle	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.5 VGT	ABSESP	ABS/ESP	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control	√	√	√				
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				BHEATER	Fuel Fired Heater		√	√				
			CODE	Transmitter Code Saving					√			
			G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set	
					Unleaded GEN		√	√	√	√	√	Special Features
					Leaded All		√	√	√	√	√	Special Features
				AT	Automatic Transaxle	√	√	√	√	√		
				ABSESP	ABS/ESP	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control	√	√	√				
			BCM	Body Control Module	√			√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				CODE	Transmitter Code Saving				√			
			G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set	
					Unleaded GEN		√	√	√	√	√	Special Features
					Leaded All		√	√	√	√	√	Special Features
				AT	Automatic Transaxle	√	√	√	√	√		
				ABSESP	ABS/ESP	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control	√	√	√				
				BCM	Body Control Module	√			√	√		
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√			

2007



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
SORENTO(BL)			D 2.5 WGT	ENGINE	Engine Control		√	√				
				AT	Automatic Transaxle	√	√	√	√			
				ABSESP	ABS/ESP	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control	√	√	√				
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				BHEATER	Fuel Fired Heater		√	√				
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control		√	√				
				AT	Automatic Transaxle	√	√	√	√			
				ABSESP	ABS/ESP	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control	√	√	√				
BCM	Body Control Module	√			√	√						



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.5 VGT	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				BHEATER	Fuel Fired Heater		√	√				
				CODE	Transmitter Code Saving					√		
			G 2.4 DOHC	ENGINE	Unleaded All		√	√	√	√		
				ENGINE	Leaded All		√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√			
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD(TOD-AUTO)		√	√				
				4WD	4WD(EST-MANUAL)	√	√	√				
				IMMO	Immobilizer					√		Password learning/modify Key match Neutral mode Limp mode
				ENGINE	Engine Control		√	√	√	√		
			AT	Automatic Transaxle	√	√	√	√				
			ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode		
			AIRBAG	Airbag Control	√	√	√	√				



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2006	G 3.5 DOHC	EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD(TOD-AUTO)		√	√				
					4WD(EST-MANUAL)	√	√	√				
				IMMO	Immobilizer					√		Password learning/modify Key match Neutral mode Limp mode
			D 2.5 WGT	ENGINE	Engine Control		√	√				
				AT	Automatic Transaxle	√	√	√	√			
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD(TOD-AUTO)		√	√				
					4WD(EST-MANUAL)	√	√	√				
				BHEATER	Fuel Fired Heater		√	√	√	√		
				ENGINE	Engine Control		√	√				
				AT	Automatic Transaxle	√	√	√	√			
				ABSESP	ABS/ESP	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control	√	√	√				
				BCM	Body Control Module	√			√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.5 VGT	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				BHEATER	Fuel Fired Heater		√	√				
				CODE	Transmitter Code Saving					√		
			G 2.4 DOHC	ENGINE	Unleaded All		√	√	√	√		
				ENGINE	Leaded All		√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√			
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD(TOD-AUTO)		√	√				
					4WD	4WD(EST-MANUAL)	√	√	√			
				IMMO	Immobilizer					√		Password learning/modify Key match Neutral mode Limp mode
				ENGINE	Engine Control		√	√	√	√		
			AT	Automatic Transaxle	√	√	√	√				
			ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode		
			AIRBAG	Airbag Control	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2005	G 3.5 DOHC	EPS	Electronic Power Steering	√	√	√	√				
				4WD	4WD(TOD-AUTO)		√	√					
					4WD(EST-MANUAL)	√	√	√					
				IMMO	Immobilizer						√		Password learning/modify Key match Neutral mode Limp mode
			D 2.5 WGT	ENGINE	Engine Control		√	√					
				AT	Automatic Transaxle	√	√	√	√				
				ABS	Anti-Lock Brake	√	√	√	√	√			Deflated mode
				AIRBAG	Airbag Control	√	√	√	√				
				EPS	Electronic Power Steering	√	√	√	√				
				4WD	4WD(TOD-AUTO)		√	√					
					4WD(EST-MANUAL)	√	√	√					
			BHEATER	Fuel Fired Heater		√	√	√	√				
			G 2.4 DOHC	ENGINE	Unleaded All		√	√	√	√			
					Leaded All		√	√	√	√			
		AT		4-Speed		√	√	√	√	√			
				5-Speed	√	√	√	√					
		ABS		Anti-Lock Brake	√	√	√	√	√			Deflated mode	
		AIRBAG		Airbag Control	√	√	√	√					
		EPS		Electronic Power Steering	√	√	√	√					
		4WD		4WD(TOD-AUTO)		√	√						
			4WD(EST-MANUAL)	√	√	√							



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				IMMO	Immobilizer				√		Password learning/modify Key match Neutral mode Limp mode	
		2004	G 3.5 DOHC	ENGINE	Engine Control		√	√	√	√		
				AT	4-Speed			√	√	√	√	
					5-Speed	√	√	√	√			
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD(TOD-AUTO)				√	√		
					4WD(EST-MANUAL)	√	√	√				
				IMMO	Immobilizer						√	Password learning/modify Key match Neutral mode Limp mode
				ENGINE	Engine(WGT F/L)				√	√		
					Engine(WGT)				√	√	√	√
				AT	4-Speed				√	√	√	√
					5-Speed	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode
		AIRBAG	Airbag Control	√	√	√	√					
		EPS	Electronic Power Steering	√	√	√	√					
		4WD	4WD(TOD-AUTO)				√	√				
			4WD(EST-MANUAL)	√	√	√						
			D 2.5 WGT									



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				BHEATER	Fuel Fired Heater		√	√	√	√		
		2003	G 2.4 DOHC	ENGINE	Unleaded All		√	√	√	√		
				ENGINE	Leaded All		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√	√	√	
				4WD	4WD(TOD-AUTO)		√	√	√	√	√	
				4WD	4WD(EST-MANUAL)	√	√	√	√	√	√	
				IMMO	Immobilizer						√	Password learning/modify Key match Neutral mode Limp mode
				ENGINE	Engine Control		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√	√	√	
		4WD	4WD(TOD-AUTO)		√	√	√	√	√			
		4WD	4WD(EST-MANUAL)	√	√	√	√	√	√			
		IMMO	Immobilizer						√	Password learning/modify Key match Neutral mode Limp mode		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2002	D 2.5 WGT	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
				ABSESP	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD(TOD-AUTO)		√	√			
					4WD(EST-MANUAL)	√	√	√			
			BHEATER	Fuel Fired Heater		√	√	√	√		
			G 3.5 DOHC	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD(TOD-AUTO)		√	√			
		4WD(EST-MANUAL)			√	√	√				
		IMMO	Immobilizer					√	Password learning/modify Key match Neutral mode Limp mode		
		D 2.5 WGT	ENGINE	Engine Control		√	√	√	√		
			AT	Automatic Transaxle		√	√	√	√		
			ABSESP	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
			AIRBAG	Airbag Control	√	√	√	√			
			EPS	Electronic Power Steering	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				4WD	4WD(TOD-AUTO)		√	√				
				4WD	4WD(EST-MANUAL)	√	√	√				
				BHEATER	Fuel Fired Heater		√	√	√	√		
			G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√		
					Unleaded GEN	√	√	√	√	√	√	
					Leaded All	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√			
					Airbag(Event #2)	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control		√	√	√			
				BCM	Instrument Panel Module	√	√	√	√	√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	√	
			Power Distribution Module		√	√	√	√	√	√		
			AHLS	Auto Headlamp Leveling	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
			G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√		
						Unleaded GEN	√	√	√	√	√	
						Leaded All	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	
					ESP	Electronic Stability Program	√	√	√	√	√	
					AIRBAG	Airbag(Event #1)	√	√	√	√		
						Airbag(Event #2)	√	√	√	√		
					AIRCON	Air Conditioner	√	√	√	√	√	
					EPS	Electronic Power Steering	√	√	√	√		
					4WD	4WD Control		√	√	√		
					BCM	Instrument Panel Module	√	√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PIC	All Systems	√	√	√	√	√	
						Smart Key Unit	√	√	√	√	√	
						Power Distribution Module	√	√	√	√	√	
				AHLS	Auto Headlamp Leveling	√	√	√	√			
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
		2012										



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 2.2 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	
				ENGINE	Engine Control(CPF+)	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		
				AIRBAG	Airbag(Event #2)	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD Control		√	√	√		
				BCM	Instrument Panel Module	√	√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	
				PIC	Smart Key Unit	√	√	√	√	√	
				PIC	Power Distribution Module	√	√	√	√	√	
				AHLS	AHLS	√	√	√	√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control(CPF-)	√	√	√	√	√	
			ENGINE	Engine Control(CPF+)	√	√	√	√	√		
			AT	Automatic Transaxle	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.0 TCI-R	ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag(Event #1)		√	√	√	√		
					Airbag(Event #2)		√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Power Steering	√	√	√	√			
				4WD	4WD Control		√	√	√			
				BCM	Instrument Panel Module	√	√	√	√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
				AHLS	Auto Headlamp Leveling	√	√	√	√			
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
			ENGINE	Unleaded EOBD	√	√	√	√	√			
				Unleaded GEN	√	√	√	√	√			
				Leaded All	√	√	√	√	√			
			AT	Automatic Transaxle	√	√	√	√	√			
			ESP	Electronic Stability Program	√	√	√	√	√			
			AIRBAG	Airbag(Event #1)	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 3.5 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control		√	√	√			
				BCM	Instrument Panel Module	√	√	√	√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
				AHLS	Auto Headlamp Leveling	√	√	√	√			
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
				ENGINE	Unleaded EOBD	√	√	√	√	√		
					Unleaded GEN	√	√	√	√	√		
					Leaded All	√	√	√	√	√		
			AT	Automatic Transaxle	√	√	√	√	√			
			ESP	Electronic Stability Program	√	√	√	√	√			
			AIRBAG	Airbag(Event #1)	√	√	√	√				
				Airbag(Event #2)	√	√	√	√				
			AIRCON	Air Conditioner	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2011	G 2.4 DOHC	EPS	Electronic Power Steering	√	√	√	√				
				4WD	4WD Control				√	√	√		
				BCM	Instrument Panel Module	√		√	√	√	√	√	
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√		√	√	√	√	√	
					Smart Key Unit	√		√	√	√	√	√	
					Power Distribution Module	√		√	√	√	√	√	
				AHLS	Auto Headlamp Leveling	√		√	√	√	√		
				TPMS	Tire Pressure Monitoring	√		√	√	√	√	√	
				CODE	Transmitter Code Saving						√		
			ENGINE	Engine Control(CPF-)	√		√	√	√	√	√		
				Engine Control(CPF+)	√		√	√	√	√	√		
				AT	Automatic Transaxle	√		√	√	√	√	√	
				ESP	Electronic Stability Program	√		√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√		√	√	√	√		
					Airbag(Event #2)	√		√	√	√	√		
				AIRCON	Air Conditioner	√		√	√	√	√	√	
				EPS	Electronic Power Steering	√		√	√	√	√		
		4WD	4WD Control				√	√	√				
		BCM	Instrument Panel Module	√		√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	SORENTO(XM)		D 2.2 TCI-R	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
				AHLS	AHLS	√	√	√	√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control(CPF-)	√	√	√	√	√	
					Engine Control(CPF+)	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
			ESP	Electronic Stability Program	√	√	√	√	√		
			AIRBAG	Airbag(Event #1)	√	√	√	√			
				Airbag(Event #2)	√	√	√	√			
			AIRCON	Air Conditioner	√	√	√	√	√		
			EPS	Power Steering	√	√	√	√			
			4WD	4WD Control		√	√	√			
			BCM	Instrument Panel Module	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			D 2.0 TCI-R	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
				PIC		All Systems	√	√	√	√	√		
						Smart Key Unit	√	√	√	√	√		
						Power Distribution Module	√	√	√	√	√		
					AHLS	Auto Headlamp Leveling	√	√	√	√			
					TPMS	Tire Pressure Monitoring	√	√	√	√	√		
					CODE	Transmitter Code Saving				√			
					ENGINE	Unleaded EOBD	√	√	√	√	√		
							Unleaded GEN	√	√	√	√	√	
							Leaded All	√	√	√	√	√	
						AT	Automatic Transaxle	√	√	√	√	√	
						ESP	Electronic Stability Program	√	√	√	√	√	
						AIRBAG	Airbag(Event #1)	√	√	√	√		
							Airbag(Event #2)	√	√	√	√		
					AIRCON	Air Conditioner	√	√	√	√	√		
					EPS	Electronic Power Steering	√	√	√	√			
					4WD	4WD Control		√	√	√			
				BCM	Instrument Panel Module	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 2.4 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
				PIC		All Systems	√	√	√	√	√		
						Smart Key Unit	√	√	√	√	√		
						Power Distribution Module	√	√	√	√	√		
					AHLS	Auto Headlamp Leveling	√	√	√	√			
					TPMS	Tire Pressure Monitoring	√	√	√	√	√		
					CODE	Transmitter Code Saving				√			
				ENGINE		Unleaded EOBD	√	√	√	√	√		
						Unleaded GEN	√	√	√	√	√		
						Leaded All	√	√	√	√	√		
						AT	Automatic Transaxle	√	√	√	√	√	
						ESP	Electronic Stability Program	√	√	√	√	√	
						AIRBAG	Airbag(Event #1)	√	√	√	√		
							Airbag(Event #2)	√	√	√	√		
						AIRCON	Air Conditioner	√	√	√	√	√	
					EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control		√	√	√				
				BCM	Instrument Panel Module	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2010	G 3.5 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
				AHLS	Auto Headlamp Leveling	√	√	√	√			
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control(CPF-)	√	√	√	√	√		
					Engine Control(CPF+)	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag(Event #1)	√	√	√	√			
					Airbag(Event #2)	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control			√	√	√		
				BCM	Instrument Panel Module	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.2 TCI-R	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems		√	√	√	√	√	
					Smart Key Unit		√	√	√	√	√	
					Power Distribution Module		√	√	√	√	√	
				AHLS	AHLS		√	√	√	√		
				TPMS	Tire Pressure Monitoring		√	√	√	√	√	
				CODE	Transmitter Code Saving					√		
				ENGINE	Low Power(CPF+)		√	√	√	√	√	
					Low Power(CPF-)		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	√	
				ESP	Electronic Stability Program		√	√	√	√	√	
				AIRBAG	Airbag(Event #1)		√	√	√	√		
					Airbag(Event #2)		√	√	√	√		
				AIRCON	Air Conditioner		√	√	√	√	√	
			EPS	Power Steering		√	√	√	√			
			4WD	4WD Control			√	√	√			
			BCM	Instrument Panel Module		√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			D 2.0 TCI-R	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
				PIC	All Systems	√	√	√	√	√			
					Smart Key Unit	√	√	√	√	√			
					Power Distribution Module	√	√	√	√	√			
				AHLS	Auto Headlamp Leveling	√	√	√	√				
				TPMS	Tire Pressure Monitoring	√	√	√	√	√			
				CODE	Transmitter Code Saving				√				
				ENGINE	Unleaded EOBD	√	√	√	√	√			
					Unleaded GEN	√	√	√	√	√			
					Leaded All	√	√	√	√	√			
					AT	Automatic Transaxle	√	√	√	√	√		
					ESP	Electronic Stability Program		√	√	√	√		
					AIRBAG	Airbag(Event #1)	√	√	√	√			
						Airbag(Event #2)	√	√	√	√			
			AIRCON		Air Conditioner	√	√	√	√	√			
			EPS		Electronic Power Steering	√	√	√	√				
			4WD		4WD Control		√	√	√				
			BCM	Instrument Panel Module	√	√	√	√	√				



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2009	G 2.4 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
				AHLS	Auto Headlamp Leveling	√	√	√	√			
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control(CPF-)	√	√	√	√	√		
					Engine Control(CPF+)	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program		√	√	√	√		
				AIRBAG	Airbag(Event #1)	√	√	√	√			
					Airbag(Event #2)	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control		√	√	√			
				BCM	Instrument Panel Module	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			D 2.2 TCI-R	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
				PIC	All Systems	√	√	√	√	√			
					Smart Key Unit	√	√	√	√	√			
					Power Distribution Module	√	√	√	√	√			
				AHLS	AHLS	√	√	√	√				
				TPMS	Tire Pressure Monitoring	√	√	√	√	√			
				CODE	Transmitter Code Saving				√				
					ENGINE	Unleaded EOBD	√	√	√	√	√		
						Unleaded GEN	√	√	√	√	√		
						Leaded All	√	√	√	√	√		
			AT		Automatic Transaxle	√	√	√	√	√			
			ESP		Electronic Stability Program	√	√	√	√	√			
			AIRBAG		Airbag(Event #1)	√	√	√	√			Real-time information	
					Airbag(Event #2)	√	√	√	√			Real-time information	
			EPS		Motor Driven Power Steering Control	√	√	√	√				
			BCM		Module(EUPD)	√			√	√			
					Body Control Module(GEN)	√			√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 2.0 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
				PIC		All Systems	√	√	√	√	√		
						Smart Key Unit	√	√	√	√	√		
						Power Distribution Module	√	√	√	√	√		
						Smart Key Code Saving				√			
					TPMS	Tire Pressure Monitoring	√	√	√	√	√		
					CODE	Transmitter Code Saving				√			
				ENGINE		Unleaded EOBD	√	√	√	√	√	self-learning clear	
						Unleaded GEN	√	√	√	√	√	self-learning clear	
						Leaded All	√	√	√	√	√	self-learning clear	
						AT	Automatic Transaxle	√	√	√	√	√	
						ESP	Electronic Stability Program	√	√	√	√	√	
						AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
							Airbag(Event #2)	√	√	√	√		Real-time information
						EPS	Motor Driven Power Steering Control	√	√	√	√		
					BCM	Module(EUPO)	√			√	√		
						Body Control Module(GEN)	√			√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2012	G 1.6 GDI	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
					Smart Key Code Saving					√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving					√		
				ENGINE	Engine Control	√	√	√	√	√		self-learning clear
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag(Event #1)	√	√	√	√			Real-time information
					Airbag(Event #2)	√	√	√	√			Real-time information
				EPS	Power Steering	√	√	√	√			
				BCM	Body Control Module(FUPO)	√				√	√	
					Body Control Module(GEN)	√				√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			F 1.6 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
					Smart Key Code Saving				√			
				TPMS	Tire Pressure Monitoring System	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
			AIRBAG	Airbag(Event #1)	√	√	√	√			Real-time information	
				Airbag(Event #2)	√	√	√	√			Real-time information	
			EPS	Motor Driven Power Steering Control	√	√	√	√				
			BCM	Body Control Module(FJBC)	√			√	√			
				Body Control Module(GEN)	√			√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 1.6 TCI-U2	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
					Smart Key Code Saving				√			
				TPMS	Tire Pressure Monitoring System	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
				ENGINE	Unleaded EOBD	√	√	√	√	√		Special Features
					Unleaded GEN	√	√	√	√	√		Special Features
					Leaded All	√	√	√	√	√		Special Features
			AT	Automatic Transaxle	√	√	√	√	√		Reset automatically drive shaft value	
			ESP	Electronic Stability Program	√	√	√	√	√			
			AIRBAG	Airbag(Event #1)	√	√	√	√			Real-time information	
				Airbag(Event #2)	√	√	√	√			Real-time information	
			EPS	MDPS	√	√	√	√				
			BCM	Body Control Module	√			√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.0 DOHC	IMMO	IMMO(Bosch)						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems		√	√	√	√	√	
					Smart Key Unit		√	√	√	√	√	
					Power Distribution Module		√	√	√	√	√	
					Smart Key Code Saving					√		
				TPMS	LEAR		√	√	√	√	√	
				CODE	Transmitter Code Saving					√		
				ENGINE	Unleaded EOBD		√	√	√	√	√	Special Features
					Unleaded GEN		√	√	√	√	√	Special Features
					Leaded All		√	√	√	√	√	Special Features
				AT	Automatic Transaxle		√	√	√	√	√	Reset automatically drive shaft value
				ESP	Electronic Stability Program		√	√	√	√	√	
				AIRBAG	Airbag(Event #1)		√	√	√	√		Real-time information
					Airbag(Event #2)		√	√	√	√		Real-time information
			EPS	MDPS		√	√	√	√			
			BCM	Body Control Module		√			√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2011	G 1.6 DOHC	IMMO	IMMO(Bosch)						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems		√	√	√	√	√	
					Smart Key Unit		√	√	√	√	√	
					Power Distribution Module		√	√	√	√	√	
					Smart Key Code Saving					√		
				TPMS	LEAR		√	√	√	√	√	
				CODE	Transmitter Code Saving					√		
				ENGINE	Engine Control		√			√	√	Reading trouble code Clear fault code self-learning clear
				AT	Automatic Transaxle		√	√	√	√	√	Reset automatically drive shaft value
				ESP	Electronic Stability Program		√	√	√	√	√	
				AIRBAG	Airbag(Event #1)		√	√	√	√		Real-time information
					Airbag(Event #2)		√	√	√	√		Real-time information
				EPS	Power Steering		√	√	√	√		
				BCM	Body Control Module		√			√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	SOUL(AIM)		F 1.6 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				TPMS	Tire Pressure Monitoring System	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine(CPF+)	√	√	√	√	√	
					Engine(CPF-)	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
					Airbag(Event #2)	√	√	√	√		Real-time information
				EPS	MDPS	√	√	√	√		
				BCM	Body Control Module	√			√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 1.6 TCI-U2	IMMO	IMMO(Bosch)						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems		√	√	√	√	√	
					Smart Key Unit		√	√	√	√	√	
					Power Distribution Module		√	√	√	√	√	
					Smart Key Code Saving					√		
				TPMS	LEAR		√	√	√	√	√	
			CODE	Transmitter Code Saving					√			
			G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Special Features	
					Unleaded GEN	√	√	√	√	√	√	Special Features
					Leaded All	√	√	√	√	√	√	Special Features
				AT	Automatic Transaxle		√	√	√	√	√	Reset automatically drive shaft value
				ESP	Electronic Stability Program		√	√	√	√	√	
				AIRBAG	Airbag(Event #1)		√	√	√	√		Real-time information
					Airbag(Event #2)		√	√	√	√		Real-time information
				EPS	MDPS		√	√	√	√		
			BCM	Body Control Module		√			√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	IMMO(Bosch)						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	LEAR	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Unleaded EOBD	√	√	√	√	√	Special Features
			Unleaded GEN		√	√	√	√	√	√	Special Features
			Leaded All		√	√	√	√	√	√	Special Features
				AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
					Airbag(Event #2)	√	√	√	√		Real-time information
				EPS	MDPS	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	IMMO(Bosch)						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	LEAR	√	√	√	√	√	

2010 G 1.6 DOHC



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				CODE	Transmitter Code Saving				√		
			D 1.6 TCI-U2	ENGINE	Engine(CPF+)	√	√	√	√	√	
					Engine(CPF-)	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
					Airbag(Event #2)	√	√	√	√		Real-time information
				EPS	MDPS	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	IMMO(Bosch)						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	LEAR	√	√	√	√	√	
			CODE	Transmitter Code Saving				√			
					Unleaded EOBD	√	√	√	√	√	Special Features
			ENGINE		Unleaded GEN	√	√	√	√	√	Special Features
					Leaded All	√	√	√	√	√	Special Features
				AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value
			ESP	Electronic Stability Program	√	√	√	√	√		
			AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 1.6 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√		Real-time information	
				EPS	MDPS	√	√	√	√			
				BCM	Body Control Module	√			√	√		
				IMMO	IMMO(Bosch)						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				TPMS	LEAR	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
		2009	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Special Features	
						Unleaded GEN	√	√	√	√	√	Special Features
						Leaded All	√	√	√	√	√	Special Features
					AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value
					ESP	Electronic Stability Program	√	√	√	√	√	
					AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
						Airbag(Event #2)	√	√	√	√		Real-time information
					EPS	MDPS	√	√	√	√		
			BCM	Body Control Module	√			√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				IMMO	IMMO(Bosch)						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				TPMS	LEAR	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
			D 1.6 TCI-U2	ENGINE	Engine(CPF+)	√	√	√	√	√		
				ENGINE	Engine(CPF-)	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value	
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information	
				AIRBAG	Airbag(Event #2)	√	√	√	√		Real-time information	
				EPS	MDPS	√	√	√	√			
				BCM	Body Control Module	√			√	√		
					IMMO	IMMO(Bosch)						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					TPMS	LEAR	√	√	√	√	√	
				CODE	Transmitter Code Saving				√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2004	G 2.0 DOHC	ENGINE	Unleaded		√	√	√				
					Leaded		√	√	√	√			
				AT	Automatic Transaxle	√	√	√	√	√			
			ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode		
			D 2.0 RF-TCI	ENGINE	Engine Control		√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	√		
		ABS		Anti-Lock Brake	√	√	√	√	√	√	Deflated mode		
		2003	G 2.0 DOHC	ENGINE	Unleaded		√	√	√	√			
					Leaded		√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	√		
			D 2.0 RF-TCI	ENGINE	Engine Control		√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	√	Deflated mode	
		2002	G 2.0 DOHC	ENGINE	Unleaded		√	√	√	√			
					Leaded		√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	√		
			D 2.0 RE(RF-TCI)	ENGINE	Engine Control		√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	√		
ABS	Anti-Lock Brake			√	√	√	√	√	√	Deflated mode			
D 2.0 RT(RF-TCI)	ENGINE		Engine Control		√	√	√	√	√				
	AT		Automatic Transaxle	√	√	√	√	√	√				
	ABS		Anti-Lock Brake	√	√	√	√	√	√	Deflated mode			
			ENGINE	Unleaded		√	√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2001	G 2.0 DOHC	ENGINE	Leaded		√	√	√	√	
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	Deflated mode
			D 2.0 RE(RF-TCI)	AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	Deflated mode
			D 2.0 RT(RF-TCI)	AT	Automatic Transaxle		√	√	√		
		ABS		Anti-Lock Brake		√	√	√	√	Deflated mode	
		2000	G 2.0 DOHC	ENGINE	Engine Control(AUS)		√	√	√		
					Unleaded		√	√	√		
					Leaded		√	√	√	√	
				AT	Automatic Transaxle		√	√	√		
					Automatic Transaxle(AUS)		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	
			Anti-Lock Brake(AUS)			√	√	√	√		
			AIRBAG	Airbag Control		√	√				
				Airbag(AUS)		√	√				
			D 2.0 RE(RF-TCI)	AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	
				AIRBAG	Airbag Control		√	√			
			D 2.0 RT(RF-TCI)	AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	
				AIRBAG	Airbag Control		√	√			
		G 2.0 DOHC	ENGINE	Unleaded		√	√	√			
				Leaded		√	√	√	√		
			AT	Automatic Transaxle		√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
SPORTAGE (AL)		1999		ABS	Anti-Lock Brake		√	√	√	√		
				AIRBAG	Airbag Control		√	√				
				AT	Automatic Transaxle		√	√	√			
			D 2.0 RE(RF-TCI)	ABS	Anti-Lock Brake		√	√	√	√		
				AIRBAG	Airbag Control		√	√				
				AT	Automatic Transaxle		√	√	√			
			D 2.0 RT(RF-TCI)	ABS	Anti-Lock Brake		√	√	√	√	√	
				AIRBAG	Airbag Control		√	√				
				AT	Automatic Transaxle		√	√	√			
			G 2.0 DOHC	ENGINE	Leaded		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√	√	
		AIRBAG		Airbag Control		√	√	√	√	√		
		AT		Automatic Transaxle		√	√	√				
		ABS		Anti-Lock Brake		√	√	√	√	√		
		G 2.0 SOHC	AIRBAG	Airbag Control		√	√	√	√	√		
			AT	Automatic Transaxle		√	√	√				
			ABS	Anti-Lock Brake		√	√	√	√	√		
		1998	D 2.0 RE(RF-TCI)	AIRBAG	Airbag Control		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√	√	
			D 2.0 RT(RF-TCI)	AIRBAG	Airbag Control		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake		√	√	√	√	√	
HW	AIRBAG	Airbag Control		√	√	√	√	√				
	AT	Automatic Transaxle		√	√	√						
	ABS	Anti-Lock Brake		√	√	√	√	√				
			ENGINE	Engine Control		√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		1997	G 2.0 DOHC	AT	Automatic Transaxle		√	√	√		
				AIRBAG	Airbag Control		√	√			
			G 2.0 SOHC	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle		√	√	√		
			D 2.0 RE(RF-TCI)	AIRBAG	Airbag Control		√	√			
				ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle		√	√	√		
			D 2.0 RT(RF-TCI)	AIRBAG	Airbag Control		√	√			
				ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle		√	√	√		
			HW	AIRBAG	Airbag Control		√	√			
				ENGINE	Engine Control		√	√	√	√	
		AT		Automatic Transaxle		√	√	√			
		1996	G 2.0 DOHC	AIRBAG	Airbag Control		√	√			
				ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle		√	√	√		
			G 2.0 SOHC	AIRBAG	Airbag Control		√	√			
				ENGINE	Engine Control		√	√	√	√	
			D 2.0 RT(RF-TCI)	AT	Automatic Transaxle		√	√	√		
				AIRBAG	Airbag Control		√	√			
				ENGINE	Engine Control		√	√	√	√	
			HW	AT	Automatic Transaxle		√	√	√		
				ENGINE	Engine Control		√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				AIRBAG	Airbag Control		√	√				
		1995	G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√			
				AIRBAG	Airbag Control		√	√				
			G 2.0 SOHC	ENGINE	Engine Control		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√			
				AIRBAG	Airbag Control		√	√				
			D 2.0 RT(RF-TCI)	ENGINE	Engine Control		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√			
				AIRBAG	Airbag Control		√	√				
			HW	ENGINE	Engine Control		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√			
				AIRBAG	Airbag Control		√	√				
		1994	G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√			
				AIRBAG	Airbag Control		√	√				
			G 2.0 SOHC	ENGINE	Engine Control		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√			
				AIRBAG	Airbag Control		√	√				
			HW	ENGINE	Engine Control		√	√	√	√	√	
				AT	Automatic Transaxle		√	√	√			
				AIRBAG	Airbag Control		√	√				
		1993	G 2.0 SOHC	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√			
				AIRBAG	Airbag Control		√	√				



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2010	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
					Unleaded GEN	√	√	√	√	√	Adaptive value reset	
					Leaded All	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				4WD	4WD Control	√	√	√				
				ETACS	ETACS	√			√	√		
			G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				4WD	4WD Control	√	√	√				
			ETACS	ETACS	√			√	√			
			D 2.0 WGT	ENGINE	Engine Control		√	√				
				AT	Automatic Transaxle		√	√				
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				4WD	4WD Control	√	√	√				
				ETACS	ETACS	√			√	√		
			D 2.0 VGT	ENGINE	Engine Control		√	√				
				AT	Automatic Transaxle		√	√				
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				4WD	4WD Control	√	√	√				
				ETACS	ETACS	√			√	√		
					Unleaded EOBD	√	√	√	√	√	Adaptive value reset	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2009	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√		
				ABSESP	ABS/ESP(MGH-25)	√	√	√	√		Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information
				4WD	4WD Control	√	√	√			
				ETACS	ETACS	√			√	√	
			G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information
				4WD	4WD Control	√	√	√			
			D 2.0 WGT	ETACS	ETACS	√			√	√	
				ENGINE	Engine Control		√	√			
				AT	Automatic Transaxle		√	√			
				AIRBAG	Airbag Control	√	√	√			Collision Information
				4WD	4WD Control	√	√	√			
			D 2.0 VGT	ETACS	ETACS	√			√	√	
				ENGINE	Engine Control		√	√			
				AT	Automatic Transaxle		√	√			
AIRBAG	Airbag Control	√		√	√			Collision Information			
4WD	4WD Control	√		√	√						
				Unleaded EOBD	√	√	√	√	√	Adaptive value reset	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2008	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√		
				ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information
				4WD	4WD Control	√	√	√			
				ETACS	ETACS	√			√	√	
			G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
					Unleaded GEN	√	√	√	√	√	Adaptive value reset
					Leaded All	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	
				ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information
				4WD	4WD Control	√	√	√			
			D 2.0 WGT	ETACS	ETACS	√			√	√	
				ENGINE	Engine Control		√	√			
				AT	Automatic Transaxle		√	√			
				ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information
				4WD	4WD Control	√	√	√			
			D 2.0 VGT	ETACS	ETACS	√			√	√	
				ENGINE	Engine Control		√	√			
				AT	Automatic Transaxle		√	√			
				ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	Deflated mode
	AIRBAG	Airbag Control	√	√	√			Collision Information			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function								
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions			
	SPORTAGE (KM)			4WD	4WD Control	√	√	√						
				ETACS	ETACS	√			√	√				
			2007	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset		
								Unleaded GEN	√	√	√	√	√	Adaptive value reset
								Leaded All	√	√	√	√	√	Adaptive value reset
							AT	Automatic Transaxle	√	√	√	√	√	
							ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
							AIRBAG	Airbag Control	√	√	√			Collision Information
							4WD	4WD Control	√	√	√			
							ETACS	ETACS	√			√	√	
					G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
								Unleaded GEN	√	√	√	√	√	Adaptive value reset
								Leaded All	√	√	√	√	√	Adaptive value reset
							AT	Automatic Transaxle	√	√	√	√	√	
							ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
							AIRBAG	Airbag Control	√	√	√			Collision Information
				D 2.0 WGT	ENGINE	4WD	4WD Control	√	√	√				
							ETACS	ETACS	√			√	√	
						ENGINE	Engine Control		√	√				
						AT	Automatic Transaxle		√	√				
					ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode		
					AIRBAG	Airbag Control	√	√	√			Collision Information		
					4WD	4WD Control	√	√	√					



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.0 VGT	AT	Automatic Transaxle		√	√				
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				4WD	4WD Control	√	√	√				
				ETACS	ETACS	√			√	√		
		2006	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
						Unleaded GEN	√	√	√	√	√	Adaptive value reset
						Leaded All	√	√	√	√	√	Adaptive value reset
					AT	Automatic Transaxle	√	√	√	√	√	
					ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
					AIRBAG	Airbag Control	√	√	√			Collision Information
					4WD	4WD Control		√	√			
				ETACS	ETACS	√			√	√		
				G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset
						Unleaded GEN	√	√	√	√	√	Adaptive value reset
						Leaded All	√	√	√	√	√	Adaptive value reset
					AT	Automatic Transaxle	√	√	√	√	√	
					ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode
			AIRBAG		Airbag Control	√	√	√			Collision Information	
			4WD	4WD Control		√	√					
			ETACS	ETACS	√			√	√			
			D 2.0 WGT	ENGINE	Engine Control		√	√				
				AT	Automatic Transaxle		√	√				
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√			Collision Information	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
				4WD	4WD Control		√	√					
				ETACS	ETACS	√			√	√			
			D 2.0 VGT	ENGINE	Engine Control		√	√					
				AT	Automatic Transaxle		√	√					
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode		
				AIRBAG	Airbag Control	√	√	√			Collision Information		
				4WD	4WD Control	√	√	√					
				ETACS	ETACS	√			√	√			
				G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset	
			Unleaded GEN			√	√	√	√	√	√	Adaptive value reset	
			Leaded All			√	√	√	√	√	√	Adaptive value reset	
			AT		Automatic Transaxle	√	√	√	√	√			
			ABS		Anti-Lock Brake	√	√	√	√	√	Deflated mode		
			AIRBAG		Airbag Control	√	√	√			Collision Information		
			4WD		4WD Control		√	√					
			ETACS	ETACS	√			√	√				
		2005	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	Adaptive value reset		
						Unleaded GEN	√	√	√	√	√	√	Adaptive value reset
						Leaded All	√	√	√	√	√	√	Adaptive value reset
					AT	Automatic Transaxle	√	√	√	√	√		
					ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
					AIRBAG	Airbag Control	√	√	√			Collision Information	
				4WD	4WD Control		√	√					
				ETACS	ETACS	√			√	√			
				ENGINE	Engine Control	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			D 2.0 WGT	AT	Automatic Transaxle	√	√	√	√	√		
				ABS	Anti-Lock Brake	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				4WD	4WD Control		√	√				
				ETACS	ETACS	√			√	√		
			G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√		
					Unleaded GEN	√	√	√	√	√	√	
					Leaded All	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag(Event #1)	√	√	√	√			
					Airbag(Event #2)	√	√	√	√			
				EPS	Power Steering	√	√	√	√			
				4WD	4WD Control	√	√	√	√	√		
				BCM	All Systems	√	√	√	√	√		
					Body Control Module	√	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	Smart Key Unit	√	√	√	√	√		
				AHLS	Auto Headlamp Leveling	√			√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				SPAS	Smart Parking Assist System	√	√	√	√	√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
			G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√		
						Unleaded GEN	√	√	√	√	√	
						Leaded All	√	√	√	√		
					AT	Automatic Transaxle	√	√	√	√	√	
					ESP	Electronic Stability Program	√	√	√	√	√	
					AIRBAG	Airbag(Event #1)	√	√	√	√		
						Airbag(Event #2)	√	√	√	√		
					EPS	Power Steering	√	√	√	√		
					4WD	4WD Control	√	√	√	√	√	
					BCM	All Systems	√	√	√	√	√	
						Body Control Module	√	√	√	√	√	
						Smart Junction Box	√	√	√	√	√	
					IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					PIC	Smart Key Unit	√	√	√	√	√	
					AHLS	Auto Headlamp Leveling	√			√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				SPAS	Smart Parking Assist System	√	√	√	√	√	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	self-learning clear
				AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		
					Airbag(Event #2)	√	√	√	√		
				EPS	Power Steering	√	√	√	√		
				4WD	4WD Control	√	√	√	√	√	
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√	
				AHLS	Auto Headlamp Leveling	√			√		
				SPAS	Smart Parking Assist System	√	√	√	√	√	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				CODE	Transmitter Code Saving				√			
			D 2.0 TCI-R	ENGINE	High Power(CPF+)	√	√	√	√	√		
					High Power(CPF-)	√	√	√	√	√	√	
					Low Power(CPF-)	√	√	√	√	√	√	
					Low Power(CPF+)	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√			
					Airbag(Event #2)	√	√	√	√			
				EPS	Power Steering	√	√	√	√			
				4WD	4WD Control	√	√	√	√	√	√	
				BCM	All Systems	√	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√	√	
			AHLS	Auto Headlamp Leveling	√			√				
			SPAS	Smart Parking Assist System	√	√	√	√	√	√		
			TPMS	Tire Pressure Monitoring	√	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				CODE	Transmitter Code Saving				√		
			D 1.7 TCI-U2	ENGINE	Engine Control(CPF-)	√	√	√	√	√	
					Engine Control(CPF+)	√	√	√	√	√	√
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		
					Airbag(Event #2)	√	√	√	√		
				EPS	Power Steering	√	√	√	√		
				4WD	4WD Control	√	√	√	√	√	
					All Systems	√	√	√	√	√	
				BCM	Body Control Module	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√	
				AHLS	Auto Headlamp Leveling	√			√		
				SPAS	Smart Parking Assist System	√	√	√	√	√	
			TPMS	Tire Pressure Monitoring	√	√	√	√	√		
			CODE	Transmitter Code Saving				√			
	SPORTAGE (SL/SLE)			ENGINE	Unleaded EOBD	√	√	√	√	√	
				ENGINE	Unleaded GEN	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.0 DOHC		Leaded All	√	√	√	√			
				AT	Automatic Transaxle	√	√	√	√	√		
				ESP	Electronic Stability Program	√	√	√	√	√		
				AIRBAG	Airbag(Event #1)	√	√	√	√			
					Airbag(Event #2)	√	√	√	√			
				EPS	Power Steering	√	√	√	√			
				4WD	4WD Control	√	√	√	√	√		
				BCM	All Systems	√	√	√	√	√		
					Body Control Module	√	√	√	√	√		
					Smart Junction Box	√	√	√	√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√		
				AHLS	Auto Headlamp Leveling	√			√			
				SPAS	Smart Parking Assist System	√	√	√	√	√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
			CODE	Transmitter Code Saving				√				
			ENGINE	Unleaded EOBD	√	√	√	√	√			
				Unleaded GEN	√	√	√	√	√			
				Leaded All	√	√	√	√				



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 2.4 DOHC	AT	Automatic Transaxle	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		
					Airbag(Event #2)	√	√	√	√		
				EPS	Power Steering	√	√	√	√		
				4WD	4WD Control	√	√	√	√	√	
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√	
				AHLS	Auto Headlamp Leveling	√			√		
				SPAS	Smart Parking Assist System	√	√	√	√	√	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
			ENGINE	Engine Control	√	√	√	√	√	self-learning clear	
			AT	Automatic Transaxle	√	√	√	√	√		
			ESP	Electronic Stability Program	√	√	√	√	√		
			AIRBAG	Airbag(Event #1)	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2011	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√			
				EPS	Power Steering	√	√	√	√			
				4WD	4WD Control	√	√	√	√	√		
				BCM	All Systems	√	√	√	√	√		
					Body Control Module	√	√	√	√	√		
					Smart Junction Box	√	√	√	√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√		
				AHLS	Auto Headlamp Leveling	√			√			
				SPAS	Smart Parking Assist System	√	√	√	√	√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
				ENGINE	High Power(CPF-)	√	√	√	√	√		
					High Power(CPF+)	√	√	√	√	√		
					Low Power(CPF-)	√	√	√	√	√		
			Low Power(CPF+)		√	√	√	√	√			
			AT	Automatic Transaxle	√	√	√	√	√			
			ESP	Electronic Stability Program	√	√	√	√	√			
			AIRBAG	Airbag(Event #1)	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√		
				EPS	Power Steering	√	√	√	√		
				4WD	4WD Control	√	√	√	√	√	
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√	
				AHLS	Auto Headlamp Leveling	√			√		
				SPAS	Smart Parking Assist System	√	√	√	√	√	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control(CPF-)	√	√	√	√	√	
					Engine Control(CPF+)	√	√	√	√	√	
				ESP	Electronic Stability Program	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		
					Airbag(Event #2)	√	√	√	√		
				EPS	Power Steering	√	√	√	√		
			4WD	4WD Control	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function										
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions					
			D 1.7 TCI-U2	BCM	All Systems	√	√	√	√	√						
					Body Control Module	√	√	√	√	√						
					Smart Junction Box	√	√	√	√	√						
				IMMO	Immobilizer									Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		
						PIC	Smart Key Unit	√	√	√	√	√				
						AHLS	Auto Headlamp Leveling	√			√					
						SPAS	Smart Parking Assist System	√	√	√	√	√				
						TPMS	Tire Pressure Monitoring	√	√	√	√	√				
						CODE	Transmitter Code Saving				√					
						TOWNER(HA)	2003	G 0.8 SOHC	ENGINE	Engine Control		√	√	√	√	
							2002	G 0.8 SOHC	ENGINE	Engine Control		√	√	√	√	
				2001	G 0.8 SOHC		ENGINE	Engine Control		√	√	√	√			
				2000	G 0.8 SOHC		ENGINE	Engine Control		√	√	√	√			
				1999	G 0.8 SOHC		ENGINE	Engine Control		√	√	√	√			
				1998	G 0.8 SOHC		ENGINE	Engine Control		√	√	√	√			
1997	G 0.8 SOHC	ENGINE	Engine Control		√		√	√	√							
1996	G 0.8 SOHC	ENGINE	Engine Control		√	√	√	√								
1995	G 0.8 SOHC	ENGINE	Engine Control		√	√	√	√								
1994	G 0.8 SOHC	ENGINE	Engine Control		√	√	√	√								



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		1993	G 0.8 SOHC	ENGINE	Engine Control		√	√	√	√	
			G 1.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	self-learning clear
				ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag Control(Event #1)	√	√	√	√		
					Airbag Control(Event #2)	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√	√		
				BCM	Body Control Module	√	√	√	√	√	
				IMMO	Immobilizer				√		
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
			CODE	Transmitter Code Saving				√			
			G 1.6 DOHC	ENGINE	Engine Control	√	√	√	√	√	self-learning clear
				AT	Automatic Transaxle	√	√	√	√	√	
				ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag Control(Event #1)	√	√	√	√		
					Airbag Control(Event #2)	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√	√		
				BCM	Body Control Module	√	√	√	√	√	
			IMMO	Immobilizer				√			
				All Systems	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2012		PIC	Smart Key Unit	√	√	√	√	√			
					Power Distribution Module	√	√	√	√	√	√		
					Smart Key Code Saving					√			
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	√		
				CODE	Transmitter Code Saving					√			
				D 1.6 TCI-U2	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
						Engine Control(CPF+)	√	√	√	√	√	√	√
					ABSESP	ABS/ESP	√	√	√	√	√	√	
					AIRBAG	Airbag Control(Event #1)	√	√	√	√	√		
						Airbag Control(Event #2)	√	√	√	√	√		
			AIRCON		Air Conditioner	√	√	√	√	√	√		
			EPS		Power Steering	√	√	√	√	√			
			BCM		Body Control Module	√	√	√	√	√	√		
			IMMO		Immobilizer					√			
			PIC		All Systems	√	√	√	√	√	√	√	
				Smart Key Unit	√	√	√	√	√	√	√		
				Power Distribution Module	√	√	√	√	√	√	√		
				Smart Key Code Saving						√			
			TPMS	Tire Pressure Monitoring	√	√	√	√	√	√	√		
			CODE	Transmitter Code Saving						√			
			ABSESP	ABS/ESP	√	√	√	√	√	√			
				Airbag Control(Event #1)	√	√	√	√	√	√			
			AIRBAG	Airbag Control(Event #2)	√	√	√	√	√	√			
				Air Conditioner	√	√	√	√	√	√	√		
			EPS	Power Steering	√	√	√	√	√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			D 1.4 TCI-U2	BCM	Body Control Module	√	√	√	√	√	
				IMMO	Immobilizer				√		
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
			CODE	Transmitter Code Saving				√			
			G 1.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	self-learning clear
				ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag Control(Event #1)	√	√	√	√		
					Airbag Control(Event #2)	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer				√		
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
			CODE	Transmitter Code Saving				√			
			ENGINE	Engine Control	√	√	√	√	√	self-learning clear	
			AT	Automatic Transaxle	√	√	√	√	√		
			ABSESP	ABS/ESP	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
	VENGA(YN)	2011	G 1.6 DOHC	AIRBAG	Airbag Control(Event #1)	√	√	√	√			
					Airbag Control(Event #2)	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Power Steering	√	√	√	√			
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer				√			
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
					Smart Key Code Saving				√			
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
			D 1.6 TCI-U2	ENGINE	Engine Control(CPF-)	√	√	√	√	√		
					Engine Control(CPF+)	√	√	√	√	√		
				ABSESP	ABS/ESP	√	√	√	√	√		
				AIRBAG	Airbag Control(Event #1)	√	√	√	√			
					Airbag Control(Event #2)	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		
				EPS	Power Steering	√	√	√	√			
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer				√			
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
Smart Key Code Saving					√							



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
			D 1.4 TCI-U2	ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag Control(Event #1)	√	√	√	√		
					Airbag Control(Event #2)	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer				√		
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
			G 1.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	self-learning clear
				ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag Control(Event #1)	√	√	√	√		
					Airbag Control(Event #2)	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer				√		
			PIC	All Systems	√	√	√	√	√		
				Smart Key Unit	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				PIC	Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
			G 1.6 DOHC	ENGINE	Engine Control	√	√	√	√	√	self-learning clear
				AT	Automatic Transaxle	√	√	√	√	√	
				ABSESP	ABS/ESP	√	√	√	√	√	
				AIRBAG	Airbag Control(Event #1)	√	√	√	√		
					Airbag Control(Event #2)	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer				√		
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
			CODE	Transmitter Code Saving				√			
		2010	ENGINE	Engine Control(CPF-)	√	√	√	√	√		
				Engine Control(CPF+)	√	√	√	√	√		
			ABSESP	ABS/ESP	√	√	√	√	√		
			AIRBAG	Airbag Control(Event #1)	√	√	√	√			
				Airbag Control(Event #2)	√	√	√	√			
			AIRCON	Air Conditioner	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
GENERAL			D 1.6 TCI-U2	EPS	Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer				√		
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				D 1.4 TCI-U2	ABSESP	ABS/ESP	√	√	√	√	√
			AIRBAG		Airbag Control(Event #1)	√	√	√	√		
					Airbag Control(Event #2)	√	√	√	√		
			AIRCON		Air Conditioner	√	√	√	√	√	
			EPS		Power Steering	√	√	√	√		
			BCM		Body Control Module	√			√	√	
			IMMO		Immobilizer				√		
			PIC		All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
				Smart Key Code Saving				√			
			TPMS	Tire Pressure Monitoring	√	√	√	√	√		
			CODE	Transmitter Code Saving				√			
							ENGINE	Engine Control	√	√	√



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				AT	Automatic Transaxle	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Power Window Main		√	√	√	√	
					Power Seat		√	√	√	√	
					Power Window Assistance		√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving		√	√	√	√	
					All systems	√	√	√	√	√	
				TPMS	Tire Pressure Monitoring System	√	√	√		√	
				CODE	Transmitter Code Saving				√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				ENGINE	Engine Control	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				EPS	Electronic Power Steering	√	√	√	√		
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Power Window Main		√	√	√	√	
					Power Seat		√	√	√	√	
					Power Window Assistance		√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring System	√	√	√		√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
	AMANTI(GH)	2007	G 3.8 DOHC	AT	Automatic Transaxle	√	√	√	√	√			
				ESC	Electronic Stability Control	√	√	√	√	√			
				AIRBAG	Airbag Control	√	√	√	√				
				AIRCON	Air Conditioner	√	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√				
				BCM	All Systems	√	√	√	√	√			
					Body Control Module	√	√	√	√	√			
					Power Window Main		√	√	√	√			
					Power Seat		√	√	√	√			
					Power Window Assistance		√	√	√	√			
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving						√		
		2006	G 3.5 DOHC	ENGINE	Engine Control				√	√	√	√	
				AT	Automatic Transaxle				√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	√		
				AIRBAG	Airbag Control				√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	√		
				EPS	Electronic Power Steering				√	√			
	All Systems			√	√	√	√	√					
	Body Control Module			√	√	√	√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				BCM	Power Window Main		√	√	√	√		
					Power Seat		√	√	√	√		
					Power Window Assistance		√	√	√	√		
				IMMO	Immobilizer				√		Password learning/modify Limp mode	
				CODE	Transmitter Code Saving				√			
		2005	G 3.5 DOHC	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	√	
				AIRBAG	Airbag Control		√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	√	
				EPS	Electronic Power Steering		√	√				
				BCM	All Systems	√	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	√	
					Power Window Main		√	√	√	√	√	
					Power Seat		√	√	√	√	√	
					Power Window Assistance		√	√	√	√	√	
				IMMO	Immobilizer					√		Password learning/modify Limp mode
				CODE	Transmitter Code Saving					√		
				ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√	√		
				ESC	Electronic Stability Control	√	√	√	√	√		
				AIRBAG	Airbag Control		√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		2004	G 3.5 DOHC	EPS	Electronic Power Steering		√	√			
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Power Window Main		√	√	√	√	
					Power Seat		√	√	√	√	
					Power Window Assistance		√	√	√	√	
				IMMO	Immobilizer				√		Password learning/modify Limp mode
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag
				EPS	Power Steering	√	√	√	√		
				ECS	Electronic Control Suspension	√	√	√	√	√	
				4WD	4WD Control(EST)	√	√	√	√		
					4WD Control(TOD)	√	√	√	√		
					All Systems	√	√	√	√	√	
					Instrument Panel Module	√	√	√	√	√	
					Front Area Module	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
	BORREGO(HM)	2009	G 3.8 DOHC	BCM	Rear Area Module	√	√	√	√	√			
					Driver Door Module	√	√	√	√	√			
					Assist Door Module	√	√	√	√	√			
					Integrated Memory System		√	√	√	√			
					User Option	√	√	√	√	√			
					Steering Column Module		√	√	√	√			
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√			
					Smart Key Unit	√	√	√	√	√			
					Power Distribution Module	√	√	√	√	√			
					Smart Key Code Saving				√				
				AHLS	Auto Headlamp Leveling System	√	√	√	√				
				TPMS	Tire Pressure Monitoring System	√	√	√		√			
				CODE	Transmitter Code Saving				√				
				ENGINE	Engine Control	√	√	√	√		Adaptive value reset		
AT	Automatic Transaxle	√	√	√	√	√							
ESC	Electronic Stability Control	√	√	√	√	√							



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 4.6 DOHC	AIRBAG	Airbag Control	√	√	√			Collision Information Real-time information of passenger airbag	
				EPS	Power Steering	√	√	√	√			
				ECS	Electronic Control Suspension	√	√	√	√	√		
				4WD	4WD Control(EST)	√	√	√	√			
					4WD Control(TOD)	√	√	√	√			
				BCM	All Systems	√	√	√	√	√		
					Instrument Panel Module	√	√	√	√	√		
					Front Area Module	√	√	√	√	√		
					Rear Area Module	√	√	√	√	√		
					Driver Door Module	√	√	√	√	√		
					Assist Door Module	√	√	√	√	√		
					Integrated Memory System		√	√	√	√		
					User Option	√	√	√	√	√		
					Steering Column Module		√	√	√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu					Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving				√		
				AHLS	Auto Headlamp Leveling System	√	√	√	√		
				TPMS	Tire Pressure Monitoring System	√	√	√		√	
				CODE	Transmitter Code Saving				√		
			G 2.0 DOHC	ENGINE	Engine Control(SULEV)	√	√	√	√	√	self-learning clear
					Engine Control(ULEV)	√	√	√	√	√	√
				AT	Automatic Transaxle	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	Deflation
				AIRBAG	All Systems	√	√	√	√		Real-time information
					Airbag(Event #1)	√	√	√	√		Real-time information
					Airbag(Event #2)	√	√	√	√		
					Weight Classification	√	√	√	√		
				EPS	Power Steering	√	√	√			EPS type recognition ASP calibration
				BCM	Body Control Module	√			√	√	
					Body Control Module(KOUP)	√			√	√	
					Body Control Module(5DR)	√			√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2012		IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
			PIC	All Systems	√	√	√		√			
				PIC	Smart Key Unit	√	√	√		√		
				PIC	Power Distribution Module	√	√	√	√	√		ESCL open stae inspection
				PIC	Smart Key Code Saving							Match key
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
				ENGINE	Engine Control	√	√	√	√	√		self-learning clear
				AT	Automatic Transaxle	√	√	√	√	√		
				ESC	Electronic Stability Control	√	√	√	√	√		Deflation
				AIRBAG	All Systems	√	√	√	√			Real-time information
					Airbag(Event #1)	√	√	√	√			Real-time information
					Airbag(Event #2)	√	√	√	√			
					Weight Classification	√	√	√	√			
				EPS	Power Steering	√	√	√				EPS type recognition ASP calibration
					Power Steering(KOUP)	√	√	√	√			
				BCM	Body Control Module	√			√	√		
					Body Control Module(KOUP)	√			√	√		
					Body Control Module(5DR)	√			√	√		

G 2.4 DOHC



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√		√	
					Smart Key Unit	√	√	√		√	
					Power Distribution Module	√	√	√	√	√	ESCL open stae inspection
					Smart Key Code Saving						Match key
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control(SULEV)	√	√	√	√	√	self-learning clear
					Engine Control(ULEV)	√	√	√	√	√	Engine testing capabilities
				AT	Automatic Transaxle	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	Deflation
				AIRBAG	Airbag(Event #1)	√	√	√	√		Real-time information
					Airbag(Event #2)	√	√	√	√		
					Weight Classification	√	√	√	√		
				EPS	Power Steering	√	√	√			EPS type recognition ASP calibration
				BCM	Body Control Module	√			√	√	
					Body Control Module(KOUP)	√			√	√	
					Body Control Module(5DR)	√			√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2011	G 2.0 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PIC	All Systems	√	√	√		√		
					Smart Key Unit	√	√	√		√		
					Power Distribution Module	√	√	√	√	√		ESCL open stae inspection
					Smart Key Code Saving							Match key
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
				CODE	Transmitter Code Saving					√		
				ENGINE	Engine Control	√	√	√	√	√		self-learning clear
				AT	Automatic Transaxle	√	√	√	√	√		
				ESC	Electronic Stability Control	√	√	√	√	√		Deflation
			AIRBAG	All Systems	√	√	√	√			Real-time information	
				Airbag(Event #1)	√	√	√	√			Real-time information	
				Airbag(Event #2)	√	√	√	√				
				Weight Classification	√	√	√	√				
			EPS	Power Steering	√	√	√				EPS type recognition ASP calibration	
				Power Steering(KOUP)	√	√	√	√				
			BCM	Body Control Module	√			√	√			
				Body Control Module(KOUP)	√			√	√			
		Body Control Module(5DR)		√			√	√				
			G 2.4 DOHC									



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu					Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	FORTE/FORTE KOUPTD			IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√		√	
					Smart Key Unit	√	√	√		√	
					Power Distribution Module	√	√	√	√	√	ESCL open stae inspection
					Smart Key Code Saving						Match key
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control(SULEV)	√	√	√	√	√	self-learning clear
					Engine Control(ULEV)	√	√	√	√	√	Engine testing capabilities
				AT	4-Speed	√	√	√	√	√	Clear automatic transmission fitness
					5-Speed	√	√	√	√	√	Clear automatic transmission fitness
				ESC	Electronic Stability Control	√	√	√	√	√	Deflation
				AIRBAG	All Systems	√	√	√	√		Real-time information
					Airbag(Event #1)	√	√	√	√		Real-time information
					Airbag(Event #2)	√	√	√	√		
			Weight Classification		√	√	√	√			
			EPS	Power Steering	√	√	√			EPS type recognition ASP calibration	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu					Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 2.0 DOHC		Power Steering(KOUP)	√	√	√	√		
				BCM	Body Control Module	√			√	√	User select
					Body Control Module(KOUP)	√			√	√	User select
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					Multiselection	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Smart Key Unit(ESCL-)	√	√	√		√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2010		PIC	Smart Key Unit(ESCL+)	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information		
					Power Distribution Module(ESCL-)	√	√	√	√	√	√	ESCL open stae inspection	
					Power Distribution Module(ESCL+)	√	√	√	√	√	√		
					Smart Key Code Saving(ESCL+)						√		
					Smart Key Code SavingS(ESCL-)								Match key
					TPMS	Tire Pressure Monitoring	√	√	√	√	√	√	
					CODE	Transmitter Code Saving					√		
					ENGINE	Engine Control	√	√	√	√	√	√	self-learning clear
					AT	Automatic Transaxle	√	√	√	√	√	√	Clear automatic transmission fitness
					ESC	Electronic Stability Control	√	√	√	√	√	√	Deflation
						All Systems	√	√	√	√	√		Real-time information
					AIRBAG	Airbag(Event #1)	√	√	√	√	√		Real-time information



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu					Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 2.4 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√		
						Weight Classification	√	√	√	√	
				EPS	Power Steering	√	√	√			EPS type recognition ASP calibration
						Power Steering(KOUP)	√	√	√	√	
				BCM	Body Control Module	√			√	√	User select
						Body Control Module(KOUP)	√			√	√
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
					Multiselection	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Smart Key Unit(ESCL-)	√	√	√		√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				PIC	Smart Key Unit(ESCL+)	√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Power Distribution Module(ESCL-)	√	√	√	√	√	ESCL open stae inspection
					Power Distribution Module(ESCL+)	√	√	√	√	√	
					Smart Key Code Saving(ESCL-)						Match key
					Smart Key Code Saving(ESCL+)				√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√			Collision Information
				EPS	Electronic Power Steering	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.4 DOHC	ECS	Electronic Control Suspension		√	√	√	√		
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer				√			
				PIC	Smart Key Unit(ESCL-)	√	√	√	√	√		
					Smart Key Unit(ESCL+)	√	√	√				Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Power Distribution Module(ESCL-)	√	√	√	√	√		
					Power Distribution Module(ESCL+)	√	√	√	√	√		
					Smart Key Code Saving(ESCL-)							Match key
					Smart Key Code Saving(ESCL+)					√		
					TPMS	Tire Pressure Monitoring System	√	√	√		√	
			CODE	Transmitter Code Saving				√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2010	G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ESC	Electronic Stability Control	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√			Collision Information	
				EPS	Electronic Power Steering	√	√	√	√			
				ECS	Electronic Control Suspension		√	√	√	√		
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer				√			
				PIC	Smart Key Unit(ESCL-)		√	√	√	√	√	
					Smart Key Unit(ESCL+)		√	√	√			Input/output experiment Antenna drive Serial line check Antenna status check Neutral gear mode FOB status information SMK state information ESCL state information PDM status information
					Power Distribution Module(ESCL-)		√	√	√	√	√	
					Power Distribution Module(ESCL+)		√	√	√	√	√	
					Smart Key Code Saving(ESCL-)							Match key



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
					Smart Key Code Saving(ESCL+)				√			
				TPMS	Tire Pressure Monitoring System	√	√	√		√		
				CODE	Transmitter Code Saving				√			
		2009	G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√				Collision Information
				EPS	Electronic Power Steering	√	√	√	√			
				ECS	Electronic Control Suspension			√	√	√	√	
				BCM	Body Control Module	√				√	√	
				IMMO	Immobilizer					√		
				TPMS	Tire Pressure Monitoring System	√	√	√			√	
				CODE	Transmitter Code Saving						√	
				ENGINE	Engine Control	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√				Collision Information
		EPS	Electronic Power Steering	√	√	√	√					
		ECS	Electronic Control Suspension			√	√	√	√			
		BCM	Body Control Module	√				√	√			



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
				IMMO	Immobilizer				√				
				TPMS	Tire Pressure Monitoring System	√	√	√		√			
				CODE	Transmitter Code Saving				√				
	OPTIMA(MG)	2008	G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset		
AT				Automatic Transaxle	√	√	√	√	√				
ABSESC				Electronic Stability Control	√	√	√	√	√				
AIRBAG				Airbag Control	√	√	√	√	√				
EPS				Electronic Power Steering	√	√	√	√	√				
ECS				Electronic Control Suspension		√	√	√	√				
BCM				Body Control Module	√		√	√	√				
IMMO				Immobilizer									Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
TPMS				Tire Pressure Monitoring System	√	√	√					√	
CODE				Transmitter Code Saving							√		
				ENGINE	Engine Control		√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set		
				AT	Automatic Transaxle		√	√	√	√			



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 2.7 DOHC	ESC	Electronic Stability Control	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring System	√	√	√		√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				ECS	Electronic Control Suspension		√	√	√	√	
				BCM	Body Control Module	√			√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2007	G 2.4 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				TPMS	Tire Pressure Monitoring System	√	√	√		√		
				CODE	Transmitter Code Saving				√			
			G 2.7 DOHC	ENGINE	Engine Control		√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set	
				AT	Automatic Transaxle		√	√	√	√		
				ESC	Electronic Stability Control	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				ECS	Electronic Control Suspension		√	√	√	√		
				BCM	Body Control Module	√			√	√		
			IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
				TPMS	Tire Pressure Monitoring System	√	√	√		√			
				CODE	Transmitter Code Saving				√				
		2006	G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset		
				AT	Automatic Transaxle	√	√	√	√	√			
				ESC	Electronic Stability Control	√	√	√	√	√			
				AIRBAG	Airbag Control	√	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√	√			
				ECS	Electronic Control Suspension		√	√	√	√			
				BCM	Body Control Module	√			√	√			
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				TPMS	Tire Pressure Monitoring System	√	√	√			√		
				CODE	Transmitter Code Saving						√		
				ENGINE	Engine Control				√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle				√	√			
		ESC	Electronic Stability Control	√	√	√	√	√	√				



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.7 DOHC	AIRBAG	Airbag Control	√	√	√	√			
				EPS	Electronic Power Steering	√	√	√	√			
				ECS	Electronic Control Suspension		√	√	√	√		
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				TPMS	Tire Pressure Monitoring System	√	√	√		√		
				CODE	Transmitter Code Saving				√			
			2006	G 2.4 DOHC	ENGINE	Engine Control(A/T)	√	√	√	√	√	Adaptive value reset
						Engine Control(M/T)	√	√	√	√	√	Adaptive value reset
					AT	Automatic Transaxle		√	√			
					ABS	Anti-Lock Brake		√	√			
					AIRBAG	Airbag Control	√	√	√	√		
				G 2.7 DOHC	ENGINE	Engine Control		√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					AT	Automatic Transaxle		√	√			
ABS	Anti-Lock Brake		√		√							
			AIRBAG	Airbag Control	√	√	√	√				



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	OPTIMA(MS)	2005	G 2.4 DOHC	ENGINE	Engine Control(A/T)	√	√	√	√	√	Adaptive value reset
					Engine Control(M/T)	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle		√	√			
				ABS	Anti-Lock Brake		√	√			
				AIRBAG	Airbag Control	√	√	√	√		
			G 2.7 DOHC	ENGINE	Engine Control		√	√	√	√	PCM automatically detect reset PCM lock(MEC)is set
					AT	Automatic Transaxle		√	√		
				ABS	Anti-Lock Brake		√	√			
				AIRBAG	Airbag Control	√	√	√	√		
		2004	G 2.4 DOHC	ENGINE	Engine Control(A/T)	√	√	√	√	√	
					Engine Control(M/T)	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake		√	√			
				AIRBAG	Airbag Control	√	√	√	√		
			G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle		√	√			
				ABS	Anti-Lock Brake		√	√			
				AIRBAG	Airbag Control	√	√	√	√		
2003	G 2.4 DOHC	ENGINE	Engine Control(A/T)	√	√	√	√	√			
			Engine Control(M/T)	√	√	√	√	√			
		AT	Automatic Transaxle	√	√	√	√	√			
		ABS	Anti-Lock Brake		√	√					
		AIRBAG	Airbag Control	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
			G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle		√	√				
				ABS	Anti-Lock Brake		√	√				
				AIRBAG	Airbag Control	√	√	√	√			
		2002	G 2.4 DOHC	ENGINE	Engine Control(A/T)	√	√	√	√	√		
					ENGINE	Engine Control(M/T)	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	
					ABS	Anti-Lock Brake(Bosch)		√	√			
					ABS	Anti-Lock Brake(Mando)	√	√	√	√	√	
			AIRBAG	Airbag Control	√	√	√	√				
		2001	G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset	
					AT	Automatic Transaxle		√	√			
					ABS	Anti-Lock Brake(Bosch)		√	√			
					ABS	Anti-Lock Brake(Mando)	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√	√		
		2001	G 2.4 DOHC	ENGINE	Engine Control(A/T)	√	√	√	√	√		
					ENGINE	Engine Control(M/T)	√	√	√	√	√	
					AT	Automatic Transaxle	√	√	√	√	√	
					ABS	Anti-Lock Brake	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√	√		
		2001	G 2.5 DOHC	ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset	
					AT	Automatic Transaxle		√	√			
					ABS	Anti-Lock Brake	√	√	√	√	√	
					AIRBAG	Airbag Control	√	√	√	√		
				ENGINE	Engine Control	√	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				AT	Automatic Transaxle	√	√	√	√	√	
				ABSESC	ABS/ESC	√	√	√	√	√	
				AHB	Active Hydraulic Booster	√	√	√	√	√	
				AIRBAG	All Systems	√	√	√			
					Airbag(Event #1)	√	√	√			
					Airbag(Event #2)	√	√	√	√		
					Weight Classification	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√		
				HCU	HEV Control System	√	√	√	√	√	
				MCU	HEV Motor System	√	√	√	√	√	
				BMS	HEV Battery System	√	√	√	√	√	
				LDC	Low DC/DC Converter	√	√	√	√	√	
				AAF	Active Air Flap	√	√	√	√	√	
				EPS	Motor Driven Power Steering	√	√	√	√		
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Cluster Module	√	√	√	√	√	
					Power Seat Module	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				PIC	Smart Key Unit	√	√	√	√	√	
				AHLS	Auto Headlamp Leveling System	√	√	√	√	√	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
			G 2.0 T-GDI	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	
				AIRBAG	All Systems	√	√	√			
					Airbag(Event #1)	√	√	√			
					Airbag(Event #2)	√	√	√	√		
					Weight Classification	√	√	√	√		
				AIRCON	Air Conditioner	√	√	√	√	√	
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Cluster Module	√	√	√	√	√	
					Power Seat Module	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2012	G 2.4 GDI	AHLS	Auto Headlamp Leveling	√	√	√	√	√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	√	
				CODE	Transmitter Code Saving					√		
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	√	
				AIRBAG	All Systems	√	√	√				
					Airbag(Event #1)	√	√	√				
					Airbag(Event #2)	√	√	√	√			
					Weight Classification	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	√	
				BCM	All Systems	√	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	√	
					Cluster Module	√	√	√	√	√	√	
					Power Seat Module	√	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√	√	
		AHLS	Auto Headlamp Leveling	√	√	√	√	√	√			
		TPMS	Tire Pressure Monitoring	√	√	√	√	√	√			
		CODE	Transmitter Code Saving					√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	ENGINE	Engine Control	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ESC	Electronic Stability Control	√	√	√	√	√		
				AIRBAG	All Systems	√	√	√				
					Airbag(Event #1)	√	√	√				
					Airbag(Event #2)	√	√	√	√			
					Weight Classification	√	√	√	√			
				AIRCON	Air Conditioner	√	√	√	√	√	√	
				BCM	All Systems	√	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	√	
					Cluster Module	√	√	√	√	√	√	
					Power Seat Module	√	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√	√	
				AHLS	Auto Headlamp Leveling	√	√	√	√	√	√	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	√	
				CODE	Transmitter Code Saving					√		
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
			G 2.4 GDI	AIRBAG	All Systems	√	√	√					
					Airbag(Event #1)	√	√	√					
					Airbag(Event #2)	√	√	√	√				
					Weight Classification	√	√	√	√				
				AIRCON	Air Conditioner	√	√	√	√	√			
				BCM	All Systems	√	√	√	√	√			
					Body Control Module	√	√	√	√	√			
					Cluster Module	√	√	√	√	√			
					Power Seat Module	√	√	√	√	√			
					Smart Junction Box	√	√	√	√	√			
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√			
				AHLS	Auto Headlamp Leveling	√	√	√	√	√			
				TPMS	Tire Pressure Monitoring	√	√	√	√	√			
				CODE	Transmitter Code Saving					√			
2005	G 1.6 DOHC	ENGINE	Engine Control			√	√	√					
		AT	Automatic Transaxle			√	√	√					
		ABS	Anti-Lock Brake System	√	√	√	√	√					
		AIRBAG	Airbag Control	√	√	√	√						
		ENGINE	Engine Control			√	√	√					



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
	RIO(BC)	2004	G 1.6 DOHC	AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake System	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√			
		2003	G 1.6 DOHC	ENGINE	Engine Control			√	√	√		
				AT	Automatic Transaxle			√	√	√		
				ABS	Anti-Lock Brake System	√	√	√	√	√	√	
		2002	G 1.5 DOHC	AIRBAG	Airbag Control	√	√	√	√	√		
				ENGINE	Engine Control			√	√	√		
				AT	Automatic Transaxle			√	√	√		
		2001	G 1.5 DOHC	ABS	Anti-Lock Brake System			√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√			
				ENGINE	Engine Control			√	√	√		
		2012	G 1.6 DOHC	AT	Automatic Transaxle	√	√	√	√	√		Reset adaptive values
				ABS	Anti-Lock Brake	√	√	√	√	√		Adaptive reset
				EPS	Power Steering	√	√	√	√			
				TPMS	Tire Pressure Monitoring System	√	√	√		√		
				ENGINE	Engine Control	√	√	√	√	√		
		2011	G 1.6 DOHC	AT	Automatic Transaxle	√	√	√	√	√		Reset adaptive values
				ABS	Anti-Lock Brake	√	√	√	√	√		Adaptive reset
				EPS	Power Steering	√	√	√	√			
ENGINE				Engine Control	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				TPMS	Tire Pressure Monitoring System	√	√	√		√		
		2010	G 1.6 DOHC	ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values	
				AT	Automatic Transaxle	√	√	√	√	√	√	Adaptive reset
				ABS	Anti-Lock Brake	√	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√	√	√	
				EPS	Power Steering	√	√	√	√	√	√	
				TPMS	Tire Pressure Monitoring System	√	√	√	√	√	√	
		2009	G 1.6 DOHC	ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values	
				AT	Automatic Transaxle	√	√	√	√	√	√	Adaptive reset
				ABS	ABS(MGH-40)	√	√	√	√	√	√	Deflated mode
					ABS(MGH-25)	√	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√	√	√	
				TPMS	Tire Pressure Monitoring System	√	√	√	√	√	√	
		2008	G 1.6 DOHC	ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values	
				AT	Automatic Transaxle	√	√	√	√	√	√	Adaptive reset
				ABS	ABS(MGH-40)	√	√	√	√	√	√	Deflated mode
					ABS(MGH-25)	√	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√	√	√	
				TPMS	Tire Pressure Monitoring System	√	√	√	√	√	√	
				ENGINE	Engine Control	√	√	√	√	√	Reset adaptive values	
				AT	Automatic Transaxle	√	√	√	√	√	Adaptive reset	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2007	G 1.6 DOHC	ABS	Anti-Lock Brake System	√	√	√	√	√	Deflated mode		
				AIRBAG	Airbag Control	√	√	√	√				
				TPMS	Tire Pressure Monitoring System	√	√	√		√			
		2006	G 1.6 DOHC	ENGINE	Engine Control	√	√	√	√	√		Reset adaptive values	
				AT	Automatic Transaxle	√	√	√	√	√		Adaptive reset	
				ABS	Anti-Lock Brake System	√	√	√	√	√		Deflated mode	
	RIO(UB)	2012	G 1.6 GDI	AIRBAG	Airbag Control	√	√	√	√				
				TPMS	Tire Pressure Monitoring System	√	√	√		√			
				ENGINE	Engine Control	√			√	√		Reading trouble code Clear fault code self-learning clear	
				ABSESC	ABS/ESC	√	√	√	√	√			
				AIRBAG	Airbag(Event #1)	√	√	√	√				
				AIRBAG	Airbag(Event #2)	√	√	√	√				
					EPS	Motor driven Power Steering	√	√	√	√	√		
					BCM	Body Control Module	√	√	√	√	√		
					CODE	Transmitter Code Saving				√			
ENGINE					Engine Control	√	√	√	√	√			
AT					Automatic Transaxle	√	√	√	√	√			
ABSESC					ABS/ESC	√	√	√	√	√			
				AIRBAG	All Systems	√	√	√	√				
				AIRBAG	Airbag Control	√	√	√	√				
				AIRBAG	Weight Classification		√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2010	G 2.7 DOHC	BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring System	√	√	√		√		
				CODE	Transmitter Code Saving					√		
			G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ABSESC	ABS/ESC	√	√	√	√	√		
				AIRBAG	All Systems	√	√	√	√			
					Airbag Control	√	√	√	√			
					Weight Classification		√	√				
				BCM	Body Control Module	√				√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
			TPMS	Tire Pressure Monitoring System	√	√	√			√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
				CODE	Transmitter Code Saving				√				
		2009	G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√			
				AT	Automatic Transaxle	√	√	√	√	√	√		
				ABSESC	ABS/ESC(MGH-25)	√	√	√	√	√	√		
					ABS/ESC(MGH-40)	√	√	√	√	√	√		
				AIRBAG	All Systems	√	√	√	√				
					Airbag Control	√	√	√	√				
					Weight Classification		√	√					
				BCM	Body Control Module	√			√		√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				TPMS	Tire Pressure Monitoring System	√	√	√			√		
				CODE	Transmitter Code Saving						√		
				ENGINE	Engine Control	√	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√	√	
				ABSESC	ABS/ESC(MGH-25)	√	√	√	√	√	√	√	
		ABS/ESC(MGH-40)	√		√	√	√	√	√	√			
		AIRBAG	All Systems	√	√	√	√						
			Airbag Control	√	√	√	√						
			Weight Classification		√	√							



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
	RONDO(UN)		G 2.4 DOHC	BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring System	√	√	√		√		
				CODE	Transmitter Code Saving				√			
			G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√		
				ABS	ABS/ESC(MGH-25)	√	√	√	√	√		
					ABS/ESC(MGH-40)	√	√	√	√	√		
				AIRBAG	All Systems	√	√	√	√			
					Airbag Control Unit	√	√	√	√			
					Weight Classification		√	√				
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2008	G 2.7 DOHC	TPMS	Tire Pressure Monitoring System	√	√	√		√		
				CODE	Transmitter Code Saving					√		
				ENGINE	Engine Control	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ABS	ABS/ESC(MGH-25)	√	√	√	√	√		
					ABS/ESC(MGH-40)	√	√	√	√	√		
				AIRBAG	All Systems	√	√	√	√			
					Airbag Control Unit	√	√	√	√			
					Weight Classification		√	√				
				BCM	Body Control Module	√			√		√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring System	√	√	√			√	
				CODE	Transmitter Code Saving					√		
				ENGINE	Engine Control	√	√	√	√	√		Adaptive value reset
		AT	Automatic Transaxle	√	√	√	√	√				
		ABS	Anti-Lock Brake System	√	√	√	√	√				
		AIRBAG	All Systems	√	√	√	√					
			Airbag Control Unit	√	√	√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2007	G 2.4 DOHC		Weight Classification		√	√				
				BCM	Body Control Module	√			√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring System	√	√	√		√		
				CODE	Transmitter Code Saving					√		
			ENGINE	Engine Control	√	√	√	√	√	√		
			AT	Automatic Transaxle	√	√	√	√	√	√		
			ABS	Anti-Lock Brake System	√	√	√	√	√	√		
			AIRBAG	All Systems	√	√	√	√				
				Airbag Control Unit	√	√	√	√				
				Weight Classification		√	√					
			BCM	Body Control Module	√			√	√			
			G 2.7 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				TPMS	Tire Pressure Monitoring System	√	√	√		√		
				CODE	Transmitter Code Saving				√			
	SEDONA(G Q)	2005	G 3.5 DOHC	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√	√		
				ABS	Anti-Lock Brake System		√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control		√	√				
		2004	G 3.5 DOHC	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√	√		
				ABS	Anti-Lock Brake System		√	√	√	√	√	Deflated mode
		2003	G 3.5 DOHC	AIRBAG	Airbag Control		√	√				
				ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle		√	√	√	√		
		2002	G 3.5 DOHC	ABS	Anti-Lock Brake System		√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control		√	√				
	ENGINE			Engine Control		√	√	√	√	√		
	AT			Automatic Transaxle		√	√	√	√	√		
				ABSESC	ABS(MEB-2)	√	√	√	√	√		
					ESC(MEB-2)	√	√	√	√	√		
					All Systems		√	√				
					Instrument Panel Module		√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2012	G 3.5 DOHC	BCM	Front Area Module		√	√					
					Rear Area Module		√	√					
					Driver Door Module		√	√					
					Assist Door Module		√	√					
					Integrated Memory System		√	√					
						IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
						PSD	All Systems		√	√			
							Power Sliding Door-LH		√	√			
							Power Sliding Door-RH		√	√			
						PTG	Power Tail Gate		√	√			
						TPMS	Tire Pressure Monitoring System	√	√	√		√	
						CODE	Transmitter Code Saving				√		
						ENGINE	Engine Control	√	√	√	√	√	
						AT	Automatic Transaxle	√	√	√	√	√	
				ABSESC	ABS(MEB-2)	√	√	√	√	√			
					ESC(MEB-2)	√	√	√	√	√			
					All Systems		√	√					
					Instrument Panel Module		√	√					
					Front Area Module		√	√					



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2011	G 3.5 DOHC	BCM	Rear Area Module		√	√					
					Driver Door Module		√	√					
					Assist Door Module		√	√					
					Integrated Memory System		√	√					
						IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
						PSD	All Systems		√	√			
							Power Sliding Door-LH		√	√			
							Power Sliding Door-RH		√	√			
						PTG	Power Tail Gate		√	√			
						TPMS	Tire Pressure Monitoring System	√	√	√		√	
						CODE	Transmitter Code Saving				√		
						ENGINE	Engine Control		√	√	√	√	
						AT	Automatic Transaxle		√	√	√	√	
						ABSESC	ABS(MEB-2)	√	√	√	√	√	
				ESC(MEB-2)	√		√	√	√	√			
				BCM	All Systems		√	√					
					Instrument Panel Module		√	√					
					Front Area Module		√	√					
					Rear Area Module		√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2010	G 3.8 DOHC		Driver Door Module		√	√					
					Assist Door Module		√	√					
					Integrated Memory System		√	√					
						IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
						PSD	All Systems		√	√			
							Power Sliding Door-LH		√	√			
							Power Sliding Door-RH		√	√			
						PTG	Power Tail Gate		√	√			
						TPMS	Tire Pressure Monitoring System	√	√	√		√	
						CODE	Transmitter Code Saving				√		
						ENGINE	Engine Control		√	√	√	√	
						AT	Automatic Transaxle		√	√	√	√	
						ABSESC	ABS/ESC	√	√	√	√	√	
						AIRBAG	All Systems		√	√			
				Airbag Control Unit			√	√					
				Weight Classification			√	√					
					All Systems		√	√					
					Instrument Panel Module		√	√					
					Front Area Module		√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
	SEDONA(VQ)	2009	G 3.8 DOHC	BCM	Rear Area Module		√	√					
					Driver Door Module		√	√					
					Assist Door Module		√	√					
					Integrated Memory System		√	√					
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PSD	All Systems		√	√					
					Power Sliding Door-LH		√	√					
					Power Sliding Door-RH		√	√					
				PTG	Power Tail Gate		√	√					
		TPMS	TPMS(HIGH)	√	√	√		√					
			TPMS(LOW)	√	√	√		√					
		CODE	Transmitter Code Saving						√				
						ENGINE	Engine Control		√	√	√	√	
						AT	Automatic Transaxle		√	√	√	√	
						ABSESC	ABS/ESC	√	√	√	√	√	
						AIRBAG	All Systems		√	√			
							Airbag Control Unit		√	√			
Weight Classification							√	√					
	All Systems						√	√					
	Instrument Panel Module						√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2008	G 3.8 DOHC	BCM	Front Area Module		√	√					
					Rear Area Module		√	√					
					Driver Door Module		√	√					
					Assist Door Module		√	√					
					Integrated Memory System		√	√					
						IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
						PSD	All Systems		√	√			
							Power Sliding Door-LH		√	√			
							Power Sliding Door-RH		√	√			
						PTG	Power Tail Gate		√	√			
						TPMS	Tire Pressure Monitoring System	√	√	√		√	
						CODE	Transmitter Code Saving				√		
						ENGINE	Engine Control		√	√	√	√	
						AT	Automatic Transaxle		√	√	√	√	
				ABSESC	ABS/ESC	√	√	√	√	√			
				AIRBAG	All Systems		√	√					
					Airbag Control Unit		√	√					
					Weight Classification		√	√					
					All Systems		√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function								
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions			
		2007	G 3.8 DOHC	BCM	Instrument Panel Module		√	√						
					Front Area Module		√	√						
					Rear Area Module		√	√						
					Driver Door Module		√	√						
					Assist Door Module		√	√						
					Integrated Memory System		√	√						
				IMMO	Immobilizer								Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
				PSD	All Systems		√	√						
					Power Sliding Door-LH		√	√						
					Power Sliding Door-RH		√	√						
				PTG	Power Tail Gate		√	√						
				TPMS	Tire Pressure Monitoring System	√	√	√				√		
				CODE	Transmitter Code Saving							√		
				ENGINE	Engine Control		√	√	√					PCM automatically detect reset PCM lock(MEC)is set
				AT	Automatic Transaxle		√	√						
ABSESC	Electronic Stability Control	√	√	√	√	√								
	All Systems		√	√										



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2006	G 3.8 DOHC	AIRBAG	Airbag Control Unit		√	√				
					Weight Classification		√	√				
				BCM	All Systems		√	√				
					Instrument Panel Module		√	√				
					Front Area Module		√	√				
					Rear Area Module		√	√				
					Driver Door Module		√	√				
					Assist Door Module		√	√				
					Integrated Memory System		√	√				
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
		PSD	All Systems		√	√						
			Power Sliding Door-LH		√	√						
			Power Sliding Door-RH		√	√						
		PTG	Power Tail Gate		√	√						
		TPMS	Tire Pressure Monitoring System	√	√	√			√			
		CODE	Transmitter Code Saving						√			
		2001	G 1.8 DOHC	ENGINE	Engine Control		√	√	√			
				AT	Automatic Transaxle		√	√	√			
				ABS	Anti-Lock Brake System		√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	SEPHIA(FB)	2000	G 1.8 DOHC	AIRBAG	Airbag Control		√	√			
				ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake System		√	√	√	√	
				AIRBAG	Airbag Control		√	√			
		1999	G 1.8 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake System		√	√	√	√	
				AIRBAG	Airbag Control		√	√			
		1998	G 1.8 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake System		√	√	√	√	
				AIRBAG	Airbag Control		√	√			
		1997	G 1.8 DOHC	AT	Automatic Transaxle		√	√	√		
				AIRBAG	Airbag Control		√	√			
			G 1.6 DOHC	AT	Automatic Transaxle		√	√	√		
				AIRBAG	Airbag Control		√	√			
		1996	G 1.8 DOHC	AT	Automatic Transaxle		√	√	√		
				AIRBAG	Airbag Control		√	√			
			G 1.6 DOHC	AT	Automatic Transaxle		√	√	√		
	AIRBAG	Airbag Control			√	√					
	1995	G 1.6 SOHC	AT	Automatic Transaxle		√	√	√			
			AIRBAG	Airbag Control		√	√				
		G 1.8 DOHC	AT	Automatic Transaxle		√	√	√			
			AIRBAG	Airbag Control		√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		1994	G 1.6 DOHC	AT	Automatic Transaxle		√	√	√			
				AIRBAG	Airbag Control		√	√				
			G 1.6 SOHC	AT	Automatic Transaxle		√	√	√			
				AIRBAG	Airbag Control		√	√				
		G 1.8 DOHC	AT	Automatic Transaxle		√	√	√				
			G 1.6 DOHC	AT	Automatic Transaxle		√	√	√			
		2009	G 3.3 DOHC	ENGINE	Engine Control		√	√	√	√	√	Special Features
				AT	Automatic Transaxle	√	√	√	√	√		
	ESC			Electronic Stability Control	√	√	√	√	√			
	AIRBAG			Airbag Control	√	√	√	√				
	EPS			Electronic Power Steering	√	√	√	√				
	4WD			4WD Control	√	√	√					
	BCM			Body Control Module	√			√	√			
	IMMO			Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode	
	TPMS			Tire Pressure Monitoring System	√	√	√		√			
	CODE			Transmitter Code Saving					√			
	2009	G 3.3 DOHC	ENGINE	Engine Control		√	√	√	√	√	Special Features	
			AT	Automatic Transaxle	√	√	√	√	√			
ESC			Electronic Stability Control	√	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu					Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 3.8 DOHC	AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD Control	√	√	√			
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring System	√	√	√		√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control		√	√	√	√	Special Features
				AT	Automatic Transaxle	√	√	√	√	√	
				ABSESC	ABS/ESC	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD Control(EST)	√	√	√			
					4WD Control(TOD)	√	√	√			
				BCM	Body Control Module	√			√	√	



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
	SORENTO(BL)	2008	G 3.8 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring System	√	√	√		√	
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control		√	√	√	√	Special Features
			AT	Automatic Transaxle	√	√	√	√	√		
			ABSESC	ABS/ESC	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√	√			
			EPS	Electronic Power Steering	√	√	√	√			
			4WD	4WD Control(EST)	√	√	√				
				4WD Control(TOD)	√	√	√				
			BCM	Body Control Module	√			√	√		
			G 3.3 DOHC	IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				TPMS	Tire Pressure Monitoring System	√	√	√		√	



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control		√	√	√	√	Special Features
				AT	Automatic Transaxle	√	√	√	√	√	
				ABSESC	ABS/ESC	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD Control(EST)	√	√	√			
				4WD	4WD Control(TOD)	√	√	√			
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
		2007		ENGINE	Engine Control		√	√	√	√	Special Features
				AT	Automatic Transaxle	√	√	√	√	√	
				ABSESC	ABS/ESC	√	√	√	√	√	
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD Control(EST)	√	√	√			
				4WD	4WD Control(TOD)	√	√	√			
				BCM	Body Control Module	√			√	√	
			G 3.8 DOHC								
			G 3.3 DOHC								



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				CODE	Transmitter Code Saving				√		
		2006	G 3.5 DOHC	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√		
				ABS	Anti-Lock Brake System	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD Control(EST)	√	√	√			
					4WD Control(TOD)		√	√			
		2005	G 3.5 DOHC	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√		
				ABS	Anti-Lock Brake System	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√		
				4WD	4WD Control(EST)	√	√	√			
					4WD Control(TOD)		√	√			
		2004	G 3.5 DOHC	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle		√	√	√	√	
				ABS	Anti-Lock Brake System	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				EPS	Electronic Power Steering	√	√	√	√			
				4WD	4WD Control(EST)	√	√	√				
					4WD Control(TOD)		√	√				
		2003	G 3.5 DOHC	ENGINE	Engine Control		√	√	√	√		
				AT	Automatic Transaxle			√	√	√	√	
				ABS	Anti-Lock Brake System	√	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√	√		
				EPS	Electronic Power Steering	√	√	√	√	√		
				4WD	4WD Control(EST)	√	√	√				
					4WD Control(TOD)			√	√			
				G 3.5 DOHC		ENGINE	Engine Control	√	√	√	√	√
		AT	Automatic Transaxle			√	√	√	√	√	√	
		ESC	Electronic Stability Control					√	√	√	√	
		AIRBAG	All Systems			√	√	√	√	√		
			Airbag(Event #1)			√	√	√	√	√		
			Airbag(Event #2)					√	√		√	
		4WD	4WD Control					√	√	√		
		BCM	Instrument Panel Module			√	√	√	√	√	√	
		IMMO	Immobilizer							√		
		PIC	All Systems			√	√	√	√	√	√	
			Smart Key Unit			√	√	√	√	√	√	
			Power Distribution Module			√	√	√	√	√	√	
			Smart Key Code Saving									
		TPMS	Tire Pressure Monitoring			√	√	√	√	√	√	
		CODE	Transmitter Code Saving					√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
	SORENTO(XM)	2012	G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ESC	Electronic Stability Control		√	√	√	√		
				AIRBAG	All Systems	√	√	√	√			
					Airbag(Event #1)	√	√	√	√			
					Airbag(Event #2)		√	√		√		
				4WD	4WD Control		√	√	√			
				BCM	Instrument Panel Module	√	√	√	√	√		
				IMMO	Immobilizer				√			
				PIC	All Systems	√	√	√	√	√	√	
			Smart Key Unit		√	√	√	√	√	√		
			Power Distribution Module		√	√	√	√	√	√		
			Smart Key Code Saving								Match key	
			TPMS	Tire Pressure Monitoring	√	√	√	√	√	√		
			CODE	Transmitter Code Saving					√			
			G 2.4 GDI	ENGINE	Engine Control	√	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	√	
				ESC	Electronic Stability Control		√	√	√	√	√	
				AIRBAG	All Systems	√	√	√	√			
					Airbag(Event #1)	√	√	√	√			
Airbag(Event #2)		√			√		√					
4WD	4WD Control			√	√	√						
BCM	Instrument Panel Module	√		√	√	√	√	√				
IMMO	Immobilizer				√							
	All Systems	√	√	√	√	√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
				PIC	Smart Key Unit	√	√	√	√	√			
					Power Distribution Module	√	√	√	√	√			
					Smart Key Code Saving						Match key		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√			
				CODE	Transmitter Code Saving				√				
		2011	G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√			
						AT	Automatic Transaxle	√	√	√	√	√	
						ESC	Electronic Stability Control		√	√	√	√	
						AIRBAG	All Systems	√	√	√	√		
							Airbag(Event #1)	√	√	√	√		
							Airbag(Event #2)		√	√		√	
						4WD	4WD Control		√	√	√		
						BCM	Instrument Panel Module	√	√	√	√	√	
						IMMO	Immobilizer				√		
						PIC	All Systems	√	√	√	√	√	
							Smart Key Unit	√	√	√	√	√	
							Power Distribution Module	√	√	√	√	√	
							Smart Key Code Saving						Match key
						TPMS	Tire Pressure Monitoring	√	√	√	√	√	
						CODE	Transmitter Code Saving				√		
				ENGINE	Engine Control	√	√	√	√	√			
				AT	Automatic Transaxle	√	√	√	√	√			
				ESC	Electronic Stability Control		√	√	√	√			
				AIRBAG	All Systems	√	√	√	√				
					Airbag(Event #1)	√	√	√	√				



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 3.5 DOHC		Airbag(Event #2)		√	√		√	
				4WD	4WD Control		√	√	√		
				BCM	Instrument Panel Module	√	√	√	√	√	
				IMMO	Immobilizer				√		
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	
					Smart Key Code Saving						
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		
			G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ESC	Electronic Stability Control	√	√	√	√	√	
				AIRBAG	Weight Classification	√	√	√	√		
				EPS	Motor Driven Power Steering	√	√	√	√		
				BCM	Body Control Module	√			√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√	
					Smart Key Unit	√	√	√	√	√	
					Power Distribution Module	√	√	√	√	√	



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
		2012	G 1.6 GDI		Smart Key Code Saving						Match key	
				TPMS	Tire Pressure Monitoring System	√	√	√	√	√		
				CODE	Transmitter Code Saving					√		
				ENGINE	Engine Control	√	√	√	√	√		self-learning clear
				AT	Automatic Transaxle	√	√	√	√	√		
				ESC	Electronic Stability Control	√	√	√	√	√		
				AIRBAG	Weight Classification	√	√	√	√	√		
				EPS	Motor Driven Power Steering	√	√	√	√	√		
				BCM	Body Control Module	√				√	√	
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
					Smart Key Code Saving							Match key
				TPMS	Tire Pressure Monitoring System	√	√	√	√	√		
		CODE	Transmitter Code Saving					√				
		ENGINE	Engine Control	√	√	√	√	√		Special Features		



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
	SOUL(AM)	2011	G 2.0 DOHC	AT	Automatic Transaxle	√	√	√	√	√	Reset automatically drive shaft value	
				ESC	Electronic Stability Control	√	√	√	√	√		
				AIRBAG	Weight Classification	√	√	√	√			
				EPS	Motor driven Power Steering	√	√	√	√			
				BCM	Body Control Module	√			√	√		
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
					Smart Key Code Saving							Match key
				TPMS	Tire Pressure Monitoring System	√	√	√	√	√		
		CODE	Transmitter Code Saving				√					
		2011	G 1.6 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Special Features
				AT	Automatic Transaxle	√	√	√	√	√	√	Reset automatically drive shaft value
				ESC	Electronic Stability Control	√	√	√	√	√		
				AIRBAG	Weight Classification	√	√	√	√			
				EPS	Motor driven Power Steering	√	√	√	√			
				BCM	Body Control Module	√			√	√		
				PIC	All Systems	√	√	√	√	√		
					Smart Key Unit	√	√	√	√	√		
					Power Distribution Module	√	√	√	√	√		
Smart Key Code Saving										Match key		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
				TPMS	Tire Pressure Monitoring System	√	√	√	√	√			
				CODE	Transmitter Code Saving				√				
		2010	G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	Special Features		
				AT	Automatic Transaxle	√	√	√	√	√	√	Reset automatically drive shaft value	
				ESC	Electronic Stability Control	√	√	√	√	√	√		
				AIRBAG	All Systems	√	√	√	√	√		Real-time information	
					Airbag(Event #1)	√	√	√	√	√		Real-time information	
					Airbag(Event #2)	√	√	√	√	√		Real-time information	
					Weight Classification	√	√	√	√	√			
				EPS	Motor driven Power Steering	√	√	√	√	√			
				BCM	Body Control Module	√				√	√		
				TPMS	Tire Pressure Monitoring System	√	√	√	√	√	√		
				CODE	Transmitter Code Saving						√		
				G 1.6 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Special Features
					AT	Automatic Transaxle	√	√	√	√	√	√	Reset automatically drive shaft value
					ESC	Electronic Stability Control	√	√	√	√	√	√	
		AIRBAG	All Systems		√	√	√	√	√		Real-time information		
			Airbag(Event #1)		√	√	√	√	√		Real-time information		
			Airbag(Event #2)		√	√	√	√	√		Real-time information		
			Weight Classification		√	√	√	√	√				
		EPS	Motor driven Power Steering	√	√	√	√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				BCM	Body Control Module	√			√	√		
				TPMS	Tire Pressure Monitoring System	√	√	√	√	√		
				CODE	Transmitter Code Saving				√			
	SPECTRA(LD)	2009	G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset	
AT				Automatic Transaxle	√	√	√	√	√	√	Reset automatically drive shaft value	
ABS				Anti-Lock Brake	√	√	√	√	√	√		
AIRBAG				Airbag Control		√	√	√				
TPMS				Tire Pressure Monitoring System	√	√	√			√		
		2008	G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Adaptive value reset
AT				Automatic Transaxle	√	√	√	√	√	√	Reset automatically drive shaft value	
ABS				Anti-Lock Brake	√	√	√	√	√	√		
AIRBAG				Airbag Control		√	√	√				
TPMS				Tire Pressure Monitoring System	√	√	√			√		
		2007	G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Adaptive value reset
AT				Automatic Transaxle	√	√	√	√	√	√	Reset automatically drive shaft value	
ABS				Anti-Lock Brake	√	√	√	√	√	√		
AIRBAG				Airbag Control		√	√	√				
TPMS				Tire Pressure Monitoring System	√	√	√			√		



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
		2006	G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√			
				AT	Automatic Transaxle	√	√	√	√				
				ABS	Anti-Lock Brake	√	√	√	√	√			
				AIRBAG	Airbag Control	√	√	√	√				
		2005	G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√			
				AT	Automatic Transaxle	√	√	√	√				
				ABS	Anti-Lock Brake	√	√	√	√	√			
				AIRBAG	Airbag Control	√	√	√	√				
		2004	G 2.0 DOHC	ABS	Anti-Lock Brake	√	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√	√				
				2004	G 1.8 DOHC	ENGINE	Engine Control		√	√	√		
						AT	Automatic Transaxle		√	√	√		
	ABS	Anti-Lock Brake				√	√	√	√				
	AIRBAG	Airbag Control				√	√						
	2003	G 1.8 DOHC	ENGINE	Engine Control		√	√	√					
			AT	Automatic Transaxle		√	√	√					
			ABS	Anti-Lock Brake		√	√	√	√				
			AIRBAG	Airbag Control		√	√						
	2002	G 1.8 DOHC	ENGINE	Engine Control		√	√	√					
			AT	Automatic Transaxle		√	√	√					
			ABS	Anti-Lock Brake		√	√	√	√				
			AIRBAG	Airbag Control		√	√						
	2001	G 1.8 DOHC	ENGINE	Engine Control		√	√	√					
			AT	Automatic Transaxle		√	√	√					
ABS			Anti-Lock Brake		√	√	√	√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
				AIRBAG	Airbag Control		√	√			
				ENGINE	Engine Control						
		2000	G 1.8 DOHC	AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake		√	√	√	√	
				AIRBAG	Airbag Control		√	√			
		2002	G 2.0 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake System		√	√	√	√	Deflated mode
		2001	G 2.0 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake System		√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√	√		
		2000	G 2.0 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake System		√	√	√	√	
		1999	G 2.0 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake System		√	√	√	√	
		1998	G 2.0 DOHC	ENGINE	Engine Control		√	√	√		
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake System		√	√	√	√	
		1997	G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√	
				AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake System		√	√	√	√	
				ENGINE	Engine Control		√	√	√	√	

SPORTAGE (AL)



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
		1996	G 2.0 DOHC	AT	Automatic Transaxle		√	√	√		
				ABS	Anti-Lock Brake System		√	√	√	√	
	1995	G 2.0 DOHC	ENGINE	Engine Control		√	√	√	√		
			AT	Automatic Transaxle		√	√	√			
			ABS	Anti-Lock Brake System		√	√	√	√		
		G 2.0 SOHC	ENGINE	Engine Control		√	√	√	√		
			AT	Automatic Transaxle		√	√	√			
			ABS	Anti-Lock Brake System		√	√	√	√		
	2010	G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Adaptive value reset
			AT	Automatic Transaxle	√	√	√	√	√		
			ESC	Electronic Stability Control	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√			Collision Information	
			4WD	4WD Control	√	√	√				
			ETACS	ETACS	√			√	√		
			TPMS	Tire Pressure Monitoring System	√	√	√		√		
			CODE	Transmitter Code Saving				√			
		G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Adaptive value reset
			AT	Automatic Transaxle	√	√	√	√	√		
			ESC	Electronic Stability Control	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√			Collision Information	
			4WD	4WD Control	√	√	√				
ETACS			ETACS	√			√	√			
TPMS	Tire Pressure Monitoring System	√	√	√		√					



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				CODE	Transmitter Code Saving				√			
		2009	G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√		
				ESC	Electronic Stability Control	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information
				4WD	4WD Control	√	√	√				
				ETACS	ETACS	√			√		√	
				TPMS	Tire Pressure Monitoring System	√	√	√			√	
				CODE	Transmitter Code Saving						√	
			G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√		
				ESC	Electronic Stability Control	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information
				4WD	4WD Control	√	√	√				
				ETACS	ETACS	√				√	√	
		TPMS		Tire Pressure Monitoring System	√	√	√			√		
		CODE		Transmitter Code Saving						√		
		G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Adaptive value reset	
			AT	Automatic Transaxle	√	√	√	√	√			
			ABSESC	ABS/ESC(MGH-25)	√	√	√	√	√	√	Deflated mode	
			ABSESC	ABS/ESC(MGH-40)	√	√	√	√	√	√		
			AIRBAG	Airbag Control	√	√	√				Collision Information	
			4WD	4WD Control	√	√	√					



FCAR F3 Diagnostic List

Automaker
KIA

Software Version:
V6.5

Menu						Function							
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions		
	SPORTAGE (KM)	2008		ETACS	ETACS	√			√	√			
				TPMS	Tire Pressure Monitoring System	√	√	√		√			
				CODE	Transmitter Code Saving				√				
			G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√			
				ABSESC	ABS/ESC(MGH-25)	√	√	√	√	√	√	Deflated mode	
					ABS/ESC(MGH-40)	√	√	√	√	√	√		
				AIRBAG	Airbag Control	√	√	√				Collision Information	
				4WD	4WD Control	√	√	√					
		ETACS		ETACS	√			√		√			
		TPMS		Tire Pressure Monitoring System	√	√	√			√			
		CODE		Transmitter Code Saving				√					
		2007	G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√			
				ABS	Anti-Lock Brake System	√	√	√	√	√	√	Deflated mode	
				AIRBAG	Airbag Control	√	√	√				Collision Information	
				4WD	4WD Control	√	√	√					
				ETACS	ETACS	√			√		√		
			CODE	Transmitter Code Saving				√					
			G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√	√	√	Adaptive value reset
				AT	Automatic Transaxle	√	√	√	√	√	√		
ABS	Anti-Lock Brake System			√	√	√	√	√	√	√	Deflated mode		
AIRBAG	Airbag Control			√	√	√					Collision Information		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
				4WD	4WD Control	√	√	√				
				ETACS	ETACS	√			√	√		
				CODE	Transmitter Code Saving				√			
		2006	G 2.0 DOHC	ENGINE	Engine Control	√	√	√	√	√	Adaptive value reset	
				AT	Automatic Transaxle	√	√	√	√	√		
				ABS	Anti-Lock Brake System	√	√	√	√	√		Deflated mode
				AIRBAG	Airbag Control	√	√	√				Collision Information
				4WD	4WD Control		√	√				
				ETACS	ETACS	√			√	√		
				CODE	Transmitter Code Saving				√			
				G 2.7 DOHC	ENGINE	Engine Control	√	√	√	√	√	√
			AT		Automatic Transaxle	√	√	√	√	√		
			ABS		Anti-Lock Brake System	√	√	√	√	√		Deflated mode
			AIRBAG		Airbag Control	√	√	√				Collision Information
			4WD		4WD Control		√	√				
			ETACS		ETACS	√			√	√		
			2005	G 2.0 DOHC	CODE	Transmitter Code Saving				√		
		ENGINE			Engine Control	√	√	√	√	√	√	Adaptive value reset
		AT			Automatic Transaxle	√	√	√	√	√		
		ABS			Anti-Lock Brake System	√	√	√	√	√		Deflated mode
		AIRBAG			Airbag Control	√	√	√				Collision Information
		4WD			4WD Control		√	√				
		ETACS			ETACS	√			√	√		
		CODE			Transmitter Code Saving				√			



FCAR F3 Diagnostic List

Automaker
KIA

Software
Version:
V6.5

Menu						Function					
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions
			G 2.7 DOHC	AT	Automatic Transaxle	√	√	√	√	√	
				ABS	Anti-Lock Brake System	√	√	√	√	√	Deflated mode
				AIRBAG	Airbag Control	√	√	√			Collision Information
				4WD	4WD Control		√	√			
				ETACS	ETACS	√			√	√	
				CODE	Transmitter Code Saving				√		
			G 2.4 DOHC	ENGINE	Engine Control	√	√	√	√	√	
				AT	Automatic Transaxle	√	√	√	√	√	
				ABSESC	Electronic Stability Control	√	√	√	√	√	
				AIRBAG	Airbag(Event #1)	√	√	√	√		
					Airbag(Event #2)	√	√	√	√		
				EPS	Power Steering	√	√	√	√		
				4WD	4WD Control	√	√	√	√	√	
				BCM	All Systems	√	√	√	√	√	
					Body Control Module	√	√	√	√	√	
					Smart Junction Box	√	√	√	√	√	
				IMMO	Immobilizer						Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√	
				TPMS	Tire Pressure Monitoring	√	√	√	√	√	
				CODE	Transmitter Code Saving				√		



FCAR F3 Diagnostic List

Automaker KIA

Software Version: V6.5

Menu						Function						
District	Series	Year	Type	System	Sub System	ECU INFO.	Read Codes	Erase Codes	Read Data Stream	Actuator Test	Additional Functions	
USA	SPORTAGE (SL)	2011	G 2.0 T-GDI	ENGINE	Engine Control	√	√	√	√	√		
				AT	Automatic Transaxle	√	√	√	√	√		
				ABSESC	Electronic Stability Control	√	√	√	√	√		
				AIRBAG	Airbag(Event #1)	√	√	√	√			
					Airbag(Event #2)	√	√	√	√			
				EPS	Power Steering	√	√	√	√			
				4WD	4WD Control	√	√	√	√	√		
				BCM	All Systems	√	√	√	√	√		
					Body Control Module	√	√	√	√	√		
					Smart Junction Box	√	√	√	√	√		
				IMMO	Immobilizer							Key information Password learning/modify Match Anti-theft reset Safe Mode Neutral mode
				PIC	Smart Key Unit	√	√	√	√	√		
				TPMS	Tire Pressure Monitoring	√	√	√	√	√		
CODE	Transmitter Code Saving					√						