



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
1007VAN	Driver assist device/Comfort	Parking assist	√	√	√	√	—	—
		Air conditioning	√	√	√	√	—	—
		Power-assisted steering	√	√	√	√	—	—
	Notify driver /voice frequency/ Communication	BSI	√	√	√	—	—	—
		telecommunication	√	√	√	√	√	—
		Multi-Function Display	√	√	√	√	—	—
		Audio system	√	√	√	√	—	—
		CD changer	√	√	√	√	—	—
		Combiniation instrument	√	√	√	√	—	—
		Combiniation instrument under steering wheel	√	√	√	√	—	—
		Transmission ECU	√	√	√	√	—	—
	Engine ECU	NFU ME744	√	√	√	√	—	—
		N6A BOSCH ME7.4.5	√	√	√	√	√	Adaptive initialization
		N6B BOSCH ME7.4.5	√	√	√	√	√	Adaptive initialization
		NFU BOSCH ME7.4.5	√	√	√	√	√	Adaptive initialization
		KFV S2000PM2	√	√	√	√	—	—
		KFU MM6LP	√	√	√	√	√	Adaptive system re-centering
		KFV J34P	√	√	√	√	√	Adaptive initialization
	Diesel engine	8HX SIEMENS SID 804	√	√	√	√	—	—
		8HZ SIEMENS SID 804	√	√	√	√	—	—
	Vehicle protection device/Acces	Alarm	√	√	√	√	√	—
		Sliding side door module	√	√	√	√	—	—
	Active and passive safety	ABS or ESP ECU	√	√	√	√	√	Exhaust;Steering wheel angle sensor calibration;Steering wheel angle sensor
		Airbag ECU	√	√	√	√	—	—



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
Visibility/lighting/signal		Rain/brightness sensor	√	√	√	–	–	–
		tion instrument under steer	√	√	√	√	–	–
Driver assist device/Comfort	Vehicle VIN		√	–	–	–	–	–
		Parking assist	√	√	√	√	√	–
		Air conditioning	√	√	√	√	√	–
		Tire pressure detection	√	√	√	√	–	Disable/Enable Tire pressure detection function
		Power-assisted steering	√	√	√	√	–	–
Notify driver/voice frequency/Communication	BSI		√	√	√	√	√	Switching operating mode electrical; Self-learning
	Multi-Function Display	EMF A+	√	√	√	√	√	–
		EMF C-	√	√	√	√	√	–
	Audio system		√	√	√	√	√	–
	CD changer		√	√	√	–	√	–
	Combination instrument		√	√	√	√	√	Maintain
	Hands-free kits		√	√	√	√	√	–
	Combination instrument under steering wheel		√	√	√	√	√	–
	telecommunication		√	√	√	√	√	–
	High frequency receiver		√	√	√	√	–	–
1007CAN	Transmission ECU		√	√	√	√	√	–
	Gasoline	NFU BOSCH ME7.4.5 .	√	√	√	√	√	–
		KFV J34P .	√	√	√	√	√	–
		KFJ MM6LPC .	√	√	√	√	√	–
	Diesel engine	8HX SID 806 DV4 .	√	√	√	√	√	–
		8HZ SID 806 DV4 .	√	√	√	√	√	–
		9HZ BOSCH EDC16C3 .	√	√	√	√	√	–
		9HT BOSCH EDC16C3 .	√	√	√	√	√	–
	Multiplexing additive pump ECU		√	√	√	√	√	–
	Vehicle protection device/Acc		Alarm	√	√	√	√	–



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
Vehicle protection device/Accessories	Active and Passive security	ABS or ESP ECU	Electric side sliding door	√	√	√	√	√
			ABS MK70.1	√	√	√	√	Exhaust;
			ESP MK60-0	√	√	√	√	Exhaust;Steering wheel angle sensor calibration;Steering wheel angle sensor not calibrated
		Airbag ECU	√	√	√	√	—	—
106R	Engine / Automatic transmission	Gasoline Engine	Visibility/lighting/signal	Rain/brightness sensor	√	√	—	—
			Airbag	√	√	√	—	—
			Active safety system	ABS TEVES MKIVGI	√	√	√	—
				ABS TEVES MK20E	√	√	√	Exhaust
			CDY BOSCH MA3.1	CDY BOSCH MA3.1	√	√	√	—
				CDZ BOSCH MA3.1	√	√	√	—
				HDY BOSCH MA3.1	√	√	√	—
				HDZ BOSCH MA3.1	√	√	√	—
			HFX BOSCH M7.4.4	HFX BOSCH M7.4.4	√	√	√	Automatic adjusting device
				KFW SAGEM S2000	√	√	√	Automatic adjusting device initialization
			KFX BOSCH MP7.3	KFX BOSCH MP7.3	√	√	√	Injection control unit Initialization method
				KFX MM1AP	√	√	√	Adjust ignition time; Injection control unit Initialization method



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
		NFX MM1AP	√	√	√	√	√	Adjust ignition time; Injection control unit Initialization method
		NFX MM48P	√	√	√	√	√	Injection control unit Initialization method; Adaptive initialization
		NFZ BOSCH MP5.2	-	√	√	√	-	-
		Diesel Engine	VJU BOSCH VP20	√	√	√	-	-
		VJX BOSCH VP20	√	√	√	√	-	-
		BSI	√	√	√	√	-	-
	Driving information/Communication	multi-functional display screen	√	√	√	-	√	-
		Portable navigation system	√	√	√	√	-	-
		Service module	√	√	√	√	√	Configuration;s statement file
		Airbag and seat belt tensioner	√	√	√	-	-	-
	Airbag	Side airbag (Right side)	√	√	√	-	√	-
		Side airbag (Left side)	√	√	√	-	√	-
		Door/Throttle control	Electric folding sunroof	√	√	√	√	-
	Active Safety(ABS)	Air conditioning	√	√	√	√	√	-
		Anti-lock brakes TEVES	-	-	-	-	-	Exhaust
		ABS MK70	√	√	√	√	√	ABS programming;Exh aust
		7LZ MM5NP	√	√	√	√	√	Adaptive initialization



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu	System	Function					
		Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
206(BC<09075)	Gasoline Engine system	HFX MM4.8P	√	√	√	√	Initialization method of Injection unit;Adaptive initialization
		RFR MM4.8P	√	√	√	√	Initialization method of Injection unit;Adaptive initialization
		RFN MM4.8P	√	√	√	√	Initialization method of Injection unit;Adaptive initialization
		HFY MM1AP	√	√	√	√	Adjust ignition time;Initialization method of Injection unit
		HFZ MM1AP	√	√	√	√	Adjust ignition time;Initialization method of Injection unit
		K6C MM1AP	√	√	√	√	Adjust ignition time;Initialization method of Injection unit
		KFW SAGEM S2000	√	√	√	√	Automatic adjusting device
		K6D SAGEM S2000	√	√	√	√	Automatic adjusting device
		KFX BOSCH MP7.3	√	√	√	√	Initialization method of Injection control unit



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
	Diesel engine	KFX MM1AP	√	√	√	√	√	Adjust ignition time; Initialization method of Injection unit
		N6A BOSCH ME7.4.4	√	√	√	√	√	Automatic adjusting device
		NFU BOSCH ME7.4.4	√	√	√	√	√	Automatic adjusting device
		NFZ BOSCH MP7.2	√	√	√	√	√	Initialization method of Injection control unit
		WJY LUCAS DCN2	√	√	√	√	√	-
		WJZ LUCAS DCN2	√	√	√	√	√	-
		RHY BOSCH EDC15C2	√	√	√	√	√	-
		BVA_AL4_AT8	√	√	√	√	√	-
		Intelligent control box	√	√	√	√	-	-
	Driving information/Communication	Intelligent control box(Siemens)	√	√	√	√	-	-
		Alarm	√	√	√	√	√	-
		Display/Telecommunication (AMF)	√	√	√	√	√	-
		Display/Telecommunication (RT3)	√	√	√	√	√	-
		Audio system	√	√	√	√	√	-
		filament	√	√	√	√	√	-
		CD changer	√	√	√	√	√	-
		Instrument cluster	√	√	√	√	√	-
		Switch unit under steering wheel	√	√	√	√	-	-
	Vision/light	Portable navigation system	√	√	√	√	-	-
		Driving School	√	-	-	√	√	-
		Rain/luminance sensor	√	-	-	√	√	-
	Airbag	SAC CENT AUTOLIV 2	√	√	√	-	-	-



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
206 (BC>09074)	Door/Throttle control	Electric folding sunroof	√	√	√	√	√	—
	Air conditioning		√	√	√	√	√	—
	Active Safety(ABS)	ABS MK70	√	√	√	√	√	ABS programming; Exhaust
		ESP MK60	√	√	√	√	√	Exhaust;Steering wheel angle sensor calibration;Steering wheel angle sensor not calibrated
		7LZ MM5NP	√	√	√	√	√	—
		KFW SAGEM S2000	√	√	√	√	√	Automatic adjusting device
		K6D SAGEM S2000	√	√	√	√	√	Automatic adjusting device
		N6A BOSCH ME7.4.4	√	√	√	√	√	Automatic adjusting device
		NFU BOSCH ME7.4.4	√	√	√	√	√	Automatic adjusting device
		KFW BOSCH ME7.4.4	√	√	√	√	√	Automatic adjusting device
		N6A BOSCH ME7.4.4 FLEX FUEL	√	√	√	√	√	Automatic adjusting device
		NFU BOSCH ME7.4.4 FLEX FUEL	√	√	√	√	√	Automatic adjusting device
		KFW BOSCH ME7.4.4 FLEX FUEL	√	√	√	√	√	Automatic adjusting device



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
Engine system	Gasoline		NFU BOSCH ME745	√	√	√	√	√	Adaptive initialization
			N6A BOSCH ME745	√	√	√	√	√	Adaptive initialization
			RFN MM4.8P	√	√	√	√	√	Initialization method of Injection unit;Adaptive initialization
			HFX MM4.8P	√	√	√	√	√	Initialization method of Injection unit;Adaptive initialization
			KFU MM6LP	√	√	√	√	√	Re-centering of Adaptive system
			RFK MM6LP	√	√	√	√	√	Re-centering of Adaptive system
			RFN MM6LP	√	√	√	√	√	Re-centering of Adaptive system
			KFW J34P	√	√	√	√	√	Adaptive initialization
			K6D J34P	√	√	√	√	√	Adaptive initialization
			NFU or N6A or N6B ME749 BIO FLEX	√	√	√	√	√	Adaptive initialization
			KFW ME749	√	√	√	√	√	Adaptive initialization
			KFW ME749 BIO FLEX	√	√	√	√	√	Adaptive initialization
Diesel engine			8HX/8HZ BOSCH EDC16C3 EURO2	√	√	√	√	-	-
			8HZ BOSCH EDC16C3 EURO4	√	√	√	√	√	-
			9HY BOSCH EDC16C3 EURO4	√	√	√	√	√	-
			9HY BOSCH EDC16C3	√	√	√	√	√	-
			9HZ BOSCH EDC16C3	√	√	√	√	√	-



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function						
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark	
			9HX BOSCH EDC16C3	✓	✓	✓	✓	✓	-	
			RHY BOSCH EDC15C2	✓	✓	✓	✓	✓	-	
			WJY LUCAS DCN2	✓	✓	✓	✓	✓	-	
			9HT BOSCH EDC16C3	✓	✓	✓	✓	-	-	
	Diesel fuel additive control unit			✓	✓	✓	✓	✓	-	
	BVA_AL4_AT8			✓	✓	✓	✓	✓	-	
	Electric pump unit (power steering)			✓	✓	✓	✓	-	-	
	BSI			✓	✓	✓	✓	-	-	
	Driving information/Communication	multi-functional display screen		✓	✓	✓	-	✓	-	
			Portable navigation system	✓	✓	✓	✓	-	-	
		Service module		✓	✓	✓	✓	✓	Configuration; statement file	
	Airbag	Airbag and seat belt tensioner		✓	✓	✓	-	-	-	
			Side airbag (Right side)	✓	✓	✓	-	✓	-	
		Side airbag (Left side)		✓	✓	✓	-	✓	-	
	Door/Throttle control	Electric folding sunroof		✓	✓	✓	✓	✓	-	
	Air conditioning			✓	✓	✓	✓	✓	-	
	Active Safety(ABS)	Anti-lock brakes TEVES	-	-	-	-	-	-	Exhaust	
		ABS MK70	✓	✓	✓	✓	✓	✓	ABS programming;Exhaust	
		7LZ MM5NP	✓	✓	✓	✓	✓	✓	Adaptive initialization	
		HFX MM4.8P	✓	✓	✓	✓	✓	✓	Initialization method of Injection unit;Adaptive initialization	
		RFR MM4.8P	✓	✓	✓	✓	✓	✓	Initialization method of Injection unit;Adaptive initialization	



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu	System	Function						
		Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark	
206MUX (BC<090 75)	Engine system	Gasoline	RFN MM4.8P	√	√	√	√	Initialization method of Injection unit;Adaptive initialization
			HFY MM1AP	√	√	√	√	Adjust ignition time;Initialization method of Injection unit
			HFZ MM1AP	√	√	√	√	Adjust ignition time;Initialization method of Injection unit
			K6C MM1AP	√	√	√	√	Adjust ignition time;Initialization method of Injection unit
			KFW SAGEM S2000	√	√	√	√	Automatic adjusting device
			K6D SAGEM S2000	√	√	√	√	Automatic adjusting device
			KFX BOSCH MP7.3	√	√	√	√	Initialization method of Injection control unit
			KFX MM1AP	√	√	√	√	Adjust ignition time;Initialization method of Injection unit
			N6A BOSCH ME7.4.4	√	√	√	√	Automatic adjusting device
			NFU BOSCH ME7.4.4	√	√	√	√	Automatic adjusting device



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu	System	Function					
		Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
	NFZ BOSCH MP7.2	√	√	√	√	√	Initialization method of Injection control unit
	Diesel engine	WJY LUCAS DCN2	√	√	√	√	—
		WJZ LUCAS DCN2	√	√	√	√	—
		RHY BOSCH EDC15C2	√	√	√	√	—
	BVA_AL4_AT8	√	√	√	√	√	—
	Intelligent control box	√	√	√	√	—	—
	Intelligent control box(Siemens)	√	√	√	√	—	—
	Alarm	√	√	√	√	√	—
	Driving information/Communication	Display/Telecommunication (AMF)	√	√	√	√	—
		Display/Telecommunication (RT3)	√	√	√	√	—
		Audio system	√	√	√	√	—
		filament	√	√	√	√	—
		CD changer	√	√	√	√	—
		Instrument cluster	√	√	√	√	—
		Switch unit under steering wheel	√	√	√	—	—
		Portable navigation system	√	√	√	—	—
	Vision/light	Driving School	√	—	—	√	—
		Rain/luminance sensor	√	—	—	√	—
	Airbag	SAC CENT AUTOLIV 2	√	√	√	—	—
	Door/Throttle control	Electric folding sunroof	√	√	√	√	—
	Air conditioning		√	√	√	√	—
	ABS MK70		√	√	√	√	ABS programming;Exhaust



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu	System	Function						
		Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark	
206MUX (BC>090 74)	Gasoline	Active Safety (ABS)	ESP MK60	√	√	√	√	Exhaust;Steering wheel angle sensor calibration;Steering wheel angle sensor not calibrated
		7LZ MM5NP	KFW SAGEM S2000	√	√	√	√	-
		K6D SAGEM S2000	N6A BOSCH ME7.4.4	√	√	√	√	Automatic adjusting device
		NFU BOSCH ME7.4.4	KFW BOSCH ME7.4.4	√	√	√	√	Automatic adjusting device
		N6A BOSCH ME7.4.4 FLEX FUEL	NFU BOSCH ME7.4.4 FLEX FUEL	√	√	√	√	Automatic adjusting device
		KFW BOSCH ME7.4.4 FLEX FUEL	KFW BOSCH ME745	√	√	√	√	Automatic adjusting device
		NFU BOSCH ME745	N6A BOSCH ME745	√	√	√	√	Adaptive initialization
								Adaptive initialization



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
Engine system	Engine system		RFN MM4.8P	√	√	√	√	√	Initialization method of Injection unit;Adaptive initialization
			HFX MM4.8P	√	√	√	√	√	Initialization method of Injection unit;Adaptive initialization
			KFU MM6LP	√	√	√	√	√	Re-centering of Adaptive system
			RFK MM6LP	√	√	√	√	√	Re-centering of Adaptive system
			RFN MM6LP	√	√	√	√	√	Re-centering of Adaptive system
			KFW J34P	√	√	√	√	√	Adaptive initialization
			K6D J34P	√	√	√	√	√	Adaptive initialization
			NFU or N6A or N6B ME749 BIO FLEX	√	√	√	√	√	Adaptive initialization
			KFW ME749	√	√	√	√	√	Adaptive initialization
			KFW ME749 BIO FLEX	√	√	√	√	√	Adaptive initialization
Diesel engine	Diesel engine		8HX/8HZ BOSCH EDC16C3 EURO02	√	√	√	√	-	-
			8HZ BOSCH EDC16C3 EURO04	√	√	√	√	√	-
			9HY BOSCH EDC16C3 EURO04	√	√	√	√	√	-
			9HY BOSCH EDC16C3	√	√	√	√	√	-
			9HZ BOSCH EDC16C3	√	√	√	√	√	-
			9HX BOSCH EDC16C3	√	√	√	√	√	-
			RHY BOSCH EDC15C2	√	√	√	√	√	-
			WJY LUCAS DCN2	√	√	√	√	√	-
			9HT BOSCH EDC16C3	√	√	√	√	-	-



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function						
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark	
	Diesel fuel additive control unit		✓	✓	✓	✓	✓	-	
	BVA_AL4_AT8		✓	✓	✓	✓	✓	-	
	Electric pump unit (power steering)		✓	✓	✓	✓	-	-	
206 +	Driving auxiliary devices/comfort	Air conditioning	✓	✓	✓	✓	✓	-	
		Electronic power steering pump	✓	✓	✓	✓	-	-	
	BSI		✓	✓	✓	✓	✓	-	
	Inform driver/audio/Communication	Display/Telecommunication	RT3	✓	✓	✓	✓	-	
		Display	✓	✓	✓	✓	✓	-	
		Combination switch under steering wheel	✓	✓	✓	✓	-	-	
		Audio system	Audio system	✓	✓	✓	✓	-	
			Audio system filament	✓	✓	✓	✓	-	
	CD changer		✓	✓	✓	✓	✓	-	
	Instrument cluster	✓	✓	✓	✓	✓	-		
	Stolen vehicle positioning control unit		✓	✓	✓	✓	✓	-	
	Vehicle protection device/visit management		Alarm	✓	✓	-	✓	-	
206 +	Engine	Gasoline	NFU Or N6A ME749 .	✓	✓	✓	✓	✓	Adaptive initialization
			N6A ME749 BIO FLEX .	✓	✓	✓	✓	✓	Adaptive initialization
			KFW ME749 .	✓	✓	✓	✓	✓	Adaptive initialization
			KFW ME749 BIO FLEX .	✓	✓	✓	✓	✓	Adaptive initialization
			KFW J34P .	✓	✓	✓	✓	✓	Adaptive initialization
			HFX J34P .	✓	✓	✓	✓	✓	Adaptive initialization
			N6B Or N6A Or NFU ME745 .	✓	✓	✓	✓	✓	Adaptive initialization
			HPV V34.3 .	✓	✓	✓	✓	✓	-
			KFT V34.3 .	✓	✓	✓	✓	✓	-
			WJY DCN2 .	✓	✓	✓	✓	✓	-



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function						
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark	
207VAN	Diesel engine	RHY EDC15C2 .	✓	✓	✓	✓	✓	✓	-	
		8HZ BOSCH EDC16C3 EURO4 .	✓	✓	✓	✓	✓	✓	-	
		9HY BOSCH EDC16C3 EURO4 .	✓	✓	✓	✓	✓	✓	-	
		8HR EDC17C10_BR2 .	✓	✓	✓	✓	✓	✓	-	
	AL4 AT8 Automatic Transmission			✓	✓	✓	✓	✓	Adaptive initialization	
	Active and passive safety	ABS or ESP ECU	ABS MK70	✓	✓	✓	✓	✓	Exhaust	
			ESP MK60	✓	✓	✓	✓	✓	Exhaust	
	Airbag		✓	✓	✓	-	-	-	-	
	Visibility/lighting/signal		Rain/luminance sensor	✓	✓	✓	-	-	-	
	Driving auxiliary devices/comfort		Air conditioning	✓	✓	✓	✓	✓	-	
207VAN	BSI			✓	✓	✓	✓	✓	-	
	Inform driver/audio/communication	Display/Telecommunication	RT3	✓	✓	✓	✓	✓	-	
			Display	✓	✓	✓	✓	✓	-	
	Combination switch under steering wheel		✓	✓	✓	✓	-	-	-	
	Audio system	Audio system	✓	✓	✓	✓	✓	-	-	
			Audio system filament	✓	✓	✓	✓	✓	-	
	CD changer		✓	✓	✓	✓	✓	-	-	
	Instrument cluster		✓	✓	✓	✓	✓	-	-	
	Stolen vehicle positioning control unit			✓	✓	✓	✓	✓	-	
	Vehicle protection device/visit management		Alarm	✓	✓	✓	-	✓	-	
207VAN	Gasoline	NFU Or N6A ME749 .	✓	✓	✓	✓	✓	✓	Adaptive initialization	
		N6A ME749 BIO FLEX .	✓	✓	✓	✓	✓	✓	Adaptive initialization	
		KFW ME749 .	✓	✓	✓	✓	✓	✓	Adaptive initialization	
		KFW ME749 BIO FLEX .	✓	✓	✓	✓	✓	✓	Adaptive initialization	
		KFW J34P .	✓	✓	✓	✓	✓	✓	Adaptive initialization	



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
<div style="display: flex; align-items: center;"> <span style="font-size: 2em; margin-right: 10px;">Engine</span> <div style="flex-grow: 1; border-left: 1px solid black; padding-left: 10px;"></div> </div>	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">N6B Or N6A Or NFU ME745 .</span> <div style="flex-grow: 1; border-left: 1px solid black; padding-left: 10px;"></div> </div>	HFX J34P .	√	√	√	√	√	√	Adaptive initialization
		HFV V34.3 .	√	√	√	√	√	√	Adaptive initialization
		KFT V34.3 .	√	√	√	√	√	√	—
		WJY DCN2 .	√	√	√	√	√	√	—
	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">Diesel engine</span> <div style="flex-grow: 1; border-left: 1px solid black; padding-left: 10px;"></div> </div>	RHY EDC15C2 .	√	√	√	√	√	—	
		8HZ BOSCH EDC16C3 EURO4 .	√	√	√	√	√	—	
		9HY BOSCH EDC16C3 EURO4 .	√	√	√	√	√	—	
		8HR EDC17C10_BR2 .	√	√	√	√	√	—	
		AL4 AT8 Automatic Transmission	√	√	√	√	√	—	Adaptive initialization
<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">Active and passive safety</span> <div style="flex-grow: 1; border-left: 1px solid black; padding-left: 10px;"></div> </div>	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">ABS or ESP ECU</span> <div style="flex-grow: 1; border-left: 1px solid black; padding-left: 10px;"></div> </div>	ABS MK70	√	√	√	√	√	Exhaust	
		ESP MK60	√	√	√	√	√	Exhaust	
		Airbag	√	√	√	—	—	—	
	Visibility/lighting/signal	Rain/luminance sensor	√	√	√	—	—	—	
	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">Driving auxiliary devices/comfort</span> <div style="flex-grow: 1; border-left: 1px solid black; padding-left: 10px;"></div> </div>	Park assist	√	√	√	√	√	—	
<div style="display: flex; align-items: center;"> <span style="font-size: 2em; margin-right: 10px;">BSI</span> <div style="flex-grow: 1; border-left: 1px solid black; padding-left: 10px;"></div> </div>		Air conditioning	√	√	√	√	√	—	
		Tire pressure detection	√	√	√	√	—	Disable/ Enable Tire pressure detection function	
		Power steering	√	√	√	√	—	—	
		<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">multi-functional display screen</span> <div style="flex-grow: 1; border-left: 1px solid black; padding-left: 10px;"></div> </div>	√	√	√	√	√	Switching operation mode electrical, self-learning, Key matching	
			√	√	√	√	√	—	
			√	√	√	√	√	—	
<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">CD changer</span> <div style="flex-grow: 1; border-left: 1px solid black; padding-left: 10px;"></div> </div>			√	√	√	—	√	—	
			√	√	√	—	√	—	
			√	√	√	—	√	—	



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu	System	Function						
		Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark	
Inform driver/audio/Communication	Instrument cluster	√	√	√	√	√	maintenance (Maintenance mileage zero)	
	Combination switch under steering wheel	√	√	√	√	√	-	
	Hands-free kit	√	√	√	√	√	-	
	Telecommunication(Data Communication ECU)	√	√	√	√	√	-	
	Telecommunication(RNEG Audio navigation)	√	√	√	√	√	-	
	Seat belts not fasten warning lights	√	-	-	-	√	-	
	High frequency receiver	√	√	√	√	-	-	
	Battery charging state	√	√	√	√	-	-	
	Telecommunication unit	√	√	√	√	√	-	
Transmission ECU	Mechanical electronic control Transmission MAP	√	√	√	√	√	-	
	BVA_AL4_AT8	√	√	√	√	√	Adaptive initialization	
207CAN	Gasoline	N6A BOSCH ME7.4.5 .	√	√	√	√	√	Re-centering of Adaptive system(Throttle matching)
		N6B BOSCH ME7.4.5 .	√	√	√	√	√	Re-centering of Adaptive system(Throttle matching)
		NFU BOSCH ME7.4.5 .	√	√	√	√	√	Re-centering of Adaptive system(Throttle matching)
		5FX MED17.4 .	√	√	√	√	√	-
		5FY MED17.4 .	√	√	√	√	√	-
		KFU MM6LPC .	√	√	√	√	√	-
		KFV J34P .	√	√	√	√	√	-
		5FW MEV17.4 .	√	√	√	√	√	-
		MEV17.4EVO	√	√	√	√	√	-



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function						
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark	
Engine system	Engine system		8FS MEV17.4 .	✓	✓	✓	✓	✓	-	
			5FS MEV17.4 .	✓	✓	✓	✓	✓	-	
			8FR MEV17.4 .	✓	✓	✓	✓	✓	-	
			8FP MEV17.4 .	✓	✓	✓	✓	✓	-	
			EP3C 8FP MEV17.4.2 .	✓	✓	✓	✓	✓	-	
			EP3CM 8FP MEV17.4.2 .	✓	✓	✓	✓	✓	-	
			EP3C 8FR MEV17.4.2 .	✓	✓	✓	✓	✓	-	
			EP6C 5FS MEV17.4.2 .	✓	✓	✓	✓	✓	-	
			KFT V34.1 .	✓	✓	✓	✓	✓	-	
			5FR MED17.4 .	✓	✓	✓	✓	✓	-	
	Diesel engine		8HZ BOSCH EDC16C3 EURO4 .	✓	✓	✓	✓	✓	-	
			9HX BOSCH EDC16C3 .	✓	✓	✓	✓	✓	-	
			9HY BOSCH EDC16C3 EURO4 .	✓	✓	✓	✓	✓	-	
			9HZ BOSCH EDC16C3 .	✓	✓	✓	✓	✓	-	
			9HV BOSCH EDC16C3 .	✓	✓	✓	✓	✓	-	
			9HY BOSCH EDC16C3 .	✓	✓	✓	✓	✓	-	
			9HT BOSCH EDC16C3 .	✓	✓	✓	✓	✓	-	
			9HL HDI SID807 .	✓	✓	✓	-	✓	-	
			9HR HDI SID807 .	✓	✓	✓	-	✓	-	
			9HP BOSCH EDC17C10 .	✓	✓	✓	✓	✓	-	
	Vehicle protection device/visit management		8HR BOSCH EDC17C10 .	✓	✓	✓	✓	✓	-	
			9HP EDC17C10_BR2 .	✓	✓	✓	✓	✓	-	
Active and passive safety	ABS or ESP ECU		Complex transmission additive pump ECU	✓	✓	✓	✓	✓	-	
			Vehicle protection device/visit management	Alarm	✓	✓	✓	✓	-	
			folding top	✓	✓	✓	✓	✓	-	
			ABS MK70.1	✓	✓	✓	✓	✓	Exhaust	
			ESP MK60-0	✓	✓	✓	✓	✓	Exhaust;Steering wheel angle sensor calibration;Steering wheel angle sensor not calibrated	



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
207 i	Inform driver/audio/communication	Airbag	√	√	√	-	-	-
		Rain/luminance sensor	√	√	√	-	-	-
		static AFS	√	√	√	√	√	-
		Driving school module	√	√	√	-	√	-
		Combination switch under steering wheel	√	√	√	√	√	-
		Driving auxiliary devices/comfort	Air conditioning	√	√	√	√	-
		BSI		√	√	√	√	-
		Display/Telecommunication	RT3	√	√	√	√	-
			Display	√	√	√	√	-
		Combination switch under steering wheel	√	√	√	√	-	-
207 i	Engine	Audio system	Audio system	√	√	√	√	-
			Audio system filament	√	√	√	√	-
		CD changer	√	√	√	√	√	-
		Instrument cluster	√	√	√	√	√	-
		Stolen vehicle positioning control unit	√	√	√	√	√	-
		Vehicle protection device/visit management	Alarm	√	√	√	-	√
		Gasoline	NFU Or N6A ME749 .	√	√	√	√	√
			N6A ME749 BIO FLEX .	√	√	√	√	√
			KFW ME749 .	√	√	√	√	√
			KFW ME749 BIO FLEX .	√	√	√	√	√
			KFW J34P .	√	√	√	√	√
			HFX J34P .	√	√	√	√	√
			N6B Or N6A Or NFU ME745 .	√	√	√	√	√
			HFV V34.3 .	√	√	√	√	-



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
HOGGAR	Diesel engine	KFT V34.3 .	✓	✓	✓	✓	✓	✓	-
		WJY DCN2 .	✓	✓	✓	✓	✓	✓	-
		RHY EDC15C2 .	✓	✓	✓	✓	✓	✓	-
		8HZ BOSCH EDC16C3 EURO4 .	✓	✓	✓	✓	✓	✓	-
		9HY BOSCH EDC16C3 EURO4 .	✓	✓	✓	✓	✓	✓	-
		8HR EDC17C10_BR2 .	✓	✓	✓	✓	✓	✓	-
	AL4 AT8 Automatic Transmission			✓	✓	✓	✓	✓	Adaptive initialization
	Active and passive safety	ABS MK70	✓	✓	✓	✓	✓	✓	Exhaust
		ESP MK60	✓	✓	✓	✓	✓	✓	Exhaust
	Airbag		✓	✓	✓	-	-	-	-
	Visibility/lighting/signal		Rain/luminance sensor	✓	✓	✓	-	-	-
HOGGAR	Driving auxiliary devices/comfort		Air conditioning	✓	✓	✓	✓	✓	-
	BSI			✓	✓	✓	✓	✓	-
	Inform driver/audio/communication	Display/Telecommunication	RT3	✓	✓	✓	✓	✓	-
		Display	✓	✓	✓	✓	✓	✓	-
		Combination switch under steering wheel		✓	✓	✓	✓	-	-
		Audio system	Audio system	✓	✓	✓	✓	✓	-
			Audio system filament	✓	✓	✓	✓	✓	-
		CD changer		✓	✓	✓	✓	✓	-
		Instrument cluster		✓	✓	✓	✓	✓	-
	Stolen vehicle positioning control unit			✓	✓	✓	✓	✓	-
	Vehicle protection device/visit management		Alarm	✓	✓	✓	-	✓	-
	HOGGAR	NFU Or N6A ME749 .	✓	✓	✓	✓	✓	✓	Adaptive initialization
		N6A ME749 BIO FLEX .	✓	✓	✓	✓	✓	✓	Adaptive initialization
		KFW ME749 .	✓	✓	✓	✓	✓	✓	Adaptive initialization
		KFW ME749 BIO FLEX .	✓	✓	✓	✓	✓	✓	Adaptive initialization



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
<div style="display: flex; align-items: center;"> <span style="font-size: 2em; margin-right: 10px;">Gasoline</span> <div style="flex-grow: 1; display: flex; justify-content: space-between;"> <div style="width: 45%;">Engine</div> <div style="width: 45%; display: flex; justify-content: space-around;"> <div style="width: 33%;">Diesel engine</div> <div style="width: 33%;">AL4 AT8 Automatic Transmission</div> <div style="width: 33%;">Active and passive safety</div> </div> </div> </div>	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">Engine</span> <div style="flex-grow: 1; display: flex; justify-content: space-between;"> <div style="width: 45%;">Gasoline</div> <div style="width: 45%; display: flex; justify-content: space-around;"> <div style="width: 33%;">Diesel engine</div> <div style="width: 33%;">AL4 AT8 Automatic Transmission</div> <div style="width: 33%;">Active and passive safety</div> </div> </div> </div>	KFW J34P .	√	√	√	√	√	Adaptive initialization	
		HFX J34P .	√	√	√	√	√	Adaptive initialization	
		N6B Or N6A Or NFU ME745 .	√	√	√	√	√	Adaptive initialization	
		HFV V34.3 .	√	√	√	√	√	—	
		KFT V34.3 .	√	√	√	√	√	—	
		WJY DCN2 .	√	√	√	√	√	—	
		RHY EDC15C2 .	√	√	√	√	√	—	
		8HZ BOSCH EDC16C3 EURO4 .	√	√	√	√	√	—	
		9HY BOSCH EDC16C3 EURO4 .	√	√	√	√	√	—	
		8HR EDC17C10_BR2 .	√	√	√	√	√	—	
		AL4 AT8 Automatic Transmission		√	√	√	√	√	Adaptive initialization
	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">ABS or ESP ECU</span> <div style="flex-grow: 1; display: flex; justify-content: space-between;"> <div style="width: 45%;">Active and passive safety</div> <div style="width: 45%;">Driver assist device/Comfort</div> </div> </div>	ABS MK70	√	√	√	√	√	Exhaust	
		ESP MK60	√	√	√	√	√	Exhaust	
		Airbag	√	√	√	—	—	—	
	Visibility/lighting/signal	Rain/luminance sensor	√	√	√	—	—	—	
<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">Vehicle VIN</span> <div style="flex-grow: 1; display: flex; justify-content: space-between;"> <div style="width: 45%;">Driver assist device/Comfort</div> <div style="width: 45%; display: flex; justify-content: space-around;"> <div style="width: 33%;">Driver assist device/Comfort</div> <div style="width: 33%;">Vehicle VIN</div> <div style="width: 33%;">Vehicle VIN</div> </div> </div> </div>	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">Vehicle VIN</span> <div style="flex-grow: 1; display: flex; justify-content: space-between;"> <div style="width: 45%;">Driver assist device/Comfort</div> <div style="width: 45%; display: flex; justify-content: space-around;"> <div style="width: 33%;">Driver assist device/Comfort</div> <div style="width: 33%;">Vehicle VIN</div> <div style="width: 33%;">Vehicle VIN</div> </div> </div> </div>	Vehicle VIN	√	—	—	—	—	—	
		Head-up Display	√	√	√	√	√	—	
		Vehicle distance keep auxiliary system	√	√	√	√	—	—	
		Lane departure warning system	√	√	√	√	√	—	
		Air conditioning control unit	√	√	√	√	√	—	
		Parking assist	√	√	√	√	—	—	
		Electronic booster pump	√	√	√	√	√	—	
		Tire pressure detection	√	√	√	√	—	Disable/Enable Tire pressure detection function	
		Electronic parking brake	√	√	√	√	√	—	



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
3008	BSI			√	√	√	√	√
	Notify driver/voice frequency/Communication	voice frequency amplifier	√	√	√	√	—	Switching operating mode electrical; Self-learning
		Multi-Function Display (EMF)	EMF_A	√	√	√	√	—
		EMF_C	√	√	√	√	√	—
		Combiniation instrument under steering wheel	√	√	√	√	√	—
		NOMADE unit	√	√	√	√	√	—
		Audio system	√	√	√	√	√	—
		telecommunication	RNEG Audio navigation	√	√	√	√	—
		Radio navigation NG4	√	√	√	√	√	—
		Service module	√	√	√	√	√	—
		telecommunication unit	√	√	√	√	√	—
		Combiniation instrument	√	√	√	√	√	—
		Combiniation instrument Dot matrix Display	√	√	√	√	√	—
		Battery charging state unit	√	√	√	√	—	—
		CD changer	√	√	√	—	√	—
		Warning lights for No fasten(TNB)	√	—	—	—	√	—
	Engine ECU	Gasoline	5FW MEV17.4 .	√	√	√	√	—
			MEV17.4EVO	√	√	√	√	—
			5FS MEV17.4 .	√	√	√	√	—
			5FX MED17.4 .	√	√	√	√	—
			5FV MED17.4 .	√	√	√	√	—
			5FV MED 17.4.2 Euro5.	√	√	√	√	—
		Diesel Engine	9HZ EDC16C3 .	√	√	√	√	—
			RHH DCM3.5 .	√	√	√	√	—
			RHE DCM3.5 .	√	√	√	√	—
			9HL HDI SID807 .	—	—	—	√	—
			9HR HDI SID807 .	—	—	—	√	—
	Transmission	CFC300P Transmission	√	√	√	√	√	—
		AM6 Euro5 Automatic Transmission	√	√	√	√	√	—



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
		AT6 Euro5 Automatic Transmission	✓	✓	✓	✓	✓	-
		Pompe mux MGI	✓	✓	✓	✓	✓	-
	Multiplexing additive pump	Pompe mux TI	✓	✓	✓	✓	✓	-
		Vehicle protection device/Access Management	Driver side door control panel	✓	✓	✓	✓	-
		Alarm	✓	✓	✓	✓	✓	-
	Active and passive safety	AirbagECU	✓	✓	✓	✓	-	-
		ESP8.1	✓	✓	✓	✓	✓	Exhaust
		ASR+switch	✓	✓	-	✓	✓	-
		Network isolation unit						
	Visibility/lighting/signal	Rain sensor	✓	✓	✓	-	-	-
		Front wiper	✓	✓	✓	-	✓	-
		Front wiper (Parameters measurement )	-	-	-	✓	-	-
		Headlight beam regulator	✓	✓	✓	✓	✓	-
306	Engine system	GasolineEngine	KFX MM1AP	✓	✓	✓	-	-
			RFS MM1AP	✓	✓	✓	-	-
			HDY BOSCH MA3.1	✓	✓	✓	-	-
			HDZ BOSCH MA3.1	✓	✓	✓	-	-
	Airbag	SAC_AKF Airbag		✓	✓	✓	-	Configuration
	Engine	GasolineEngine	KFX BOSCH MP7.3	✓	✓	✓	✓	-
			KFX MM1AP	✓	✓	✓	✓	-
			KFX SAGEM SL96	✓	✓	✓	-	✓
			LFY BOSCH MP7.3	✓	✓	✓	✓	Adaptive initialization
			LFY SAGEM SL96	✓	✓	✓	✓	-
			NFT BOSCH M7.4.4	✓	✓	✓	✓	-
			NFV BOSCH M7.4.4	✓	✓	✓	✓	-
			RFS MM1AP	✓	✓	✓	✓	-



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
306R	system	KFW SAGEM S2000	√	√	√	√	√	Automatic adjusting device initialization ;
			√	√	√	√	-	-
		Diesel Engine	√	√	√	√	-	-
			√	√	√	√	-	-
			√	√	√	√	-	-
			√	√	√	√	-	-
		Transmission	AL4 Gearbox	√	√	√	-	-
		ABS	ABS BOSCH 5.3	√	√	√	√	Exhaust
		Airbag	SAC_AKF Airbag	√	√	√	-	Configuration
			Left Airbag	√	√	√	-	Configuration
			Right Airbag	√	√	√	-	Configuration
	Gasoline	RFN MM6LP	-	√	√	√	√	-
			√	√	√	√	√	Automatic adjusting device initialization ;
		NFU BOSCH ME7.4.4	√	√	√	√	√	Automatic adjusting device initialization ;
			√	√	√	√	√	Automatic adjusting device initialization ;
		N6A BOSCH ME7.4.5	√	√	√	√	√	Automatic adjusting device initialization ;
			√	√	√	√	√	Automatic adjusting device initialization ;
		NFU BOSCH ME7.4.5	√	√	√	√	√	Automatic adjusting device initialization ;



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
307VAN	Engine	Diesel Engine	KWF SAGEM S2000	✓	✓	✓	✓	✓
			RFK MM6LP	✓	✓	✓	✓	✓
			KFU MM6LP	✓	✓	✓	✓	—
			RHZ BOSCH EDC15C2	✓	✓	✓	✓	—
			RHS BOSCH EDC15C2	✓	✓	✓	✓	Service action (particle filter/additional ECU)
		Diesel Fuel additive control unit	RHY BOSCH EDC15C2	✓	✓	✓	✓	—
			8HZ BOSCH EDC16C3	✓	✓	✓	✓	—
			9HY BOSCH EDC16C3	✓	✓	✓	✓	—
			RHY SIEMENS SID801	✓	✓	✓	✓	—
			9HZ BOSCH EDC16C3	✓	✓	✓	✓	—
			RHZ BOSCH EDC15C2	✓	✓	✓	✓	✓
			RHS BOSCH EDC15C2	✓	✓	✓	✓	Service action (particle filter/additional ECU)
			RHY BOSCH EDC15C2	✓	✓	✓	✓	—
			8HZ BOSCH EDC16C3	✓	✓	✓	✓	—
			9HY BOSCH EDC16C3	✓	✓	✓	✓	—
			RHY SIEMENS SID801	✓	✓	✓	✓	—
			9HZ BOSCH EDC16C3	✓	✓	✓	✓	—
		Active safety(ABS)	ABS BOSCH 8	✓	✓	✓	✓	—
			TEVES_MK60_ABS	✓	✓	✓	✓	—
			ABS BOSCH 5.3	✓	✓	✓	✓	✓
			ESP BOSCH 8	✓	✓	✓	✓	Exhaust;Steering wheel angle sensor calibration;Steering wheel angle sensor not calibrated



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu	System	Function						Remark
		Version Info.	Read DTC	Clear DTC	Read Data	Action test		
Automatic transmission	ESP BOSCH 5.7	√	√	√	√	-	Exhaust;Steering wheel angle sensor calibration;Steering wheel angle sensor not calibrated	
	BV4 AL4	√	√	√	√	-	-	
	ZF 4HP20 AT	√	√	√	√	-	-	
	Airbag	SAC Central AIRBAG	√	√	√	-	-	Configuration
	Driver information/Communication	Display/information	-	√	√	√	√	-
		Auxiliary parking system	√	√	√	√	-	
		Instrument panel	√	√	√	√	√	-
		CD player	√	√	√	√	√	-
		Switch unit under steering wheel (COM 2000)	√	√	√	√	-	-
		Radio	√	√	√	√	√	-
	Door switch system	Driver door module	√	√	√	√	-	-
		Passenger door module	√	√	√	√	-	-
		Electric pump unit (Power steering)	√	√	√	√	-	-
		Embedded system interface (BSI)	√	√	√	√	√	-
		Air conditioning	√	√	√	√	√	-
		Alarm	√	√	√	√	-	-
Driver assist/comfort system	Vehicle identification	-	-	-	-	-	-	Vehicle identification
	Park assist	√	√	√	√	√	-	
	Warm wind/ventilation	√	√	√	√	√	-	
	Tire pressure monitoring	√	√	√	√	-	-	Disable/ Enable Tire pressure detection function
	Power steering	√	√	√	√	-	-	



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu	System	Function						
		Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark	
307CAN	Driver information module/audio/Communication	Intelligent box control system(BSI)	√	√	√	√	√	Switching operation mode electrical, self-learning, Key matching
		multi-functional display screen	√	√	√	√	√	-
		Audio system	√	√	√	√	√	-
		CD changer	√	√	√	√	√	-
		Instrument cluster	√	√	√	√	√	-
		Combination switch under steering wheel	√	√	√	√	√	-
		Hands-free kit	√	√	√	√	√	-
		Telecommunication	√	√	√	√	√	-
		Service module	√	√	√	√	√	-
		Diesel additive control unit	√	√	√	√	√	-
307CAN	Engine/Transmission	Transmission	BVA_AL4_AT8	√	√	√	√	Configuration, Adaptive initialization, Engine oil aging counter
		Gasoline engine	N6A BOSCH ME7.4.5.	√	√	√	√	Throttle matching
			N6B BOSCH ME7.4.5.	√	√	√	√	Throttle matching
			NFU BOSCH ME7.4.5.	√	√	√	√	Throttle matching
			KFU MM6LP .	√	√	√	√	-
			RFK MM6LP .	√	√	√	√	-
			RFN MM6LP .	√	√	√	√	-
			RFJ MM6LPB .	√	√	√	√	-
			KFU MM6LPC .	√	√	√	√	-
			NFU Or N6A Or N6B ME749 .	√	√	√	√	Adaptive initialization



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
Vehicle protection/visit management	NFU Or N6A Or N6B ME749 BioFlex.	NFU Or N6A Or N6B ME749 BioFlex.	√	√	√	√	√	Adaptive initialization
		MM6KP BioFlex.	√	√	√	√	√	—
		MM6KP Non-BioFlex.	√	√	√	√	√	—
	Active and passive safety	Alarm	√	√	√	√	√	—
		Driver door module	√	√	√	√	√	—
		Passenger door module	√	√	√	√	√	—
		Folding top	√	√	√	√	√	—
		skylight	√	√	√	√	√	—
Visibility/brightness/signal	ABS or /ESPECU	ABS BOSCH 8	√	√	√	√	√	Exhaust
		ESP BOSCH 8	√	√	√	√	√	Exhaust;Steering wheel angle sensor calibration;Steering wheel angle sensor not calibrated
		ABS BOSCH 8.1	√	√	√	√	√	Exhaust
		ESP BOSCH 8.1	√	√	√	√	√	Exhaust
		Airbag ECU	√	√	√	√	—	—
	Driving auxiliary devices/comfort	Rain/sun sensor	√	√	√	—	—	—
		Right side Headlamp light regulator	√	√	√	√	√	Calibration
		Left side Headlamp light regulator	√	√	√	√	√	Calibration
		Driving school module	√	√	√	—	√	—
		Combination switch under steering wheel	√	√	√	√	√	—



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu	System	Function						
		Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark	
Inform driver/audio/communication	Tire pressure detection	√	√	√	√	-	Disable/ Enable Tire pressure detection function	
	Intelligent box control system(BSI)	√	√	√	√	√	Switching operation mode electrical, self-learning	
	multi-functional display screen	√	√	√	√	√	-	
	Audio system	√	√	√	√	√	-	
	Instrument cluster	√	√	√	√	√	maintenance	
	Hands-free kit	√	√	√	√	√	-	
	Not fasten warning lights(TNB)	√	-	-	-	√	-	
	Data Communication ECU	√	√	√	√	√	-	
	Telecommunication	RNEG Audio navigation	√	√	√	√	-	
		Radio navigation NG4	√	√	√	√	-	
	Combination switch under steering wheel	√	√	√	√	√	-	
	Audio amplifier	√	√	√	-	√	-	
	Service module	√	√	√	√	√	-	
	Telecommunication unit	√	√	√	√	√	-	
	Instrument cluster dot matrix display	√	√	√	√	√	-	
	Battery charging state unit	√	√	√	√	-	-	
Gasoline	N6A ME745 . N6B ME745 . NFU ME745 . RFJ MM6LPB . 5FW MEV17.4 . 8FS MEV17.4 . 5FS MEV17.4 . 8FR MEV17.4 . 5FV MED17.4 .	N6A ME745 .	√	√	√	√	√	Adaptive initialization
		N6B ME745 .	√	√	√	√	√	Adaptive initialization
		NFU ME745 .	√	√	√	√	√	Adaptive initialization
		RFJ MM6LPB .	√	√	√	√	√	-
		5FW MEV17.4 .	√	√	√	√	√	-
		8FS MEV17.4 .	√	√	√	√	√	-
		5FS MEV17.4 .	√	√	√	√	√	-
		8FR MEV17.4 .	√	√	√	√	√	-
		5FV MED17.4 .	√	√	√	√	√	-



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
308	Engine		5FT MED17.4 .	✓	✓	✓	✓	✓	-
			5FY MED17.4 .	✓	✓	✓	✓	✓	-
			5FX MED17.4 .	✓	✓	✓	✓	✓	-
			5FU MEVD17.4.2 .	✓	✓	✓	✓	✓	-
			MM6KP Non-BioFlex.	✓	✓	✓	✓	✓	-
			MM6KP BioFlex.	✓	✓	✓	✓	✓	-
			NFU ME749 BioFlex.	✓	✓	✓	✓	✓	Adaptive initialization
			EP6C 5FS MEVD17.4.2 .	✓	✓	✓	✓	✓	-
			EP3C 8FP MEVD17.4.2 .	✓	✓	✓	✓	✓	-
			EP3C 8FR MEVD17.4.2 .	✓	✓	✓	✓	✓	-
	Diesel		9HV EDC16C3 .	✓	✓	✓	✓	✓	-
			9HX EDC16C3 .	✓	✓	✓	✓	✓	-
			9HY EDC16C3 .	✓	✓	✓	✓	✓	-
			9HZ EDC16C3 .	✓	✓	✓	✓	✓	-
			RHR DCM3.4 .	✓	✓	✓	✓	✓	-
			RHL DCM3.4 .	✓	✓	✓	✓	✓	-
			RHF DCM3.4 .	✓	✓	✓	✓	✓	-
			9HL HDI_SID807 .	✓	✓	✓	-	✓	-
			9HR HDI_SID807 .	✓	✓	✓	-	✓	-
			9HR HDI_SID807_BR2 .	✓	✓	✓	✓	✓	-
			9HG HDI_SID807_BR2 .	✓	✓	✓	✓	✓	-
			9HL HDI_SID807_BR2 .	✓	✓	✓	✓	✓	-
			RHH DCM3.5 .	✓	✓	✓	✓	✓	-
			RHE DCM3.5 .	✓	✓	✓	✓	✓	-
			9HP EDC17C10 .	✓	✓	✓	✓	✓	-
			8HR EDC17C10 .	✓	✓	✓	✓	✓	-
			9HP EDC17C10_BR2 .	✓	✓	✓	✓	✓	-
			9HJ EDC17C10_BR2 .	✓	✓	✓	✓	✓	-
	Transmission ECU		AM6C Transmission	✓	✓	✓	✓	✓	-
			AM6 Euro5 Transmission	✓	✓	✓	✓	✓	-
			AT6 Euro5 Transmission	✓	✓	✓	✓	✓	-



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
Complex transmission additive pump ECU	CFC300P Transmission	CFC300P Transmission	√	√	√	√	√	—
		AL4 AT8 Transmission	√	√	√	√	√	Adaptive initialization
	Pompe mux MG1	Pompe mux MG1	√	√	√	√	√	—
		Pompe mux TI	√	√	√	√	√	—
	Vehicle protection device/visit management	Alarm	√	√	√	√	√	—
		Driver door control panel	√	√	√	√	√	—
	Active and passive safety	ABS 8.1	√	√	√	√	√	Exhaust
		ESP 8.1	√	√	√	√	√	Exhaust
	Airbag		√	√	√	√	—	—
	Visibility/lighting/signal	Rain sensor	√	√	√	—	—	—
		Xenon headlamps vertical and horizontal adjustment	√	√	√	√	√	—
		Driving school module	√	√	√	—	√	—
Driving auxiliary devices/comfort	Driving auxiliary devices/comfort	Air conditioning	√	√	√	√	√	—
		Electronic power steering pump	√	√	√	√	√	—
		Driver seat position memory unit	√	√	√	√	√	—
		Park assist	√	√	√	√	—	—
		Tire pressure detection	√	√	√	√	—	Disable/ Enable Tire pressure detection function
		Active deflector	√	√	√	√	√	—
	Intelligent box control system(BSI)	Pedestrian collision detection unit	√	√	√	—	√	—
		Intelligent box control system(BSI)	√	√	√	√	√	Switching operation mode electrical, self-learning
		multi-functional display screen	√	√	√	√	√	—
		Audio system	√	√	√	√	√	—
	Instrument cluster	Instrument cluster	√	√	√	√	√	maintenance



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
RCZ	Inform driver/audio/communication	Not fasten warning lights(TNB)	✓	-	-	-	✓	-
		Telecommunication	Radio navigation NG4	✓	✓	✓	✓	-
		Combination switch under steering wheel	✓	✓	✓	✓	✓	-
		CD changer	✓	✓	✓	-	✓	-
		Audio amplifier	✓	✓	✓	-	✓	-
		Service module	✓	✓	✓	✓	✓	-
		Instrument cluster dot matrix display	✓	✓	✓	✓	✓	-
		Battery charging state unit	✓	✓	✓	✓	-	-
	Gasoline	5FW MEV17.4 .	✓	✓	✓	✓	✓	-
		8FS MEV17.4 .	✓	✓	✓	✓	✓	-
		5FS MEV17.4 .	✓	✓	✓	✓	✓	-
		8FR MEV17.4 .	✓	✓	✓	✓	✓	-
		5FV MED17.4 .	✓	✓	✓	✓	✓	-
		5FT MED17.4 .	✓	✓	✓	✓	✓	-
		5FY MED17.4 .	✓	✓	✓	✓	✓	-
		5FX MED17.4 .	✓	✓	✓	✓	✓	-
		5FU MEVD17.4.2 .	✓	✓	✓	✓	✓	-
		Diesel	RHH DCM3.5 .	✓	✓	✓	✓	-
	Transmission ECU	RHE DCM3.5 .	✓	✓	✓	✓	✓	-
		AM6 Euro5 Transmission	✓	✓	✓	✓	✓	-
		AT6 Euro5 Transmission	✓	✓	✓	✓	✓	-
		Complex transmission additive pump ECU	Pompe mux TI	✓	✓	✓	✓	-
Visibility/lighting/signal	Vehicle protection device/visit management	Alarm	✓	✓	✓	✓	✓	-
		Driver side door control panel	✓	✓	✓	✓	✓	-
	Active and passive safety	ABS 8.1	✓	✓	✓	✓	✓	Exhaust
		ESP 8.1	✓	✓	✓	✓	✓	-
	Airbag		✓	✓	✓	✓	-	-
	Rain sensor		✓	✓	✓	-	-	-
	Xenon headlamps vertical and horizontal adjustment		✓	✓	✓	✓	✓	-



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
4007	Visibility/lighting/signal	Front wiper	√	√	√	√	-	-
		Front wiper system data stream	-	-	-	-	-	-
4007	Vehicle VIN		√	-	-	-	-	-
	Driver assist device/Comfort	Air conditioning	√	√	√	√	√	-
	BSI		√	√	√	√	√	-
	Notify driver/voice frequency/Communication	Audio system	√	√	√	√	√	-
		Navigationsystem	√	√	√	-	-	-
		Combiniation instrument	√	√	√	√	√	-
		Hands-free kits	√	√	√	√	√	-
	Engine ECU	Gasoline	SFZ 4B12 MIVEC EURO4 .	√	√	√	√	-
			AFZ 4B11 MIVEC EURO4 .	√	√	√	√	-
		Diesel Engine	SFY 4B12 MIVEC EURO5 .	√	√	√	√	-
	Transmission		4HN EDC16CP39 .	√	√	√	√	-
			4HK EDC16CP39 EURO5 .	√	√	√	√	-
	4x4Transmission		CTV Transmission	√	√	√	-	-
			DCT control Transmission	√	√	√	-	-
	LEVIER GETRAG		√	√	√	√	√	-
	Vehicle protection device/Access Management		Anti-start password	√	√	√	-	-
			Driver side door control panel	√	√	√	-	-
			Passenger side door control panel	√	√	√	-	-
			Left rear door controller	√	√	√	-	-
			Right rear door controller	√	√	√	-	-
			Sunroof	√	√	√	-	-
	Active and passive safety		Airbag	√	√	√	√	-
	ABS or ESP ECU	ABS.	√	√	√	√	√	-
		ESP.	√	√	√	√	√	-
	Flywheel angle sensor		√	√	√	-	-	-
			Static AFS	√	√	√	√	-



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu	System	Function					
		Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
	Visibility/lighting/signal	Rainfall and luminance sensors	√	√	√	√	—
405	Engine/Transmission	BFZ SAGEM 4GJ	√	√	√	√	—
		L6A SAGEM SL96	√	√	√	√	—
		1600RD SL96	√	√	√	√	—
		N6A ME7.4.4	√	√	√	√	Adaptive initialization
		N6B ME7.4.4	√	√	√	√	Adaptive initialization
		NFU ME7.4.4	√	√	√	√	Adaptive initialization
		LFZ SAGEM S2000	√	√	√	√	Adaptive initialization
		1600RD SAGEM S2000	√	√	√	√	Adaptive initialization
		LFY BOSCH MP7.3	√	√	√	√	Adaptive initialization
		NFU J35	√	√	√	√	Adaptive initialization
		BVA_AL4_AT8	√	√	√	√	—
	Driving auxiliary devices/comfort	Air conditioning	√	√	√	—	√
		Driver seat position memory unit	√	√	√	√	√
		Park assist	√	√	√	√	—
		Tire pressure detection	√	√	√	√	Disable/ Enable Tire pressure detection function
		skylight	√	√	√	√	—
	Intelligent box control system(BSI)		√	√	√	√	Switching operation mode electrical, self-learning
	multi-functional display screen	multi-functional display screen	√	√	√	√	—
		Audio system	√	√	√	√	—
		Instrument cluster	√	√	√	√	maintenance



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
408	Inform driver/audio/communication	Not fasten warning lights(TNB)	✓	-	-	-	✓	-
		RNEG Audio navigation	✓	✓	✓	✓	✓	-
		Telecommunication	✓	✓	✓	✓	✓	-
		RNEG Audio navigation C	✓	✓	✓	✓	✓	-
		ECU RNEG2004EC0	✓	✓	✓	✓	✓	-
		Combination switch under steering wheel	✓	✓	✓	✓	✓	-
		Audio amplifier	✓	✓	✓	-	✓	-
	Engine	Instrument cluster dot matrix display	✓	✓	✓	✓	✓	-
		Stolen vehicle positioning control unit	✓	✓	✓	✓	✓	-
		TU5JP4 ME745 .	✓	✓	✓	✓	✓	Adaptive initialization
		RFJ MM6LPB .	✓	✓	✓	✓	✓	-
		MM6KP Non-BioFlex.	✓	✓	✓	✓	✓	-
		MM6KP BioFlex.	✓	✓	✓	✓	✓	-
		NFU ME749 BioFlex.	✓	✓	✓	✓	✓	Adaptive initialization
	Diesel	9HR HDI_SID807_BR2 .	✓	✓	✓	✓	✓	-
		9HG HDI_SID807_BR2 .	✓	✓	✓	✓	✓	-
		9HL HDI_SID807_BR2 .	✓	✓	✓	✓	✓	-
	AL4 AT8 Transmission		✓	✓	✓	✓	✓	Adaptive initialization
	Vehicle protection device/visit management	Alarm	✓	✓	✓	✓	✓	-
		Driver side door control panel	✓	✓	✓	✓	✓	-
	Active and passive safety	ABS 8.1	✓	✓	✓	✓	✓	-
		ESP 8.1	✓	✓	✓	✓	✓	-
	Airbag		✓	✓	✓	✓	-	-
	Visibility/lighting/signal	Rain sensor	✓	✓	✓	-	-	-
		Xenon headlamps vertical and horizontal adjustment	✓	✓	✓	✓	✓	-
	Protect the vehicle	Transponder PEUGEOT	✓	✓	✓	✓	-	-
	Airbag	Side Airbag (Right side)	✓	✓	✓	-	✓	-
		Side Airbag (Left side)	✓	✓	✓	-	✓	-
		ABS5 BOSCH	✓	✓	✓	✓	✓	-



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
406	Active safety system	ABS BOSCH 5.3	✓	✓	✓	✓	✓	排气
		Electronic control suspension	✓	✓	✓	✓	-	-
	Engine	LFX MM1AP	✓	✓	✓	✓	✓	-
		LFY BOSCH MP7.3	✓	✓	✓	✓	✓	-
		LFY SAGEM SL 96	✓	✓	✓	✓	✓	-
		XFZ BOSCH MP7.0	✓	✓	✓	✓	✓	-
		P8C LUCAS EPIC	✓	-	-	✓	-	-
	Diesel Engine	RHZ BOSCH EDC15C2	✓	✓	✓	✓	✓	-
		4HP20Automatic Transmission	✓	✓	✓	✓	✓	-
	Automatic Transmission	BVA_AL4_AT8	✓	✓	✓	✓	✓	-
		Speed related Power-assisted steering	✓	✓	✓	-	-	-
		Seat position memory control unit	✓	✓	✓	✓	-	-
		Protect the vehicle	Transponder PEUGEOT	✓	✓	✓	-	-
406 coupe	Airbag	Side Airbag (Right side)	✓	✓	✓	-	✓	-
		Side Airbag (Left side)	✓	✓	✓	-	✓	-
	Active safety system	BOSCH ABS5	✓	✓	✓	✓	✓	-
		BOSCH ABS5.3	✓	✓	✓	✓	✓	排气
	Engine /Automatic Transmission	Gasoline	XFZ BOSCH MP7.0	✓	✓	✓	✓	-
		4HP20Automatic Transmission	✓	✓	✓	✓	✓	-
		BVA_AL4_AT8	✓	✓	✓	✓	✓	-
	Speed related Power-assisted steering		✓	✓	✓	-	-	-
	Seat position memory control unit		✓	✓	✓	✓	-	-
	BSI		✓	✓	✓	✓	✓	-
	Driver information/Communication	Multi-Function Display	✓	✓	✓	✓	✓	-
		Audio system	✓	✓	✓	✓	✓	-
		CD changer	✓	✓	✓	✓	✓	-
		Combination instrument	✓	✓	✓	✓	✓	-
	Airbag	Portable navigation system	✓	✓	✓	✓	-	-
		Airbag and seat belt tensioner	✓	✓	✓	-	-	-
		Side Airbag (Right side)	✓	✓	✓	-	✓	-
		Side Airbag (Left side)	✓	✓	✓	-	✓	-



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
406R(BC<09000 )	Engine	Gasoline	Air conditioning	√	√	√	√	—
			BOSCH ABS 5.3	√	√	√	√	Exhaust
			ESP BOSCH 5.3	√	√	√	√	—
			Electronic control suspension	√	√	√	√	—
			3FZ MM4MP2	√	√	√	√	Adaptive system re-centering
			6FZ SAGEM S2000	√	√	√	√	Automatic adjusting device
			RLZ SIEMENS SIRIUS 81	√	√	√	√	Adaptive initialization
			LFX MM1AP	√	√	√	√	Adjust ignition time; Injection unit initialization method
			LFY BOSCH MP5.2	—	√	√	—	—
			LFY BOSCH MP7.3	√	√	√	√	Injection control unit Initialization method
			LFY SAGEM SL 96	√	√	√	√	—
			R6E BOSCH MP5.2	—	√	√	—	—
			R6F MM4.8P	√	√	√	√	Injection unit initialization method; Adaptive initialization
			RFR MM4.8P	√	√	√	√	Injection unit initialization method; Adaptive initialization
			RFN MM4.8P	√	√	√	√	Injection unit initialization method; Adaptive initialization
			RFV BOSCH MP5.2	—	√	√	—	—



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function						
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark	
<div style="display: flex; align-items: center;"> <span style="font-size: 2em; margin-right: 10px;">●</span> <span>FCAR</span> </div> <div style="display: flex; justify-content: space-between;"> <span>FCAR F3 Diagnostic List</span> <span>(Note: For reference only)</span> </div>	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">●</span> <span>FCAR</span> </div>	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">●</span> <span>FCAR</span> </div>	XFX BOSCH ME7.4.6	✓	✓	✓	✓	✓	Adaptive initialization	
			XFZ BOSCH MP7.0	✓	✓	✓	✓	✓	Injection control unit Initialization method	
	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">●</span> <span>Diesel Engine</span> </div>		4HX BOSCH EDC15C2	✓	✓	✓	✓	✓	—	
			RHY BOSCH EDC15C2	✓	✓	✓	✓	✓	—	
			RHZ BOSCH EDC15C2	✓	✓	✓	✓	✓	—	
	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">●</span> <span>Automatic Transmission</span> </div>		4HP20_1	✓	✓	✓	✓	—	—	
			4HP20_2	✓	✓	✓	✓	✓	Adaptive initialization	
			BVA_AL4_AT8	✓	✓	✓	✓	✓	—	
	Speed related Power-assisted steering			✓	✓	✓	—	—	—	
	Seat position memory control unit			✓	✓	✓	✓	—	—	
<div style="display: flex; align-items: center;"> <span style="font-size: 2em; margin-right: 10px;">●</span> <span>FCAR</span> </div> <div style="display: flex; justify-content: space-between;"> <span>FCAR F3 Diagnostic List</span> <span>(Note: For reference only)</span> </div>	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">●</span> <span>FCAR</span> </div>	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">●</span> <span>FCAR</span> </div>	BSI	✓	✓	✓	✓	✓	—	
			Alarm	✓	✓	✓	✓	✓	—	
			Multi-Function Display	✓	✓	✓	✓	✓	—	
			Combination instrument	✓	✓	✓	✓	✓	—	
			Audio system	✓	✓	✓	✓	✓	—	
			CD changer	✓	✓	✓	✓	✓	—	
			Portable navigation system	✓	✓	✓	✓	—	—	
	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">●</span> <span>Driver information / Communication</span> </div>		Switch unit under steering wheel (COM 2000)	✓	✓	✓	✓	—	—	
			Vision/light	Rain/brightness sensor	✓	✓	✓	—	—	
			Airbag		✓	✓	✓	—	—	
			Air conditioning		✓	✓	✓	✓	✓	
	<div style="display: flex; align-items: center;"> <span style="font-size: 1.5em; margin-right: 10px;">●</span> <span>FCAR</span> </div>		Active safety system	BOSCH ABS 5.3	✓	✓	✓	✓	✓	
				ESP BOSCH 5.3	✓	✓	✓	✓	✓	
	<span style="font-size: 1.5em; margin-right: 10px;">●</span> <span>FCAR</span>			3FZ MM4MP2	✓	✓	✓	✓	Adaptive system re-centering	
	<span style="font-size: 1.5em; margin-right: 10px;">●</span> <span>FCAR</span>			6FZ SAGEM S2000	✓	✓	✓	✓	Automatic adjusting device	



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
406R(BC>09000 )	Engine	Gasoline	R6F MM4.8P	√	√	√	√	√	Injection unit initialization method;Adaptive initialization
			RFN MM4.8P	√	√	√	√	√	Injection unit initialization method;Adaptive initialization
			XFX BOSCH ME7.4.6	√	√	√	√	√	Adaptive initialization
			RLZ IDE SIRIUS 81	√	√	√	√	√	Adaptive initialization
			RFV BOSCH MP5.2	-	√	√	√	-	-
		Diesel Engine	4HX BOSCH EDC15C2	√	√	√	√	√	-
			RHS BOSCH EDC15C2	√	√	√	√	√	-
			RHY BOSCH EDC15C2	√	√	√	√	√	-
			RHZ BOSCH EDC15C2	√	√	√	√	√	-
			RHY SIEMENS SID 801	√	√	√	√	√	-
	Diesel additive control unit			√	√	√	√	√	-
	Automatic Transmission	4HP20 Transmission	4HP20_1	√	√	√	√	-	-
			4HP20_2	√	√	√	√	√	Adaptive initialization
		BVA_AL4_AT8	√	√	√	√	√	√	-
	Speed related Power-assisted steering			√	√	√	-	-	-
	Seat position memory control unit			√	√	√	√	-	-
	BSI			√	√	√	√	√	-
	Driver information/Communication	Multi-Function Display		√	√	√	√	√	-
		Audio system		√	√	√	√	√	-
		CD changer		√	√	√	√	√	-
		Combination instrument		√	√	√	√	√	-
	Airbag	Portable navigation system		√	√	√	√	-	-
		Airbag and seat belt tensioner		√	√	√	-	-	-
		Side Airbag (Right side)		√	√	√	-	√	-
		Side Airbag (Left side)		√	√	√	-	√	-



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
406R COUPE(BC<0900 0)	Engine	Gasoline	Air conditioning	√	√	√	√	—
			BOSCH ABS 5.3	√	√	√	√	√ Exhaust
			ESP BOSCH 5.3	√	√	√	√	—
			Electronic control suspension	√	√	√	√	—
			3FZ MM4MP2	√	√	√	√	Adaptive system re-centering
			6FZ SAGEM S2000	√	√	√	√	Automatic adjusting device
			RLZ SIEMENS SIRIUS 81	√	√	√	√	Adaptive initialization
			LFX MM1AP	√	√	√	√	Adjust ignition time; Injection unit initialization method
			LFY BOSCH MP5.2	—	√	√	—	—
			LFY BOSCH MP7.3	√	√	√	√	Injection control unit Initialization method
			LFY SAGEM SL 96	√	√	√	√	—
			R6E BOSCH MP5.2	—	√	√	—	—
			R6F MM4.8P	√	√	√	√	Injection unit initialization method; Adaptive initialization
			RFR MM4.8P	√	√	√	√	Injection unit initialization method; Adaptive initialization
			RFN MM4.8P	√	√	√	√	Injection unit initialization method; Adaptive initialization
			RFV BOSCH MP5.2	—	√	√	—	—



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
			XFX BOSCH ME7.4.6	√	√	√	√	√	Adaptive initialization
			XFZ BOSCH MP7.0	√	√	√	√	√	Injection control unit Initialization method
		Diesel Engine	4HX BOSCH EDC15C2	√	√	√	√	√	—
			RHY BOSCH EDC15C2	√	√	√	√	√	—
			RHZ BOSCH EDC15C2	√	√	√	√	√	—
	Automatic Transmission	4HP20_1	√	√	√	√	—	—	
		4HP20_2	√	√	√	√	√	√	Adaptive initialization
		BVA_AL4_AT8	√	√	√	√	√	√	—
	Speed related Power-assisted steering			√	√	√	—	—	—
	Seat position memory control unit			√	√	√	√	—	—
		BSI		√	√	√	√	√	—
		Alarm		√	√	√	√	√	—
		Driver information / Communication	Multi-Function Display	√	√	√	√	√	—
			Combination instrument	√	√	√	√	√	—
			Audio system	√	√	√	√	√	—
			CD changer	√	√	√	√	√	—
			Portable navigation system	√	√	√	√	—	—
	Active safety system	Switch unit under steering wheel (COM 2000)		√	√	√	√	—	—
		Vision/light		Rain/brightness sensor	√	√	√	—	—
		Airbag		√	√	√	—	—	—
		Air conditioning		√	√	√	√	√	
		BOSCH ABS 5.3	√	√	√	√	√	√	Exhaust
			ESP BOSCH 5.3	√	√	√	√	√	—
		3FZ MM4MP2	√	√	√	√	√	√	Adaptive system re-centering
		6FZ SAGEM S2000	√	√	√	√	√	√	Automatic adjusting device



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
406R COUPE(BC>0900 0)	Engine	Gasoline	R6F MM4.8P	√	√	√	√	√	Injection unit initialization method;Adaptive initialization
			RFN MM4.8P	√	√	√	√	√	Injection unit initialization method;Adaptive initialization
			XFX BOSCH ME7.4.6	√	√	√	√	√	Adaptive initialization
			RLZ IDE SIRIUS 81	√	√	√	√	√	Adaptive initialization
			RFV BOSCH MP5.2	-	√	√	√	-	-
		Diesel Engine	4HX BOSCH EDC15C2	√	√	√	√	√	-
			RHS BOSCH EDC15C2	√	√	√	√	√	-
			RHY BOSCH EDC15C2	√	√	√	√	√	-
			RHZ BOSCH EDC15C2	√	√	√	√	√	-
			RHY SIEMENS SID 801	√	√	√	√	√	-
	Diesel additive control unit			√	√	√	√	√	-
	Automatic Transmission	4HP20 Transmission	4HP20_1	√	√	√	√	-	-
			4HP20_2	√	√	√	√	√	Adaptive initialization
		BVA_AL4_AT8	√	√	√	√	√	√	-
	Speed related Power-assisted steering			√	√	√	-	-	-
	Seat position memory control unit			√	√	√	√	-	-
Driver assist	Vehicle VIN			√	-	-	-	-	-
	Driver seat position memory unit	Parking assist	√	√	√	√	√	-	-
		Driver seat position memory unit	√	√	√	√	√	√	-
		Passenger seat memory unit	√	√	√	√	√	√	-
	Air conditioning	407 Air conditioning	√	√	√	√	√	√	-
		407 revamped Air conditioning	√	√	√	√	√	√	-
	Auxiliary heating device			√	√	√	√	√	-



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
407	device/Comfort	Tire pressure detection	√	√	√	√	-	Disable/Enable Tire pressure detection function
		Power-assisted steering	√	√	√	√	√	-
		Controlled suspension device	√	√	√	-	-	-
		Battery charging state unit	√	√	√	√	-	-
		Stop and start Battery charging state unit	√	√	√	√	-	-
	BSI		√	√	√	√	√	Switching operating mode electrical; Self-learning
	Notify driver/voice frequency/Communication	Multi-Function Display	√	√	√	√	√	-
		Audio system	√	√	√	√	√	-
		CD changer	√	√	√	-	√	-
		Combiniation instrument	√	√	√	√	√	Maintain
		Combiniation instrument under steering wheel	√	√	√	√	√	-
		Hands-free kits	√	√	√	√	√	-
		telecommunication	Data Communication ECU	√	√	√	√	-
			RNEG Audio navigation	√	√	√	√	-
		High frequency receiver	√	√	√	√	-	-
	NOMADE unit		√	√	√	√	√	-
	Diesel additive control unit		√	√	√	√	√	-
	Transmission ECU	AM6 Automatic Transmission	√	√	√	-	√	-
		BVA_AL4_AT8	√	√	√	-	√	-
		4HP20 Automatic Transmission	√	√	√	√	-	Adaptive initialization
		AM6 Euro5 Automatic Transmission	√	√	√	√	√	-
	Gasoline	XFV ME747	√	√	√	√	√	-
		3FZ MM6LP	√	√	√	√	√	-
		RFN MM6LP	√	√	√	√	√	-
		RFJ MM6LPB	√	√	√	√	√	-
		3FY MM6LPB	√	√	√	√	√	-



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
Engine ECU	Diesel Engine		6FY MM6LPB	✓	✓	✓	✓	✓	-
			6FZ S2000PM2	✓	✓	✓	-	-	-
			MM6KP Non BioFlex	✓	✓	✓	✓	✓	-
			MM6KP BioFlex	✓	✓	✓	✓	✓	-
			EDC17CP11	✓	✓	✓	✓	✓	-
			9HY BOSCH EDC16C3 EURO3	✓	✓	✓	✓	✓	-
			9HZ BOSCH EDC16C3	✓	✓	✓	✓	✓	-
			4HP BOSCH EDC16CP39	✓	✓	✓	✓	✓	-
			4HR BOSCH EDC16CP39	✓	✓	✓	✓	✓	-
			4HS BOSCH EDC16CP39	✓	✓	✓	✓	✓	-
			4HT BOSCH EDC16CP39	✓	✓	✓	✓	✓	-
			RHL DCM3.4	✓	✓	✓	✓	✓	-
			RHR DCM3.4	✓	✓	✓	✓	✓	-
			RHF DCM3.4	✓	✓	✓	✓	✓	-
			UHZ SIEMENS SID201	✓	✓	✓	✓	✓	-
			RHR SIEMENS SID 803	✓	✓	✓	✓	✓	-
			RHL SIEMENS SID 803	✓	✓	✓	✓	✓	-
			9HT BOSCH EDC16C3	✓	✓	✓	✓	✓	-
			RHH DCM3.5	✓	✓	✓	✓	✓	-
Vehicle protection device/Access Management		Alarm	✓	✓	✓	✓	✓	✓	-
		Driver door module	✓	✓	✓	✓	✓	✓	-
		Passenger door module	✓	✓	✓	✓	✓	✓	-
		Sunroof	✓	✓	✓	✓	✓	✓	-
Active and passive safety	ABS or ESP ECU	ESP EBC 440 (CAN) .	✓	✓	✓	✓	✓	✓	-
		ESP EBC 440 (K) .	✓	✓	✓	✓	✓	✓	-
		ESP 8.1 .	✓	✓	✓	✓	✓	✓	-
Visibility/lighting/signal		Airbag ECU	✓	✓	✓	✓	-	-	-
		ECU Windshield wiper	✓	✓	✓	✓	✓	✓	-
		Rain/brightness sensor	✓	✓	✓	✓	✓	✓	Calibration
		Main discharging bulb	✓	✓	✓	✓	✓	✓	-
		Auxiliary discharging bulb	✓	✓	✓	✓	✓	✓	Calibration



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
		Combination instrument under steering wheel	√	√	√	√	√	—
Driver assist device/Comfort	Vehicle VIN		√	—	—	—	—	—
	Head-up Display		√	√	√	√	√	—
	Vehicle distance keep auxiliary system		√	√	√	√	—	—
	Lane departure warning system		√	√	√	√	√	—
	Air conditioning control unit		√	√	√	√	√	—
	Parking assist		√	√	√	√	—	—
	Electronic booster pump		√	√	√	√	√	—
	Tire pressure detection		√	√	√	√	—	Disable/Enable Tire pressure detection function
	Electronic parking brake		√	√	√	√	√	—
BSI			√	√	√	√	√	Switching operating mode electrical; Self-learning
Notify driver/voice frequency/Communication	voice frequency amplifier		√	√	√	—	√	—
	Multi-Function Display (EMF)		√	√	√	√	√	—
	Combination instrument under steering wheel		√	√	√	√	√	—
	NOMADE unit		√	√	√	√	√	—
	Audio system		√	√	√	√	√	—
	telecommunication	RNEG Audio navigation		√	√	√	√	—
		Radio navigation NG4		√	√	√	√	—
	Service module	Service module		√	√	√	√	—
		telecommunication unit		√	√	√	√	—
	Combination instrument		√	√	√	√	√	—
	Combination instrument Dot matrix Display		√	√	√	√	√	—
	Battery charging state unit		√	√	√	√	—	—
	CD changer		√	√	√	—	√	—
	Warning lights for No fasten(TNB)		√	—	—	—	√	—

5008



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
Engine ECU	Gasoline	5FW MEV17.4 .	✓	✓	✓	✓	✓	✓	-
		5FS MEV17.4 .	✓	✓	✓	✓	✓	✓	-
	Diesel Engine	5FX MED17.4 .	✓	✓	✓	✓	✓	✓	-
		5FV MED17.4 .	✓	✓	✓	✓	✓	✓	-
		5FV MED 17.4.2 Euro5.	✓	✓	✓	✓	-	-	-
		9HZ EDC16C3 .	✓	✓	✓	✓	✓	✓	-
		RHH DCM3.5 .	✓	✓	✓	✓	✓	✓	-
	Transmission	RHE DCM3.5 .	✓	✓	✓	✓	✓	✓	-
		9HL HDI SID807 .	-	-	-	-	✓	-	-
		9HR HDI SID807 .	-	-	-	-	✓	-	-
		CFC300P Transmission	✓	✓	✓	✓	✓	✓	-
		AM6 Euro5 Automatic Transmission	✓	✓	✓	✓	✓	✓	-
	Multiplexing additive pump	AT6 Euro5 Automatic Transmission	✓	✓	✓	✓	✓	✓	-
		Pompe mux MGI	✓	✓	✓	✓	✓	✓	-
	Vehicle protection device/Access Management	Pompe mux TI	✓	✓	✓	✓	✓	✓	-
		Driver side door control panel	✓	✓	✓	✓	✓	✓	-
	Active and passive safety	Alarm	✓	✓	✓	✓	✓	✓	-
		AirbagECU	✓	✓	✓	✓	-	-	-
		ESP8.1	✓	✓	✓	✓	✓	✓	Exhaust
		ASR+switch	✓	✓	-	✓	✓	✓	-
		Network isolation unit							
	Visibility/lighting/signal	Rain sensor	✓	✓	✓	-	-	-	-
		Front wiper	✓	✓	✓	-	✓	-	-
		Front wiper (Parameters measurement )	-	-	-	✓	-	-	-
		Headlight beam regulator	✓	✓	✓	✓	✓	✓	-
	BSI			✓	✓	✓	✓	✓	-
	Multi-functional Display	Multi-functional Display	✓	✓	✓	✓	✓	✓	-
		Auxiliary parking system	✓	✓	✓	✓	-	-	-
		Audio system	✓	✓	✓	✓	-	-	-



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
607	Driver information/Communication	CD changer	✓	✓	✓	✓	✓	—
		Combination instrument	✓	✓	✓	✓	—	—
		Radio telephone	✓	✓	✓	✓	—	—
		Hands-free kits	✓	✓	✓	✓	—	—
		Portable navigation system	Portable navigation system(monochrome)	✓	✓	✓	—	—
			Portable navigation system(Multicolor)	✓	—	—	—	—
		Vision/light	Headlight beam regulator	✓	✓	✓	✓	—
		Door/throttle control	Airbag	✓	✓	✓	—	—
			Electric trunkECU	✓	✓	✓	✓	ECU power supplu
		Air conditioning	Driver door controlsystem	✓	✓	✓	✓	—
			Passenger door central lock system	✓	✓	✓	✓	—
	Active safety system	Air conditioning		✓	✓	✓	✓	—
		ABS BOSCH 5.3	ABS BOSCH 5.3	✓	✓	✓	✓	Exhaust
			ESP BOSCH 5.3	✓	✓	✓	✓	Exhaust;Steering wheel angle sensor calibration;Steering wheel angle sensor not calibrated
			Electronic control suspension	✓	✓	✓	✓	—
		GasolineEngine	3FZ MM4MP2	✓	✓	✓	✓	Adaptive system re-centering
			RFN MM4MP2(Electronic throttle )	✓	✓	✓	✓	Adaptive system re-centering
			RFN MM48P(Mechanical throttle unit )	✓	✓	✓	✓	Adaptive initialization
			R6F MM4.8P	✓	✓	✓	✓	Adaptive initialization
			XFX BOSCH ME7.4.6	✓	✓	✓	✓	Adaptive initialization
		4HX BOSCH EDC15C2	✓	✓	✓	✓	✓	—



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
		Diesel Engine	RHS BOSCH EDC15C2	√	√	√	√	√	—
			RHZ BOSCH EDC15C2	√	√	√	√	√	—
	Diesel fuel additive control unit			√	√	√	√	√	—
	4HP20 Transmission			√	√	√	√	—	Adaptive initialization
	Driver seat position control system(BDM)			√	√	√	√	√	—
607R	Vehicle VIN			√	—	—	—	—	—
	Driver assist device/Comfort	Parking assist	√	√	√	√	√	√	—
		Driver seat position memory unit	√	√	√	√	√	√	—
		Air conditioning	√	√	√	√	√	√	—
		Tire pressure detection	√	√	√	√	—		Disable/Enable Tire pressure detection function
		Power-assisted steering	√	√	√	√	√	√	—
	BSI	Controlled suspension device	√	√	√	√	√	√	—
			√	√	√	√	√	√	Switching operating mode electrical; Self-learning
			√	√	√	√	√	√	
	Notify driver/voice frequency/Communication	Multi-Function Display	√	√	√	√	√	√	—
		Audio system	√	√	√	√	√	√	—
		CD changer	√	√	√	—	√	√	—
		Combiniation instrument	√	√	√	√	√	√	Maintain
		Combiniation instrument under steering wheel	√	√	√	√	√	√	—
		Hands-free kits	√	√	√	√	√	√	—
		telecommunication	√	√	√	√	√	√	—
	Diesel additive control unit			√	√	√	√	√	—
	Transmission ECU	AM6 Automatic Transmission	√	√	√	√	√	√	—
		4HP20 Automatic Transmission	√	√	√	√	√	√	Adaptive initialization
	Gasoline	XFV ME747 .	√	√	√	√	√	√	—
		3FZ MM6LP .	√	√	√	√	√	√	—



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
Engine ECU	Diesel Engine	3FY MM6LPB .	✓	✓	✓	✓	✓	✓	-
		4HX BOSCH EDC15C2 .	✓	✓	✓	✓	✓	✓	-
		RHS BOSCH EDC15C2 .	✓	✓	✓	✓	✓	✓	-
		4HP BOSCH EDC16CP39 .	✓	✓	✓	✓	✓	✓	-
		4HR BOSCH EDC16CP39 .	✓	✓	✓	✓	✓	✓	-
		4HS BOSCH EDC16CP39 .	✓	✓	✓	✓	✓	✓	-
		4HT BOSCH EDC16CP39 .	✓	✓	✓	✓	✓	✓	-
		UHZ SIEMENS SID201 .	✓	✓	✓	✓	✓	✓	-
		RHR SIEMENS SID 803 .	✓	✓	✓	✓	✓	✓	-
		RHL SIEMENS SID 803 .	✓	✓	✓	✓	✓	✓	-
Vehicle protection device/Access Management	Alarm		✓	✓	✓	✓	✓	✓	-
	Electric trunkECU		✓	✓	✓	✓	-	-	-
	Driver door module		✓	✓	✓	✓	✓	✓	-
	Passenger door module		✓	✓	✓	✓	✓	✓	-
Active and passive safety	ABS or ESP ECU	ESP_BOSCH8	✓	✓	✓	✓	✓	✓	Exhaust;Steering wheel angle sensor calibration;Steering wheel
		Airbag ECU	✓	✓	✓	✓	-	-	-
Visibility/lighting/signal	Rain/brightness sensor		✓	✓	✓	-	-	-	-
	Automatic headlamps regulator		✓	✓	✓	✓	✓	✓	-
	Combination instrument under steering wheel		✓	✓	✓	✓	✓	✓	-
Notify driver/voice frequency/Communication	BSI		✓	✓	✓	-	-	-	-
	Alarm		✓	✓	✓	✓	✓	✓	-
	Display / Telematics	AMF	✓	✓	✓	✓	✓	✓	-
		RT3	✓	✓	✓	✓	✓	✓	-
	Audio system		✓	✓	✓	✓	✓	✓	-
	Parking assist		✓	✓	✓	✓	✓	✓	-
	Odometer and warning lamps electronic unit		✓	✓	✓	✓	✓	✓	-
	Combiniation instrument		✓	✓	✓	✓	✓	✓	-



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
807VAN	Information	CD changer	✓	✓	✓	✓	✓	-
		Combination instrument under steering wheel	✓	✓	✓	✓	-	-
	Visibility / lighting	Combination instrument under steering wheel	✓	✓	✓	✓	-	-
		Right headlamp beam corrector	✓	✓	✓	✓	✓	-
		Left headlamp beam level corrector	✓	✓	✓	✓	✓	-
		Airbag ECU	✓	✓	✓	✓	-	-
	Vehicle protection device/Access Management	Driver door module	✓	✓	✓	✓	-	-
		Passenger door module	✓	✓	✓	✓	-	-
		Sliding side door module	✓	✓	✓	✓	✓	-
		Front Sunroof	✓	✓	✓	✓	✓	-
		Rear Sunroof	✓	✓	✓	✓	✓	-
		Center Sunroof	✓	✓	✓	✓	✓	-
	Active and passive safety	ABR BOSCH 5.7	✓	✓	✓	✓	✓	-
		ESP BOSCH 5.7	-	✓	✓	-	✓	-
	Air conditioning	WEBASTO additional heating	✓	✓	✓	✓	✓	-
		Air conditioning	✓	✓	✓	✓	✓	-
	Engine /Automatic Transmission	RFN MM48P	✓	✓	✓	✓	✓	-
		R6F MM4.8P	✓	✓	✓	✓	✓	-
		3FZ MM4MP2	✓	✓	✓	✓	✓	-
		RFN MM4MP2	✓	✓	✓	✓	✓	-
		3FZ MM6LP	✓	✓	✓	✓	-	-
		RFN MM6LP	✓	✓	✓	✓	✓	-
		XFW BOSCH ME746	✓	✓	✓	✓	✓	-
	Diesel Engine	RHW BOSCH EDC15C2	✓	✓	✓	✓	✓	-
		RHM BOSCH EDC15C2	✓	✓	✓	✓	✓	-
		RHT BOSCH EDC15C2	✓	✓	✓	✓	✓	-
		4HW BOSCH EDC15C2	✓	✓	✓	✓	✓	-
	Diesel fuel additive control unit: ADDITIVE EAD		✓	✓	✓	✓	✓	-
	Diesel fuel additive control unit: ADDG02		✓	✓	✓	✓	✓	-
	Automatic	Auto gearbox AL4	✓	✓	✓	✓	✓	-



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu	System	Function					
		Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
	Transmission	Auto gearbox 4HP20	✓	✓	✓	✓	—
	Storing of the driving position		✓	✓	✓	✓	—
	Auxiliary heating device		✓	✓	✓	✓	—
Driver assist device/Comfort	Vehicle VIN		✓	—	—	—	—
	Driver assist device/Comfort	Parking assist	✓	✓	✓	✓	—
		Auxiliary heating device	✓	✓	✓	✓	—
		Driver seat position memory unit	✓	✓	✓	✓	—
		Air conditioning	✓	✓	✓	✓	—
		Tire pressure detection	✓	✓	✓	✓	Disable/Enable Tire pressure detection function
		Power-assisted steering	✓	✓	✓	✓	—
	BSI		✓	✓	✓	✓	Switching operating mode electrical; Self-learning
Notify driver/voice frequency/Communication	Multi-Function Display		✓	✓	✓	✓	—
	Audio system		✓	✓	✓	✓	—
	Indicator light/odometer unit		✓	✓	✓	✓	—
	CD changer		✓	✓	✓	✓	—
	telecommunication receiver control		✓	—	—	✓	—
	Combiniation instrument		✓	✓	✓	✓	Maintain
	Combiniation instrument under steering wheel		✓	✓	✓	✓	—
	Hands-free kits		✓	✓	✓	✓	—
	telecommunication	RNEG Audio navigation	✓	✓	✓	✓	—
		Data Communication ECU	✓	✓	✓	✓	—
Transmission ECU	Diesel additive control unit		✓	✓	✓	✓	—
	BVA_AL4_AT8		✓	✓	✓	✓	Adaptive initialization
	BVA_AM6C		✓	✓	✓	✓	—
	AM6 EURO5 Automatic Transmission		✓	✓	✓	✓	—



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
807 CAN	Engine ECU	Gasoline	RFJ MM6LPB	✓	✓	✓	✓	✓	-
			4HW BOSCH EDC15C2 .	✓	✓	✓	✓	✓	-
		Diesel Engine	RHM BOSCH EDC15C2 .	✓	✓	✓	✓	✓	-
			RHT BOSCH EDC15C2 .	✓	✓	✓	✓	✓	-
			RHW BOSCH EDC15C2 .	✓	✓	✓	✓	✓	-
			RHR SIEMENS SID 803 .	✓	✓	✓	✓	✓	-
			RHL SIEMENS SID 803 .	✓	✓	✓	✓	✓	-
			RHK SIEMENS SID 803 .	✓	✓	✓	✓	✓	-
			4HP EDC16CP39 .	✓	✓	✓	✓	✓	-
			4HR EDC16CP39 .	✓	✓	✓	✓	✓	-
			4HS EDC16CP39 .	✓	✓	✓	✓	✓	-
			4HT EDC16CP39 .	✓	✓	✓	✓	✓	-
			RHH DCM3.5 .	✓	✓	✓	✓	✓	-
			RHD DCM3.5 .	✓	✓	✓	✓	✓	-
		Vehicle protection device/Access Management	Alarm	✓	✓	✓	✓	✓	-
			Sliding side door module	✓	✓	✓	✓	✓	-
			Driver door module	✓	✓	✓	✓	✓	-
			Passenger door module	✓	✓	✓	✓	✓	-
			Front Sunroof	✓	✓	✓	✓	✓	-
			Rear Sunroof	✓	✓	✓	✓	✓	-
			Center Sunroof	✓	✓	✓	✓	✓	-
	Active and passive safety	ABS or ESP ECU	ESP_BOSCH8	✓	✓	✓	✓	✓	Exhaust;Steering wheel angle sensor calibration;Steering wheel angle sensor not calibrated
			ESP 8.1	✓	✓	✓	✓	✓	Exhaust
		Airbag ECU	Rain/brightness sensor	✓	✓	✓	-	-	-
	Visibility/lighting/signal		Right headlamp regulator	✓	✓	✓	✓	✓	-
			Left headlamp height regulator	✓	✓	✓	✓	✓	-



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
BOXER	Engine / Automatic transmission	Combination instrument under steering wheel	√	√	√	√	√	-
		MM4.8P ZL unleaded gasoline	√	√	√	√	√	-
		MM48P 2L essence plombee	√	√	√	√	√	-
		MM48P 2L duel fuel ( LPG )	√	√	√	√	√	-
		2.0L HDI Bosch EDC15C7	√	√	√	√	-	-
		2.2L HDI Bosch EDC15C7	√	√	√	√	-	-
		2.8L HDI Bosch EDC15C7	√	√	√	√	-	-
		TUB EDC16C39	√	√	√	-	-	-
		Parking assist	√	√	√	√	-	-
		Auxiliary heating device	√	√	√	√	-	-
BOXER 3	Driver assist device/Comfort	Air conditioning	√	√	√	√	-	-
		Power-assisted steering	√	√	√	√	-	-
		Air suspension	√	√	√	√	-	-
		BSI	√	√	-	√	-	-
		Notify driver/voice frequency/Communication	Combination instrument	√	√	√	-	-
	Engine /Transmission	Time tachometer	√	√	√	√	-	-
		telecommunication	√	√	√	√	-	-
		4HU PUMA DCU102	√	√	√	√	-	-
		4HV PUMA DCU102	√	√	√	√	-	-
		Sofim 3.0 145cv	√	√	√	-	-	-
	Active and passive safety	SOFIM EDC17CP52	√	√	√	√	-	-
		Sofim 3.0 145cv FAP	√	√	√	-	-	-
		ABS 8.0	√	√	√	√	-	-
		ESP 8.0	√	√	√	√	-	-
		ASR 8.0	√	√	√	√	-	-
	Driver assist device/Comfort	Airbag ECU	√	√	√	√	-	-
		Parking assist	√	√	√	√	-	-
		Auxiliary heating device	√	√	√	√	-	-
		Air conditioning	√	√	√	√	-	-
		Power-assisted steering	√	√	√	√	-	-
		Air suspension	√	√	√	√	-	-



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function						
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark	
BOXER 3 MINIBUS	BSI		√	√	-	√	-	-	
	Notify driver/voice frequency/Communication		Combination instrument	√	√	√	√	-	
			Time tachometer	√	√	√	√	-	
			telecommunication	√	√	√	√	-	
	Engine /Transmission		4HU PUMA DCU102	√	√	√	√	-	
			4HV PUMA DCU102	√	√	√	√	-	
			Sofim 3.0 145cv	√	√	√	-	-	
			SOFIM EDC17CP52	√	√	√	√	-	
			Sofim 3.0 145cv FAP	√	√	√	-	-	
	Active and passive safety	ABS or ESP ECU	ABS 8.0	√	√	√	√	-	
			ESP 8.0	√	√	√	√	-	
			ASR 8.0	√	√	√	√	-	
			Airbag ECU	√	√	√	√	-	
EXPERT	Airbag		Airbag and seat belt tensioner	√	√	√	-	-	
	Engine / Automatic transmission	Gasoline	R6F MM4.8P	√	√	√	√	√	
			RFN MM4.8P	√	√	√	√	√	
	Diesel Engine	Diesel Engine	RHW BOSCH EDC15C2	√	√	√	√	√	
			RHX BOSCH EDC15C2	√	√	√	√	√	
			RHZ BOSCH EDC15C2	√	√	√	√	√	
			WJY LUCAS DCN2	√	√	√	√	√	
		AL4 Adaptive Automatic Transmission	√	√	√	√	√	-	
	Active safety system		BOSCH ABS53	√	√	√	√	√	
	Auxiliary heating device		√	√	√	√	-	-	
..	Vehicle VIN		√	-	-	-	-	-	
	Parking assist		√	√	√	√	√	-	
	Auxiliary heating device		√	√	√	√	√	-	



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
EXPERT 2	Driver assist device/Comfort	Air conditioning	Air conditioning/Front Air conditioning	√	√	√	√	√	-
			Rear Air conditioning	√	√	√	√	√	-
			Power-assisted steering	√	√	√	√	√	-
		Air suspension		√	√	√	√	√	-
	BSI			√	√	√	√	√	Switching operating mode electrical; Self-learning
	Notify driver/voice frequency/Communication	Multi-Function Display		√	√	√	√	√	-
		Audio system		√	√	√	√	√	-
		CD changer		√	√	√	-	√	-
		Combination instrument		√	√	√	√	-	-
		Hands-free kits		√	√	√	√	√	-
		Combination instrument under steering wheel		√	√	√	√	√	-
		telecommunication	RNEG Audio navigation	√	√	√	√	√	-
			Data Communication ECU	√	√	√	√	√	-
	Engine ECU	Gasoline	RFH MM6KP (EW10A) .	√	√	√	√	√	-
			9HU BOSCH EDC16C3-EDC16C34	√	√	√	√	√	-
		Diesel Engine	RHR SIEMENS SID 803 .	√	√	√	√	√	-
			RHL SIEMENS SID 803 .	√	√	√	√	√	-
			RHK SIEMENS SID 803 .	√	√	√	√	√	-
			RHG SIEMENS SID 803 .	√	√	√	√	√	-
			9HT BOSCH EDC16C3 .	√	√	√	√	√	-
			RHH DCM3.5 .	√	√	√	√	√	-
		Transmission ECU	AM6 EURO5 Automatic Transmission	√	√	√	√	√	-
	Vehicle protection device/Access Management		Alarm	√	√	√	√	√	-
			ABS8_BOSCH	√	√	√	√	√	Exhaust



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
M49(BC<09457)	Active and passive safety	ABS or ESP ECU	ESP_BOSCH8	√	√	√	√	√	Exhaust;Steering wheel angle sensor calibration;Steering wheel angle sensor not calibrated
			ABS 8.1	√	√	√	√	√	Exhaust
			ESP 8.1	√	√	√	√	√	Exhaust
		Airbag ECU	Rain/brightness sensor	√	√	√	√	—	—
	Visibility/lighting/signal	Rain/brightness sensor	Combiniation instrument under steering wheel	√	√	√	√	√	—
			BSI	√	√	√	√	√	—
		Notify driver/voice frequency/Communicat	Audio system PHILIPS	√	√	√	√	√	—
	Engine	Gasoline	Audio system CLARION	√	√	√	√	√	—
			CD changer	√	√	√	—	√	—
			Combiniation instrument	√	√	√	√	√	—
			HDY BOSCH MA3.1	√	√	√	√	—	—
			HDZ BOSCH MA3.1	√	√	√	√	—	—
			HFX BOSCH M7.4.4	√	√	√	√	√	—
			KFW SAGEM S2000	√	√	√	√	√	—
			K6D SAGEM S2000	√	√	√	√	√	—
			KFX BOSCH MP7.3	√	√	√	√	√	—
			KFX MM1AP	√	√	√	√	√	—
			KFX SAGEM SL 96	√	√	√	√	√	—
			LFX MM1AP	√	√	√	√	√	—
			N6A BOSCH ME7.4.4	√	√	√	√	√	—
			NFU BOSCH ME7.4.4	√	√	√	√	√	—
			N6A BOSCH ME7.4.5	√	√	√	√	√	—
			N6B BOSCH ME7.4.5	√	√	√	√	√	—
			NFU BOSCH ME7.4.5	√	√	√	√	√	—
		Diesel Engine	RHY SIEMENS SID801	√	√	√	√	√	—
			RHY BOSCH EDC15C2	√	√	√	√	√	—



# FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
Active safety	Diesel Engine	WJY LUCAS DCN2	✓	✓	✓	✓	✓	✓	-
		WJZ LUCAS DCN2	✓	✓	✓	✓	✓	✓	-
	BOSCH ABS5	BOSCH ABS5	✓	✓	✓	✓	✓	✓	-
	BOSCH ABS5.3	BOSCH ABS5.3	✓	✓	✓	✓	✓	✓	Exhaust
	Auxiliary heating device	Auxiliary heating device	✓	✓	✓	✓	✓	✓	-
Notify driver/voice frequency/Communication	Driver assist device/Com	Parking assist	✓	✓	✓	✓	✓	✓	-
		Auxiliary heating device	✓	✓	✓	✓	✓	✓	-
	BSI		-	✓	✓	✓	✓	✓	-
	Alarm		✓	✓	✓	✓	✓	✓	-
	Service module	Stolen vehicle location control unit	✓	✓	✓	✓	✓	✓	-
	Display / Telematics	AMF	✓	✓	✓	✓	✓	✓	-
		RT3	✓	✓	✓	✓	✓	✓	-
	Audio system	Audio system	✓	✓	✓	✓	✓	✓	-
		RED filament	✓	✓	✓	✓	✓	✓	-
	CD changer		✓	✓	✓	✓	✓	✓	-
Visibility / lighting	Combination instrument		✓	✓	✓	✓	✓	✓	-
	Combination instrument under steering wheel		✓	✓	✓	✓	-	-	-
	Airbag ECU		✓	✓	✓	-	-	-	-
	Gasoline	Combination instrument under steering wheel	✓	✓	✓	✓	-	-	-
		Rain/sunlight sensor	✓	✓	✓	-	-	-	-
FCAR F3 Diagnostic List (Note: For reference only)									



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
M59(BC>=09457 &&BC<=09478)	Engine	Diesel Engine	KFW BOSCH ME749 BIO FLEX	✓	✓	✓	✓	✓
			KFW J34P	✓	✓	✓	✓	✓
			RHY SIEMENS SID801	✓	✓	✓	✓	✓
			RHY SIEMENS SID801	✓	✓	✓	✓	✓
			WJY LUCAS DCN2	✓	✓	✓	✓	✓
			9HW BOSCH EDC16C3	✓	✓	✓	✓	✓
			9HX BOSCH EDC16C3	✓	✓	✓	✓	✓
			9HT BOSCH EDC16C3	✓	✓	✓	✓	✓
			9HJ EDC17C10_BR2-92 CV	✓	✓	✓	✓	✓
			9HK EDC17C10_BR2-75 CV	✓	✓	✓	✓	✓
		LPG/Gnv	9HE EDC17C10_BR2-89 CV .	✓	✓	✓	✓	✓
			SAGEM SAX500	✓	✓	✓	✓	✓
			BOSCH ABS5.3	✓	✓	✓	✓	✓
			ABS BOSCH 8	✓	✓	✓	✓	✓
			ESP BOSCH 5.7	✓	✓	✓	✓	✓
	Active safety system	ESP BOSCH 8	ESP BOSCH 8	✓	✓	✓	✓	✓
			ESP BOSCH 8	✓	✓	✓	✓	✓
			ABS 8.1	✓	✓	✓	✓	✓
		ESP 8.1	ESP 8.1	✓	✓	✓	✓	✓
			ABS 8.1	✓	✓	✓	✓	✓
Driver	Vehicle VIN		✓	-	-	-	-	-
	Parking assist	Parking assist	✓	✓	✓	✓	-	-
		Air conditioning	✓	✓	✓	✓	✓	-



## FCAR F3 Diagnostic List (Note: For reference only)

Automaker:	Peugeot
Version:	v7.4

Menu		System	Function					
			Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
PARTNER B9	Driver assist device/Comfort	Tire pressure detection	✓	✓	✓	✓	-	Disable/Enable Tire pressure detection function
		Power-assisted steering	✓	✓	✓	✓	✓	-
	BSI		✓	✓	✓	✓	✓	Switching operating mode electrical; Self-learning
	Notify driver/voice frequency/Communication	Multi-Function Display (EMF)	EMF_A	✓	✓	✓	✓	-
		EMF_C	✓	✓	✓	✓	✓	-
		Audio system		✓	✓	✓	✓	-
		Combination instrument		✓	✓	✓	✓	-
		CD changer		✓	✓	✓	-	✓
		Hands Free Kits		✓	✓	✓	✓	-
		Switch unit under steering wheel		✓	✓	✓	✓	-
		telecommunication	RNEG Audio navigation	✓	✓	✓	✓	-
		Battery charge status unit		✓	✓	✓	-	-
	independent telematic unit		✓	✓	✓	✓	✓	-
	Engine	Gasoline	N6A ME745	✓	✓	✓	✓	Adaptive initialization
			N6B ME745	✓	✓	✓	✓	Adaptive initialization
			NFU ME745	✓	✓	✓	✓	Adaptive initialization
			NFR ME745	✓	✓	✓	✓	Adaptive initialization
			5FS MEV17.4	✓	✓	✓	✓	-
			5FK MEV17.4	✓	✓	✓	✓	-
		DIESEL	9HT DV6	✓	✓	✓	✓	-
			9HT EDC16C3	✓	✓	✓	✓	-
			9HX EDC16C3	✓	✓	✓	✓	-
			9HZ EDC16C3	✓	✓	✓	✓	-
			9HS EDC16C3	✓	✓	✓	✓	-
			9HV EDC16C3	✓	✓	✓	✓	-

Automaker:	Peugeot
Version:	v7.4

Menu			System	Function					
				Version Info.	Read DTC	Clear DTC	Read Data	Action test	Remark
Diesel Engine	9HW EDC16C3 9HP EDC17C10_BR - 92 CV . 9HN EDC17C10_BR2 - DV6ETED 9HF EDC17C10_BR2 - 89 CV . 9HK EDC17C10_BR2- 75 CV 9HE EDC17C10_BR2 - 89 CV . 9HL HDI_SID807	9HW EDC16C3	✓	✓	✓	✓	✓	-	
		9HP EDC17C10_BR - 92 CV .	✓	✓	✓	✓	✓	-	
		9HN EDC17C10_BR2 - DV6ETED	✓	✓	✓	✓	✓	-	
		9HF EDC17C10_BR2 - 89 CV .	✓	✓	✓	✓	✓	-	
		9HK EDC17C10_BR2- 75 CV	✓	✓	✓	✓	✓	-	
		9HE EDC17C10_BR2 - 89 CV .	✓	✓	✓	✓	✓	-	
		9HL HDI_SID807	✓	✓	✓	✓	✓	-	
	multiplexe d additive adding	Pompe mux MGI	✓	✓	✓	✓	✓	-	
		Pompe mux TI	✓	✓	✓	✓	✓	-	
Gearbox ECU	CFC300P	Alarm	✓	✓	✓	✓	✓	-	
		Vehicle protection / Management of accesses	✓	✓	✓	✓	✓	-	
	Active safety system	Airbag	✓	✓	✓	✓	-	-	
		ABS or ESP ECU	✓	✓	✓	✓	✓	Exhaust	
		ESP8.1	✓	✓	✓	✓	✓	Exhaust	
	Visibility/lighting/signal	Rain/brightness sensor	✓	✓	✓	-	-	-	
						-	-	-	

Remark: ✓ means the system has this function - means not