Daihatsu

GIT Vehicle Coverage Table

As of July. 1st. 2013

Connector Type	System	Sub System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	CVT ECU Initial Learning	Radar Cruise Optical Adjustment	Secondary Repair Air Bleeding Drive	Roof ECU Initailization
16PIN Connector	EFI(Engine)	Type 1	V	V	V					
		Type 2	V	V	V	V				
	AT		V	V	V					
	CVT	Type 1	V	V						
		Type 2	V	V		V	V			
	eco IDLE		V		V	V				
	ERS(Idle Stop)		V			V				
	POWER(PUSH START)		V							
	ACC(Adaptive Cruise Control)		V					V		
	IMG(Lane Keeping Assist)		V			V				
	DSS(Precrash Safefy System)		V			V				
	ABS		V	V	V				V	
	ABS/VSC		V	V	V	V				
	DVS(Daihatsu Vehicle Stability control system)		V	V	V					
	4WD(4 Wheel Drive)		V	V						
	EPS(Electric Power Steering)	Type 1	V							
		Type 2	V	V						
	SRS AIRBAG		V							
	ITC(Intergrated Timer Control)		V	V	V					
	Immobilizer		V							
	KFS(Key Free System)		V	V	V					
	Roof		V	V	V					V
	Pre-crash Seat Belt(Driver Seat)		V			V				
	Pre-crash Seat Belt(Passenger Seat)		V			V				
	Meter		V		V	V				

This document is provided for your reference only.
Do not disclose to a third party without prior written consent of GIT.